

FunLux

NVR Manual

1	Before using this product.....	1.1
1.1	Understanding the manual	1.1
	How this manual is organized	1.1
	Manual Conventions	1.2
1.2	Safety Precautions.....	1.3
1.3	Minimum Requirements	1.3
2	Product Introduction	2.1
2.1	Product Overview	2.1
2.2	Technical Specifications	2.2
	NVR (ZP-NE14-S).....	2.2
	IP Camera (ZP-IBT15-S).....	2.3
2.3	Package Contents.....	2.4
2.4	Getting Familiar with your NVR.....	2.6
	Main Functions & Features.....	2.6
	Front Panel	2.7
	Rear Panel.....	2.7
	Mouse	2.8
3	First-time Setup	3.1
3.1	NVR Installation.....	3.1
	HDD Installation.....	3.1
	Connecting your NVR.....	3.5
	Connecting an External Alarm	3.6
3.2	Camera Installation	3.6
	Connecting the cameras to the NVR.....	3.6
	Mounting the Camera	3.9
3.3	NVR First-Time Startup.....	3.10
	Startup Guide Explained	3.11
3.4	Home Screen Introduction.....	3.12
	Main Menu	3.13
	New Notification.....	3.13
	Single View.....	3.13
	Quad View	3.13
	Playback	3.13
	Logout / Shutdown.....	3.13
4	Using the NVR.....	4.1
4.1	Main Menu Detailed.....	4.1
	General Settings.....	4.1
	Device Management	4.8
	Network Settings	4.11

Event Management.....	4.13
4.2 Camera Controls	4.18
Image Setting.....	4.18
Zoom	4.19
Playback	4.20
4.3 Remote-viewing Setup	4.22
4.4 Updating your NVR.....	4.26
From your NVR (via USB).....	4.26
5 Support	5.1
5.1 Troubleshooting.....	5.1
5.2 Warranty.....	5.3
5.3 Funlux Support	5.7

1 Before using this product...

1.1 Understanding the manual

How this manual is organized

This manual is specifically organized to provide comprehensive instructions for full setup and basic operation of your NVR when read front-to-back. The contents of the manual are conveniently organized for quick reference after you have read through the entire manual. For further instructions, please visit our knowledge base at <http://kb.zmodo.com/> or our website at <http://www.zmodo.com/support-software>.

- **Chapter 1 Before using this product...**

This chapter contains important information prior to reading the manual and installing the system. It overviews the manual purpose and conventions to aid in installation, and covers minimum system requirements to ensure successful setup and use. It is essential that you read this chapter before reading the manual and installing the system.

- **Chapter 2 Product Introduction**

This chapter describes the package contents and overviews some of the features and capabilities of the NVR system.

- **Chapter 3 First-time Setup**

This chapter covers the initial setup procedures of the NVR. This includes hardware setup procedures such as NVR wiring, HDD installation, alarm installation and camera installation. It also covers basic setup procedures to configure your NVR when setting it up for the first time.

- **Chapter 4 Using the NVR**

The NVR's full features can be utilized through the new and revolutionary user-friendly menu system. This chapter covers detailed instruction on the functions and navigation of each menu element, use of the camera control interface, live remote-viewing setup, and firmware update procedures for the NVR and IP cameras. Refer to this chapter for specific instructions for advanced functions of the NVR.

- **Chapter 5 Support**

This chapter covers common troubleshooting issues that can be easily resolved, warranty information, and information for Funlux support and other resources. Please refer to this chapter before calling technical support.

Manual Conventions

This manual uses several symbols, typographies and abbreviations that carry specific definitions. In order to properly follow instructions, please familiarize yourself with the following conventions.

[Text]	Text enclosed in square [brackets] indicates a menu or an item to select.
IMPORTANT:	Denotes information or instructions that you MUST follow to complete instructions.
NOTE:	Denotes additional information or tips to aid you in completing instructions.
NVR	Abbreviation for network video recorder. This is the main control component of your system.
IPC	Abbreviation for internet protocol camera. These are the recording and surveillance devices attached to the system.
HDD	Abbreviation for hard disk drive. This is the storage component of your NVR system.
sPOE	Abbreviation for simplified power over Ethernet. The Ethernet cables are able to carry data and power to the cameras.

1.2 Safety Precautions

Please read and follow these instructions for your safety while operating and setting up the equipment.

- Use only the provided power adapter to power the NVR.
- Do not insert any objects into the NVR case or openings.
- Do not place heavy objects on top of the NVR.
- Keep the NVR surfaces clean and dry.
- Do not operate in wet or dusty environments.
- Keep the NVR away from all fluids.
- Operate and keep the NVR in temperatures between -10°C~50°C.
- Do not install the NVR near any heat sources and avoid direct sunlight.
- Make sure there is good air circulation where the NVR is installed.
- Install the NVR in a stable environment.
- Handle the NVR carefully and avoid collisions and strong falls.

1.3 Minimum Requirements

Minimum requirements must be met for full and proper functionality of the NVR.

- External display with VGA input and VGA cable.
- A wireless router with one empty port (for remote viewing).
- A physical internet connection such as Cable / DSL / Fiber—no satellite, 3G/4G hotspots, or city-wide wireless (for remote viewing).
- A minimum upload speed of >256kbps at the location of the NVR (for remote viewing).
- Android (v.2.3 and up) or iOS (v.5 and up) mobile device (for remote viewing).

2 Product Introduction

2.1 Product Overview

This Funlux NVR system is specially designed to safeguard your home or business by providing cutting-edge video surveillance and monitoring. With a 2.8mm wide-angle lens and full 720p high definition video, the security cameras are able to monitor more space in greater detail. The 24 infrared LEDs eliminate low light problems, capturing HD videos from up to 80ft away. Instant email notifications and multiple live streaming and recording options make your NVR available and accessible anywhere at anytime.

Using next generation plug-and-play technology and a revolutionized user interface, this system delivers a revolutionarily user-friendly experience that is accessible to anybody. Achieving security and peace of mind has never been easier. With top products at low prices and setup procedures that anybody can follow, our goal is to bring security and safety to all people; making *your* security *our* priority.



2.2 Technical Specifications

NVR (ZP-NE14-S)

Video Input / Output

IP Video Input	4 Channel
VGA Output	1 channel
Recording Resolution	720P
Compression	H.264
Record Rate	100fps
Multi screen Display	1024x768@60Hz, 1280x1024@60Hz
Record Mode	Constant / Alarm Triggered / Motion Detect
Playback Options	Fast forward / Rewind / Slow motion

Hard Disk Drive

Interface Type	1 SATA (3.5")
Capacity	Up to 2TB

External Interface

Network Interface	1 RJ45 10M/100M self-adaptation & 4 independent 10/100 Mbps Ethernet interfaces
USB Interface	2 USB 2.0 inputs
Alarm Inputs / Output	4 channel sensor inputs / 1 channel alarm output

General

Application Support	Remote configuration, video browsing, local recording, local and remote playback
Motion Detection	Yes
Protocol Support	P2P, TCP/IP, UDP, DNS/DDNS, SMTP, UPNP, DHCP, HTTP, etc.
Alarm Notification	Yes
Operation System	Linux-based
Power Supply	DC 19V, 3A
PoE ports	4
Power consumption	<12W (without hard disks)
Operating Temperature	-10 °C to 50 °C
Dimensions	220 x 205 x 42mm (8.6" x 8.1" x 1.7")
Weight	1.49lbs (without HDD)
Language Support	11 languages

IP Camera (ZP-IBT15-S)

Camera

Image Sensor	¼" color CMOS sensor
Minimum Illumination	0.1 Lux (IR LED On) / F 1.2
Shutter Speed	Auto
Lens	2.8mm
Viewing Angle	90°
Night-Vision	Electronic (IR-CUT with auto switch)

Compression Standard

Video Compression	H.264
Bit Rate	16Kbps~2Mbps
Dual Stream	Yes

Image

Image Resolution	720P (1280x720), VGA (640x480), QVGA (320x240)
Frame Rate	25fps real-time
White Balance	Auto
Backlight Balance	Auto
Image Setting Options	Brightness, contrast, saturation

Network

Alarm Trigger	Intelligent motion detection
Alarm Response	Email notification, video recording, snapshot, buzzer
Network Protocols	TCP/IP, UDP, DNS/DDNS, SMTP, UPNP, DHCP, HTTP, etc.
ONVIF	ONVIF Ver. 2.0
Wireless	No
Security	User authentication, software encryption

Interface

Communication Interface	RJ45 10 / 100M self-adaptive
-------------------------	------------------------------

General

User Management	Multi-level user management, support up to 16 users
Weather proof	IP65
WDR	No
Operating Temperature	-10 °C to 50 °C
Color / Material	White / Aluminum
Power Supply	Simplified Power over Ethernet (sPoE)
Power Consumption	2W~4W
IR Distance	Night visibility up to 20m (60ft)
Dimensions	52 x 52 x 72mm (2.1" x 2.1" x 2.8")
Weight	0.44lb

2.3 Package Contents

Before proceeding with any setup procedures, please make sure that your package includes the following contents:



- (4) 720P Bullet IP Network Cameras (ZP-IBT15-S)
- 4-Channel Security NVR (ZP-NE14-S)
- (2) 15m (50ft) Camera sPoE Cables
- (2) 25m (80ft) Camera sPoE Cables
- 1m (3ft) CAT5e Network Cable
- USB Mouse
- IR Remote Control & AAA batteries
- 19V 3A Power Adapter
- Quick Installation Guide
- (4) Wall Mount Screw Packets
- 1TB HDD Pre-Installed*

*Included only in systems purchased specifically with an included HDD.

2.4 Getting Familiar with your NVR

Main Functions & Features



Live Remote Viewing

Access your NVR remotely from anywhere in the world on your Android or iOS mobile device.



Intelligent Recording Mode

Intelligent recording identifies surveillance footage triggered by critical events such as motion detection and alarm triggering and optimizes storage by increasing recording quality when a critical event occurs.



Multitasking

Users can view, record, playback, backup, live-view and remotely access the NVR simultaneously from multiple devices.



Instant Notification & Alarm System

Receive instant email alerts and push notifications with snapshots to your mobile device when motion is detected, an alarm is triggered, or video loss occurs.




Multi-level, Multi-user management

Different user privileges allow you to share video surveillance without worrying about unpermitted setting changes.

Front Panel



Rear Panel



Mouse

-Confirm selection in menus
-Select or de-select boxes
in menus

Scroll through pull-down
menus



Return to previous operation
or exit operations

3 First-time Setup

3.1 NVR Installation


HDD Installation

IMPORTANT: Your system will not be preinstalled with a hard disk drive (HDD) unless the system was specifically purchased with an included HDD. You may install a **SATA HDD** between **250GB** and **2TB** of storage after receiving your system. We recommend **Western Digital Caviar Green AV-GP** hard drives or **Seagate Pipeline** hard drives that are specifically engineered for use in security camera environments. We also suggest that you make your purchase from an official reseller (such as Newegg.com, Tiger-Direct, and Best Buy) to ensure the quality of the HDD.


For the following HDD installation instructions, you will need:

- 1) Your NVR system
- 2) A SATA Hard Drive (not provided)
- 3) 4 silver Phillips screws (provided)
- 4) 5 black Phillips screws (provided)
- 5) A Phillips screwdriver (not provided)

1. Make sure your NVR is unplugged from its power source and slide the top panel off of the NVR.




2. Connect the SATA power and data cables from the NVR to the corresponding ports on your HDD (as shown):




3. Once connected, place the HDD into the NVR with the cables placed as shown.




4. Holding the hard drive and the NVR, gently turn it over and line up the holes on the hard drive with the holes on the NVR. Using a Phillips screwdriver, screw the provided screws into the holes.




5. Slide the NVR panel back on and locate the 5 black Phillips screws (found in kit). Apply the screws in the three holes on the back panel, and the two holes on the sides.




6. When you power on your system, you will see a popup asking you to format your HDD. Press [OK] and wait 5-10 minutes. NOTE: If you do not see this popup, please manually format your HDD by going to the *Disk Drive Info* page (for more instructions, please refer to **4.1 Main Menu Detailed**).



7. The system will begin formatting the HDD, and will automatically reboot once the formatting is complete.



Connecting your NVR




1. Connect your IP cameras directly to the system with the provided PoE cables as shown. Please refer to **3.2 Camera Installation** for specific instructions.
2. Connect your display to the VGA input on the system as shown.
3. Connect your system to a nearby power outlet with the provided power adapter as shown.
4. Connect your USB mouse to the corresponding input as shown.
5. Connect your NVR system to your wireless router with the provided Ethernet cable as shown.

Connecting an External Alarm

NOTE: A large portion of the installation of an alarm will vary based on the type of alarm. Because of this, the following instructions are not comprehensive, and will have to be supplemented by specific instructions for your desired external alarms/systems. Please refer to our knowledge base (<http://kb.zmodo.com/>) for more information.

Prior to installation, please locate the alarm input and output ports on the back panel of your NVR. The following instructions will show you how to plug in the wires from the external system to the NVR.




1. Push the orange tab on the alarm port (with your finger nail or pen) in order to open the spring-loaded connection.
2. With the orange tab pushed in, insert the bare wire from your alarm about 1/8-1/4 inches into the port.
3. Let go of the orange tab and the port should clamp onto the cable. Give the wire a light tug to ensure that it is securely clamped.


3.2 Camera Installation


Connecting the cameras to the NVR

1. Remove the cameras from the packaging and set it near the NVR.
2. Connect all four cameras to the NVR using the provided PoE cables by plugging one end to the Ethernet port of the cameras and one end to the port on the back of the NVR.


3. Power on and login to your NVR using the default user 'admin' and the default password '111111'. Once you have logged in, your system will attempt to add your cameras automatically. Please wait 3-5 minutes for this process to complete. If your system has not automatically added the cameras, proceed to step 4 for manual setup.



4. Access the main menu [] by moving your cursor to the bottom left of your screen. When the main menu appears, select and open the [Device Management].



5. Click the [Add Device] option on the left, then click [Auto Add] to automatically search for IP cameras. Please wait 3-5 minutes for the system to automatically add all of the cameras.



6. Once you see a live video stream, your setup is complete! If you were unable to perform any of the steps, please refer to **5.1 Troubleshooting** in the user manual.



Mounting the Camera

IMPORTANT: Please complete the instructions for "Connecting the cameras to the NVR" prior to mounting your cameras.

The following steps provide instructions to mount the camera on a drywall.

You will need:

- 1) IP camera
- 2) Mounting bracket (provided)
- 3) 3 screws with 3 anchor screws (provided)
- 4) Power drill (not provided)

1. Choose a location. Find a suitable location to mount your IP camera.

2. Mark screw locations. Using a pencil and the holes in the mounting bracket as a guide, mark three holes against the wall where you wish to mount the camera.

3. Drill holes. With a drill bit slightly smaller than the green plastic anchor screw, drill a 1" deep hole in each of the three marked locations.

4. Insert anchor screws. Place the anchor with the closed end evenly into the hole. Gently tap the open end until the anchor is almost flush with the wall.


5. Attach the camera to the mounting bracket. Fasten your camera to the mounting bracket using either the hole found on the top or bottom of the camera. Rotate until the camera is securely attached to the mounting bracket.

6. Mount the camera to the wall. Align your mounting bracket with the anchors and slowly screw the bracket onto the wall with the 3 screws provided.

7. Adjust the camera position. To adjust the camera position, loosen the nob on the bracket by turning it counterclockwise and adjust the camera accordingly. When the desired camera position is achieved, tighten the nob by turning it clockwise.


3.3 NVR First-Time Startup

Power on your NVR and double-click anywhere on the screen. On the login screen, a Startup Wizard will appear to help you quickly setup your NVR. Please follow the on-screen instructions to quickly and easily configure basic settings on your NVR.



Startup Guide Explained

Network Time Protocol: When enabled, the NVR system will automatically set the date and time settings through the internet connection. If you do not enable this, you will need to manually input the date and time in the corresponding forms.




The screenshot shows a 'Startup Guide' dialog box with the following settings:

- Enable NTP (Network Time Protocol)
- System Time: 04 - 24 - 2014 12 : 20 : 12
- Date Format: MM-DD-YYYY
- Time Format: 12 Hour
- Language: English

Buttons: Back, Next

Name, phone, email: This information is added to the default administrator account of your NVR system.




The screenshot shows a 'Startup Guide' dialog box with the following information:

- Name: zmodo
- Phone: 5551234567
- Email: zmodo@email.com

Buttons: Back, Next

3.4 Home Screen Introduction

The home screen is the main screen of your NVR, displaying the live-video stream from the connected cameras. There are several viewing options available locally on your NVR. By default it will be set to the quad-screen view with the live-video streams from all four camera feeds. To access the new **quick-menu**, move your cursor to the bottom of the screen using your mouse or press the menu button on your remote.




The quick-menu includes the following options:



Main Menu

Use the main menu to access all of the full features of the NVR. Refer to **4.1 Main Menu Detailed** for more information and specific instructions.



New Notification

When your NVR has an update or an urgent message (i.e. missing HDD, motion detection, alarm triggering, etc.) a notification will appear in your quick-menu. Click on the new notification icon to view more details.



Single View

This option enables you to quickly view one camera feed in full-screen. Click on the icon to select the camera feed to view. For further live-video viewing options, refer to **4.1 Main Menu Detailed – General Settings – Display Settings**.



Quad View

Quickly toggle the viewing mode to four simultaneous channel feeds.



Playback

Review and backup surveillance footage from this menu. Refer to **4.2 Camera Controls** for more details.



Logout / Shutdown

Logout of your current user profile or shutdown the system. Administrator permission will be required to shutdown.

4 Using the NVR

4.1 Main Menu Detailed


Use the main menu to access all of the full features of the NVR. The following chapter will explain how to navigate and perform the features through the menu.

General Settings

Use the General Settings menu to manage accounts, change the date & time, change the live-video streaming options and settings, view the system events log, view hard disk information, view and upgrade your firmware and restore your device to factory settings.

Account Management

This NVR supports multiple user profiles with different permissions, which allow you to share video surveillance without worrying about unpermitted tampering with the system settings, playback files, etc.



The system can support up to 16 accounts, with two different account types:


Administrator: Has full access to all features of the NVR and full permission to change all settings.

Operator: Can only view the live-video stream.

Managing your user accounts by simply highlighting a user account from the menu and selecting a function to perform.

Date & Language

Use this menu to change the date & time settings and the language settings of your NVR.




NTP Enabling the Network Time Protocol (NTP) allows the system to automatically set the date and time of your system. This requires an internet connection.

Sync Camera Time The NVR will automatically update your camera's date and time settings to match that of your NVR.

Language Choose a different language for your NVR system to display.

Display Settings

The NVR offers several options to best customize the content displayed on the home-screen of your NVR.



Channel Select a channel display to customize. Each channel can display a specific channel name and the current time.

IMPORTANT: When changing the settings on a channel, press [Save] before editing another channel or exiting the page otherwise all changes will be lost.


Channel Name You may set a name to describe the camera feed on your NVR. For example, if you have set up a camera in the front yard on channel 1, you could name it "Front Yard".

Channel Time Select this option to display the current date and time on the channel feed.

Enable Auto Sequence Selecting this option will activate sequential viewing. In sequential viewing, the NVR will automatically cycle between certain channel feeds. You may change the duration of each sequence and select which feeds to cycle through under this menu.

System Log

The NVR will provide notifications when certain events occur. Such events could be, but are not limited to: a missing hard drive or hard drive failure, activated motion sensors, activated alarms, etc. Use this menu to review the system log of all event notifications.



The screenshot shows the 'General Settings' window with the 'System Log' menu item selected. The interface includes a 'Type' dropdown menu set to 'alarm log', a 'Date' field showing '2014 - 04 - 28', and a 'Search' button. Below these controls is a table with the following data:

Series	Type	Start Time	Event
01	Alarm	07:36:58	Mo 01 alarm
02	Alarm	07:36:58	Mo 02 alarm
03	Alarm	07:36:58	Mo 04 alarm
04	Alarm	07:36:59	Mo 03 alarm
05	Alarm	07:37:22	Mo 01 alarm
06	Alarm	07:38:49	Mo 02 alarm
07	Alarm	07:48:17	Mo 01 alarm
08	Alarm	07:48:35	Mo 01 alarm
09	Alarm	07:48:42	Mo 01 alarm
10	Alarm	07:48:58	Mo 01 alarm

Series Numbers the events in sequence


Type Describes the type of notification (Alarm / System)

Start Time The time when the event occurred.

Event Gives detailed description of the notification, e.g. Mo = Motion; 02 = motion captured on channel 2; alarm = type of notification.

Disk Drive Info

This menu allows you to review important HDD information, format HDD's and change it's settings.



Hard Disk Drive Full Defines how the NVR will behave when the HDD is full. When the HDD has reached its storage capacity, the NVR will either stop recording or overwrite the older playback files. The overwrite feature is generally recommended.

Refresh Update the HDD information shown on the page.


Total Space The total available storage space on the HDD in the NVR.

Free Space The amount of storage space left on the HDD in the NVR.

Format In order to format a drive, select it from the menu and press [Format]. The system will automatically format the HDD.

System Settings

Use this menu to view and change basic settings and information of the NVR. From this menu, you may enable the startup guide, change the display resolution, view system information, upgrade the NVR firmware and reset the system to factory default settings.




Startup Guide Check this box to enable the startup guide to appear (refer to **3.3 NVR First-time Startup**). The startup guide will appear the next time the system is powered on.

Please refer to the following instructions to upgrade the firmware from the system (required: a USB drive).

1. Download the updated firmware from the website on your computer.
2. Place the file onto the root directory of a USB drive.
3. Connect the USB drive to the USB port on your NVR.
4. Go to the [General Settings] menu in the Main Menu and access the [System Settings] page.
5. Select [Upgrade] and wait 5-10 minutes.

Help & FAQ


Funlux offers comprehensive support for our users. This page provides links to some of our resources that will help guide you to a maximal experience of our products.



Device Management

Use the Device Management menu to manage the IP cameras connected to the NVR.

Add Device



Search and Add All Devices Automatically Check this box to enable the automatic search and add functions of the NVR. If there are empty channels, the NVR will automatically search and add nearby cameras. Please wait 3-5 minutes for this process to be completed.

Search for Devices Select to search for devices with the same protocol. A pull up menu will appear for you to manually select the devices to add.

Auto Add Will prompt the system to automatically search for and add devices.

Add Device Manually Allows you to add a specific device by inputting the MAC address and port information.

Refresh Refresh the page to update camera information.

Delete Device Select a channel and press [Delete Device] to remove the camera assigned to the corresponding channel.


Adding a device:

You will have four options different methods to add a device:

- 1) The system will automatically search for and add devices if you leave the [Search and Add All Devices Automatically] option selected.
- 2) Prompt the system to automatically search for and add devices by selecting [Auto Add].
- 3) Press [Search for Devices] to open a list of available cameras and manually select the desired cameras to add to the system.
- 4) Press [Add Device Manually] to add the device by inputting the specific MAC address of the connected camera.

Video Stream Settings

Adjusts the video quality, frame rate, resolution and streaming bit rate



Channel Choose the channel that you would like to change the settings for.

IMPORTANT: When changing the settings on a channel, press [Save] before editing another channel or exiting the page otherwise all changes will be lost.

Local Video Stream Changes the video streaming settings for devices that are connected to the NVR locally (devices that are connected to the same internet connection as the NVR).

Network Transmission Stream Changes the video streaming settings for devices that are connected to the NVR remotely (devices that are connected through 3G/4G or a different internet connection than the NVR).

Video Quality Change the overall quality of the video. Increasing the quality also increases the bandwidth used.

Frame Rate (FPS) This changes the number of pictures (frames) per second that make up the video stream. The higher this value, the smoother and better the video quality is, however increasing this value also increases the bandwidth.


Resolution Change the resolution of the video stream. QVGA=320x240.

Streaming Bit Rate This is the type of bit rate that the NVR uses to view video from the camera. VBR stands for the variable bit rate, and CBR stands for the constant bit rate—CBR is higher quality than variable, however it uses more bandwidth.

Video Mask

The NVR allows you to mask / hide certain areas of your camera feed from recording and monitoring.

To create an area to mask you must first select the channel to edit and check [Enable]. Select an area by clicking and dragging down and to the right with your cursor. A gray box will appear. Remove the selected areas by right-clicking on the box. After you are done, press [Save] and proceed to other channels or return to the home-screen.




Network Settings

Basic Settings

Selecting *DHCP* will allow the NVR to manually configure the IP address and network parameters.

The settings on this page enable access to the NVR over the internet. Unless you are an advanced user, we do not recommend that you change these settings. These definitions are not sufficient for manual networking and configuration.



The screenshot displays the 'Network Settings' window with a sidebar on the left containing 'Basic Settings', 'DDNS', and 'UPNP'. The main area is titled 'Basic Settings' and includes a 'DHCP' checkbox which is checked. Below this are several input fields: 'IP Protocol' (set to 'IPv4'), 'IP Address' (192.168.1.132), 'Subnet Mask' (255.255.255.0), 'Gateway' (192.168.1.1), 'Preferred DNS' (8.8.8.8), 'Alternate DNS' (202.96.134.133), 'MAC Address' (04-5c-06-05-2b-93), 'Web Port' (00080), 'Video Port' (08000), and 'Mobile Port' (09000). At the bottom right, there are 'Default' and 'Save' buttons.


Web Port This designates the port used when accessing the NVR through a web browser.

Video Port This designates the port that the video feed is transmitted over.

Mobile Port This designates the port used when accessing the NVR through a smart phone or mobile device.

DDNS


NOTE: For advanced users only. Router port-forwarding is required. Use this page to set up a DDNS (Dynamic DNS Server) for remote surveillance, please refer to the knowledge base for full instructions.



The screenshot shows the 'Network Settings' window with the 'DDNS' tab selected. The 'On' toggle is checked. The 'Server' dropdown menu is set to 'ztnoddns'. Below it are input fields for 'Domain', 'Account', and 'Password'. A 'Save' button is located at the bottom right.

UPNP

UPNP (Universal Plug and Play) is a protocol used to establish network connectivity and interaction between devices. Enabling this feature will allow easier network connectivity.



The screenshot shows the 'Network Settings' window with the 'UPNP' tab selected. The 'On' toggle is checked. Below it are three input fields for 'Web Mapping Port' (15995), 'Video Mapping Port' (15996), and 'Mobile Mapping Port' (15997). A 'Save' button is located at the bottom right.

NOTE: The UPNP settings for the device are not the same as the UPNP settings on your router and do not pose the same security risks.


NOTE*: For advanced users only. We do not recommend that you change any settings under this page without prior networking knowledge.

Event Management

This NVR system is specialized for 24/7 continuous recording, and will automatically mark recordings that are triggered by "critical events" (motion detection and alarms) in the playback menu. Use this menu to define "critical events" and best optimize recording and storage on the system.

Record Mode

The system has two available recording modes:




The **basic recording** profile will record continuously at full frames. This means that all recorded video files will be high quality, and the HDD will be able to store less footage at one time.

The **intelligent recording** profile will automatically manage the recording to optimize storage capacity. During scenes of interest when "critical events" are triggered, the NVR will automatically record in full frames to ensure higher

quality. During stationary scenes, the NVR will record at a lower framerate to optimize storage capacity.

Motion Detection

This NVR supports advanced motion detection features for bolstered security. Please follow the following instructions in order to properly configure and setup the motion detection functions.



IMPORTANT: When changing the settings on a channel, press [Save] before editing another channel or exiting the page otherwise all changes will be lost.

1. Choose a channel to edit. Select a channel under the dropdown menu next to [Channel] and select the box next to the channel in order to turn on motion detection.

2. Customize schedules for motion detection. The NVR allows you to set up to 4 different time periods for motion detection. To activate a time period, input the desired values and select the box to the right of the corresponding time period.

- a. You can either manually configure a schedule for each day by selecting the day in the [Week] dropdown menu, or you can apply the schedule to multiple days at once by selecting [Apply to].

b. Once changes have been made, always press [Save] before navigating to another page or editing schedules for another day otherwise the changes will be lost.

3. Select the motion detection area. Using the motion detection grid, define a motion detection area by left-clicking on a square. Click-and-drag to toggle large areas. You may adjust the sensitivity of the motion detection with the [Sensitivity] drop-down menu.


4. Define how the system responds when motion is detected. There are four different responses that the system can take when motion is detected. NOTE: The system will automatically record video when motion is detected.

- a. "Alarm Sounding Buzzer" The NVR's built-in buzzer will sound.
- b. "Alarm Output" The NVR will activate any external alarms that have been connected to the back panel (see: **3.1 NVR Installation – Connecting an External Alarm**).
- c. "Alarm Duration" will adjust how long both the buzzer and the alarm output will sound after motion is detected. NOTE: The alarm will sound continuously while motion is being detected.
- d. "Snapshot" The NVR will take a snapshot and send it to your mobile device and email address (when configured).
- e. "Send E-mail" The NVR will send an email notification. The NVR comes with predefined server settings for common service providers, however you may need to specify your own settings if your provider is not included. Choose an email address using the specified service provider to send the email and input the corresponding password to the existing email address.
- f. "Alarm Interval" This setting defines the interval between motion detection notifications. For example, when set to 1 minute, the NVR will send an email notification every minute when motion is detected.

5. Save and then select another channel to configure. If you do not save prior to selecting another channel, all changes will be lost. You may also restore setting defaults by pressing [Default].

External Alarm

The NVR supports up to four external alarm inputs and one external alarm output. External alarm inputs may include, but are not limited to motion detectors, trip wires, door sensors, etc. External alarm outputs may include, but are not limited to sirens, visual alarms, silent alarms, etc.



Please follow the following instructions to properly configure the external alarm features.

IMPORTANT: When changing the settings on a channel, press [Save] before editing another channel or exiting the page otherwise all changes will be lost.

1. Choose an alarm to edit. In the dropdown menu, choose an alarm and select [On] to enable the alarm input. Choose the type (normally open or normally closed) that describes your specific alarm.

2. Customize the active period for your alarm. The NVR allows you to set up to 4 different time periods in which your alarm will be considered active. To activate a time period, input the desired values and select the box to the right of the corresponding time period.

- a. You can either manually configure a schedule for each day by selecting the day in the [Week] dropdown menu, or you can apply the schedule to multiple days at once by choosing the [Apply to].

b. Once changes have been made, always press [Save] before navigating to another page or editing schedules for another day otherwise the changes will be lost.

3. Define how the system responds when an alarm is triggered. There are three possible responses when an alarm is triggered. Choose an option by selecting the box next to it. **NOTE:** The system will automatically record video when an alarm is triggered.

a. "Buzzer" The NVR's built-in buzzer will sound.

b. "Alarm Output" The NVR will activate any external alarms that have been connected to the back panel (see: **3.1 NVR Installation – Connecting an External Alarm**).

c. "Alarm Duration" will adjust how long both the buzzer and the alarm output will sound after motion is detected.

d. "Send E-mail" The NVR will send an email notification. The NVR comes with predefined server settings for common service providers, however you may need to specify your own settings if your provider is not included. Choose an email address using the specified service provider to send the email and input the corresponding password to the existing email address.

Alarm Input Select the channel of the input alarm that you would like to edit. Select "On" to enable this alarm.

Type Select the type of alarm that you are using. Please refer to your alarm's manual if you are unsure of this.

4.2 Camera Controls

When on the home screen, you can access the NVR's camera controls by double-clicking on the desired channel feed and a blue menu will appear as shown. The icons represent the three control features: image settings, zoom, and playback.





Image Setting



This will adjust the image settings of the camera from the NVR. **NOTE:** This will affect everyone connected to the NVR.

Image Orientation

Change the image orientation. "Flip" will flip the image vertically, "Mirror" will flip the image horizontally, and "Flip and Mirror" will apply both functions.

Operating Scene



Select scene of operation for optimal white balance.

Adjust the brightness settings of the camera.


Adjust the color saturation of the camera.

Adjust the contrast settings of the camera.

Zoom

Selecting this will bring you into the zoom-in mode. Use the scroll wheel to zoom in and out, and click on areas of the screen in the bottom right corner to select viewing areas.

Right click to exit out of the view.




Playback

Access and review your surveillance footage from this menu.



Video Playback

1. Select the channel of your recording on the right panel under "Channel". When you select a channel, it will be highlighted in blue.
2. Select the month and year on the calendar in the right panel. The days that are highlighted in blue will have recordings available. Select one of the days.
3. Use the Playback Controls to playback video.



Backup

The system allows you to backup specific files from your machine onto an external USB drive. The following instructions will show you how to find specific files on your system to backup.

1. Select the channel of your recording on the right panel under "Channel". When you select a channel, it will be highlighted in blue.
2. Once a channel is selected, select a month and year on the calendar. The days that are highlighted in blue will have available recordings. Select one of the days.
3. Under "Event" choose which type of recording that you want to search for. You can choose normal, alarm triggered or motion triggered recordings only, or you can choose all recordings.
4. Choose the time frame that your recording will fall under. For example, if you are looking for a video file that was recorded at 3:00 a.m. you will specify the time frame 0:00-6:00.
5. Press [Search]. If your NVR has saved any recordings during this time frame, they will appear in the menu.
6. Select all of the videos that you would like to back up, and press [Back up]. Wait for the progress bar to complete for each video file.
7. Repeat steps 1-7 for video files under different channels, days, events, time frames, etc.

4.3 Remote-viewing Setup



Remote / Local View via
Zsight Mobile APP



Remote viewing allows you to access your NVR from any location in the world for unprecedented surveillance versatility using any Android or iOS mobile device with our 'Zsight' application installed. With our revolutionary user-friendly setup, we have eliminated the need for complex port-forwarding procedures and other networking hassles. Our product servers will automatically authenticate and configure your hardware for remote-viewing. The following instructions will guide you through the remote-viewing setup:

Minimum Requirements:


- Android or iOS mobile device with wireless/3G/4G internet connection
- 'Zsight' Application downloaded on your mobile device.

1. Locate the NVR information on the outer casing of your system.




2. Connect your mobile device to the same local network as your NVR.

Please make sure your mobile device is connected to the internet through the same wireless router as your NVR.




3. Open the Zsight app on your mobile device and select the [+] icon. Open the 'Zsight' application and the device will automatically enter a 'Device List' section. Tap the [+] on the upper right hand corner to open the 'Add Device' menu.




4. Add your NVR by scanning the QR code found in step 1. There are three available methods to add your NVR device. We recommend that you add your device with the [Scan QR code] function or by manually inputting the NVR ID from step 1.


- a. To scan the QR code, open the [Scan QR code] function by pressing the button as shown in the pictures. Point your camera at the QR code on your device and hold it steadily until it scans successfully.
- b. Find the 10-digit device ID obtained from Step 1. Manually input the ID in the appropriate form on the 'Zsight' application.




5. Login with the default user 'admin' and default password '111111'. Once you have successfully added the system, a login screen will appear. Enter the default password '111111' or your password if you have changed it, and tap [Submit].




6. Select your system from the device list to view the live video stream. Go back to the 'Device List' section and select your device from the list. Make sure that a live video stream from your NVR appears.



7. Disconnect from your wireless network and access the NVR using 3G/4G. Connect your mobile device to a different internet connection from your NVR (3G/4G or any other wireless connection) and repeat step 6. Our product servers will automatically authenticate your NVR for remote-viewing capabilities.



8. Your device is now activated for remote surveillance! You will now be able to view your NVR on any Android or iOS device with internet connection! In order to do so, repeat steps 3-6 on the desired device (for step 4, you will need to add your system through the NVR ID). **Congratulations! Thank you for choosing Funlux!**



 iphone



 ipad

4.4 Updating your NVR

From your NVR (via USB)

Please refer to the following instructions to upgrade the firmware from the system (required: a USB drive).

1. Download the updated firmware from the website on your computer.
2. Place the file onto the root directory of a USB drive.
3. Connect the USB drive to the USB port on your NVR.
4. Go to the [General Settings] menu in the Main Menu and access the [System Settings] page.
5. Select [Upgrade] and wait 5-10 minutes.

5 Support

5.1 Troubleshooting

Most problems encountered are common problems and are easily correctible. For your convenience, please refer to the following table before calling our Funlux Technical Support.

Common Problem	Possible Causes	Solution
The system won't turn on.	The cables are not connected properly	<ol style="list-style-type: none">1. Make sure that the power brick is properly connected to the wall plug by unplugging it and replugging it until it fits snugly into the brick.2. Make sure that your power adapter is properly plugged into the power outlet and your NVR system.
	The cables are connected but the system still does not receive power	<ol style="list-style-type: none">1. Check your NVR front panel and check if the POWER LED indicator is on. If so, your monitor may be off or it may not be properly plugged into your NVR.2. If the unit is connected to the power outlet through a surge protector, make sure that the surge protector is on.3. Make sure that there is power coming from the outlet by plugging in another device to the outlet. If there is no power, please try another outlet or power source.
The cameras will not properly connect to the NVR	The cameras are not properly connected	<ol style="list-style-type: none">1. Make sure that your IP cameras are properly connected. Check the connections at the IP camera's Ethernet port and the NVR's camera ports.2. Check to see if the camera is on by placing your hand next to the camera's lens. If you hear a clicking sound, the camera is switching to the night-time viewing and your camera is on. Your NVR may be detecting offline IP cameras.

	The NVR is detecting offline IP cameras	<ol style="list-style-type: none"> 1. Access the [Device Management] page and unmark the "Search and Add All Devices Automatically" option. 2. Under the "Channel" column, select the channel of the camera that is not properly connected, then press the "Delete Device" button on the bottom right. 3. Select the "Auto Add" option and wait 3-5 minutes. If the proper cameras still aren't setup, please repeat steps 1-2 and proceed to step 4. 4. Press the "Search for Device" function and a list will appear. Select the device with the corresponding MAC address that is shown on your IP camera. Alternatively, you can directly add the camera by selecting "Add Device Manually" and inputting the MAC address manually.
There is a live feed showing on my NVR, but it isn't the same as my camera	The NVR is adding other IP cameras in your network	<ol style="list-style-type: none"> 1. Access the [Device Management] page and unmark the "Search and Add All Devices Automatically" option. 2. Under the "Channel" column, select the channel of the undesired camera feed and then press "Delete Device" to remove the device from the system. 3. Press the "Search for Device" function and a list will appear. You will have to select the device with the corresponding MAC address that is shown on your IP camera. Alternatively, you can directly add the camera by selecting "Add Device Manually" and inputting the MAC address manually.
Hard drive is not detected by the system	Hard drive cables may not be properly connected	Remove the cover and check that the SATA power and data cables are properly connected to the logic board and the hard drive.
	Your hard drive may not be compatible with the system	Check your HDD compatibility with the recommendations under the HDD Installation section of this user manual.
HDD is full and the unit is not recording	The NVR is set to stop recording when the HDD is full	<ol style="list-style-type: none"> 1. Access the [General Settings] menu and open the [Disk Drive Info] page. 2. Open the drop-down menu at the top next to the "Hard Disk Drive Full", select "Overwrite" and press save.
The mouse is not working	The mouse is not properly connected	Check the back panel of your NVR to make sure that the mouse is connected to the corresponding USB port.
	The mouse is connected but it is still not recognized	Please disconnect and reconnect the mouse to the system and reboot the system using the power switch on the back panel.

Remote control is not detected by the system	There are no batteries in the remote or the batteries are dead	Install two new AAA alkaline batteries into the remote control.
	The infrared signals are not reaching the NVR	Please make sure that the front panel of your NVR is not obstructed by any objects. Place your NVR in an open area and point your remote at the NVR during use.
The system beeps at startup		For some versions of the NVR firmware, this beeping will be normal.
The system is constantly beeping	The NVR is beeping when motion is detected	Under the [Event Management] menu, access the [Motion Detection] page and configure the motion detection settings. Please visit Section 4.1 of this user manual for further instructions.

5.2 Warranty

Please visit <http://www.zmodo.com/rma> for complete information.

General Guidelines

To qualify for a Return Merchandise Authorization (RMA) for either a refund or repair of Funlux products, all items require an RMA number prior to being returned. Products must be 100% complete, in the same condition as when sold, and in the original packaging as provided by the manufacturer. All packing materials, manuals, CDs, and other accessories and documentation must be included. Kits and other items assembled after purchase must be unassembled and returned in the manufacturer's original packaging. All returns will be inspected and products found to be non-conforming will be rejected or subject to a 15% restocking fee at Funlux's sole discretion.

Non-qualified and non-conforming returns are not included in Funlux RMA policy and, if returned, will be rejected or subject to a restocking fee of up to 15% at Funlux's sole discretion. If the non-qualified or non-conforming package is rejected, the party who returned the item(s) will be billed for return shipping cost of the item(s).

Receiving Procedure

All returned products will be thoroughly inspected and a determination will be made if eligibility and conforming requirements are met. To avoid any delay or denial of processing your return please verify the product you are returning meets the guidelines below and qualifies for return. If a non-conforming product is accepted for return Funlux reserves the right to charge a restocking fee up to 15% at Funlux's sole discretion. Return processing may take up to 5 business days from the time your product is received.

Inspection Criteria

Products must be in the original manufacturers packaging, and shipped securely.

Products must be complete with any standard certification labels originally placed and not tampered with. This includes , but is not limited to UL listing, capacity, brand name, UPC code.

Products must be free of any permanent alterations including, but not limited to paint, altered connection inputs, severed wires or cables, or indication of removed screws/fasteners or seals.

Products must be free from damage of any type, including, but not limited to dents, scratches, cracks, abuse, defacement or damage resulting from power surges.

Products labeled with a security seal, must have the seal intact and not tampered with.

Cross shipment

In the event that a replacement product is needed immediately, a cross-shipment option is available if the original purchase date is within 6 months of the cross-shipment request.

Customers located in Canada are responsible for the shipping charges to send the replacement items to them.

Requesting this option implies that the customer has the defective part and will ship it back to Funlux within 25 calendar days of the ship date of the replacement product. The customer will be asked to secure the return by providing a credit card number. There will be a 25-day cross-authorization placed on the card equal to the list price of the item being shipped. When the cross-authorization is placed on the credit card, the customer will see an approximate 48-hour hold for the amount equal to the list price if the item(s) being exchanged. After the initial 48-hour hold expires, the customer should see no charge placed on the credit card unless the RMA items are not returned to Funlux within 25 calendar days. Should 25 days pass and the original product is not yet received by Funlux, we will charge the full amount that was authorized on the credit card. Subject to availability, Funlux will ship product on the same day the RMA is generated.

Missing Parts Procedure

In the event that your order arrived incomplete, and the tracking indicates that your order was shipped from the Funlux warehouse in central Illinois; Funlux may require image confirmation at our discretion before replacements for any missing parts are shipped out.

If your order included a DVR with a Hard Disk Drive included, and a Hard Disk Drive was not installed in the DVR that you received, Funlux may ask for image confirmation before exchanging the DVR you've received with a DVR that has a Hard Disk Drive installed.

If your order was not delivered or if your order arrived damaged, please contact Funlux customer support so that we can file a claim with the carrier service we used to ship your order. In the event that your order arrived damaged or incomplete due to external damage, please keep all interior and exterior packaging as this is needed when we file the shipping claim.

Missing Parts Procedure for International Customers

In the event that an order is shipped to an international location and that order is either incomplete or including any incorrect items in lieu of correct items, the customer will be responsible for arranging that the correct item(s) be shipped to the international location. It is the customer's responsibility to ship the incorrect item(s) to the Funlux location that is detailed in the RMA information. Funlux will reimburse the customer for all international return shipping costs pending the acquisition of their shipping receipt indicating the exact cost to ship the defective item(s) internationally.

Return Shipping

For your protection, we recommend that you insure your return and use a traceable carrier that can provide you with delivery confirmation. Funlux shall not be responsible for items returned that are lost or damaged in transit. Postage and handling charges, both to and from our warehouse will be paid by the customer, and are non-refundable. At our discretion, Funlux may reimburse shipping charges related to the return or exchange of defective products inside the U.S. only.

Return Shipping for International RMAs for Repair

In the event that item(s) become defective within the one year manufacturer's warranty and the item(s) are located outside of the United States, it is the customer's responsibility to ship the defective item(s) to the Funlux location that is detailed in the RMA information. Funlux will only ship RMA returns to the USA and Canada. At our discretion, we may reimburse the customer for international shipping costs in the form of store credit.

If the returned item(s) are tested and found to be non-defective by the certified Funlux RMA technicians, the customer will not be reimbursed but international return shipping costs. The customer will be responsible for arranging shipment of the returned non-defective items from the US to their international location.

If the returned item(s) are tested and found to be defective by the certified Funlux RMA technicians, the customer will be reimbursed for all costs of return international shipping in the form of store credit. The customer will be responsible for arranging shipment of the returned defective item(s) from the US to the customer's international location.

In the event that we decide to issue store credit to a customer to reimburse for the cost of return international shipping, the customer must provide a copy of their shipping receipt indicating the exact cost to ship the defective item(s) internationally.

Under no circumstances is Funlux able to reimburse any Customs and/or Duty tax fees that are enacted by the shipping carrier.

Refund Policy for Funlux Purchases

Unless otherwise specified in the item listing on our website, on the receipt or packing slip, or in the terms agreement, Funlux will accept qualified and conforming products for refund within 30 days of the original purchase date.

Refund Policy for Retail Purchases

In order to return any number of Funlux items for refund, please contact the sales venue where these item(s) were originally purchased from and request to send your product(s) back for a refund. Most vendors who offer Funlux products will offer a 30 day refund option, however this is subject to the specific policy of the sales vendor that the product(s) were purchased from. Please refer to the return policy of the original store or vendor that you purchased your Funlux products from for specific return policy information.

Upgrade or Exchange Procedure

If the item(s) that you have purchased do not function to your satisfaction or do not apply to your installation application, please contact the sales venue in which the item was originally purchased from and request a refund for any item(s) that you wish to return. Funlux is unable to exchange any item for an item of a different type unless the following circumstance applies:

1. An item is returned to Funlux for repair under the manufacturer's one year warranty period and that same item was found to be defective and un-repairable by certified Funlux RMA technicians.
2. That same item is out of stock at the time that it was returned to Funlux and tested by certified RMA technicians.

Should the described circumstance directly apply, Funlux will offer at its sole discretion, either a variety of options for an item substitution, an item upgrade, a refund for the list price of the irreplaceable item, or store credit for the list price of the irreplaceable item.

Limitations of Warranty

This warranty does not include non-Funlux installed components. This limited warranty does not cover any damage to the product that results from abnormal mechanical or environmental conditions, abuse, accident, improper installation, misuse, insufficient or excessive electrical supply, natural disaster, or any unauthorized disassembly, repair, or modification. This limited warranty also does not apply to any product on which the original product label and or UPC information has been altered, obliterated or removed, has not been handled or packaged correctly, has been sold as second-hand, or has been resold contrary to US export regulations.

This limited warranty covers only replacements for defective Funlux products, as described above. Funlux does not cover under warranty and is not liable for any loss of data or any costs associated with diagnosing the source of system problems or installing, removing or servicing Funlux products. This warranty excludes 3rd party software, connected equipment or stored data. In the event of a claim, Funlux's sole obligation shall be to replace our product with its equivalent or the best possible substitute.

Under no circumstances shall Funlux be liable in any way to the user for damages, including any lost profits, lost savings or other incidental or consequential damages arising out of the use of, or inability to use the Funlux products. Funlux reserves the right to revise or update its products, software, or documentation in keeping with technological advances without obligation to notify any individual or entity.

Technical Support and firmware upgrades for Funlux products are restricted to the country/region of purchase. Please refer to www.zmodo.com/Contact/ in order to contact us to clarify any concerns with the warranty.

5.3 Funlux Support

Online Resources

For full instructional manuals, software downloads, and more, please visit:

<http://www.zmodo.com/support-software>

For detailed and specific instruction, please our frequently updated knowledge-base: <http://kb.zmodo.com>

Technical Support

If you ever have any problems setting up or using this product, call our TOLL-FREE number for additional assistance: **866-551-6881**

Telephone Service Hours: Mon-Fri 8:00am-8:00pm CST

Email: support@zmodo.com

Customer Service & RMA

Customer Service: support@zmodo.com

RMA: RMA@zmodo.com

General Inquiries & Sales

Sales/Inquiries from North America: sales-us@zmodo.com

Sales/Inquiries from other locations: sales@zmodo.com