

Muestrario de refacciones A.B.Dick®

egomexico



r e f a c c i o n e s

instrucciones de uso

1. Identifique la imagen de la parte que busca.
2. Identifique la descripción y el número de parte.
3. Ingrese a www.equiposgraficos.com y complete el formulario de **cotización** o **pedido** incluyendo el número de parte y descripción.
4. Solicite asistencia a los teléfonos +52(55) 5396 6021 / 6580 ext. 210 o a estelar@egomexico.com



Gracias por su compra

A.B.Dick® es una marca registrada de A.B.Dick Company

Salónica #259, Col. Sector Naval,
Del. Azcapotzalco México, D.F.,
C.P. 02080
+52-55-5396-6580
+52-55-5396-6021
+52-55-5341 5926
+52-55-5342 0366
info@egomexico.com

www.egomexico.com


Replacement parts for: A.B. DICK 350, 360, 360PRO, 369, 8805, 8810, 8815, 8820,

	PART #
 FILTER ASSEMBLY (A) Tube P-1147 (B) Filter (need 2) P-1146 Plug (not shown) P-1148 P-1150	
 ... Rather than buy a new cradle, replace only the parts that wear. CRADLE REPAIR KIT - For 8800 & 9800 series. Complete Kit P-98037 (A) Washer P-613 (B) Hex nut - 2 ea. P-514 (C) Retaining ring P-707 (D) Shaft P-98038 (E) Key P-1745 (F) Ball bearing - 2 ea. P-11149 (G) Steel bushing P-98058 (H) Cradle (w/ shaft and bearing) P-98041	
 PUMP VANE (need 4 per pump) 350, 360, 375, 8800, 9800 P-1159 380, 382, 385 P-1931	
 FLEXIBLE SPEED CONTROL SHAFT For the 8800 & 9800 series Shaft P-98053 Set screw P-7	
 CRANK ASSEMBLY Speed control Complete - 350, 360, 375, 385 P-36060 Complete - 9800 P-98060 (A) Handle P-36062 (B) Spring for handle P-36410 Mounting screw P-299	
 SPEED PULLEY Variable P-1630 Heavy duty (all steel) P-1631	
 FEEDER CLAMP Thumb screw P-1539 Adjusting clamp P-36087 ... MADE OF DURABLE ZINC DIE CAST!	
 STOCK RETAINER PLATE GUIDE 350, 360 Center P-36712 350, 360 Right hand P-36092 350, 360, 375, 9800 Left hand P-36089 385 Back guide plate P-38089	
 MICRO GUIDE ADJUSTING KIT FOR ACCURATE FEED & REGISTRATION 350, 360 P-36113 375, 9800 P-37113	
 BACK PAPER GUIDE P-36090 THUMB NUT P-1058	
 SPRING GUIDE 350, 360, 375 P-36088 385 Side P-38088 385 Back P-38090 Screw P-984	
 TABLE RELEASE LEVER ASSEMBLY 350, 360, 375, 385 P-36969 9800 P-37969	


	PART #
 TABLE RAISE HANDLE ASSEMBLY 350, 360, 375 For feeder P-36955 9805 - 9850 For feeder P-98955 380, 385 For feeder P-38955 Chain del. 350,360,375,385 P-362630 Chain del. 9800 P-982630	
 TABLE RAISE GEAR & RATCHET ASS'Y. For feeder hand crank on 350, 360, 375, 9800 350, 360, 375 (complete) P-36975 9800 P-98975 Gear P-36974 Ratchet 350, 360, 375 P-36973 Ratchet 9800 P-98973 Screw (3 needed) P-44	
 TABLE RAISE SHAFT ASSEMBLY - 9800 Complete P-98070 Shaft P-98102 Gear P-38103 Sprocket P-36101	
 COUNTER ASSEMBLY Complete P-36952 Counter P-36954 Mounting screw P-229 Arm P-36956 Screw for arm P-151 Wheel (screw on type) P-36958 Screw for wheel P-1056	
 COUNTER SENSOR SWITCH 9900 Series P-9814	
 BLEEDER VALVE ASSEMBLY Complete P-36847 (A) Valve body P-36844 (B) Shaft P-36841 (C) Plug P-36951 (D) Spring (inside) P-36859 (E) Valve (inside) P-36845 (F) Roll pin P-379	
 SUCKER TUBES WITH SHUT OFF VALVE ON BOTTOM ... Ideal for envelope runs and T-Heads. Shut off tube P-36990 Sucker tube (standard) P-36174 Paper leveler assy. P-36164 Paper leveler tube P-36166 Plug P-36172 Compensating sucker tube w/shut off valve P-36966	
 SUCKER FOOT ...P-1555 MATERIAL IS NEW TACKY GUM RUBBER TO ENSURE BETTER SHEET PICK UP. All presses (cup) each P-1555* Extra heavy (cup) each P-5219 Flat disc (3/4" dia.) each P-1552 Flat disc (1/2" dia.) each P-1554 *Note: P-1555 Sold individually or in bags of 50 or 100.	
 BLOWER TUBE SHUT OFF VALVE - All models P-36760	
 SPRING For feed roller support arms P-36177	

375, 9805, 9810, 9815, 9820, 9835, 9840, 9850, 9865, 9870, 9880, 380, 382, 385


PART #	
	
UPPER FEED ROLLER	
350, 360	P-36157
375, 9800	P-37157
9870, 9910XCS, 9910 XCS	P-98157
385	P-38157
Arm 350, 360, 375, 9800	P-36175
Bearing (plastic)	P-1566
	
SHAFT & LEVER ASSEMBLY For upper feed roller	
Complete 350, 360	P-36147
Complete 375, 9805 - 9850	P-37147
Shaft only 350, 360	P-36149
Shaft only 375, 9805 - 9850	P-37149
Lever (operators side)	P-36171
Lever & cam assy. (n.o.s.)	P-36151
Pin	P-349
	
STUD - For feed roll shaft assembly	
350, 360, 375, 385, 9800	P-1561
	
STUD - For upper forwarding feed roll shaft assembly.	
9870, 9890	P-8270
SCREW - For P-8270	
	P-6512
	
SUPPORT ARMS - For upper feed roller	
Operators side	P-36153
Non-operators side	P-36155
	
FINGER ASSEMBLY & BLOWER TUBE	
350, 360, 375, 9800	P-36158
385	P-38158
	
HOSE For blower tube	
350, 360, 375, 9800	P-1189
380, 385	P-1677
	
SOLENOID 9800 impression cylinder power lever	
	P-4029
	
PAPER SENSOR For AB Dick 9800	
Complete	P-98269
Sensor arm	P-98974
Spring	P-98581
	
FEELER CONTROL LEVER ASSEMBLY	
350, 360, 375, 9805, 9810, 385	
	P-36839
	
IMPRESSION CYLINDER GRIPPER FINGERS	
... Sand blasted tips for better grip.	
350 (1/2")	P-35225
360, 385 (1/4")	P-36225
375, 9800 (small)	P-37224
375, 9800 (large)	P-37225
Mounting screw	P-268
	
PAPER WEIGHT BAR	
Light weight 350, 360	P-36094
Heavy weight 350, 360	P-36093
Light weight 375, 9800	P-37094
Heavy weight 375, 9800	P-37093

PART #	
	
PAPER STOP Impression cylinder	
350	P-35241
360	P-36241
375, 9800	P-37241
	
LEVER ASSEMBLY For impression cylinder	
	P-36207
	
SEGMENT Imp. cylinder	
	P-36203
	
GRIPPER SHAFT ASSEMBLY For impression cylinder	
Complete 350, 360	P-36229
Shaft only	P-36231
Gear	P-36235
Taper pin	P-421
	
BLANKET CYLINDER SHAFT	
350, 360	P-36290
375, 9800	P-37290
380, 382, 385	P-38290
	
PRINT ADJUSTING DRAW ROD	
350, 360	(30° pressure angle) P-36180
	(20° pressure angle) P-36308
375, 9800	(30° pressure angle) P-37180
	(20° pressure angle) P-37308
385	(30° pressure angle) P-38180
	(20° pressure angle) P-38308
	
RETAINER NUT	
	P-36182
	P-36186
	
BLANKET CYLINDER RING SEGMENTS	
... New style - Case hardened for longer wear.	
Left hand	P-36194
Right hand	P-36195
	
(A) SCALE Blanket cylinder raise & lower	
2 screws needed	P-36208
	
(B) SCALE Blanket cylinder adjustment	
5 screws needed	P-36202
DRIVE SCREW For both scales (not shown)	
	P-1040
	
BLANKET BARS Standard	
360	P-36252
375, 9800	P-37252
380, 382, 385 Serial #1305 & below	P-38252
9880	P-988252
Mounting screw	P-36204
Blanket screw	P-124
	
QUICK CHANGE BLANKET BARS	
... Save time & money by changing only 4 screws to mount your blanket.	
360	P-36777
375, 9800	P-37777
380, 382, 385	P-38777
9880	P-988777
Mounting screws	P-36204
Blanket screws	P-124

Replacement parts for: A.B. DICK 350, 360, 360PRO, 369, 8805, 8810, 8815, 8820,

PART #		PART #	
	BEARING HOUSING COMPLETE For blanket cylinder • Made of "REINFORCED STEEL" for longer life. • Completely enclosed for added strength.		
	(A) Operators side P-36295 (B) Non-Operators side P-36283		
	BLANKET CYLINDER ADJUSTING SHAFT 350, 360, 375 P-36236 9800 P-98236		
	CYLINDER GEARS *** All cylinder gears are made with "SOLID STEEL" for longer life. Master cylinder gear 350, 360, 375 P-36313 Master cylinder gear 9800 P-98313 Inner blanket cylinder gear 350, 360, 375 P-36214 5/16" wider than standard for longer life. Inner blanket cylinder gear 9800 P-98214 "Wide" inner blanket cylinder gear P-36211 Outer blanket cylinder gear 350, 360 P-36196 Outer blanket cylinder gear 369 P-36198 Outer blanket cylinder gear 375, 9800 P-37196 Outer blanket cylinder gear 385 P-38196 Impression cylinder gear P-36191	 IMPRESSION  INNER BLANKET  MASTER	
	PLATE CYLINDER UPPER SUPPORT ARMS 350, 360 P-36801 375, 9800 P-37801 PLATE CYLINDER LOWER SUPPORT ARMS 350, 360, 375, 9800(9/16" hole) P-36833		
	STUD - For master cylinder support arm. 9890, 9900 P-4577		
	WATER FOUNTAIN HOSE P-1549		
	IDLER GEAR Water section Plastic P-36368		
	HARDWARE REPAIR KIT For Super Aquamatic. Complete P-36376-K Consists of 2 ea. P-36376 Shield P-658 Spring washer P-617 Flat washer P-706 Retaining ring *ALL PARTS SOLD SEPARATELY.		
	WATER FOUNTAIN BOTTLE ASSEMBLY. *** The valve assembly is made of hardened plastic which helps eliminate build up and rust. (1 quart) P-1915 350, 360 only (2 quart) P-1919		
	COUPLING ASSEMBLY For water waver roller ass'y. P-36426		
	COUPLING HOUSING For water waver roller ass'y. P-36432		
			CHROME WATER DUCTOR ROLLER (SMOOTH) 350, 360 P-36342-S 375, 9800 P-37342-S
			CHROME WATER DUCTOR ROLLER (ROUGH) 350, 360 P-36342-R 375, 9800 P-37342-R
			WATER FOUNTAIN ROLLER 350, 350T, 357, 357A, 367, 367A (Smooth Aluminum) P-35364 360, 360CD, 360T (Rough Aluminum) P-36364 375, 9800 (Rough Aluminum) P-37364
			WATER DUCTOR ROLLER HOUSING Housing (cone hub) P-36322 Housing (flat hub) P-36366 Bearing P-746
			COMPRESSION SPRING (Painted Red) For water waver roller P-36413
			SHAFT For water repellant waver roller 350, 360 P-36378 375, 9800* P-37378 9800 PRO ***Shaft is universal, fits old & new style.
			TIRE Form roll knobs P-36399 TIRE Ink fountain knob P-36244
			NIGHT LATCH IDLER GEAR Brass P-36446 Steel P-36457 Nylon P-36455
			SINGLE LEVER CONTROL ARM 360 Complete P-36856 9800 Complete P-98856 (without knob) P-36860 Knob P-36858
			INK OPERATING PAWL For ink metering fountain 360 Pro P-36251 9800 P-98251
			SPRING For lower ink oscillator P-36459
			FORM ROLL SHAFT 350, 360 P-36401 375, 9805 - 9850, 9865, 9870 P-37401

PART #




MASTER CYLINDER HEAD CLAMP ASSEMBLY

For 9800 - consists of all items shown

COMPLETE

(A) Screw	P-98352
(B) Head clamp	P-253
(C) Screw	P-98353
(D) Hinge	P-43
(E) Plate clamp	P-98299
(F) Knob	P-98359
(G) Spring	P-98175
(H) Washer	P-36707
(I) Eccentric pin	P-592
(J) Retaining ring	P-98351
(K) Bracket	P-668
(L) Bar	P-98171
(M) Screw	P-98387
(N) Shoulder screw	P-257
(O) Retaining ring	P-8042
(P) Bracket	P-666
(Q) Spring	P-98181
(R) Thumb screw	P-36349
(S) Bracket	P-98347
(T) Screw	P-98153
(U) Radial bar	P-37
	P-98393



HEAD & TAIL CLAMP ASSEMBLY For 350, 360

COMPLETE - 360 consists of all items shown

COMPLETE - 375 consists of all items shown

TAIL CLAMP ASSY. (A - F)

(A) C-Ring	P-36354
(B) Tail clamp (360)	P-37354
(B) Tail clamp (375)	P-36606
(B) Tail clamp (9800 not part of kit)	P-37606
(C) Pivot screw	P-666
(D) Spring	P-36323
(E) Thumb screw	P-37323
(F) Spring	P-98323

HEAD CLAMP ASSEMBLY (G - S)

HEAD CLAMP ASSEMBLY (G - S)

(G) Lateral adj. knob	P-36347
(H) Washer	P-569
(I) Spring	P-36349
(J) Pin bar (360)	P-36345
(J) Pin bar (375)	P-37345
(K) Bracket (360)	P-36353
(K) Bracket (375)	P-37353
(L) Spring	P-36032
(M) Washer	P-586
(N) Spring washer	P-1049
(O) C-Ring	P-668
(P) Screw	P-892
(Q) Hinge (360 & 375)	P-36299
(Q) Hinge (9800)	P-98299
(R) Stop plate (360)	P-36359
(S) Vertical adj. knob	P-36351

PART #



FORM ROLL SEPARATING SHAFT

9800/9900 Complete	P-98497
(A) Roll pin	P-382
(B) Collar	P-739
(C) Cam - non-operators side	P-36623
(D) Shaft only	P-37499
(E) Cam - operators side	P-36503
(F) Eccentric collar	P-747
(G) Set screw	P-8
(H) Taper pin	P-424
(I) Separating lever	P-98505



INK DUCTOR LEVER ASSEMBLY

Complete	P-36572
Lever only	P-36569
Bushing 360, 375, 9800	P-1569
Bushing 380, 382, 385	P-1568
Retaining ring	P-703



SEAL For ink fountain roller - 360Pro & 9800 (need 2)
P-36262




INK DUCTOR OPERATING CAM
P-36542



INK ROLLER RATCHET ASSEMBLY

360 PRO	P-36263
9800 PRO, 9900	P-98263
Ratchet only	P-36239



... DESIGNED WITH REPLACEABLE "STEEL" END CAPS AND A DEEPER INK WELL FOR 50% MORE INK CAPACITY.

INK FOUNTAIN ASSEMBLY

350	Complete	P-35071
	Fountain only	P-35072
	Wire	P-35084
360	Complete	P-36778
	Fountain only	P-36789
	Wire	P-36084
360 PRO	Complete	P-36805
	Fountain only	P-36807
375, 9800	Complete	P-37778
	Fountain only	P-37789
	Wire	P-37084
9800PRO	Complete	P-98805
	Fountain only	P-98807
All models	Adjusting screw	P-1570
350, 360, 375, 9800	End caps	P-36792
360PRO, 9800PRO	End caps	P-98792



INK FOUNTAIN BLADE

350	1-3/4" wide	P-35079
	2-7/8" wide	P-35233
360, 360PRO	1-3/4" wide	P-36079
	2-7/8" wide	P-36233
375, 9800	1-3/4" wide	P-37079
	2-7/8" wide	P-37233
385	Standard width	P-38079
	Screw	P-118

METERING BLADE With studs

360	3-5/8" wide	P-36095
9800	3-5/8" wide	P-98095


Replacement parts for: A.B. DICK 350, 360, 360PRO, 369, 8805, 8810, 8815, 8820,

PART #		
 HEAVY DUTY CAM KIT For ink ductor P-36500 *** Uses a bearing in place of the Cam to prevent premature wear.		
 INK FOUNTAIN HAND CRANK 9800 P-98402		
  IMPROVED BLOCK IS COLD WELDED WHICH MAKES IT LESS BRITTLE.		
CLUTCH PULLEY ASSEMBLY 360, 375, 9800 Complete hub I.D. 1/2" P-36597 9800 QPC, PRO Complete hub I.D. 7/8" P-98597 (A) Spring P-36591 (B) Pinion P-36595 (C) Link P-36593 (D) Lever P-36605 (E) Pulley only 360 P-36587 (E) Pulley only 9800 P-98587		
360 OVERSIZED CLUTCH PULLEY For thermographers Complete P-36589 Pulley only P-36599		
 SPRING HOLDER & SLEEVE KIT Used in place of old design single piece. 9800 Series P-98595-K		
 SENSOR For 9800 clock sync. mechanism Male connector P-4047 SENSOR For 9800 clock sync. mechanism Female connector P-4032		
 FEELER LINK OPERATING LINK ASSEMBLY 350, 360, 375, 9800 P-36885 380, 382, 385 P-38885		
 GAP CONTROL SHAFT ASSEMBLY 350, 360 Complete P-36689 375 Complete P-37689 9800 Imp. Cyl. Complete P-98689 9800 Master Cyl. Complete P-98693 350, 360 Shaft only P-36695 375 Shaft only P-37695 9800 Imp. Cyl. Shaft only P-98695 9800 Master Cyl. Shaft only P-98697 350, 360, 375, 385 Dial assy. P-36688 8800, 9800 Dial assy. P-98688		
 HANDWHEEL 350, 360, 375, 8805/10 P-36615		
 SPLINE DISC Safety handwheel P-99665		

PART #		
 DRIVE SHAFT AND GEAR ASSEMBLY COMPLETE 350, 360 P-36577 375 P-37577 9865 P-98577-65 9870 P-98577-70		
DRIVE SHAFT 350, 360 P-36583 375 P-37583 9800 - 1/2" O.D. P-98583 9800 - 5/8" O.D. P-98388 9865 P-98583-65 9870 P-98583-70 380, 385 P-38583		
HOUSING Non-operators side 350, 360 P-36487 375 P-37487 9800 TD/CD/QP/QPC/PRO P-98487		
HOUSING ASSY. 9800 TD/CD/QP/QPC/PRO P-98385		
HOUSING Operators side 350, 360 P-36585 375, 9800 P-37585 9800 QPC, PRO P-98585		
DRIVE GEAR 350, 360, 375 P-36581 9800, 380, 385 P-38581		
 CONTROL PANEL OVERLAY & MEMBRANE (A) 9815, 9850 P-98540 (B) 9870 P-98562		
 POWER SUPPLY 9800 Control box (5V. 115V.) P-4401		
 DRIVE & PUMP SWITCH Old style (drive & pump) - 2 position with screw connectors P-36977 (385) Momentary - 3 position with tab connectors P-38977 New style (motor) momentary- 3 position with tab connectors P-36303 New style (pump) - 3 position with tab connectors P-36307 New style (pump) - 2 position with tab connectors P-36305		
 RELAY - 9800 Control box P-4037 36.00		
 MICRO SWITCH Chain delivery safety guards P-362940		
 TIMING PULLEY ASSEMBLY 350, 360, 385 P-362080 375, 9800 P-372080 Shaft only 350, 360, 385 P-362040 Shaft only 375, 9800 P-372040 Pulley only all models P-362120		

375, 9805, 9810, 9815, 9820, 9835, 9840, 9850, 9865, 9870, 9880, 380, 382, 385

	PART #
	JOGGER OPERATING LEVER - New style 350, 360, 375 P-361610
	SIDE JOGGER LEVER 9800 P-984130
	LEVER SUPPORT P-984140
	GEAR & SHAFT ASSEMBLY Chain delivery P-36754 Chute delivery P-36752 385 P-38754 9800 P-98754
	SHAFT & SPROCKET ASSEMBLY 350, 360 (12-1/4" Inside sprocket to sprocket) P-361160 350, 360 (12-1/16" Inside sprocket to sprocket) P-361165 8810 P-881160 375, 9800 Standard P-371160 9800, 1-1 P-981160



*** Reinforced anvil is made of steel which prevents bowing and lasts longer.

GRIPPER BAR ASSEMBLY	
350, 360 Complete	P-360990
375, (9800 standard) Complete	P-370990
9800 (1 to 1)	P-980990
385 Complete	P-380990
(A) Gripper finger	P-361020
(B) Pin (for finger)	P-3001
(C) Anvil 350, 360	P-361090
(C) Anvil 375, 9800 (universal)	P-371090
(C) Anvil 385	P-381090
(D) Butterfly spring 350, 360	P-361070
(D) Butterfly spring 375, 9800	P-371070
(D) Butterfly spring 385	P-381070
(E) Shoulder screw	P-8032
(F) Shaft 350, 360	P-361060
(F) Shaft 375, 9800	P-371060
(F) Shaft 385	P-381060
(G) Shaft bearing	P-361000
(H) Cam	P-1416
(I) Stud	P-401
(J) Lever 350,360,375,9800standard,385	P-361040
(J) Lever 9800 (1 to 1)	P-981040
(K) Loop spring	P-361080

GRIPPER BAR REPAIR KIT

*** Comes with all parts (less anvil & shaft) to repair one gripper bar.

350, 360	P-30730
375, 9800 Std. & 1-1	P-30731
385	P-30732



TAPE TRACK (18 inches)

*** Made of "sand paper like" material that holds better.
For star wheels on 9800, 1 to 1 chain deliveries
P-983130

	PART #
	BACK STOP 350, 360, 375 P-362420 9800 P-984320 9800, 1-1 P-982420
	BACK STOP SPRING Complete with cam P-362300 350, 360, 375, 385 P-982300 Complete with cam-9800 P-362320 Spring only P-982320 Spring only P-982320 Cam P-1521 Pin P-3002
	DELIVERY GRIPPER CHAINS <i>Sold in a set of 1 Left hand & 1 Right hand</i> 350, 360, 375, 9800 O.S., 385 P-361390 N.S. 5/8" carrier link P-361100 O.S. 1/2" carrier link P-361100 new style 9800, 1 to 1 CD P-981390 - 6" star wheels with tapes

ARMS For 9800 1 to 1 chain delivery safety guards



Operators side - complete	P-984289
Arm only OS	P-984290
Non-oper. side - complete	P-984279
Arm only NOS	P-984280
Cam	P-1475
Pin	P-3012
C-ring	P-679



INK WASH UP ATTACHMENT

350, 360	P-36773
375	P-37773



REPLACEMENT WASH UP BLADES

350, 360	(11-5/8 x 1-5/8) 4 holes	P-5028
350, 360	(11-3/4 x 2-1/16) no holes	P-36767
375	(12-7/8 x 1-5/8) 4 holes	P-5029
9800	(13-1/4 x 2) 6 holes	P-30200
9800XLK	(13-1/4 x 2-1/16) 6 slots	P-30216
9985	(14-3/32 x 1-5/8) 6-holes	P-30225
Century 3000	(14 x 1-5/16) 7 holes	P-30792

*** ELIMINATE COSTLY DOWNTIME WITH YOUR OWN EMERGENCY KIT FOR YOUR MODEL PRESS.



REPAIR KITS FOR ALL A.B. DICKS

Master kit	P-1707 - 720 pcs.
Junior kit	P-5088 - 437 pcs.
Nut kit	P-1701 - 100 pcs.
Washer kit	P-1702 - 120 pcs.
Screw kit	P-1703 - 108 pcs.
Ring kit	P-1704 - 228 pcs.
Pin kit	P-1705 - 136 pcs.
Spring kit	P-1706 - 28 pcs.