CAT® CLASSIC™ PARTS PRODUCT BOOK

March 2011

CAT® CLASSIC™ PARTS PRODUCT BOOK

March 2011

CAT®

Table of Contents

Cat® Classic™ Parts Overview 1-1
Backhoe Loaders 2-1
Engines 3-1
Excavators 4-1
Motor Graders 5-1
Pipelayers 6-1
Scrapers 7-1
Track Loaders 8-1
Track-Type Tractors 9-1
Wheel Loaders 10-1
Literature References 11-1
Part Cross-Reference 12-1

Cat Classic Parts

Cat® Classic™ Parts provide owners of older Cat equipment with lower cost repair alternatives that minimize the risk associated with non-genuine parts. Cat machines and engines have long, productive lives. As the equipment ages, maintenance costs often need to be re-evaluated, taking the remaining market value into consideration. Cat Classic Parts are lower-cost, genuine Cat parts that provide acceptable service life for older Cat equipment. Not all Cat original parts have a Classic Parts option. The Classic Parts line generally contains parts that have a greater impact on the overall repair costs. Together with Cat original and remanufactured parts, Cat Classic Parts help Caterpillar offer value-priced repair alternatives over the entire product life cycle.

Benefits

Cat Classic Parts help manage the owning and operating costs for older equipment by offering a low cost repair alternative. Classic Parts minimize the risk associated with non-genuine parts since the parts are backed by the reliable Cat standard warranty and by the dependable Cat Dealer network. Cat Classic Parts are approved by Caterpillar engineers, who ensure that the product will meet form, fit, and function. Caterpillar approved suppliers manufacture these parts utilizing industry standard product quality assurance processes. Quality checks are performed by Cat parts stock locations to ensure that only the highest quality parts are being sent out to our customers. Ultimately the Cat brand provides peace of mind for the equipment owner.

Cat® Classic™ Parts Product Book

This Cat Classic Parts Product Book contains the line of Classic Parts available for Cat machines and engines. The Classic Parts Overview section of this manual provides you with detailed information to help your customer make an informed decision on which type of part to purchase. The next eight sections contain a cross reference between Cat Classic part numbers and Cat original part numbers categorized by product family and models. This section is further broken down into the model numbers of specific Cat machines and engines. The Literature Reference section provides a reference of available promotional material for Cat Classic Parts information. The Part Cross-Reference section at the end of the catalog details the available parts in numerical order.

Warranty

Cat Classic Parts are backed by the standard Caterpillar parts warranty. This warranty covers the parts for a six month time period. The customer warranty statement for these parts is SELF5426. It should be referenced for general information on the overall warranty terms. Dealers should reference the relevant parts warranty bulletin for additional specific details about Classic Parts warranty.

Undercarriage Assurance (3 years/4,000 hours) is now offered for Cat Classic major moving undercarriage parts. Enrollment requirements will be the same as for Cat premium undercarriage products.

Additional Information

For more information on the Cat Classic Parts product line, customers should visit the Classic Parts section of www.cat.com.

Dealers, please use your CWS ID to access the global Classic Parts websites. They are contained within the Product Support area of your Cat regional internet websites under Parts Products.
NACD - https://nacd.cat.com
APD - https://apdnet.cat.com
LACD - https://lacd.cat.com
EAME - https://eame.cat.com
Types of information that can be found on these pages include the following: advertising/promotional material, cost comparisons, presentations, a video explaining Classic parts, and appropriate Cat Classic parts contacts.

Contact Information

Classic Parts Email Address:
Classic_Parts_Support@cat.com
Customer Interaction Center:
USA: 1-877-CAT-CICO (228-2420)
International: 309-578-7372
Email: cic@cat.com

Cat® Classic™ Parts for Backhoe Loaders

Cat® backhoe loaders are designed for maximum performance and durability in any application. Caterpillar has been delivering industry-leading digging forces with this product line since its introduction. However, as with any aging equipment, maintenance costs need to be re-evaluated over time to ensure that maximum profitability is maintained. Cat Classic Parts are offered as another solution to help keep these maintenance costs down for Caterpillar equipment. They are released for several models of backhoe loaders as a competitively priced alternative to aftermarket parts.

Cat Classic Parts provide owners of older Caterpillar products with low cost repair alternatives that minimize the risk associated with non-genuine parts.

Cat Classic Parts coverage for backhoe loaders includes:

- Engine
- Final Drive
- Hydraulics
- Steering
- Transmission
- ...and many more.

Sales Model 416

Original Part Number	Part Name	Classic Part Number
054-2213	Spider and Bearing As	347-0464
054-6549	Pinion - Planetary	347-0478
055-1260	Housing Bk - Outer	347-0479
130-1637	Shaft	347-0471
160-1014	Pin As	347-0473
175-4070	Bushing - Sleeve	347-0484
186-4118	Gear - Planet	347-0483
7T-3173	Piston	346-5680
7T-3194	Yoke	346-5681
7W-5194	Muffler As	346-5682
9R-0080	Coupling	346-5683

Original Part Number	Part Name	Classic Part Number
9R-0097	Pin	346-5684
9R-0237	Pin As	346-5685
9R-0424	Pin	346-5686
9R-2410	Retainer As	346-5688
9R-2421	Shaft	346-5689
9R-2424	Gear - Planet Sun	346-5690
9R-2476	Disc - Bk Rear	346-5691
9R-2477	Disc As	346-5692
9R-2491	Spider	346-5693
9R-2846	Pin	346-5694
9R-2956	Pin	346-5695
9R-3161	Shaft - Sun Gear	346-5696
9R-3933	Pin	346-5697

Original Part Number	Part Name	Classic Part Number
9R-6158	Pin	346-5698
9R-6159	Pin	346-5699
9R-6160	Pin	346-5700
9R-6163	Pin	346-5701
9R-6475	Pad As	346-5702
9R-7158	Pin As	346-5704
9R-7894	Pin As	346-5706
9R-7895	Pin As	346-5707
9R-8715	Spider and Bearing As	346-5716
9R-8718	Yoke As	364-5258
9R-9190	Rod Gp - Tie	346-5718
9R-9403	Pinion	347-0477
9R-9631	Pin	347-0467
9Y-9431	Precleaner As	361-1718

Sales Model 416B

Original Part Number	Part Name	Classic Part Number
054-2213	Spider and Bearing As	347-0464
054-6549	Pinion - Planetary	347-0478
102-4560	Bearing - Sleeve	347-0469
112-1773	Piston	347-0462
127-8592	Muffler As	347-0463
130-1637	Shaft	347-0471
160-1014	Pin As	347-0473
175-4070	Bushing - Sleeve	347-0484

Original Part Number	Part Name	Classic Part Number
186-4118	Gear - Planet	347-0483
1M-7250	Bowl - Precleaner	360-2296
237-2252	Bearing - Sleeve	347-0474
239-9956	Brake Disc	347-0485
6E-1500	Piston	346-5677
6E-6153	Plate - Port	346-5678
6E-6163	Shaft	346-5679
7T-3173	Piston	346-5680
7T-3194	Yoke	346-5681

Original Part Number	Part Name	Classic Part Number
9R-0097	Pin	346-5684
9R-0424	Pin	346-5686
9R-2421	Shaft	346-5689
9R-2424	Gear - Planet Sun	346-5690
9R-2477	Disc As	346-5692
9R-2491	Spider	346-5693
9R-2846	Pin	346-5694
9R-2956	Pin	346-5695
9R-3161	Shaft - Sun Gear	346-5696

(Continued)

Sales Model 416B (Continued)

Original Part Number	Part Name	Classic Part Number
9R-3933	Pin	346-5697
9R-6163	Pin	346-5701
9R-7158	Pin As	346-5704
9R-7696	Pin	346-5705
9R-8202	Pin	346-5708
9R-8206	Pin	346-5709

Original Part Number	Part Name	Classic Part Number
9R-8523	Pin	346-5710
9R-8579	Pin	346-5711
9R-8662	Pin	346-5713
9R-8663	Pin	365-8831
9R-8715	Spider and Bearing As	346-5716
9R-8718	Yoke As	364-5258

Original Part Number	Part Name	Classic Part Number
9R-9190	Rod Gp - Tie	346-5718
9R-9400	Case As	346-5719
9R-9402	Seal - Rax	347-0476
9R-9403	Pinion	347-0477
9R-9631	Pin	347-0467
9R-9812	Pin	347-0468
9Y-9431	Precleaner As	361-1718

Sales Model 416C

Original Part Number	Part Name	Classic Part Number
055-1986	Seal - Lip type	347-0465
102-4560	Bearing - Sleeve	347-0469
112-1773	Piston	347-0462
112-9629	Pin	347-0470
119-7042	Shaft	347-0480
119-7047	Seal	347-0481
122-1881	Plate - Clutch	347-0475
130-1637	Shaft	347-0471
130-6879	Seal	347-0482
160-1014	Pin As	347-0473
186-4118	Gear - Planet	347-0483

Original Part Number	Part Name	Classic Part Number
229-2949	Rod As - Track	347-0486
229-2950	Rod As - Track	347-0487
237-2252	Bearing - Sleeve	347-0474
6E-1500	Piston	346-5677
9R-0097	Pin	346-5684
9R-0424	Pin	346-5686
9R-2421	Shaft	346-5689
9R-2424	Gear - Planet Sun	346-5690
9R-2477	Disc As	346-5692
9R-2491	Spider	346-5693

Original Part Number	Part Name	Classic Part Number
9R-2956	Pin	346-5695
9R-3933	Pin	346-5697
9R-6163	Pin	346-5701
9R-7696	Pin	346-5705
9R-8202	Pin	346-5708
9R-8206	Pin	346-5709
9R-8523	Pin	346-5710
9R-8579	Pin	346-5711
9R-8662	Pin	346-5713
9R-9049	Pin	346-5717
9R-9403	Pinion	347-0477
9R-9812	Pin	347-0468
9T-2373	Head	347-0461
239-9956	Brake Disc	347-0485
9R-8663	Pin	365-8831

Sales Model 428

Original Part Number	Part Name	Classic Part Number
054-2213	Spider and Bearing As	347-0464
054-6549	Pinion - Planetary	347-0478
055-1260	Housing Bk - Outer	347-0479
160-1014	Pin As	347-0473
175-4070	Bushing - Sleeve	347-0484
186-4118	Gear - Planet	347-0483
7T-3173	Piston	346-5680
7T-3194	Yoke	346-5681
7W-5194	Muffler As	346-5682
9R-0080	Coupling	346-5683
9R-0097	Pin	346-5684
9R-0237	Pin As	346-5685

Original Part Number	Part Name	Classic Part Number
9R-0424	Pin	346-5686
9R-2410	Retainer As	346-5688
9R-2421	Shaft	346-5689
9R-2424	Gear - Planet Sun	346-5690
9R-2476	Disc - Bk Rear	346-5691
9R-2477	Disc As	346-5692
9R-2491	Spider	346-5693
9R-2846	Pin	346-5694
9R-2956	Pin	346-5695
9R-3161	Shaft - Sun Gear	346-5696
9R-3933	Pin	346-5697
9R-6158	Pin	346-5698
9R-6159	Pin	346-5699

Original Part Number	Part Name	Classic Part Number
9R-6160	Pin	346-5700
9R-6163	Pin	346-5701
9R-6475	Pad As	346-5702
9R-6545	Pin	346-5703
9R-7092	Bar	364-5272
9R-7158	Pin As	346-5704
9R-7894	Pin As	346-5706
9R-7895	Pin As	346-5707
9R-8639	Cylinder	346-5712
9R-8715	Spider and Bearing As	346-5716
9R-8718	Yoke As	364-5258
9R-9190	Rod Gp - Tie	346-5718
9R-9403	Pinion	347-0477
9R-9631	Pin	347-0467
9Y-9431	Precleaner As	361-1718

Sales Model 428B

Original Part Number	Part Name	Classic Part Number
054-2213	Spider and Bearing As	347-0464
054-6549	Pinion - Planetary	347-0478
102-4560	Bearing - Sleeve	347-0469
112-1773	Piston	347-0462
127-8592	Muffler As	347-0463
160-1014	Pin As	347-0473
175-4070	Bushing - Sleeve	347-0484
186-4118	Gear - Planet	347-0483
1M-7250	Bowl - Precleaner	360-2296
237-2252	Bearing - Sleeve	347-0474
239-9956	Brake Disc	347-0485
6E-1500	Piston	346-5677
6E-6153	Plate - Port	346-5678
6E-6163	Shaft	346-5679

Original Part Number	Part Name	Classic Part Number
7T-3173	Piston	346-5680
7T-3194	Yoke	346-5681
9R-0097	Pin	346-5684
9R-0424	Pin	346-5686
9R-2421	Shaft	346-5689
9R-2424	Gear - Planet Sun	346-5690
9R-2477	Disc As	346-5692
9R-2491	Spider	346-5693
9R-2846	Pin	346-5694
9R-2956	Pin	346-5695
9R-3161	Shaft - Sun Gear	346-5696
9R-3933	Pin	346-5697
9R-6159	Pin	346-5699
9R-6163	Pin	346-5701
9R-6545	Pin	346-5703
9R-7092	Bar	364-5272
9R-7158	Pin As	346-5704
9R-7696	Pin	346-5705

Original Part Number	Part Name	Classic Part Number
9R-8202	Pin	346-5708
9R-8206	Pin	346-5709
9R-8523	Pin	346-5710
9R-8579	Pin	346-5711
9R-8639	Cylinder	346-5712
9R-8662	Pin	346-5713
9R-8663	Pin	365-8831
9R-8707	Pin	346-5714
9R-8709	Pin	346-5715
9R-8715	Spider and Bearing As	346-5716
9R-8718	Yoke As	364-5258
9R-9049	Pin	346-5717
9R-9190	Rod Gp - Tie	346-5718
9R-9400	Case As	346-5719
9R-9402	Seal - Rax	347-0476
9R-9403	Pinion	347-0477
9R-9631	Pin	347-0467
9R-9812	Pin	347-0468
9Y-9431	Precleaner As	361-1718

Sales Model 428C

Orginal Part Number	Part Name	Classic Part Number
055-1986	Seal - Lip type	347-0465
102-4560	Bearing - Sleeve	347-0469
112-1773	Piston	347-0462
112-9629	Pin	347-0470
119-7042	Shaft	347-0480
119-7047	Seal	347-0481
122-1881	Plate - Clutch	347-0475
130-6879	Seal	347-0482
160-1014	Pin As	347-0473
167-2329	Seal - U-cup	347-0466
186-4118	Gear - Planet	347-0483
229-2949	Rod As - Track	347-0486

Orginal Part Number	Part Name	Classic Part Number
229-2950	Rod As - Track	347-0487
237-2252	Bearing - Sleeve	347-0474
239-9956	Brake Disc	347-0485
6E-1500	Piston	346-5677
9R-0097	Pin	346-5684
9R-2421	Shaft	346-5689
9R-2424	Gear - Planet Sun	346-5690
9R-2477	Disc As	346-5692
9R-2491	Spider	346-5693
9R-2956	Pin	346-5695
9R-3933	Pin	346-5697
9R-6159	Pin	346-5699

Orginal Part Number	Part Name	Classic Part Number
9R-6163	Pin	346-5701
9R-6545	Pin	346-5703
9R-7092	Bar	364-5272
9R-7696	Pin	346-5705
9R-8202	Pin	346-5708
9R-8206	Pin	346-5709
9R-8523	Pin	346-5710
9R-8579	Pin	346-5711
9R-8639	Cylinder	346-5712
9R-8662	Pin	346-5713
9R-8663	Pin	365-8831
9R-9190	Rod Gp - Tie	346-5718
9R-9403	Pinion	347-0477
9R-9812	Pin	347-0468
9T-2373	Head	347-0461

Cat® Classic™ Parts for Older Engines



Cat® Classic™ parts are available for the following engine models: D353C/D/E; D379/B; D398/B; D399; G353D; G379; G398; G399. First produced by Caterpillar more than four decades ago, thousands of these engines are still heavily relied upon in a variety of petroleum, marine, and prime power applications. As these engines age, maintenance costs sometimes need to be re-evaluated.

Cat Classic parts provide owners of older Cat products with low cost repair alternatives that minimize the risk associated with non-genuine parts.

Cat Classic parts offerings for engines include:

- Air, Manifold, & Outlet Elbows
- Cooler Core
- Cylinder Liner
- Front & Upper Manifolds
- Fuel Injection Lines & Pumps
- Fuel Transfer Pumps
- Gaskets
- Inlet & Exhaust Valves
- Pistons
- ...and many more.

Sales Model D353C, D353D, D353E

Original Part Number	Part Name	Classic Part Number
102-1561	Lifter As - Valve	311-9402
1A-2846	Cap As - Filler	311-9368
1F-2254	Bushing - Stem	314-8510
1P-1758	Bushing - Stem	311-9350
1P-8005	Gasket - Chamber	314-8527
1S-5738	Insert - Seat Exhaust	311-9396
1S-7114	Bolt	314-8500
1W-3062	Retainer As	311-9445
1W-5105	Ring Gp - Piston	311-9446
2F-5721	Bearing - Ball	311-9354
2L-4731	Adapter - Housing	311-9343
2N-3220	Gear - Oil Pump Drive	311-9392
2N-9297	Retainer - Spring	314-8535
2S-3966	Ring - Seal	297-7237
2S-7264	Pump As - Fuel Injector	311-9442
2W-3211	Valve - Exhaust	311-9471
3F-7445	Bearing - Sleeve	314-8508
3L-1425	Bearing - Ball	311-9356
3N-3368	Pipe - Exhaust	311-9434
3P-0651	Seal - o-Ring	314-8541
4F-4974	Clamp	311-9373
4M-9214	Shaft - Pump Drive	314-8543
4M-9215	Gear - Pump Idler	311-9391
4M-9216	Gear - Pump Drive	311-9390
4N-3664	Guide - Valve	314-8524
4N-7526	Seal As - Pump	311-9454
4N-9180	Seal As - Pump	311-9455
4S-8906	Insert	311-9397
4S-8908	Insert	311-9399
4S-8909	Insert - Valve Seat	311-9400
5F-7404	Nut - Bearing Lock	308-9878
5H-5553	Screw -Tappet Adjustable	311-9451
5L-8856	Coupling - Exhaust	311-9379
5L-9371	Connector - Inlet	311-9375
5L-9738	Coupling - Exhaust	311-9380
5M-6211	Shaft - Planet	219-9684
5P-7807	Bearing - Ball	314-8502
5S-1757	Insert - Seat	311-9401
6H-3957	Bearing - Ball	311-9358
6L-7816	Seal - o-Ring	314-8542
6L-8585	Gear - Gov Drive	314-8526
6L-8968	Coupling - Exhaust	311-9381
6N-6969	Chamber As	247-3299
6N-8847	Guide - Valve	314-8523
7B-2420	Ferrule - Director	314-8517
7C-5920	Insert - Seat	314-8528
7C-5921	Insert - Seat	314-8529
7C-5922	Insert - Seat	314-8530
7H-0602	Dog - Clutch	314-8515
7M-4603	Body - Fuel Valve	311-9348
7M-4926	Retainer - Pin	314-8538
7M-7431	Service Gp - Valve	314-8550
7M-7817	Valve - Inlet	311-9474
7N-4515	Body As - Piston	311-9346
7N-9810	Pin - Piston	311-9432
7S-5787	Chamber As	247-3300
7T-2036	Cap As - Filter	361-1721
8F-5104	Screen As - Oil Pan	314-8539
8F-8858	Button Valve	314-8511

(Continued)

Sales Model D353C, D353D, D353E (Continued)

Original Part Number	Part Name	Classic Part Number
8H-2810	Case As - Filter	314-8512
8M-0874	Plunger As - Valve	311-9439
8M-2549	Rod As - Connector	314-8537
8M-4014	Insert - Seat Exhaust	311-9398
8N-2275	Bearing - Sleeve	311-9365
8N-3723	Valve - Exhaust	311-9472
8N-7780	Shield - Oil	314-8544
8N-9174	Liner - Cylinder	314-8531
8S-3617	Chamber As	247-3302
9H-2256	Pump Gp	311-9443
9S-8493	Bolt - Connecting Rod	311-9351

Sales Model D379

Original Part Number	Part Name	Classic Part Number
0T-0259	Nut - Bearing Sleeve	311-9431
102-1561	Lifter As - Valve	311-9402
1A-2846	Cap As - Filler	311-9368
1F-2254	Bushing - Stem	314-8510
1F-4419	Gasket - Cover	311-9393
1N-5943	Manifold - Upper	311-9429
1N-7478	Manifold - Front	311-9428
1P-0009	Rod As - Conn	311-9450
1P-1758	Bushing - Stem	311-9350
1P-8005	Gasket - Chamber	314-8527
1S-5738	Insert - Seat Exhaust	311-9396
1S-7114	Bolt	314-8500
1W-3062	Retainer As	311-9445
1W-5105	Ring Gp - Piston	311-9446
1W-9205	Line As - Fuel Injector	311-9415
1W-9206	Line As - Fuel Injector	311-9416
1W-9207	Line As - Fuel Injector	311-9417
1W-9208	Line As - Fuel Injector	311-9418
1W-9209	Line As - Fuel Injector	311-9419
1W-9210	Line As - Fuel Injector	311-9420
1W-9211	Line As - Fuel Injector	311-9421
1W-9212	Line As - Fuel Injector	311-9422
2D-5658	Bearing - Ball	301-4628
2F-5721	Bearing - Ball	311-9354
2K-3592	Boss	314-8501
2L-4731	Adapter - Housing	311-9343
2N-3220	Gear - Oil Pump Drive	311-9392
2N-3227	Bracket - Lft Guide	311-9367
2N-7194	Cap - Main Bearing	311-9369
2N-7224	Cap As - Main Bearing	311-9370
2N-8519	Guide - Spring	314-8525
2N-9297	Retainer - Spring	314-8535
2P-1757	Hub - Fan Pulley	296-1357
2S-2781	Plunger - Relief	311-9435
2S-3966	Ring - Seal	297-7237
2S-4015	Plunger As - Valve	311-9438
2S-7264	Pump As - Fuel Injector	311-9442
2W-3211	Valve - Exhaust	311-9471
3F-7445	Bearing - Sleeve	314-8508
3L-1425	Bearing - Ball	311-9356
3N-2078	Pump Gp - Fuel Transfer	311-9444
3N-3148	Tube As	311-9461
3N-3368	Pipe - Exhaust	311-9434
3N-6841	Tube As - Inlet Rh	311-9464
3N-7326	Thrower - Camshaft Oil	311-9458
3N-7327	Thrower - Camshaft Oil	311-9459
3N-9160	Ring - Camshaft Seal	311-9447
3P-0651	Seal - o-Ring	314-8541
3S-9466	Bearing - Sleeve	314-8509
4F-4974	Clamp	311-9373
4L-3307	Elbow - Manifold Inlet	311-9387
4L-3756	Bearing - Thrust	311-9366
4L-4653	Plate - Thrust	311-9440
4L-7820	Rod Assembly	311-9449
4M-9215	Gear - Pump Idler	311-9391
4M-9216	Gear - Pump Drive	311-9390
4N-3664	Guide - Valve	314-8524
4N-6302	Belt Set - Vee	314-8495
4N-7526	Seal As - Pump	311-9454
4N-9180	Seal As - Pump	311-9455
4S-8906	Insert	311-9397
4S-8908	Insert	311-9399
4S-8909	Insert - Valve Seat	311-9400
4W-2606	Seal Gp - Camshaft	311-9452
4W-2607	Seal Gp - Camshaft	311-9453
4W-5550	Core As - Oil Cooler	311-9377
5H-5553	Screw -Tappet Adjustable	311-9451
5L-2648	Bearing - Sleeve	311-9362
5L-2660	Bearing - Sleeve	311-9363

(Continued)

Sales Model D379 (Continued)

Original Part Number	Part Name	Classic Part Number
5L-2894	Bearing - Sleeve	311-9364
5L-3980	V - Belt Set	314-8498
5L-5656	Belt Set - Vee	314-8499
5L-8856	Coupling - Exhaust	311-9379
5L-9370	Elbow - Manifold Inlet	311-9388
5L-9371	Connector - Inlet	311-9375
5L-9738	Coupling - Exhaust	311-9380
5M-7900	Bolt - Hex Head	311-9349
5N-2691	Elbow - Air Transfer	311-9383
5N-2692	Elbow - Air Transfer	311-9384
5N-2902	Seal - Oil	314-8540
5N-3009	Tube As - Inlet Lh	311-9465
5N-3012	Tube As - Inlet	311-9466
5N-3050	Elbow - Outlet	311-9389
5N-4378	Shaft As - Pump	311-9456
5P-7807	Bearing - Ball	314-8502
5S-1757	Insert - Seat	311-9401
5S-4557	Bearing	311-9360
6H-3217	Shaft As - Rocker	311-9457
6H-3957	Bearing - Ball	311-9358

Original Part Number	Part Name	Classic Part Number
6L-3910	Line As - Fuel	311-9424
6L-4714	Panel - Air Cleaner Filter	314-8532
6L-6481	Elbow - Air Inlet	311-9385
6L-6482	Elbow - Air Outlet	311-9386
6L-6491	Pipe - Crossover	311-9433
6L-7816	Seal - o-Ring	314-8542
6L-8585	Gear - Gov Drive	314-8526
6L-8968	Coupling - Exhaust	311-9381
6N-8847	Guide - Valve	314-8523
7B-2420	Ferrule - Director	314-8517
7C-5920	Insert - Seat	314-8528
7C-5921	Insert - Seat	314-8529
7C-5922	Insert - Seat	314-8530
7H-0602	Dog - Clutch	314-8515
7L-0104	Impeller - Pump	311-9395
7M-4603	Body - Fuel Valve	311-9348
7M-4926	Retainer - Pin	314-8538
7M-7431	Service Gp - Valve	314-8550
7M-7817	Valve - Inlet	311-9474
7N-4515	Body As - Piston	311-9346
7N-9810	Pin - Piston	311-9432

Original Part Number	Part Name	Classic Part Number
7S-5787	Chamber As	247-3300
7S-7809	Cap As - Radiator	295-6417
8B-5972	Bearing - Ball	314-8503
8F-5104	Screen As - Oil Pan	314-8539
8F-8858	Button Valve	314-8511
8L-3972	Baffle	311-9345
8M-0874	Plunger As - Valve	311-9439
8M-2549	Rod As - Connector	314-8537
8M-4014	Insert - Seat Exhaust	311-9398
8N-2275	Bearing - Sleeve	311-9365
8N-3723	Valve - Exhaust	311-9472
8N-7769	Bearing - Conn Rod	314-8505
8N-7770	Bearing - Conn Rod	314-8506
8N-7771	Bearing - Conn Rod	314-8507
8N-7780	Shield - Oil	314-8544
8N-9174	Liner - Cylinder	314-8531
8S-3617	Chamber As	247-3302
9H-2256	Pump Gp	311-9443
9K-8757	Rod End - Bearing	311-9361
9S-8493	Bolt - Connecting Rod	311-9351

Sales Model D379B

Original Part Number	Part Name	Classic Part Number
0T-0259	Nut - Bearing Sleeve	311-9431
102-1561	Lifter As - Valve	311-9402
1A-2846	Cap As - Filler	311-9368
1F-2254	Bushing - Stem	314-8510
1F-4419	Gasket - Cover	311-9393
1N-5943	Manifold - Upper	311-9429
1N-7478	Manifold - Front	311-9428
1P-0009	Rod As - Conn	311-9450

Original Part Number	Part Name	Classic Part Number
1P-1758	Bushing - Stem	311-9350
1P-8005	Gasket - Chamber	314-8527
1S-5738	Insert - Seat Exhaust	311-9396
1S-7114	Bolt	314-8500
1W-3062	Retainer As	311-9445
1W-5105	Ring Gp - Piston	311-9446
1W-9205	Line As - Fuel Injector	311-9415
1W-9206	Line As - Fuel Injector	311-9416

Original Part Number	Part Name	Classic Part Number
1W-9207	Line As - Fuel Injector	311-9417
1W-9208	Line As - Fuel Injector	311-9418
1W-9209	Line As - Fuel Injector	311-9419
1W-9210	Line As - Fuel Injector	311-9420
1W-9211	Line As - Fuel Injector	311-9421
1W-9212	Line As - Fuel Injector	311-9422
2D-5658	Bearing - Ball	301-4628
2F-5721	Bearing - Ball	311-9354
2K-3592	Boss	314-8501

(Continued)

Sales Model D379B (Continued)

Original Part Number	Part Name	Classic Part Number
2L-4731	Adapter - Housing	311-9343
2N-3220	Gear - Oil Pump Drive	311-9392
2N-3227	Bracket - Lft Guide	311-9367
2N-7194	Cap - Main Bearing	311-9369
2N-7224	Cap As - Main Bearing	311-9370
2N-8519	Guide - Spring	314-8525
2N-9297	Retainer - Spring	314-8535
2P-1757	Hub - Fan Pulley	296-1357
2S-2781	Plunger - Relief	311-9435
2S-3966	Ring - Seal	297-7237
2S-4015	Plunger As - Valve	311-9438
2S-7264	Pump As - Fuel Injector	311-9442
2W-3211	Valve - Exhaust	311-9471
3F-7445	Bearing - Sleeve	314-8508
3L-1425	Bearing - Ball	311-9356
3N-2078	Pump Gp - Fuel Transfer	311-9444
3N-3148	Tube As	311-9461
3N-3368	Pipe - Exhaust	311-9434
3N-6841	Tube As - Inlet Rh	311-9464
3N-7326	Thrower - Camshaft Oil	311-9458
3N-7327	Thrower - Camshaft Oil	311-9459
3N-9160	Ring - Camshaft Seal	311-9447
3P-0651	Seal - o-Ring	314-8541
3S-9466	Bearing - Sleeve	314-8509
4F-4974	Clamp	311-9373
4L-3307	Elbow - Manifold Inlet	311-9387
4L-3756	Bearing - Thrust	311-9366
4L-4653	Plate - Thrust	311-9440
4L-7820	Rod Assembly	311-9449
4M-9215	Gear - Pump Idler	311-9391
4M-9216	Gear - Pump Drive	311-9390
4N-3664	Guide - Valve	314-8524
4N-6302	Belt Set - Vee	314-8495
4N-7526	Seal As - Pump	311-9454
4N-9180	Seal As - Pump	311-9455
4S-8906	Insert	311-9397
4S-8908	Insert	311-9399
4S-8909	Insert - Valve Seat	311-9400
4W-2606	Seal Gp - Camshaft	311-9452
4W-2607	Seal Gp - Camshaft	311-9453
4W-5550	Core As - Oil Cooler	311-9377
5H-5553	Screw -Tappet Adjustable	311-9451
5L-2648	Bearing - Sleeve	311-9362
5L-2660	Bearing - Sleeve	311-9363
5L-2894	Bearing - Sleeve	311-9364
5L-3980	V - Belt Set	314-8498
5L-5656	Belt Set - Vee	314-8499
5L-8856	Coupling - Exhaust	311-9379
5L-9370	Elbow - Manifold Inlet	311-9388
5L-9371	Connector - Inlet	311-9375
5L-9738	Coupling - Exhaust	311-9380
5M-7900	Bolt - Hex Head	311-9349
5N-2691	Elbow - Air Transfer	311-9383
5N-2692	Elbow - Air Transfer	311-9384
5N-2902	Seal - Oil	314-8540
5N-3009	Tube As - Inlet Lh	311-9465
5N-3012	Tube As - Inlet	311-9466
5N-3050	Elbow - Outlet	311-9389
5N-4378	Shaft As - Pump	311-9456
5P-7807	Bearing - Ball	314-8502
5S-1757	Insert - Seat	311-9401
5S-4557	Bearing	311-9360
6H-3217	Shaft As - Rocker	311-9457
6H-3957	Bearing - Ball	311-9358
6L-3910	Line As - Fuel	311-9424
6L-4714	Panel - Air Cleaner Filter	314-8532
6L-6481	Elbow - Air Inlet	311-9385
6L-6482	Elbow - Air Outlet	311-9386
6L-6491	Pipe - Cross-over	311-9433
6L-7816	Seal - o-Ring	314-8542
6L-8585	Gear - Gov Drive	314-8526
6L-8968	Coupling - Exhaust	311-9381
6N-8847	Guide - Valve	314-8523
7B-2420	Ferrule - Director	314-8517
7C-5920	Insert - Seat	314-8528
7C-5921	Insert - Seat	314-8529
7C-5922	Insert - Seat	314-8530
7H-0602	Dog - Clutch	314-8515
7L-0104	Impeller - Pump	311-9395
7M-4603	Body - Fuel Valve	311-9348
7M-4926	Retainer - Pin	314-8538
7M-7431	Service Gp - Valve	314-8550
7M-7817	Valve - Inlet	311-9474
7N-4515	Body As - Piston	311-9346
7N-9810	Pin - Piston	311-9432
7S-5787	Chamber As	247-3300
7S-7809	Cap As - Radiator	295-6417
8B-5972	Bearing - Ball	314-8503
8F-5104	Screen As - Oil Pan	314-8539
8F-8858	Button Valve	314-8511
8L-3972	Baffle	311-9345
8M-0874	Plunger As - Valve	311-9439
8M-2549	Rod As - Connector	314-8537
8M-4014	Insert - Seat Exhaust	311-9398

(Continued)

Sales Model D379B (Continued)

Original Part Number	Part Name	Classic Part Number
8N-2275	Bearing - Sleeve	311-9365
8N-3723	Valve - Exhaust	311-9472
8N-7769	Bearing - Conn Rod	314-8505
8N-7770	Bearing - Conn Rod	314-8506
8N-7771	Bearing - Conn Rod	314-8507
8N-7780	Shield - Oil	314-8544
8N-9174	Liner - Cylinder	314-8531
8S-3617	Chamber As	247-3302
9H-2256	Pump Gp	311-9443
9K-8757	Rod End - Bearing	311-9361
9S-8493	Bolt - Connecting Rod	311-9351
5S-9062	Spacer	363-7463

Sales Model D398

Original Part Number	Part Name	Classic Part Number
0T-0259	Nut - Bearing Sleeve	311-9431
102-1561	Lifter As - Valve	311-9402
1F-2254	Bushing - Stem	314-8510
1F-4419	Gasket - Cover	311-9393
1N-5943	Manifold - Upper	311-9429
1N-7478	Manifold - Front	311-9428
1P-0009	Rod As - Conn	311-9450
1P-1758	Bushing - Stem	311-9350
1P-8005	Gasket - Chamber	314-8527
1S-5738	Insert - Seat Exhaust	311-9396
1S-7114	Bolt	314-8500
1W-3062	Retainer As	311-9445
1W-5105	Ring Gp - Piston	311-9446
1W-9201	Line As - Fuel Injector	311-9411
1W-9202	Line As - Fuel Injector	311-9412
1W-9203	Line As - Fuel Injector	311-9413
1W-9204	Line As - Fuel Injector	311-9414
1W-9205	Line As - Fuel Injector	311-9415
1W-9206	Line As - Fuel Injector	311-9416
1W-9207	Line As - Fuel Injector	311-9417
1W-9208	Line As - Fuel Injector	311-9418
1W-9209	Line As - Fuel Injector	311-9419
1W-9210	Line As - Fuel Injector	311-9420
1W-9211	Line As - Fuel Injector	311-9421
1W-9212	Line As - Fuel Injector	311-9422
2D-5658	Bearing - Ball	301-4628
2F-5721	Bearing - Ball	311-9354
2K-3592	Boss	314-8501
2L-4731	Adapter - Housing	311-9343
2N-3220	Gear - Oil Pump Drive	311-9392
2N-3227	Bracket - Lft Guide	311-9367
2N-7194	Cap - Main Bearing	311-9369
2N-7224	Cap As - Main Bearing	311-9370
2N-8519	Guide - Spring	314-8525
2N-9297	Retainer - Spring	314-8535
2S-2781	Plunger - Relief	311-9435
2S-3966	Ring - Seal	297-7237
2S-4015	Plunger As - Valve	311-9438
2S-7264	Pump As - Fuel Injector	311-9442
2W-3211	Valve - Exhaust	311-9471
3F-7445	Bearing - Sleeve	314-8508
3N-2078	Pump Gp - Fuel Transfer	311-9444
3N-3148	Tube As	311-9461
3N-3368	Pipe - Exhaust	311-9434
3N-6841	Tube As - Inlet Rh	311-9464
3N-7326	Thrower - Camshaft Oil	311-9458
3N-7327	Thrower - Camshaft Oil	311-9459
3N-9160	Ring - Camshaft Seal	311-9447
3P-0651	Seal - o-Ring	314-8541
3S-9466	Bearing - Sleeve	314-8509
4F-4974	Clamp	311-9373
4L-3307	Elbow - Manifold Inlet	311-9387
4L-3756	Bearing - Thrust	311-9366
4L-4653	Plate - Thrust	311-9440
4L-7820	Rod Assembly	311-9449
4M-9215	Gear - Pump Idler	311-9391
4M-9216	Gear - Pump Drive	311-9390
4N-3664	Guide - Valve	314-8524
4N-7526	Seal As - Pump	311-9454
4N-9180	Seal As - Pump	311-9455
4S-8906	Insert	311-9397
4S-8908	Insert	311-9399
4S-8909	Insert - Valve Seat	311-9400
4W-2606	Seal Gp - Camshaft	311-9452
4W-2607	Seal Gp - Camshaft	311-9453
4W-5549	Core As - Oil Cooler	311-9376
5H-5553	Screw -Tappet Adjustable	311-9451
5L-2648	Bearing - Sleeve	311-9362

(Continued)

Sales Model D398 (Continued)

Original Part Number	Part Name	Classic Part Number
5L-2660	Bearing - Sleeve	311-9363
5L-2894	Bearing - Sleeve	311-9364
5L-3980	V - Belt Set	314-8498
5L-5656	Belt Set - Vee	314-8499
5L-8856	Coupling - Exhaust	311-9379
5L-9370	Elbow - Manifold Inlet	311-9388
5L-9371	Connector - Inlet	311-9375
5L-9738	Coupling - Exhaust	311-9380
5M-7900	Bolt - Hex Head	311-9349
5N-2691	Elbow - Air Transfer	311-9383
5N-2692	Elbow - Air Transfer	311-9384
5N-2902	Seal - Oil	314-8540
5N-3009	Tube As - Inlet Lh	311-9465
5N-3012	Tube As - Inlet	311-9466
5N-3050	Elbow - Outlet	311-9389
5N-4378	Shaft As - Pump	311-9456
5P-7807	Bearing - Ball	314-8502
5S-1757	Insert - Seat	311-9401
5S-4557	Bearing	311-9360
6H-3217	Shaft As - Rocker	311-9457
6H-3957	Bearing - Ball	311-9358
6L-3902	Line As - Fuel	311-9423
6L-3910	Line As - Fuel	311-9424
6L-4714	Panel - Air Cleaner Filter	314-8532
6L-6481	Elbow - Air Inlet	311-9385
6L-6482	Elbow - Air Outlet	311-9386
6L-6491	Pipe - Cross-over	311-9433
6L-7816	Seal - o-Ring	314-8542
6L-8585	Gear - Gov Drive	314-8526
6L-8968	Coupling - Exhaust	311-9381
6N-6969	Chamber As	247-3299
6N-8847	Guide - Valve	314-8523
7B-2420	Ferrule - Director	314-8517
7C-5920	Insert - Seat	314-8528
7C-5921	Insert - Seat	314-8529
7C-5922	Insert - Seat	314-8530
7H-0602	Dog - Clutch	314-8515
7L-0104	Impeller - Pump	311-9395
7M-4603	Body - Fuel Valve	311-9348
7M-4926	Retainer - Pin	314-8538
7M-7431	Service Gp - Valve	314-8550
7M-7817	Valve - Inlet	311-9474
7N-4515	Body As - Piston	311-9346
7N-9810	Pin - Piston	311-9432
7S-5787	Chamber As	247-3300
7S-7809	Cap As - Radiator	295-6417
8B-5972	Bearing - Ball	314-8503
8F-5104	Screen As - Oil Pan	314-8539
8F-8858	Button Valve	314-8511
8H-2810	Case As - Filter	314-8512
8L-3972	Baffle	311-9345
8M-0874	Plunger As - Valve	311-9439
8M-2549	Rod As - Connector	314-8537
8M-4014	Insert - Seat Exhaust	311-9398
8N-2275	Bearing - Sleeve	311-9365
8N-3723	Valve - Exhaust	311-9472
8N-7769	Bearing - Conn Rod	314-8505
8N-7770	Bearing - Conn Rod	314-8506
8N-7771	Bearing - Conn Rod	314-8507
8N-7780	Shield - Oil	314-8544
8N-9174	Liner - Cylinder	314-8531
8S-3617	Chamber As	247-3302
9H-2256	Pump Gp	311-9443
9K-8757	Rod End - Bearing	311-9361
9S-8493	Bolt - Connecting Rod	311-9351

Sales Model D398B

Original Part Number	Part Name	Classic Part Number
0T-0259	Nut - Bearing Sleeve	311-9431
102-1561	Lifter As - Valve	311-9402
1F-2254	Bushing - Stem	314-8510
1F-4419	Gasket - Cover	311-9393
1N-5943	Manifold - Upper	311-9429
1N-7478	Manifold - Front	311-9428
1P-0009	Rod As - Conn	311-9450
1P-1758	Bushing - Stem	311-9350
1P-8005	Gasket - Chamber	314-8527
1S-5738	Insert - Seat Exhaust	311-9396
1S-7114	Bolt	314-8500
1W-3062	Retainer As	311-9445
1W-5105	Ring Gp - Piston	311-9446
1W-9201	Line As - Fuel Injector	311-9411
1W-9202	Line As - Fuel Injector	311-9412
1W-9203	Line As - Fuel Injector	311-9413
1W-9204	Line As - Fuel Injector	311-9414
1W-9205	Line As - Fuel Injector	311-9415
1W-9206	Line As - Fuel Injector	311-9416
1W-9207	Line As - Fuel Injector	311-9417
1W-9208	Line As - Fuel Injector	311-9418

(Continued)

Sales Model D398B (Continued)

Original Part Number	Part Name	Classic Part Number
1W-9209	Line As - Fuel Injector	311-9419
1W-9210	Line As - Fuel Injector	311-9420
1W-9211	Line As - Fuel Injector	311-9421
1W-9212	Line As - Fuel Injector	311-9422
2D-5658	Bearing - Ball	301-4628
2F-5721	Bearing - Ball	311-9354
2K-3592	Boss	314-8501
2L-4731	Adapter - Housing	311-9343
2N-3220	Gear - Oil Pump Drive	311-9392
2N-3227	Bracket - Lft Guide	311-9367
2N-7194	Cap - Main Bearing	311-9369
2N-7224	Cap As - Main Bearing	311-9370
2N-8519	Guide - Spring	314-8525
2N-9297	Retainer - Spring	314-8535
2S-2781	Plunger - Relief	311-9435
2S-3966	Ring - Seal	297-7237
2S-4015	Plunger As - Valve	311-9438
2S-7264	Pump As - Fuel Injector	311-9442
2W-3211	Valve - Exhaust	311-9471
3F-7445	Bearing - Sleeve	314-8508
3N-2078	Pump Gp - Fuel Transfer	311-9444
3N-3148	Tube As	311-9461
3N-3368	Pipe - Exhaust	311-9434
3N-6841	Tube As - Inlet Rh	311-9464
3N-7326	Thrower - Camshaft Oil	311-9458
3N-7327	Thrower - Camshaft Oil	311-9459
3N-9160	Ring - Camshaft Seal	311-9447
3P-0651	Seal - o-Ring	314-8541
3S-9466	Bearing - Sleeve	314-8509
4F-4974	Clamp	311-9373
4L-3307	Elbow - Manifold Inlet	311-9387
4L-3756	Bearing - Thrust	311-9366
4L-4653	Plate - Thrust	311-9440
4L-7820	Rod Assembly	311-9449
4M-9215	Gear - Pump Idler	311-9391
4M-9216	Gear - Pump Drive	311-9390
4N-3664	Guide - Valve	314-8524
4N-7526	Seal As - Pump	311-9454
4N-9180	Seal As - Pump	311-9455
4S-8906	Insert	311-9397
4S-8908	Insert	311-9399
4S-8909	Insert - Valve Seat	311-9400
4W-2606	Seal Gp - Camshaft	311-9452
4W-2607	Seal Gp - Camshaft	311-9453
4W-5549	Core As - Oil Cooler	311-9376
5H-5553	Screw -Tappet Adjustable	311-9451
5L-2648	Bearing - Sleeve	311-9362
5L-2660	Bearing - Sleeve	311-9363
5L-2894	Bearing - Sleeve	311-9364
5L-3980	V - Belt Set	314-8498
5L-5656	Belt Set - Vee	314-8499
5L-8856	Coupling - Exhaust	311-9379
5L-9370	Elbow - Manifold Inlet	311-9388
5L-9371	Connector - Inlet	311-9375
5L-9738	Coupling - Exhaust	311-9380
5M-7900	Bolt - Hex Head	311-9349
5N-2691	Elbow - Air Transfer	311-9383
5N-2692	Elbow - Air Transfer	311-9384
5N-2902	Seal - Oil	314-8540
5N-3009	Tube As - Inlet Lh	311-9465
5N-3012	Tube As - Inlet	311-9466
5N-3050	Elbow - Outlet	311-9389
5N-4378	Shaft As - Pump	311-9456
5P-7807	Bearing - Ball	314-8502
5S-1757	Insert - Seat	311-9401
5S-4557	Bearing	311-9360
6H-3217	Shaft As - Rocker	311-9457
6H-3957	Bearing - Ball	311-9358
6L-3902	Line As - Fuel	311-9423
6L-3910	Line As - Fuel	311-9424
6L-4714	Panel - Air Cleaner Filter	314-8532
6L-6481	Elbow - Air Inlet	311-9385
6L-6482	Elbow - Air Outlet	311-9386
6L-6491	Pipe - Crossover	311-9433
6L-7816	Seal - o-Ring	314-8542
6L-8585	Gear - Gov Drive	314-8526
6L-8968	Coupling - Exhaust	311-9381
6N-6969	Chamber As	247-3299
6N-8847	Guide - Valve	314-8523
7B-2420	Ferrule - Director	314-8517
7C-5920	Insert - Seat	314-8528
7C-5921	Insert - Seat	314-8529
7C-5922	Insert - Seat	314-8530
7H-0602	Dog - Clutch	314-8515
7L-0104	Impeller - Pump	311-9395
7M-4603	Body - Fuel Valve	311-9348
7M-4926	Retainer - Pin	314-8538
7M-7431	Service Gp - Valve	314-8550
7M-7817	Valve - Inlet	311-9474
7N-4515	Body As - Piston	311-9346
7N-9810	Pin - Piston	311-9432
7S-5787	Chamber As	247-3300
7S-7809	Cap As - Radiator	295-6417
8B-5972	Bearing - Ball	314-8503

(Continued)

Sales Model D398B (Continued)

Original Part Number	Part Name	Classic Part Number
8F-5104	Screen As - Oil Pan	314-8539
8F-8858	Button Valve	314-8511
8H-2810	Case As - Filter	314-8512
8L-3972	Baffle	311-9345
8M-0874	Plunger As - Valve	311-9439
8M-2549	Rod As - Connector	314-8537
8M-4014	Insert - Seat Exhaust	311-9398
8N-2275	Bearing - Sleeve	311-9365
8N-3723	Valve - Exhaust	311-9472
8N-7769	Bearing - Conn Rod	314-8505
8N-7770	Bearing - Conn Rod	314-8506
8N-7771	Bearing - Conn Rod	314-8507
8N-7780	Shield - Oil	314-8544
8N-9174	Liner - Cylinder	314-8531
8S-3617	Chamber As	247-3302
9H-2256	Pump Gp	311-9443
9K-8757	Rod End - Bearing	311-9361
9S-8493	Bolt - Connecting Rod	311-9351

Sales Model D399

Original Part Number	Part Name	Classic Part Number
102-1561	Lifter As - Valve	311-9402
1F-4419	Gasket - Cover	311-9393
1N-5943	Manifold - Upper	311-9429
1N-7478	Manifold - Front	311-9428
1P-0009	Rod As - Conn	311-9450
1P-1758	Bushing - Stem	311-9350
1P-8005	Gasket - Chamber	314-8527
1S-7114	Bolt	314-8500
1W-3062	Retainer As	311-9445
1W-5105	Ring Gp - Piston	311-9446
1W-9191	Line As - Fuel Injector	311-9403
1W-9192	Line As - Fuel Injector	311-9404
1W-9193	Line As - Fuel Injector	311-9405
1W-9194	Line As - Fuel Injector	311-9406
1W-9195	Line As - Fuel Injector	311-9407
1W-9196	Line As - Fuel Injector	311-9408
1W-9197	Line As - Fuel Injector	311-9409
1W-9198	Line As - Fuel Injector	311-9410
2F-5721	Bearing - Ball	311-9354
2K-3592	Boss	314-8501
2L-4731	Adapter - Housing	311-9343
2N-3220	Gear - Oil Pump Drive	311-9392
2N-3227	Bracket - Lft Guide	311-9367
2N-7194	Cap - Main Bearing	311-9369
2N-7224	Cap As - Main Bearing	311-9370
2N-8519	Guide - Spring	314-8525
2N-9297	Retainer - Spring	314-8535
2S-2781	Plunger - Relief	311-9435
2S-3966	Ring - Seal	297-7237
2S-4015	Plunger As - Valve	311-9438
2S-7264	Pump As - Fuel Injector	311-9442
2W-3211	Valve - Exhaust	311-9471
3F-7445	Bearing - Sleeve	314-8508
3N-2078	Pump Gp - Fuel Transfer	311-9444
3N-3148	Tube As	311-9461
3N-3368	Pipe - Exhaust	311-9434
3N-6841	Tube As - Inlet Rh	311-9464
3N-7326	Thrower - Camshaft Oil	311-9458
3N-7327	Thrower - Camshaft Oil	311-9459
3N-9160	Ring - Camshaft Seal	311-9447
3P-0651	Seal - o-Ring	314-8541
3S-9466	Bearing - Sleeve	314-8509
4F-4974	Clamp	311-9373
4L-3756	Bearing - Thrust	311-9366
4L-4653	Plate - Thrust	311-9440
4L-7820	Rod Assembly	311-9449
4M-9215	Gear - Pump Idler	311-9391
4M-9216	Gear - Pump Drive	311-9390
4N-3664	Guide - Valve	314-8524
4N-7526	Seal As - Pump	311-9454
4N-9180	Seal As - Pump	311-9455
4S-8906	Insert	311-9397
4S-8908	Insert	311-9399
4S-8909	Insert - Valve Seat	311-9400
4W-2606	Seal Gp - Camshaft	311-9452
4W-2607	Seal Gp - Camshaft	311-9453
4W-5551	Core As - Oil Cooler	311-9378
5D-0470	Valve Gp	314-8549
5H-5553	Screw -Tappet Adjustable	311-9451
5L-2648	Bearing - Sleeve	311-9362
5L-2660	Bearing - Sleeve	311-9363
5L-2894	Bearing - Sleeve	311-9364

(Continued)

Sales Model D399 (Continued)

Original Part Number	Part Name	Classic Part Number
5L-3980	V - Belt Set	314-8498
5L-8856	Coupling - Exhaust	311-9379
5L-9370	Elbow - Manifold Inlet	311-9388
5L-9371	Connector - Inlet	311-9375
5L-9738	Coupling - Exhaust	311-9380
5M-7900	Bolt - Hex Head	311-9349
5N-2691	Elbow - Air Transfer	311-9383
5N-2692	Elbow - Air Transfer	311-9384
5N-2902	Seal - Oil	314-8540
5N-3009	Tube As - Inlet Lh	311-9465
5N-3012	Tube As - Inlet	311-9466
5N-3050	Elbow - Outlet	311-9389
5N-4378	Shaft As - Pump	311-9456
5P-7807	Bearing - Ball	314-8502
5S-1757	Insert - Seat	311-9401
5S-4557	Bearing	311-9360
6H-3217	Shaft As - Rocker	311-9457
6L-4714	Panel - Air Cleaner Filter	314-8532
6L-6481	Elbow - Air Inlet	311-9385
6L-6482	Elbow - Air Outlet	311-9386
6L-6491	Pipe - Crossover	311-9433
6L-7816	Seal - o-Ring	314-8542
6L-8585	Gear - Gov Drive	314-8526
6L-8968	Coupling - Exhaust	311-9381
6N-8847	Guide - Valve	314-8523
7B-2420	Ferrule - Director	314-8517
7L-0104	Impeller - Pump	311-9395
7M-4603	Body - Fuel Valve	311-9348
7M-4926	Retainer - Pin	314-8538
7M-7431	Service Gp - Valve	314-8550
7M-7817	Valve - Inlet	311-9474
7N-4515	Body As - Piston	311-9346
7N-9810	Pin - Piston	311-9432
7S-5787	Chamber As	247-3300
7S-7809	Cap As - Radiator	295-6417
8F-8858	Button Valve	314-8511
8H-2810	Case As - Filter	314-8512
8L-3972	Baffle	311-9345
8M-0874	Plunger As - Valve	311-9439
8M-4014	Insert - Seat Exhaust	311-9398
8N-2275	Bearing - Sleeve	311-9365
8N-3723	Valve - Exhaust	311-9472
8N-7769	Bearing - Conn Rod	314-8505
8N-7770	Bearing - Conn Rod	314-8506
8N-7771	Bearing - Conn Rod	314-8507
8N-7780	Shield - Oil	314-8544
8N-9174	Liner - Cylinder	314-8531
8S-3617	Chamber As	247-3302
9K-8757	Rod End - Bearing	311-9361
9S-8493	Bolt - Connecting Rod	311-9351

Sales Model G353D

Original Part Number	Part Name	Classic Part Number
102-1561	Lifter As - Valve	311-9402
1P-1758	Bushing - Stem	311-9350
1S-5738	Insert - Seat Exhaust	311-9396
1W-5105	Ring Gp - Piston	311-9446
2F-5721	Bearing - Ball	311-9354
2N-9297	Retainer - Spring	314-8535
2S-3966	Ring - Seal	297-7237
2W-3211	Valve - Exhaust	311-9471
3F-7445	Bearing - Sleeve	314-8508
3N-3368	Pipe - Exhaust	311-9434
3P-0651	Seal - o-Ring	314-8541
4F-4974	Clamp	311-9373
4N-3664	Guide - Valve	314-8524
4N-7526	Seal As - Pump	311-9454
4N-9180	Seal As - Pump	311-9455
4S-8906	Insert	311-9397
4S-8908	Insert	311-9399
4S-8909	Insert - Valve Seat	311-9400
5F-7404	Nut - Bearing Lock	308-9878
5L-8856	Coupling - Exhaust	311-9379
5P-7807	Bearing - Ball	314-8502
5S-1757	Insert - Seat	311-9401
6H-3957	Bearing - Ball	311-9358
6L-7816	Seal - o-Ring	314-8542
6L-8968	Coupling - Exhaust	311-9381
6N-8847	Guide - Valve	314-8523
7B-2420	Ferrule - Director	314-8517
7C-4297	Seal As - Camshaft	325-6192
7C-5920	Insert - Seat	314-8528
7C-5921	Insert - Seat	314-8529
7C-5922	Insert - Seat	314-8530
7M-4926	Retainer - Pin	314-8538
7M-7817	Valve - Inlet	311-9474
7N-9810	Pin - Piston	311-9432
8F-8858	Button Valve	314-8511
8H-2810	Case As - Filter	314-8512
8M-4014	Insert - Seat Exhaust	311-9398
8N-2275	Bearing - Sleeve	311-9365
8N-3723	Valve - Exhaust	311-9472

(Continued)

Sales Model G353D (Continued)

Original Part Number	Part Name	Classic Part Number
8N-9174	Liner - Cylinder	314-8531
9S-8493	Bolt - Connecting Rod	311-9351

Sales Model G379

Original Part Number	Part Name	Classic Part Number
0T-0259	Nut - Bearing Sleeve	311-9431
102-1561	Lifter As - Valve	311-9402
1F-4419	Gasket - Cover	311-9393
1P-0009	Rod As - Conn	311-9450
1P-1758	Bushing - Stem	311-9350
1P-8005	Gasket - Chamber	314-8527
1S-5738	Insert - Seat Exhaust	311-9396
1W-3062	Retainer As	311-9445
1W-5105	Ring Gp - Piston	311-9446
2D-5658	Bearing - Ball	301-4628
2F-5721	Bearing - Ball	311-9354
2N-3220	Gear - Oil Pump Drive	311-9392
2N-3227	Bracket - Lft Guide	311-9367
2N-7194	Cap - Main Bearing	311-9369
2N-7224	Cap As - Main Bearing	311-9370
2N-8519	Guide - Spring	314-8525
2N-9297	Retainer - Spring	314-8535
2P-1757	Hub - Fan Pulley	296-1357
2S-2781	Plunger - Relief	311-9435
2S-3966	Ring - Seal	297-7237
2W-3211	Valve - Exhaust	311-9471
3F-7445	Bearing - Sleeve	314-8508
3L-1425	Bearing - Ball	311-9356
3N-3368	Pipe - Exhaust	311-9434
3N-7326	Thrower - Camshaft Oil	311-9458
3N-7327	Thrower - Camshaft Oil	311-9459
3N-9160	Ring - Camshaft Seal	311-9447
3P-0651	Seal - o-Ring	314-8541
4F-4974	Clamp	311-9373
4L-3307	Elbow - Manifold Inlet	311-9387
4L-3756	Bearing - Thrust	311-9366
4L-4653	Plate - Thrust	311-9440
4L-7820	Rod Assembly	311-9449
4N-3664	Guide - Valve	314-8524
4N-6302	Belt Set - Vee	314-8495
4N-7526	Seal As - Pump	311-9454
4N-9180	Seal As - Pump	311-9455
4S-8906	Insert	311-9397
4S-8908	Insert	311-9399
4S-8909	Insert - Valve Seat	311-9400
4W-2606	Seal Gp - Camshaft	311-9452
4W-2607	Seal Gp - Camshaft	311-9453
4W-5550	Core As - Oil Cooler	311-9377
5L-2648	Bearing - Sleeve	311-9362
5L-2660	Bearing - Sleeve	311-9363
5L-2894	Bearing - Sleeve	311-9364
5L-3980	V - Belt Set	314-8498
5L-5656	Belt Set - Vee	314-8499
5L-8856	Coupling - Exhaust	311-9379
5L-9370	Elbow - Manifold Inlet	311-9388
5L-9371	Connector - Inlet	311-9375
5N-3050	Elbow - Outlet	311-9389
5N-4378	Shaft As - Pump	311-9456
5P-7807	Bearing - Ball	314-8502
5S-1757	Insert - Seat	311-9401
6H-3217	Shaft As - Rocker	311-9457
6H-3957	Bearing - Ball	311-9358
6L-4714	Panel - Air Cleaner Filter	314-8532
6L-6481	Elbow - Air Inlet	311-9385
6L-6491	Pipe - Crossover	311-9433
6L-7816	Seal - o-Ring	314-8542
6L-8585	Gear - Gov Drive	314-8526
6L-8968	Coupling - Exhaust	311-9381
6N-8847	Guide - Valve	314-8523
7B-2420	Ferrule - Director	314-8517
7C-5920	Insert - Seat	314-8528
7C-5921	Insert - Seat	314-8529
7C-5922	Insert - Seat	314-8530
7H-0602	Dog - Clutch	314-8515
7L-0104	Impeller - Pump	311-9395
7M-4926	Retainer - Pin	314-8538
7M-7817	Valve - Inlet	311-9474
7N-9810	Pin - Piston	311-9432
7S-5787	Chamber As	247-3300
8B-5972	Bearing - Ball	314-8503
8F-5104	Screen As - Oil Pan	314-8539
8F-8858	Button Valve	314-8511
8H-2810	Case As - Filter	314-8512
8L-3972	Baffle	311-9345
8M-2549	Rod As - Connector	314-8537
8M-4014	Insert - Seat Exhaust	311-9398
8N-2275	Bearing - Sleeve	311-9365

(Continued)

Sales Model G379 (Continued)

Original Part Number	Part Name	Classic Part Number
8N-3723	Valve - Exhaust	311-9472
8N-7769	Bearing - Conn Rod	314-8505
8N-7770	Bearing - Conn Rod	314-8506
8N-7771	Bearing - Conn Rod	314-8507
8N-7780	Shield - Oil	314-8544
8N-9174	Liner - Cylinder	314-8531
8S-3617	Chamber As	247-3302

Sales Model G398

Original Part Number	Part Name	Classic Part Number
0T-0259	Nut - Bearing Sleeve	311-9431
102-1561	Lifter As - Valve	311-9402
1F-4419	Gasket - Cover	311-9393
1P-0009	Rod As - Conn	311-9450
1P-1758	Bushing - Stem	311-9350
1P-8005	Gasket - Chamber	314-8527
1S-5738	Insert - Seat Exhaust	311-9396
1W-3062	Retainer As	311-9445
1W-5105	Ring Gp - Piston	311-9446
2D-5658	Bearing - Ball	301-4628
2F-5721	Bearing - Ball	311-9354
2N-3220	Gear - Oil Pump Drive	311-9392
2N-3227	Bracket - Lft Guide	311-9367
2N-7194	Cap - Main Bearing	311-9369
2N-7224	Cap As - Main Bearing	311-9370
2N-8519	Guide - Spring	314-8525
2N-9297	Retainer - Spring	314-8535
2S-2781	Plunger - Relief	311-9435
2S-3966	Ring - Seal	297-7237
2W-3211	Valve - Exhaust	311-9471
3F-7445	Bearing - Sleeve	314-8508
3N-3368	Pipe - Exhaust	311-9434
3N-7326	Thrower - Camshaft Oil	311-9458
3N-7327	Thrower - Camshaft Oil	311-9459
3N-9160	Ring - Camshaft Seal	311-9447
3P-0651	Seal - o-Ring	314-8541
4F-4974	Clamp	311-9373
4L-3307	Elbow - Manifold Inlet	311-9387
4L-3756	Bearing - Thrust	311-9366
4L-4653	Plate - Thrust	311-9440
4L-7820	Rod Assembly	311-9449
4N-3664	Guide - Valve	314-8524
4N-7526	Seal As - Pump	311-9454
4N-9180	Seal As - Pump	311-9455
4S-8906	Insert	311-9397
4S-8908	Insert	311-9399
4S-8909	Insert - Valve Seat	311-9400
4W-2606	Seal Gp - Camshaft	311-9452
4W-2607	Seal Gp - Camshaft	311-9453
4W-5549	Core As - Oil Cooler	311-9376
5L-2648	Bearing - Sleeve	311-9362
5L-2660	Bearing - Sleeve	311-9363
5L-2894	Bearing - Sleeve	311-9364
5L-3980	V - Belt Set	314-8498
5L-5656	Belt Set - Vee	314-8499
5L-8856	Coupling - Exhaust	311-9379
5L-9370	Elbow - Manifold Inlet	311-9388
5L-9371	Connector - Inlet	311-9375
5N-3050	Elbow - Outlet	311-9389
5N-4378	Shaft As - Pump	311-9456
5P-7807	Bearing - Ball	314-8502
5S-1757	Insert - Seat	311-9401
6H-3217	Shaft As - Rocker	311-9457
6H-3957	Bearing - Ball	311-9358
6L-4714	Panel - Air Cleaner Filter	314-8532
6L-6481	Elbow - Air Inlet	311-9385
6L-6491	Pipe - Crossover	311-9433
6L-7816	Seal - o-Ring	314-8542
6L-8585	Gear - Gov Drive	314-8526
6L-8968	Coupling - Exhaust	311-9381
6N-8847	Guide - Valve	314-8523
7B-2420	Ferrule - Director	314-8517
7C-5920	Insert - Seat	314-8528
7C-5921	Insert - Seat	314-8529
7C-5922	Insert - Seat	314-8530
7H-0602	Dog - Clutch	314-8515
7L-0104	Impeller - Pump	311-9395
7M-4926	Retainer - Pin	314-8538
7M-7817	Valve - Inlet	311-9474
7N-9810	Pin - Piston	311-9432
7S-5787	Chamber As	247-3300
8B-5972	Bearing - Ball	314-8503
8F-5104	Screen As - Oil Pan	314-8539
8F-8858	Button Valve	314-8511
8H-2810	Case As - Filter	314-8512
8L-3972	Baffle	311-9345
8M-2549	Rod As - Connector	314-8537

(Continued)

Sales Model G398 (Continued)

Original Part Number	Part Name	Classic Part Number
8M-4014	Insert - Seat Exhaust	311-9398
8N-2275	Bearing - Sleeve	311-9365
8N-3723	Valve - Exhaust	311-9472
8N-7769	Bearing - Conn Rod	314-8505
8N-7770	Bearing - Conn Rod	314-8506
8N-7771	Bearing - Conn Rod	314-8507
8N-7780	Shield - Oil	314-8544
8N-9174	Liner - Cylinder	314-8531
8S-3617	Chamber As	247-3302

Sales Model G399

Original Part Number	Part Name	Classic Part Number
102-1561	Lifter As - Valve	311-9402
1F-4419	Gasket - Cover	311-9393
1P-0009	Rod As - Conn	311-9450
1P-1758	Bushing - Stem	311-9350
1P-8005	Gasket - Chamber	314-8527
1S-5738	Insert - Seat Exhaust	311-9396
1W-3062	Retainer As	311-9445
1W-5105	Ring Gp - Piston	311-9446
2F-5721	Bearing - Ball	311-9354
2N-3220	Gear - Oil Pump Drive	311-9392
2N-3227	Bracket - Lft Guide	311-9367
2N-7194	Cap - Main Bearing	311-9369
2N-7224	Cap As - Main Bearing	311-9370
2N-8519	Guide - Spring	314-8525
2N-9297	Retainer - Spring	314-8535
2S-2781	Plunger - Relief	311-9435
2S-3966	Ring - Seal	297-7237
2W-3211	Valve - Exhaust	311-9471
3F-7445	Bearing - Sleeve	314-8508
3N-3368	Pipe - Exhaust	311-9434
3N-7326	Thrower - Camshaft Oil	311-9458
3N-7327	Thrower - Camshaft Oil	311-9459
3N-9160	Ring - Camshaft Seal	311-9447
3P-0651	Seal - o-Ring	314-8541
4F-4974	Clamp	311-9373
4L-3756	Bearing - Thrust	311-9366
4L-4653	Plate - Thrust	311-9440
4L-7820	Rod Assembly	311-9449
4N-3664	Guide - Valve	314-8524
4N-7526	Seal As - Pump	311-9454
4N-9180	Seal As - Pump	311-9455
4S-8906	Insert	311-9397
4S-8908	Insert	311-9399
4S-8909	Insert - Valve Seat	311-9400
4W-2606	Seal Gp - Camshaft	311-9452
4W-2607	Seal Gp - Camshaft	311-9453
4W-5551	Core As - Oil Cooler	311-9378
5D-0470	Valve Gp	314-8549
5L-2648	Bearing - Sleeve	311-9362
5L-2660	Bearing - Sleeve	311-9363
5L-2894	Bearing - Sleeve	311-9364
5L-3980	V - Belt Set	314-8498
5L-8856	Coupling - Exhaust	311-9379
5L-9370	Elbow - Manifold Inlet	311-9388
5L-9371	Connector - Inlet	311-9375
5N-3050	Elbow - Outlet	311-9389
5N-4378	Shaft As - Pump	311-9456
5P-7807	Bearing - Ball	314-8502
5S-1757	Insert - Seat	311-9401
6H-3217	Shaft As - Rocker	311-9457
6L-4714	Panel - Air Cleaner Filter	314-8532
6L-6481	Elbow - Air Inlet	311-9385
6L-6491	Pipe - Crossover	311-9433
6L-7816	Seal - o-Ring	314-8542
6L-8585	Gear - Gov Drive	314-8526
6L-8968	Coupling - Exhaust	311-9381
6N-8847	Guide - Valve	314-8523
7B-2420	Ferrule - Director	314-8517
7C-5920	Insert - Seat	314-8528
7C-5921	Insert - Seat	314-8529
7C-5922	Insert - Seat	314-8530
7L-0104	Impeller - Pump	311-9395
7M-4926	Retainer - Pin	314-8538
7M-7817	Valve - Inlet	311-9474
7N-9810	Pin - Piston	311-9432
7S-5787	Chamber As	247-3300
8F-8858	Button Valve	314-8511
8H-2810	Case As - Filter	314-8512
8L-3972	Baffle	311-9345
8M-4014	Insert - Seat Exhaust	311-9398
8N-2275	Bearing - Sleeve	311-9365
8N-3723	Valve - Exhaust	311-9472
8N-7769	Bearing - Conn Rod	314-8505
8N-7770	Bearing - Conn Rod	314-8506
8N-7771	Bearing - Conn Rod	314-8507
8N-7780	Shield - Oil	314-8544

(Continued)

Sales Model G399 (Continued)

Original Part Number	Part Name	Classic Part Number
8N-9174	Liner - Cylinder	314-8531
8S-3617	Chamber As	247-3302

Cat® Classic™ Parts for Excavators

Cat® excavators are built to last; however, as the machine ages, the cost to repair the machine is often re-evaluated. This is why Caterpillar offers the Cat® Classic™ parts product line. They are intended to help you manage your owning and operating costs towards the end of a product's life cycle. Cat Classic parts are available for several older models of excavators.

Cat Classic parts provide owners of older Cat products with low cost repair alternatives that minimize the risk associated with non-genuine parts.

Cat Classic parts coverage for excavators includes:

- Engine
- Final Drive
- Linkage Pin
- Transmission Shafts/Gears
- Non-Moving U/C
- Pump Drive
- ...and many more.

Sales Model 215

Original Part Number	Part Name	Classic Part Number
100-7860	Valve - Inlet	270-4360 (Valve), 270-4362 (Valve Kit)
104-4253	Line As - Fuel Injector	279-4988
104-4254	Line As - Fuel Injector	279-4989
111-8015	Gasket As - Head	279-4977
112-3818	Shaft - Input	302-2698
112-5585	Shaft - Planet	308-9932
112-8041	Carrier - Planet	295-5681
121-7746	Precleaner As	360-2311
131-3815	Seal Gp - Basic	325-6193
148-7455	Valve - Exhaust	270-4361
172-5185	Shaft - Water Pump	325-6201
172-5188	Shaft - Water Pump	325-6202
172-5189	Impeller - Pump	295-5687
172-5190	Impeller - Pump	325-6111
172-6712	Impeller - Pump	325-6112
172-7767	Pump Gp - Water	296-1365
190-8609	Valve - Fill	360-2288
196-0028	Gear As - Idler	364-5259
1M-7250	Bowl - Precleaner	360-2296
1N-3576	Block Gp - Cylinder	279-4978
1N-3958	Elbow	325-6087
1N-4304	Head Gp - Cylinder	269-8761
1P-1216	Manifold - Exhaust	261-0902
1P-1721	Gear - Balance	298-2769
1P-1722	Gear - Balance	298-2770
1P-9946	Shaft - Fan	325-6194
1S-4701	Pulley - Alt	264-5866
1S-5331	Cylinder - Adjustable	226-0214
1V-6342	Gear As	308-9847
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1695	Pump Gp	279-4980
1W-1698	Housing - Transfer Pump	296-1356
1W-2870	Shaft As - Balance	314-8715
1W-2871	Shaft As - Balance	314-8716
1W-4402	Gear - Camshaft	279-4981
1W-4405	Gear - Crankshaft	279-4982
1W-5912	Tappet As - Guide	325-6223
1W-6541	Plunger As	325-6173
244-1090	Alarm - Back up	360-2345
2D-5658	Bearing - Ball	301-4628
2F-5721	Bearing - Ball	311-9354
2K-3592	Boss	314-8501
2P-1170	Shaft As - Gear	296-1367
2P-1757	Hub - Fan Pulley	296-1357
2P-1781	Spacer - Oil Pump	325-6214
2P-2519	Tube As - Inlet	325-6230
2P-2719	Pipe	363-7454
2P-6245	Shaft As - Pump	325-6197
2P-7828	Pan - Oil	314-8691
2V-0707	Bearing - Sleeve	360-2328
2V-0961	Driver	231-0255
2W-1086	Cover As - Cylinder Head	325-6049
2W-2621	Valve - Inlet	247-6892 (Valve), 241-3381 (Valve Kit)
2W-7255	Shaft - Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear - Water Pump	325-6088

(Continued)

Sales Model 215 (Continued)

Original Part Number	Part Name	Classic Part Number
3L-1425	Bearing - Ball	311-9356
3T-2145	Carrier As	325-6041
3T-9153	Rim - Sprocket	322-6303
3V-5257	Bracket - Carriage Roller	297-7149
3V-5317	Gear	231-0010
3V-5378	Gear - Output	231-0235
3V-6648	Pin As	308-9884
3V-9439	Retainer As	231-0257
4E-3456	Lever As	367-6081
4E-9426	Collar	231-0000
4F-4974	Clamp	311-9373
4N-2954	Sleeve - Camshaft	299-2059
4N-4539	Sleeve	314-8720
4N-7692	Crankshaft As	242-3440
4N-7693	Crankshaft As	242-3439
4N-7977	Shaft As - Balance	314-8709
4N-7978	Shaft As - Balance	314-8710
4N-9587	Shield - Heat	297-7260
4P-3546	Valve As - Relief	325-6236
4P-4010	Muffler As	298-2788
4P-9381	Line As - Fuel Injector	279-4984
4P-9382	Line As - Fuel Injector	279-4985
4P-9961	Line As - Fuel Injector	325-6115
4P-9962	Line As - Fuel Injector	325-6116
4P-9963	Line As - Fuel Injector	298-2777
4P-9964	Line As - Fuel Injector	298-2778
4T-5172	Seal As	325-6189
4V-2518	Shaft	297-7243
4V-3680	Bellcrank	308-9802
4V-9236	Plate - Pressure	231-0260
4V-9577	Shaft - Planet	231-0001
4W-0452	Seal As - Camshaft	325-6191
4W-2042	Spacer	325-6217
5C-0451	Gear Gp - Bearing	235-5053
5C-0949	Link As	290-3452
5C-1834	Gear	231-0002
5C-3712	Gear	231-0003
5C-3714	Gear	231-0222
5C-3715	Gear	231-0223
5C-3716	Gear	231-0224
5C-3717	Gear	231-0225
5C-3784	Pin As	241-2512
5C-5038	Pin As	241-2506
5C-5153	Cartridge	231-0011
5C-5236	Gear	231-0226
5C-5829	Pin As	241-2510
5C-5837	Retainer - Pin	299-2047
5C-5937	Gear	231-0004
5C-6690	Pin As	241-2508
5C-8172	Pin As	241-2515
5C-8582	Shaft - Planet	231-0241
5C-8583	Gear - Ring	231-0005
5C-8584	Gear - Planet	231-0006
5C-8586	Gear	231-0007
5C-8587	Cover	231-0243
5C-8966	Gear	231-0227
5J-6421	Bearing	256-4801
5P-7807	Bearing - Ball	314-8502
5P-8194	Ring - Retaining	308-9920
5S-6795	Chamber As	242-3437
5S-9062	Spacer	363-7463
5S-9080	Pulley - Alt Drive	264-5883
5V-7207	Pinion - Final Drive	231-0252
5V-7222	Gear - Final Drive	231-0237
6A-4701	Gear	231-0231
6A-7129	Bearing - Sleeve	301-3130
6A-7534	Retainer	231-0244
6A-7539	Sprocket - Track	322-6304
6C-0739	Carrier As	231-0012
6C-1573	Rod	297-7238
6C-3495	Sprocket - Track	322-6302
6C-3740	Shaft As	231-0013
6C-5062	Pinion	231-0016
6H-3957	Bearing - Ball	311-9358
6I-1346	Pump Gp - Oil	295-5674
6N-1036	Gear - Oil Pump	279-4991
6N-1553	Coupling - Exhaust	295-6422
6N-3256	Mount As	314-8688
6N-8413	Housing - Pump	325-6110
6P-7704	Carrier - Ring	314-8658
6T-0511	Link As	290-3449
6T-1705	Shaft - Pump Drive	283-5201
6T-1706	Gear - Pump Drive	283-5202
6W-2398	Retainer	231-0014
6W-3674	Gear	231-0228
6Y-2054	Plate As	302-2695
6Y-4819	Carrier - Planet	296-1348
7C-3567	Mount As	314-8689
7C-4297	Seal As - Camshaft	325-6192
7G-2516	Gear - Planet	283-5203
7G-2830	Ring - Seal	295-6441
7G-5618	Manifold As	283-5204
7G-7218	Carrier - Planet	283-5205
7G-7724	Piston - Clutch	283-5206
7J-9708	Bearing - Sleeve	299-1964
7K-0252	Gear - Ring	231-0008
7K-7237	Gear - Planet	231-0009
7M-1851	Bolt - Spring	226-0223
7M-1856	Pilot - Recoil Spring	226-0225
7N-0061	Muffler As	360-7889
7N-0128	Core As - Oil Cooler	299-1994
7N-0165	Core As - Oil Cooler	295-5670
7N-1164	Mount As	295-5451
7N-2949	Pulley	264-5887
7N-3515	Gear - Camshaft	314-8669
7N-3536	Gear - Fuel	279-4993
7N-5910	Impeller - Pump	314-8686
7N-9145	Gear - Flywheel	279-4994
7N-9805	Pin - Piston	295-6438
7P-2372	Joint As	367-6072
7S-3161	Lifter - Valve	279-4996
7S-6723	Bracket - Alternator	299-1978
7S-7070	Head As - Cylinder	325-6107

(Continued)

Sales Model 215 (Continued)

Original Part Number	Part Name	Classic Part Number
7T-3370	Yoke As	302-2702
7T-5038	Housing As	297-7202
7T-9370	Gear - Sun	283-5207
7V-5981	Driver	231-0256
7V-7973	Gear Final Drive	231-0239
7V-7974	Pinion Final Drive	231-0253
7W-0450	Gear - Water Pump	279-4997
7W-0507	Gear - Oil Pump Drive	279-4998
7W-0508	Gear - Fuel Pump Drive	296-1351
7W-3042	Tube As - Drain	325-6231
7W-5687	Hub - Camshaft	314-8684
8E-3332	Shoe - Track	175-8184
8E-7494	Roller Gp - SF	175-8185
8H-2810	Case As - Filter	314-8512
8H-7980	Piston	226-0249
8K-0323	Link As	290-3450
8K-0665	Cage - Bearing	231-0262
8K-1749	Shaft - Sprocket	231-0242
8K-1754	Spacer	231-0247
8K-1755	Retainer - Cap	231-0246
8K-1756	Cage - Bearing	231-0263
8K-2518	Joint As	231-0267
8K-2682	Adapter	231-0268
8K-4699	Link As	290-3451
8M-6191	Sleeve - Bolt	226-0234
8N-0875	Valve - Exhaust	247-6893 (Valve), 241-3381 (Valve Kit)
8N-1187	Head Gp - Cylinder	242-3435
8N-1188	Head Gp - Cylinder	242-3436
8N-1721	Rod As - Conn	269-5291
8N-2510	Shaft	325-6208
8N-2641	Sleeve	325-6210
8N-3251	Shaft As - Rocker Arm	314-8711
8N-3312	Shaft As - Rocker Arm	325-6200
8N-3325	Arm Gp - Rocker	314-8623
8N-3327	Arm Gp - Rocker	314-8624
8N-5305	Spacer	363-7464
8N-5929	Cover - Water Pump	296-1349
8N-6796	Head Gp - Cylinder	269-5290
8N-7315	Tube As - Outlet	325-6232
8N-7780	Shield - Oil	314-8544
8N-8225	Bearing - Main	314-8652
8P-0953	Turbine - Converter	297-7269
8P-1121	Ring - Clamp	299-2049
8P-1892	Piston - Clutch	283-5208
8P-1916	Gear - Planet	283-5209
8P-1918	Gear - Planet	283-5210
8P-1919	Gear - Planet	300-2579
8P-2042	Shaft - Planet	283-5211
8P-8677	Hub - Impeller	297-7205
8P-9507	Piston - Clutch	283-5212
8S-0248	Breather As	325-6033
8S-0493	Shaft As - Pump	325-6198
8S-3970	Chamber As	242-3438
9C-1618	Gear	231-0229
9C-2646	Sprocket - Track	289-9674
9C-6244	Gear	231-0230
9G-0280	Piston - Clutch	283-5213
9G-0284	Housing - Clutch	283-5214
9G-0285	Piston - Clutch	283-5215
9G-0289	Shaft - Planet	283-5216
9G-0290	Hub - Clutch	283-5217
9G-2413	Shaft - Output	297-7255
9G-7411	Gear - Oil Pump Drive	297-7182
9G-7412	Gear As - Oil Pump	297-7183
9K-8757	Rod End - Bearing	311-9361
9L-6371	Rod	363-7459
9M-4789	Shaft - Gov Control	297-7256
9N-5769	Cover - Housing	325-6050
9P-7757	Gear - Sun	283-5218
9P-8623	Shaft - Planet	314-8719
9P-8624	Shaft - Planet	295-5446
9P-8626	Gear - Sun	283-5219
9P-9031	Gear - Sun	283-5220
9P-9517	Stator - Converter	297-7262
9P-9610	Pump Gp	283-5221
9P-9790	Shaft - Output	302-2696
9S-2356	Manifold - Exhaust	261-0905
9S-6129	Pulley - Alternator Drive	264-5891
9S-8679	Chamber As	325-6042
9U-2400	Housing As	231-0249
9W-3605	Carrier - Ring	314-8662
9W-8270	Gear - Ring	308-9859
9W-8384	Hub - Turbine	297-7207
9W-8433	Shaft As - Output	302-4249
9W-8437	Gear - Sun	283-5222
9W-9069	Shaft - Input	302-2715
9Y-2992	Bearing - Sleeve	325-6032

Sales Model 215B

Original Part Number	Part Name	Classic Part Number
100-7860	Valve - Inlet	270-4360 (Valve), 270-4362 (Valve Kit)
104-4253	Line As - Fuel Injector	279-4988
104-4254	Line As - Fuel Injector	279-4989
111-8015	Gasket As - Head	279-4977
112-3818	Shaft - Input	302-2698
112-5585	Shaft - Planet	308-9932
112-8041	Carrier - Planet	295-5681
121-7746	Precleaner As	360-2311
122-9405	Bracket As	325-6005
131-3815	Seal Gp - Basic	325-6193
148-7455	Valve - Exhaust	270-4361
167-8123	Damper As	299-2006
172-5185	Shaft - Water Pump	325-6201
172-5188	Shaft - Water Pump	325-6202
172-5189	Impeller - Pump	295-5687
172-5190	Impeller - Pump	325-6111
172-6712	Impeller - Pump	325-6112
172-7767	Pump Gp - Water	296-1365
190-8609	Valve - Fill	360-2288
196-0028	Gear As - Idler	364-5259
1M-7250	Bowl - Precleaner	360-2296
1N-3576	Block Gp - Cylinder	279-4978
1N-3958	Elbow	325-6087
1N-4304	Head Gp - Cylinder	269-8761
1P-1216	Manifold - Exhaust	261-0902
1P-1721	Gear - Balance	298-2769
1P-1722	Gear - Balance	298-2770
1S-4701	Pulley - Alt	264-5866
1S-5331	Cylinder - Adjustable	226-0214
1V-6342	Gear As	308-9847
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1695	Pump Gp	279-4980
1W-1698	Housing - Transfer Pump	296-1356
1W-2870	Shaft As - Balance	314-8715
1W-2871	Shaft As - Balance	314-8716
1W-4402	Gear - Camshaft	279-4981
1W-4405	Gear - Crankshaft	279-4982
1W-5912	Tappet As - Guide	325-6223
1W-6541	Plunger As	325-6173
244-1090	Alarm - Back up	360-2345
2D-5658	Bearing - Ball	301-4628
2F-5721	Bearing - Ball	311-9354
2K-3592	Boss	314-8501
2P-1170	Shaft As - Gear	296-1367
2P-1438	Pipe - Exhaust Ext	325-6157
2P-1738	Plate As - Oil Pan	325-6164
2P-1739	Tube As - Pump	325-6229
2P-1757	Hub - Fan Pulley	296-1357
2P-1781	Spacer - Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2519	Tube As - Inlet	325-6230
2P-2719	Pipe	363-7454
2P-5608	Pipe - Extension	367-6066
2P-6245	Shaft As - Pump	325-6197
2P-7828	Pan - Oil	314-8691
2V-0707	Bearing - Sleeve	360-2328
2V-0961	Driver	231-0255
2W-1086	Cover As - Cylinder Head	325-6049
2W-2621	Valve - Inlet	247-6892 (Valve), 241-3381 (Valve Kit)
2W-6757	Trunnion As	295-5678
2W-7255	Shaft - Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
3L-1425	Bearing - Ball	311-9356
3T-2145	Carrier As	325-6041
3V-5257	Bracket - Carriage Roller	297-7149
3V-5317	Gear	231-0010
3V-5378	Gear - Output	231-0235
3V-6648	Pin As	308-9884
3V-9439	Retainer As	231-0257
4E-3456	Lever As	367-6081
4E-9426	Collar	231-0000
4F-4974	Clamp	311-9373
4N-4539	Sleeve	314-8720
4N-4782	Pulley	325-6176
4N-7692	Crankshaft As	242-3440
4N-7693	Crankshaft As	242-3439
4N-9587	Shield - Heat	297-7260
4P-3546	Valve As - Relief	325-6236
4P-4010	Muffler As	298-2788
4P-9381	Line As - Fuel Injector	279-4984
4P-9382	Line As - Fuel Injector	279-4985
4P-9385	Line As - Fuel Injector	279-4986
4P-9386	Line As - Fuel Injector	279-4987
4P-9961	Line As - Fuel Injector	325-6115
4P-9962	Line As - Fuel Injector	325-6116
4P-9963	Line As - Fuel Injector	298-2777
4P-9964	Line As - Fuel Injector	298-2778
4T-5172	Seal As	325-6189
4V-2518	Shaft	297-7243
4V-3680	Bellcrank	308-9802
4V-9236	Plate - Pressure	231-0260
4W-0452	Seal As - Camshaft	325-6191
4W-2042	Spacer	325-6217
4W-2446	Damper As	279-4990
5C-0451	Gear Gp - Bearing	235-5053

(Continued)

Sales Model 215B (Continued)

Original Part Number	Part Name	Classic Part Number
5C-1834	Gear	231-0002
5C-3712	Gear	231-0003
5C-3714	Gear	231-0222
5C-3715	Gear	231-0223
5C-3716	Gear	231-0224
5C-3717	Gear	231-0225
5C-3784	Pin As	241-2512
5C-5038	Pin As	241-2506
5C-5153	Cartridge	231-0011
5C-5236	Gear	231-0226
5C-5829	Pin As	241-2510
5C-5837	Retainer - Pin	299-2047
5C-5937	Gear	231-0004
5C-6690	Pin As	241-2508
5C-8172	Pin As	241-2515
5C-8582	Shaft - Planet	231-0241
5C-8583	Gear - Ring	231-0005
5C-8584	Gear - Planet	231-0006
5C-8586	Gear	231-0007
5C-8587	Cover	231-0243
5C-8966	Gear	231-0227
5J-6421	Bearing	256-4801
5P-7807	Bearing - Ball	314-8502
5P-8194	Ring - Retaining	308-9920
5S-4557	Bearing	311-9360
5S-6795	Chamber As	242-3437
5S-9062	Spacer	363-7463
5S-9080	Pulley - Alt Drive	264-5883
5V-7207	Pinion - Final Drive	231-0252
5V-7222	Gear - Final Drive	231-0237
6A-7129	Bearing - Sleeve	301-3130
6A-7534	Retainer	231-0244
6C-0739	Carrier As	231-0012
6C-1573	Rod	297-7238
6C-3740	Shaft As	231-0013
6C-5062	Pinion	231-0016
6H-3957	Bearing - Ball	311-9358
6I-1346	Pump Gp - Oil	295-5674
6N-1036	Gear - Oil Pump	279-4991
6N-1553	Coupling - Exhaust	295-6422
6N-3256	Mount As	314-8688
6N-8413	Housing - Pump	325-6110
6P-7704	Carrier - Ring	314-8658
6T-1705	Shaft - Pump Drive	283-5201
6T-1706	Gear - Pump Drive	283-5202
6W-2398	Retainer	231-0014
6W-3674	Gear	231-0228
6Y-2054	Plate As	302-2695
6Y-4819	Carrier - Planet	296-1348
7C-3567	Mount As	314-8689
7G-2516	Gear - Planet	283-5203
7G-2830	Ring - Seal	295-6441
7G-5618	Manifold As	283-5204
7G-7218	Carrier - Planet	283-5205
7G-7724	Piston - Clutch	283-5206
7J-9708	Bearing - Sleeve	299-1964
7M-1851	Bolt - Spring	226-0223
7M-1856	Pilot - Recoil Spring	226-0225
7N-0061	Muffler As	360-7889
7N-0128	Core As - Oil Cooler	299-1994
7N-0165	Core As - Oil Cooler	295-5670
7N-1164	Mount As	295-5451
7N-2949	Pulley	264-5887
7N-3515	Gear - Camshaft	314-8669
7N-5910	Impeller - Pump	314-8686
7N-9145	Gear - Flywheel	279-4994
7N-9146	Gear - Flywheel Starter	279-4995
7N-9312	Damper As - Camshaft	299-2005
7N-9805	Pin - Piston	295-6438
7P-2372	Joint As	367-6072
7S-3161	Lifter - Valve	279-4996
7S-6723	Bracket - Alternator	299-1978
7S-7809	Cap As - Radiator	295-6417
7T-3370	Yoke As	302-2702
7T-5038	Housing As	297-7202
7T-9370	Gear - Sun	283-5207
7V-5981	Driver	231-0256
7V-7973	Gear Final Drive	231-0239
7V-7974	Pinion Final Drive	231-0253
7W-0450	Gear - Water Pump	279-4997
7W-0507	Gear - Oil Pump Drive	279-4998
7W-0508	Gear - Fuel Pump Drive	296-1351
7W-3042	Tube As - Drain	325-6231
7W-5687	Hub - Camshaft	314-8684
8H-2810	Case As - Filter	314-8512
8H-7980	Piston	226-0249
8K-0665	Cage - Bearing	231-0262
8K-1749	Shaft - Sprocket	231-0242
8K-1754	Spacer	231-0247
8K-1755	Retainer - Cap	231-0246
8K-1756	Cage - Bearing	231-0263
8K-2518	Joint As	231-0267
8K-2682	Adapter	231-0268
8M-6191	Sleeve - Bolt	226-0234
8N-0875	Valve - Exhaust	247-6893 (Valve), 241-3381 (Valve Kit)
8N-1187	Head Gp - Cylinder	242-3435
8N-1188	Head Gp - Cylinder	242-3436
8N-1721	Rod As - Conn	269-5291
8N-2510	Shaft	325-6208
8N-2641	Sleeve	325-6210
8N-3251	Shaft As - Rocker Arm	314-8711
8N-3312	Shaft As - Rocker Arm	325-6200
8N-3325	Arm Gp - Rocker	314-8623
8N-3327	Arm Gp - Rocker	314-8624
8N-5305	Spacer	363-7464
8N-5929	Cover - Water Pump	296-1349

(Continued)

Sales Model 215B (Continued)

Original Part Number	Part Name	Classic Part Number
8N-6796	Head Gp - Cylinder	269-5290
8N-7315	Tube As - Outlet	325-6232
8N-8225	Bearing - Main	314-8652
8P-0953	Turbine - Converter	297-7269
8P-1121	Ring - Clamp	299-2049
8P-1892	Piston - Clutch	283-5208
8P-1916	Gear - Planet	283-5209
8P-1918	Gear - Planet	283-5210
8P-1919	Gear - Planet	300-2579
8P-2042	Shaft - Planet	283-5211
8P-8677	Hub - Impeller	297-7205
8P-9507	Piston - Clutch	283-5212
8S-0248	Breather As	325-6033
8S-0493	Shaft As - Pump	325-6198
8S-3970	Chamber As	242-3438
9C-1618	Gear	231-0229
9C-6244	Gear	231-0230
9G-0280	Piston - Clutch	283-5213
9G-0284	Housing - Clutch	283-5214
9G-0285	Piston - Clutch	283-5215
9G-0289	Shaft - Planet	283-5216
9G-0290	Hub - Clutch	283-5217
9G-2413	Shaft - Output	297-7255
9G-7411	Gear - Oil Pump Drive	297-7182
9G-7412	Gear As - Oil Pump	297-7183
9K-8757	Rod End - Bearing	311-9361
9L-6371	Rod	363-7459
9N-5769	Cover - Housing	325-6050
9P-7757	Gear - Sun	283-5218
9P-8623	Shaft - Planet	314-8719
9P-8624	Shaft - Planet	295-5446
9P-8626	Gear - Sun	283-5219
9P-9031	Gear - Sun	283-5220
9P-9517	Stator - Converter	297-7262
9P-9610	Pump Gp	283-5221
9P-9790	Shaft - Output	302-2696
9S-2354	Manifold - Exhaust	261-0888
9S-2355	Manifold - Exhaust	261-0891
9S-6129	Pulley - Alternator Drive	264-5891
9S-8679	Chamber As	325-6042
9U-2400	Housing As	231-0249
9W-3605	Carrier - Ring	314-8662
9W-8270	Gear - Ring	308-9859
9W-8384	Hub - Turbine	297-7207
9W-8433	Shaft As - Output	302-4249
9W-8437	Gear - Sun	283-5222
9W-9069	Shaft - Input	302-2715
9Y-2992	Bearing - Sleeve	325-6032

Sales Model 215C

Original Part Number	Part Name	Classic Part Number
100-7860	Valve - Inlet	270-4360 (Valve), 270-4362 (Valve Kit)
104-4253	Line As - Fuel Injector	279-4988
104-4254	Line As - Fuel Injector	279-4989
111-8015	Gasket As - Head	279-4977
121-7746	Precleaner As	360-2311
131-3815	Seal Gp - Basic	325-6193
148-7455	Valve - Exhaust	270-4361
172-5185	Shaft - Water Pump	325-6201
172-5188	Shaft - Water Pump	325-6202
172-5189	Impeller - Pump	295-5687
172-5190	Impeller - Pump	325-6111
172-6712	Impeller - Pump	325-6112
172-7767	Pump Gp - Water	296-1365
190-8609	Valve - Fill	360-2288
196-0028	Gear As - Idler	364-5259
1M-7250	Bowl - Precleaner	360-2296
1N-3576	Block Gp - Cylinder	279-4978
1N-3958	Elbow	325-6087
1N-4304	Head Gp - Cylinder	269-8761
1P-1216	Manifold - Exhaust	261-0902
1P-1721	Gear - Balance	298-2769
1P-1722	Gear - Balance	298-2770
1S-4701	Pulley - Alt	264-5866
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1695	Pump Gp	279-4980
1W-1698	Housing - Transfer Pump	296-1356
1W-2870	Shaft As - Balance	314-8715
1W-2871	Shaft As - Balance	314-8716
1W-4402	Gear - Camshaft	279-4981
1W-4405	Gear - Crankshaft	279-4982
1W-5912	Tappet As - Guide	325-6223
1W-6541	Plunger As	325-6173
244-1090	Alarm - Backup	360-2345
2D-5658	Bearing - Ball	301-4628
2F-5721	Bearing - Ball	311-9354
2K-3592	Boss	314-8501
2P-1170	Shaft As - Gear	296-1367
2P-1757	Hub - Fan Pulley	296-1357
2P-1781	Spacer - Oil Pump	325-6214

(Continued)

Sales Model 215C (Continued)

Original Part Number	Part Name	Classic Part Number
2P-2519	Tube As - Inlet	325-6230
2P-2719	Pipe	363-7454
2P-6245	Shaft As - Pump	325-6197
2P-7828	Pan - Oil	314-8691
2V-0707	Bearing - Sleeve	360-2328
2V-0961	Driver	231-0255
2V-1722	Pin As	241-2525
2W-1086	Cover As - Cylinder Head	325-6049
2W-2621	Valve - Inlet	247-6892 (Valve), 241-3381 (Valve Kit)
2W-7255	Shaft - Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
3L-1425	Bearing - Ball	311-9356
4E-1065	Pin As	241-2538
4E-9426	Collar	231-0000
4F-4974	Clamp	311-9373
4N-4539	Sleeve	314-8720
4N-7692	Crankshaft As	242-3440
4N-7693	Crankshaft As	242-3439
4P-3546	Valve As - Relief	325-6236
4P-4010	Muffler As	298-2788
4P-9381	Line As - Fuel Injector	279-4984
4P-9382	Line As - Fuel Injector	279-4985
4P-9961	Line As - Fuel Injector	325-6115
4P-9962	Line As - Fuel Injector	325-6116
4P-9963	Line As - Fuel Injector	298-2777
4P-9964	Line As - Fuel Injector	298-2778
4T-5172	Seal As	325-6189
4W-0452	Seal As - Camshaft	325-6191
5C-0451	Gear Gp - Bearing	235-5053
5C-1834	Gear	231-0002
5C-3712	Gear	231-0003
5C-3714	Gear	231-0222
5C-3715	Gear	231-0223
5C-3716	Gear	231-0224
5C-3717	Gear	231-0225
5C-3784	Pin As	241-2512
5C-5038	Pin As	241-2506
5C-5153	Cartridge	231-0011
5C-5236	Gear	231-0226
5C-5829	Pin As	241-2510
5C-5837	Retainer - Pin	299-2047
5C-5937	Gear	231-0004
5C-6690	Pin As	241-2508
5C-8172	Pin As	241-2515
5C-8582	Shaft - Planet	231-0241
5C-8583	Gear - Ring	231-0005
5C-8584	Gear - Planet	231-0006
5C-8586	Gear	231-0007
5C-8587	Cover	231-0243
5C-8966	Gear	231-0227
5J-6421	Bearing	256-4801
5P-7807	Bearing - Ball	314-8502
5S-6795	Chamber As	242-3437
5S-9062	Spacer	363-7463
5S-9080	Pulley - Alt Drive	264-5883
6A-7129	Bearing - Sleeve	301-3130
6A-7534	Retainer	231-0244
6C-0739	Carrier As	231-0012
6C-1573	Rod	297-7238
6C-3740	Shaft As	231-0013
6C-5062	Pinion	231-0016
6H-3957	Bearing - Ball	311-9358
6I-1346	Pump Gp - Oil	295-5674
6N-1036	Gear - Oil Pump	279-4991
6N-1553	Coupling - Exhaust	295-6422
6N-3256	Mount As	314-8688
6N-8413	Housing - Pump	325-6110
6W-2398	Retainer	231-0014
6W-3674	Gear	231-0228
7C-3567	Mount As	314-8689
7N-0165	Core As - Oil Cooler	295-5670
7N-1164	Mount As	295-5451
7N-2949	Pulley	264-5887
7N-5910	Impeller - Pump	314-8686
7N-9145	Gear - Flywheel	279-4994
7N-9805	Pin - Piston	295-6438
7S-3161	Lifter - Valve	279-4996
7S-6723	Bracket - Alternator	299-1978
7V-5981	Driver	231-0256
7W-0450	Gear - Water Pump	279-4997
7W-0507	Gear - Oil Pump Drive	279-4998
7W-0508	Gear - Fuel Pump Drive	296-1351
7W-3042	Tube As - Drain	325-6231
7W-5687	Hub - Camshaft	314-8684
8G-4189	Bearing - Aligning	295-6411
8H-2810	Case As - Filter	314-8512
8K-0665	Cage - Bearing	231-0262
8K-2518	Joint As	231-0267
8K-2682	Adapter	231-0268
8N-0875	Valve - Exhaust	247-6893 (Valve), 241-3381 (Valve Kit)
8N-1187	Head Gp - Cylinder	242-3435
8N-1188	Head Gp - Cylinder	242-3436
8N-1721	Rod As - Conn	269-5291
8N-2510	Shaft	325-6208
8N-2641	Sleeve	325-6210
8N-3251	Shaft As - Rocker Arm	314-8711
8N-3312	Shaft As - Rocker Arm	325-6200
8N-3325	Arm Gp - Rocker	314-8623
8N-3327	Arm Gp - Rocker	314-8624
8N-5305	Spacer	363-7464
8N-5929	Cover - Water Pump	296-1349
8N-6796	Head Gp - Cylinder	269-5290
8N-7315	Tube As - Outlet	325-6232
8N-8225	Bearing - Main	314-8652
8R-7336	Bearing	301-3394
8S-0493	Shaft As - Pump	325-6198

(Continued)

Sales Model 215C (Continued)

Original Part Number	Part Name	Classic Part Number
8S-3970	Chamber As	242-3438
9C-1618	Gear	231-0229
9C-6244	Gear	231-0230
9K-8425	Bearing - Sleeve	314-8638
9K-8757	Rod End - Bearing	311-9361
9N-5769	Cover - Housing	325-6050
9S-6129	Pulley - Alternator Drive	264-5891
9S-8679	Chamber As	325-6042
9U-2400	Housing As	231-0249
9Y-2992	Bearing - Sleeve	325-6032

Sales Model 215D

Original Part Number	Part Name	Classic Part Number
100-7860	Valve - Inlet	270-4360 (Valve), 270-4362 (Valve Kit)
104-4253	Line As - Fuel Injector	279-4988
104-4254	Line As - Fuel Injector	279-4989
111-8015	Gasket As - Head	279-4977
121-7746	Precleaner As	360-2311
131-3815	Seal Gp - Basic	325-6193
148-7455	Valve - Exhaust	270-4361
172-5185	Shaft - Water Pump	325-6201
172-5188	Shaft - Water Pump	325-6202
172-5189	Impeller - Pump	295-5687
172-5190	Impeller - Pump	325-6111
172-6712	Impeller - Pump	325-6112
172-7767	Pump Gp - Water	296-1365
190-8609	Valve - Fill	360-2288
196-0028	Gear As - Idler	364-5259
1M-7250	Bowl - Precleaner	360-2296
1N-3576	Block Gp - Cylinder	279-4978
1N-3958	Elbow	325-6087
1N-4304	Head Gp - Cylinder	269-8761
1P-1216	Manifold - Exhaust	261-0902
1P-1721	Gear - Balance	298-2769
1P-1722	Gear - Balance	298-2770
1S-4701	Pulley - Alt	264-5866
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1695	Pump Gp	279-4980
1W-1698	Housing - Transfer Pump	296-1356
1W-2870	Shaft As - Balance	314-8715
1W-2871	Shaft As - Balance	314-8716
1W-4402	Gear - Camshaft	279-4981
1W-4405	Gear - Crankshaft	279-4982
1W-5912	Tappet As - Guide	325-6223
1W-6541	Plunger As	325-6173
244-1090	Alarm - Back up	360-2345
2D-5658	Bearing - Ball	301-4628
2F-5721	Bearing - Ball	311-9354
2K-3592	Boss	314-8501
2P-1170	Shaft As - Gear	296-1367
2P-1757	Hub - Fan Pulley	296-1357
2P-1781	Spacer - Oil Pump	325-6214
2P-2519	Tube As - Inlet	325-6230
2P-2719	Pipe	363-7454
2P-6128	Pulley	264-5872
2P-6245	Shaft As - Pump	325-6197
2P-7828	Pan - Oil	314-8691
2V-0961	Driver	231-0255
2V-1722	Pin As	241-2525
2W-1086	Cover As - Cylinder Head	325-6049
2W-2621	Valve - Inlet	247-6892 (Valve), 241-3381 (Valve Kit)
2W-7255	Shaft - Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
3L-1425	Bearing - Ball	311-9356
4E-0183	Pin	301-7976
4E-1065	Pin As	241-2538
4E-9426	Collar	231-0000
4F-4974	Clamp	311-9373
4N-4539	Sleeve	314-8720
4N-7692	Crankshaft As	242-3440
4N-7693	Crankshaft As	242-3439
4P-3546	Valve As - Relief	325-6236
4P-4010	Muffler As	298-2788
4P-9381	Line As - Fuel Injector	279-4984
4P-9382	Line As - Fuel Injector	279-4985
4P-9961	Line As - Fuel Injector	325-6115
4P-9962	Line As - Fuel Injector	325-6116
4P-9963	Line As - Fuel Injector	298-2777
4P-9964	Line As - Fuel Injector	298-2778
4T-5172	Seal As	325-6189
4W-0452	Seal As - Camshaft	325-6191
5C-0451	Gear Gp - Bearing	235-5053
5C-1834	Gear	231-0002
5C-3712	Gear	231-0003
5C-3714	Gear	231-0222
5C-3715	Gear	231-0223
5C-3716	Gear	231-0224
5C-3717	Gear	231-0225

(Continued)

Sales Model 215D (Continued)

Original Part Number	Part Name	Classic Part Number
5C-3784	Pin As	241-2512
5C-5038	Pin As	241-2506
5C-5153	Cartridge	231-0011
5C-5236	Gear	231-0226
5C-5829	Pin As	241-2510
5C-5837	Retainer - Pin	299-2047
5C-5937	Gear	231-0004
5C-8172	Pin As	241-2515
5C-8582	Shaft - Planet	231-0241
5C-8583	Gear - Ring	231-0005
5C-8584	Gear - Planet	231-0006
5C-8586	Gear	231-0007
5C-8587	Cover	231-0243
5C-8966	Gear	231-0227
5J-6421	Bearing	256-4801
5P-7807	Bearing - Ball	314-8502
5S-6795	Chamber As	242-3437
5S-9062	Spacer	363-7463
5S-9080	Pulley - Alt Drive	264-5883
6A-7129	Bearing - Sleeve	301-3130
6A-7534	Retainer	231-0244
6C-0739	Carrier As	231-0012
6C-1573	Rod	297-7238
6C-3740	Shaft As	231-0013
6C-5062	Pinion	231-0016
6H-3957	Bearing - Ball	311-9358
6I-1346	Pump Gp - Oil	295-5674
6N-1036	Gear - Oil Pump	279-4991
6N-1553	Coupling - Exhaust	295-6422
6N-3256	Mount As	314-8688
6N-8413	Housing - Pump	325-6110
6W-2398	Retainer	231-0014
6W-3674	Gear	231-0228
7C-3567	Mount As	314-8689
7N-0165	Core As - Oil Cooler	295-5670
7N-1164	Mount As	295-5451
7N-2949	Pulley	264-5887
7N-5910	Impeller - Pump	314-8686
7N-9145	Gear - Fly-wheel	279-4994
7N-9805	Pin - Piston	295-6438
7S-3161	Lifter - Valve	279-4996
7S-6723	Bracket - Alternator	299-1978
7V-5981	Driver	231-0256
7W-0450	Gear - Water Pump	279-4997
7W-0507	Gear - Oil Pump Drive	279-4998
7W-0508	Gear - Fuel Pump Drive	296-1351
7W-3042	Tube As - Drain	325-6231
7W-5687	Hub - Cam-shaft	314-8684
8G-4189	Bearing - Aligning	295-6411
8H-2810	Case As - Filter	314-8512
8K-0665	Cage - Bear-ing	231-0262
8K-2518	Joint As	231-0267
8K-2682	Adapter	231-0268
8N-0875	Valve - Ex-haust	247-6893 (Valve), 241-3381 (Valve Kit)
8N-1187	Head Gp - Cylinder	242-3435
8N-1188	Head Gp - Cylinder	242-3436
8N-1721	Rod As - Conn	269-5291
8N-2510	Shaft	325-6208
8N-2641	Sleeve	325-6210
8N-3251	Shaft As - Rocker Arm	314-8711
8N-3312	Shaft As - Rocker Arm	325-6200
8N-3325	Arm Gp - Rocker	314-8623
8N-3327	Arm Gp - Rocker	314-8624
8N-5305	Spacer	363-7464
8N-5929	Cover - Water Pump	296-1349
8N-6796	Head Gp - Cylinder	269-5290
8N-7315	Tube As - Outlet	325-6232
8N-8225	Bearing - Main	314-8652
8R-7336	Bearing	301-3394
8S-0493	Shaft As - Pump	325-6198
8S-3970	Chamber As	242-3438
9C-1618	Gear	231-0229
9C-6244	Gear	231-0230
9K-8425	Bearing - Sleeve	314-8638
9K-8757	Rod End - Bearing	311-9361
9N-5769	Cover - Hous-ing	325-6050
9S-6129	Pulley - Alter-nator Drive	264-5891
9S-8679	Chamber As	325-6042
9U-2400	Housing As	231-0249
9Y-2992	Bearing - Sleeve	325-6032

Sales Model 219

Original Part Number	Part Name	Classic Part Number
100-7860	Valve - Inlet	270-4360 (Valve), 270-4362 (Valve Kit)
104-4253	Line As - Fuel Injector	279-4988
104-4254	Line As - Fuel Injector	279-4989
111-8015	Gasket As - Head	279-4977
121-7746	Precleaner As	360-2311
131-3815	Seal Gp - Basic	325-6193
148-7455	Valve - Ex-haust	270-4361
172-5185	Shaft - Water Pump	325-6201
172-5188	Shaft - Water Pump	325-6202

(Continued)

Sales Model 219 (Continued)

Original Part Number	Part Name	Classic Part Number
172-5189	Impeller - Pump	295-5687
172-5190	Impeller - Pump	325-6111
172-6712	Impeller - Pump	325-6112
172-7767	Pump Gp - Water	296-1365
190-8609	Valve - Fill	360-2288
196-0028	Gear As - Idler	364-5259
1M-7250	Bowl - Pre-cleaner	360-2296
1N-3576	Block Gp - Cylinder	279-4978
1N-3958	Elbow	325-6087
1N-4304	Head Gp - Cylinder	269-8761
1P-1216	Manifold - Exhaust	261-0902
1P-1721	Gear - Balance	298-2769
1P-1722	Gear - Balance	298-2770
1S-4701	Pulley - Alt	264-5866
1S-5331	Cylinder - Adjustable	226-0214
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1695	Pump Gp	279-4980
1W-1698	Housing - Transfer Pump	296-1356
1W-2870	Shaft As - Balance	314-8715
1W-2871	Shaft As - Balance	314-8716
1W-4402	Gear - Camshaft	279-4981
1W-4405	Gear - Crankshaft	279-4982
1W-5912	Tappet As - Guide	325-6223
1W-6541	Plunger As	325-6173
244-1090	Alarm - Back up	360-2345
2D-5658	Bearing - Ball	301-4628
2F-5721	Bearing - Ball	311-9354
2K-3592	Boss	314-8501
2P-1170	Shaft As - Gear	296-1367
2P-1757	Hub - Fan Pulley	296-1357
2P-1781	Spacer - Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2519	Tube As - Inlet	325-6230
2P-2719	Pipe	363-7454
2P-6245	Shaft As - Pump	325-6197
2P-7828	Pan - Oil	314-8691
2V-0707	Bearing - Sleeve	360-2328
2V-0961	Driver	231-0255
2V-1722	Pin As	241-2525
2W-1086	Cover As - Cylinder Head	325-6049
2W-2621	Valve - Inlet	247-6892 (Valve), 241-3381 (Valve Kit)
2W-7255	Shaft - Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
3L-1425	Bearing - Ball	311-9356
3V-5257	Bracket - Carriage Roller	297-7149
3V-5317	Gear	231-0010
3V-5378	Gear - Output	231-0235
3V-9025	Link As	289-4946
3V-9439	Retainer As	231-0257
4E-1065	Pin As	241-2538
4E-9426	Collar	231-0000
4F-4974	Clamp	311-9373
4N-4539	Sleeve	314-8720
4N-7692	Crankshaft As	242-3440
4N-7693	Crankshaft As	242-3439
4P-3546	Valve As - Relief	325-6236
4P-4010	Muffler As	298-2788
4P-9381	Line As - Fuel Injector	279-4984
4P-9382	Line As - Fuel Injector	279-4985
4P-9961	Line As - Fuel Injector	325-6115
4P-9962	Line As - Fuel Injector	325-6116
4P-9963	Line As - Fuel Injector	298-2777
4P-9964	Line As - Fuel Injector	298-2778
4T-5172	Seal As	325-6189
4V-9236	Plate - Pressure	231-0260
4W-0452	Seal As - Camshaft	325-6191
5C-0451	Gear Gp - Bearing	235-5053
5C-1834	Gear	231-0002
5C-3712	Gear	231-0003
5C-3714	Gear	231-0222
5C-3715	Gear	231-0223
5C-3716	Gear	231-0224
5C-3717	Gear	231-0225
5C-3784	Pin As	241-2512
5C-5038	Pin As	241-2506
5C-5153	Cartridge	231-0011
5C-5236	Gear	231-0226
5C-5829	Pin As	241-2510
5C-5837	Retainer - Pin	299-2047
5C-5937	Gear	231-0004
5C-6690	Pin As	241-2508
5C-8172	Pin As	241-2515
5C-8582	Shaft - Planet	231-0241
5C-8583	Gear - Ring	231-0005
5C-8584	Gear - Planet	231-0006
5C-8586	Gear	231-0007
5C-8587	Cover	231-0243
5C-8966	Gear	231-0227
5J-6421	Bearing	256-4801
5P-7807	Bearing - Ball	314-8502
5S-6795	Chamber As	242-3437
5S-9062	Spacer	363-7463
5S-9080	Pulley - Alt Drive	264-5883
5V-7207	Pinion - Final Drive	231-0252
5V-7222	Gear - Final Drive	231-0237
6A-7129	Bearing - Sleeve	301-3130
6A-7534	Retainer	231-0244
6C-0739	Carrier As	231-0012
6C-3740	Shaft As	231-0013
6C-5062	Pinion	231-0016
6H-3957	Bearing - Ball	311-9358
6I-1346	Pump Gp - Oil	295-5674
6N-1036	Gear - Oil Pump	279-4991
6N-1553	Coupling - Exhaust	295-6422
6N-3256	Mount As	314-8688

(Continued)

Sales Model 219 (Continued)

Original Part Number	Part Name	Classic Part Number
6N-8413	Housing - Pump	325-6110
6W-2398	Retainer	231-0014
6W-3674	Gear	231-0228
6Y-8184	Link As	289-4948
7C-3567	Mount As	314-8689
7M-1851	Bolt - Spring	226-0223
7M-1856	Pilot - Recoil Spring	226-0225
7N-0165	Core As - Oil Cooler	295-5670
7N-1164	Mount As	295-5451
7N-2949	Pulley	264-5887
7N-5910	Impeller - Pump	314-8686
7N-9145	Gear - Flywheel	279-4994
7N-9805	Pin - Piston	295-6438
7S-3161	Lifter - Valve	279-4996
7S-6723	Bracket - Alternator	299-1978
7V-5981	Driver	231-0256
7V-7973	Gear Final Drive	231-0239
7V-7974	Pinion Final Drive	231-0253
7W-0450	Gear - Water Pump	279-4997
7W-0507	Gear - Oil Pump Drive	279-4998
7W-0508	Gear - Fuel Pump Drive	296-1351
7W-3042	Tube As - Drain	325-6231
7W-5687	Hub - Camshaft	314-8684
8G-4189	Bearing - Aligning	295-6411
8H-2810	Case As - Filter	314-8512
8H-7980	Piston	226-0249
8K-0665	Cage - Bearing	231-0262
8K-1749	Shaft - Sprocket	231-0242
8K-1754	Spacer	231-0247
8K-1755	Retainer - Cap	231-0246
8K-1756	Cage - Bearing	231-0263
8K-2518	Joint As	231-0267
8K-2682	Adapter	231-0268
8M-6191	Sleeve - Bolt	226-0234
8N-0875	Valve - Exhaust	247-6893 (Valve), 241-3381 (Valve Kit)
8N-1187	Head Gp - Cylinder	242-3435
8N-1188	Head Gp - Cylinder	242-3436
8N-1721	Rod As - Conn	269-5291
8N-2510	Shaft	325-6208
8N-2641	Sleeve	325-6210
8N-3251	Shaft As - Rocker Arm	314-8711
8N-3312	Shaft As - Rocker Arm	325-6200
8N-3325	Arm Gp - Rocker	314-8623
8N-3327	Arm Gp - Rocker	314-8624
8N-5305	Spacer	363-7464
8N-5929	Cover - Water Pump	296-1349
8N-6796	Head Gp - Cylinder	269-5290
8N-7315	Tube As - Outlet	325-6232
8N-8225	Bearing - Main	314-8652
8R-7336	Bearing	301-3394
8S-0493	Shaft As - Pump	325-6198
8S-3970	Chamber As	242-3438
9C-1618	Gear	231-0229
9C-6244	Gear	231-0230
9K-8425	Bearing - Sleeve	314-8638
9K-8757	Rod End - Bearing	311-9361
9N-5769	Cover - Housing	325-6050
9S-6129	Pulley - Alternator Drive	264-5891
9S-8679	Chamber As	325-6042
9U-2400	Housing As	231-0249
9Y-2992	Bearing - Sleeve	325-6032

Sales Model 219D

Original Part Number	Part Name	Classic Part Number
100-7860	Valve - Inlet	270-4360 (Valve), 270-4362 (Valve Kit)
104-4253	Line As - Fuel Injector	279-4988
104-4254	Line As - Fuel Injector	279-4989
111-8015	Gasket As - Head	279-4977
121-7746	Precleaner As	360-2311
131-3815	Seal Gp - Basic	325-6193
148-7455	Valve - Exhaust	270-4361
172-5185	Shaft - Water Pump	325-6201
172-5188	Shaft - Water Pump	325-6202
172-5189	Impeller - Pump	295-5687
172-5190	Impeller - Pump	325-6111
172-6712	Impeller - Pump	325-6112
172-7767	Pump Gp - Water	296-1365
196-0028	Gear As - Idler	364-5259
1M-7250	Bowl - Precleaner	360-2296
1N-3576	Block Gp - Cylinder	279-4978
1N-3958	Elbow	325-6087
1N-4304	Head Gp - Cylinder	269-8761
1P-1216	Manifold - Exhaust	261-0902
1P-1721	Gear - Balance	298-2769

(Continued)

Sales Model 219D (Continued)

Original Part Number	Part Name	Classic Part Number
1P-1722	Gear - Balance	298-2770
1S-4701	Pulley - Alt	264-5866
1S-5331	Cylinder - Adjustable	226-0214
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1695	Pump Gp	279-4980
1W-1698	Housing - Transfer Pump	296-1356
1W-2870	Shaft As - Balance	314-8715
1W-2871	Shaft As - Balance	314-8716
1W-4402	Gear - Camshaft	279-4981
1W-4405	Gear - Crankshaft	279-4982
1W-5912	Tappet As - Guide	325-6223
1W-6541	Plunger As	325-6173
244-1090	Alarm - Back up	360-2345
2D-5658	Bearing - Ball	301-4628
2F-5721	Bearing - Ball	311-9354
2K-3592	Boss	314-8501
2P-1170	Shaft As - Gear	296-1367
2P-1757	Hub - Fan Pulley	296-1357
2P-1781	Spacer - Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2519	Tube As - Inlet	325-6230
2P-2719	Pipe	363-7454
2P-6128	Pulley	264-5872
2P-6245	Shaft As - Pump	325-6197
2P-7828	Pan - Oil	314-8691
2V-0961	Driver	231-0255
2V-1722	Pin As	241-2525
2W-1086	Cover As - Cylinder Head	325-6049
2W-2621	Valve - Inlet	247-6892 (Valve), 241-3381 (Valve Kit)
2W-7255	Shaft - Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
3L-1425	Bearing - Ball	311-9356
3V-5257	Bracket - Carriage Roller	297-7149
3V-5317	Gear	231-0010
3V-5378	Gear - Output	231-0235
3V-9439	Retainer As	231-0257
4E-0183	Pin	301-7976
4E-1065	Pin As	241-2538
4E-9426	Collar	231-0000
4F-4974	Clamp	311-9373
4N-4539	Sleeve	314-8720
4N-7692	Crankshaft As	242-3440
4N-7693	Crankshaft As	242-3439
4P-3546	Valve As - Relief	325-6236
4P-4010	Muffler As	298-2788
4P-9381	Line As - Fuel Injector	279-4984
4P-9382	Line As - Fuel Injector	279-4985
4P-9961	Line As - Fuel Injector	325-6115
4P-9962	Line As - Fuel Injector	325-6116
4P-9963	Line As - Fuel Injector	298-2777
4P-9964	Line As - Fuel Injector	298-2778
4V-9236	Plate - Pressure	231-0260
4W-0452	Seal As - Camshaft	325-6191
5C-0451	Gear Gp - Bearing	235-5053
5C-1834	Gear	231-0002
5C-3712	Gear	231-0003
5C-3714	Gear	231-0222
5C-3715	Gear	231-0223
5C-3716	Gear	231-0224
5C-3717	Gear	231-0225
5C-3784	Pin As	241-2512
5C-5038	Pin As	241-2506
5C-5153	Cartridge	231-0011
5C-5236	Gear	231-0226
5C-5829	Pin As	241-2510
5C-5837	Retainer - Pin	299-2047
5C-5937	Gear	231-0004
5C-8172	Pin As	241-2515
5C-8582	Shaft - Planet	231-0241
5C-8583	Gear - Ring	231-0005
5C-8584	Gear - Planet	231-0006
5C-8586	Gear	231-0007
5C-8587	Cover	231-0243
5C-8966	Gear	231-0227
5J-6421	Bearing	256-4801
5P-7807	Bearing - Ball	314-8502
5S-6795	Chamber As	242-3437
5S-9062	Spacer	363-7463
5S-9080	Pulley - Alt Drive	264-5883
5V-7207	Pinion - Final Drive	231-0252
5V-7222	Gear - Final Drive	231-0237
6A-7129	Bearing - Sleeve	301-3130
6A-7534	Retainer	231-0244
6C-0739	Carrier As	231-0012
6C-3740	Shaft As	231-0013
6C-5062	Pinion	231-0016
6H-3957	Bearing - Ball	311-9358
6I-1346	Pump Gp - Oil	295-5674
6N-1036	Gear - Oil Pump	279-4991
6N-1553	Coupling - Exhaust	295-6422
6N-3256	Mount As	314-8688
6N-8413	Housing - Pump	325-6110
6W-2398	Retainer	231-0014
6W-3674	Gear	231-0228
7C-3567	Mount As	314-8689
7M-1851	Bolt - Spring	226-0223
7M-1856	Pilot - Recoil Spring	226-0225
7N-0165	Core As - Oil Cooler	295-5670
7N-1164	Mount As	295-5451
7N-2949	Pulley	264-5887
7N-5910	Impeller - Pump	314-8686
7N-9145	Gear - Flywheel	279-4994
7N-9805	Pin - Piston	295-6438
7S-3161	Lifter - Valve	279-4996
7S-6723	Bracket - Alternator	299-1978
7V-5981	Driver	231-0256
7V-7973	Gear Final Drive	231-0239

(Continued)

Sales Model 219D (Continued)

Original Part Number	Part Name	Classic Part Number
7V-7974	Pinion Final Drive	231-0253
7W-0450	Gear - Water Pump	279-4997
7W-0507	Gear - Oil Pump Drive	279-4998
7W-0508	Gear - Fuel Pump Drive	296-1351
7W-3042	Tube As - Drain	325-6231
7W-5687	Hub - Camshaft	314-8684
8G-4189	Bearing - Aligning	295-6411
8H-2810	Case As - Filter	314-8512
8H-7980	Piston	226-0249
8K-0665	Cage - Bearing	231-0262
8K-1749	Shaft - Sprocket	231-0242
8K-1754	Spacer	231-0247
8K-1755	Retainer - Cap	231-0246
8K-1756	Cage - Bearing	231-0263
8K-2518	Joint As	231-0267
8K-2682	Adapter	231-0268
8M-6191	Sleeve - Bolt	226-0234
8N-0875	Valve - Exhaust	247-6893 (Valve), 241-3381 (Valve Kit)
8N-1187	Head Gp - Cylinder	242-3435
8N-1188	Head Gp - Cylinder	242-3436
8N-1721	Rod As - Conn	269-5291
8N-2510	Shaft	325-6208
8N-2641	Sleeve	325-6210
8N-3251	Shaft As - Rocker Arm	314-8711
8N-3312	Shaft As - Rocker Arm	325-6200
8N-3325	Arm Gp - Rocker	314-8623
8N-3327	Arm Gp - Rocker	314-8624
8N-5305	Spacer	363-7464
8N-5929	Cover - Water Pump	296-1349
8N-6796	Head Gp - Cylinder	269-5290
8N-7315	Tube As - Outlet	325-6232
8N-8225	Bearing - Main	314-8652
8R-7336	Bearing	301-3394
8S-0493	Shaft As - Pump	325-6198
8S-3970	Chamber As	242-3438
9C-1618	Gear	231-0229
9C-6244	Gear	231-0230
9K-8425	Bearing - Sleeve	314-8638
9K-8757	Rod End - Bearing	311-9361
9N-5769	Cover - Housing	325-6050
9S-6129	Pulley - Alternator Drive	264-5891
9S-8679	Chamber As	325-6042
9U-2400	Housing As	231-0249
9Y-2992	Bearing - Sleeve	325-6032

Sales Model 225

Original Part Number	Part Name	Classic Part Number
100-7860	Valve - Inlet	270-4360 (Valve), 270-4362 (Valve Kit)
104-4253	Line As - Fuel Injector	279-4988
104-4254	Line As - Fuel Injector	279-4989
111-8015	Gasket As - Head	279-4977
121-7746	Precleaner As	360-2311
131-3815	Seal Gp - Basic	325-6193
148-7455	Valve - Exhaust	270-4361
172-5185	Shaft - Water Pump	325-6201
172-5188	Shaft - Water Pump	325-6202
172-5189	Impeller - Pump	295-5687
172-5190	Impeller - Pump	325-6111
172-6712	Impeller - Pump	325-6112
172-7767	Pump Gp - Water	296-1365
190-8609	Valve - Fill	360-2288
196-0028	Gear As - Idler	364-5259
1M-7250	Bowl - Precleaner	360-2296
1N-3576	Block Gp - Cylinder	279-4978
1N-3958	Elbow	325-6087
1N-4304	Head Gp - Cylinder	269-8761
1P-0963	Guard As - Roller	226-0179
1P-1216	Manifold - Exhaust	261-0902
1P-1721	Gear - Balance	298-2769
1P-1722	Gear - Balance	298-2770
1P-8554	Coupling - Exhaust	325-6052
1P-9952	Impeller - Pump	314-8685
1P-9989	Pipe	363-7453
1S-2268	Piston	226-2726
1S-4701	Pulley - Alt	264-5866
1S-5331	Cylinder - Adjustable	226-0214
1U-2738	Piston As	367-6074
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1695	Pump Gp	279-4980
1W-1698	Housing - Transfer Pump	296-1356
1W-2572	Muffler As	247-2663
1W-2870	Shaft As - Balance	314-8715

(Continued)

Sales Model 225 (Continued)

Original Part Number	Part Name	Classic Part Number
1W-2871	Shaft As - Balance	314-8716
1W-4402	Gear - Camshaft	279-4981
1W-4405	Gear - Crankshaft	279-4982
1W-5912	Tappet As - Guide	325-6223
1W-6541	Plunger As	325-6173
244-1090	Alarm - Back up	360-2345
246-5228	Rim	289-2207
2D-5658	Bearing - Ball	301-4628
2F-5721	Bearing - Ball	311-9354
2K-3592	Boss	314-8501
2K-6413	Pin	360-2270
2P-1170	Shaft As - Gear	296-1367
2P-1757	Hub - Fan Pulley	296-1357
2P-1781	Spacer - Oil Pump	325-6214
2P-2519	Tube As - Inlet	325-6230
2P-2719	Pipe	363-7454
2P-6245	Shaft As - Pump	325-6197
2P-7828	Pan - Oil	314-8691
2V-0705	Pin As	241-2524
2V-0707	Bearing - Sleeve	360-2328
2V-0812	Pinion - Final Drive	231-0250
2V-0813	Gear - Sec Cluster	231-0232
2V-0814	Gear - Output	231-0233
2V-0816	Pinion - Swing Drive	231-0017
2V-0817	Gear - Cluster	231-0234
2V-0961	Driver	231-0255
2V-1722	Pin As	241-2525
2W-1086	Cover As - Cylinder Head	325-6049
2W-2621	Valve - Inlet	247-6892 (Valve), 241-3381 (Valve Kit)
2W-7255	Shaft - Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2Y-4213	Pulley	314-8703
3L-1425	Bearing - Ball	311-9356
3T-9152	Rim - Sprocket	322-6377
3V-1133	Strip	226-0203
3V-4622	Bracket - Carriage Roller	297-7148
3V-4874	Pin	241-2544
3V-5148	Pinion - Swing Gr	231-0251
3V-5257	Bracket - Carriage Roller	297-7149
3V-5317	Gear	231-0010
3V-5378	Gear - Output	231-0235
3V-8927	Pin	241-2545
3V-9025	Link As	289-4946
3V-9281	Bearing	314-8631
3V-9285	Pin	241-2546
3V-9439	Retainer As	231-0257
4E-9426	Collar	231-0000
4F-4974	Clamp	311-9373
4N-2954	Sleeve - Camshaft	299-2059
4N-3281	Line As - Fuel Injector	247-3362
4N-3282	Line As - Fuel Injector	247-3363
4N-3283	Line As - Fuel Injector	247-3364
4N-3284	Line As - Fuel Injector	247-3365
4N-4539	Sleeve	314-8720
4N-4782	Pulley	325-6176
4N-7692	Crankshaft As	242-3440
4N-7693	Crankshaft As	242-3439
4N-7977	Shaft As - Balance	314-8709
4N-7978	Shaft As - Balance	314-8710
4N-9587	Shield - Heat	297-7260
4P-3546	Valve As - Relief	325-6236
4P-9381	Line As - Fuel Injector	279-4984
4P-9382	Line As - Fuel Injector	279-4985
4P-9961	Line As - Fuel Injector	325-6115
4P-9962	Line As - Fuel Injector	325-6116
4P-9963	Line As - Fuel Injector	298-2777
4P-9964	Line As - Fuel Injector	298-2778
4V-5608	Pin As	241-2529
4V-9236	Plate - Pressure	231-0260
4W-0452	Seal As - Camshaft	325-6191
5C-1834	Gear	231-0002
5C-5937	Gear	231-0004
5C-8582	Shaft - Planet	231-0241
5C-8583	Gear - Ring	231-0005
5C-8584	Gear - Planet	231-0006
5C-8586	Gear	231-0007
5C-8587	Cover	231-0243
5C-8966	Gear	231-0227
5P-7807	Bearing - Ball	314-8502
5S-6795	Chamber As	242-3437
5S-9062	Spacer	363-7463
5S-9080	Pulley - Alt Drive	264-5883
5V-4969	Sprocket - Track	289-2205
5V-7207	Pinion - Final Drive	231-0252
5V-7214	Pin As	241-2522
5V-7222	Gear - Final Drive	231-0237
6A-7534	Retainer	231-0244
6C-0739	Carrier As	231-0012
6H-3957	Bearing - Ball	311-9358
6I-1346	Pump Gp - Oil	295-5674
6N-1036	Gear - Oil Pump	279-4991
6N-1553	Coupling - Exhaust	295-6422
6N-3256	Mount As	314-8688
6N-3964	Muffler As	360-7884
6N-8413	Housing - Pump	325-6110
6W-2451	Sprocket - Track	322-6376
6Y-8184	Link As	289-4948
7C-4297	Seal As - Camshaft	325-6192
7E-5663	Muffler As	247-2667
7M-1851	Bolt - Spring	226-0223
7M-1856	Pilot - Recoil Spring	226-0225
7N-0128	Core As - Oil Cooler	299-1994

(Continued)

Sales Model 225 (Continued)

Original Part Number	Part Name	Classic Part Number
7N-0165	Core As - Oil Cooler	295-5670
7N-1164	Mount As	295-5451
7N-2871	Line As - Fuel Injector	319-8172
7N-2872	Line As - Fuel Injector	319-8173
7N-2874	Line As - Fuel Injector	298-2779
7N-2949	Pulley	264-5887
7N-3515	Gear - Camshaft	314-8669
7N-3536	Gear - Fuel	279-4993
7N-5910	Impeller - Pump	314-8686
7N-9145	Gear - Flywheel	279-4994
7N-9805	Pin - Piston	295-6438
7S-3161	Lifter - Valve	279-4996
7S-6723	Bracket - Alternator	299-1978
7T-2036	Cap As - Filter	361-1721
7V-5979	Gear	231-0238
7V-5981	Driver	231-0256
7V-7017	Pinion Swing	231-0018
7V-7973	Gear Final Drive	231-0239
7V-7974	Pinion Final Drive	231-0253
7V-7976	Pinion - Swing Drive	231-0254
7W-0450	Gear - Water Pump	279-4997
7W-0507	Gear - Oil Pump Drive	279-4998
7W-0508	Gear - Fuel Pump Drive	296-1351
7W-3042	Tube As - Drain	325-6231
7W-5687	Hub - Camshaft	314-8684
8H-2810	Case As - Filter	314-8512
8H-7980	Piston	226-0249
8K-0393	Pin	241-2548
8K-0442	Gear	231-0240
8K-0455	Pin	241-2547
8K-0518	Pin	241-2549
8K-0533	Bearing - Sleeve	314-8637

Original Part Number	Part Name	Classic Part Number
8K-0576	Cage - Bearing	231-0261
8K-0578	Spacer	231-0248
8K-0579	Retainer	231-0245
8K-0665	Cage - Bearing	231-0262
8K-1107	Rack - Disconnect	231-0264
8K-1317	Shaft	231-0019
8K-1749	Shaft - Sprocket	231-0242
8K-1754	Spacer	231-0247
8K-1755	Retainer - Cap	231-0246
8K-1756	Cage - Bearing	231-0263
8K-1940	Retainer As	231-0258
8K-1944	Case As - Swing Drive	231-0265
8K-1945	Shaft As - Output	231-0266
8K-1946	Retainer As	231-0259
8K-2518	Joint As	231-0267
8K-2682	Adapter	231-0268
8K-2743	Sprocket - Track	289-2206
8K-2779	Cage - Bearing	231-0483
8K-2956	Pin	241-2550
8K-4127	Gear Gp - Bearing & Basic	235-5055
8M-6191	Sleeve - Bolt	226-0234
8N-0002	Trunnion As	314-8728
8N-0875	Valve - Exhaust	247-6893 (Valve), 241-3381 (Valve Kit)
8N-1187	Head Gp - Cylinder	242-3435
8N-1188	Head Gp - Cylinder	242-3436
8N-1721	Rod As - Conn	269-5291
8N-1984	Rod As - Conn	242-3441
8N-2510	Shaft	325-6208
8N-2641	Sleeve	325-6210

Original Part Number	Part Name	Classic Part Number
8N-3182	Body As - Piston	250-6564 (Piston As), 250-6556 (Liner Kits)
8N-3183	Piston Gp - Basic	250-6556 (Liner Kit)
8N-3251	Shaft As - Rocker Arm	314-8711
8N-3311	Shaft As - Rocker Arm	325-6199
8N-3312	Shaft As - Rocker Arm	325-6200
8N-3325	Arm Gp - Rocker	314-8623
8N-3327	Arm Gp - Rocker	314-8624
8N-5305	Spacer	363-7464
8N-5929	Cover - Water Pump	296-1349
8N-6796	Head Gp - Cylinder	269-5290
8N-7315	Tube As - Outlet	325-6232
8N-8225	Bearing - Main	314-8652
8N-9733	Line As - Fuel Injector	319-8174
8P-5197	Bearing As	295-6413
8S-0248	Breather As	325-6033
8S-0493	Shaft As - Pump	325-6198
8S-3970	Chamber As	242-3438
8V-2631	Pin As	241-2526
8V-2632	Pin As	241-2523
8V-2634	Pin As	241-2518
9C-3187	Pin As	314-8694
9C-4211	Pin As	241-2519
9C-4737	Pin As	241-2520
9C-4912	Pin As	241-2517
9C-5060	Link As - Bearing	299-2022
9C-6187	Pin As	241-2521
9K-0092	Pinion	231-0484
9K-8757	Rod End - Bearing	311-9361
9N-5769	Cover - Housing	325-6050
9S-6129	Pulley - Alternator Drive	264-5891
9S-8679	Chamber As	325-6042
9T-6526	Joint As - Univ	365-8824

(Continued)

Sales Model 225 (Continued)

Original Part Number	Part Name	Classic Part Number
9U-0654	Coupling	297-7167
9Y-2992	Bearing - Sleeve	325-6032

Sales Model 225B

Original Part Number	Part Name	Classic Part Number
100-3431	Stop	314-8723
100-7860	Valve - Inlet	270-4360 (Valve), 270-4362 (Valve Kit)
104-4253	Line As - Fuel Injector	279-4988
104-4254	Line As - Fuel Injector	279-4989
111-8015	Gasket As - Head	279-4977
121-7746	Precleaner As	360-2311
131-3815	Seal Gp - Basic	325-6193
148-7455	Valve - Exhaust	270-4361
172-5185	Shaft - Water Pump	325-6201
172-5188	Shaft - Water Pump	325-6202
172-5189	Impeller - Pump	295-5687
172-5190	Impeller - Pump	325-6111
172-6712	Impeller - Pump	325-6112
172-7767	Pump Gp - Water	296-1365
190-8609	Valve - Fill	360-2288
196-0028	Gear As - Idler	364-5259
1M-7250	Bowl - Precleaner	360-2296
1N-3576	Block Gp - Cylinder	279-4978
1N-3958	Elbow	325-6087
1N-4304	Head Gp - Cylinder	269-8761
1P-1216	Manifold - Exhaust	261-0902
1P-1721	Gear - Balance	298-2769
1P-1722	Gear - Balance	298-2770
1P-8554	Coupling - Exhaust	325-6052
1S-2268	Piston	226-2726
1S-4701	Pulley - Alt	264-5866
1S-5331	Cylinder - Adjustable	226-0214
1U-2738	Piston As	367-6074
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1695	Pump Gp	279-4980
1W-1698	Housing - Transfer Pump	296-1356
1W-2572	Muffler As	247-2663
1W-2870	Shaft As - Balance	314-8715
1W-2871	Shaft As - Balance	314-8716
1W-4402	Gear - Camshaft	279-4981
1W-4405	Gear - Crankshaft	279-4982
1W-5912	Tappet As - Guide	325-6223
1W-6541	Plunger As	325-6173
244-1090	Alarm - Back up	360-2345
2D-5658	Bearing - Ball	301-4628
2F-5721	Bearing - Ball	311-9354
2K-3592	Boss	314-8501
2K-6413	Pin	360-2270
2P-1170	Shaft As - Gear	296-1367
2P-1757	Hub - Fan Pulley	296-1357
2P-1781	Spacer - Oil Pump	325-6214
2P-2519	Tube As - Inlet	325-6230
2P-2719	Pipe	363-7454
2P-6245	Shaft As - Pump	325-6197
2P-7828	Pan - Oil	314-8691
2V-0705	Pin As	241-2524
2V-0707	Bearing - Sleeve	360-2328
2V-0814	Gear - Output	231-0233
2V-0816	Pinion - Swing Drive	231-0017
2V-0817	Gear - Cluster	231-0234
2V-0961	Driver	231-0255
2V-1722	Pin As	241-2525
2W-1086	Cover As - Cylinder Head	325-6049
2W-2621	Valve - Inlet	247-6892 (Valve), 241-3381 (Valve Kit)
2W-7255	Shaft - Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
3L-1425	Bearing - Ball	311-9356
3V-4874	Pin	241-2544
3V-5148	Pinion - Swing Gr	231-0251
3V-5257	Bracket - Carriage Roller	297-7149
3V-5317	Gear	231-0010
3V-5378	Gear - Output	231-0235
3V-8927	Pin	241-2545
3V-9281	Bearing	314-8631
3V-9285	Pin	241-2546
3V-9439	Retainer As	231-0257
4E-9426	Collar	231-0000
4F-4974	Clamp	311-9373
4N-2954	Sleeve - Camshaft	299-2059
4N-4539	Sleeve	314-8720
4N-7692	Crankshaft As	242-3440
4N-7693	Crankshaft As	242-3439
4P-3546	Valve As - Relief	325-6236
4P-9381	Line As - Fuel Injector	279-4984
4P-9382	Line As - Fuel Injector	279-4985
4P-9961	Line As - Fuel Injector	325-6115

(Continued)

Sales Model 225B (Continued)

Original Part Number	Part Name	Classic Part Number
4P-9962	Line As - Fuel Injector	325-6116
4P-9963	Line As - Fuel Injector	298-2777
4P-9964	Line As - Fuel Injector	298-2778
4T-5172	Seal As	325-6189
4V-5608	Pin As	241-2529
4V-9236	Plate - Pressure	231-0260
4W-0452	Seal As - Camshaft	325-6191
5C-1834	Gear	231-0002
5C-3784	Pin As	241-2512
5C-5038	Pin As	241-2506
5C-5829	Pin As	241-2510
5C-5837	Retainer - Pin	299-2047
5C-5937	Gear	231-0004
5C-8582	Shaft - Planet	231-0241
5C-8583	Gear - Ring	231-0005
5C-8584	Gear - Planet	231-0006
5C-8586	Gear	231-0007
5C-8587	Cover	231-0243
5C-8966	Gear	231-0227
5P-7807	Bearing - Ball	314-8502
5S-6795	Chamber As	242-3437
5S-9062	Spacer	363-7463
5S-9080	Pulley - Alt Drive	264-5883
5V-7207	Pinion - Final Drive	231-0252
5V-7214	Pin As	241-2522
5V-7222	Gear - Final Drive	231-0237
6A-7129	Bearing - Sleeve	301-3130
6A-7534	Retainer	231-0244
6C-0739	Carrier As	231-0012
6H-3957	Bearing - Ball	311-9358
6I-1346	Pump Gp - Oil	295-5674
6N-1036	Gear - Oil Pump	279-4991
6N-1553	Coupling - Exhaust	295-6422
6N-3256	Mount As	314-8688
6N-8413	Housing - Pump	325-6110
7E-5663	Muffler As	247-2667
7M-1851	Bolt - Spring	226-0223
7M-1856	Pilot - Recoil Spring	226-0225
7N-0165	Core As - Oil Cooler	295-5670
7N-1164	Mount As	295-5451
7N-2949	Pulley	264-5887
7N-5910	Impeller - Pump	314-8686
7N-9145	Gear - Flywheel	279-4994
7N-9805	Pin - Piston	295-6438
7S-3161	Lifter - Valve	279-4996
7S-6723	Bracket - Alternator	299-1978
7V-5979	Gear	231-0238
7V-5981	Driver	231-0256
7V-7017	Pinion Swing	231-0018
7V-7973	Gear Final Drive	231-0239
7V-7974	Pinion Final Drive	231-0253
7V-7976	Pinion - Swing Drive	231-0254
7W-0450	Gear - Water Pump	279-4997
7W-0507	Gear - Oil Pump Drive	279-4998
7W-0508	Gear - Fuel Pump Drive	296-1351
7W-3042	Tube As - Drain	325-6231
7W-5687	Hub - Camshaft	314-8684
8H-2810	Case As - Filter	314-8512
8H-7980	Piston	226-0249
8K-0442	Gear	231-0240
8K-0533	Bearing - Sleeve	314-8637
8K-0576	Cage - Bearing	231-0261
8K-0578	Spacer	231-0248
8K-0579	Retainer	231-0245
8K-0665	Cage - Bearing	231-0262
8K-1749	Shaft - Sprocket	231-0242
8K-1754	Spacer	231-0247
8K-1755	Retainer - Cap	231-0246
8K-1756	Cage - Bearing	231-0263
8K-1940	Retainer As	231-0258
8K-1944	Case As - Swing Drive	231-0265
8K-1945	Shaft As - Output	231-0266
8K-1946	Retainer As	231-0259
8K-2518	Joint As	231-0267
8K-2682	Adapter	231-0268
8K-2779	Cage - Bearing	231-0483
8K-3712	Pin As	241-2541
8K-4127	Gear Gp - Bearing & Basic	235-5055
8M-6191	Sleeve - Bolt	226-0234
8N-0875	Valve - Exhaust	247-6893 (Valve), 241-3381 (Valve Kit)
8N-1187	Head Gp - Cylinder	242-3435
8N-1188	Head Gp - Cylinder	242-3436
8N-1721	Rod As - Conn	269-5291
8N-2510	Shaft	325-6208
8N-2641	Sleeve	325-6210
8N-3251	Shaft As - Rocker Arm	314-8711
8N-3312	Shaft As - Rocker Arm	325-6200
8N-3325	Arm Gp - Rocker	314-8623
8N-3327	Arm Gp - Rocker	314-8624
8N-5305	Spacer	363-7464
8N-5929	Cover - Water Pump	296-1349
8N-6796	Head Gp - Cylinder	269-5290
8N-7315	Tube As - Outlet	325-6232
8N-8225	Bearing - Main	314-8652
8P-5197	Bearing As	295-6413
8S-0248	Breather As	325-6033
8S-0493	Shaft As - Pump	325-6198
8S-3970	Chamber As	242-3438
8V-2631	Pin As	241-2526
8V-2632	Pin As	241-2523
8V-2634	Pin As	241-2518
9C-3187	Pin As	314-8694

(Continued)

Sales Model 225B (Continued)

Original Part Number	Part Name	Classic Part Number
9C-4211	Pin As	241-2519
9C-4737	Pin As	241-2520
9C-4912	Pin As	241-2517
9C-5060	Link As - Bearing	299-2022
9C-6187	Pin As	241-2521

Original Part Number	Part Name	Classic Part Number
9K-8425	Bearing - Sleeve	314-8638
9K-8757	Rod End - Bearing	311-9361
9N-5769	Cover - Housing	325-6050

Original Part Number	Part Name	Classic Part Number
9S-6129	Pulley - Alternator Drive	264-5891
9S-8679	Chamber As	325-6042
9T-6526	Joint As - Univ	365-8824
9U-0654	Coupling	297-7167
9Y-2992	Bearing - Sleeve	325-6032

Sales Model 225D

Original Part Number	Part Name	Classic Part Number
100-3431	Stop	314-8723
100-7860	Valve - Inlet	270-4360 (Valve), 270-4362 (Valve Kit)
104-4253	Line As - Fuel Injector	279-4988
104-4254	Line As - Fuel Injector	279-4989
111-8015	Gasket As - Head	279-4977
121-7746	Precleaner As	360-2311
131-3815	Seal Gp - Basic	325-6193
148-7455	Valve - Exhaust	270-4361
172-5185	Shaft - Water Pump	325-6201
172-5188	Shaft - Water Pump	325-6202
172-5189	Impeller - Pump	295-5687
172-5190	Impeller - Pump	325-6111
172-6712	Impeller - Pump	325-6112
172-7767	Pump Gp - Water	296-1365
190-8609	Valve - Fill	360-2288
196-0028	Gear As - Idler	364-5259
1M-7250	Bowl - Precleaner	360-2296
1N-3576	Block Gp - Cylinder	279-4978
1N-3958	Elbow	325-6087
1N-4304	Head Gp - Cylinder	269-8761
1P-1216	Manifold - Exhaust	261-0902

Original Part Number	Part Name	Classic Part Number
1P-1721	Gear - Balance	298-2769
1P-1722	Gear - Balance	298-2770
1P-8554	Coupling - Exhaust	325-6052
1S-4701	Pulley - Alt	264-5866
1S-5331	Cylinder - Adjustable	226-0214
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1695	Pump Gp	279-4980
1W-1698	Housing - Transfer Pump	296-1356
1W-2572	Muffler As	247-2663
1W-2870	Shaft As - Balance	314-8715
1W-2871	Shaft As - Balance	314-8716
1W-4402	Gear - Camshaft	279-4981
1W-4405	Gear - Crankshaft	279-4982
1W-5912	Tappet As - Guide	325-6223
1W-6541	Plunger As	325-6173
244-1090	Alarm - Back up	360-2345
2D-5658	Bearing - Ball	301-4628
2F-5721	Bearing - Ball	311-9354
2K-3592	Boss	314-8501
2K-6413	Pin	360-2270
2P-1170	Shaft As - Gear	296-1367
2P-1757	Hub - Fan Pulley	296-1357
2P-1781	Spacer - Oil Pump	325-6214

Original Part Number	Part Name	Classic Part Number
2P-2519	Tube As - Inlet	325-6230
2P-2719	Pipe	363-7454
2P-6245	Shaft As - Pump	325-6197
2P-7828	Pan - Oil	314-8691
2V-0707	Bearing - Sleeve	360-2328
2V-0814	Gear - Output	231-0233
2V-0816	Pinion - Swing Drive	231-0017
2V-0817	Gear - Cluster	231-0234
2V-0961	Driver	231-0255
2V-1722	Pin As	241-2525
2W-1086	Cover As - Cylinder Head	325-6049
2W-2621	Valve - Inlet	247-6892 (Valve), 241-3381 (Valve Kit)
2W-7255	Shaft - Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
3L-1425	Bearing - Ball	311-9356
3V-5148	Pinion - Swing Gr	231-0251
3V-5257	Bracket - Carriage Roller	297-7149
3V-5317	Gear	231-0010
3V-5378	Gear - Output	231-0235
3V-9439	Retainer As	231-0257
4E-0183	Pin	301-7976
4E-9426	Collar	231-0000
4F-4974	Clamp	311-9373
4N-2954	Sleeve - Camshaft	299-2059
4N-4539	Sleeve	314-8720
4N-7692	Crankshaft As	242-3440
4N-7693	Crankshaft As	242-3439

(Continued)

Sales Model 225D (Continued)

Original Part Number	Part Name	Classic Part Number
4P-3546	Valve As - Relief	325-6236
4P-9381	Line As - Fuel Injector	279-4984
4P-9382	Line As - Fuel Injector	279-4985
4P-9961	Line As - Fuel Injector	325-6115
4P-9962	Line As - Fuel Injector	325-6116
4P-9963	Line As - Fuel Injector	298-2777
4P-9964	Line As - Fuel Injector	298-2778
4T-5172	Seal As	325-6189
4V-5608	Pin As	241-2529
4V-9236	Plate - Pressure	231-0260
4W-0452	Seal As - Camshaft	325-6191
5C-1834	Gear	231-0002
5C-3784	Pin As	241-2512
5C-5038	Pin As	241-2506
5C-5829	Pin As	241-2510
5C-5837	Retainer - Pin	299-2047
5C-5937	Gear	231-0004
5C-8582	Shaft - Planet	231-0241
5C-8583	Gear - Ring	231-0005
5C-8584	Gear - Planet	231-0006
5C-8586	Gear	231-0007
5C-8587	Cover	231-0243
5C-8966	Gear	231-0227
5P-7807	Bearing - Ball	314-8502
5S-6795	Chamber As	242-3437
5S-9062	Spacer	363-7463
5S-9080	Pulley - Alt Drive	264-5883
5V-7207	Pinion - Final Drive	231-0252
5V-7222	Gear - Final Drive	231-0237
6A-7129	Bearing - Sleeve	301-3130
6A-7534	Retainer	231-0244
6C-0739	Carrier As	231-0012
6H-3957	Bearing - Ball	311-9358
6I-1346	Pump Gp - Oil	295-5674
6N-1036	Gear - Oil Pump	279-4991
6N-1553	Coupling - Exhaust	295-6422
6N-3256	Mount As	314-8688
6N-8413	Housing - Pump	325-6110
7E-5663	Muffler As	247-2667
7M-1851	Bolt - Spring	226-0223
7M-1856	Pilot - Recoil Spring	226-0225
7N-0165	Core As - Oil Cooler	295-5670
7N-1164	Mount As	295-5451
7N-2949	Pulley	264-5887
7N-5910	Impeller - Pump	314-8686
7N-9145	Gear - Flywheel	279-4994
7N-9805	Pin - Piston	295-6438
7S-3161	Lifter - Valve	279-4996
7S-6723	Bracket - Alternator	299-1978
7T-2036	Cap As - Filter	361-1721
7V-5979	Gear	231-0238
7V-5981	Driver	231-0256
7V-7017	Pinion Swing	231-0018
7V-7973	Gear Final Drive	231-0239
7V-7974	Pinion Final Drive	231-0253
7V-7976	Pinion - Swing Drive	231-0254
7W-0450	Gear - Water Pump	279-4997
7W-0507	Gear - Oil Pump Drive	279-4998
7W-0508	Gear - Fuel Pump Drive	296-1351
7W-3042	Tube As - Drain	325-6231
7W-5687	Hub - Camshaft	314-8684
8H-2810	Case As - Filter	314-8512
8H-7980	Piston	226-0249
8K-0442	Gear	231-0240
8K-0576	Cage - Bearing	231-0261
8K-0578	Spacer	231-0248
8K-0579	Retainer	231-0245
8K-0665	Cage - Bearing	231-0262
8K-1749	Shaft - Sprocket	231-0242
8K-1754	Spacer	231-0247
8K-1755	Retainer - Cap	231-0246
8K-1756	Cage - Bearing	231-0263
8K-1940	Retainer As	231-0258
8K-1944	Case As - Swing Drive	231-0265
8K-1945	Shaft As - Output	231-0266
8K-1946	Retainer As	231-0259
8K-2518	Joint As	231-0267
8K-2779	Cage - Bearing	231-0483
8K-3712	Pin As	241-2541
8K-4127	Gear Gp - Bearing & Basic	235-5055
8M-6191	Sleeve - Bolt	226-0234
8N-0875	Valve - Exhaust	247-6893 (Valve), 241-3381 (Valve Kit)
8N-1187	Head Gp - Cylinder	242-3435
8N-1188	Head Gp - Cylinder	242-3436
8N-1721	Rod As - Conn	269-5291
8N-2510	Shaft	325-6208
8N-2641	Sleeve	325-6210
8N-3251	Shaft As - Rocker Arm	314-8711
8N-3312	Shaft As - Rocker Arm	325-6200
8N-3325	Arm Gp - Rocker	314-8623
8N-3327	Arm Gp - Rocker	314-8624
8N-5305	Spacer	363-7464
8N-5929	Cover - Water Pump	296-1349
8N-6796	Head Gp - Cylinder	269-5290
8N-7315	Tube As - Outlet	325-6232
8N-8225	Bearing - Main	314-8652
8R-7336	Bearing	301-3394
8S-0248	Breather As	325-6033
8S-0493	Shaft As - Pump	325-6198
8S-3970	Chamber As	242-3438
8V-2631	Pin As	241-2526

(Continued)

Sales Model 225D (Continued)

Original Part Number	Part Name	Classic Part Number
8V-2632	Pin As	241-2523
8V-2634	Pin As	241-2518
9C-3187	Pin As	314-8694
9C-4211	Pin As	241-2519
9C-4737	Pin As	241-2520
9C-5060	Link As - Bearing	299-2022
9C-6187	Pin As	241-2521
9K-8757	Rod End - Bearing	311-9361
9N-5769	Cover - Housing	325-6050
9S-6129	Pulley - Alternator Drive	264-5891
9S-8679	Chamber As	325-6042
9T-6526	Joint As - Univ	365-8824
9Y-2992	Bearing - Sleeve	325-6032

Sales Model 229

Original Part Number	Part Name	Classic Part Number
100-7860	Valve - Inlet	270-4360 (Valve), 270-4362 (Valve Kit)
104-4253	Line As - Fuel Injector	279-4988
104-4254	Line As - Fuel Injector	279-4989
111-8015	Gasket As - Head	279-4977
121-7746	Precleaner As	360-2311
131-3815	Seal Gp - Basic	325-6193
148-7455	Valve - Exhaust	270-4361
172-5185	Shaft - Water Pump	325-6201
172-5188	Shaft - Water Pump	325-6202
172-5189	Impeller - Pump	295-5687
172-5190	Impeller - Pump	325-6111
172-6712	Impeller - Pump	325-6112
172-7767	Pump Gp - Water	296-1365
190-8609	Valve - Fill	360-2288
196-0028	Gear As - Idler	364-5259
1M-7250	Bowl - Precleaner	360-2296
1N-3576	Block Gp - Cylinder	279-4978
1N-3958	Elbow	325-6087
1N-4304	Head Gp - Cylinder	269-8761
1P-1216	Manifold - Exhaust	261-0902
1P-1721	Gear - Balance	298-2769
1P-1722	Gear - Balance	298-2770
1P-8554	Coupling - Exhaust	325-6052
1S-2268	Piston	226-2726
1S-4701	Pulley - Alt	264-5866
1S-5331	Cylinder - Adjustable	226-0214
1V-9148	Bearing - Sleeve	308-9811
1W-1219	Trunnion As	314-8724
1W-2572	Muffler As	247-2663
1W-2870	Shaft As - Balance	314-8715
1W-2871	Shaft As - Balance	314-8716
1W-4402	Gear - Camshaft	279-4981
1W-4405	Gear - Crankshaft	279-4982
1W-6541	Plunger As	325-6173
244-1090	Alarm - Back up	360-2345
2D-5658	Bearing - Ball	301-4628
2F-5721	Bearing - Ball	311-9354
2K-3592	Boss	314-8501
2K-6413	Pin	360-2270
2P-1170	Shaft As - Gear	296-1367
2P-1757	Hub - Fan Pulley	296-1357
2P-1781	Spacer - Oil Pump	325-6214
2P-2519	Tube As - Inlet	325-6230
2P-2719	Pipe	363-7454
2P-6245	Shaft As - Pump	325-6197
2P-7828	Pan - Oil	314-8691
2V-0705	Pin As	241-2524
2V-0707	Bearing - Sleeve	360-2328
2V-0814	Gear - Output	231-0233
2V-0816	Pinion - Swing Drive	231-0017
2V-0817	Gear - Cluster	231-0234
2V-0961	Driver	231-0255
2V-1722	Pin As	241-2525
2W-1086	Cover As - Cylinder Head	325-6049
2W-2621	Valve - Inlet	247-6892 (Valve), 241-3381 (Valve Kit)
2W-7255	Shaft - Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
3L-1425	Bearing - Ball	311-9356
3V-4874	Pin	241-2544
3V-5148	Pinion - Swing Gr	231-0251
3V-5257	Bracket - Carriage Roller	297-7149
3V-5317	Gear	231-0010
3V-5378	Gear - Output	231-0235
3V-8927	Pin	241-2545
3V-9281	Bearing	314-8631
3V-9285	Pin	241-2546
3V-9439	Retainer As	231-0257
4E-9426	Collar	231-0000
4F-4974	Clamp	311-9373
4N-2954	Sleeve - Camshaft	299-2059
4N-4539	Sleeve	314-8720
4N-7692	Crankshaft As	242-3440
4N-7693	Crankshaft As	242-3439
4P-3546	Valve As - Relief	325-6236
4P-9381	Line As - Fuel Injector	279-4984

(Continued)

Sales Model 229 (Continued)

Original Part Number	Part Name	Classic Part Number
4P-9382	Line As - Fuel Injector	279-4985
4P-9961	Line As - Fuel Injector	325-6115
4P-9962	Line As - Fuel Injector	325-6116
4P-9963	Line As - Fuel Injector	298-2777
4P-9964	Line As - Fuel Injector	298-2778
4V-5608	Pin As	241-2529
4V-9236	Plate - Pressure	231-0260
4W-0452	Seal As - Camshaft	325-6191
5C-1834	Gear	231-0002
5C-5937	Gear	231-0004
5C-8582	Shaft - Planet	231-0241
5C-8583	Gear - Ring	231-0005
5C-8584	Gear - Planet	231-0006
5C-8586	Gear	231-0007
5C-8587	Cover	231-0243
5C-8966	Gear	231-0227
5P-7807	Bearing - Ball	314-8502
5S-6795	Chamber As	242-3437
5S-9062	Spacer	363-7463
5S-9080	Pulley - Alt Drive	264-5883
5V-7207	Pinion - Final Drive	231-0252
5V-7214	Pin As	241-2522
5V-7222	Gear - Final Drive	231-0237
6A-7534	Retainer	231-0244
6C-0739	Carrier As	231-0012
6H-3957	Bearing - Ball	311-9358
6I-1346	Pump Gp - Oil	295-5674
6N-1036	Gear - Oil Pump	279-4991
6N-1553	Coupling - Exhaust	295-6422
6N-3256	Mount As	314-8688
6N-8413	Housing - Pump	325-6110
7E-5663	Muffler As	247-2667
7M-1851	Bolt - Spring	226-0223
7M-1856	Pilot - Recoil Spring	226-0225
7N-0165	Core As - Oil Cooler	295-5670
7N-1164	Mount As	295-5451
7N-2949	Pulley	264-5887
7N-5910	Impeller - Pump	314-8686
7N-9145	Gear - Flywheel	279-4994
7N-9805	Pin - Piston	295-6438
7S-3161	Lifter - Valve	279-4996
7S-6723	Bracket - Alternator	299-1978
7V-5979	Gear	231-0238
7V-5981	Driver	231-0256
7V-7017	Pinion Swing	231-0018
7V-7973	Gear Final Drive	231-0239
7V-7974	Pinion Final Drive	231-0253
7V-7976	Pinion - Swing Drive	231-0254
7W-0450	Gear - Water Pump	279-4997
7W-0507	Gear - Oil Pump Drive	279-4998
7W-0508	Gear - Fuel Pump Drive	296-1351
7W-3042	Tube As - Drain	325-6231
7W-5687	Hub - Camshaft	314-8684
8E-4576	Roller Gp - SF	288-3690
8E-4713	Link As	288-3705
8E-4714	Link As	288-3693
8H-2810	Case As - Filter	314-8512
8H-7980	Piston	226-0249
8K-0442	Gear	231-0240
8K-0533	Bearing - Sleeve	314-8637
8K-0576	Cage - Bearing	231-0261
8K-0578	Spacer	231-0248
8K-0579	Retainer	231-0245
8K-0665	Cage - Bearing	231-0262
8K-1749	Shaft - Sprocket	231-0242
8K-1754	Spacer	231-0247
8K-1755	Retainer - Cap	231-0246
8K-1756	Cage - Bearing	231-0263
8K-1940	Retainer As	231-0258
8K-1944	Case As - Swing Drive	231-0265
8K-1945	Shaft As - Output	231-0266
8K-1946	Retainer As	231-0259
8K-2518	Joint As	231-0267
8K-2779	Cage - Bearing	231-0483
8K-4127	Gear Gp - Bearing & Basic	235-5055
8M-6191	Sleeve - Bolt	226-0234
8N-0875	Valve - Exhaust	247-6893 (Valve), 241-3381 (Valve Kit)
8N-1187	Head Gp - Cylinder	242-3435
8N-1188	Head Gp - Cylinder	242-3436
8N-1721	Rod As - Conn	269-5291
8N-2510	Shaft	325-6208
8N-3251	Shaft As - Rocker Arm	314-8711
8N-3312	Shaft As - Rocker Arm	325-6200
8N-3325	Arm Gp - Rocker	314-8623
8N-3327	Arm Gp - Rocker	314-8624
8N-5305	Spacer	363-7464
8N-5929	Cover - Water Pump	296-1349
8N-6796	Head Gp - Cylinder	269-5290
8N-7315	Tube As - Outlet	325-6232
8N-8225	Bearing - Main	314-8652
8P-5197	Bearing As	295-6413
8S-0248	Breather As	325-6033
8S-0493	Shaft As - Pump	325-6198
8S-3970	Chamber As	242-3438
8V-2631	Pin As	241-2526
8V-2632	Pin As	241-2523
8V-2634	Pin As	241-2518
9C-3187	Pin As	314-8694
9C-4211	Pin As	241-2519
9C-4737	Pin As	241-2520
9C-4912	Pin As	241-2517

(Continued)

Sales Model 229 (Continued)

Original Part Number	Part Name	Classic Part Number
9C-5060	Link As - Bearing	299-2022
9C-6187	Pin As	241-2521
9K-8425	Bearing - Sleeve	314-8638
9K-8757	Rod End - Bearing	311-9361
9N-5769	Cover - Housing	325-6050
9S-6129	Pulley - Alternator Drive	264-5891
9S-8679	Chamber As	325-6042
9T-6526	Joint As - Univ	365-8824
9U-0654	Coupling	297-7167
9Y-2992	Bearing - Sleeve	325-6032

Sales Model 229D

Original Part Number	Part Name	Classic Part Number
100-3431	Stop	314-8723
100-7860	Valve - Inlet	270-4360 (Valve), 270-4362 (Valve Kit)
104-4253	Line As - Fuel Injector	279-4988
104-4254	Line As - Fuel Injector	279-4989
111-8015	Gasket As - Head	279-4977
121-7746	Precleaner As	360-2311
131-3815	Seal Gp - Basic	325-6193
148-7455	Valve - Exhaust	270-4361
172-5185	Shaft - Water Pump	325-6201
172-5188	Shaft - Water Pump	325-6202
172-5189	Impeller - Pump	295-5687
172-5190	Impeller - Pump	325-6111
172-6712	Impeller - Pump	325-6112
172-7767	Pump Gp - Water	296-1365
190-8609	Valve - Fill	360-2288
196-0028	Gear As - Idler	364-5259
1M-7250	Bowl - Precleaner	360-2296
1N-3576	Block Gp - Cylinder	279-4978
1N-3958	Elbow	325-6087
1N-4304	Head Gp - Cylinder	269-8761
1P-1216	Manifold - Exhaust	261-0902
1P-1721	Gear - Balance	298-2769
1P-1722	Gear - Balance	298-2770
1S-2268	Piston	226-2726
1S-4701	Pulley - Alt	264-5866
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1695	Pump Gp	279-4980
1W-1698	Housing - Transfer Pump	296-1356
1W-2572	Muffler As	247-2663
1W-2870	Shaft As - Balance	314-8715
1W-2871	Shaft As - Balance	314-8716
1W-4402	Gear - Camshaft	279-4981
1W-4405	Gear - Crankshaft	279-4982
1W-5912	Tappet As - Guide	325-6223
1W-6541	Plunger As	325-6173
244-1090	Alarm - Back up	360-2345
2D-5658	Bearing - Ball	301-4628
2F-5721	Bearing - Ball	311-9354
2K-6413	Pin	360-2270
2P-1170	Shaft As - Gear	296-1367
2P-1757	Hub - Fan Pulley	296-1357
2P-1781	Spacer - Oil Pump	325-6214
2P-2519	Tube As - Inlet	325-6230
2P-2719	Pipe	363-7454
2P-6245	Shaft As - Pump	325-6197
2P-7828	Pan - Oil	314-8691
2V-0707	Bearing - Sleeve	360-2328
2V-0814	Gear - Output	231-0233
2V-0816	Pinion - Swing Drive	231-0017
2V-0817	Gear - Cluster	231-0234
2V-1722	Pin As	241-2525
2W-1086	Cover As - Cylinder Head	325-6049
2W-2621	Valve - Inlet	247-6892 (Valve), 241-3381 (Valve Kit)
2W-7255	Shaft - Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
3L-1425	Bearing - Ball	311-9356
4F-4974	Clamp	311-9373
4N-4539	Sleeve	314-8720
4N-7692	Crankshaft As	242-3440
4N-7693	Crankshaft As	242-3439
4P-3546	Valve As - Relief	325-6236
4P-9381	Line As - Fuel Injector	279-4984
4P-9382	Line As - Fuel Injector	279-4985
4P-9961	Line As - Fuel Injector	325-6115
4P-9962	Line As - Fuel Injector	325-6116
4P-9963	Line As - Fuel Injector	298-2777
4P-9964	Line As - Fuel Injector	298-2778
4W-0452	Seal As - Camshaft	325-6191
5P-7807	Bearing - Ball	314-8502
5S-6795	Chamber As	242-3437
5S-9062	Spacer	363-7463
5S-9080	Pulley - Alt Drive	264-5883
6H-3957	Bearing - Ball	311-9358
6I-1346	Pump Gp - Oil	295-5674

(Continued)

Sales Model 229D (Continued)

Original Part Number	Part Name	Classic Part Number
6N-1036	Gear - Oil Pump	279-4991
6N-1553	Coupling - Exhaust	295-6422
6N-3256	Mount As	314-8688
6N-8413	Housing - Pump	325-6110
7N-0165	Core As - Oil Cooler	295-5670
7N-1164	Mount As	295-5451
7N-2949	Pulley	264-5887
7N-5910	Impeller - Pump	314-8686
7N-9145	Gear - Flywheel	279-4994
7N-9805	Pin - Piston	295-6438
7S-3161	Lifter - Valve	279-4996
7S-6723	Bracket - Alternator	299-1978
7T-2036	Cap As - Filter	361-1721
7V-7017	Pinion Swing	231-0018
7V-7976	Pinion - Swing Drive	231-0254
7W-0450	Gear - Water Pump	279-4997
7W-0507	Gear - Oil Pump Drive	279-4998
7W-0508	Gear - Fuel Pump Drive	296-1351
7W-3042	Tube As - Drain	325-6231
7W-5687	Hub - Camshaft	314-8684
8H-2810	Case As - Filter	314-8512
8K-0576	Cage - Bearing	231-0261
8K-0578	Spacer	231-0248
8K-0579	Retainer	231-0245
8K-0665	Cage - Bearing	231-0262
8K-1940	Retainer As	231-0258
8K-1944	Case As - Swing Drive	231-0265
8K-1946	Retainer As	231-0259
8N-0875	Valve - Exhaust	247-6893 (Valve), 241-3381 (Valve Kit)
8N-1187	Head Gp - Cylinder	242-3435
8N-1188	Head Gp - Cylinder	242-3436
8N-1721	Rod As - Conn	269-5291
8N-2510	Shaft	325-6208
8N-2641	Sleeve	325-6210
8N-3251	Shaft As - Rocker Arm	314-8711
8N-3312	Shaft As - Rocker Arm	325-6200
8N-3325	Arm Gp - Rocker	314-8623
8N-3327	Arm Gp - Rocker	314-8624
8N-5305	Spacer	363-7464
8N-5929	Cover - Water Pump	296-1349
8N-6796	Head Gp - Cylinder	269-5290
8N-7315	Tube As - Outlet	325-6232
8N-8225	Bearing - Main	314-8652
8P-5197	Bearing As	295-6413
8S-0248	Breather As	325-6033
8S-0493	Shaft As - Pump	325-6198
8S-3970	Chamber As	242-3438
8V-2632	Pin As	241-2523
8V-2634	Pin As	241-2518
9C-3187	Pin As	314-8694
9C-4211	Pin As	241-2519
9C-4737	Pin As	241-2520
9C-5060	Link As - Bearing	299-2022
9K-8757	Rod End - Bearing	311-9361
9N-5769	Cover - Housing	325-6050
9S-6129	Pulley - Alternator Drive	264-5891
9S-8679	Chamber As	325-6042
9U-0654	Coupling	297-7167
9Y-2992	Bearing - Sleeve	325-6032

Sales Model 231D

Original Part Number	Part Name	Classic Part Number
100-3431	Stop	314-8723
115-6427	Spring	301-4776
115-6429	Cylinder	301-4679
121-7746	Precleaner As	360-2311
122-5076	Rod	301-4569
122-5077	Cylinder	301-4673
122-5178	Piston As	301-5252
131-3815	Seal Gp - Basic	325-6193
190-8609	Valve - Fill	360-2288
1M-7250	Bowl - Precleaner	360-2296
1P-8554	Coupling - Exhaust	325-6052
1S-2268	Piston	226-2726
1S-4701	Pulley - Alt	264-5866
244-1090	Alarm - Back up	360-2345
2D-5658	Bearing - Ball	301-4628
2F-5721	Bearing - Ball	311-9354
2V-0814	Gear - Output	231-0233
2V-0816	Pinion - Swing Drive	231-0017
2V-0817	Gear - Cluster	231-0234
2V-1722	Pin As	241-2525
3V-4622	Bracket - Carriage Roller	297-7148
3V-5317	Gear	231-0010
3V-5378	Gear - Output	231-0235
3V-9439	Retainer As	231-0257
4E-1035	Pin	241-2553
4E-9426	Collar	231-0000
4F-4974	Clamp	311-9373
4N-2954	Sleeve - Camshaft	299-2059
4N-4539	Sleeve	314-8720
4V-9236	Plate - Pressure	231-0260

(Continued)

Sales Model 231D (Continued)

Original Part Number	Part Name	Classic Part Number
5C-1834	Gear	231-0002
5C-5937	Gear	231-0004
5C-8582	Shaft - Planet	231-0241
5C-8583	Gear - Ring	231-0005
5C-8584	Gear - Planet	231-0006
5C-8586	Gear	231-0007
5C-8587	Cover	231-0243
5C-8966	Gear	231-0227
5P-7807	Bearing - Ball	314-8502
5S-9080	Pulley - Alt Drive	264-5883
5V-7207	Pinion - Final Drive	231-0252
5V-7222	Gear - Final Drive	231-0237
6A-7534	Retainer	231-0244
6C-0739	Carrier As	231-0012
6C-1573	Rod	297-7238
6N-3256	Mount As	314-8688
7E-5663	Muffler As	247-2667
7T-2036	Cap As - Filter	361-1721
7V-7017	Pinion Swing	231-0018
7V-7973	Gear Final Drive	231-0239
7V-7974	Pinion Final Drive	231-0253
7V-7976	Pinion - Swing Drive	231-0254
7Y-0223	Shaft - Planet	301-4625
7Y-0225	Shaft - Planet	301-4571
7Y-1427	Gear - Sun	288-8727
7Y-1428	Gear - Planet	288-8728
7Y-1430	Gear - Sun	314-8671
7Y-1431	Gear - Planet	288-8729
7Y-1432	Carrier	314-8659
8K-0576	Cage - Bearing	231-0261
8K-0578	Spacer	231-0248
8K-0579	Retainer	231-0245
8K-0665	Cage - Bearing	231-0262
8K-1749	Shaft - Sprocket	231-0242
8K-1754	Spacer	231-0247
8K-1755	Retainer - Cap	231-0246
8K-1756	Cage - Bearing	231-0263
8K-1940	Retainer As	231-0258
8K-1944	Case As - Swing Drive	231-0265
8K-1946	Retainer As	231-0259
8K-3712	Pin As	241-2541
8P-5197	Bearing As	295-6413
8V-2631	Pin As	241-2526
9C-3187	Pin As	314-8694
9K-8425	Bearing - Sleeve	314-8638
9K-8430	Pin As	241-2540
9K-8757	Rod End - Bearing	311-9361
9T-6526	Joint As - Univ	365-8824
9U-0654	Coupling	297-7167

Sales Model 235

Original Part Number	Part Name	Classic Part Number
100-3431	Stop	314-8723
100-7860	Valve - Inlet	270-4360 (Valve), 270-4362 (Valve Kit)
104-4253	Line As - Fuel Injector	279-4988
104-4254	Line As - Fuel Injector	279-4989
111-8015	Gasket As - Head	279-4977
122-9405	Bracket As	325-6005
127-5537	Core As	325-6045
131-3815	Seal Gp - Basic	325-6193
131-7736	Support As - Engine	325-6222
148-7455	Valve - Exhaust	270-4361
167-8123	Damper As	299-2006
172-5185	Shaft - Water Pump	325-6201
172-5188	Shaft - Water Pump	325-6202
172-5189	Impeller - Pump	295-5687
172-5190	Impeller - Pump	325-6111
172-6712	Impeller - Pump	325-6112
172-7767	Pump Gp - Water	296-1365
190-8609	Valve - Fill	360-2288
196-0028	Gear As - Idler	364-5259
1N-3576	Block Gp - Cylinder	279-4978
1N-3958	Elbow	325-6087
1P-0963	Guard As - Roller	226-0179
1P-9952	Impeller - Pump	314-8685
1P-9989	Pipe	363-7453
1Q-4983	Shoe - Track	289-5117
1S-2268	Piston	226-2726
1S-4701	Pulley - Alt	264-5866
1V-0557	Shoe - Track	288-6678
1W-1669	Piston	325-6158
1W-1695	Pump Gp	279-4980
1W-1698	Housing - Transfer Pump	296-1356
1W-4402	Gear - Camshaft	279-4981
1W-4405	Gear - Crankshaft	279-4982
1W-4737	Gear - Camshaft	295-5688
1W-4738	Bearing - Sleeve	325-6020
1W-4740	Gear As - Drive	295-5689
1W-4746	Retainer - Gear	295-5690
1W-5912	Tappet As - Guide	325-6223
1W-6541	Plunger As	325-6173
1W-9229	Muffler As	302-4282
244-1090	Alarm - Backup	360-2345
248-2041	Rim	289-2211
2F-5721	Bearing - Ball	311-9354
2K-3592	Boss	314-8501

(Continued)

Sales Model 235 (Continued)

Original Part Number	Part Name	Classic Part Number
2P-1170	Shaft As - Gear	296-1367
2P-1438	Pipe - Exhaust Ext	325-6157
2P-1738	Plate As - Oil Pan	325-6164
2P-1739	Tube As - Pump	325-6229
2P-1757	Hub - Fan Pulley	296-1357
2P-1781	Spacer - Oil Pump	325-6214
2P-2519	Tube As - Inlet	325-6230
2P-4611	Pipe - Exhaust	365-8821
2P-5608	Pipe - Extension	367-6066
2P-6245	Shaft As - Pump	325-6197
2V-0705	Pin As	241-2524
2V-1722	Pin As	241-2525
2W-1086	Cover As - Cylinder Head	325-6049
2W-2621	Valve - Inlet	247-6892 (Valve), 241-3381 (Valve Kit)
2W-3428	Muffler As	298-2784
2W-6757	Trunnion As	295-5678
2W-7255	Shaft - Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear - Water Pump	325-6088
3L-1425	Bearing - Ball	311-9356
3N-6815	Shoe - Track	288-6681
3Q-5391	Shoe - Track	292-5634
3V-1133	Strip	226-0203
3V-4527	Sprocket - Track	289-2209
3V-4622	Bracket - Carriage Roller	297-7148
3V-5317	Gear	231-0010
3V-5378	Gear - Output	231-0235
3V-9439	Retainer As	231-0257
3Y-9984	Manifold - Exhaust	325-6123
3Y-9985	Manifold - Exhaust	325-6124
4E-1035	Pin	241-2553
4E-1065	Pin As	241-2538
4E-1285	Link As	299-2021
4E-8500	Idler Gp -Track	288-3691
4E-9426	Collar	231-0000
4N-2954	Sleeve - Camshaft	299-2059
4N-3281	Line As - Fuel Injector	247-3362
4N-3282	Line As - Fuel Injector	247-3363
4N-3283	Line As - Fuel Injector	247-3364
4N-3284	Line As - Fuel Injector	247-3365
4N-4539	Sleeve	314-8720
4N-4782	Pulley	325-6176
4N-7693	Crankshaft As	242-3439
4N-8591	Coupling - Exhaust	325-6053
4N-8814	Line As - Fuel Injector	247-3366
4N-9587	Shield - Heat	297-7260
4P-3546	Valve As - Relief	325-6236
4P-9381	Line As - Fuel Injector	279-4984
4P-9382	Line As - Fuel Injector	279-4985
4P-9385	Line As - Fuel Injector	279-4986
4P-9386	Line As - Fuel Injector	279-4987
4V-5608	Pin As	241-2529
4V-9236	Plate - Pressure	231-0260
4W-0452	Seal As - Camshaft	325-6191
4W-2446	Damper As	279-4990
5C-1834	Gear	231-0002
5C-5937	Gear	231-0004
5C-8582	Shaft - Planet	231-0241
5C-8583	Gear - Ring	231-0005
5C-8584	Gear - Planet	231-0006
5C-8586	Gear	231-0007
5C-8587	Cover	231-0243
5C-8966	Gear	231-0227
5P-7807	Bearing - Ball	314-8502
5S-4557	Bearing	311-9360
5S-6795	Chamber As	242-3437
5S-9062	Spacer	363-7463
5S-9080	Pulley - Alt Drive	264-5883
5V-7207	Pinion - Final Drive	231-0252
5V-7214	Pin As	241-2522
5V-7222	Gear - Final Drive	231-0237
6A-7534	Retainer	231-0244
6C-0739	Carrier As	231-0012
6H-3957	Bearing - Ball	311-9358
6I-1346	Pump Gp - Oil	295-5674
6N-1036	Gear - Oil Pump	279-4991
6N-1965	Line As - Fuel Injector	250-7535
6N-1966	Line As - Fuel Injector	250-7536
6N-3256	Mount As	314-8688
6N-8413	Housing - Pump	325-6110
6Y-2192	Shoe - Track	288-6668
6Y-6405	Shoe - Track	290-9938
6Y-6407	Shoe - Track	288-6679
7C-4297	Seal As - Camshaft	325-6192
7N-0110	Core As - Oil Cooler	319-3435
7N-0128	Core As - Oil Cooler	299-1994
7N-0165	Core As - Oil Cooler	295-5670
7N-1164	Mount As	295-5451
7N-2871	Line As - Fuel Injector	319-8172
7N-2872	Line As - Fuel Injector	319-8173
7N-2874	Line As - Fuel Injector	298-2779
7N-2875	Line As - Fuel Injector	298-2780
7N-2876	Line As - Fuel Injector	298-2781
7N-2949	Pulley	264-5887
7N-3486	Manifold - Exhaust	261-0899
7N-3515	Gear - Camshaft	314-8669
7N-3536	Gear - Fuel	279-4993
7N-5910	Impeller - Pump	314-8686
7N-9146	Gear - Flywheel Starter	279-4995

(Continued)

Sales Model 235 (Continued)

Original Part Number	Part Name	Classic Part Number
7N-9312	Damper As - Camshaft	299-2005
7N-9805	Pin - Piston	295-6438
7S-3161	Lifter - Valve	279-4996
7S-6723	Bracket - Alternator	299-1978
7S-7809	Cap As - Radiator	295-6417
7T-2036	Cap As - Filter	361-1721
7V-6898	Pin As	241-2539
7V-7973	Gear Final Drive	231-0239
7V-7974	Pinion Final Drive	231-0253
7W-0450	Gear - Water Pump	279-4997
7W-0507	Gear - Oil Pump Drive	279-4998
7W-0508	Gear - Fuel Pump Drive	296-1351
7W-5687	Hub - Camshaft	314-8684
7Y-1517	Pipe As - Tail	301-5246
8E-4275	Link As	288-3694
8E-4426	Shoe -Track	288-6671
8E-4427	Shoe -Track	288-6670
8E-4428	Shoe -Track	288-6669
8E-4429	Shoe - Track	288-6677
8E-4430	Shoe - Track	288-6676
8E-4579	Roller Gp - SF	175-8216
8E-6135	Idler Gp -Track	288-3691
8E-7868	Shoe - Track	290-9940
8E-8643	Link As	288-5754
8E-8644	Link As	288-5755
8H-2810	Case As - Filter	314-8512
8K-0665	Cage - Bearing	231-0262
8K-1749	Shaft - Sprocket	231-0242
8K-1754	Spacer	231-0247
8K-1755	Retainer - Cap	231-0246
8K-1756	Cage - Bearing	231-0263
8K-2860	Flange - Coupling	297-7171
8K-3712	Pin As	241-2541
8N-0002	Trunnion As	314-8728
8N-0875	Valve - Exhaust	247-6893 (Valve), 241-3381 (Valve Kit)
8N-1187	Head Gp - Cylinder	242-3435
8N-1721	Rod As - Conn	269-5291
8N-1984	Rod As - Conn	242-3441
8N-2510	Shaft	325-6208
8N-2641	Sleeve	325-6210
8N-3182	Body As - Piston	250-6564 (Piston As), 250-6556 (Liner Kits)
8N-3183	Piston Gp - Basic	250-6556 (Liner Kit)
8N-3251	Shaft As - Rocker Arm	314-8711
8N-3325	Arm Gp - Rocker	314-8623
8N-3327	Arm Gp - Rocker	314-8624
8N-5305	Spacer	363-7464
8N-5929	Cover - Water Pump	296-1349
8N-6796	Head Gp - Cylinder	269-5290
8N-7315	Tube As - Outlet	325-6232
8N-8225	Bearing - Main	314-8652
8N-9733	Line As - Fuel Injector	319-8174
8P-5197	Bearing As	295-6413
8R-3787	Shaft	299-2058
8S-0248	Breather As	325-6033
8S-0493	Shaft As - Pump	325-6198
8S-3970	Chamber As	242-3438
8V-2631	Pin As	241-2526
8V-2632	Pin As	241-2523
8V-5439	Pin As	241-2531
9K-3565	Shoe - Track	290-9941
9K-3568	Shoe - Track	290-9942
9K-8425	Bearing - Sleeve	314-8638
9K-8427	Pin As	241-2527
9K-8428	Pin As	241-2533
9K-8430	Pin As	241-2540
9K-8435	Pin	241-2552
9K-8757	Rod End - Bearing	311-9361
9N-5251	Piston Gp - Basic	250-6557 (Liner Kit)
9N-5769	Cover - Housing	325-6050
9S-2354	Manifold - Exhaust	261-0888
9S-2355	Manifold - Exhaust	261-0891
9S-6129	Pulley - Alternator Drive	264-5891
9S-8679	Chamber As	325-6042
9T-6526	Joint As - Univ	365-8824
9U-0654	Coupling	297-7167
9W-6483	Shoe - Track	288-6672, 288-6673

Sales Model 235B

Original Part Number	Part Name	Classic Part Number
100-7860	Valve - Inlet	270-4360 (Valve), 270-4362 (Valve Kit)
104-4253	Line As - Fuel Injector	279-4988
104-4254	Line As - Fuel Injector	279-4989
111-8015	Gasket As - Head	279-4977
122-9405	Bracket As	325-6005
127-5537	Core As	325-6045
131-3815	Seal Gp - Basic	325-6193
131-7736	Support As - Engine	325-6222
148-7455	Valve - Exhaust	270-4361
167-8123	Damper As	299-2006
172-5185	Shaft - Water Pump	325-6201
172-5188	Shaft - Water Pump	325-6202
172-5189	Impeller - Pump	295-5687
172-5190	Impeller - Pump	325-6111
172-6712	Impeller - Pump	325-6112
172-7767	Pump Gp - Water	296-1365
190-8609	Valve - Fill	360-2288
196-0028	Gear As - Idler	364-5259
1N-3576	Block Gp - Cylinder	279-4978
1N-3958	Elbow	325-6087
1P-8554	Coupling - Exhaust	325-6052
1P-9945	Bracket As - Fan	296-1344
1P-9946	Shaft - Fan	325-6194
1P-9952	Impeller - Pump	314-8685
1P-9989	Pipe	363-7453
1S-2268	Piston	226-2726
1S-4701	Pulley - Alt	264-5866
1U-2738	Piston As	367-6074
1W-1669	Piston	325-6158
1W-1695	Pump Gp	279-4980
1W-1698	Housing - Transfer Pump	296-1356
1W-4402	Gear - Camshaft	279-4981
1W-4405	Gear - Crankshaft	279-4982
1W-4737	Gear - Camshaft	295-5688
1W-4738	Bearing - Sleeve	325-6020
1W-4740	Gear As - Drive	295-5689
1W-4746	Retainer - Gear	295-5690
1W-5912	Tappet As - Guide	325-6223
1W-6541	Plunger As	325-6173
1W-9229	Muffler As	302-4282
244-1090	Alarm - Back up	360-2345
2F-5721	Bearing - Ball	311-9354
2K-3592	Boss	314-8501
2K-6413	Pin	360-2270
2P-1170	Shaft As - Gear	296-1367
2P-1438	Pipe - Exhaust Ext	325-6157
2P-1738	Plate As - Oil Pan	325-6164
2P-1739	Tube As - Pump	325-6229
2P-1757	Hub - Fan Pulley	296-1357
2P-1781	Spacer - Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2519	Tube As - Inlet	325-6230
2P-2719	Pipe	363-7454
2P-4611	Pipe - Exhaust	365-8821
2P-5608	Pipe - Extension	367-6066
2P-6128	Pulley	264-5872
2P-6245	Shaft As - Pump	325-6197
2W-1086	Cover As - Cylinder Head	325-6049
2W-2621	Valve - Inlet	247-6892 (Valve), 241-3381 (Valve Kit)
2W-3428	Muffler As	298-2784
2W-6757	Trunnion As	295-5678
2W-7255	Shaft - Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear - Water Pump	325-6088
2W-9978	Core As - Oil Cooler	279-4983
3L-1425	Bearing - Ball	311-9356
3V-4622	Bracket - Carriage Roller	297-7148
3Y-9984	Manifold - Exhaust	325-6123
3Y-9985	Manifold - Exhaust	325-6124
4E-1035	Pin	241-2553
4E-1065	Pin As	241-2538
4E-1285	Link As	299-2021
4N-2954	Sleeve - Camshaft	299-2059
4N-3281	Line As - Fuel Injector	247-3362
4N-3282	Line As - Fuel Injector	247-3363
4N-3283	Line As - Fuel Injector	247-3364
4N-4539	Sleeve	314-8720
4N-4782	Pulley	325-6176
4N-7693	Crankshaft As	242-3439
4N-8591	Coupling - Exhaust	325-6053
4N-8814	Line As - Fuel Injector	247-3366
4N-9587	Shield - Heat	297-7260
4P-3546	Valve As - Relief	325-6236
4P-9381	Line As - Fuel Injector	279-4984
4P-9382	Line As - Fuel Injector	279-4985
4P-9385	Line As - Fuel Injector	279-4986
4P-9386	Line As - Fuel Injector	279-4987
4V-5608	Pin As	241-2529
4W-0452	Seal As - Camshaft	325-6191
4W-2446	Damper As	279-4990
5P-7807	Bearing - Ball	314-8502
5S-1211	Cover - Valve	314-8665
5S-4557	Bearing	311-9360
5S-6795	Chamber As	242-3437

(Continued)

Sales Model 235B (Continued)

Original Part Number	Part Name	Classic Part Number
5S-9062	Spacer	363-7463
5S-9080	Pulley - Alt Drive	264-5883
6H-3957	Bearing - Ball	311-9358
6I-1346	Pump Gp - Oil	295-5674
6N-1036	Gear - Oil Pump	279-4991
6N-1965	Line As - Fuel Injector	250-7535
6N-1966	Line As - Fuel Injector	250-7536
6N-2789	Pulley	264-5886
6N-3256	Mount As	314-8688
6N-8413	Housing - Pump	325-6110
7C-4297	Seal As - Camshaft	325-6192
7N-0110	Core As - Oil Cooler	319-3435
7N-0128	Core As - Oil Cooler	299-1994
7N-0165	Core As - Oil Cooler	295-5670
7N-1164	Mount As	295-5451
7N-2871	Line As - Fuel Injector	319-8172
7N-2872	Line As - Fuel Injector	319-8173
7N-2874	Line As - Fuel Injector	298-2779
7N-2875	Line As - Fuel Injector	298-2780
7N-2876	Line As - Fuel Injector	298-2781
7N-2949	Pulley	264-5887
7N-2957	Cover - Rad Cap	361-1722
7N-3486	Manifold - Exhaust	261-0899
7N-3515	Gear - Camshaft	314-8669
7N-3536	Gear - Fuel	279-4993
7N-5511	Gear As - Idler	233-2180
7N-5910	Impeller - Pump	314-8686
7N-9145	Gear - Flywheel	279-4994
7N-9146	Gear - Flywheel Starter	279-4995
7N-9312	Damper As - Camshaft	299-2005
7N-9805	Pin - Piston	295-6438
7S-3161	Lifter - Valve	279-4996
7S-6723	Bracket - Alternator	299-1978
7S-7809	Cap As - Radiator	295-6417
7T-2036	Cap As - Filter	361-1721
7W-0450	Gear - Water Pump	279-4997
7W-0507	Gear - Oil Pump Drive	279-4998
7W-0508	Gear - Fuel Pump Drive	296-1351
7W-5687	Hub - Camshaft	314-8684
7Y-1517	Pipe As - Tail	301-5246
8H-2810	Case As - Filter	314-8512
8K-0665	Cage - Bearing	231-0262
8K-2860	Flange - Coupling	297-7171
8K-3712	Pin As	241-2541
8N-0002	Trunnion As	314-8728
8N-0875	Valve - Exhaust	247-6893 (Valve), 241-3381 (Valve Kit)
8N-1187	Head Gp - Cylinder	242-3435
8N-1721	Rod As - Conn	269-5291
8N-1984	Rod As - Conn	242-3441
8N-2510	Shaft	325-6208
8N-2641	Sleeve	325-6210
8N-3182	Body As - Piston	250-6564 (Piston As), 250-6556 (Liner Kits)
8N-3183	Piston Gp - Basic	250-6556 (Liner Kit)
8N-3251	Shaft As - Rocker Arm	314-8711
8N-3325	Arm Gp - Rocker	314-8623
8N-3327	Arm Gp - Rocker	314-8624
8N-5305	Spacer	363-7464
8N-5779	Coupling - Exhaust	325-6047
8N-5929	Cover - Water Pump	296-1349
8N-6796	Head Gp - Cylinder	269-5290
8N-7315	Tube As - Outlet	325-6232
8N-8225	Bearing - Main	314-8652
8N-9733	Line As - Fuel Injector	319-8174
8R-3787	Shaft	299-2058
8S-0248	Breather As	325-6033
8S-0493	Shaft As - Pump	325-6198
8S-0905	Muffler As	302-2690
8S-3970	Chamber As	242-3438
8S-7716	Manifold - Exhaust	295-0415
8S-7717	Manifold - Exhaust	261-0894
8S-7718	Manifold - Exhaust	295-0416
8V-5439	Pin As	241-2531
9C-6544	Drum - Brake	297-7169
9K-8425	Bearing - Sleeve	314-8638
9K-8427	Pin As	241-2527
9K-8428	Pin As	241-2533
9K-8430	Pin As	241-2540
9K-8435	Pin	241-2552
9K-8757	Rod End - Bearing	311-9361
9N-5769	Cover - Housing	325-6050
9S-2354	Manifold - Exhaust	261-0888
9S-2355	Manifold - Exhaust	261-0891
9S-6129	Pulley - Alternator Drive	264-5891
9S-7079	Muffler As	247-2669
9S-8679	Chamber As	325-6042
9T-6526	Joint As - Univ	365-8824
9U-0654	Coupling	297-7167

Sales Model 235C

Original Part Number	Part Name	Classic Part Number
100-3431	Stop	314-8723
100-7860	Valve - Inlet	270-4360 (Valve), 270-4362 (Valve Kit)
104-4253	Line As - Fuel Injector	279-4988
104-4254	Line As - Fuel Injector	279-4989
111-8015	Gasket As - Head	279-4977
122-9405	Bracket As	325-6005
127-5537	Core As	325-6045
131-3815	Seal Gp - Basic	325-6193
131-7736	Support As - Engine	325-6222
148-7455	Valve - Exhaust	270-4361
167-8123	Damper As	299-2006
172-5185	Shaft - Water Pump	325-6201
172-5188	Shaft - Water Pump	325-6202
172-5189	Impeller - Pump	295-5687
172-5190	Impeller - Pump	325-6111
172-6712	Impeller - Pump	325-6112
172-7767	Pump Gp - Water	296-1365
190-8609	Valve - Fill	360-2288
196-0028	Gear As - Idler	364-5259
1N-3576	Block Gp - Cylinder	279-4978
1P-8554	Coupling - Exhaust	325-6052
1P-9945	Bracket As - Fan	296-1344
1P-9946	Shaft - Fan	325-6194
1P-9952	Impeller - Pump	314-8685
1S-2268	Piston	226-2726
1S-4701	Pulley - Alt	264-5866
1U-2738	Piston As	367-6074
1W-1669	Piston	325-6158
1W-1695	Pump Gp	279-4980
1W-1698	Housing - Transfer Pump	296-1356
1W-4402	Gear - Camshaft	279-4981
1W-4405	Gear - Crankshaft	279-4982
1W-4737	Gear - Camshaft	295-5688
1W-4738	Bearing - Sleeve	325-6020
1W-4740	Gear As - Drive	295-5689
1W-4746	Retainer - Gear	295-5690
1W-5912	Tappet As - Guide	325-6223
1W-6541	Plunger As	325-6173
1W-9229	Muffler As	302-4282
244-1090	Alarm - Back up	360-2345
2F-5721	Bearing - Ball	311-9354
2K-3592	Boss	314-8501
2K-6413	Pin	360-2270
2P-1170	Shaft As - Gear	296-1367
2P-1738	Plate As - Oil Pan	325-6164
2P-1739	Tube As - Pump	325-6229
2P-1757	Hub - Fan Pulley	296-1357
2P-1781	Spacer - Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2519	Tube As - Inlet	325-6230
2P-2719	Pipe	363-7454
2P-4611	Pipe - Exhaust	365-8821
2P-6128	Pulley	264-5872
2P-6245	Shaft As - Pump	325-6197
2W-1086	Cover As - Cylinder Head	325-6049
2W-2621	Valve - Inlet	247-6892 (Valve), 241-3381 (Valve Kit)
2W-6757	Trunnion As	295-5678
2W-7255	Shaft - Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear - Water Pump	325-6088
2W-9978	Core As - Oil Cooler	279-4983
3F-4971	Pin	295-5693
3L-1425	Bearing - Ball	311-9356
3P-0651	Seal - o-Ring	314-8541
3V-4622	Bracket - Carriage Roller	297-7148
3V-5317	Gear	231-0010
3V-5378	Gear - Output	231-0235
3V-9439	Retainer As	231-0257
3Y-9984	Manifold - Exhaust	325-6123
3Y-9985	Manifold - Exhaust	325-6124
4E-1035	Pin	241-2553
4E-1065	Pin As	241-2538
4E-1285	Link As	299-2021
4E-9426	Collar	231-0000
4K-6810	Retainer - Seal	300-2586
4N-2954	Sleeve - Camshaft	299-2059
4N-3281	Line As - Fuel Injector	247-3362
4N-3282	Line As - Fuel Injector	247-3363
4N-3283	Line As - Fuel Injector	247-3364
4N-4539	Sleeve	314-8720
4N-4782	Pulley	325-6176
4N-7693	Crankshaft As	242-3439
4N-8591	Coupling - Exhaust	325-6053
4N-8814	Line As - Fuel Injector	247-3366
4N-9587	Shield - Heat	297-7260
4P-3546	Valve As - Relief	325-6236
4P-9381	Line As - Fuel Injector	279-4984
4P-9382	Line As - Fuel Injector	279-4985
4P-9385	Line As - Fuel Injector	279-4986
4P-9386	Line As - Fuel Injector	279-4987
4V-9236	Plate - Pressure	231-0260
4W-0452	Seal As - Camshaft	325-6191
4W-2446	Damper As	279-4990

(Continued)

Sales Model 235C (Continued)

Original Part Number	Part Name	Classic Part Number
5C-1834	Gear	231-0002
5C-5937	Gear	231-0004
5C-8582	Shaft - Planet	231-0241
5C-8583	Gear - Ring	231-0005
5C-8584	Gear - Planet	231-0006
5C-8586	Gear	231-0007
5C-8587	Cover	231-0243
5C-8966	Gear	231-0227
5P-7807	Bearing - Ball	314-8502
5S-1211	Cover - Valve	314-8665
5S-4557	Bearing	311-9360
5S-6795	Chamber As	242-3437
5S-9062	Spacer	363-7463
5S-9080	Pulley - Alt Drive	264-5883
5V-7207	Pinion - Final Drive	231-0252
5V-7222	Gear - Final Drive	231-0237
6A-7534	Retainer	231-0244
6C-0739	Carrier As	231-0012
6H-3957	Bearing - Ball	311-9358
6I-1346	Pump Gp - Oil	295-5674
6N-1036	Gear - Oil Pump	279-4991
6N-1965	Line As - Fuel Injector	250-7535
6N-1966	Line As - Fuel Injector	250-7536
6N-2789	Pulley	264-5886
6N-3256	Mount As	314-8688
6N-8413	Housing - Pump	325-6110
7C-4297	Seal As - Camshaft	325-6192
7N-0110	Core As - Oil Cooler	319-3435
7N-0128	Core As - Oil Cooler	299-1994
7N-0165	Core As - Oil Cooler	295-5670
7N-1164	Mount As	295-5451
7N-2871	Line As - Fuel Injector	319-8172
7N-2872	Line As - Fuel Injector	319-8173
7N-2874	Line As - Fuel Injector	298-2779
7N-2875	Line As - Fuel Injector	298-2780
7N-2876	Line As - Fuel Injector	298-2781
7N-2949	Pulley	264-5887
7N-2957	Cover - Rad Cap	361-1722
7N-3486	Manifold - Exhaust	261-0899
7N-3515	Gear - Camshaft	314-8669
7N-3536	Gear - Fuel	279-4993
7N-5511	Gear As - Idler	233-2180
7N-5910	Impeller - Pump	314-8686
7N-9145	Gear - Flywheel	279-4994
7N-9146	Gear - Flywheel Starter	279-4995
7N-9312	Damper As - Camshaft	299-2005
7N-9805	Pin - Piston	295-6438
7S-3161	Lifter - Valve	279-4996
7S-6723	Bracket - Alternator	299-1978
7S-7809	Cap As - Radiator	295-6417
7V-7973	Gear Final Drive	231-0239
7V-7974	Pinion Final Drive	231-0253
7W-0450	Gear - Water Pump	279-4997
7W-0507	Gear - Oil Pump Drive	279-4998
7W-0508	Gear - Fuel Pump Drive	296-1351
7W-5687	Hub - Camshaft	314-8684
7Y-1517	Pipe As - Tail	301-5246
8H-2810	Case As - Filter	314-8512
8K-0665	Cage - Bearing	231-0262
8K-1107	Rack - Disconnect	231-0264
8K-1749	Shaft - Sprocket	231-0242
8K-1754	Spacer	231-0247
8K-1755	Retainer - Cap	231-0246
8K-1756	Cage - Bearing	231-0263
8K-2779	Cage - Bearing	231-0483
8K-2860	Flange - Coupling	297-7171
8N-0002	Trunnion As	314-8728
8N-0875	Valve - Exhaust	247-6893 (Valve), 241-3381 (Valve Kit)
8N-1187	Head Gp - Cylinder	242-3435
8N-1721	Rod As - Conn	269-5291
8N-1984	Rod As - Conn	242-3441
8N-2510	Shaft	325-6208
8N-2641	Sleeve	325-6210
8N-3182	Body As - Piston	250-6564 (Piston As), 250-6556 (Liner Kits)
8N-3183	Piston Gp - Basic	250-6556 (Liner Kit)
8N-3251	Shaft As - Rocker Arm	314-8711
8N-3325	Arm Gp - Rocker	314-8623
8N-3327	Arm Gp - Rocker	314-8624
8N-5305	Spacer	363-7464
8N-5779	Coupling - Exhaust	325-6047
8N-5929	Cover - Water Pump	296-1349
8N-6796	Head Gp - Cylinder	269-5290
8N-7315	Tube As - Outlet	325-6232
8N-8225	Bearing - Main	314-8652
8N-9733	Line As - Fuel Injector	319-8174
8P-5197	Bearing As	295-6413
8R-3787	Shaft	299-2058
8S-0248	Breather As	325-6033
8S-0493	Shaft As - Pump	325-6198
8S-0905	Muffler As	302-2690
8S-3970	Chamber As	242-3438
8S-7716	Manifold - Exhaust	295-0415
8S-7717	Manifold - Exhaust	261-0894
8S-7718	Manifold - Exhaust	295-0416

(Continued)

Sales Model 235C (Continued)

Original Part Number	Part Name	Classic Part Number
8V-5439	Pin As	241-2531
9C-6544	Drum - Brake	297-7169
9K-0092	Pinion	231-0484
9K-8425	Bearing - Sleeve	314-8638
9K-8427	Pin As	241-2527
9K-8430	Pin As	241-2540

Original Part Number	Part Name	Classic Part Number
9K-8435	Pin	241-2552
9K-8757	Rod End - Bearing	311-9361
9N-5769	Cover - Housing	325-6050
9S-2354	Manifold - Exhaust	261-0888

Original Part Number	Part Name	Classic Part Number
9S-2355	Manifold - Exhaust	261-0891
9S-6129	Pulley - Alternator Drive	264-5891
9S-7079	Muffler As	247-2669
9S-8679	Chamber As	325-6042
9T-6526	Joint As - Univ	365-8824
9U-0654	Coupling	297-7167

Sales Model 235D

Original Part Number	Part Name	Classic Part Number
100-3431	Stop	314-8723
100-7860	Valve - Inlet	270-4360 (Valve), 270-4362 (Valve Kit)
104-4253	Line As - Fuel Injector	279-4988
104-4254	Line As - Fuel Injector	279-4989
111-8015	Gasket As - Head	279-4977
122-9405	Bracket As	325-6005
127-5537	Core As	325-6045
131-3815	Seal Gp - Basic	325-6193
131-7736	Support As - Engine	325-6222
148-7455	Valve - Exhaust	270-4361
167-8123	Damper As	299-2006
172-5185	Shaft - Water Pump	325-6201
172-5189	Impeller - Pump	295-5687
172-5190	Impeller - Pump	325-6111
190-8609	Valve - Fill	360-2288
196-0028	Gear As - Idler	364-5259
1N-3576	Block Gp - Cylinder	279-4978
1S-2268	Piston	226-2726
1S-4701	Pulley - Alt	264-5866
1U-2738	Piston As	367-6074
1W-1669	Piston	325-6158
1W-1695	Pump Gp	279-4980
1W-1698	Housing - Transfer Pump	296-1356

Original Part Number	Part Name	Classic Part Number
1W-4402	Gear - Camshaft	279-4981
1W-4405	Gear - Crankshaft	279-4982
1W-4737	Gear - Camshaft	295-5688
1W-4738	Bearing - Sleeve	325-6020
1W-4740	Gear As - Drive	295-5689
1W-4746	Retainer - Gear	295-5690
1W-5912	Tappet As - Guide	325-6223
1W-9229	Muffler As	302-4282
244-1090	Alarm - Back up	360-2345
2F-5721	Bearing - Ball	311-9354
2K-3592	Boss	314-8501
2K-6413	Pin	360-2270
2P-1170	Shaft As - Gear	296-1367
2P-1738	Plate As - Oil Pan	325-6164
2P-1739	Tube As - Pump	325-6229
2P-1757	Hub - Fan Pulley	296-1357
2P-1781	Spacer - Oil Pump	325-6214
2P-2519	Tube As - Inlet	325-6230
2P-2719	Pipe	363-7454
2P-4611	Pipe - Exhaust	365-8821
2P-6245	Shaft As - Pump	325-6197
2W-1086	Cover As - Cylinder Head	325-6049

Original Part Number	Part Name	Classic Part Number
2W-2621	Valve - Inlet	247-6892 (Valve), 241-3381 (Valve Kit)
2W-6757	Trunnion As	295-5678
2W-7255	Shaft - Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
3F-4971	Pin	295-5693
3L-1425	Bearing - Ball	311-9356
3P-0651	Seal - o-Ring	314-8541
3V-4622	Bracket - Carriage Roller	297-7148
3Y-9984	Manifold - Exhaust	325-6123
3Y-9985	Manifold - Exhaust	325-6124
4E-1035	Pin	241-2553
4E-1065	Pin As	241-2538
4E-1285	Link As	299-2021
4K-6810	Retainer - Seal	300-2586
4N-4539	Sleeve	314-8720
4N-4782	Pulley	325-6176
4N-7693	Crankshaft As	242-3439
4N-8591	Coupling - Exhaust	325-6053
4P-3546	Valve As - Relief	325-6236
4P-9381	Line As - Fuel Injector	279-4984
4P-9382	Line As - Fuel Injector	279-4985
4P-9385	Line As - Fuel Injector	279-4986
4P-9386	Line As - Fuel Injector	279-4987

(Continued)

Sales Model 235D (Continued)

Original Part Number	Part Name	Classic Part Number
4W-0452	Seal As - Camshaft	325-6191
4W-2446	Damper As	279-4990
5P-7807	Bearing - Ball	314-8502
5S-4557	Bearing	311-9360
5S-6795	Chamber As	242-3437
5S-9062	Spacer	363-7463
5S-9080	Pulley - Alt Drive	264-5883
6H-3957	Bearing - Ball	311-9358
6I-1346	Pump Gp - Oil	295-5674
6N-1036	Gear - Oil Pump	279-4991
6N-3256	Mount As	314-8688
7C-4297	Seal As - Camshaft	325-6192
7N-0110	Core As - Oil Cooler	319-3435
7N-1164	Mount As	295-5451
7N-2949	Pulley	264-5887
7N-5910	Impeller - Pump	314-8686
7N-9146	Gear - Flywheel Starter	279-4995
7N-9805	Pin - Piston	295-6438
7S-3161	Lifter - Valve	279-4996
7S-6723	Bracket - Alternator	299-1978
7S-7809	Cap As - Radiator	295-6417
7W-0450	Gear - Water Pump	279-4997
7W-0507	Gear - Oil Pump Drive	279-4998
7W-0508	Gear - Fuel Pump Drive	296-1351
7W-5687	Hub - Camshaft	314-8684
7Y-1517	Pipe As - Tail	301-5246
8H-2810	Case As - Filter	314-8512
8K-0665	Cage - Bearing	231-0262
8K-1107	Rack - Disconnect	231-0264
8K-2779	Cage - Bearing	231-0483
8K-2860	Flange - Coupling	297-7171
8N-0875	Valve - Exhaust	247-6893 (Valve), 241-3381 (Valve Kit)
8N-1187	Head Gp - Cylinder	242-3435
8N-1721	Rod As - Conn	269-5291
8N-2510	Shaft	325-6208
8N-2641	Sleeve	325-6210
8N-3251	Shaft As - Rocker Arm	314-8711
8N-3325	Arm Gp - Rocker	314-8623
8N-3327	Arm Gp - Rocker	314-8624
8N-5305	Spacer	363-7464
8N-5929	Cover - Water Pump	296-1349
8N-6796	Head Gp - Cylinder	269-5290
8N-7315	Tube As - Outlet	325-6232
8N-8225	Bearing - Main	314-8652
8R-3787	Shaft	299-2058
8S-0248	Breather As	325-6033
8S-0493	Shaft As - Pump	325-6198
8S-3970	Chamber As	242-3438
8S-7716	Manifold - Exhaust	295-0415
8S-7717	Manifold - Exhaust	261-0894
8S-7718	Manifold - Exhaust	295-0416
8V-5439	Pin As	241-2531
9C-6544	Drum - Brake	297-7169
9K-0092	Pinion	231-0484
9K-8425	Bearing - Sleeve	314-8638
9K-8427	Pin As	241-2527
9K-8430	Pin As	241-2540
9K-8757	Rod End - Bearing	311-9361
9N-5769	Cover - Housing	325-6050
9S-6129	Pulley - Alternator Drive	264-5891
9S-8679	Chamber As	325-6042
9T-6526	Joint As - Univ	365-8824
9U-0654	Coupling	297-7167

Sales Model 245

Original Part Number	Part Name	Classic Part Number
100-3431	Stop	314-8723
129-3068	Rebuild Kit, W/P (Str Brgs)	363-7455
131-3815	Seal Gp - Basic	325-6193
177-9024	Adapter - Damper	299-1956
180-3767	Adapter - Damper	299-1957
190-8609	Valve - Fill	360-2288
1P-9946	Shaft - Fan	325-6194
1S-4701	Pulley - Alt	264-5866
1U-2738	Piston As	367-6074
1V-5744	Pin	241-2554
1W-1669	Piston	325-6158
1W-1698	Housing - Transfer Pump	296-1356
1W-4738	Bearing - Sleeve	325-6020
244-1090	Alarm - Back up	360-2345
2F-5721	Bearing - Ball	311-9354
2K-3592	Boss	314-8501
2N-7942	Spacer	363-7462
2P-1757	Hub - Fan Pulley	296-1357
3F-4971	Pin	295-5693
3L-1425	Bearing - Ball	311-9356
3P-0651	Seal - o-Ring	314-8541
4J-6374	Bearing - Sleeve	295-6407
4K-6810	Retainer - Seal	300-2586

(Continued)

Sales Model 245 (Continued)

Original Part Number	Part Name	Classic Part Number
4N-3714	Chamber, Precom	363-7450
4N-4539	Sleeve	314-8720
4N-6302	Belt Set - Vee	314-8495
4P-9961	Line As - Fuel Injector	325-6115
4S-8472	Hood As	296-1355
5G-3612	Cap Gp	295-6419
5L-8856	Coupling - Exhaust	311-9379
5P-7807	Bearing - Ball	314-8502
5S-1211	Cover - Valve	314-8665
5S-9062	Spacer	363-7463
5S-9080	Pulley - Alt Drive	264-5883
6H-3957	Bearing - Ball	311-9358
6N-3256	Mount As	314-8688
7C-0942	Adapter As	302-2636
7C-3039	Core, Oil Cooler	363-7451
7C-6398	Muffler As	360-7885
7N-2957	Cover - Rad Cap	361-1722
7S-7809	Cap As - Radiator	295-6417
7T-1310	Rim -Track Sprocket	290-0861
7T-2036	Cap As - Filter	361-1721
7W-1902	Adapter - Fuel Nozzle	299-1955
7W-2164	Core As - Oil Cooler	299-1996
8E-7857	Link As	290-0819
8H-2810	Case As - Filter	314-8512
8K-0665	Cage - Bearing	231-0262
8K-1107	Rack - Disconnect	231-0264
8K-2779	Cage - Bearing	231-0483
8K-2860	Flange - Coupling	297-7171
8K-3712	Pin As	241-2541
8K-4296	Pin	241-2555
8K-4753	Link As	290-0837
8K-4764	Pin	241-2556
8M-0874	Plunger As - Valve	311-9439
8N-2510	Shaft	325-6208
8N-2641	Sleeve	325-6210
8N-5305	Spacer	363-7464
8V-2639	Pin As	241-2542
9C-6544	Drum - Brake	297-7169
9K-0092	Pinion	231-0484
9K-8757	Rod End - Bearing	311-9361
9T-6526	Joint As - Univ	365-8824
9Y-2988	Breather As	361-1716

Sales Model 245B

Original Part Number	Part Name	Classic Part Number
100-3431	Stop	314-8723
129-3068	Rebuild Kit, W/P (Str Brgs)	363-7455
131-3815	Seal Gp - Basic	325-6193
177-9024	Adapter - Damper	299-1956
180-3767	Adapter - Damper	299-1957
190-8609	Valve - Fill	360-2288
1S-4701	Pulley - Alt	264-5866
1U-2738	Piston As	367-6074
1V-5744	Pin	241-2554
1W-1669	Piston	325-6158
1W-1698	Housing - Transfer Pump	296-1356
1W-4738	Bearing - Sleeve	325-6020
244-1090	Alarm - Back up	360-2345
2F-5721	Bearing - Ball	311-9354
2K-3592	Boss	314-8501
2N-7942	Spacer	363-7462
2P-1757	Hub - Fan Pulley	296-1357
3F-4971	Pin	295-5693
3L-1425	Bearing - Ball	311-9356
3P-0651	Seal - o-Ring	314-8541
4J-6374	Bearing - Sleeve	295-6407
4K-6810	Retainer - Seal	300-2586
4N-3714	Chamber, Precom	363-7450
4N-4539	Sleeve	314-8720
4N-6302	Belt Set - Vee	314-8495
4P-1463	Muffler As	360-7876
4P-9961	Line As - Fuel Injector	325-6115
5G-3612	Cap Gp	295-6419
5L-8856	Coupling - Exhaust	311-9379
5P-7807	Bearing - Ball	314-8502
5S-1211	Cover - Valve	314-8665
5S-9062	Spacer	363-7463
5S-9080	Pulley - Alt Drive	264-5883
6N-3256	Mount As	314-8688
7C-0942	Adapter As	302-2636
7C-3039	Core, Oil Cooler	363-7451
7C-6398	Muffler As	360-7885
7N-2957	Cover - Rad Cap	361-1722
7S-7809	Cap As - Radiator	295-6417
7W-1902	Adapter - Fuel Nozzle	299-1955
7W-2164	Core As - Oil Cooler	299-1996
7Y-0223	Shaft - Planet	301-4625
7Y-0225	Shaft - Planet	301-4571
7Y-1430	Gear - Sun	314-8671
7Y-1431	Gear - Planet	288-8729
7Y-1432	Carrier	314-8659
8H-2810	Case As - Filter	314-8512
8K-0665	Cage - Bearing	231-0262
8K-1107	Rack - Disconnect	231-0264
8K-2779	Cage - Bearing	231-0483
8K-3712	Pin As	241-2541
8K-4296	Pin	241-2555

(Continued)

Sales Model 245B (Continued)

Original Part Number	Part Name	Classic Part Number
8K-4764	Pin	241-2556
8M-0874	Plunger As - Valve	311-9439
8N-2510	Shaft	325-6208
8N-2641	Sleeve	325-6210
8N-5305	Spacer	363-7464
8V-2639	Pin As	241-2542
9C-6544	Drum - Brake	297-7169
9K-0092	Pinion	231-0484
9K-8757	Rod End - Bearing	311-9361
9T-6526	Joint As - Univ	365-8824
9Y-2988	Breather As	361-1716

Sales Model 245D

Original Part Number	Part Name	Classic Part Number
100-3431	Stop	314-8723
129-3068	Rebuild Kit, W/P (Str Brgs)	363-7455
131-3815	Seal Gp - Basic	325-6193
177-9024	Adapter - Damper	299-1956
180-3767	Adapter - Damper	299-1957
190-8609	Valve - Fill	360-2288
1S-4701	Pulley - Alt	264-5866
1U-2738	Piston As	367-6074
1V-5744	Pin	241-2554
1W-1669	Piston	325-6158
1W-1698	Housing - Transfer Pump	296-1356
1W-4738	Bearing - Sleeve	325-6020
244-1090	Alarm - Back up	360-2345
2F-5721	Bearing - Ball	311-9354
2N-7942	Spacer	363-7462
3F-4971	Pin	295-5693
4J-6374	Bearing - Sleeve	295-6407
4K-6810	Retainer - Seal	300-2586
4N-3714	Chamber, Precom	363-7450
4N-4539	Sleeve	314-8720
4P-1463	Muffler As	360-7876
4P-9961	Line As - Fuel Injector	325-6115
5G-3612	Cap Gp	295-6419
5L-8856	Coupling - Exhaust	311-9379
5P-7807	Bearing - Ball	314-8502
5S-1211	Cover - Valve	314-8665
5S-9080	Pulley - Alt Drive	264-5883
6N-3256	Mount As	314-8688
7C-0942	Adapter As	302-2636
7C-3039	Core, Oil Cooler	363-7451
7N-2957	Cover - Rad Cap	361-1722
7S-7809	Cap As - Radiator	295-6417
7W-1902	Adapter - Fuel Nozzle	299-1955
7W-2164	Core As - Oil Cooler	299-1996
8H-2810	Case As - Filter	314-8512
8K-0665	Cage - Bearing	231-0262
8K-1107	Rack - Disconnect	231-0264
8K-3712	Pin As	241-2541
8K-4296	Pin	241-2555
8K-4764	Pin	241-2556
8N-2510	Shaft	325-6208
8N-2641	Sleeve	325-6210
8V-2639	Pin As	241-2542
9C-6544	Drum - Brake	297-7169
9K-0092	Pinion	231-0484
9K-8757	Rod End - Bearing	311-9361
9Y-2988	Breather As	361-1716

Sales Model 320

Original Part Number	Part Name	Classic Part Number
086-0523	Pin	314-8696
087-5499	Bearing - Sleeve	314-8640
087-5533	Bearing - Sleeve	314-8628
087-5802	Link - Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
087-5847	Bearing - Sleeve	314-8629
094-1509	Shaft - Planet	360-2273
095-2927	Valve - Fill	360-2292
095-9291	Valve - Fill	360-2293
096-7911	Bearing - Sleeve	314-8653
096-7912	Bearing - Sleeve	314-8654
096-7913	Bearing - Sleeve	314-8655
099-0718	Bearing - Sleeve	360-2313
099-0721	Bearing - Sleeve	314-8641
102-8112	Cylinder - Adjustable	360-2276
108-0980	Pin As	314-8692
110-7058	Carrier - Planet	301-4630
110-7059	Carrier - Planet	301-4636
110-7209	Carrier As	301-5237
115-4204	Pulley As - Idler	301-5219
115-6427	Spring	301-4776
115-6429	Cylinder	301-4679

(Continued)

Sales Model 320 (Continued)

Original Part Number	Part Name	Classic Part Number
119-2863	Pin	314-8698
122-5076	Rod	301-4569
122-5077	Cylinder	301-4673
122-5178	Piston As	301-5252
125-2950	Gear As	301-4762
126-5061	Shoe -Track	335-5478
126-5062	Shoe -Track	286-9827
127-3365	Joint Gp - Slip	367-6067
127-5969	Gear - Sun	301-4761
127-5970	Gear - Planet	301-3398
128-9863	Bearing - Sleeve	314-8630
128-9882	Bearing - Sleeve	314-8642
128-9884	Bearing - Sleeve	360-2315
129-7768	Bearing - Sleeve	360-2316
130-9293	Rod	314-8708
137-2819	Bearing - Sleeve	360-2317
137-2820	Bearing - Sleeve	360-2318
137-2919	Bearing - Sleeve	360-2319
145-3030	Cylinder	360-2260
148-4634	Shaft - Planet	360-2274
163-4143	Roller Gp - SF	286-9823
190-8609	Valve - Fill	360-2288
194-1608	Link As	308-6230
194-1609	Link As	308-6229
223-3095	Gauge As	360-2295
227-0620	Gauge As	360-2295
227-6228	Cage	360-2343
227-6789	Bearing - Sleeve	360-2322
236-6271	Bearing - Sleeve	360-2324
240-2913	Bearing - Sleeve	360-2325
244-1090	Alarm - Back up	360-2345
248-7143	Idler Gp	286-9830
250-2402	Pin As	360-2351
253-4393	Muffler - Converter	301-7975
253-4426	Muffler - Converter	301-7974
2D-5658	Bearing - Ball	301-4628
2K-6413	Pin	360-2270
2N-7942	Spacer	363-7462
3P-1849	Ring - Sealing	360-2259
4E-0183	Pin	301-7976
4I-0453	Bearing - Sleeve	360-2331
4I-0704	Bearing Sleeve	360-2332
4I-3954	Tube As	301-4779
4I-3955	Tube As	301-4802
4I-3956	Tube As	301-4780
4I-3957	Tube As	301-4801
4I-8881	Tube As	301-4777
4N-3714	Chamber, Precom	363-7450
4W-2042	Spacer	325-6217
5C-5837	Retainer - Pin	299-2047
5I-7619	Pulley	301-4772
5I-7694	Impeller	301-4763
5I-7959	Pulley As	301-5256
5I-8628	Plate - Valve	301-4771
5S-9062	Spacer	363-7463
6A-7129	Bearing - Sleeve	301-3130
6C-6374	Tube As	301-4778
6E-3535	Bearing - Sleeve	360-2333
6I-9454	Shoe -Track	286-9826
7C-3039	Core, Oil Cooler	363-7451
7I-6843	Pin	301-4766
7K-9639	Bearing - Sleeve	314-8643
7Y-0212	Gear - Ring	301-4681
7Y-0213	Gear - Planet	301-4760
7Y-0221	Gear - Planet	301-4758
7Y-0223	Shaft - Planet	301-4625
7Y-0224	Gear - Planet	301-4759
7Y-0225	Shaft - Planet	301-4571
7Y-0228	Carrier As	301-5239
7Y-0238	Gear - Sun	301-4689
7Y-0241	Carrier	301-4635
7Y-0242	Carrier	301-4637
7Y-0249	Gear - Sun	301-4694
7Y-0680	Piston	360-2262
7Y-1258	Piston	367-6091
7Y-1427	Gear - Sun	288-8727
7Y-1428	Gear - Planet	288-8728
7Y-1430	Gear - Sun	314-8671
7Y-1431	Gear - Planet	288-8729
7Y-1432	Carrier	314-8659
7Y-1461	Coupling	301-4649
7Y-1513	Pipe As - Exhaust	301-5249
7Y-1517	Pipe As - Tail	301-5246
7Y-1643	Gear - Sun	314-8670
7Y-1644	Gear - Planet	301-3406
7Y-1646	Shaft - Planet	301-4624
7Y-1687	Piston As	360-2266
7Y-1751	Carrier - Planet	314-8660
7Y-1752	Carrier - Planet	314-8661
7Y-1775	Shaft - Pinion	314-8718
7Y-1780	Cylinder	360-2261
7Y-2348	Pin	314-8697
7Y-2349	Pin	301-4556
7Y-2357	Pin	301-4564
7Y-2391	Link As	301-5240
7Y-2392	Link - Rh	301-4765
7Y-2395	Bearing - Sleeve	314-8646
7Y-2396	Bearing - Sleeve	314-8634
7Y-3427	Bearing - Sleeve	314-8635
7Y-3428	Bearing - Sleeve	314-8647
7Y-3553	Bearing - Sleeve	301-0433
7Y-4666	Bearing - Sleeve	314-8636
7Y-5128	Bearing - Sleeve	314-8648
7Y-5131	Bearing - Sleeve	301-4626
7Y-6608	Bearing	314-8649
7Y-6626	Bearing	314-8650
7Y-6627	Pin As	314-8693
8E-5600	Roller Gp - Carrier	286-9824
8E-9805	Sprocket	286-9821
8H-2810	Case As - Filter	314-8512
8R-7336	Bearing	301-3394
8S-0248	Breather As	325-6033
9G-9349	Retainer	295-0411
9W-3361	Nut - Track	200-9127
9W-3619	Bolt - Track	286-9828
9W-9351	Shoe -Track	286-9825

Sales Model 320B

Original Part Number	Part Name	Classic Part Number
094-1509	Shaft - Planet	360-2273
095-2927	Valve - Fill	360-2292
095-9291	Valve - Fill	360-2293
099-0718	Bearing - Sleeve	360-2313
102-8112	Cylinder - Adjustable	360-2276
107-2139	Pin As	360-2352
118-9906	Muffler As	360-7865
128-9883	Bearing - Sleeve	360-2314
128-9884	Bearing - Sleeve	360-2315
129-7768	Bearing - Sleeve	360-2316
137-2819	Bearing - Sleeve	360-2317
137-2820	Bearing - Sleeve	360-2318

Original Part Number	Part Name	Classic Part Number
137-2919	Bearing - Sleeve	360-2319
137-3060	Bearing - Sleeve	360-2320
190-8609	Valve - Fill	360-2288
196-0028	Gear As - Idler	364-5259
223-3095	Gauge As	360-2295
227-0620	Gauge As	360-2295
227-6789	Bearing - Sleeve	360-2322
236-6271	Bearing - Sleeve	360-2324
240-2913	Bearing - Sleeve	360-2325
240-2915	Bearing - Sleeve	360-2326
244-1090	Alarm - Back up	360-2345

Original Part Number	Part Name	Classic Part Number
250-2402	Pin As	360-2351
2K-6413	Pin	360-2270
2N-7942	Spacer	363-7462
2V-0707	Bearing - Sleeve	360-2328
3P-1849	Ring - Sealing	360-2259
3W-8239	Sleeve - Wear	360-2342
4I-0453	Bearing - Sleeve	360-2331
4I-0704	Bearing Sleeve	360-2332
5S-9062	Spacer	363-7463
6E-3535	Bearing - Sleeve	360-2333
6Y-9930	Mount As	360-2353
7C-3039	Core, Oil Cooler	363-7451
7Y-0680	Piston	360-2262
8N-5305	Spacer	363-7464

Sales Model 320C

Part Number	Part Name	Classic Part Number
094-1509	Shaft - Planet	360-2273
095-2927	Valve - Fill	360-2292
099-0718	Bearing - Sleeve	360-2313
107-2139	Pin As	360-2352
128-9884	Bearing - Sleeve	360-2315
129-7768	Bearing - Sleeve	360-2316
137-2819	Bearing - Sleeve	360-2317
137-2820	Bearing - Sleeve	360-2318
137-3060	Bearing - Sleeve	360-2320
145-3030	Cylinder	360-2260
148-4634	Shaft - Planet	360-2274

Part Number	Part Name	Classic Part Number
223-3095	Gauge As	360-2295
227-0620	Gauge As	360-2295
227-6228	Cage	360-2343
227-6789	Bearing - Sleeve	360-2322
228-5621	Bearing - Sleeve	360-2323
236-6271	Bearing - Sleeve	360-2324
240-2913	Bearing - Sleeve	360-2325
240-2915	Bearing - Sleeve	360-2326
240-2916	Bearing - Sleeve	360-2327
244-1090	Alarm - Back up	360-2345
250-2402	Pin As	360-2351

Part Number	Part Name	Classic Part Number
2K-6413	Pin	360-2270
2V-0707	Bearing - Sleeve	360-2328
3P-1849	Ring - Sealing	360-2259
3W-8239	Sleeve - Wear	360-2342
4I-0453	Bearing - Sleeve	360-2331
4I-0704	Bearing Sleeve	360-2332
5S-9062	Spacer	363-7463
6E-3535	Bearing - Sleeve	360-2333
7J-1309	Bearing - Aligning	360-2275
7K-9592	Bearing - Sleeve	360-2336
7Y-3549	Pin	360-2349

Sales Model 320S

Original Part Number	Part Name	Classic Part Number
087-5499	Bearing - Sleeve	314-8640
087-5533	Bearing - Sleeve	314-8628
087-5802	Link - Rh	301-7964
087-5803	Link As	301-7966

Original Part Number	Part Name	Classic Part Number
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
087-5847	Bearing - Sleeve	314-8629

Original Part Number	Part Name	Classic Part Number
094-1509	Shaft - Planet	360-2273
095-2927	Valve - Fill	360-2292
095-9291	Valve - Fill	360-2293
102-8112	Cylinder - Adjustable	360-2276

(Continued)

Sales Model 320S (Continued)

Original Part Number	Part Name	Classic Part Number
110-7058	Carrier - Planet	301-4630
110-7059	Carrier - Planet	301-4636
110-7209	Carrier As	301-5237
115-4204	Pulley As - Idler	301-5219
119-2863	Pin	314-8698
129-7768	Bearing - Sleeve	360-2316
130-9293	Rod	314-8708
137-2819	Bearing - Sleeve	360-2317
137-2820	Bearing - Sleeve	360-2318
137-2919	Bearing - Sleeve	360-2319
190-8609	Valve - Fill	360-2288
223-3095	Gauge As	360-2295
227-0620	Gauge As	360-2295
227-6789	Bearing - Sleeve	360-2322
236-6271	Bearing - Sleeve	360-2324
250-2402	Pin As	360-2351
253-4393	Muffler - Converter	301-7975

Original Part Number	Part Name	Classic Part Number
2D-5658	Bearing - Ball	301-4628
3P-1849	Ring - Sealing	360-2259
4E-0183	Pin	301-7976
4I-0453	Bearing - Sleeve	360-2331
4I-0704	Bearing Sleeve	360-2332
4W-2042	Spacer	325-6217
5C-5837	Retainer - Pin	299-2047
5I-8628	Plate - Valve	301-4771
6C-6374	Tube As	301-4778
7Y-0212	Gear - Ring	301-4681
7Y-0213	Gear - Planet	301-4760
7Y-0221	Gear - Planet	301-4758
7Y-0223	Shaft - Planet	301-4625
7Y-0224	Gear - Planet	301-4759
7Y-0225	Shaft - Planet	301-4571
7Y-0228	Carrier As	301-5239
7Y-0238	Gear - Sun	301-4689
7Y-0241	Carrier	301-4635
7Y-0242	Carrier	301-4637
7Y-0249	Gear - Sun	301-4694
7Y-0680	Piston	360-2262
7Y-1427	Gear - Sun	288-8727
7Y-1428	Gear - Planet	288-8728
7Y-1430	Gear - Sun	314-8671

Original Part Number	Part Name	Classic Part Number
7Y-1431	Gear - Planet	288-8729
7Y-1432	Carrier	314-8659
7Y-1461	Coupling	301-4649
7Y-1513	Pipe As - Exhaust	301-5249
7Y-1517	Pipe As - Tail	301-5246
7Y-1775	Shaft - Pinion	314-8718
7Y-2348	Pin	314-8697
7Y-2349	Pin	301-4556
7Y-2357	Pin	301-4564
7Y-2391	Link As	301-5240
7Y-2392	Link - Rh	301-4765
7Y-2395	Bearing - Sleeve	314-8646
7Y-2396	Bearing - Sleeve	314-8634
7Y-3427	Bearing - Sleeve	314-8635
7Y-3428	Bearing - Sleeve	314-8647
7Y-4666	Bearing - Sleeve	314-8636
7Y-5128	Bearing - Sleeve	314-8648
7Y-5131	Bearing - Sleeve	301-4626
8H-2810	Case As - Filter	314-8512
8S-0248	Breather As	325-6033

Sales Model 330

Original Part Number	Part Name	Classic Part Number
086-0523	Pin	314-8696
087-5533	Bearing - Sleeve	314-8628
087-5802	Link - Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
087-5847	Bearing - Sleeve	314-8629
095-2927	Valve - Fill	360-2292
095-9291	Valve - Fill	360-2293
099-0721	Bearing - Sleeve	314-8641
100-7860	Valve - Inlet	270-4360 (Valve), 270-4362 (Valve Kit)

Original Part Number	Part Name	Classic Part Number
102-8112	Cylinder - Adjustable	360-2276
104-4253	Line As - Fuel Injector	279-4988
104-4254	Line As - Fuel Injector	279-4989
109-9463	Muffler As	360-7864
110-7058	Carrier - Planet	301-4630
110-7059	Carrier - Planet	301-4636
110-7209	Carrier As	301-5237
111-8015	Gasket As - Head	279-4977
115-4204	Pulley As - Idler	301-5219
122-9405	Bracket As	325-6005
128-9863	Bearing - Sleeve	314-8630

Original Part Number	Part Name	Classic Part Number
128-9882	Bearing - Sleeve	314-8642
130-9293	Rod	314-8708
131-3815	Seal Gp - Basic	325-6193
137-2819	Bearing - Sleeve	360-2317
148-7455	Valve - Exhaust	270-4361
167-8123	Damper As	299-2006
172-5185	Shaft - Water Pump	325-6201
172-5188	Shaft - Water Pump	325-6202
172-5189	Impeller - Pump	295-5687
172-5190	Impeller - Pump	325-6111

(Continued)

Sales Model 330 (Continued)

Original Part Number	Part Name	Classic Part Number
172-6712	Impeller - Pump	325-6112
172-7767	Pump Gp - Water	296-1365
177-9024	Adapter - Damper	299-1956
180-3767	Adapter - Damper	299-1957
190-8609	Valve - Fill	360-2288
196-0028	Gear As - Idler	364-5259
1N-3576	Block Gp - Cylinder	279-4978
1S-4701	Pulley - Alt	264-5866
1V-8241	Bearing - Sleeve	308-9808
1W-1669	Piston	325-6158
1W-1695	Pump Gp	279-4980
1W-1698	Housing - Transfer Pump	296-1356
1W-4402	Gear - Cam-shaft	279-4981
1W-4405	Gear - Crank-shaft	279-4982
1W-4738	Bearing - Sleeve	325-6020
1W-4740	Gear As - Drive	295-5689
1W-4746	Retainer - Gear	295-5690
1W-5912	Tappet As - Guide	325-6223
223-3095	Gauge As	360-2295
227-0620	Gauge As	360-2295
228-5621	Bearing - Sleeve	360-2323
244-1090	Alarm - Back up	360-2345
2D-5658	Bearing - Ball	301-4628
2F-5721	Bearing - Ball	311-9354
2K-6413	Pin	360-2270
2N-7942	Spacer	363-7462
2P-1170	Shaft As - Gear	296-1367
2P-1738	Plate As - Oil Pan	325-6164
2P-1739	Tube As - Pump	325-6229
2P-1757	Hub - Fan Pulley	296-1357
2P-1781	Spacer - Oil Pump	325-6214
2P-2519	Tube As - Inlet	325-6230
2P-6128	Pulley	264-5872
2P-6245	Shaft As - Pump	325-6197
2W-1086	Cover As - Cylinder Head	325-6049
2W-2621	Valve - Inlet	247-6892 (Valve), 241-3381 (Valve Kit)
2W-6757	Trunnion As	295-5678
2W-7255	Shaft - Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
3L-1425	Bearing - Ball	311-9356
3P-0651	Seal - o-Ring	314-8541
4I-4665	Bearing - Sleeve	364-5267
4I-4805	Pin	365-8828
4I-4806	Pin	364-5268
4I-5015	Pin	365-8829
4N-3714	Chamber, Precom	363-7450
4N-4782	Pulley	325-6176
4N-7693	Crankshaft As	242-3439
4P-3546	Valve As - Relief	325-6236
4P-9381	Line As - Fuel Injector	279-4984
4P-9382	Line As - Fuel Injector	279-4985
4P-9385	Line As - Fuel Injector	279-4986
4P-9386	Line As - Fuel Injector	279-4987
4P-9961	Line As - Fuel Injector	325-6115
4V-8520	Bearing - Sleeve	307-1527
4W-0452	Seal As - Camshaft	325-6191
4W-2042	Spacer	325-6217
4W-2446	Damper As	279-4990
5P-7807	Bearing - Ball	314-8502
5S-4557	Bearing	311-9360
5S-6795	Chamber As	242-3437
5S-9062	Spacer	363-7463
5S-9080	Pulley - Alt Drive	264-5883
6H-3957	Bearing - Ball	311-9358
6I-1346	Pump Gp - Oil	295-5674
6N-1036	Gear - Oil Pump	279-4991
6N-8413	Housing - Pump	325-6110
7C-0942	Adapter As	302-2636
7C-3039	Core, Oil Cooler	363-7451
7I-6843	Pin	301-4766
7J-6461	Crown	325-6054
7J-9884	Bearing - Sleeve	325-6016
7N-0110	Core As - Oil Cooler	319-3435
7N-2949	Pulley	264-5887
7N-5910	Impeller - Pump	314-8686
7N-9146	Gear - Fly-wheel Starter	279-4995
7N-9805	Pin - Piston	295-6438
7S-3161	Lifter - Valve	279-4996
7S-6723	Bracket - Alternator	299-1978
7S-8443	Muffler	247-2675
7W-0450	Gear - Water Pump	279-4997
7W-0507	Gear - Oil Pump Drive	279-4998
7W-0508	Gear - Fuel Pump Drive	296-1351
7W-1902	Adapter - Fuel Nozzle	299-1955
7W-2164	Core As - Oil Cooler	299-1996
7W-5687	Hub - Cam-shaft	314-8684
7Y-0212	Gear - Ring	301-4681
7Y-0213	Gear - Planet	301-4760
7Y-0221	Gear - Planet	301-4758
7Y-0223	Shaft - Planet	301-4625
7Y-0224	Gear - Planet	301-4759
7Y-0225	Shaft - Planet	301-4571
7Y-0228	Carrier As	301-5239
7Y-0238	Gear - Sun	301-4689
7Y-0241	Carrier	301-4635
7Y-0242	Carrier	301-4637
7Y-0249	Gear - Sun	301-4694
7Y-0680	Piston	360-2262
7Y-1258	Piston	367-6091
7Y-1427	Gear - Sun	288-8727
7Y-1428	Gear - Planet	288-8728
7Y-1430	Gear - Sun	314-8671

(Continued)

Sales Model 330 (Continued)

Original Part Number	Part Name	Classic Part Number
7Y-1431	Gear - Planet	288-8729
7Y-1432	Carrier	314-8659
7Y-1461	Coupling	301-4649
7Y-1513	Pipe As - Exhaust	301-5249
7Y-1517	Pipe As - Tail	301-5246
7Y-2348	Pin	314-8697
7Y-2349	Pin	301-4556
7Y-2357	Pin	301-4564
7Y-2391	Link As	301-5240
7Y-2392	Link - Rh	301-4765
7Y-2395	Bearing - Sleeve	314-8646
7Y-2396	Bearing - Sleeve	314-8634
7Y-3427	Bearing - Sleeve	314-8635
7Y-3428	Bearing - Sleeve	314-8647
7Y-3549	Pin	360-2349
7Y-3550	Pin	360-2350
7Y-3552	Bearing - Sleeve	364-5266
7Y-3553	Bearing - Sleeve	301-0433
7Y-4666	Bearing - Sleeve	314-8636
7Y-5128	Bearing - Sleeve	314-8648
7Y-5131	Bearing - Sleeve	301-4626
7Y-6608	Bearing	314-8649
7Y-6626	Bearing	314-8650
7Y-6627	Pin As	314-8693
8H-2810	Case As - Filter	314-8512
8N-0875	Valve - Exhaust	247-6893 (Valve), 241-3381 (Valve Kit)
8N-1187	Head Gp - Cylinder	242-3435
8N-1721	Rod As - Conn	269-5291
8N-2510	Shaft	325-6208
8N-2641	Sleeve	325-6210
8N-3251	Shaft As - Rocker Arm	314-8711
8N-3325	Arm Gp - Rocker	314-8623
8N-3327	Arm Gp - Rocker	314-8624
8N-5305	Spacer	363-7464
8N-5779	Coupling - Exhaust	325-6047
8N-5929	Cover - Water Pump	296-1349
8N-6796	Head Gp - Cylinder	269-5290
8N-7315	Tube As - Outlet	325-6232
8N-8225	Bearing - Main	314-8652
8N-9402	Coupling	325-6048
8S-0248	Breather As	325-6033
8S-0493	Shaft As - Pump	325-6198
8S-3970	Chamber As	242-3438
9J-7964	Bearing - Spherical	325-6017
9N-5769	Cover - Housing	325-6050
9S-6129	Pulley - Alternator Drive	264-5891
9S-8679	Chamber As	325-6042

Cat® Classic™ Parts for Motor Graders

Cat® motor graders have long, productive lives, and maintenance costs need to be evaluated as these machines age. Cat® Classic™ parts are a repair option targeted at the end of the product life cycle when lower cost options are more desired. Caterpillar offers the Classic parts line for several older models of motor graders. Cat Classic parts is a repair option that is priced to allow the machines to continue to be operated profitably as they age.

Cat Classic parts provide owners of older Cat products with low cost repair alternatives that minimize the risk associated with non-genuine parts.

Cat Classic parts coverage for motor graders includes:

- Axle
- Engine
- Final Drive
- Flywheel Clutch
- Linkage Pin
- Steering
- Transmission
- Trunnion/Blade Support
- ...and many more.

Sales Model 12

Original Part Number	Part Name	Classic Part Number
0T-0259	Nut - Bearing Sleeve	311-9431
121-7746	Precleaner As	360-2311
1A-2846	Cap As - Filler	311-9368
1D-3996	Fork - Knuckle	228-9428
1H-8037	Yoke - Fitting	228-9415
1M-7250	Bowl - Precleaner	360-2296
1S-1967	Chamber As	247-3291
1S-1970	Chamber As	247-3292
2D-1345	Drum - Brake	228-9430
2D-1659	Rack - Shift	228-9431
2D-3188	Yoke	365-8822
2D-3467	Hub - Final Drive Gear	228-9396
2D-3609	Shaft - Final Drive Pinion	228-8919
2D-4010	Adjuster - Bearing	228-8916
2D-4205	Block - Pivot	228-9432
2D-4209	Pin - Pivot	228-9434
2D-4211	Arm - Steering	228-9435
2D-4215	Knuckle - Rh	228-9436
2D-4216	Knuckle - Lh	228-9437
2D-5795	Sleeve - Thrust	243-0360
2D-5799	Pinion - Reverse	243-0342
2D-5961	Pin - Axle Pivot	228-9438
2D-6382	Gear - Worm	228-9558
2D-7933	Cover - Circle Rev	243-0340
2D-8212	Plate As - Press	229-1582
2F-5721	Bearing - Ball	311-9354
2F-5894	Drum - Brake	228-9439
2F-5969	Collar - Coupling	228-9440
2F-5970	Collar - Coupling	228-9441
2F-6046	Pinion - Reduction	228-9442
2F-6050	Gear - Reduction	229-1584
2F-6051	Gear	229-1585
2F-6053	Gear - Reduction	228-9443
2F-6057	Gear - Reduction	228-9444
2F-8001	Shaft - Worm	228-9445
2F-9047	Block - Pivot	228-9446
2F-9074	Link - Tie Bar	228-9447
2G-4187	Shell - Bearing	245-5794
2K-6413	Pin	360-2270
2S-1273	Chamber As	319-3434
2S-4015	Plunger As - Valve	311-9438
3B-5067	Shaft - Shift Worm	228-8907
3B-6217	Muffler As	247-2671
3B-6218	Muffler As	247-2672
3B-6695	Gear - Worm	228-9448
3B-9970	Worm	228-8908
3D-2136	Sprocket	228-9398
3D-2149	Pinion	228-9450
3D-2236	Sprocket As	228-9399
3D-4442	Shaft - Rev Worm	243-0354
3D-4443	Shaft - Rev Worm	243-0351
3D-4498	Shaft - Lower	243-0348
3D-4718	Bearing - Sleeve	245-5795
3D-5457	Cage - Bearing	228-9400
3D-9194	Gear	245-5796
3D-9502	Bolt - Draft	243-0332
3D-9932	Cage - Bearing	228-9401
3F-0017	Gear - Coupling	229-1587
3F-0018	Gear - Coupling	229-1588
3F-0019	Collar - Coupling	229-1589

(Continued)

Sales Model 12 (Continued)

Original Part Number	Part Name	Classic Part Number
3F-6334	End-tie Rod - Rh	228-9451
3F-6338	End-tie Rod - Lh	228-9452
3K-3124	Muffler - Trap	247-2673
4B-5806	Shaft - Upper	243-0347
4B-7064	Shaft - Worm	245-5803
4D-1626	Shaft - Lift Arm	245-5805
4D-2229	Cage - Bearing	229-1598
4D-2268	Cover - Shaft	228-9454
4D-3898	Gear - Bevel	228-8921
4D-5997	Pinion	245-5809
4D-6664	Coupling - Shaft	243-0338
4D-6665	Shaft - Circle Rev	243-0349
4D-6698	Bearing - Tandem Housing	228-9405
4D-6926	Segment - Control	228-9455
4D-7213	Coupling	228-9406
4D-7282	Shaft - Axle	228-9408
4F-4974	Clamp	311-9373
4H-2029	Gear - Reverse	229-1602
4H-7969	Bearing - Worm	245-5811
4N-7526	Seal As - Pump	311-9454
4N-9180	Seal As - Pump	311-9455
5B-0577	Collar	299-1992
5D-0034	Plate - Retainer	228-9456
5D-0395	Bracket - Rail Rh	243-0335
5D-0396	Bracket - Rail Lh	243-0334
5D-3283	Coupling - Shaft	243-0339
5D-3961	Block - Brake	245-5813
5D-6201	Shoe - Yoke	243-0356
5D-7339	Coupling	245-5816
5D-7462	Pin	247-4442
5D-9548	Hub - Final Drive Gear	228-9412
5D-9906	Shaft - Axle	228-9413
5H-0049	Hub - Flywheel	229-1608
5H-0051	Plate - Flywheel	229-1610
5H-0057	Ring - Bearing Thrust	229-1613
5S-1211	Cover - Valve	314-8665
6B-3158	Shoe - Yoke Lh	243-0357
6B-6911	Worm - Rh	245-5819
6B-6912	Worm - Lh	245-5820
6B-6941	Bearing - Worm	245-5812
6D-2362	Worm	243-0361
6D-6943	Housing - Axle	228-9416
6D-9164	Shaft - Pinion	243-0353
6D-9193	Hub - Final Drive Gear	228-9417
6F-5201	Gear - Worm	245-5797
6F-6992	Cap - Ballsocket	297-7160
6G-1633	Chain Gp	282-6565
6G-2947	Shaft	243-0346
6H-3957	Bearing - Ball	311-9358
7B-2420	Ferrule - Director	314-8517
7B-5036	Shaft - Bracket	297-7251
7D-2199	Sleeve As	228-9563
7D-2267	Link As	228-9564
7D-3815	Gear - Final Drive	228-9419
7D-5813	Gear - Worm	228-8911
7D-5847	Pinion	228-8912
7D-6516	Pinion - Reverse	243-0343
7D-6524	Shaft - Axle	228-8917
7D-6568	Cover As	228-9457
7D-6588	Worm	243-0362
7D-6841	Joint As - Univ	228-9566
7D-7075	Worm	243-0363
7D-7078	Shaft - Rev Worm	243-0355
7D-7427	Sprocket	228-9458
7D-7442	Hub - Final Drive Gear	228-8918
7F-6269	Gear - Worm	245-5798
7F-9263	Cap - Pivot	243-0336
7H-0602	Dog - Clutch	314-8515
7M-4603	Body - Fuel Valve	311-9348
7M-4926	Retainer - Pin	314-8538
7S-7809	Cap As - Radiator	295-6417
7T-2036	Cap As - Filter	361-1721
8B-5972	Bearing - Ball	314-8503
8D-0682	Shaft	245-5806
8D-0994	Rod As - Tie Rh	228-9459
8D-0995	Rod As - Tie Lh	228-9460
8D-1769	Plate - Driving	229-1622
8D-5344	Gear - Worm	243-0341
8D-5346	Shaft - Drive Pinion	243-0350
8F-7422	Gear - Worm	228-9461
9D-2716	Spindle - Wheel	228-9463
9D-2731	Spindle - Wheel	228-9423
9Y-9431	Precleaner As	361-1718

Sales Model 12E

Original Part Number	Part Name	Classic Part Number
100-7860	Valve - Inlet	270-4360 (Valve), 270-4362 (Valve Kit)
104-4253	Line As - Fuel Injector	279-4988
104-4254	Line As - Fuel Injector	279-4989
111-8015	Gasket As - Head	279-4977
121-7746	Precleaner As	360-2311
122-9405	Bracket As	325-6005
131-3815	Seal Gp - Basic	325-6193
148-7455	Valve - Exhaust	270-4361
172-5185	Shaft - Water Pump	325-6201
172-5188	Shaft - Water Pump	325-6202
172-5189	Impeller - Pump	295-5687
172-5190	Impeller - Pump	325-6111
172-6712	Impeller - Pump	325-6112
172-7767	Pump Gp - Water	296-1365
196-0028	Gear As - Idler	364-5259
1A-2846	Cap As - Filler	311-9368
1D-3996	Fork - Knuckle	228-9428
1H-8037	Yoke - Fitting	228-9415
1M-5270	Pipe - Extension	367-6065
1M-6128	Manifold - Exhaust	261-0906
1N-3576	Block Gp - Cylinder	279-4978
1N-3958	Elbow	325-6087
1P-4303	Head As - Cylinder	242-3434
1P-9945	Bracket As - Fan	296-1344
1P-9946	Shaft - Fan	325-6194
1P-9952	Impeller - Pump	314-8685
1S-1888	Bracket - Lamp	297-7147
1S-4701	Pulley - Alt	264-5866
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1695	Pump Gp	279-4980
1W-1698	Housing - Transfer Pump	296-1356
1W-4402	Gear - Camshaft	279-4981
1W-4405	Gear - Crankshaft	279-4982
1W-5912	Tappet As - Guide	325-6223
1W-6541	Plunger As	325-6173
2D-1345	Drum - Brake	228-9430
2D-1659	Rack - Shift	228-9431
2D-3188	Yoke	365-8822
2D-3467	Hub - Final Drive Gear	228-9396
2D-3609	Shaft - Final Drive Pinion	228-8919
2D-4010	Adjuster - Bearing	228-8916
2D-4205	Block - Pivot	228-9432
2D-4209	Pin - Pivot	228-9434
2D-4211	Arm - Steering	228-9435
2D-4215	Knuckle - Rh	228-9436
2D-4216	Knuckle - Lh	228-9437
2D-5795	Sleeve - Thrust	243-0360
2D-5799	Pinion - Reverse	243-0342
2D-5961	Pin - Axle Pivot	228-9438
2D-6381	Pinion	228-8915
2D-6382	Gear - Worm	228-9558
2D-7933	Cover - Circle Rev	243-0340
2D-8212	Plate As - Press	229-1582
2F-5721	Bearing - Ball	311-9354
2F-5894	Drum - Brake	228-9439
2F-5969	Collar - Coupling	228-9440
2F-5970	Collar - Coupling	228-9441
2F-6046	Pinion - Reduction	228-9442
2F-6050	Gear - Reduction	229-1584
2F-6051	Gear	229-1585
2F-6053	Gear - Reduction	228-9443
2F-6057	Gear - Reduction	228-9444
2F-8001	Shaft - Worm	228-9445
2F-9047	Block - Pivot	228-9446
2F-9074	Link - Tie Bar	228-9447
2G-4187	Shell - Bearing	245-5794
2K-4507	Bearing - Sleeve	325-6021
2K-6413	Pin	360-2270
2P-1170	Shaft As - Gear	296-1367
2P-1738	Plate As - Oil Pan	325-6164
2P-1757	Hub - Fan Pulley	296-1357
2P-1781	Spacer - Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2519	Tube As - Inlet	325-6230
2P-2719	Pipe	363-7454
2P-6128	Pulley	264-5872
2P-6245	Shaft As - Pump	325-6197
2P-7830	Pump Gp	314-8533
2S-4015	Plunger As - Valve	311-9438
2S-6739	Pulley - Tightener	298-2794
2W-1086	Cover As - Cylinder Head	325-6049
2W-2621	Valve - Inlet	247-6892 (Valve), 241-3381 (Valve Kit)
2W-7255	Shaft - Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
3B-5067	Shaft - Shift Worm	228-8907
3B-6218	Muffler As	247-2672
3B-6695	Gear - Worm	228-9448
3B-9970	Worm	228-8908
3D-0409	Arm - Pitman	228-9397
3D-2136	Sprocket	228-9398
3D-2149	Pinion	228-9450
3D-2236	Sprocket As	228-9399
3D-4442	Shaft - Rev Worm	243-0354
3D-4443	Shaft - Rev Worm	243-0351

(Continued)

Sales Model 12E (Continued)

Original Part Number	Part Name	Classic Part Number
3D-4498	Shaft - Lower	243-0348
3D-4718	Bearing - Sleeve	245-5795
3D-5457	Cage - Bearing	228-9400
3D-6672	Gear	229-1586
3D-9194	Gear	245-5796
3D-9502	Bolt - Draft	243-0332
3D-9786	Ballstud	228-9559
3D-9932	Cage - Bearing	228-9401
3F-0017	Gear - Coupling	229-1587
3F-0018	Gear - Coupling	229-1588
3F-0019	Collar - Coupling	229-1589
3F-6334	End-tie Rod - Rh	228-9451
3F-6338	End-tie Rod - Lh	228-9452
3H-3378	Gear As - Pump	298-2795
3K-3124	Muffler - Trap	247-2673
3L-1425	Bearing - Ball	311-9356
4B-5806	Shaft - Upper	243-0347
4B-7064	Shaft - Worm	245-5803
4D-1626	Shaft - Lift Arm	245-5805
4D-2184	Shaft - Low Pinion	229-1592
4D-2185	Shaft - Rev Idler	229-1593
4D-2198	Cage - Bearing	229-1594
4D-2218	Gear - Coupling	229-1595
4D-2219	Gear - Reverse	229-1597
4D-2220	Pinion - Transmission & Bevel	228-8920
4D-2227	Pinion	228-9453
4D-2229	Cage - Bearing	229-1598
4D-2268	Cover - Shaft	228-9454
4D-3898	Gear - Bevel	228-8921
4D-3966	Gear - Reduction	228-8924
4D-4863	Pinion	229-1599
4D-5997	Pinion	245-5809
4D-6664	Coupling - Shaft	243-0338
4D-6665	Shaft - Circle Rev	243-0349
4D-6698	Bearing - Tandem Housing	228-9405
4D-6926	Segment - Control	228-9455
4D-7213	Coupling	228-9406
4D-7282	Shaft - Axle	228-9408
4D-9934	Trunnion	229-1601
4F-4974	Clamp	311-9373
4H-2029	Gear - Reverse	229-1602
4H-7969	Bearing - Worm	245-5811
4K-3004	Bearing - Trunnion Support	314-8632
4K-3128	Bearing - Sleeve	314-8633
4N-2954	Sleeve - Camshaft	299-2059
4N-4864	Pump Gp - Fuel Transfer	242-3442
4N-7693	Crankshaft As	242-3439
4N-9587	Shield - Heat	297-7260
4P-0660	Muffler As	298-2787
4P-3546	Valve As - Relief	325-6236
4P-9381	Line As - Fuel Injector	279-4984
4P-9382	Line As - Fuel Injector	279-4985
4P-9385	Line As - Fuel Injector	279-4986
4P-9386	Line As - Fuel Injector	279-4987
5B-0577	Collar	299-1992
5D-0034	Plate - Retainer	228-9456
5D-0395	Bracket - Rail Rh	243-0335
5D-0396	Bracket - Rail Lh	243-0334
5D-0927	Shaft - Reduction	229-1605
5D-3283	Coupling - Shaft	243-0339
5D-3961	Block - Brake	245-5813
5D-4010	Rack	228-8909
5D-6201	Shoe - Yoke	243-0356
5D-7339	Coupling	245-5816
5D-7462	Pin	247-4442
5D-9548	Hub - Final Drive Gear	228-9412
5D-9906	Shaft - Axle	228-9413
5H-0049	Hub - Flywheel	229-1608
5H-0051	Plate - Flywheel	229-1610
5H-0057	Ring - Bearing Thrust	229-1613
5P-7807	Bearing - Ball	314-8502
5S-1211	Cover - Valve	314-8665
5S-1822	Chamber As	248-5406
5S-1833	Chamber As	247-3298
5S-6795	Chamber As	242-3437
5S-7609	Pulley - Alt Drive	264-5881
5S-9062	Spacer	363-7463
5S-9080	Pulley - Alt Drive	264-5883
6B-3158	Shoe - Yoke Lh	243-0357
6B-6911	Worm - Rh	245-5819
6B-6912	Worm - Lh	245-5820
6D-0687	Gear - Bevel	228-8922
6D-0708	Pinion	228-8923
6D-1599	Block - Link Pivot	228-9414
6D-1644	Shaft - Rod Pivot	228-9562
6D-2362	Worm	243-0361
6D-6943	Housing - Axle	228-9416
6D-9164	Shaft - Pinion	243-0353
6D-9193	Hub - Final Drive Gear	228-9417
6D-9294	Shaft	228-9418
6F-5201	Gear - Worm	245-5797
6F-6992	Cap - Ballsocket	297-7160
6G-1633	Chain Gp	282-6565
6G-2947	Shaft	243-0346
6H-3957	Bearing - Ball	311-9358
6N-1036	Gear - Oil Pump	279-4991
6N-2789	Pulley	264-5886
6N-8413	Housing - Pump	325-6110
7B-2420	Ferrule - Director	314-8517

(Continued)

Sales Model 12E (Continued)

Original Part Number	Part Name	Classic Part Number
7B-5036	Shaft - Bracket	297-7251
7C-4297	Seal As - Camshaft	325-6192
7D-2199	Sleeve As	228-9563
7D-2267	Link As	228-9564
7D-3815	Gear - Final Drive	228-9419
7D-4688	Shaft As - Steering	228-9565
7D-5446	Shaft As - Control Drive	229-1616
7D-5813	Gear - Worm	228-8911
7D-5847	Pinion	228-8912
7D-6516	Pinion - Reverse	243-0343
7D-6524	Shaft - Axle	228-8917
7D-6568	Cover As	228-9457
7D-6588	Worm	243-0362
7D-6841	Joint As - Univ	228-9566
7D-7075	Worm	243-0363
7D-7078	Shaft - Rev Worm	243-0355
7D-7289	Hub As Brake	229-1617
7D-7386	Shaft	228-9567
7D-7427	Sprocket	228-9458
7D-7442	Hub - Final Drive Gear	228-8918
7F-6269	Gear - Worm	245-5798
7F-9263	Cap - Pivot	243-0336
7M-2167	Ring - Governor Control	308-9919
7M-4204	Manifold - Exhaust	261-0901
7M-4603	Body - Fuel Valve	311-9348
7M-4926	Retainer - Pin	314-8538
7M-7358	Valve - Inlet	298-2774
7N-0128	Core As - Oil Cooler	299-1994
7N-0165	Core As - Oil Cooler	295-5670
7N-2871	Line As - Fuel Injector	319-8172
7N-2872	Line As - Fuel Injector	319-8173
7N-2874	Line As - Fuel Injector	298-2779
7N-2875	Line As - Fuel Injector	298-2780
7N-2876	Line As - Fuel Injector	298-2781
7N-2957	Cover - Rad Cap	361-1722
7N-3515	Gear - Camshaft	314-8669
7N-3536	Gear - Fuel	279-4993
7N-5910	Impeller - Pump	314-8686
7N-9146	Gear - Flywheel Starter	279-4995
7N-9312	Damper As - Camshaft	299-2005
7N-9805	Pin - Piston	295-6438
7S-3161	Lifter - Valve	279-4996
7S-6723	Bracket - Alternator	299-1978
7S-7809	Cap As - Radiator	295-6417
7S-9749	Pulley - Gen Drive	264-5888
7W-0450	Gear - Water Pump	279-4997
7W-0508	Gear - Fuel Pump Drive	296-1351
7W-5687	Hub - Camshaft	314-8684
8D-0527	Gear	229-1621
8D-0682	Shaft	245-5806
8D-0994	Rod As - Tie Rh	228-9459
8D-0995	Rod As - Tie Lh	228-9460
8D-1769	Plate - Driving	229-1622
8D-5344	Gear - Worm	243-0341
8D-5346	Shaft - Drive Pinion	243-0350
8F-7422	Gear - Worm	228-9461
8H-2810	Case As - Filter	314-8512
8H-9806	Gear - Shaft Drive	325-6091
8M-0874	Plunger As - Valve	311-9439
8M-3224	Muffler	247-2676
8N-0002	Trunnion As	314-8728
8N-0875	Valve - Exhaust	247-6893 (Valve), 241-3381 (Valve Kit)
8N-1187	Head Gp - Cylinder	242-3435
8N-1721	Rod As - Conn	269-5291
8N-1984	Rod As - Conn	242-3441
8N-2510	Shaft	325-6208
8N-2641	Sleeve	325-6210
8N-3180	Body As - Piston	250-6563
8N-3181	Piston Gp - Basic	250-6555 (Liner Kit)
8N-3183	Piston Gp - Basic	250-6556 (Liner Kit)
8N-3251	Shaft As - Rocker Arm	314-8711
8N-3325	Arm Gp - Rocker	314-8623
8N-3327	Arm Gp - Rocker	314-8624
8N-5305	Spacer	363-7464
8N-5929	Cover - Water Pump	296-1349
8N-6796	Head Gp - Cylinder	269-5290
8N-7315	Tube As - Outlet	325-6232
8N-8225	Bearing - Main	314-8652
8N-9733	Line As - Fuel Injector	319-8174
8S-0248	Breather As	325-6033
8S-0493	Shaft As - Pump	325-6198
8S-3970	Chamber As	242-3438
9D-2716	Spindle - Wheel	228-9463
9D-2731	Spindle - Wheel	228-9423
9H-2256	Pump Gp	311-9443
9M-4163	Valve - Exhaust	298-2773
9M-4789	Shaft - Gov Control	297-7256
9M-4955	Pump Gp - Fuel Transfer	242-3443
9N-5769	Cover - Housing	325-6050
9S-2355	Manifold - Exhaust	261-0891
9S-6129	Pulley - Alternator Drive	264-5891
9S-8679	Chamber As	325-6042

Sales Model 12F

Original Part Number	Part Name	Classic Part Number
111-8015	Gasket As - Head	279-4977
121-7746	Precleaner As	360-2311
130-6856	Precleaner As	361-1717
131-3815	Seal Gp - Basic	325-6193
153-3580	Shaft	299-2055
172-5185	Shaft - Water Pump	325-6201
172-5188	Shaft - Water Pump	325-6202
172-5189	Impeller - Pump	295-5687
172-5190	Impeller - Pump	325-6111
172-6712	Impeller - Pump	325-6112
172-7767	Pump Gp - Water	296-1365
196-0028	Gear As - Idler	364-5259
1A-2846	Cap As - Filler	311-9368
1H-8037	Yoke - Fitting	228-9415
1M-6128	Manifold - Exhaust	261-0906
1M-7250	Bowl - Precleaner	360-2296
1N-3576	Block Gp - Cylinder	279-4978
1N-3958	Elbow	325-6087
1P-4303	Head As - Cylinder	242-3434
1P-5480	Cover As - End	299-1998
1P-8554	Coupling - Exhaust	325-6052
1P-9945	Bracket As - Fan	296-1344
1P-9946	Shaft - Fan	325-6194
1P-9952	Impeller - Pump	314-8685
1P-9989	Pipe	363-7453
1S-1888	Bracket - Lamp	297-7147
1S-4701	Pulley - Alt	264-5866
1W-4402	Gear - Camshaft	279-4981
1W-4405	Gear - Crankshaft	279-4982
244-1090	Alarm - Back up	360-2345
2D-1345	Drum - Brake	228-9430
2D-3188	Yoke	365-8822
2D-3467	Hub - Final Drive Gear	228-9396
2D-3609	Shaft - Final Drive Pinion	228-8919
2D-4010	Adjuster - Bearing	228-8916
2D-8212	Plate As - Press	229-1582
2F-5721	Bearing - Ball	311-9354
2F-5894	Drum - Brake	228-9439
2F-5969	Collar - Coupling	228-9440
2F-5970	Collar - Coupling	228-9441
2F-6050	Gear - Reduction	229-1584
2F-6051	Gear	229-1585
2G-2858	Cap - Pivot	243-0345
2G-4187	Shell - Bearing	245-5794
2K-4507	Bearing - Sleeve	325-6021
2K-6413	Pin	360-2270
2P-1170	Shaft As - Gear	296-1367
2P-1738	Plate As - Oil Pan	325-6164
2P-1739	Tube As - Pump	325-6229
2P-1757	Hub - Fan Pulley	296-1357
2P-1781	Spacer - Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2519	Tube As - Inlet	325-6230
2P-2719	Pipe	363-7454
2P-6128	Pulley	264-5872
2P-6245	Shaft As - Pump	325-6197
2P-7830	Pump Gp	314-8533
2S-4015	Plunger As - Valve	311-9438
2W-1086	Cover As - Cylinder Head	325-6049
2W-2621	Valve - Inlet	247-6892 (Valve), 241-3381 (Valve Kit)
2W-7255	Shaft - Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear - Water Pump	325-6088
2W-9978	Core As - Oil Cooler	279-4983
3B-5067	Shaft - Shift Worm	228-8907
3B-6218	Muffler As	247-2672
3B-9970	Worm	228-8908
3D-0409	Arm - Pitman	228-9397
3D-2136	Sprocket	228-9398
3D-2236	Sprocket As	228-9399
3D-4718	Bearing - Sleeve	245-5795
3D-5457	Cage - Bearing	228-9400
3D-6672	Gear	229-1586
3D-9932	Cage - Bearing	228-9401
3F-0017	Gear - Coupling	229-1587
3F-0018	Gear - Coupling	229-1588
3F-0019	Collar - Coupling	229-1589
3H-3378	Gear As - Pump	298-2795
3K-3124	Muffler - Trap	247-2673
3L-1425	Bearing - Ball	311-9356
4B-1455	Cap As - Filter	361-1719
4B-5806	Shaft - Upper	243-0347
4D-0913	Arm - Steering	228-9402
4D-0926	Pin	247-4439
4D-0929	Rod End - Tie	228-9403
4D-0930	Rod End - Tie	228-9404
4D-2184	Shaft - Low Pinion	229-1592
4D-2185	Shaft - Rev Idler	229-1593
4D-2198	Cage - Bearing	229-1594
4D-2218	Gear - Coupling	229-1595
4D-2219	Gear - Reverse	229-1597
4D-2220	Pinion - Transmission & Bevel	228-8920
4D-2229	Cage - Bearing	229-1598
4D-2268	Cover - Shaft	228-9454

(Continued)

Sales Model 12F (Continued)

Original Part Number	Part Name	Classic Part Number
4D-3462	Pin - Pivot	247-4440
4D-3898	Gear - Bevel	228-8921
4D-3966	Gear - Reduction	228-8924
4D-4863	Pinion	229-1599
4D-6698	Bearing - Tandem Housing	228-9405
4D-7213	Coupling	228-9406
4D-7282	Shaft - Axle	228-9408
4D-9934	Trunnion	229-1601
4F-4974	Clamp	311-9373
4H-2029	Gear - Reverse	229-1602
4J-3015	Shaft	325-6204
4K-3004	Bearing - Trunnion Support	314-8632
4K-3128	Bearing - Sleeve	314-8633
4N-2954	Sleeve - Camshaft	299-2059
4N-3281	Line As - Fuel Injector	247-3362
4N-3282	Line As - Fuel Injector	247-3363
4N-3283	Line As - Fuel Injector	247-3364
4N-3284	Line As - Fuel Injector	247-3365
4N-4864	Pump Gp - Fuel Transfer	242-3442
4N-5503	Adapter - Exhaust	299-1954
4N-7693	Crankshaft As	242-3439
4N-8814	Line As - Fuel Injector	247-3366
4N-9587	Shield - Heat	297-7260
4P-0660	Muffler As	298-2787
4P-3546	Valve As - Relief	325-6236
4S-6707	Piston - Clutch	215-1686
4S-8708	Housing - Clutch	216-3557
4S-8718	Cage - Carrier Bearing	217-7724
4W-0452	Seal As - Camshaft	325-6191
5B-0577	Collar	299-1992
5D-0034	Plate - Retainer	228-9456
5D-0395	Bracket - Rail Rh	243-0335
5D-0396	Bracket - Rail Lh	243-0334
5D-0927	Shaft - Reduction	229-1605
5D-4010	Rack	228-8909
5D-5039	Ballstud	228-8910
5D-6375	Shaft - Final Drive Pinion	228-9409
5D-7461	Pin	247-4441
5D-9548	Hub - Final Drive Gear	228-9412
5D-9906	Shaft - Axle	228-9413
5D-9972	Shaft	229-1607
5H-0049	Hub - Flywheel	229-1608
5H-0051	Plate - Flywheel	229-1610
5H-0057	Ring - Bearing Thrust	229-1613
5M-6120	Gear - Sun	213-8740
5M-6210	Shaft - Planet	219-9683
5M-6211	Shaft - Planet	219-9684
5M-7841	Gear - Ring	214-0525
5M-7869	Gear - Ring	214-0530
5M-7875	Carrier - Front	213-4495
5M-7900	Bolt - Hex Head	311-9349
5P-7807	Bearing - Ball	314-8502
5S-1211	Cover - Valve	314-8665
5S-1822	Chamber As	248-5406
5S-1833	Chamber As	247-3298
5S-4557	Bearing	311-9360
5S-6795	Chamber As	242-3437
5S-7609	Pulley - Alt Drive	264-5881
5S-9062	Spacer	363-7463
5S-9080	Pulley - Alt Drive	264-5883
5T-8500	Shoe - Circle Drive	243-0359
5T-8501	Shoe - Circle Drive	243-0358
6D-0687	Gear - Bevel	228-8922
6D-0708	Pinion	228-8923
6D-1599	Block - Link Pivot	228-9414
6D-1644	Shaft - Rod Pivot	228-9562
6D-1777	Gear - Planet	245-5799
6D-1778	Gear - Planet	245-5800
6D-1779	Gear - Planet	245-5801
6D-2362	Worm	243-0361
6D-6114	Cap	245-5822
6D-6201	Ballstud	228-9103
6D-6943	Housing - Axle	228-9416
6D-8671	Bolt - Draft	243-0333
6D-9193	Hub - Final Drive Gear	228-9417
6D-9294	Shaft	228-9418
6F-6992	Cap - Ballsocket	297-7160
6G-1633	Chain Gp	282-6565
6G-1664	Adapter	297-7135
6G-1919	Cap - Pivot	243-0337
6G-2947	Shaft	243-0346
6G-4525	Strip - Wear	282-6624
6H-3957	Bearing - Ball	311-9358
6I-1346	Pump Gp - Oil	295-5674
6N-1036	Gear - Oil Pump	279-4991
6N-1965	Line As - Fuel Injector	250-7535
6N-1966	Line As - Fuel Injector	250-7536
6N-2789	Pulley	264-5886
6N-8413	Housing - Pump	325-6110
7B-2420	Ferrule - Director	314-8517
7B-5036	Shaft - Bracket	297-7251
7C-4297	Seal As - Camshaft	325-6192
7D-2199	Sleeve As	228-9563
7D-2267	Link As	228-9564
7D-2637	Gear - Worm	231-8761
7D-3815	Gear - Final Drive	228-9419
7D-4519	Shaft	245-5807
7D-4523	Coupling	245-5817
7D-4688	Shaft As - Steering	228-9565
7D-5446	Shaft As - Control Drive	229-1616
7D-5813	Gear - Worm	228-8911
7D-5847	Pinion	228-8912
7D-5859	Adapter	297-7136
7D-5861	Adapter	243-0364

(Continued)

Sales Model 12F (Continued)

Original Part Number	Part Name	Classic Part Number
7D-6436	Pinion - Reverse	243-0344
7D-6524	Shaft - Axle	228-8917
7D-6568	Cover As	228-9457
7D-6588	Worm	243-0362
7D-6841	Joint As - Univ	228-9566
7D-7289	Hub As Brake	229-1617
7D-7385	Shaft	228-9420
7D-7427	Sprocket	228-9458
7D-7442	Hub - Final Drive Gear	228-8918
7D-7854	Support - Rack	228-8913
7G-2475	Gear - Planet	223-4815
7G-2476	Gear - Planet	223-4816
7G-2513	Gear - Planet	215-1734
7M-2167	Ring - Governor Control	308-9919
7M-4204	Manifold - Exhaust	261-0901
7M-4603	Body - Fuel Valve	311-9348
7M-7358	Valve - Inlet	298-2774
7N-0128	Core As - Oil Cooler	299-1994
7N-0165	Core As - Oil Cooler	295-5670
7N-2871	Line As - Fuel Injector	319-8172
7N-2872	Line As - Fuel Injector	319-8173
7N-2874	Line As - Fuel Injector	298-2779
7N-2875	Line As - Fuel Injector	298-2780
7N-2876	Line As - Fuel Injector	298-2781
7N-2957	Cover - Rad Cap	361-1722
7N-3515	Gear - Camshaft	314-8669
7N-3536	Gear - Fuel	279-4993
7N-5910	Impeller - Pump	314-8686
7N-9145	Gear - Flywheel	279-4994
7N-9146	Gear - Flywheel Starter	279-4995
7N-9312	Damper As - Camshaft	299-2005
7N-9805	Pin - Piston	295-6438
7S-3161	Lifter - Valve	279-4996
7S-6723	Bracket - Alternator	299-1978
7S-6902	Gear - Sun	229-1619
7S-6964	Gear - Ring	214-0532
7S-7809	Cap As - Radiator	295-6417
7S-9749	Pulley - Gen Drive	264-5888
7W-0450	Gear - Water Pump	279-4997
7W-0507	Gear - Oil Pump Drive	279-4998
7W-5687	Hub - Camshaft	314-8684
7Y-1517	Pipe As - Tail	301-5246
8D-0527	Gear	229-1621
8D-0926	Rod As - Tie Lh	228-9422
8D-1769	Plate - Driving	229-1622
8D-5344	Gear - Worm	243-0341
8D-5347	Shaft - Drive Pinion	243-0352
8H-9806	Gear - Shaft Drive	325-6091
8M-0874	Plunger As - Valve	311-9439
8M-3224	Muffler	247-2676
8M-8623	Gear - Sun	213-8755
8M-8642	Housing - Clutch	219-9669
8M-8644	Housing - Clutch	215-1782
8M-8646	Plate As - Center	216-3583
8M-8650	Piston - Clutch	217-9778
8M-8677	Carrier - Planet	213-4449
8N-0002	Trunnion As	314-8728
8N-0875	Valve - Exhaust	247-6893 (Valve), 241-3381 (Valve Kit)
8N-1187	Head Gp - Cylinder	242-3435
8N-1721	Rod As - Conn	269-5291
8N-1984	Rod As - Conn	242-3441
8N-3180	Body As - Piston	250-6563
8N-3181	Piston Gp - Basic	250-6555 (Liner Kit)
8N-3182	Body As - Piston	250-6564 (Piston As), 250-6556 (Liner Kits)
8N-3183	Piston Gp - Basic	250-6556 (Liner Kit)
8N-3325	Arm Gp - Rocker	314-8623
8N-3327	Arm Gp - Rocker	314-8624
8N-5305	Spacer	363-7464
8N-5929	Cover - Water Pump	296-1349
8N-7315	Tube As - Outlet	325-6232
8N-8225	Bearing - Main	314-8652
8N-9733	Line As - Fuel Injector	319-8174
8S-0248	Breather As	325-6033
8S-0493	Shaft As - Pump	325-6198
8S-0905	Muffler As	302-2690
8S-3970	Chamber As	242-3438
9D-2716	Spindle - Wheel	228-9463
9D-2731	Spindle - Wheel	228-9423
9D-6638	Strip - Wear	297-7263
9H-2256	Pump Gp	311-9443
9M-1500	Shaft - Planet	219-9685
9M-1995	Gear - Sun	213-8756
9M-1996	Shaft - Planet	215-1875
9M-2049	Gear - Ring	214-0533
9M-4163	Valve - Exhaust	298-2773
9M-4789	Shaft - Gov Control	297-7256
9M-4955	Pump Gp - Fuel Transfer	242-3443
9N-5251	Piston Gp - Basic	250-6557 (Liner Kit)
9N-5769	Cover - Housing	325-6050
9S-2354	Manifold - Exhaust	261-0888
9S-2355	Manifold - Exhaust	261-0891
9S-6129	Pulley - Alternator Drive	264-5891
9S-8679	Chamber As	325-6042

Sales Model 12G

Original Part Number	Part Name	Classic Part Number
100-7860	Valve - Inlet	270-4360 (Valve), 270-4362 (Valve Kit)
104-4253	Line As - Fuel Injector	279-4988
104-4254	Line As - Fuel Injector	279-4989
105-3196	Motor Gp - Gerotor	282-6547
106-7131	Shaft	288-8714
109-5562	Shaft	275-5272
110-4652	Housing	302-2683
111-8015	Gasket As - Head	279-4977
112-3249	Muffler As	247-2661
112-5495	Joint Gp - Univ	297-4858
122-9405	Bracket As	325-6005
124-3240	Pin	282-6548
126-7130	Shaft As	275-5300
129-2381	Gear - Planet	275-5274
131-3736	Socket Gp - Basic	325-6211
131-3737	Socket As	282-6626
131-3738	Socket As	282-6627
131-3815	Seal Gp - Basic	325-6193
147-3400	Spindle	282-6549
148-7455	Valve - Exhaust	270-4361
153-3580	Shaft	299-2055
170-0560	Rebuild Kit	363-7458
172-5185	Shaft - Water Pump	325-6201
172-5188	Shaft - Water Pump	325-6202
172-5189	Impeller - Pump	295-5687
172-5190	Impeller - Pump	325-6111
172-6712	Impeller - Pump	325-6112
172-7767	Pump Gp - Water	296-1365
196-0028	Gear As - Idler	364-5259
1N-3576	Block Gp - Cylinder	279-4978
1N-3958	Elbow	325-6087
1N-4304	Head Gp - Cylinder	269-8761
1P-1216	Manifold - Exhaust	261-0902
1P-1721	Gear - Balance	298-2769
1P-1722	Gear - Balance	298-2770
1P-5480	Cover As - End	299-1998
1P-9945	Bracket As - Fan	296-1344
1P-9946	Shaft - Fan	325-6194
1P-9952	Impeller - Pump	314-8685
1P-9989	Pipe	363-7453
1S-1888	Bracket - Lamp	297-7147
1S-4701	Pulley - Alt	264-5866
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1695	Pump Gp	279-4980
1W-1698	Housing - Transfer Pump	296-1356
1W-4402	Gear - Camshaft	279-4981
1W-4405	Gear - Crankshaft	279-4982
1W-5912	Tappet As - Guide	325-6223
1W-6541	Plunger As	325-6173
236-7724	Retainer	299-2048
244-1090	Alarm - Back up	360-2345
2F-5721	Bearing - Ball	311-9354
2G-2858	Cap - Pivot	243-0345
2G-8238	Yoke As	282-6631
2G-8609	Pin	319-3450
2G-8613	Pin	282-6553
2G-8617	Pin	282-6555
2G-8621	Pin	282-6557
2G-8625	Pin	282-6558
2G-8629	Pin	282-6560
2G-8633	Pin	282-6561
2G-9098	Cap	300-2573
2K-6413	Pin	360-2270
2P-1170	Shaft As - Gear	296-1367
2P-1738	Plate As - Oil Pan	325-6164
2P-1739	Tube As - Pump	325-6229
2P-1757	Hub - Fan Pulley	296-1357
2P-1781	Spacer - Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2519	Tube As - Inlet	325-6230
2P-2719	Pipe	363-7454
2P-4435	Plate	275-5295
2P-4510	Piston - Clutch	275-5293
2P-4611	Pipe - Exhaust	365-8821
2P-5608	Pipe - Extension	367-6066
2P-5609	Muffler As	247-2665
2P-6128	Pulley	264-5872
2P-6245	Shaft As - Pump	325-6197
2P-7828	Pan - Oil	314-8691
2P-7830	Pump Gp	314-8533
2P-9632	Damper As	299-2004
2W-1086	Cover As - Cylinder Head	325-6049
2W-2621	Valve - Inlet	247-6892 (Valve), 241-3381 (Valve Kit)
2W-7255	Shaft - Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear - Water Pump	325-6088
2W-9094	Adapter - Exhaust	299-2534
2W-9978	Core As - Oil Cooler	279-4983
312-0782	Worm - Circle Drive	282-6623
3B-6218	Muffler As	247-2672
3J-6575	Trunnion	297-7265
3K-3124	Muffler - Trap	247-2673
3L-1425	Bearing - Ball	311-9356
3P-0114	Elbow - Exhaust	314-8516
3P-0165	Pulley - Fan Drive	298-2775
3P-0297	Shaft As	275-5297
3P-0307	Cage As - Bearing	300-2572
3P-0324	Coupling	301-0234
3P-0335	Platepress	297-7228

(Continued)

Sales Model 12G (Continued)

Original Part Number	Part Name	Classic Part Number
3P-0726	Shaft As	275-5298
3P-0785	Hub As - Clutch	302-2688
3P-3713	Gear As	275-5288
3P-5349	Piston As	275-5292
3P-5359	Piston - Clutch	299-2037
3P-5737	Shaft As - Clutch	275-5273
4B-1455	Cap As - Filter	361-1719
4F-4974	Clamp	311-9373
4K-3004	Bearing - Trunnion Support	314-8632
4N-2954	Sleeve - Camshaft	299-2059
4N-3281	Line As - Fuel Injector	247-3362
4N-3282	Line As - Fuel Injector	247-3363
4N-3283	Line As - Fuel Injector	247-3364
4N-3284	Line As - Fuel Injector	247-3365
4N-4864	Pump Gp - Fuel Transfer	242-3442
4N-5503	Adapter - Exhaust	299-1954
4N-7692	Crankshaft As	242-3440
4N-7693	Crankshaft As	242-3439
4N-7977	Shaft As - Balance	314-8709
4N-7978	Shaft As - Balance	314-8710
4N-8591	Coupling - Exhaust	325-6053
4N-8814	Line As - Fuel Injector	247-3366
4N-8942	Muffler As	298-2786
4N-9587	Shield - Heat	297-7260
4P-3546	Valve As - Relief	325-6236
4P-9381	Line As - Fuel Injector	279-4984
4P-9382	Line As - Fuel Injector	279-4985
4P-9385	Line As - Fuel Injector	279-4986
4P-9386	Line As - Fuel Injector	279-4987
4S-8472	Hood As	296-1355
4T-0998	Lever	314-8687
4V-0015	Plate - Lock	282-6563
4W-0452	Seal As - Camshaft	325-6191
5B-0577	Collar	299-1992
5D-0470	Valve Gp	314-8549
5K-0871	Pin - Lower	282-6630
5K-0989	Cap - Upper	297-7158
5K-0990	Pin	299-2035
5K-0991	Cap - Lower	319-3433
5P-7807	Bearing - Ball	314-8502
5S-6795	Chamber As	242-3437
5S-7944	Shaft - Planet	297-7246
5S-7945	Shaft As - Planet	275-5299
5S-9062	Spacer	363-7463
5S-9080	Pulley - Alt Drive	264-5883
5T-0906	Cover	282-6625
5T-1362	Bearing - Spider	325-6011
5T-3475	Shaft	297-7247
5T-6298	Lever	299-2018
5T-8500	Shoe - Circle Drive	243-0359
5T-8501	Shoe - Circle Drive	243-0358
6F-6992	Cap - Ball-socket	297-7160
6G-1633	Chain Gp	282-6565
6G-1664	Adapter	297-7135
6G-1908	Housing As - Drive	297-7198
6G-1919	Cap - Pivot	243-0337
6G-2947	Shaft	243-0346
6G-4525	Strip - Wear	282-6624
6G-8425	Valve Gp - Control	367-6086
6H-3957	Bearing - Ball	311-9358
6I-1346	Pump Gp - Oil	295-5674
6N-1036	Gear - Oil Pump	279-4991
6N-1553	Coupling - Exhaust	295-6422
6N-1878	Muffler As	360-7883
6N-1965	Line As - Fuel Injector	250-7535
6N-1966	Line As - Fuel Injector	250-7536
6N-2789	Pulley	264-5886
6N-8413	Housing - Pump	325-6110
6Y-0305	Cage As - Bearing	297-7150
7B-5036	Shaft - Bracket	297-7251
7C-4297	Seal As - Camshaft	325-6192
7D-5861	Adapter	243-0364
7D-6568	Cover As	228-9457
7D-7889	Gear - Ring	275-5276
7G-3450	Gear - Planet	275-5289
7G-3451	Gear - Planet	297-7188
7G-3452	Gear - Planet	275-5290
7G-3461	Gear - Planet	275-5291
7J-6461	Crown	325-6054
7J-9884	Bearing - Sleeve	325-6016
7K-9348	Pin	252-6872
7M-2167	Ring - Governor Control	308-9919
7N-0128	Core As - Oil Cooler	299-1994
7N-0165	Core As - Oil Cooler	295-5670
7N-2871	Line As - Fuel Injector	319-8172
7N-2872	Line As - Fuel Injector	319-8173
7N-2874	Line As - Fuel Injector	298-2779
7N-2875	Line As - Fuel Injector	298-2780
7N-2876	Line As - Fuel Injector	298-2781
7N-3486	Manifold - Exhaust	261-0899
7N-3515	Gear - Camshaft	314-8669
7N-3536	Gear - Fuel	279-4993
7N-5910	Impeller - Pump	314-8686
7N-9145	Gear - Flywheel	279-4994
7N-9146	Gear - Flywheel Starter	279-4995
7N-9312	Damper As - Camshaft	299-2005
7N-9805	Pin - Piston	295-6438
7S-3161	Lifter - Valve	279-4996
7S-6723	Bracket - Alternator	299-1978
7S-8631	Shaft As	275-5296
7T-2036	Cap As - Filter	361-1721

(Continued)

Sales Model 12G (Continued)

Original Part Number	Part Name	Classic Part Number
7T-9647	Piston - Clutch	275-5294
7W-0450	Gear - Water Pump	279-4997
7W-0507	Gear - Oil Pump Drive	279-4998
7W-0508	Gear - Fuel Pump Drive	296-1351
7W-5687	Hub - Camshaft	314-8684
7Y-1517	Pipe As - Tail	301-5246
8D-1784	Pin	282-6567
8D-2429	Pin As	319-3445
8D-2469	Shaft - Drive	275-5280
8D-3591	Carrier - Planet	301-4769
8D-3744	Shaft - Drive	275-5283
8D-3877	Gear - Sun	275-5278
8D-4766	Pin - Cylinder	365-8832
8D-5344	Gear - Worm	243-0341
8D-7096	Pin - Axle Leaning	297-7219
8D-7174	Cover As	299-1997
8D-7427	Shaft - Drive Pinion	282-6568
8D-9804	Housing - Drive	302-2682
8H-2810	Case As - Filter	314-8512
8H-9806	Gear - Shaft Drive	325-6091
8J-2022	Piston As - Pump	367-6073
8M-0874	Plunger As - Valve	311-9439
8N-0002	Trunnion As	314-8728
8N-0875	Valve - Exhaust	247-6893 (Valve), 241-3381 (Valve Kit)
8N-1187	Head Gp - Cylinder	242-3435
8N-1188	Head Gp - Cylinder	242-3436
8N-1721	Rod As - Conn	269-5291
8N-1984	Rod As - Conn	242-3441
8N-2510	Shaft	325-6208
8N-2641	Sleeve	325-6210
8N-3180	Body As - Piston	250-6563
8N-3181	Piston Gp - Basic	250-6555 (Liner Kit)
8N-3182	Body As - Piston	250-6564 (Piston As), 250-6556 (Liner Kits)
8N-3183	Piston Gp - Basic	250-6556 (Liner Kit)
8N-3251	Shaft As - Rocker Arm	314-8711
8N-3311	Shaft As - Rocker Arm	325-6199
8N-3312	Shaft As - Rocker Arm	325-6200
8N-3325	Arm Gp - Rocker	314-8623
8N-3327	Arm Gp - Rocker	314-8624
8N-5305	Spacer	363-7464
8N-5929	Cover - Water Pump	296-1349
8N-6796	Head Gp - Cylinder	269-5290
8N-7315	Tube As - Outlet	325-6232
8N-7780	Shield - Oil	314-8544
8N-8225	Bearing - Main	314-8652
8N-9733	Line As - Fuel Injector	319-8174
8P-1656	Plate - Clutch	367-6071
8S-0248	Breather As	325-6033
8S-0493	Shaft As - Pump	325-6198
8S-3970	Chamber As	242-3438
8S-7716	Manifold - Exhaust	295-0415
8S-7718	Manifold - Exhaust	295-0416
8W-1751	Bracket As	288-8732
8W-1752	Bracket - Rail	288-8733
8W-1753	Bracket - Rail	288-8734
8W-2308	Shaft - Planet	275-5285
8W-4066	Bracket - Rail	288-8735
8W-4067	Bracket - Rail	288-8736
8W-5092	Pinion - Circle Drive	282-6569
8W-5293	Pin	282-6570
8W-6497	Pin	319-3465
8W-8317	Sprocket	275-5287
9D-4441	Housing	297-7195
9D-6638	Strip - Wear	297-7263
9D-7924	Mounting	360-2356
9D-9665	Bracket - Cylinder Mtg	299-1980
9H-2256	Pump Gp	311-9443
9M-4789	Shaft - Gov Control	297-7256
9N-5769	Cover - Housing	325-6050
9P-4859	Cage As - Bearing	297-7151
9P-8452	Hub - Output	297-7206
9P-8455	Cage As - Bearing	297-7152
9P-9742	Cage As - Bearing	297-7153
9S-2355	Manifold - Exhaust	261-0891
9S-6129	Pulley - Alternator Drive	264-5891
9S-8679	Chamber As	325-6042
9Y-2992	Bearing - Sleeve	325-6032

Sales Model 14B

Original Part Number	Part Name	Classic Part Number
0T-0259	Nut - Bearing Sleeve	311-9431
1A-2846	Cap As - Filler	311-9368
1D-3996	Fork - Knuckle	228-9428
1H-8037	Yoke - Fitting	228-9415
1S-1967	Chamber As	247-3291
1S-1970	Chamber As	247-3292
2D-1345	Drum - Brake	228-9430
2D-1659	Rack - Shift	228-9431
2D-3188	Yoke	365-8822
2D-3467	Hub - Final Drive Gear	228-9396
2D-3609	Shaft - Final Drive Pinion	228-8919

(Continued)

Sales Model 14B (Continued)

Original Part Number	Part Name	Classic Part Number
2D-4010	Adjuster - Bearing	228-8916
2D-4205	Block - Pivot	228-9432
2D-4209	Pin - Pivot	228-9434
2D-4211	Arm - Steering	228-9435
2D-4215	Knuckle - Rh	228-9436
2D-4216	Knuckle - Lh	228-9437
2D-5795	Sleeve - Thrust	243-0360
2D-5799	Pinion - Reverse	243-0342
2D-5961	Pin - Axle Pivot	228-9438
2D-6381	Pinion	228-8915
2D-6382	Gear - Worm	228-9558
2D-7933	Cover - Circle Rev	243-0340
2D-8212	Plate As - Press	229-1582
2F-5721	Bearing - Ball	311-9354
2F-5894	Drum - Brake	228-9439
2F-5969	Collar - Coupling	228-9440
2F-5970	Collar - Coupling	228-9441
2F-6050	Gear - Reduction	229-1584
2F-6051	Gear	229-1585
2F-8001	Shaft - Worm	228-9445
2F-9047	Block - Pivot	228-9446
2F-9074	Link - Tie Bar	228-9447
2G-4187	Shell - Bearing	245-5794
2S-1273	Chamber As	319-3434
2S-4015	Plunger As - Valve	311-9438
3B-5067	Shaft - Shift Worm	228-8907
3B-6695	Gear - Worm	228-9448
3B-9970	Worm	228-8908
3D-2149	Pinion	228-9450
3D-4443	Shaft - Rev Worm	243-0351
3D-4498	Shaft - Lower	243-0348
3D-4718	Bearing - Sleeve	245-5795
3D-5457	Cage - Bearing	228-9400
3D-9194	Gear	245-5796
3D-9502	Bolt - Draft	243-0332
3D-9786	Ballstud	228-9559
3D-9932	Cage - Bearing	228-9401
3F-0017	Gear - Coupling	229-1587
3F-0018	Gear - Coupling	229-1588
3F-0019	Collar - Coupling	229-1589
3F-6334	End-tie Rod - Rh	228-9451
3F-6338	End-tie Rod - Lh	228-9452
4B-5806	Shaft - Upper	243-0347
4B-7064	Shaft - Worm	245-5803
4D-1626	Shaft - Lift Arm	245-5805
4D-2229	Cage - Bearing	229-1598
4D-2268	Cover - Shaft	228-9454
4D-3898	Gear - Bevel	228-8921
4D-5997	Pinion	245-5809
4D-6664	Coupling - Shaft	243-0338
4D-6665	Shaft - Circle Rev	243-0349
4D-6926	Segment - Control	228-9455
4D-7282	Shaft - Axle	228-9408
4H-2029	Gear - Reverse	229-1602
4H-7969	Bearing - Worm	245-5811
4N-7526	Seal As - Pump	311-9454
4N-9180	Seal As - Pump	311-9455
5B-0577	Collar	299-1992
5D-0034	Plate - Retainer	228-9456
5D-3283	Coupling - Shaft	243-0339
5D-3961	Block - Brake	245-5813
5D-4010	Rack	228-8909
5D-6201	Shoe - Yoke	243-0356
5D-7339	Coupling	245-5816
5D-7462	Pin	247-4442
5D-9548	Hub - Final Drive Gear	228-9412
5D-9906	Shaft - Axle	228-9413
5H-0049	Hub - Flywheel	229-1608
5H-0051	Plate - Flywheel	229-1610
5H-0057	Ring - Bearing Thrust	229-1613
5S-1211	Cover - Valve	314-8665
6B-3158	Shoe - Yoke Lh	243-0357
6B-6911	Worm - Rh	245-5819
6B-6912	Worm - Lh	245-5820
6D-2362	Worm	243-0361
6D-6943	Housing - Axle	228-9416
6D-9193	Hub - Final Drive Gear	228-9417
6F-5201	Gear - Worm	245-5797
6F-6992	Cap - Ballsocket	297-7160
6G-2947	Shaft	243-0346
6H-3957	Bearing - Ball	311-9358
7B-2420	Ferrule - Director	314-8517
7B-5036	Shaft - Bracket	297-7251
7D-2199	Sleeve As	228-9563
7D-2267	Link As	228-9564
7D-3815	Gear - Final Drive	228-9419
7D-5813	Gear - Worm	228-8911
7D-5847	Pinion	228-8912
7D-6516	Pinion - Reverse	243-0343
7D-6568	Cover As	228-9457
7D-6841	Joint As - Univ	228-9566
7F-6269	Gear - Worm	245-5798
7F-9263	Cap - Pivot	243-0336
7H-0602	Dog - Clutch	314-8515
7M-4603	Body - Fuel Valve	311-9348
7M-4926	Retainer - Pin	314-8538
7S-7809	Cap As - Radiator	295-6417
8D-0682	Shaft	245-5806
8D-0994	Rod As - Tie Rh	228-9459
8D-0995	Rod As - Tie Lh	228-9460
8D-1769	Plate - Driving	229-1622
8D-5344	Gear - Worm	243-0341
8D-5346	Shaft - Drive Pinion	243-0350

(Continued)

Sales Model 14B (Continued)

Original Part Number	Part Name	Classic Part Number
8F-7422	Gear - Worm	228-9461
9D-2731	Spindle - Wheel	228-9423

Sales Model 14C

Original Part Number	Part Name	Classic Part Number
2D-1345	Drum - Brake	228-9430
2D-3188	Yoke	365-8822
2K-4507	Bearing - Sleeve	325-6021
2K-6413	Pin	360-2270
4K-3004	Bearing - Trunnion Support	314-8632
4K-3128	Bearing - Sleeve	314-8633
5B-0577	Collar	299-1992
5D-3283	Coupling - Shaft	243-0339
5S-1211	Cover - Valve	314-8665
5S-1822	Chamber As	248-5406
5S-1833	Chamber As	247-3298
6F-6992	Cap - Ball-socket	297-7160
7D-6841	Joint As - Univ	228-9566
7M-7358	Valve - Inlet	298-2774
7N-0128	Core As - Oil Cooler	299-1994
7S-9749	Pulley - Gen Drive	264-5888
8M-3224	Muffler	247-2676
8N-8225	Bearing - Main	314-8652
9H-2256	Pump Gp	311-9443
9M-4163	Valve - Exhaust	298-2773

Sales Model 14D

Original Part Number	Part Name	Classic Part Number
1A-2846	Cap As - Filler	311-9368
1H-8037	Yoke - Fitting	228-9415
1M-5270	Pipe - Extension	367-6065
1M-6128	Manifold - Exhaust	261-0906
1S-4701	Pulley - Alt	264-5866
1W-4405	Gear - Crankshaft	279-4982
2D-1345	Drum - Brake	228-9430
2D-1659	Rack - Shift	228-9431
2D-3188	Yoke	365-8822
2D-3467	Hub - Final Drive Gear	228-9396
2D-3609	Shaft - Final Drive Pinion	228-8919
2D-4010	Adjuster - Bearing	228-8916
2D-5795	Sleeve - Thrust	243-0360
2D-5961	Pin - Axle Pivot	228-9438
2D-6381	Pinion	228-8915
2D-6382	Gear - Worm	228-9558
2D-7933	Cover - Circle Rev	243-0340
2D-8212	Plate As - Press	229-1582
2F-5721	Bearing - Ball	311-9354
2F-5894	Drum - Brake	228-9439
2F-5969	Collar - Coupling	228-9440
2F-5970	Collar - Coupling	228-9441
2F-6046	Pinion - Reduction	228-9442
2F-6050	Gear - Reduction	229-1584
2F-6051	Gear	229-1585
2F-6053	Gear - Reduction	228-9443
2F-6057	Gear - Reduction	228-9444
2F-8001	Shaft - Worm	228-9445
2G-4187	Shell - Bearing	245-5794
2K-4507	Bearing - Sleeve	325-6021
2K-6413	Pin	360-2270
2S-4015	Plunger As - Valve	311-9438
3B-5067	Shaft - Shift Worm	228-8907
3B-6695	Gear - Worm	228-9448
3B-9970	Worm	228-8908
3D-0409	Arm - Pitman	228-9397
3D-2149	Pinion	228-9450
3D-4443	Shaft - Rev Worm	243-0351
3D-4498	Shaft - Lower	243-0348
3D-4718	Bearing - Sleeve	245-5795
3D-5457	Cage - Bearing	228-9400
3D-6672	Gear	229-1586
3D-9194	Gear	245-5796
3D-9786	Ballstud	228-9559
3D-9932	Cage - Bearing	228-9401
3F-0017	Gear - Coupling	229-1587
3F-0018	Gear - Coupling	229-1588
3F-0019	Collar - Coupling	229-1589
4B-5806	Shaft - Upper	243-0347
4B-7064	Shaft - Worm	245-5803
4D-0913	Arm - Steering	228-9402
4D-0926	Pin	247-4439
4D-0929	Rod End - Tie	228-9403
4D-0930	Rod End - Tie	228-9404
4D-2184	Shaft - Low Pinion	229-1592
4D-2185	Shaft - Rev Idler	229-1593
4D-2198	Cage - Bearing	229-1594

(Continued)

Sales Model 14D (Continued)

Original Part Number	Part Name	Classic Part Number
4D-2218	Gear - Coupling	229-1595
4D-2219	Gear - Reverse	229-1597
4D-2220	Pinion - Transmission & Bevel	228-8920
4D-2227	Pinion	228-9453
4D-2229	Cage - Bearing	229-1598
4D-2268	Cover - Shaft	228-9454
4D-3462	Pin - Pivot	247-4440
4D-3898	Gear - Bevel	228-8921
4D-3966	Gear - Reduction	228-8924
4D-4863	Pinion	229-1599
4D-5997	Pinion	245-5809
4D-6664	Coupling - Shaft	243-0338
4D-6665	Shaft - Circle Rev	243-0349
4D-6926	Segment - Control	228-9455
4D-7213	Coupling	228-9406
4D-7282	Shaft - Axle	228-9408
4D-9934	Trunnion	229-1601
4H-2029	Gear - Reverse	229-1602
4H-7969	Bearing - Worm	245-5811
4K-3004	Bearing - Trunnion Support	314-8632
4K-3128	Bearing - Sleeve	314-8633
5B-0577	Collar	299-1992
5D-0034	Plate - Retainer	228-9456
5D-0395	Bracket - Rail Rh	243-0335
5D-0396	Bracket - Rail Lh	243-0334
5D-3283	Coupling - Shaft	243-0339
5D-3961	Block - Brake	245-5813
5D-4010	Rack	228-8909
5D-7461	Pin	247-4441
5D-9548	Hub - Final Drive Gear	228-9412
5D-9906	Shaft - Axle	228-9413
5H-0049	Hub - Flywheel	229-1608
5H-0051	Plate - Flywheel	229-1610
5H-0057	Ring - Bearing Thrust	229-1613
5P-7807	Bearing - Ball	314-8502
5S-1211	Cover - Valve	314-8665
5S-1822	Chamber As	248-5406
5S-1833	Chamber As	247-3298
5S-9080	Pulley - Alt Drive	264-5883
6B-6911	Worm - Rh	245-5819
6B-6912	Worm - Lh	245-5820
6D-1599	Block - Link Pivot	228-9414
6D-1644	Shaft - Rod Pivot	228-9562
6D-2362	Worm	243-0361
6D-6943	Housing - Axle	228-9416
6D-9193	Hub - Final Drive Gear	228-9417
6D-9294	Shaft	228-9418
6F-5201	Gear - Worm	245-5797
6F-6992	Cap - Ballsocket	297-7160
7B-2420	Ferrule - Director	314-8517
7B-5036	Shaft - Bracket	297-7251
7D-2199	Sleeve As	228-9563
7D-2267	Link As	228-9564
7D-3815	Gear - Final Drive	228-9419
7D-4688	Shaft As - Steering	228-9565
7D-5446	Shaft As - Control Drive	229-1616
7D-5813	Gear - Worm	228-8911
7D-5847	Pinion	228-8912
7D-6568	Cover As	228-9457
7D-6841	Joint As - Univ	228-9566
7D-7289	Hub As Brake	229-1617
7F-6269	Gear - Worm	245-5798
7M-4204	Manifold - Exhaust	261-0901
7M-4603	Body - Fuel Valve	311-9348
7M-7358	Valve - Inlet	298-2774
7N-0128	Core As - Oil Cooler	299-1994
7S-7809	Cap As - Radiator	295-6417
7S-9749	Pulley - Gen Drive	264-5888
8D-0926	Rod As - Tie Lh	228-9422
8D-1769	Plate - Driving	229-1622
8D-5344	Gear - Worm	243-0341
8F-7422	Gear - Worm	228-9461
8H-9806	Gear - Shaft Drive	325-6091
8M-3224	Muffler	247-2676
8N-8225	Bearing - Main	314-8652
9D-2731	Spindle - Wheel	228-9423
9H-2256	Pump Gp	311-9443
9M-4163	Valve - Exhaust	298-2773
9M-4955	Pump Gp - Fuel Transfer	242-3443

Sales Model 14E

Original Part Number	Part Name	Classic Part Number
111-8015	Gasket As - Head	279-4977
131-3815	Seal Gp - Basic	325-6193
172-5188	Shaft - Water Pump	325-6202
172-6712	Impeller - Pump	325-6112
196-0028	Gear As - Idler	364-5259
1A-2846	Cap As - Filler	311-9368
1H-8037	Yoke - Fitting	228-9415
1M-6128	Manifold - Exhaust	261-0906
1N-3576	Block Gp - Cylinder	279-4978
1P-4303	Head As - Cylinder	242-3434

(Continued)

Sales Model 14E (Continued)

Original Part Number	Part Name	Classic Part Number
1P-8554	Coupling - Exhaust	325-6052
1P-9945	Bracket As - Fan	296-1344
1P-9946	Shaft - Fan	325-6194
1P-9952	Impeller - Pump	314-8685
1S-1888	Bracket - Lamp	297-7147
1S-4701	Pulley - Alt	264-5866
1W-4405	Gear - Crankshaft	279-4982
244-1090	Alarm - Back up	360-2345
2D-1345	Drum - Brake	228-9430
2D-3188	Yoke	365-8822
2D-3467	Hub - Final Drive Gear	228-9396
2D-3609	Shaft - Final Drive Pinion	228-8919
2D-4010	Adjuster - Bearing	228-8916
2D-8212	Plate As - Press	229-1582
2F-5721	Bearing - Ball	311-9354
2F-5894	Drum - Brake	228-9439
2F-5969	Collar - Coupling	228-9440
2F-5970	Collar - Coupling	228-9441
2F-6046	Pinion - Reduction	228-9442
2F-6050	Gear - Reduction	229-1584
2F-6051	Gear	229-1585
2F-6053	Gear - Reduction	228-9443
2F-6057	Gear - Reduction	228-9444
2G-2858	Cap - Pivot	243-0345
2G-4187	Shell - Bearing	245-5794
2K-4507	Bearing - Sleeve	325-6021
2K-6413	Pin	360-2270
2P-1170	Shaft As - Gear	296-1367
2P-1738	Plate As - Oil Pan	325-6164
2P-1739	Tube As - Pump	325-6229
2P-1757	Hub - Fan Pulley	296-1357
2P-1781	Spacer - Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2519	Tube As - Inlet	325-6230
2P-2719	Pipe	363-7454
2P-5608	Pipe - Extension	367-6066
2P-5609	Muffler As	247-2665
2P-6128	Pulley	264-5872
2P-6245	Shaft As - Pump	325-6197
2P-7830	Pump Gp	314-8533
2S-4015	Plunger As - Valve	311-9438
2W-1086	Cover As - Cylinder Head	325-6049
2W-2621	Valve - Inlet	247-6892 (Valve), 241-3381 (Valve Kit)
2W-7458	Crankshaft As	242-3439
2W-9978	Core As - Oil Cooler	279-4983
3B-5067	Shaft - Shift Worm	228-8907
3B-9970	Worm	228-8908
3D-0409	Arm - Pitman	228-9397
3D-4718	Bearing - Sleeve	245-5795
3D-5457	Cage - Bearing	228-9400
3D-6672	Gear	229-1586
3D-9932	Cage - Bearing	228-9401
3F-0017	Gear - Coupling	229-1587
3F-0018	Gear - Coupling	229-1588
3F-0019	Collar - Coupling	229-1589
3L-1425	Bearing - Ball	311-9356
4B-1455	Cap As - Filter	361-1719
4B-5806	Shaft - Upper	243-0347
4D-0913	Arm - Steering	228-9402
4D-0926	Pin	247-4439
4D-0929	Rod End - Tie	228-9403
4D-0930	Rod End - Tie	228-9404
4D-2184	Shaft - Low Pinion	229-1592
4D-2185	Shaft - Rev Idler	229-1593
4D-2198	Cage - Bearing	229-1594
4D-2218	Gear - Coupling	229-1595
4D-2219	Gear - Reverse	229-1597
4D-2220	Pinion - Transmission & Bevel	228-8920
4D-2227	Pinion	228-9453
4D-2229	Cage - Bearing	229-1598
4D-2268	Cover - Shaft	228-9454
4D-3462	Pin - Pivot	247-4440
4D-3898	Gear - Bevel	228-8921
4D-3966	Gear - Reduction	228-8924
4D-4863	Pinion	229-1599
4D-7213	Coupling	228-9406
4D-7282	Shaft - Axle	228-9408
4D-9934	Trunnion	229-1601
4F-4974	Clamp	311-9373
4H-2029	Gear - Reverse	229-1602
4J-3015	Shaft	325-6204
4K-3004	Bearing - Trunnion Support	314-8632
4K-3128	Bearing - Sleeve	314-8633
4N-4864	Pump Gp - Fuel Transfer	242-3442
4N-7693	Crankshaft As	242-3439
4P-3546	Valve As - Relief	325-6236
4S-6707	Piston - Clutch	215-1686
4S-8708	Housing - Clutch	216-3557
4S-8718	Cage - Carrier Bearing	217-7724
4W-0452	Seal As - Camshaft	325-6191
5B-0577	Collar	299-1992
5D-0034	Plate - Retainer	228-9456
5D-0395	Bracket - Rail Rh	243-0335
5D-0396	Bracket - Rail Lh	243-0334

(Continued)

Sales Model 14E (Continued)

Original Part Number	Part Name	Classic Part Number
5D-0927	Shaft - Reduction	229-1605
5D-4010	Rack	228-8909
5D-5039	Ballstud	228-8910
5D-6375	Shaft - Final Drive Pinion	228-9409
5D-7461	Pin	247-4441
5D-9548	Hub - Final Drive Gear	228-9412
5D-9906	Shaft - Axle	228-9413
5D-9972	Shaft	229-1607
5H-0049	Hub - Flywheel	229-1608
5H-0051	Plate - Flywheel	229-1610
5H-0057	Ring - Bearing Thrust	229-1613
5M-6120	Gear - Sun	213-8740
5M-6210	Shaft - Planet	219-9683
5M-6211	Shaft - Planet	219-9684
5M-7841	Gear - Ring	214-0525
5M-7869	Gear - Ring	214-0530
5M-7875	Carrier - Front	213-4495
5M-7900	Bolt - Hex Head	311-9349
5P-7807	Bearing - Ball	314-8502
5S-1211	Cover - Valve	314-8665
5S-1822	Chamber As	248-5406
5S-1833	Chamber As	247-3298
5S-4557	Bearing	311-9360
5S-6795	Chamber As	242-3437
5S-7609	Pulley - Alt Drive	264-5881
5S-9062	Spacer	363-7463
5S-9080	Pulley - Alt Drive	264-5883
6D-0687	Gear - Bevel	228-8922
6D-0708	Pinion	228-8923
6D-1599	Block - Link Pivot	228-9414
6D-1644	Shaft - Rod Pivot	228-9562
6D-1777	Gear - Planet	245-5799
6D-1778	Gear - Planet	245-5800
6D-1779	Gear - Planet	245-5801
6D-2362	Worm	243-0361
6D-6114	Cap	245-5822
6D-6201	Ballstud	228-9103
6D-6943	Housing - Axle	228-9416
6D-8671	Bolt - Draft	243-0333
6D-9193	Hub - Final Drive Gear	228-9417
6D-9294	Shaft	228-9418
6F-6992	Cap - Ballsocket	297-7160
6G-1664	Adapter	297-7135
6G-1919	Cap - Pivot	243-0337
6H-3957	Bearing - Ball	311-9358
6I-1346	Pump Gp - Oil	295-5674
6N-1036	Gear - Oil Pump	279-4991
6N-2789	Pulley	264-5886
6N-8413	Housing - Pump	325-6110
7B-2420	Ferrule - Director	314-8517
7B-5036	Shaft - Bracket	297-7251
7C-4297	Seal As - Camshaft	325-6192
7D-2199	Sleeve As	228-9563
7D-2267	Link As	228-9564
7D-2637	Gear - Worm	231-8761
7D-3815	Gear - Final Drive	228-9419
7D-4519	Shaft	245-5807
7D-4523	Coupling	245-5817
7D-4688	Shaft As - Steering	228-9565
7D-5446	Shaft As - Control Drive	229-1616
7D-5813	Gear - Worm	228-8911
7D-5847	Pinion	228-8912
7D-5859	Adapter	297-7136
7D-5861	Adapter	243-0364
7D-6436	Pinion - Reverse	243-0344
7D-6524	Shaft - Axle	228-8917
7D-6568	Cover As	228-9457
7D-6588	Worm	243-0362
7D-6841	Joint As - Univ	228-9566
7D-7289	Hub As Brake	229-1617
7D-7385	Shaft	228-9420
7D-7442	Hub - Final Drive Gear	228-8918
7D-7854	Support - Rack	228-8913
7G-2475	Gear - Planet	223-4815
7G-2476	Gear - Planet	223-4816
7G-2513	Gear - Planet	215-1734
7M-2167	Ring - Governor Control	308-9919
7M-4204	Manifold - Exhaust	261-0901
7M-4603	Body - Fuel Valve	311-9348
7M-7358	Valve - Inlet	298-2774
7N-0128	Core As - Oil Cooler	299-1994
7N-0165	Core As - Oil Cooler	295-5670
7N-2957	Cover - Rad Cap	361-1722
7N-9146	Gear - Flywheel Starter	279-4995
7N-9312	Damper As - Camshaft	299-2005
7N-9805	Pin - Piston	295-6438
7S-3161	Lifter - Valve	279-4996
7S-6723	Bracket - Alternator	299-1978
7S-6902	Gear - Sun	229-1619
7S-6964	Gear - Ring	214-0532
7S-7809	Cap As - Radiator	295-6417
7S-9749	Pulley - Gen Drive	264-5888
7W-0450	Gear - Water Pump	279-4997
7W-0507	Gear - Oil Pump Drive	279-4998
7W-5687	Hub - Camshaft	314-8684
7Y-1517	Pipe As - Tail	301-5246
8D-0527	Gear	229-1621
8D-0926	Rod As - Tie Lh	228-9422
8D-1769	Plate - Driving	229-1622
8D-5344	Gear - Worm	243-0341
8D-5347	Shaft - Drive Pinion	243-0352
8H-9806	Gear - Shaft Drive	325-6091
8M-0874	Plunger As - Valve	311-9439
8M-3224	Muffler	247-2676
8M-8623	Gear - Sun	213-8755
8M-8642	Housing - Clutch	219-9669
8M-8644	Housing - Clutch	215-1782

(Continued)

Sales Model 14E (Continued)

Original Part Number	Part Name	Classic Part Number
8M-8646	Plate As - Center	216-3583
8M-8650	Piston - Clutch	217-9778
8M-8677	Carrier - Planet	213-4449
8N-0002	Trunnion As	314-8728
8N-0875	Valve - Exhaust	247-6893 (Valve), 241-3381 (Valve Kit)
8N-1187	Head Gp - Cylinder	242-3435
8N-1721	Rod As - Conn	269-5291
8N-1984	Rod As - Conn	242-3441
8N-3180	Body As - Piston	250-6563
8N-3181	Piston Gp - Basic	250-6555 (Liner Kit)
8N-3183	Piston Gp - Basic	250-6556 (Liner Kit)
8N-3325	Arm Gp - Rocker	314-8623
8N-3327	Arm Gp - Rocker	314-8624
8N-5305	Spacer	363-7464
8N-5929	Cover - Water Pump	296-1349
8N-7315	Tube As - Outlet	325-6232
8N-8225	Bearing - Main	314-8652
8S-0248	Breather As	325-6033
8S-0493	Shaft As - Pump	325-6198
8S-0905	Muffler As	302-2690
8S-3970	Chamber As	242-3438
9D-2716	Spindle - Wheel	228-9463
9D-2731	Spindle - Wheel	228-9423
9D-6638	Strip - Wear	297-7263
9H-2256	Pump Gp	311-9443
9M-1500	Shaft - Planet	219-9685
9M-1995	Gear - Sun	213-8756
9M-1996	Shaft - Planet	215-1875
9M-2049	Gear - Ring	214-0533
9M-4163	Valve - Exhaust	298-2773
9M-4789	Shaft - Gov Control	297-7256
9M-4955	Pump Gp - Fuel Transfer	242-3443
9N-5769	Cover - Housing	325-6050
9S-2354	Manifold - Exhaust	261-0888
9S-2355	Manifold - Exhaust	261-0891
9S-6129	Pulley - Alternator Drive	264-5891
9S-8679	Chamber As	325-6042

Sales Model 14G

Original Part Number	Part Name	Classic Part Number
100-7860	Valve - Inlet	270-4360 (Valve), 270-4362 (Valve Kit)
104-4253	Line As - Fuel Injector	279-4988
104-4254	Line As - Fuel Injector	279-4989
105-3196	Motor Gp - Gerotor	282-6547
111-8015	Gasket As - Head	279-4977
112-3249	Muffler As	247-2661
122-9405	Bracket As	325-6005
127-3365	Joint Gp - Slip	367-6067
131-3815	Seal Gp - Basic	325-6193
141-6137	Socket Gp	325-6212
141-6138	Socket Gp	325-6213
148-7455	Valve - Exhaust	270-4361
170-0560	Rebuild Kit	363-7458
172-5185	Shaft - Water Pump	325-6201
172-5188	Shaft - Water Pump	325-6202
172-5189	Impeller - Pump	295-5687
172-5190	Impeller - Pump	325-6111
172-6712	Impeller - Pump	325-6112
196-0028	Gear As - Idler	364-5259
1N-3576	Block Gp - Cylinder	279-4978
1N-3958	Elbow	325-6087
1P-5480	Cover As - End	299-1998
1P-8554	Coupling - Exhaust	325-6052
1P-9945	Bracket As - Fan	296-1344
1P-9946	Shaft - Fan	325-6194
1P-9952	Impeller - Pump	314-8685
1P-9989	Pipe	363-7453
1S-4701	Pulley - Alt	264-5866
1U-2738	Piston As	367-6074
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1695	Pump Gp	279-4980
1W-1698	Housing - Transfer Pump	296-1356
1W-4402	Gear - Camshaft	279-4981
1W-4405	Gear - Crankshaft	279-4982
1W-5912	Tappet As - Guide	325-6223
1W-6541	Plunger As	325-6173
244-1090	Alarm - Back up	360-2345
260-7799	Pinion - Circle Drv	367-6094
2F-5721	Bearing - Ball	311-9354
2G-5876	Housing - Drive	302-2684
2G-8609	Pin	319-3450
2G-8618	Pin	299-2031
2G-8622	Pin	299-2032
2K-4507	Bearing - Sleeve	325-6021

(Continued)

Sales Model 14G (Continued)

Original Part Number	Part Name	Classic Part Number
2K-6413	Pin	360-2270
2P-1170	Shaft As - Gear	296-1367
2P-1738	Plate As - Oil Pan	325-6164
2P-1739	Tube As - Pump	325-6229
2P-1757	Hub - Fan Pulley	296-1357
2P-1781	Spacer - Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2519	Tube As - Inlet	325-6230
2P-2719	Pipe	363-7454
2P-4435	Plate	275-5295
2P-4443	Coupling - Flywheel	301-0233
2P-4510	Piston - Clutch	275-5293
2P-4611	Pipe - Exhaust	365-8821
2P-5608	Pipe - Extension	367-6066
2P-5609	Muffler As	247-2665
2P-6245	Shaft As - Pump	325-6197
2P-9632	Damper As	299-2004
2V-4332	Collar	299-1993
2W-1086	Cover As - Cylinder Head	325-6049
2W-2621	Valve - Inlet	247-6892 (Valve), 241-3381 (Valve Kit)
2W-7255	Shaft - Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear - Water Pump	325-6088
3L-1425	Bearing - Ball	311-9356
3P-0165	Pulley - Fan Drive	298-2775
3P-0862	Carrier - Input	301-4764
3P-0894	Shaft As - Planet	302-3446
3P-1609	Carrier - Planet	302-4292
3P-1626	Hub As - Clutch	302-2687
3P-1651	Piston As	302-4296
3P-2692	Cage - Bearing	302-2663
3P-2769	Support As	299-2064
3P-2852	Clutch - Hub	301-4902
3P-2856	Plate - Clutch	302-2693
3P-2859	Drum As	301-4644
3P-6880	Housing As	302-2685
4B-1455	Cap As - Filter	361-1719
4F-4974	Clamp	311-9373
4K-3004	Bearing - Trunnion Support	314-8632
4K-3128	Bearing - Sleeve	314-8633
4K-6558	Pin - Lower	302-2710
4K-6760	Cap - Lower	300-2574
4K-6761	Cap - Upper	300-2575
4K-8561	Pin	299-2036
4K-8734	Bearing - Sleeve	299-1962
4N-2954	Sleeve - Camshaft	299-2059
4N-3281	Line As - Fuel Injector	247-3362
4N-3282	Line As - Fuel Injector	247-3363
4N-3283	Line As - Fuel Injector	247-3364
4N-4782	Pulley	325-6176
4N-7693	Crankshaft As	242-3439
4N-8591	Coupling - Exhaust	325-6053
4N-8814	Line As - Fuel Injector	247-3366
4N-9587	Shield - Heat	297-7260
4P-3546	Valve As - Relief	325-6236
4P-9381	Line As - Fuel Injector	279-4984
4P-9382	Line As - Fuel Injector	279-4985
4P-9385	Line As - Fuel Injector	279-4986
4P-9386	Line As - Fuel Injector	279-4987
4S-8472	Hood As	296-1355
4S-8670	Shaft - Planet	300-2590
4T-0998	Lever	314-8687
4V-0015	Plate - Lock	282-6563
4W-0452	Seal As - Camshaft	325-6191
5D-0470	Valve Gp	314-8549
5F-7404	Nut - Bearing Lock	308-9878
5K-8330	Holder - Tooth	299-2013
5P-7807	Bearing - Ball	314-8502
5S-4557	Bearing	311-9360
5S-6795	Chamber As	242-3437
5S-9062	Spacer	363-7463
5S-9080	Pulley - Alt Drive	264-5883
5T-3475	Shaft	297-7247
5T-5222	Shoe - Circle Guide	297-7261
5T-6298	Lever	299-2018
6D-4909	Cap - Pivot	297-7159
6D-8671	Bolt - Draft	243-0333
6G-4680	Adapter	302-2633
6G-6241	Gear - Worm	299-2010
6G-8425	Valve Gp - Control	367-6086
6H-3957	Bearing - Ball	311-9358
6I-1346	Pump Gp - Oil	295-5674
6N-1036	Gear - Oil Pump	279-4991
6N-1965	Line As - Fuel Injector	250-7535
6N-1966	Line As - Fuel Injector	250-7536
6N-2789	Pulley	264-5886
6N-8413	Housing - Pump	325-6110
6Y-0580	Carrier - Planet	301-4768
7C-4297	Seal As - Camshaft	325-6192
7D-5859	Adapter	297-7136
7G-3454	Gear - Planet	300-2578
7G-3455	Gear - Planet	300-2582
7G-3456	Gear - Planet	300-2583
7J-9708	Bearing - Sleeve	299-1964
7N-0128	Core As - Oil Cooler	299-1994
7N-0165	Core As - Oil Cooler	295-5670
7N-2871	Line As - Fuel Injector	319-8172
7N-2872	Line As - Fuel Injector	319-8173
7N-2874	Line As - Fuel Injector	298-2779
7N-2875	Line As - Fuel Injector	298-2780
7N-2876	Line As - Fuel Injector	298-2781

(Continued)

Sales Model 14G (Continued)

Original Part Number	Part Name	Classic Part Number
7N-3486	Manifold - Exhaust	261-0899
7N-3515	Gear - Camshaft	314-8669
7N-3536	Gear - Fuel	279-4993
7N-5910	Impeller - Pump	314-8686
7N-9146	Gear - Flywheel Starter	279-4995
7N-9312	Damper As - Camshaft	299-2005
7N-9805	Pin - Piston	295-6438
7S-3161	Lifter - Valve	279-4996
7S-6723	Bracket - Alternator	299-1978
7T-2036	Cap As - Filter	361-1721
7T-9647	Piston - Clutch	275-5294
7W-0450	Gear - Water Pump	279-4997
7W-0507	Gear - Oil Pump Drive	279-4998
7W-0508	Gear - Fuel Pump Drive	296-1351
7Y-1517	Pipe As - Tail	301-5246
8D-1648	Disc	367-6070
8D-1833	Pin	364-5269
8D-2351	Pin	297-7217
8D-2452	Gear - Sun	297-7180
8D-2459	Gear - Planet	297-7181
8D-2519	Shaft - Planet	300-2591
8D-2532	Carrier - Planet	301-4773
8D-3665	Pin	297-7218
8D-4673	Pin - Cylinder	302-2711
8D-9479	Gear - Diff Bevel	302-2670
8D-9482	Gear - Diff Bevel	302-2673
8H-2810	Case As - Filter	314-8512
8N-0002	Trunnion As	314-8728
8N-0875	Valve - Exhaust	247-6893 (Valve), 241-3381 (Valve Kit)
8N-1187	Head Gp - Cylinder	242-3435
8N-1721	Rod As - Conn	269-5291
8N-1984	Rod As - Conn	242-3441
8N-2510	Shaft	325-6208
8N-2641	Sleeve	325-6210
8N-3182	Body As - Piston	250-6564 (Piston As), 250-6556 (Liner Kits)
8N-3183	Piston Gp - Basic	250-6556 (Liner Kit)
8N-3251	Shaft As - Rocker Arm	314-8711
8N-3325	Arm Gp - Rocker	314-8623
8N-3327	Arm Gp - Rocker	314-8624
8N-5305	Spacer	363-7464
8N-5779	Coupling - Exhaust	325-6047
8N-5929	Cover - Water Pump	296-1349
8N-6796	Head Gp - Cylinder	269-5290
8N-7315	Tube As - Outlet	325-6232
8N-8225	Bearing - Main	314-8652
8N-9733	Line As - Fuel Injector	319-8174
8P-1656	Plate - Clutch	367-6071
8S-0248	Breather As	325-6033
8S-0493	Shaft As - Pump	325-6198
8S-3970	Chamber As	242-3438
8S-7716	Manifold - Exhaust	295-0415
8S-7717	Manifold - Exhaust	261-0894
8S-7718	Manifold - Exhaust	295-0416
8W-4167	Bearing - Sleeve	361-1694
8W-5293	Pin	282-6570
9D-5741	Worm - Circle Drive	297-7270
9D-5746	Gear - Worm	299-2011
9D-5921	Shaft - Drive Pinion	297-7254
9D-7924	Mounting	360-2356
9N-5769	Cover - Housing	325-6050
9S-2354	Manifold - Exhaust	261-0888
9S-2355	Manifold - Exhaust	261-0891
9S-6129	Pulley - Alternator Drive	264-5891
9S-8679	Chamber As	325-6042
9T-4761	Head	325-6108

Sales Model 112

Original Part Number	Part Name	Classic Part Number
0T-0259	Nut - Bearing Sleeve	311-9431
121-7746	Precleaner As	360-2311
1A-2846	Cap As - Filler	311-9368
1D-3996	Fork - Knuckle	228-9428
1H-8037	Yoke - Fitting	228-9415
1M-7250	Bowl - Precleaner	360-2296
1P-1721	Gear - Balance	298-2769
1P-1722	Gear - Balance	298-2770
1S-1967	Chamber As	247-3291
1S-1970	Chamber As	247-3292
1W-4405	Gear - Crankshaft	279-4982
2D-1345	Drum - Brake	228-9430
2D-1659	Rack - Shift	228-9431
2D-3188	Yoke	365-8822
2D-3467	Hub - Final Drive Gear	228-9396
2D-4010	Adjuster - Bearing	228-8916
2D-4205	Block - Pivot	228-9432
2D-4209	Pin - Pivot	228-9434
2D-4211	Arm - Steering	228-9435
2D-4215	Knuckle - Rh	228-9436

(Continued)

Sales Model 112 (Continued)

Original Part Number	Part Name	Classic Part Number
2D-4216	Knuckle - Lh	228-9437
2D-5961	Pin - Axle Pivot	228-9438
2D-6382	Gear - Worm	228-9558
2D-8212	Plate As - Press	229-1582
2F-5721	Bearing - Ball	311-9354
2F-5894	Drum - Brake	228-9439
2F-5969	Collar - Coupling	228-9440
2F-5970	Collar - Coupling	228-9441
2F-6051	Gear	229-1585
2F-8001	Shaft - Worm	228-9445
2F-9047	Block - Pivot	228-9446
2F-9074	Link - Tie Bar	228-9447
2G-4187	Shell - Bearing	245-5794
2S-1273	Chamber As	319-3434
2S-4015	Plunger As - Valve	311-9438
3B-5067	Shaft - Shift Worm	228-8907
3B-6218	Muffler As	247-2672
3B-6695	Gear - Worm	228-9448
3B-9970	Worm	228-8908
3D-0409	Arm - Pitman	228-9397
3D-2149	Pinion	228-9450
3D-4442	Shaft - Rev Worm	243-0354
3D-4498	Shaft - Lower	243-0348
3D-4718	Bearing - Sleeve	245-5795
3D-9194	Gear	245-5796
3D-9932	Cage - Bearing	228-9401
3F-0017	Gear - Coupling	229-1587
3F-6334	End-tie Rod - Rh	228-9451
3F-6338	End-tie Rod - Lh	228-9452
3K-3124	Muffler - Trap	247-2673
4B-5806	Shaft - Upper	243-0347
4B-7064	Shaft - Worm	245-5803
4D-1626	Shaft - Lift Arm	245-5805
4D-2229	Cage - Bearing	229-1598
4D-2268	Cover - Shaft	228-9454
4D-5997	Pinion	245-5809
4D-6664	Coupling - Shaft	243-0338
4D-6665	Shaft - Circle Rev	243-0349
4D-6698	Bearing - Tandem Housing	228-9405
4D-6926	Segment - Control	228-9455
4D-7213	Coupling	228-9406
4D-7282	Shaft - Axle	228-9408
4H-7969	Bearing - Worm	245-5811
4N-7526	Seal As - Pump	311-9454
4N-9180	Seal As - Pump	311-9455
5B-0577	Collar	299-1992
5D-0034	Plate - Retainer	228-9456
5D-3283	Coupling - Shaft	243-0339
5D-3961	Block - Brake	245-5813
5D-6201	Shoe - Yoke	243-0356
5D-7339	Coupling	245-5816
5D-7462	Pin	247-4442
5H-0049	Hub - Flywheel	229-1608
5H-0051	Plate - Flywheel	229-1610
5H-0057	Ring - Bearing Thrust	229-1613
5P-7807	Bearing - Ball	314-8502
5S-1211	Cover - Valve	314-8665
5S-1822	Chamber As	248-5406
5S-1833	Chamber As	247-3298
6B-3158	Shoe - Yoke Lh	243-0357
6B-6911	Worm - Rh	245-5819
6B-6912	Worm - Lh	245-5820
6B-6941	Bearing - Worm	245-5812
6D-1599	Block - Link Pivot	228-9414
6D-1644	Shaft - Rod Pivot	228-9562
6D-9164	Shaft - Pinion	243-0353
6D-9294	Shaft	228-9418
6F-5201	Gear - Worm	245-5797
6F-6992	Cap - Ballsocket	297-7160
6G-2947	Shaft	243-0346
6H-3957	Bearing - Ball	311-9358
7B-2420	Ferrule - Director	314-8517
7B-5036	Shaft - Bracket	297-7251
7D-2199	Sleeve As	228-9563
7D-2267	Link As	228-9564
7D-4688	Shaft As - Steering	228-9565
7D-5813	Gear - Worm	228-8911
7D-5847	Pinion	228-8912
7D-6841	Joint As - Univ	228-9566
7D-7075	Worm	243-0363
7D-7078	Shaft - Rev Worm	243-0355
7D-7386	Shaft	228-9567
7F-6269	Gear - Worm	245-5798
7F-9263	Cap - Pivot	243-0336
7H-0602	Dog - Clutch	314-8515
7M-4603	Body - Fuel Valve	311-9348
7M-4926	Retainer - Pin	314-8538
7M-7358	Valve - Inlet	298-2774
7S-7809	Cap As - Radiator	295-6417
7S-9749	Pulley - Gen Drive	264-5888
7T-2036	Cap As - Filter	361-1721
8B-5972	Bearing - Ball	314-8503
8D-0682	Shaft	245-5806
8D-0994	Rod As - Tie Rh	228-9459
8D-0995	Rod As - Tie Lh	228-9460
8D-1769	Plate - Driving	229-1622
8F-7422	Gear - Worm	228-9461
8H-9806	Gear - Shaft Drive	325-6091
8M-3224	Muffler	247-2676
8N-8225	Bearing - Main	314-8652
9D-2731	Spindle - Wheel	228-9423
9H-2256	Pump Gp	311-9443
9M-4163	Valve - Exhaust	298-2773
9M-4955	Pump Gp - Fuel Transfer	242-3443
9Y-9431	Precleaner As	361-1718

Sales Model 112E

Original Part Number	Part Name	Classic Part Number
1D-3996	Fork - Knuckle	228-9428
1H-8037	Yoke - Fitting	228-9415
1P-1721	Gear - Balance	298-2769
1P-1722	Gear - Balance	298-2770
1W-4405	Gear - Crankshaft	279-4982
2D-1345	Drum - Brake	228-9430
2D-1659	Rack - Shift	228-9431
2D-3188	Yoke	365-8822
2D-3467	Hub - Final Drive Gear	228-9396
2D-4010	Adjuster - Bearing	228-8916
2D-4205	Block - Pivot	228-9432
2D-4209	Pin - Pivot	228-9434
2D-4211	Arm - Steering	228-9435
2D-4215	Knuckle - Rh	228-9436
2D-4216	Knuckle - Lh	228-9437
2D-5961	Pin - Axle Pivot	228-9438
2D-6382	Gear - Worm	228-9558
2D-8212	Plate As - Press	229-1582
2F-5894	Drum - Brake	228-9439
2F-5969	Collar - Coupling	228-9440
2F-5970	Collar - Coupling	228-9441
2F-6046	Pinion - Reduction	228-9442
2F-6050	Gear - Reduction	229-1584
2F-6051	Gear	229-1585
2F-6053	Gear - Reduction	228-9443
2F-6057	Gear - Reduction	228-9444
2F-8001	Shaft - Worm	228-9445
2F-9047	Block - Pivot	228-9446
2F-9074	Link - Tie Bar	228-9447
2G-4187	Shell - Bearing	245-5794
2S-4015	Plunger As - Valve	311-9438
3B-5067	Shaft - Shift Worm	228-8907
3B-6218	Muffler As	247-2672
3B-6695	Gear - Worm	228-9448
3B-9970	Worm	228-8908
3D-0409	Arm - Pitman	228-9397
3D-2136	Sprocket	228-9398
3D-2149	Pinion	228-9450
3D-2236	Sprocket As	228-9399
3D-4442	Shaft - Rev Worm	243-0354
3D-4498	Shaft - Lower	243-0348
3D-4718	Bearing - Sleeve	245-5795
3D-5457	Cage - Bearing	228-9400
3D-6672	Gear	229-1586
3D-9194	Gear	245-5796
3D-9932	Cage - Bearing	228-9401
3F-0017	Gear - Coupling	229-1587
3F-0018	Gear - Coupling	229-1588
3F-0019	Collar - Coupling	229-1589
3F-6334	End-tie Rod - Rh	228-9451
3F-6338	End-tie Rod - Lh	228-9452
3K-3124	Muffler - Trap	247-2673
4B-5806	Shaft - Upper	243-0347
4B-7064	Shaft - Worm	245-5803
4D-1626	Shaft - Lift Arm	245-5805
4D-2184	Shaft - Low Pinion	229-1592
4D-2185	Shaft - Rev Idler	229-1593
4D-2198	Cage - Bearing	229-1594
4D-2220	Pinion - Transmission & Bevel	228-8920
4D-2227	Pinion	228-9453
4D-2229	Cage - Bearing	229-1598
4D-2268	Cover - Shaft	228-9454
4D-3898	Gear - Bevel	228-8921
4D-3966	Gear - Reduction	228-8924
4D-4863	Pinion	229-1599
4D-5997	Pinion	245-5809
4D-6664	Coupling - Shaft	243-0338
4D-6665	Shaft - Circle Rev	243-0349
4D-6698	Bearing - Tandem Housing	228-9405
4D-6926	Segment - Control	228-9455
4D-7213	Coupling	228-9406
4D-7282	Shaft - Axle	228-9408
4D-9934	Trunnion	229-1601
4H-2029	Gear - Reverse	229-1602
4H-7969	Bearing - Worm	245-5811
5B-0577	Collar	299-1992
5D-0034	Plate - Retainer	228-9456
5D-0927	Shaft - Reduction	229-1605
5D-3283	Coupling - Shaft	243-0339
5D-3961	Block - Brake	245-5813
5D-6201	Shoe - Yoke	243-0356
5D-7339	Coupling	245-5816
5D-7462	Pin	247-4442
5D-9548	Hub - Final Drive Gear	228-9412
5H-0049	Hub - Flywheel	229-1608
5H-0051	Plate - Flywheel	229-1610
5H-0057	Ring - Bearing Thrust	229-1613
5S-1211	Cover - Valve	314-8665
5S-1822	Chamber As	248-5406
5S-1833	Chamber As	247-3298
6B-3158	Shoe - Yoke Lh	243-0357
6B-6911	Worm - Rh	245-5819
6B-6912	Worm - Lh	245-5820
6B-6941	Bearing - Worm	245-5812
6D-0687	Gear - Bevel	228-8922
6D-0708	Pinion	228-8923
6D-1599	Block - Link Pivot	228-9414
6D-1644	Shaft - Rod Pivot	228-9562
6D-6943	Housing - Axle	228-9416
6D-9164	Shaft - Pinion	243-0353

(Continued)

Sales Model 112E (Continued)

Original Part Number	Part Name	Classic Part Number
6D-9193	Hub - Final Drive Gear	228-9417
6D-9294	Shaft	228-9418
6F-5201	Gear - Worm	245-5797
6F-6992	Cap - Ball-socket	297-7160
6G-1633	Chain Gp	282-6565
6G-2947	Shaft	243-0346
7B-2420	Ferrule - Director	314-8517
7B-5036	Shaft - Bracket	297-7251
7D-2199	Sleeve As	228-9563
7D-2267	Link As	228-9564
7D-4688	Shaft As - Steering	228-9565
7D-5446	Shaft As - Control Drive	229-1616
7D-5813	Gear - Worm	228-8911
7D-5847	Pinion	228-8912
7D-6524	Shaft - Axle	228-8917
7D-6568	Cover As	228-9457
7D-6841	Joint As - Univ	228-9566
7D-7075	Worm	243-0363
7D-7078	Shaft - Rev Worm	243-0355
7D-7289	Hub As Brake	229-1617
7D-7386	Shaft	228-9567
7D-7442	Hub - Final Drive Gear	228-8918
7F-6269	Gear - Worm	245-5798
7F-9263	Cap - Pivot	243-0336
7M-4603	Body - Fuel Valve	311-9348
7M-4926	Retainer - Pin	314-8538
7M-7358	Valve - Inlet	298-2774
7S-7809	Cap As - Radiator	295-6417
7S-9749	Pulley - Gen Drive	264-5888
8D-0527	Gear	229-1621
8D-0682	Shaft	245-5806
8D-0994	Rod As - Tie Rh	228-9459
8D-0995	Rod As - Tie Lh	228-9460
8D-1769	Plate - Driving	229-1622
8F-7422	Gear - Worm	228-9461
8H-9806	Gear - Shaft Drive	325-6091
8N-8225	Bearing - Main	314-8652
9D-2716	Spindle - Wheel	228-9463
9D-2731	Spindle - Wheel	228-9423
9H-2256	Pump Gp	311-9443
9M-4163	Valve - Exhaust	298-2773
9M-4789	Shaft - Gov Control	297-7256
9M-4955	Pump Gp - Fuel Transfer	242-3443
9Y-9431	Precleaner As	361-1718

Sales Model 112F

Original Part Number	Part Name	Classic Part Number
100-7860	Valve - Inlet	270-4360 (Valve), 270-4362 (Valve Kit)
131-3815	Seal Gp - Basic	325-6193
148-7455	Valve - Exhaust	270-4361
172-5188	Shaft - Water Pump	325-6202
172-6712	Impeller - Pump	325-6112
196-0028	Gear As - Idler	364-5259
1A-2846	Cap As - Filler	311-9368
1D-3996	Fork - Knuckle	228-9428
1H-8037	Yoke - Fitting	228-9415
1M-5270	Pipe - Extension	367-6065
1N-4304	Head Gp - Cylinder	269-8761
1P-1721	Gear - Balance	298-2769
1P-1722	Gear - Balance	298-2770
1P-9945	Bracket As - Fan	296-1344
1P-9946	Shaft - Fan	325-6194
1P-9952	Impeller - Pump	314-8685
1S-1888	Bracket - Lamp	297-7147
1S-4701	Pulley - Alt	264-5866
1W-4402	Gear - Camshaft	279-4981
1W-4405	Gear - Crankshaft	279-4982
2D-1345	Drum - Brake	228-9430
2D-1659	Rack - Shift	228-9431
2D-3188	Yoke	365-8822
2D-3467	Hub - Final Drive Gear	228-9396
2D-4010	Adjuster - Bearing	228-8916
2D-4205	Block - Pivot	228-9432
2D-4209	Pin - Pivot	228-9434
2D-4211	Arm - Steering	228-9435
2D-4215	Knuckle - Rh	228-9436
2D-4216	Knuckle - Lh	228-9437
2D-5961	Pin - Axle Pivot	228-9438
2D-6382	Gear - Worm	228-9558
2D-7933	Cover - Circle Rev	243-0340
2D-8212	Plate As - Press	229-1582
2F-5721	Bearing - Ball	311-9354
2F-5894	Drum - Brake	228-9439
2F-5969	Collar - Coupling	228-9440
2F-5970	Collar - Coupling	228-9441
2F-6046	Pinion - Reduction	228-9442
2F-6050	Gear - Reduction	229-1584
2F-6051	Gear	229-1585
2F-6053	Gear - Reduction	228-9443

(Continued)

Sales Model 112F (Continued)

Original Part Number	Part Name	Classic Part Number
2F-6057	Gear - Reduction	228-9444
2F-8001	Shaft - Worm	228-9445
2F-9047	Block - Pivot	228-9446
2F-9074	Link - Tie Bar	228-9447
2G-4187	Shell - Bearing	245-5794
2P-1170	Shaft As - Gear	296-1367
2P-1757	Hub - Fan Pulley	296-1357
2P-1781	Spacer - Oil Pump	325-6214
2P-2519	Tube As - Inlet	325-6230
2P-2719	Pipe	363-7454
2P-6245	Shaft As - Pump	325-6197
2P-6255	Muffler As	247-2666
2P-7828	Pan - Oil	314-8691
2P-7830	Pump Gp	314-8533
2S-4015	Plunger As - Valve	311-9438
2W-2621	Valve - Inlet	247-6892 (Valve), 241-3381 (Valve Kit)
3B-5067	Shaft - Shift Worm	228-8907
3B-6218	Muffler As	247-2672
3B-6695	Gear - Worm	228-9448
3B-9970	Worm	228-8908
3D-0409	Arm - Pitman	228-9397
3D-2149	Pinion	228-9450
3D-4442	Shaft - Rev Worm	243-0354
3D-4498	Shaft - Lower	243-0348
3D-4718	Bearing - Sleeve	245-5795
3D-5457	Cage - Bearing	228-9400
3D-6672	Gear	229-1586
3D-9194	Gear	245-5796
3D-9502	Bolt - Draft	243-0332
3D-9932	Cage - Bearing	228-9401
3F-0017	Gear - Coupling	229-1587
3F-0018	Gear - Coupling	229-1588
3F-0019	Collar - Coupling	229-1589
3F-6334	End-tie Rod - Rh	228-9451
3F-6338	End-tie Rod - Lh	228-9452
3F-6523	Pin - Clevis	256-4818
3F-6611	Socket - Joint	256-4829
3F-6612	Cap - Ball Joint	297-7155
3K-3124	Muffler - Trap	247-2673
3L-1425	Bearing - Ball	311-9356
4B-5806	Shaft - Upper	243-0347
4B-7064	Shaft - Worm	245-5803
4D-1626	Shaft - Lift Arm	245-5805
4D-2184	Shaft - Low Pinion	229-1592
4D-2185	Shaft - Rev Idler	229-1593
4D-2198	Cage - Bearing	229-1594
4D-2220	Pinion - Transmission & Bevel	228-8920
4D-2227	Pinion	228-9453
4D-2229	Cage - Bearing	229-1598
4D-2268	Cover - Shaft	228-9454
4D-3898	Gear - Bevel	228-8921
4D-3966	Gear - Reduction	228-8924
4D-4863	Pinion	229-1599
4D-5997	Pinion	245-5809
4D-6664	Coupling - Shaft	243-0338
4D-6665	Shaft - Circle Rev	243-0349
4D-6698	Bearing - Tandem Housing	228-9405
4D-6926	Segment - Control	228-9455
4D-7213	Coupling	228-9406
4D-7282	Shaft - Axle	228-9408
4D-9934	Trunnion	229-1601
4F-4974	Clamp	311-9373
4H-2029	Gear - Reverse	229-1602
4H-7969	Bearing - Worm	245-5811
4N-4864	Pump Gp - Fuel Transfer	242-3442
4N-7692	Crankshaft As	242-3440
4N-7977	Shaft As - Balance	314-8709
4N-7978	Shaft As - Balance	314-8710
4P-3546	Valve As - Relief	325-6236
4W-0452	Seal As - Camshaft	325-6191
5B-0577	Collar	299-1992
5D-0034	Plate - Retainer	228-9456
5D-0927	Shaft - Reduction	229-1605
5D-3283	Coupling - Shaft	243-0339
5D-3961	Block - Brake	245-5813
5D-6201	Shoe - Yoke	243-0356
5D-7339	Coupling	245-5816
5D-7462	Pin	247-4442
5D-9548	Hub - Final Drive Gear	228-9412
5H-0049	Hub - Flywheel	229-1608
5H-0051	Plate - Flywheel	229-1610
5H-0057	Ring - Bearing Thrust	229-1613
5P-7807	Bearing - Ball	314-8502
5S-1211	Cover - Valve	314-8665
5S-1822	Chamber As	248-5406
5S-1833	Chamber As	247-3298
5S-4557	Bearing	311-9360
5S-6795	Chamber As	242-3437
5S-7609	Pulley - Alt Drive	264-5881
5S-8038	Pulley - Crankshaft	264-5882
5S-9062	Spacer	363-7463
5S-9080	Pulley - Alt Drive	264-5883
6B-3158	Shoe - Yoke Lh	243-0357
6B-6911	Worm - Rh	245-5819
6B-6912	Worm - Lh	245-5820
6B-6941	Bearing - Worm	245-5812
6D-0687	Gear - Bevel	228-8922
6D-0708	Pinion	228-8923
6D-1599	Block - Link Pivot	228-9414
6D-1644	Shaft - Rod Pivot	228-9562

(Continued)

Sales Model 112F (Continued)

Original Part Number	Part Name	Classic Part Number
6D-6943	Housing - Axle	228-9416
6D-9164	Shaft - Pinion	243-0353
6D-9193	Hub - Final Drive Gear	228-9417
6D-9294	Shaft	228-9418
6F-5201	Gear - Worm	245-5797
6F-6992	Cap - Ball-socket	297-7160
6G-2947	Shaft	243-0346
6H-3957	Bearing - Ball	311-9358
6N-1036	Gear - Oil Pump	279-4991
6N-8413	Housing - Pump	325-6110
7B-2420	Ferrule - Director	314-8517
7B-5036	Shaft - Bracket	297-7251
7C-4297	Seal As - Camshaft	325-6192
7D-2199	Sleeve As	228-9563
7D-2267	Link As	228-9564
7D-4688	Shaft As - Steering	228-9565
7D-5446	Shaft As - Control Drive	229-1616
7D-5813	Gear - Worm	228-8911
7D-5847	Pinion	228-8912
7D-6516	Pinion - Re-verse	243-0343
7D-6524	Shaft - Axle	228-8917
7D-6588	Worm	243-0362
7D-6841	Joint As - Univ	228-9566
7D-7075	Worm	243-0363
7D-7078	Shaft - Rev Worm	243-0355
7D-7289	Hub As Brake	229-1617
7D-7386	Shaft	228-9567
7D-7442	Hub - Final Drive Gear	228-8918
7F-6269	Gear - Worm	245-5798
7F-9263	Cap - Pivot	243-0336
7M-2167	Ring - Gover-nor Control	308-9919
7M-4358	Manifold - Exhaust	261-0907
7M-4603	Body - Fuel Valve	311-9348
7M-4926	Retainer - Pin	314-8538
7M-7358	Valve - Inlet	298-2774
7N-0128	Core As - Oil Cooler	299-1994
7N-0165	Core As - Oil Cooler	295-5670
7N-9146	Gear - Fly-wheel Starter	279-4995
7N-9805	Pin - Piston	295-6438
7S-3161	Lifter - Valve	279-4996
7S-6723	Bracket - Alternator	299-1978
7S-7070	Head As - Cylinder	325-6107
7S-7809	Cap As - Radiator	295-6417
7S-9749	Pulley - Gen Drive	264-5888
7W-0450	Gear - Water Pump	279-4997
7W-0508	Gear - Fuel Pump Drive	296-1351
8B-5972	Bearing - Ball	314-8503
8D-0527	Gear	229-1621
8D-0682	Shaft	245-5806
8D-0994	Rod As - Tie Rh	228-9459
8D-0995	Rod As - Tie Lh	228-9460
8D-1769	Plate - Driv-ing	229-1622
8D-5344	Gear - Worm	243-0341
8D-5346	Shaft - Drive Pinion	243-0350
8F-7422	Gear - Worm	228-9461
8H-9806	Gear - Shaft Drive	325-6091
8M-0874	Plunger As - Valve	311-9439
8M-3224	Muffler	247-2676
8N-0002	Trunnion As	314-8728
8N-0875	Valve - Ex-haust	247-6893 (Valve), 241-3381 (Valve Kit)
8N-1188	Head Gp - Cylinder	242-3436
8N-1984	Rod As - Conn	242-3441
8N-3180	Body As - Piston	250-6563
8N-3181	Piston Gp - Basic	250-6555 (Liner Kit)
8N-3182	Body As - Piston	250-6564 (Piston As), 250-6556 (Liner Kits)
8N-3183	Piston Gp - Basic	250-6556 (Liner Kit)
8N-3251	Shaft As - Rocker Arm	314-8711
8N-3311	Shaft As - Rocker Arm	325-6199
8N-3312	Shaft As - Rocker Arm	325-6200
8N-3325	Arm Gp - Rocker	314-8623
8N-3327	Arm Gp - Rocker	314-8624
8N-5305	Spacer	363-7464
8N-5929	Cover - Water Pump	296-1349
8N-7315	Tube As - Outlet	325-6232
8N-8225	Bearing - Main	314-8652
8S-0248	Breather As	325-6033
8S-0493	Shaft As - Pump	325-6198
8S-3970	Chamber As	242-3438
9D-2716	Spindle - Wheel	228-9463
9D-2731	Spindle - Wheel	228-9423
9H-2256	Pump Gp	311-9443
9M-4163	Valve - Ex-haust	298-2773
9M-4789	Shaft - Gov Control	297-7256
9M-4955	Pump Gp - Fuel Transfer	242-3443
9N-5769	Cover - Hous-ing	325-6050
9S-2356	Manifold - Exhaust	261-0905
9Y-2992	Bearing - Sleeve	325-6032

Sales Model 120

Original Part Number	Part Name	Classic Part Number
100-7860	Valve - Inlet	270-4360 (Valve), 270-4362 (Valve Kit)
104-4253	Line As - Fuel Injector	279-4988
104-4254	Line As - Fuel Injector	279-4989
111-8015	Gasket As - Head	279-4977
112-3249	Muffler As	247-2661
121-7746	Precleaner As	360-2311
122-9405	Bracket As	325-6005
131-3815	Seal Gp - Basic	325-6193
148-7455	Valve - Exhaust	270-4361
153-3580	Shaft	299-2055
172-5185	Shaft - Water Pump	325-6201
172-5188	Shaft - Water Pump	325-6202
172-5189	Impeller - Pump	295-5687
172-5190	Impeller - Pump	325-6111
172-6712	Impeller - Pump	325-6112
172-7767	Pump Gp - Water	296-1365
196-0028	Gear As - Idler	364-5259
1D-3996	Fork - Knuckle	228-9428
1H-8037	Yoke - Fitting	228-9415
1M-6128	Manifold - Exhaust	261-0906
1M-7250	Bowl - Precleaner	360-2296
1N-3576	Block Gp - Cylinder	279-4978
1N-3958	Elbow	325-6087
1P-4303	Head As - Cylinder	242-3434
1P-9945	Bracket As - Fan	296-1344
1P-9946	Shaft - Fan	325-6194
1P-9952	Impeller - Pump	314-8685
1S-1888	Bracket - Lamp	297-7147
1S-4701	Pulley - Alt	264-5866
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1695	Pump Gp	279-4980
1W-1698	Housing - Transfer Pump	296-1356
1W-4402	Gear - Camshaft	279-4981
1W-4405	Gear - Crankshaft	279-4982
1W-5912	Tappet As - Guide	325-6223
1W-6541	Plunger As	325-6173
244-1090	Alarm - Back up	360-2345
2D-1345	Drum - Brake	228-9430
2D-1659	Rack - Shift	228-9431
2D-3188	Yoke	365-8822
2D-3467	Hub - Final Drive Gear	228-9396
2D-3609	Shaft - Final Drive Pinion	228-8919
2D-4010	Adjuster - Bearing	228-8916
2D-4205	Block - Pivot	228-9432
2D-4209	Pin - Pivot	228-9434
2D-4211	Arm - Steering	228-9435
2D-4215	Knuckle - Rh	228-9436
2D-4216	Knuckle - Lh	228-9437
2D-5795	Sleeve - Thrust	243-0360
2D-5799	Pinion - Reverse	243-0342
2D-5961	Pin - Axle Pivot	228-9438
2D-6381	Pinion	228-8915
2D-6382	Gear - Worm	228-9558
2D-7933	Cover - Circle Rev	243-0340
2D-8212	Plate As - Press	229-1582
2F-5721	Bearing - Ball	311-9354
2F-5894	Drum - Brake	228-9439
2F-5969	Collar - Coupling	228-9440
2F-5970	Collar - Coupling	228-9441
2F-6046	Pinion - Reduction	228-9442
2F-6050	Gear - Reduction	229-1584
2F-6051	Gear	229-1585
2F-6053	Gear - Reduction	228-9443
2F-6057	Gear - Reduction	228-9444
2F-8001	Shaft - Worm	228-9445
2F-9047	Block - Pivot	228-9446
2F-9074	Link - Tie Bar	228-9447
2G-4187	Shell - Bearing	245-5794
2K-3592	Boss	314-8501
2P-1170	Shaft As - Gear	296-1367
2P-1738	Plate As - Oil Pan	325-6164
2P-1739	Tube As - Pump	325-6229
2P-1757	Hub - Fan Pulley	296-1357
2P-1781	Spacer - Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2519	Tube As - Inlet	325-6230
2P-2719	Pipe	363-7454
2P-6128	Pulley	264-5872
2P-6245	Shaft As - Pump	325-6197
2P-7830	Pump Gp	314-8533
2S-4015	Plunger As - Valve	311-9438
2W-1086	Cover As - Cylinder Head	325-6049
2W-2621	Valve - Inlet	247-6892 (Valve), 241-3381 (Valve Kit)
2W-7255	Shaft - Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-9978	Core As - Oil Cooler	279-4983
3B-5067	Shaft - Shift Worm	228-8907
3B-6218	Muffler As	247-2672
3B-6695	Gear - Worm	228-9448
3B-9970	Worm	228-8908
3D-0409	Arm - Pitman	228-9397
3D-2136	Sprocket	228-9398
3D-2149	Pinion	228-9450
3D-2236	Sprocket As	228-9399

(Continued)

Sales Model 120 (Continued)

Original Part Number	Part Name	Classic Part Number
3D-4442	Shaft - Rev Worm	243-0354
3D-4443	Shaft - Rev Worm	243-0351
3D-4498	Shaft - Lower	243-0348
3D-4718	Bearing - Sleeve	245-5795
3D-5457	Cage - Bearing	228-9400
3D-6672	Gear	229-1586
3D-9194	Gear	245-5796
3D-9502	Bolt - Draft	243-0332
3D-9786	Ballstud	228-9559
3D-9932	Cage - Bearing	228-9401
3F-0017	Gear - Coupling	229-1587
3F-0018	Gear - Coupling	229-1588
3F-0019	Collar - Coupling	229-1589
3F-6334	End-tie Rod - Rh	228-9451
3F-6338	End-tie Rod - Lh	228-9452
3K-3124	Muffler - Trap	247-2673
3L-1425	Bearing - Ball	311-9356
4B-1455	Cap As - Filter	361-1719
4B-5806	Shaft - Upper	243-0347
4B-7064	Shaft - Worm	245-5803
4D-1626	Shaft - Lift Arm	245-5805
4D-2184	Shaft - Low Pinion	229-1592
4D-2185	Shaft - Rev Idler	229-1593
4D-2198	Cage - Bearing	229-1594
4D-2218	Gear - Coupling	229-1595
4D-2219	Gear - Reverse	229-1597
4D-2220	Pinion - Transmission & Bevel	228-8920
4D-2227	Pinion	228-9453
4D-2229	Cage - Bearing	229-1598
4D-2268	Cover - Shaft	228-9454
4D-3898	Gear - Bevel	228-8921
4D-3966	Gear - Reduction	228-8924
4D-4863	Pinion	229-1599
4D-5997	Pinion	245-5809
4D-6664	Coupling - Shaft	243-0338
4D-6665	Shaft - Circle Rev	243-0349
4D-6698	Bearing - Tandem Housing	228-9405
4D-6926	Segment - Control	228-9455
4D-7213	Coupling	228-9406
4D-7282	Shaft - Axle	228-9408
4D-9934	Trunnion	229-1601
4F-4974	Clamp	311-9373
4H-2029	Gear - Reverse	229-1602
4H-7969	Bearing - Worm	245-5811
4N-2954	Sleeve - Camshaft	299-2059
4N-3281	Line As - Fuel Injector	247-3362
4N-3282	Line As - Fuel Injector	247-3363
4N-3283	Line As - Fuel Injector	247-3364
4N-3284	Line As - Fuel Injector	247-3365
4N-4864	Pump Gp - Fuel Transfer	242-3442
4N-7693	Crankshaft As	242-3439
4N-8591	Coupling - Exhaust	325-6053
4N-8814	Line As - Fuel Injector	247-3366
4N-9587	Shield - Heat	297-7260
4P-0660	Muffler As	298-2787
4P-3546	Valve As - Relief	325-6236
4P-9381	Line As - Fuel Injector	279-4984
4P-9382	Line As - Fuel Injector	279-4985
4P-9385	Line As - Fuel Injector	279-4986
4P-9386	Line As - Fuel Injector	279-4987
4S-6707	Piston - Clutch	215-1686
4S-8708	Housing - Clutch	216-3557
4S-8718	Cage - Carrier Bearing	217-7724
4W-0452	Seal As - Camshaft	325-6191
5B-0577	Collar	299-1992
5D-0034	Plate - Retainer	228-9456
5D-0395	Bracket - Rail Rh	243-0335
5D-0396	Bracket - Rail Lh	243-0334
5D-0927	Shaft - Reduction	229-1605
5D-3283	Coupling - Shaft	243-0339
5D-3961	Block - Brake	245-5813
5D-4010	Rack	228-8909
5D-6201	Shoe - Yoke	243-0356
5D-6375	Shaft - Final Drive Pinion	228-9409
5D-7339	Coupling	245-5816
5D-7462	Pin	247-4442
5D-9548	Hub - Final Drive Gear	228-9412
5D-9906	Shaft - Axle	228-9413
5D-9972	Shaft	229-1607
5H-0049	Hub - Flywheel	229-1608
5H-0051	Plate - Flywheel	229-1610
5H-0057	Ring - Bearing Thrust	229-1613
5M-6120	Gear - Sun	213-8740
5M-6210	Shaft - Planet	219-9683
5M-6211	Shaft - Planet	219-9684
5M-7841	Gear - Ring	214-0525
5M-7869	Gear - Ring	214-0530
5M-7875	Carrier - Front	213-4495
5M-7900	Bolt - Hex Head	311-9349
5P-7807	Bearing - Ball	314-8502
5S-1211	Cover - Valve	314-8665
5S-1822	Chamber As	248-5406
5S-1833	Chamber As	247-3298
5S-6795	Chamber As	242-3437
5S-7609	Pulley - Alt Drive	264-5881
5S-9062	Spacer	363-7463
5S-9080	Pulley - Alt Drive	264-5883
6B-3158	Shoe - Yoke Lh	243-0357

(Continued)

Sales Model 120 (Continued)

Original Part Number	Part Name	Classic Part Number
6B-6911	Worm - Rh	245-5819
6B-6912	Worm - Lh	245-5820
6B-6941	Bearing - Worm	245-5812
6D-0687	Gear - Bevel	228-8922
6D-0708	Pinion	228-8923
6D-1599	Block - Link Pivot	228-9414
6D-1644	Shaft - Rod Pivot	228-9562
6D-2362	Worm	243-0361
6D-6943	Housing - Axle	228-9416
6D-9164	Shaft - Pinion	243-0353
6D-9193	Hub - Final Drive Gear	228-9417
6D-9294	Shaft	228-9418
6F-5201	Gear - Worm	245-5797
6F-6992	Cap - Ball-socket	297-7160
6G-1633	Chain Gp	282-6565
6G-2947	Shaft	243-0346
6H-3957	Bearing - Ball	311-9358
6I-1346	Pump Gp - Oil	295-5674
6N-1036	Gear - Oil Pump	279-4991
6N-1965	Line As - Fuel Injector	250-7535
6N-1966	Line As - Fuel Injector	250-7536
6N-2789	Pulley	264-5886
6N-8413	Housing - Pump	325-6110
6T-1980	Collar - Idler End	226-0210
7B-2420	Ferrule - Director	314-8517
7B-5036	Shaft - Bracket	297-7251
7C-4297	Seal As - Camshaft	325-6192
7D-2199	Sleeve As	228-9563
7D-2267	Link As	228-9564
7D-3815	Gear - Final Drive	228-9419
7D-4688	Shaft As - Steering	228-9565
7D-5446	Shaft As - Control Drive	229-1616
7D-5813	Gear - Worm	228-8911
7D-5847	Pinion	228-8912
7D-6516	Pinion - Reverse	243-0343
7D-6524	Shaft - Axle	228-8917
7D-6568	Cover As	228-9457
7D-6588	Worm	243-0362
7D-6841	Joint As - Univ	228-9566
7D-7075	Worm	243-0363
7D-7078	Shaft - Rev Worm	243-0355
7D-7289	Hub As Brake	229-1617
7D-7386	Shaft	228-9567
7D-7427	Sprocket	228-9458
7D-7442	Hub - Final Drive Gear	228-8918
7F-6269	Gear - Worm	245-5798
7F-9263	Cap - Pivot	243-0336
7G-2475	Gear - Planet	223-4815
7G-2476	Gear - Planet	223-4816
7G-2513	Gear - Planet	215-1734
7M-2167	Ring - Governor Control	308-9919
7M-4603	Body - Fuel Valve	311-9348
7M-4926	Retainer - Pin	314-8538
7M-7358	Valve - Inlet	298-2774
7N-0128	Core As - Oil Cooler	299-1994
7N-0165	Core As - Oil Cooler	295-5670
7N-2871	Line As - Fuel Injector	319-8172
7N-2872	Line As - Fuel Injector	319-8173
7N-2874	Line As - Fuel Injector	298-2779
7N-2875	Line As - Fuel Injector	298-2780
7N-2876	Line As - Fuel Injector	298-2781
7N-2957	Cover - Rad Cap	361-1722
7N-3486	Manifold - Exhaust	261-0899
7N-3515	Gear - Camshaft	314-8669
7N-3536	Gear - Fuel	279-4993
7N-5910	Impeller - Pump	314-8686
7N-9146	Gear - Flywheel Starter	279-4995
7N-9312	Damper As - Camshaft	299-2005
7N-9805	Pin - Piston	295-6438
7S-3161	Lifter - Valve	279-4996
7S-6723	Bracket - Alternator	299-1978
7S-6902	Gear - Sun	229-1619
7S-6964	Gear - Ring	214-0532
7S-7809	Cap As - Radiator	295-6417
7S-9749	Pulley - Gen Drive	264-5888
7W-0450	Gear - Water Pump	279-4997
7W-0507	Gear - Oil Pump Drive	279-4998
7W-0508	Gear - Fuel Pump Drive	296-1351
7W-5687	Hub - Camshaft	314-8684
7Y-1517	Pipe As - Tail	301-5246
8D-0527	Gear	229-1621
8D-0682	Shaft	245-5806
8D-0994	Rod As - Tie Rh	228-9459
8D-0995	Rod As - Tie Lh	228-9460
8D-1769	Plate - Driving	229-1622
8D-5344	Gear - Worm	243-0341
8D-5346	Shaft - Drive Pinion	243-0350
8F-7422	Gear - Worm	228-9461
8H-2810	Case As - Filter	314-8512
8H-9806	Gear - Shaft Drive	325-6091
8M-0874	Plunger As - Valve	311-9439
8M-8623	Gear - Sun	213-8755
8M-8642	Housing - Clutch	219-9669
8M-8644	Housing - Clutch	215-1782
8M-8646	Plate As - Center	216-3583
8M-8650	Piston - Clutch	217-9778
8M-8677	Carrier - Planet	213-4449
8N-0002	Trunnion As	314-8728

(Continued)

Sales Model 120 (Continued)

Original Part Number	Part Name	Classic Part Number
8N-0875	Valve - Exhaust	247-6893 (Valve), 241-3381 (Valve Kit)
8N-1187	Head Gp - Cylinder	242-3435
8N-1721	Rod As - Conn	269-5291
8N-1984	Rod As - Conn	242-3441
8N-2510	Shaft	325-6208
8N-2641	Sleeve	325-6210
8N-3180	Body As - Piston	250-6563
8N-3181	Piston Gp - Basic	250-6555 (Liner Kit)
8N-3182	Body As - Piston	250-6564 (Piston As), 250-6556 (Liner Kits)
8N-3183	Piston Gp - Basic	250-6556 (Liner Kit)
8N-3251	Shaft As - Rocker Arm	314-8711
8N-3325	Arm Gp - Rocker	314-8623
8N-3327	Arm Gp - Rocker	314-8624
8N-5305	Spacer	363-7464
8N-5929	Cover - Water Pump	296-1349
8N-6796	Head Gp - Cylinder	269-5290
8N-7315	Tube As - Outlet	325-6232
8N-8225	Bearing - Main	314-8652
8N-9733	Line As - Fuel Injector	319-8174
8S-0248	Breather As	325-6033
8S-0493	Shaft As - Pump	325-6198
8S-0905	Muffler As	302-2690
8S-3970	Chamber As	242-3438
9D-2716	Spindle - Wheel	228-9463
9D-2731	Spindle - Wheel	228-9423
9H-2256	Pump Gp	311-9443
9M-1500	Shaft - Planet	219-9685
9M-1995	Gear - Sun	213-8756
9M-1996	Shaft - Planet	215-1875
9M-2049	Gear - Ring	214-0533
9M-4163	Valve - Exhaust	298-2773
9M-4789	Shaft - Gov Control	297-7256
9M-4955	Pump Gp - Fuel Transfer	242-3443
9N-5251	Piston Gp - Basic	250-6557 (Liner Kit)
9N-5769	Cover - Housing	325-6050
9S-2355	Manifold - Exhaust	261-0891
9S-6129	Pulley - Alternator Drive	264-5891
9S-8679	Chamber As	325-6042

Sales Model 120B

Original Part Number	Part Name	Classic Part Number
100-7860	Valve - Inlet	270-4360 (Valve), 270-4362 (Valve Kit)
104-4253	Line As - Fuel Injector	279-4988
104-4254	Line As - Fuel Injector	279-4989
111-8015	Gasket As - Head	279-4977
121-7746	Precleaner As	360-2311
122-9405	Bracket As	325-6005
131-3815	Seal Gp - Basic	325-6193
148-7455	Valve - Exhaust	270-4361
153-3580	Shaft	299-2055
172-5185	Shaft - Water Pump	325-6201
172-5188	Shaft - Water Pump	325-6202
172-5189	Impeller - Pump	295-5687
172-5190	Impeller - Pump	325-6111
172-6712	Impeller - Pump	325-6112
172-7767	Pump Gp - Water	296-1365
196-0028	Gear As - Idler	364-5259
1D-3996	Fork - Knuckle	228-9428
1H-8037	Yoke - Fitting	228-9415
1M-7250	Bowl - Precleaner	360-2296
1N-3576	Block Gp - Cylinder	279-4978
1N-3958	Elbow	325-6087
1P-4303	Head As - Cylinder	242-3434
1P-9945	Bracket As - Fan	296-1344
1P-9946	Shaft - Fan	325-6194
1P-9952	Impeller - Pump	314-8685
1S-4701	Pulley - Alt	264-5866
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1695	Pump Gp	279-4980
1W-1698	Housing - Transfer Pump	296-1356
1W-4402	Gear - Camshaft	279-4981
1W-4405	Gear - Crankshaft	279-4982
1W-5912	Tappet As - Guide	325-6223
1W-6541	Plunger As	325-6173
244-1090	Alarm - Back up	360-2345
2D-1345	Drum - Brake	228-9430
2D-1659	Rack - Shift	228-9431
2D-3188	Yoke	365-8822
2D-3467	Hub - Final Drive Gear	228-9396
2D-3609	Shaft - Final Drive Pinion	228-8919
2D-4010	Adjuster - Bearing	228-8916

(Continued)

Sales Model 120B (Continued)

Original Part Number	Part Name	Classic Part Number
2D-4205	Block - Pivot	228-9432
2D-4209	Pin - Pivot	228-9434
2D-4211	Arm - Steering	228-9435
2D-4215	Knuckle - Rh	228-9436
2D-4216	Knuckle - Lh	228-9437
2D-5795	Sleeve - Thrust	243-0360
2D-5799	Pinion - Reverse	243-0342
2D-5961	Pin - Axle Pivot	228-9438
2D-6381	Pinion	228-8915
2D-6382	Gear - Worm	228-9558
2D-7933	Cover - Circle Rev	243-0340
2D-8212	Plate As - Press	229-1582
2F-5721	Bearing - Ball	311-9354
2F-5894	Drum - Brake	228-9439
2F-5969	Collar - Coupling	228-9440
2F-5970	Collar - Coupling	228-9441
2F-6046	Pinion - Reduction	228-9442
2F-6050	Gear - Reduction	229-1584
2F-6051	Gear	229-1585
2F-6053	Gear - Reduction	228-9443
2F-6057	Gear - Reduction	228-9444
2F-8001	Shaft - Worm	228-9445
2F-9047	Block - Pivot	228-9446
2F-9074	Link - Tie Bar	228-9447
2G-4187	Shell - Bearing	245-5794
2K-3592	Boss	314-8501
2P-1170	Shaft As - Gear	296-1367
2P-1738	Plate As - Oil Pan	325-6164
2P-1757	Hub - Fan Pulley	296-1357
2P-1781	Spacer - Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2519	Tube As - Inlet	325-6230
2P-2719	Pipe	363-7454
2P-6128	Pulley	264-5872
2P-6245	Shaft As - Pump	325-6197
2P-7830	Pump Gp	314-8533
2W-1086	Cover As - Cylinder Head	325-6049
2W-2621	Valve - Inlet	247-6892 (Valve), 241-3381 (Valve Kit)
2W-7255	Shaft - Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
3B-5067	Shaft - Shift Worm	228-8907
3B-6218	Muffler As	247-2672
3B-6695	Gear - Worm	228-9448
3B-9970	Worm	228-8908
3D-0409	Arm - Pitman	228-9397
3D-2136	Sprocket	228-9398
3D-2149	Pinion	228-9450
3D-2236	Sprocket As	228-9399
3D-4442	Shaft - Rev Worm	243-0354
3D-4443	Shaft - Rev Worm	243-0351
3D-4498	Shaft - Lower	243-0348
3D-4718	Bearing - Sleeve	245-5795
3D-5457	Cage - Bearing	228-9400
3D-6672	Gear	229-1586
3D-9194	Gear	245-5796
3D-9502	Bolt - Draft	243-0332
3D-9786	Ballstud	228-9559
3D-9932	Cage - Bearing	228-9401
3F-0017	Gear - Coupling	229-1587
3F-0018	Gear - Coupling	229-1588
3F-0019	Collar - Coupling	229-1589
3F-6334	End-tie Rod - Rh	228-9451
3F-6338	End-tie Rod - Lh	228-9452
3K-3124	Muffler - Trap	247-2673
3L-1425	Bearing - Ball	311-9356
4B-5806	Shaft - Upper	243-0347
4B-7064	Shaft - Worm	245-5803
4D-1626	Shaft - Lift Arm	245-5805
4D-2184	Shaft - Low Pinion	229-1592
4D-2185	Shaft - Rev Idler	229-1593
4D-2198	Cage - Bearing	229-1594
4D-2218	Gear - Coupling	229-1595
4D-2219	Gear - Reverse	229-1597
4D-2220	Pinion - Transmission & Bevel	228-8920
4D-2227	Pinion	228-9453
4D-2229	Cage - Bearing	229-1598
4D-2268	Cover - Shaft	228-9454
4D-3898	Gear - Bevel	228-8921
4D-3966	Gear - Reduction	228-8924
4D-4863	Pinion	229-1599
4D-5997	Pinion	245-5809
4D-6664	Coupling - Shaft	243-0338
4D-6665	Shaft - Circle Rev	243-0349
4D-6698	Bearing - Tandem Housing	228-9405
4D-6926	Segment - Control	228-9455
4D-7213	Coupling	228-9406
4D-7282	Shaft - Axle	228-9408
4D-9934	Trunnion	229-1601
4F-4974	Clamp	311-9373
4H-2029	Gear - Reverse	229-1602
4H-7969	Bearing - Worm	245-5811
4N-2954	Sleeve - Camshaft	299-2059
4N-3281	Line As - Fuel Injector	247-3362
4N-3282	Line As - Fuel Injector	247-3363
4N-3283	Line As - Fuel Injector	247-3364
4N-3284	Line As - Fuel Injector	247-3365
4N-4864	Pump Gp - Fuel Transfer	242-3442
4N-7693	Crankshaft As	242-3439

(Continued)

Sales Model 120B (Continued)

Original Part Number	Part Name	Classic Part Number
4N-8591	Coupling - Exhaust	325-6053
4N-8814	Line As - Fuel Injector	247-3366
4N-9587	Shield - Heat	297-7260
4P-0660	Muffler As	298-2787
4P-3546	Valve As - Relief	325-6236
4P-9381	Line As - Fuel Injector	279-4984
4P-9382	Line As - Fuel Injector	279-4985
4P-9385	Line As - Fuel Injector	279-4986
4P-9386	Line As - Fuel Injector	279-4987
4W-0452	Seal As - Camshaft	325-6191
5B-0577	Collar	299-1992
5D-0034	Plate - Retainer	228-9456
5D-0395	Bracket - Rail Rh	243-0335
5D-0396	Bracket - Rail Lh	243-0334
5D-0927	Shaft - Reduction	229-1605
5D-3283	Coupling - Shaft	243-0339
5D-3961	Block - Brake	245-5813
5D-4010	Rack	228-8909
5D-6201	Shoe - Yoke	243-0356
5D-7339	Coupling	245-5816
5D-7462	Pin	247-4442
5D-9548	Hub - Final Drive Gear	228-9412
5D-9906	Shaft - Axle	228-9413
5H-0049	Hub - Flywheel	229-1608
5H-0051	Plate - Flywheel	229-1610
5H-0057	Ring - Bearing Thrust	229-1613
5P-7807	Bearing - Ball	314-8502
5S-1211	Cover - Valve	314-8665
5S-6795	Chamber As	242-3437
5S-7609	Pulley - Alt Drive	264-5881
5S-9062	Spacer	363-7463
5S-9080	Pulley - Alt Drive	264-5883

Original Part Number	Part Name	Classic Part Number
6B-3158	Shoe - Yoke Lh	243-0357
6B-6911	Worm - Rh	245-5819
6B-6912	Worm - Lh	245-5820
6B-6941	Bearing - Worm	245-5812
6D-0687	Gear - Bevel	228-8922
6D-0708	Pinion	228-8923
6D-1599	Block - Link Pivot	228-9414
6D-1644	Shaft - Rod Pivot	228-9562
6D-2362	Worm	243-0361
6D-6943	Housing - Axle	228-9416
6D-9164	Shaft - Pinion	243-0353
6D-9193	Hub - Final Drive Gear	228-9417
6D-9294	Shaft	228-9418
6F-5201	Gear - Worm	245-5797
6F-6992	Cap - Ballsocket	297-7160
6G-1633	Chain Gp	282-6565
6G-2947	Shaft	243-0346
6H-3957	Bearing - Ball	311-9358
6N-1036	Gear - Oil Pump	279-4991
6N-1965	Line As - Fuel Injector	250-7535
6N-1966	Line As - Fuel Injector	250-7536
6N-2789	Pulley	264-5886
6N-8413	Housing - Pump	325-6110
7B-5036	Shaft - Bracket	297-7251
7C-4297	Seal As - Camshaft	325-6192
7D-2199	Sleeve As	228-9563
7D-2267	Link As	228-9564
7D-3815	Gear - Final Drive	228-9419
7D-4688	Shaft As - Steering	228-9565
7D-5446	Shaft As - Control Drive	229-1616
7D-5813	Gear - Worm	228-8911
7D-5847	Pinion	228-8912
7D-6516	Pinion - Reverse	243-0343
7D-6524	Shaft - Axle	228-8917
7D-6568	Cover As	228-9457

Original Part Number	Part Name	Classic Part Number
7D-6588	Worm	243-0362
7D-6841	Joint As - Univ	228-9566
7D-7075	Worm	243-0363
7D-7078	Shaft - Rev Worm	243-0355
7D-7289	Hub As Brake	229-1617
7D-7386	Shaft	228-9567
7D-7427	Sprocket	228-9458
7D-7442	Hub - Final Drive Gear	228-8918
7F-6269	Gear - Worm	245-5798
7F-9263	Cap - Pivot	243-0336
7M-2167	Ring - Governor Control	308-9919
7M-4603	Body - Fuel Valve	311-9348
7M-4926	Retainer - Pin	314-8538
7N-0128	Core As - Oil Cooler	299-1994
7N-0165	Core As - Oil Cooler	295-5670
7N-2871	Line As - Fuel Injector	319-8172
7N-2872	Line As - Fuel Injector	319-8173
7N-2874	Line As - Fuel Injector	298-2779
7N-2875	Line As - Fuel Injector	298-2780
7N-2876	Line As - Fuel Injector	298-2781
7N-3486	Manifold - Exhaust	261-0899
7N-3515	Gear - Camshaft	314-8669
7N-3536	Gear - Fuel	279-4993
7N-5910	Impeller - Pump	314-8686
7N-9146	Gear - Flywheel Starter	279-4995
7N-9312	Damper As - Camshaft	299-2005
7N-9805	Pin - Piston	295-6438
7S-3161	Lifter - Valve	279-4996
7S-6723	Bracket - Alternator	299-1978
7S-7809	Cap As - Radiator	295-6417
7S-9749	Pulley - Gen Drive	264-5888

(Continued)

Sales Model 120B (Continued)

Original Part Number	Part Name	Classic Part Number
7W-0450	Gear - Water Pump	279-4997
7W-0508	Gear - Fuel Pump Drive	296-1351
7W-5687	Hub - Camshaft	314-8684
7Y-1517	Pipe As - Tail	301-5246
8D-0527	Gear	229-1621
8D-0682	Shaft	245-5806
8D-0994	Rod As - Tie Rh	228-9459
8D-0995	Rod As - Tie Lh	228-9460
8D-1769	Plate - Driving	229-1622
8D-5344	Gear - Worm	243-0341
8D-5346	Shaft - Drive Pinion	243-0350
8F-7422	Gear - Worm	228-9461
8H-2810	Case As - Filter	314-8512
8H-9806	Gear - Shaft Drive	325-6091
8M-0874	Plunger As - Valve	311-9439
8N-0002	Trunnion As	314-8728
8N-0875	Valve - Exhaust	247-6893 (Valve), 241-3381 (Valve Kit)
8N-1187	Head Gp - Cylinder	242-3435
8N-1721	Rod As - Conn	269-5291
8N-1984	Rod As - Conn	242-3441
8N-2510	Shaft	325-6208
8N-2641	Sleeve	325-6210
8N-3180	Body As - Piston	250-6563
8N-3181	Piston Gp - Basic	250-6555 (Liner Kit)
8N-3183	Piston Gp - Basic	250-6556 (Liner Kit)
8N-3251	Shaft As - Rocker Arm	314-8711
8N-3325	Arm Gp - Rocker	314-8623
8N-3327	Arm Gp - Rocker	314-8624
8N-5305	Spacer	363-7464
8N-5929	Cover - Water Pump	296-1349
8N-6796	Head Gp - Cylinder	269-5290
8N-7315	Tube As - Outlet	325-6232
8N-8225	Bearing - Main	314-8652
8N-9733	Line As - Fuel Injector	319-8174
8S-0248	Breather As	325-6033
8S-0493	Shaft As - Pump	325-6198
8S-0905	Muffler As	302-2690
8S-3970	Chamber As	242-3438
9D-2716	Spindle - Wheel	228-9463
9D-2731	Spindle - Wheel	228-9423
9H-2256	Pump Gp	311-9443
9M-4789	Shaft - Gov Control	297-7256
9N-5251	Piston Gp - Basic	250-6557 (Liner Kit)
9N-5769	Cover - Housing	325-6050
9S-2355	Manifold - Exhaust	261-0891
9S-6129	Pulley - Alternator Drive	264-5891
9S-8679	Chamber As	325-6042

Sales Model 120G

Original Part Number	Part Name	Classic Part Number
100-7860	Valve - Inlet	270-4360 (Valve), 270-4362 (Valve Kit)
104-4253	Line As - Fuel Injector	279-4988
104-4254	Line As - Fuel Injector	279-4989
105-3196	Motor Gp - Gerotor	282-6547
106-7131	Shaft	288-8714
110-4652	Housing	302-2683
111-8015	Gasket As - Head	279-4977
112-3249	Muffler As	247-2661
112-5495	Joint Gp - Univ	297-4858
121-7746	Precleaner As	360-2311
124-3240	Pin	282-6548
126-7130	Shaft As	275-5300
131-3736	Socket Gp - Basic	325-6211
131-3737	Socket As	282-6626
131-3738	Socket As	282-6627
131-3815	Seal Gp - Basic	325-6193
147-3309	Spindle	282-6628
147-3400	Spindle	282-6549
148-7455	Valve - Exhaust	270-4361
153-3580	Shaft	299-2055
170-0560	Rebuild Kit	363-7458
172-5185	Shaft - Water Pump	325-6201
172-5188	Shaft - Water Pump	325-6202
172-5189	Impeller - Pump	295-5687
172-5190	Impeller - Pump	325-6111
172-6712	Impeller - Pump	325-6112
196-0028	Gear As - Idler	364-5259
1M-5270	Pipe - Extension	367-6065
1M-7250	Bowl - Precleaner	360-2296
1N-3576	Block Gp - Cylinder	279-4978
1N-3958	Elbow	325-6087
1N-4304	Head Gp - Cylinder	269-8761
1P-1216	Manifold - Exhaust	261-0902
1P-1721	Gear - Balance	298-2769

(Continued)

Sales Model 120G (Continued)

Original Part Number	Part Name	Classic Part Number
1P-1722	Gear - Balance	298-2770
1P-5480	Cover As - End	299-1998
1P-9945	Bracket As - Fan	296-1344
1P-9946	Shaft - Fan	325-6194
1P-9952	Impeller - Pump	314-8685
1P-9989	Pipe	363-7453
1S-4701	Pulley - Alt	264-5866
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1695	Pump Gp	279-4980
1W-1698	Housing - Transfer Pump	296-1356
1W-2870	Shaft As - Balance	314-8715
1W-2871	Shaft As - Balance	314-8716
1W-4402	Gear - Camshaft	279-4981
1W-4405	Gear - Crankshaft	279-4982
1W-5912	Tappet As - Guide	325-6223
1W-6541	Plunger As	325-6173
244-1090	Alarm - Back up	360-2345
2F-5721	Bearing - Ball	311-9354
2G-2858	Cap - Pivot	243-0345
2G-6157	Pin	282-6550
2G-6336	Hub - Brake	282-6551
2G-6375	Shaft - Drive	275-5282
2G-6377	Sprocket	275-5286
2G-7829	Housing As - Drive	297-7196
2G-8239	Yoke As	282-6632
2G-8609	Pin	319-3450
2G-8612	Pin	282-6552
2G-8616	Pin	282-6554
2G-8620	Pin	282-6556
2G-8628	Pin	282-6559
2G-8633	Pin	282-6561
2G-8736	Bearing - Sleeve	299-1959
2G-8769	Pin	282-6562
2G-8872	Shaft - Bevel	275-5271
2P-1170	Shaft As - Gear	296-1367
2P-1757	Hub - Fan Pulley	296-1357
2P-1781	Spacer - Oil Pump	325-6214
2P-2519	Tube As - Inlet	325-6230
2P-2719	Pipe	363-7454
2P-4435	Plate	275-5295
2P-4510	Piston - Clutch	275-5293
2P-4611	Pipe - Exhaust	365-8821
2P-6245	Shaft As - Pump	325-6197
2P-7828	Pan - Oil	314-8691
2S-3966	Ring - Seal	297-7237
2S-4015	Plunger As - Valve	311-9438
2S-6739	Pulley - Tightener	298-2794
2W-1086	Cover As - Cylinder Head	325-6049
2W-2621	Valve - Inlet	247-6892 (Valve), 241-3381 (Valve Kit)
2W-7255	Shaft - Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear - Water Pump	325-6088
312-0782	Worm - Circle Drive	282-6623
3H-3378	Gear As - Pump	298-2795
3L-1425	Bearing - Ball	311-9356
3P-0114	Elbow - Exhaust	314-8516
3P-0165	Pulley - Fan Drive	298-2775
3P-0297	Shaft As	275-5297
3P-0307	Cage As - Bearing	300-2572
3P-0324	Coupling	301-0234
3P-0335	Platepress	297-7228
3P-0726	Shaft As	275-5298
3P-0785	Hub As - Clutch	302-2688
3P-3713	Gear As	275-5288
3P-5349	Piston As	275-5292
3P-5359	Piston - Clutch	299-2037
3P-5737	Shaft As - Clutch	275-5273
4B-1455	Cap As - Filter	361-1719
4F-4974	Clamp	311-9373
4N-2954	Sleeve - Camshaft	299-2059
4N-3281	Line As - Fuel Injector	247-3362
4N-3282	Line As - Fuel Injector	247-3363
4N-3283	Line As - Fuel Injector	247-3364
4N-3284	Line As - Fuel Injector	247-3365
4N-7526	Seal As - Pump	311-9454
4N-7692	Crankshaft As	242-3440
4N-7693	Crankshaft As	242-3439
4N-7977	Shaft As - Balance	314-8709
4N-7978	Shaft As - Balance	314-8710
4N-8942	Muffler As	298-2786
4N-9180	Seal As - Pump	311-9455
4N-9587	Shield - Heat	297-7260
4P-3546	Valve As - Relief	325-6236
4P-9381	Line As - Fuel Injector	279-4984
4P-9382	Line As - Fuel Injector	279-4985
4P-9961	Line As - Fuel Injector	325-6115
4P-9962	Line As - Fuel Injector	325-6116
4P-9963	Line As - Fuel Injector	298-2777
4P-9964	Line As - Fuel Injector	298-2778
4T-0998	Lever	314-8687
4W-0452	Seal As - Camshaft	325-6191
5B-0577	Collar	299-1992
5D-0470	Valve Gp	314-8549
5K-0990	Pin	299-2035
5P-7807	Bearing - Ball	314-8502
5S-1211	Cover - Valve	314-8665
5S-1822	Chamber As	248-5406
5S-1833	Chamber As	247-3298
5S-4557	Bearing	311-9360
5S-6795	Chamber As	242-3437

(Continued)

Sales Model 120G (Continued)

Original Part Number	Part Name	Classic Part Number
5S-7944	Shaft - Planet	297-7246
5S-7945	Shaft As - Planet	275-5299
5S-9062	Spacer	363-7463
5S-9080	Pulley - Alt Drive	264-5883
5T-0906	Cover	282-6625
5T-1362	Bearing - Spider	325-6011
5T-2925	Strip - Wear	282-6564
5T-2926	Shoe - Circle Guide	302-2699
5T-6298	Lever	299-2018
5T-8500	Shoe - Circle Drive	243-0359
5T-8501	Shoe - Circle Drive	243-0358
6F-6992	Cap - Ball-socket	297-7160
6G-1100	Shaft - Drive	297-7248
6G-1664	Adapter	297-7135
6G-1908	Housing As - Drive	297-7198
6G-1919	Cap - Pivot	243-0337
6G-2947	Shaft	243-0346
6G-4525	Strip - Wear	282-6624
6G-8425	Valve Gp - Control	367-6086
6H-3957	Bearing - Ball	311-9358
6I-1346	Pump Gp - Oil	295-5674
6K-4190	Cap - Lower	297-7161
6K-4191	Cap - Upper	300-2576
6K-4193	Plate - Lock	282-6566
6N-1036	Gear - Oil Pump	279-4991
6N-1553	Coupling - Exhaust	295-6422
6N-1878	Muffler As	360-7883
6N-8413	Housing - Pump	325-6110
6Y-0305	Cage As - Bearing	297-7150
7B-2420	Ferrule - Director	314-8517
7B-5036	Shaft - Bracket	297-7251
7C-4297	Seal As - Camshaft	325-6192
7D-5861	Adapter	243-0364
7F-9547	Pin As - Drawbar	295-0414
7G-3450	Gear - Planet	275-5289
7G-3451	Gear - Planet	297-7188
7G-3452	Gear - Planet	275-5290
7G-3461	Gear - Planet	275-5291
7J-9884	Bearing - Sleeve	325-6016
7M-4204	Manifold - Exhaust	261-0901
7M-4603	Body - Fuel Valve	311-9348
7M-7358	Valve - Inlet	298-2774
7N-0128	Core As - Oil Cooler	299-1994
7N-0165	Core As - Oil Cooler	295-5670
7N-2871	Line As - Fuel Injector	319-8172
7N-2872	Line As - Fuel Injector	319-8173
7N-2874	Line As - Fuel Injector	298-2779
7N-3515	Gear - Cam-shaft	314-8669
7N-3536	Gear - Fuel	279-4993
7N-5511	Gear As - Idler	233-2180
7N-5910	Impeller - Pump	314-8686
7N-6677	Core As - Oil Cooler	299-1995
7N-9145	Gear - Fly-wheel	279-4994
7N-9146	Gear - Fly-wheel Starter	279-4995
7N-9805	Pin - Piston	295-6438
7S-3161	Lifter - Valve	279-4996
7S-6723	Bracket - Alternator	299-1978
7S-7809	Cap As - Radiator	295-6417
7S-8631	Shaft As	275-5296
7S-9749	Pulley - Gen Drive	264-5888
7T-2036	Cap As - Filter	361-1721
7T-9647	Piston - Clutch	275-5294
7W-0450	Gear - Water Pump	279-4997
7W-0507	Gear - Oil Pump Drive	279-4998
7W-0508	Gear - Fuel Pump Drive	296-1351
7W-3042	Tube As - Drain	325-6231
7Y-1517	Pipe As - Tail	301-5246
8D-2429	Pin As	319-3445
8D-5344	Gear - Worm	243-0341
8D-7174	Cover As	299-1997
8D-7427	Shaft - Drive Pinion	282-6568
8D-8633	Shaft - Drive	275-5281
8D-8634	Gear - Planet	275-5275
8D-8638	Gear - Sun	275-5279
8D-8639	Gear - Ring	275-5277
8D-8805	Cover	299-2002
8D-9804	Housing - Drive	302-2682
8D-9815	Pin - Cylinder	297-7220
8H-2810	Case As - Filter	314-8512
8H-9806	Gear - Shaft Drive	325-6091
8J-2022	Piston As - Pump	367-6073
8N-0002	Trunnion As	314-8728
8N-0875	Valve - Ex-haust	247-6893 (Valve), 241-3381 (Valve Kit)
8N-1187	Head Gp - Cylinder	242-3435
8N-1188	Head Gp - Cylinder	242-3436
8N-1721	Rod As - Conn	269-5291
8N-1984	Rod As - Conn	242-3441
8N-2510	Shaft	325-6208
8N-2641	Sleeve	325-6210
8N-3182	Body As - Piston	250-6564 (Piston As), 250-6556 (Liner Kits)
8N-3183	Piston Gp - Basic	250-6556 (Liner Kit)
8N-3251	Shaft As - Rocker Arm	314-8711
8N-3311	Shaft As - Rocker Arm	325-6199
8N-3312	Shaft As - Rocker Arm	325-6200
8N-3325	Arm Gp - Rocker	314-8623
8N-3327	Arm Gp - Rocker	314-8624
8N-5305	Spacer	363-7464

(Continued)

Sales Model 120G (Continued)

Original Part Number	Part Name	Classic Part Number
8N-5929	Cover - Water Pump	296-1349
8N-6796	Head Gp - Cylinder	269-5290
8N-7315	Tube As - Outlet	325-6232
8N-8225	Bearing - Main	314-8652
8N-9733	Line As - Fuel Injector	319-8174
8P-1656	Plate - Clutch	367-6071
8S-0248	Breather As	325-6033
8S-0493	Shaft As - Pump	325-6198
8S-3970	Chamber As	242-3438
8W-1751	Bracket As	288-8732
8W-1752	Bracket - Rail	288-8733
8W-1753	Bracket - Rail	288-8734
8W-2307	Shaft - Planet	275-5284
8W-4066	Bracket - Rail	288-8735
8W-4067	Bracket - Rail	288-8736
8W-5092	Pinion - Circle Drive	282-6569
8W-5293	Pin	282-6570
8W-6497	Pin	319-3465
8W-8286	Sprocket	299-2061
8W-8288	Sprocket	299-2062
8W-8289	Sprocket	282-6629
8W-8628	Spindle - Front Axle	282-6571
9D-1177	Shaft - Drive Pinion	297-7253
9D-1487	Housing - Drive	297-7194
9D-6638	Strip - Wear	297-7263
9D-7924	Mounting	360-2356
9D-9665	Bracket - Cylinder Mtg	299-1980
9M-4163	Valve - Exhaust	298-2773
9M-4955	Pump Gp - Fuel Transfer	242-3443
9N-5251	Piston Gp - Basic	250-6557 (Liner Kit)
9N-5769	Cover - Housing	325-6050
9P-4859	Cage As - Bearing	297-7151
9P-8452	Hub - Output	297-7206
9P-8455	Cage As - Bearing	297-7152
9P-9742	Cage As - Bearing	297-7153
9S-6129	Pulley - Alternator Drive	264-5891
9S-8679	Chamber As	325-6042
9Y-2992	Bearing - Sleeve	325-6032

Sales Model 130G

Original Part Number	Part Name	Classic Part Number
100-7860	Valve - Inlet	270-4360 (Valve), 270-4362 (Valve Kit)
104-4253	Line As - Fuel Injector	279-4988
104-4254	Line As - Fuel Injector	279-4989
105-3196	Motor Gp - Gerotor	282-6547
106-7131	Shaft	288-8714
109-5562	Shaft	275-5272
110-4652	Housing	302-2683
111-8015	Gasket As - Head	279-4977
112-3249	Muffler As	247-2661
112-5495	Joint Gp - Univ	297-4858
124-3240	Pin	282-6548
126-7130	Shaft As	275-5300
129-2381	Gear - Planet	275-5274
131-3736	Socket Gp - Basic	325-6211
131-3737	Socket As	282-6626
131-3738	Socket As	282-6627
131-3815	Seal Gp - Basic	325-6193
147-3400	Spindle	282-6549
148-7455	Valve - Exhaust	270-4361
153-3580	Shaft	299-2055
170-0560	Rebuild Kit	363-7458
172-5185	Shaft - Water Pump	325-6201
172-5188	Shaft - Water Pump	325-6202
172-5189	Impeller - Pump	295-5687
172-5190	Impeller - Pump	325-6111
172-6712	Impeller - Pump	325-6112
196-0028	Gear As - Idler	364-5259
1N-3576	Block Gp - Cylinder	279-4978
1N-3958	Elbow	325-6087
1N-4304	Head Gp - Cylinder	269-8761
1P-1216	Manifold - Exhaust	261-0902
1P-1721	Gear - Balance	298-2769
1P-1722	Gear - Balance	298-2770
1P-5480	Cover As - End	299-1998
1P-9945	Bracket As - Fan	296-1344
1P-9946	Shaft - Fan	325-6194
1P-9952	Impeller - Pump	314-8685
1P-9989	Pipe	363-7453
1S-4701	Pulley - Alt	264-5866
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1695	Pump Gp	279-4980
1W-1698	Housing - Transfer Pump	296-1356
1W-2870	Shaft As - Balance	314-8715
1W-2871	Shaft As - Balance	314-8716
1W-4402	Gear - Camshaft	279-4981
1W-4405	Gear - Crankshaft	279-4982
1W-5912	Tappet As - Guide	325-6223
1W-6541	Plunger As	325-6173
236-7724	Retainer	299-2048
244-1090	Alarm - Back up	360-2345
2F-5721	Bearing - Ball	311-9354

(Continued)

Sales Model 130G (Continued)

Original Part Number	Part Name	Classic Part Number
2G-2858	Cap - Pivot	243-0345
2G-7829	Housing As - Drive	297-7196
2G-8238	Yoke As	282-6631
2G-8609	Pin	319-3450
2G-8613	Pin	282-6553
2G-8617	Pin	282-6555
2G-8621	Pin	282-6557
2G-8625	Pin	282-6558
2G-8629	Pin	282-6560
2G-8633	Pin	282-6561
2G-9098	Cap	300-2573
2K-6413	Pin	360-2270
2P-1170	Shaft As - Gear	296-1367
2P-1757	Hub - Fan Pulley	296-1357
2P-1781	Spacer - Oil Pump	325-6214
2P-2519	Tube As - Inlet	325-6230
2P-2719	Pipe	363-7454
2P-4435	Plate	275-5295
2P-4510	Piston - Clutch	275-5293
2P-4611	Pipe - Exhaust	365-8821
2P-6245	Shaft As - Pump	325-6197
2P-7828	Pan - Oil	314-8691
2W-1086	Cover As - Cylinder Head	325-6049
2W-2621	Valve - Inlet	247-6892 (Valve), 241-3381 (Valve Kit)
2W-7255	Shaft - Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear - Water Pump	325-6088
312-0782	Worm - Circle Drive	282-6623
3F-6523	Pin - Clevis	256-4818
3L-1425	Bearing - Ball	311-9356
3P-0114	Elbow - Exhaust	314-8516
3P-0165	Pulley - Fan Drive	298-2775
3P-0297	Shaft As	275-5297
3P-0307	Cage As - Bearing	300-2572
3P-0324	Coupling	301-0234
3P-0335	Platepress	297-7228
3P-0726	Shaft As	275-5298
3P-0785	Hub As - Clutch	302-2688
3P-3713	Gear As	275-5288
3P-5349	Piston As	275-5292
3P-5359	Piston - Clutch	299-2037
3P-5737	Shaft As - Clutch	275-5273
4B-1455	Cap As - Filter	361-1719
4F-4974	Clamp	311-9373
4K-3004	Bearing - Trunnion Support	314-8632
4N-2954	Sleeve - Camshaft	299-2059
4N-3281	Line As - Fuel Injector	247-3362
4N-3282	Line As - Fuel Injector	247-3363
4N-3283	Line As - Fuel Injector	247-3364
4N-3284	Line As - Fuel Injector	247-3365
4N-7692	Crankshaft As	242-3440
4N-7693	Crankshaft As	242-3439
4N-7977	Shaft As - Balance	314-8709
4N-7978	Shaft As - Balance	314-8710
4N-8942	Muffler As	298-2786
4N-9587	Shield - Heat	297-7260
4P-3546	Valve As - Relief	325-6236
4P-9381	Line As - Fuel Injector	279-4984
4P-9382	Line As - Fuel Injector	279-4985
4P-9961	Line As - Fuel Injector	325-6115
4P-9962	Line As - Fuel Injector	325-6116
4P-9963	Line As - Fuel Injector	298-2777
4P-9964	Line As - Fuel Injector	298-2778
4T-0998	Lever	314-8687
4V-0015	Plate - Lock	282-6563
4W-0452	Seal As - Camshaft	325-6191
5B-0577	Collar	299-1992
5D-0470	Valve Gp	314-8549
5K-0871	Pin - Lower	282-6630
5K-0989	Cap - Upper	297-7158
5K-0990	Pin	299-2035
5K-0991	Cap - Lower	319-3433
5P-7807	Bearing - Ball	314-8502
5S-6795	Chamber As	242-3437
5S-7944	Shaft - Planet	297-7246
5S-7945	Shaft As - Planet	275-5299
5S-9062	Spacer	363-7463
5S-9080	Pulley - Alt Drive	264-5883
5T-0906	Cover	282-6625
5T-1362	Bearing - Spider	325-6011
5T-2925	Strip - Wear	282-6564
5T-2926	Shoe - Circle Guide	302-2699
5T-6298	Lever	299-2018
5T-8500	Shoe - Circle Drive	243-0359
5T-8501	Shoe - Circle Drive	243-0358
6F-6992	Cap - Ball-socket	297-7160
6G-1633	Chain Gp	282-6565
6G-1664	Adapter	297-7135
6G-1908	Housing As - Drive	297-7198
6G-1919	Cap - Pivot	243-0337
6G-2947	Shaft	243-0346
6G-4525	Strip - Wear	282-6624
6G-8425	Valve Gp - Control	367-6086
6H-3957	Bearing - Ball	311-9358
6I-1346	Pump Gp - Oil	295-5674
6N-1036	Gear - Oil Pump	279-4991
6N-1553	Coupling - Exhaust	295-6422
6N-1878	Muffler As	360-7883
6N-8413	Housing - Pump	325-6110
6Y-0305	Cage As - Bearing	297-7150
7B-5036	Shaft - Bracket	297-7251
7C-4297	Seal As - Camshaft	325-6192

(Continued)

Sales Model 130G (Continued)

Original Part Number	Part Name	Classic Part Number
7D-5861	Adapter	243-0364
7D-6568	Cover As	228-9457
7D-7889	Gear - Ring	275-5276
7F-9547	Pin As - Drawbar	295-0414
7G-3450	Gear - Planet	275-5289
7G-3451	Gear - Planet	297-7188
7G-3452	Gear - Planet	275-5290
7G-3461	Gear - Planet	275-5291
7J-6461	Crown	325-6054
7J-9884	Bearing - Sleeve	325-6016
7N-0128	Core As - Oil Cooler	299-1994
7N-0165	Core As - Oil Cooler	295-5670
7N-2871	Line As - Fuel Injector	319-8172
7N-2872	Line As - Fuel Injector	319-8173
7N-2874	Line As - Fuel Injector	298-2779
7N-3515	Gear - Camshaft	314-8669
7N-3536	Gear - Fuel	279-4993
7N-5910	Impeller - Pump	314-8686
7N-9145	Gear - Flywheel	279-4994
7N-9805	Pin - Piston	295-6438
7S-3161	Lifter - Valve	279-4996
7S-6723	Bracket - Alternator	299-1978
7S-8631	Shaft As	275-5296
7T-2036	Cap As - Filter	361-1721
7T-9647	Piston - Clutch	275-5294
7W-0450	Gear - Water Pump	279-4997
7W-0507	Gear - Oil Pump Drive	279-4998
7W-0508	Gear - Fuel Pump Drive	296-1351
7W-3042	Tube As - Drain	325-6231
7Y-1517	Pipe As - Tail	301-5246
8D-1784	Pin	282-6567
8D-2429	Pin As	319-3445
8D-2469	Shaft - Drive	275-5280
8D-3591	Carrier - Planet	301-4769
8D-3744	Shaft - Drive	275-5283
8D-3877	Gear - Sun	275-5278
8D-4766	Pin - Cylinder	365-8832
8D-5344	Gear - Worm	243-0341
8D-7096	Pin - Axle Leaning	297-7219
8D-7174	Cover As	299-1997
8D-7427	Shaft - Drive Pinion	282-6568
8D-9804	Housing - Drive	302-2682
8H-2810	Case As - Filter	314-8512
8J-2022	Piston As - Pump	367-6073
8N-0002	Trunnion As	314-8728
8N-0875	Valve - Exhaust	247-6893 (Valve), 241-3381 (Valve Kit)
8N-1187	Head Gp - Cylinder	242-3435
8N-1188	Head Gp - Cylinder	242-3436
8N-1721	Rod As - Conn	269-5291
8N-1984	Rod As - Conn	242-3441
8N-2510	Shaft	325-6208
8N-2641	Sleeve	325-6210
8N-3182	Body As - Piston	250-6564 (Piston As), 250-6556 (Liner Kits)
8N-3183	Piston Gp - Basic	250-6556 (Liner Kit)
8N-3251	Shaft As - Rocker Arm	314-8711
8N-3311	Shaft As - Rocker Arm	325-6199
8N-3312	Shaft As - Rocker Arm	325-6200
8N-3325	Arm Gp - Rocker	314-8623
8N-3327	Arm Gp - Rocker	314-8624
8N-5305	Spacer	363-7464
8N-5929	Cover - Water Pump	296-1349
8N-6796	Head Gp - Cylinder	269-5290
8N-7315	Tube As - Outlet	325-6232
8N-8225	Bearing - Main	314-8652
8N-9733	Line As - Fuel Injector	319-8174
8P-1656	Plate - Clutch	367-6071
8S-0248	Breather As	325-6033
8S-0493	Shaft As - Pump	325-6198
8S-3970	Chamber As	242-3438
8W-1751	Bracket As	288-8732
8W-1752	Bracket - Rail	288-8733
8W-1753	Bracket - Rail	288-8734
8W-2308	Shaft - Planet	275-5285
8W-4066	Bracket - Rail	288-8735
8W-4067	Bracket - Rail	288-8736
8W-5092	Pinion - Circle Drive	282-6569
8W-5293	Pin	282-6570
8W-6497	Pin	319-3465
8W-8317	Sprocket	275-5287
9D-1177	Shaft - Drive Pinion	297-7253
9D-1487	Housing - Drive	297-7194
9D-4441	Housing	297-7195
9D-6638	Strip - Wear	297-7263
9D-7924	Mounting	360-2356
9D-9665	Bracket - Cylinder Mtg	299-1980
9N-5769	Cover - Housing	325-6050
9P-4859	Cage As - Bearing	297-7151
9P-8452	Hub - Output	297-7206
9P-8455	Cage As - Bearing	297-7152
9P-9742	Cage As - Bearing	297-7153
9S-6129	Pulley - Alternator Drive	264-5891
9S-8679	Chamber As	325-6042
9Y-2992	Bearing - Sleeve	325-6032

Sales Model 140

Original Part Number	Part Name	Classic Part Number
111-8015	Gasket As - Head	279-4977
121-7746	Precleaner As	360-2311
131-3815	Seal Gp - Basic	325-6193
172-5188	Shaft - Water Pump	325-6202
172-6712	Impeller - Pump	325-6112
196-0028	Gear As - Idler	364-5259
1D-3996	Fork - Knuckle	228-9428
1H-8037	Yoke - Fitting	228-9415
1M-7250	Bowl - Precleaner	360-2296
1N-3576	Block Gp - Cylinder	279-4978
1P-4303	Head As - Cylinder	242-3434
1P-8554	Coupling - Exhaust	325-6052
1P-9945	Bracket As - Fan	296-1344
1P-9946	Shaft - Fan	325-6194
1P-9952	Impeller - Pump	314-8685
1S-4701	Pulley - Alt	264-5866
1W-4405	Gear - Crankshaft	279-4982
244-1090	Alarm - Back up	360-2345
2D-1345	Drum - Brake	228-9430
2D-1659	Rack - Shift	228-9431
2D-3188	Yoke	365-8822
2D-3467	Hub - Final Drive Gear	228-9396
2D-3609	Shaft - Final Drive Pinion	228-8919
2D-4010	Adjuster - Bearing	228-8916
2D-4205	Block - Pivot	228-9432
2D-4209	Pin - Pivot	228-9434
2D-4211	Arm - Steering	228-9435
2D-4215	Knuckle - Rh	228-9436
2D-4216	Knuckle - Lh	228-9437
2D-5795	Sleeve - Thrust	243-0360
2D-5799	Pinion - Reverse	243-0342
2D-5961	Pin - Axle Pivot	228-9438
2D-6381	Pinion	228-8915
2D-6382	Gear - Worm	228-9558
2D-7933	Cover - Circle Rev	243-0340
2D-8212	Plate As - Press	229-1582
2F-5721	Bearing - Ball	311-9354
2F-5894	Drum - Brake	228-9439
2F-5969	Collar - Coupling	228-9440
2F-5970	Collar - Coupling	228-9441
2F-6046	Pinion - Reduction	228-9442
2F-6050	Gear - Reduction	229-1584
2F-6051	Gear	229-1585
2F-6053	Gear - Reduction	228-9443
2F-6057	Gear - Reduction	228-9444
2F-8001	Shaft - Worm	228-9445
2F-9047	Block - Pivot	228-9446
2F-9074	Link - Tie Bar	228-9447
2G-4187	Shell - Bearing	245-5794
2P-1170	Shaft As - Gear	296-1367
2P-1738	Plate As - Oil Pan	325-6164
2P-1739	Tube As - Pump	325-6229
2P-1757	Hub - Fan Pulley	296-1357
2P-1781	Spacer - Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2519	Tube As - Inlet	325-6230
2P-2719	Pipe	363-7454
2P-5608	Pipe - Extension	367-6066
2P-5609	Muffler As	247-2665
2P-6128	Pulley	264-5872
2P-6245	Shaft As - Pump	325-6197
2P-7830	Pump Gp	314-8533
2W-1086	Cover As - Cylinder Head	325-6049
2W-2621	Valve - Inlet	247-6892 (Valve), 241-3381 (Valve Kit)
2W-7458	Crankshaft As	242-3439
2W-9978	Core As - Oil Cooler	279-4983
3B-5067	Shaft - Shift Worm	228-8907
3B-6218	Muffler As	247-2672
3B-6695	Gear - Worm	228-9448
3B-9970	Worm	228-8908
3D-0409	Arm - Pitman	228-9397
3D-2136	Sprocket	228-9398
3D-2149	Pinion	228-9450
3D-2236	Sprocket As	228-9399
3D-4443	Shaft - Rev Worm	243-0351
3D-4498	Shaft - Lower	243-0348
3D-4718	Bearing - Sleeve	245-5795
3D-5457	Cage - Bearing	228-9400
3D-6672	Gear	229-1586
3D-9194	Gear	245-5796
3D-9502	Bolt - Draft	243-0332
3D-9786	Ballstud	228-9559
3D-9932	Cage - Bearing	228-9401
3F-0017	Gear - Coupling	229-1587
3F-0018	Gear - Coupling	229-1588
3F-0019	Collar - Coupling	229-1589
3F-6334	End-tie Rod - Rh	228-9451
3F-6338	End-tie Rod - Lh	228-9452
3K-3124	Muffler - Trap	247-2673
3L-1425	Bearing - Ball	311-9356
4B-1455	Cap As - Filter	361-1719
4B-5806	Shaft - Upper	243-0347
4B-7064	Shaft - Worm	245-5803
4D-0913	Arm - Steering	228-9402
4D-0926	Pin	247-4439
4D-0929	Rod End - Tie	228-9403
4D-0930	Rod End - Tie	228-9404
4D-1626	Shaft - Lift Arm	245-5805

(Continued)

Sales Model 140 (Continued)

Original Part Number	Part Name	Classic Part Number
4D-2184	Shaft - Low Pinion	229-1592
4D-2185	Shaft - Rev Idler	229-1593
4D-2198	Cage - Bearing	229-1594
4D-2218	Gear - Coupling	229-1595
4D-2219	Gear - Reverse	229-1597
4D-2220	Pinion - Transmission & Bevel	228-8920
4D-2227	Pinion	228-9453
4D-2229	Cage - Bearing	229-1598
4D-2268	Cover - Shaft	228-9454
4D-3462	Pin - Pivot	247-4440
4D-3898	Gear - Bevel	228-8921
4D-3966	Gear - Reduction	228-8924
4D-4863	Pinion	229-1599
4D-5997	Pinion	245-5809
4D-6664	Coupling - Shaft	243-0338
4D-6665	Shaft - Circle Rev	243-0349
4D-6698	Bearing - Tandem Housing	228-9405
4D-6926	Segment - Control	228-9455
4D-7213	Coupling	228-9406
4D-7282	Shaft - Axle	228-9408
4D-9934	Trunnion	229-1601
4F-4974	Clamp	311-9373
4H-2029	Gear - Reverse	229-1602
4H-7969	Bearing - Worm	245-5811
4N-4864	Pump Gp - Fuel Transfer	242-3442
4N-7693	Crankshaft As	242-3439
4P-0660	Muffler As	298-2787
4P-3546	Valve As - Relief	325-6236
4S-6707	Piston - Clutch	215-1686
4S-8708	Housing - Clutch	216-3557
4S-8718	Cage - Carrier Bearing	217-7724
4W-0452	Seal As - Camshaft	325-6191
5B-0577	Collar	299-1992
5D-0034	Plate - Retainer	228-9456
5D-0395	Bracket - Rail Rh	243-0335
5D-0396	Bracket - Rail Lh	243-0334
5D-0927	Shaft - Reduction	229-1605
5D-3283	Coupling - Shaft	243-0339
5D-3961	Block - Brake	245-5813
5D-4010	Rack	228-8909
5D-6201	Shoe - Yoke	243-0356
5D-6375	Shaft - Final Drive Pinion	228-9409
5D-7339	Coupling	245-5816
5D-7461	Pin	247-4441
5D-7462	Pin	247-4442
5D-9548	Hub - Final Drive Gear	228-9412
5D-9906	Shaft - Axle	228-9413
5D-9972	Shaft	229-1607
5H-0049	Hub - Flywheel	229-1608
5H-0051	Plate - Flywheel	229-1610
5H-0057	Ring - Bearing Thrust	229-1613
5M-6120	Gear - Sun	213-8740
5M-6210	Shaft - Planet	219-9683
5M-6211	Shaft - Planet	219-9684
5M-7841	Gear - Ring	214-0525
5M-7869	Gear - Ring	214-0530
5M-7875	Carrier - Front	213-4495
5M-7900	Bolt - Hex Head	311-9349
5P-7807	Bearing - Ball	314-8502
5S-1211	Cover - Valve	314-8665
5S-4557	Bearing	311-9360
5S-6795	Chamber As	242-3437
5S-7609	Pulley - Alt Drive	264-5881
5S-9062	Spacer	363-7463
5S-9080	Pulley - Alt Drive	264-5883
6B-3158	Shoe - Yoke Lh	243-0357
6B-6911	Worm - Rh	245-5819
6B-6912	Worm - Lh	245-5820
6D-0687	Gear - Bevel	228-8922
6D-0708	Pinion	228-8923
6D-1599	Block - Link Pivot	228-9414
6D-1644	Shaft - Rod Pivot	228-9562
6D-2362	Worm	243-0361
6D-6943	Housing - Axle	228-9416
6D-9193	Hub - Final Drive Gear	228-9417
6D-9294	Shaft	228-9418
6F-5201	Gear - Worm	245-5797
6F-6992	Cap - Ballsocket	297-7160
6G-1633	Chain Gp	282-6565
6G-2947	Shaft	243-0346
6H-3957	Bearing - Ball	311-9358
6I-1346	Pump Gp - Oil	295-5674
6N-1036	Gear - Oil Pump	279-4991
6N-2789	Pulley	264-5886
6N-8413	Housing - Pump	325-6110
7B-5036	Shaft - Bracket	297-7251
7C-4297	Seal As - Camshaft	325-6192
7D-2199	Sleeve As	228-9563
7D-2267	Link As	228-9564
7D-3815	Gear - Final Drive	228-9419
7D-4688	Shaft As - Steering	228-9565
7D-5446	Shaft As - Control Drive	229-1616
7D-5813	Gear - Worm	228-8911
7D-5847	Pinion	228-8912
7D-6516	Pinion - Reverse	243-0343
7D-6524	Shaft - Axle	228-8917
7D-6568	Cover As	228-9457
7D-6588	Worm	243-0362
7D-6841	Joint As - Univ	228-9566
7D-7289	Hub As Brake	229-1617
7D-7386	Shaft	228-9567
7D-7427	Sprocket	228-9458
7D-7442	Hub - Final Drive Gear	228-8918

(Continued)

Sales Model 140 (Continued)

Original Part Number	Part Name	Classic Part Number
7F-6269	Gear - Worm	245-5798
7F-9263	Cap - Pivot	243-0336
7G-2475	Gear - Planet	223-4815
7G-2476	Gear - Planet	223-4816
7G-2513	Gear - Planet	215-1734
7M-2167	Ring - Governor Control	308-9919
7M-4603	Body - Fuel Valve	311-9348
7M-4926	Retainer - Pin	314-8538
7N-0128	Core As - Oil Cooler	299-1994
7N-0165	Core As - Oil Cooler	295-5670
7N-9146	Gear - Flywheel Starter	279-4995
7N-9312	Damper As - Camshaft	299-2005
7N-9805	Pin - Piston	295-6438
7S-3161	Lifter - Valve	279-4996
7S-6723	Bracket - Alternator	299-1978
7S-6902	Gear - Sun	229-1619
7S-6964	Gear - Ring	214-0532
7S-7809	Cap As - Radiator	295-6417
7S-9749	Pulley - Gen Drive	264-5888
7W-0450	Gear - Water Pump	279-4997
7W-0507	Gear - Oil Pump Drive	279-4998
7W-5687	Hub - Camshaft	314-8684
7Y-1517	Pipe As - Tail	301-5246
8D-0527	Gear	229-1621
8D-0682	Shaft	245-5806
8D-0926	Rod As - Tie Lh	228-9422
8D-0994	Rod As - Tie Rh	228-9459
8D-0995	Rod As - Tie Lh	228-9460
8D-1769	Plate - Driving	229-1622
8D-5344	Gear - Worm	243-0341
8D-5346	Shaft - Drive Pinion	243-0350
8F-7422	Gear - Worm	228-9461
8H-9806	Gear - Shaft Drive	325-6091
8M-0874	Plunger As - Valve	311-9439
8M-8623	Gear - Sun	213-8755
8M-8642	Housing - Clutch	219-9669
8M-8644	Housing - Clutch	215-1782
8M-8646	Plate As - Center	216-3583
8M-8650	Piston - Clutch	217-9778
8M-8677	Carrier - Planet	213-4449
8N-0002	Trunnion As	314-8728
8N-0875	Valve - Exhaust	247-6893 (Valve), 241-3381 (Valve Kit)
8N-1187	Head Gp - Cylinder	242-3435
8N-1721	Rod As - Conn	269-5291
8N-1984	Rod As - Conn	242-3441
8N-3180	Body As - Piston	250-6563
8N-3181	Piston Gp - Basic	250-6555 (Liner Kit)
8N-3182	Body As - Piston	250-6564 (Piston As), 250-6556 (Liner Kits)
8N-3183	Piston Gp - Basic	250-6556 (Liner Kit)
8N-3325	Arm Gp - Rocker	314-8623
8N-3327	Arm Gp - Rocker	314-8624
8N-5305	Spacer	363-7464
8N-5929	Cover - Water Pump	296-1349
8N-7315	Tube As - Outlet	325-6232
8N-8225	Bearing - Main	314-8652
8S-0248	Breather As	325-6033
8S-0493	Shaft As - Pump	325-6198
8S-0905	Muffler As	302-2690
8S-3970	Chamber As	242-3438
9D-2716	Spindle - Wheel	228-9463
9D-2731	Spindle - Wheel	228-9423
9H-2256	Pump Gp	311-9443
9M-1500	Shaft - Planet	219-9685
9M-1995	Gear - Sun	213-8756
9M-1996	Shaft - Planet	215-1875
9M-2049	Gear - Ring	214-0533
9M-4789	Shaft - Gov Control	297-7256
9N-5769	Cover - Housing	325-6050
9S-2354	Manifold - Exhaust	261-0888
9S-2355	Manifold - Exhaust	261-0891
9S-6129	Pulley - Alternator Drive	264-5891
9S-8679	Chamber As	325-6042

Sales Model 140B

Original Part Number	Part Name	Classic Part Number
100-7860	Valve - Inlet	270-4360 (Valve), 270-4362 (Valve Kit)
104-4253	Line As - Fuel Injector	279-4988
104-4254	Line As - Fuel Injector	279-4989
111-8015	Gasket As - Head	279-4977
122-9405	Bracket As	325-6005
131-3815	Seal Gp - Basic	325-6193
148-7455	Valve - Exhaust	270-4361
172-5185	Shaft - Water Pump	325-6201
172-5188	Shaft - Water Pump	325-6202
172-5189	Impeller - Pump	295-5687
172-5190	Impeller - Pump	325-6111
172-6712	Impeller - Pump	325-6112
172-7767	Pump Gp - Water	296-1365
196-0028	Gear As - Idler	364-5259
1D-3996	Fork - Knuckle	228-9428
1H-8037	Yoke - Fitting	228-9415
1N-3576	Block Gp - Cylinder	279-4978
1N-3958	Elbow	325-6087
1P-9945	Bracket As - Fan	296-1344
1P-9946	Shaft - Fan	325-6194
1P-9952	Impeller - Pump	314-8685
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1695	Pump Gp	279-4980
1W-1698	Housing - Transfer Pump	296-1356
1W-4402	Gear - Camshaft	279-4981
1W-4405	Gear - Crankshaft	279-4982
1W-5912	Tappet As - Guide	325-6223
1W-6541	Plunger As	325-6173
2D-1345	Drum - Brake	228-9430
2D-1659	Rack - Shift	228-9431
2D-3188	Yoke	365-8822
2D-3609	Shaft - Final Drive Pinion	228-8919
2D-4010	Adjuster - Bearing	228-8916
2D-5795	Sleeve - Thrust	243-0360
2D-5799	Pinion - Reverse	243-0342
2D-5961	Pin - Axle Pivot	228-9438
2D-6381	Pinion	228-8915
2D-6382	Gear - Worm	228-9558
2D-7933	Cover - Circle Rev	243-0340
2D-8212	Plate As - Press	229-1582
2F-5721	Bearing - Ball	311-9354
2F-5894	Drum - Brake	228-9439
2F-5969	Collar - Coupling	228-9440
2F-5970	Collar - Coupling	228-9441
2F-6050	Gear - Reduction	229-1584
2F-6051	Gear	229-1585
2F-8001	Shaft - Worm	228-9445
2G-4187	Shell - Bearing	245-5794
2K-4507	Bearing - Sleeve	325-6021
2K-6413	Pin	360-2270
2P-1170	Shaft As - Gear	296-1367
2P-1738	Plate As - Oil Pan	325-6164
2P-1757	Hub - Fan Pulley	296-1357
2P-1781	Spacer - Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2519	Tube As - Inlet	325-6230
2P-2719	Pipe	363-7454
2P-6128	Pulley	264-5872
2P-6245	Shaft As - Pump	325-6197
2P-7830	Pump Gp	314-8533
2W-1086	Cover As - Cylinder Head	325-6049
2W-2621	Valve - Inlet	247-6892 (Valve), 241-3381 (Valve Kit)
2W-7255	Shaft - Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
3B-5067	Shaft - Shift Worm	228-8907
3B-6695	Gear - Worm	228-9448
3B-9970	Worm	228-8908
3D-0409	Arm - Pitman	228-9397
3D-2149	Pinion	228-9450
3D-4443	Shaft - Rev Worm	243-0351
3D-4498	Shaft - Lower	243-0348
3D-4718	Bearing - Sleeve	245-5795
3D-6672	Gear	229-1586
3D-9194	Gear	245-5796
3D-9502	Bolt - Draft	243-0332
3D-9786	Ballstud	228-9559
3F-0017	Gear - Coupling	229-1587
3F-0018	Gear - Coupling	229-1588
3F-0019	Collar - Coupling	229-1589
3L-1425	Bearing - Ball	311-9356
4B-5806	Shaft - Upper	243-0347
4B-7064	Shaft - Worm	245-5803
4D-0913	Arm - Steering	228-9402
4D-0926	Pin	247-4439
4D-0929	Rod End - Tie	228-9403
4D-0930	Rod End - Tie	228-9404
4D-2184	Shaft - Low Pinion	229-1592
4D-2185	Shaft - Rev Idler	229-1593
4D-2198	Cage - Bearing	229-1594
4D-2218	Gear - Coupling	229-1595
4D-2219	Gear - Reverse	229-1597
4D-2229	Cage - Bearing	229-1598
4D-2268	Cover - Shaft	228-9454
4D-3462	Pin - Pivot	247-4440
4D-3966	Gear - Reduction	228-8924

(Continued)

Sales Model 140B (Continued)

Original Part Number	Part Name	Classic Part Number
4D-4863	Pinion	229-1599
4D-5997	Pinion	245-5809
4D-6664	Coupling - Shaft	243-0338
4D-6665	Shaft - Circle Rev	243-0349
4D-6926	Segment - Control	228-9455
4D-9934	Trunnion	229-1601
4F-4974	Clamp	311-9373
4H-2029	Gear - Reverse	229-1602
4H-7969	Bearing - Worm	245-5811
4K-3004	Bearing - Trunnion Support	314-8632
4K-3128	Bearing - Sleeve	314-8633
4N-2954	Sleeve - Camshaft	299-2059
4N-7693	Crankshaft As	242-3439
4N-8591	Coupling - Exhaust	325-6053
4N-9587	Shield - Heat	297-7260
4P-3546	Valve As - Relief	325-6236
4P-9381	Line As - Fuel Injector	279-4984
4P-9382	Line As - Fuel Injector	279-4985
4P-9385	Line As - Fuel Injector	279-4986
4P-9386	Line As - Fuel Injector	279-4987
5B-0577	Collar	299-1992
5D-0034	Plate - Retainer	228-9456
5D-0395	Bracket - Rail Rh	243-0335
5D-0396	Bracket - Rail Lh	243-0334
5D-0927	Shaft - Reduction	229-1605
5D-3283	Coupling - Shaft	243-0339
5D-3961	Block - Brake	245-5813
5D-4010	Rack	228-8909
5D-6201	Shoe - Yoke	243-0356
5D-7339	Coupling	245-5816
5D-7461	Pin	247-4441
5H-0049	Hub - Flywheel	229-1608
5H-0051	Plate - Flywheel	229-1610
5H-0057	Ring - Bearing Thrust	229-1613
5S-1211	Cover - Valve	314-8665
5S-6795	Chamber As	242-3437
5S-9062	Spacer	363-7463
5T-8500	Shoe - Circle Drive	243-0359
6B-3158	Shoe - Yoke Lh	243-0357
6B-6911	Worm - Rh	245-5819
6B-6912	Worm - Lh	245-5820
6D-0687	Gear - Bevel	228-8922
6D-0708	Pinion	228-8923
6D-1599	Block - Link Pivot	228-9414
6D-1644	Shaft - Rod Pivot	228-9562
6D-2362	Worm	243-0361
6D-6943	Housing - Axle	228-9416
6F-5201	Gear - Worm	245-5797
6F-6992	Cap - Ballsocket	297-7160
6G-2947	Shaft	243-0346
6G-4525	Strip - Wear	282-6624
6H-3957	Bearing - Ball	311-9358
6N-1036	Gear - Oil Pump	279-4991
6N-2789	Pulley	264-5886
6N-8413	Housing - Pump	325-6110
7B-5036	Shaft - Bracket	297-7251
7D-2199	Sleeve As	228-9563
7D-2267	Link As	228-9564
7D-3815	Gear - Final Drive	228-9419
7D-5446	Shaft As - Control Drive	229-1616
7D-5813	Gear - Worm	228-8911
7D-5847	Pinion	228-8912
7D-6516	Pinion - Reverse	243-0343
7D-6524	Shaft - Axle	228-8917
7D-6568	Cover As	228-9457
7D-6588	Worm	243-0362
7D-6841	Joint As - Univ	228-9566
7D-7289	Hub As Brake	229-1617
7D-7442	Hub - Final Drive Gear	228-8918
7F-6269	Gear - Worm	245-5798
7F-9263	Cap - Pivot	243-0336
7N-0128	Core As - Oil Cooler	299-1994
7N-0165	Core As - Oil Cooler	295-5670
7N-2871	Line As - Fuel Injector	319-8172
7N-2872	Line As - Fuel Injector	319-8173
7N-2874	Line As - Fuel Injector	298-2779
7N-2875	Line As - Fuel Injector	298-2780
7N-2876	Line As - Fuel Injector	298-2781
7N-3486	Manifold - Exhaust	261-0899
7N-3515	Gear - Camshaft	314-8669
7N-3536	Gear - Fuel	279-4993
7N-5910	Impeller - Pump	314-8686
7N-9146	Gear - Flywheel Starter	279-4995
7N-9312	Damper As - Camshaft	299-2005
7N-9805	Pin - Piston	295-6438
7S-3161	Lifter - Valve	279-4996
7S-7809	Cap As - Radiator	295-6417
7W-0450	Gear - Water Pump	279-4997
7W-0508	Gear - Fuel Pump Drive	296-1351
7W-3042	Tube As - Drain	325-6231
7W-5687	Hub - Camshaft	314-8684
7Y-1517	Pipe As - Tail	301-5246
8D-0682	Shaft	245-5806
8D-0926	Rod As - Tie Lh	228-9422
8D-1769	Plate - Driving	229-1622
8D-5344	Gear - Worm	243-0341
8D-5346	Shaft - Drive Pinion	243-0350
8F-7422	Gear - Worm	228-9461

(Continued)

Sales Model 140B (Continued)

Original Part Number	Part Name	Classic Part Number
8H-2810	Case As - Filter	314-8512
8N-0002	Trunnion As	314-8728
8N-0875	Valve - Exhaust	247-6893 (Valve), 241-3381 (Valve Kit)
8N-1187	Head Gp - Cylinder	242-3435
8N-1721	Rod As - Conn	269-5291
8N-1984	Rod As - Conn	242-3441
8N-2510	Shaft	325-6208
8N-2641	Sleeve	325-6210

Original Part Number	Part Name	Classic Part Number
8N-3182	Body As - Piston	250-6564 (Piston As), 250-6556 (Liner Kits)
8N-3183	Piston Gp - Basic	250-6556 (Liner Kit)
8N-3251	Shaft As - Rocker Arm	314-8711
8N-3325	Arm Gp - Rocker	314-8623
8N-3327	Arm Gp - Rocker	314-8624
8N-5305	Spacer	363-7464
8N-5929	Cover - Water Pump	296-1349
8N-6796	Head Gp - Cylinder	269-5290

Original Part Number	Part Name	Classic Part Number
8N-7315	Tube As - Outlet	325-6232
8N-8225	Bearing - Main	314-8652
8N-9733	Line As - Fuel Injector	319-8174
8S-0248	Breather As	325-6033
8S-0493	Shaft As - Pump	325-6198
8S-0905	Muffler As	302-2690
8S-3970	Chamber As	242-3438
9D-2716	Spindle - Wheel	228-9463
9N-5769	Cover - Housing	325-6050
9S-2355	Manifold - Exhaust	261-0891
9S-6129	Pulley - Alternator Drive	264-5891
9S-8679	Chamber As	325-6042

Sales Model 140G

Original Part Number	Part Name	Classic Part Number
100-7860	Valve - Inlet	270-4360 (Valve), 270-4362 (Valve Kit)
104-4253	Line As - Fuel Injector	279-4988
104-4254	Line As - Fuel Injector	279-4989
105-3196	Motor Gp - Gerotor	282-6547
106-7131	Shaft	288-8714
109-5562	Shaft	275-5272
110-4652	Housing	302-2683
111-8015	Gasket As - Head	279-4977
112-3249	Muffler As	247-2661
112-5495	Joint Gp - Univ	297-4858
122-9405	Bracket As	325-6005
124-3240	Pin	282-6548
126-7130	Shaft As	275-5300
129-2381	Gear - Planet	275-5274
131-3736	Socket Gp - Basic	325-6211
131-3737	Socket As	282-6626
131-3738	Socket As	282-6627
131-3815	Seal Gp - Basic	325-6193

Original Part Number	Part Name	Classic Part Number
147-3400	Spindle	282-6549
148-7455	Valve - Exhaust	270-4361
153-3580	Shaft	299-2055
170-0560	Rebuild Kit	363-7458
172-5185	Shaft - Water Pump	325-6201
172-5188	Shaft - Water Pump	325-6202
172-5189	Impeller - Pump	295-5687
172-5190	Impeller - Pump	325-6111
172-6712	Impeller - Pump	325-6112
196-0028	Gear As - Idler	364-5259
1N-3576	Block Gp - Cylinder	279-4978
1N-3958	Elbow	325-6087
1P-5480	Cover As - End	299-1998
1P-8554	Coupling - Exhaust	325-6052
1P-9945	Bracket As - Fan	296-1344
1P-9946	Shaft - Fan	325-6194

Original Part Number	Part Name	Classic Part Number
1P-9952	Impeller - Pump	314-8685
1P-9989	Pipe	363-7453
1S-1888	Bracket - Lamp	297-7147
1S-4701	Pulley - Alt	264-5866
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1695	Pump Gp	279-4980
1W-1698	Housing - Transfer Pump	296-1356
1W-4402	Gear - Camshaft	279-4981
1W-4405	Gear - Crankshaft	279-4982
1W-5912	Tappet As - Guide	325-6223
1W-6541	Plunger As	325-6173
236-7724	Retainer	299-2048
244-1090	Alarm - Back up	360-2345
2F-5721	Bearing - Ball	311-9354
2G-2858	Cap - Pivot	243-0345
2G-8238	Yoke As	282-6631
2G-8609	Pin	319-3450
2G-8613	Pin	282-6553
2G-8617	Pin	282-6555

(Continued)

Sales Model 140G (Continued)

Original Part Number	Part Name	Classic Part Number
2G-8621	Pin	282-6557
2G-8625	Pin	282-6558
2G-8629	Pin	282-6560
2G-8633	Pin	282-6561
2G-9098	Cap	300-2573
2K-3592	Boss	314-8501
2K-6413	Pin	360-2270
2P-1170	Shaft As - Gear	296-1367
2P-1738	Plate As - Oil Pan	325-6164
2P-1739	Tube As - Pump	325-6229
2P-1757	Hub - Fan Pulley	296-1357
2P-1781	Spacer - Oil Pump	325-6214
2P-2519	Tube As - Inlet	325-6230
2P-2719	Pipe	363-7454
2P-4435	Plate	275-5295
2P-4510	Piston - Clutch	275-5293
2P-4611	Pipe - Exhaust	365-8821
2P-5608	Pipe - Extension	367-6066
2P-5609	Muffler As	247-2665
2P-6245	Shaft As - Pump	325-6197
2P-9632	Damper As	299-2004
2S-6739	Pulley - Tightener	298-2794
2W-1086	Cover As - Cylinder Head	325-6049
2W-2621	Valve - Inlet	247-6892 (Valve), 241-3381 (Valve Kit)
2W-7255	Shaft - Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear - Water Pump	325-6088
2W-9978	Core As - Oil Cooler	279-4983
312-0782	Worm - Circle Drive	282-6623
3J-6575	Trunnion	297-7265
3L-1425	Bearing - Ball	311-9356
3P-0165	Pulley - Fan Drive	298-2775
3P-0297	Shaft As	275-5297
3P-0307	Cage As - Bearing	300-2572
3P-0324	Coupling	301-0234
3P-0335	Platepress	297-7228
3P-0726	Shaft As	275-5298
3P-0785	Hub As - Clutch	302-2688
3P-3713	Gear As	275-5288
3P-5349	Piston As	275-5292
3P-5359	Piston - Clutch	299-2037
3P-5737	Shaft As - Clutch	275-5273
4B-1455	Cap As - Filter	361-1719
4F-4974	Clamp	311-9373
4K-3004	Bearing - Trunnion Support	314-8632
4N-2954	Sleeve - Camshaft	299-2059
4N-3281	Line As - Fuel Injector	247-3362
4N-3282	Line As - Fuel Injector	247-3363
4N-3283	Line As - Fuel Injector	247-3364
4N-4782	Pulley	325-6176
4N-7693	Crankshaft As	242-3439
4N-8591	Coupling - Exhaust	325-6053
4N-8814	Line As - Fuel Injector	247-3366
4N-9587	Shield - Heat	297-7260
4P-3546	Valve As - Relief	325-6236
4P-9381	Line As - Fuel Injector	279-4984
4P-9382	Line As - Fuel Injector	279-4985
4P-9385	Line As - Fuel Injector	279-4986
4P-9386	Line As - Fuel Injector	279-4987
4S-8472	Hood As	296-1355
4T-0998	Lever	314-8687
4V-0015	Plate - Lock	282-6563
4W-0452	Seal As - Camshaft	325-6191
5B-0577	Collar	299-1992
5D-0470	Valve Gp	314-8549
5K-0871	Pin - Lower	282-6630
5K-0989	Cap - Upper	297-7158
5K-0990	Pin	299-2035
5K-0991	Cap - Lower	319-3433
5P-7807	Bearing - Ball	314-8502
5S-4557	Bearing	311-9360
5S-6795	Chamber As	242-3437
5S-7944	Shaft - Planet	297-7246
5S-7945	Shaft As - Planet	275-5299
5S-9062	Spacer	363-7463
5S-9080	Pulley - Alt Drive	264-5883
5T-0906	Cover	282-6625
5T-1362	Bearing - Spider	325-6011
5T-3475	Shaft	297-7247
5T-6298	Lever	299-2018
5T-8500	Shoe - Circle Drive	243-0359
5T-8501	Shoe - Circle Drive	243-0358
6F-6992	Cap - Ball-socket	297-7160
6G-1633	Chain Gp	282-6565
6G-1664	Adapter	297-7135
6G-1908	Housing As - Drive	297-7198
6G-1919	Cap - Pivot	243-0337
6G-2947	Shaft	243-0346
6G-4525	Strip - Wear	282-6624
6G-8425	Valve Gp - Control	367-6086
6H-3957	Bearing - Ball	311-9358
6I-1346	Pump Gp - Oil	295-5674
6N-1036	Gear - Oil Pump	279-4991
6N-1965	Line As - Fuel Injector	250-7535
6N-1966	Line As - Fuel Injector	250-7536
6N-8413	Housing - Pump	325-6110
6Y-0305	Cage As - Bearing	297-7150
7B-5036	Shaft - Bracket	297-7251
7C-4297	Seal As - Camshaft	325-6192
7D-5861	Adapter	243-0364
7D-6568	Cover As	228-9457
7D-7889	Gear - Ring	275-5276

(Continued)

Sales Model 140G (Continued)

Original Part Number	Part Name	Classic Part Number
7G-3450	Gear - Planet	275-5289
7G-3451	Gear - Planet	297-7188
7G-3452	Gear - Planet	275-5290
7G-3461	Gear - Planet	275-5291
7J-6461	Crown	325-6054
7J-9884	Bearing - Sleeve	325-6016
7K-9348	Pin	252-6872
7N-0128	Core As - Oil Cooler	299-1994
7N-0165	Core As - Oil Cooler	295-5670
7N-2871	Line As - Fuel Injector	319-8172
7N-2872	Line As - Fuel Injector	319-8173
7N-2874	Line As - Fuel Injector	298-2779
7N-2875	Line As - Fuel Injector	298-2780
7N-2876	Line As - Fuel Injector	298-2781
7N-3486	Manifold - Exhaust	261-0899
7N-3515	Gear - Camshaft	314-8669
7N-3536	Gear - Fuel	279-4993
7N-5910	Impeller - Pump	314-8686
7N-9145	Gear - Flywheel	279-4994
7N-9312	Damper As - Camshaft	299-2005
7N-9805	Pin - Piston	295-6438
7S-3161	Lifter - Valve	279-4996
7S-6723	Bracket - Alternator	299-1978
7S-8631	Shaft As	275-5296
7T-2036	Cap As - Filter	361-1721
7T-9647	Piston - Clutch	275-5294
7W-0450	Gear - Water Pump	279-4997
7W-0507	Gear - Oil Pump Drive	279-4998
7W-0508	Gear - Fuel Pump Drive	296-1351
7Y-1517	Pipe As - Tail	301-5246
8D-1784	Pin	282-6567
8D-2429	Pin As	319-3445
8D-2469	Shaft - Drive	275-5280
8D-2532	Carrier - Planet	301-4773
8D-3591	Carrier - Planet	301-4769
8D-3744	Shaft - Drive	275-5283
8D-3877	Gear - Sun	275-5278
8D-4766	Pin - Cylinder	365-8832
8D-5344	Gear - Worm	243-0341
8D-7096	Pin - Axle Leaning	297-7219
8D-7174	Cover As	299-1997
8D-7427	Shaft - Drive Pinion	282-6568
8D-9804	Housing - Drive	302-2682
8H-2810	Case As - Filter	314-8512
8J-2022	Piston As - Pump	367-6073
8N-0002	Trunnion As	314-8728
8N-0875	Valve - Exhaust	247-6893 (Valve), 241-3381 (Valve Kit)
8N-1187	Head Gp - Cylinder	242-3435
8N-1721	Rod As - Conn	269-5291
8N-1984	Rod As - Conn	242-3441
8N-2510	Shaft	325-6208
8N-2641	Sleeve	325-6210
8N-3182	Body As - Piston	250-6564 (Piston As), 250-6556 (Liner Kits)
8N-3183	Piston Gp - Basic	250-6556 (Liner Kit)
8N-3251	Shaft As - Rocker Arm	314-8711
8N-3325	Arm Gp - Rocker	314-8623
8N-3327	Arm Gp - Rocker	314-8624
8N-5305	Spacer	363-7464
8N-5929	Cover - Water Pump	296-1349
8N-6796	Head Gp - Cylinder	269-5290
8N-7315	Tube As - Outlet	325-6232
8N-7780	Shield - Oil	314-8544
8N-8225	Bearing - Main	314-8652
8N-9733	Line As - Fuel Injector	319-8174
8P-1656	Plate - Clutch	367-6071
8S-0248	Breather As	325-6033
8S-0493	Shaft As - Pump	325-6198
8S-3970	Chamber As	242-3438
8S-7716	Manifold - Exhaust	295-0415
8S-7718	Manifold - Exhaust	295-0416
8W-1751	Bracket As	288-8732
8W-1752	Bracket - Rail	288-8733
8W-1753	Bracket - Rail	288-8734
8W-2308	Shaft - Planet	275-5285
8W-4066	Bracket - Rail	288-8735
8W-4067	Bracket - Rail	288-8736
8W-5092	Pinion - Circle Drive	282-6569
8W-5293	Pin	282-6570
8W-6497	Pin	319-3465
8W-8317	Sprocket	275-5287
9D-4441	Housing	297-7195
9D-6638	Strip - Wear	297-7263
9D-7924	Mounting	360-2356
9D-9665	Bracket - Cylinder Mtg	299-1980
9N-5769	Cover - Housing	325-6050
9P-4859	Cage As - Bearing	297-7151
9P-8452	Hub - Output	297-7206
9P-8455	Cage As - Bearing	297-7152
9P-9742	Cage As - Bearing	297-7153
9S-2354	Manifold - Exhaust	261-0888
9S-2355	Manifold - Exhaust	261-0891
9S-6129	Pulley - Alternator Drive	264-5891
9S-8679	Chamber As	325-6042

Cat® Classic™ Parts for Pipelayers

Cat® pipelayers are built to be heavy, strong, and durable. They are built to last many years. As the machines age, owning and operating costs are often re-evaluated. To help you manage these costs, Caterpillar offers Classic parts for several models of pipelayers. Cat® Classic™ parts are a repair option targeted at the end of the product life cycle when lower cost options are more desired.

Cat Classic parts provide owners of older Cat products with low cost repair alternatives that minimize the risk associated with non-genuine parts.

Cat Classic parts coverage for pipelayers includes:

- Engine
- Final Drive
- Flywheel Clutch
- Moving Undercarriage
- Non-Moving Undercarriage
- Steering
- Transmission
- ...and many more.

Sales Model 561B

Original Part Number	Part Name	Classic Part Number
121-7746	Precleaner As	360-2311
190-8609	Valve - Fill	360-2288
1A-2846	Cap As - Filler	311-9368
1H-8262	Shaft	226-8016
1H-8382	Gear - Oil Pump Drive	226-6103
1H-8937	Drumbrake	226-7993
1H-8938	Lever	226-8028
1M-0176	Flange - Drum	223-4810
1M-5165	Pinion - Final Drive	231-8766
1M-6128	Manifold - Exhaust	261-0906
1M-7250	Bowl - Precleaner	360-2296
1M-9177	Flywheel	226-6112
1P-1931	Shaft - Steer	227-4772
1P-7044	Cage	226-7975
1S-1888	Bracket - Lamp	297-7147
1S-5315	Cap As - Brace Bearing	226-4848
1S-6422	Pilot As - Spring	226-4849
1S-8764	Ring - Flywheel Clutch Adjustable	226-8014
1W-4405	Gear - Crankshaft	279-4982
2F-7576	Shaft - Sprocket	226-6071
2H-4338	Plate - Pressure	226-8010
2H-4450	Washer - Thrust	325-6237
2H-4482	Collar	229-8218
2H-5046	Link - Flycam	299-2024
2M-2290	Bracket - Ring	299-1979
2P-7622	Bolt - Spring	226-4850
2P-9660	Gear - Final Drive	226-5995
2S-1477	Holder As - Cage	226-7985
2S-4015	Plunger As - Valve	311-9438
3B-6218	Muffler As	247-2672
3F-1956	Cap - Frame Sup	226-7987
3F-1972	Retainer As	226-7988
3H-3378	Gear As - Pump	298-2795
3K-3124	Muffler - Trap	247-2673
3L-1425	Bearing - Ball	311-9356
3P-3623	Lock - Adjustable Nut	226-7989
3P-5754	Hub - Gear	219-2976
3S-0311	Rod Gp	226-4953
3S-7153	Gear - Sliding	227-0024
3S-8800	Gear - Driven	325-6090
4F-4974	Clamp	311-9373
4H-4021	Plate As - Loading	229-8219
4H-9040	Nut	226-7996
4K-4780	Strip As - Wear	299-2063
4S-8005	Pinion - Final Drive	226-6076
5A-9551	Gear - Final Drive	226-7979
5F-0689	Pin	256-4821
5F-2256	Cage - Bearing	226-7973
5H-5500	Collar - Flywheel	302-2704
5M-5244	Hub - Gear	219-2982
5P-7807	Bearing - Ball	314-8502
5S-0726	Hub As - Sprocket	227-4769
5S-1211	Cover - Valve	314-8665
5S-1822	Chamber As	248-5406
5S-1833	Chamber As	247-3298
6B-7178	Fork - Band Adjustable	299-2009
6P-0169	Hub - Flywheel Clutch	297-7204
7B-2420	Ferrule - Director	314-8517
7B-5088	Drum - Steering	223-4813
7F-9547	Pin As - Drawbar	295-0414
7G-6044	Cage As	216-7857
7H-1318	Coupling - Steering	226-8002

(Continued)

Sales Model 561B (Continued)

Original Part Number	Part Name	Classic Part Number
7H-2424	Sleeve - Spring	226-4852
7M-0820	Gear - Sliding	226-6086
7M-2167	Ring - Governor Control	308-9919
7M-4603	Body - Fuel Valve	311-9348
7M-5002	Drum - Steering	226-7992
7M-5050	Collar - Front Idler	226-4958
7M-7358	Valve - Inlet	298-2774
7M-9398	Plate - Guide	297-7230
7N-0128	Core As - Oil Cooler	299-1994
7N-2957	Cover - Rad Cap	361-1722
7S-6531	Guard As - Rh	226-4939
7S-6532	Guard As - Lh	226-4940
7S-6537	Guard As - Rh Basic	226-4941
7S-6538	Guard As - Lh Basic	226-4942
7S-7602	Pump Gp	226-0174
7S-7625	Support As	226-6095
7S-7809	Cap As - Radiator	295-6417
7S-8213	Guard As - Final Drive Wear	226-4943
7S-8214	Guard As - Final Drive Wear	226-4944
7S-9749	Pulley - Gen Drive	264-5888
7T-0203	Guide	226-4959
7T-0206	Bearing - Brace	297-7144
7T-2036	Cap As - Filter	361-1721
8B-5972	Bearing - Ball	314-8503
8H-9379	Nut - Brake Band Adjustable	299-2029
8H-9806	Gear - Shaft Drive	325-6091
8M-3224	Muffler	247-2676
8M-6676	Cylinder - Adjustable	226-4960
8N-8225	Bearing - Main	314-8652
8P-1182	Shaft	227-4771
8P-1183	Gear - Bevel	226-7980
8S-5722	Plate - Pressure	226-8009
9F-7101	Bushing - Collar	299-1988
9G-8302	Guide	226-4853
9H-2256	Pump Gp	311-9443
9H-4104	Pilot - Spring	226-4962
9H-7670	Piston	226-4961
9M-4163	Valve - Exhaust	298-2773
9M-4955	Pump Gp - Fuel Transfer	242-3443
9M-8117	Shaft - Flywheel Clutch	226-6073
9M-8119	Retainer - Inlet	226-8022
9S-3321	Cage - Pinion Bearing	226-7974

Sales Model 561C

Original Part Number	Part Name	Classic Part Number
111-8015	Gasket As - Head	279-4977
121-7746	Precleaner As	360-2311
131-3815	Seal Gp - Basic	325-6193
172-5185	Shaft - Water Pump	325-6201
172-5188	Shaft - Water Pump	325-6202
172-5189	Impeller - Pump	295-5687
172-5190	Impeller - Pump	325-6111
172-6712	Impeller - Pump	325-6112
172-7767	Pump Gp - Water	296-1365
190-8609	Valve - Fill	360-2288
196-0028	Gear As - Idler	364-5259
1A-2846	Cap As - Filler	311-9368
1H-8382	Gear - Oil Pump Drive	226-6103
1H-8937	Drumbrake	226-7993
1M-0176	Flange - Drum	223-4810
1M-5270	Pipe - Extension	367-6065
1M-6128	Manifold - Exhaust	261-0906
1M-7250	Bowl - Precleaner	360-2296
1M-9177	Flywheel	226-6112
1N-3576	Block Gp - Cylinder	279-4978
1N-3958	Elbow	325-6087
1P-1636	Lever As	226-8013
1P-1931	Shaft - Steer	227-4772
1P-4303	Head As - Cylinder	242-3434
1P-7044	Cage	226-7975
1P-9945	Bracket As - Fan	296-1344
1P-9946	Shaft - Fan	325-6194
1P-9952	Impeller - Pump	314-8685
1S-1888	Bracket - Lamp	297-7147
1S-4701	Pulley - Alt	264-5866
1S-6422	Pilot As - Spring	226-4849
1S-8734	Bracket - Roller	226-0212
1S-8764	Ring - Flywheel Clutch Adjustable	226-8014
1W-1219	Trunnion As	314-8724
1W-4402	Gear - Camshaft	279-4981
1W-4405	Gear - Crankshaft	279-4982
244-1090	Alarm - Back up	360-2345
2F-5721	Bearing - Ball	311-9354
2F-7576	Shaft - Sprocket	226-6071
2H-4338	Plate - Pressure	226-8010
2H-4450	Washer - Thrust	325-6237
2H-4482	Collar	229-8218
2H-5046	Link - Flycam	299-2024

(Continued)

Sales Model 561C (Continued)

Original Part Number	Part Name	Classic Part Number
2M-2290	Bracket - Ring	299-1979
2P-1170	Shaft As - Gear	296-1367
2P-1738	Plate As - Oil Pan	325-6164
2P-1739	Tube As - Pump	325-6229
2P-1757	Hub - Fan Pulley	296-1357
2P-1781	Spacer - Oil Pump	325-6214
2P-2519	Tube As - Inlet	325-6230
2P-6245	Shaft As - Pump	325-6197
2P-7622	Bolt - Spring	226-4850
2P-9667	Cage - Shaft Bearing	226-7971
2S-1477	Holder As - Cage	226-7985
2S-4015	Plunger As - Valve	311-9438
2W-1086	Cover As - Cylinder Head	325-6049
2W-2621	Valve - Inlet	247-6892 (Valve), 241-3381 (Valve Kit)
2W-7255	Shaft - Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
3B-6218	Muffler As	247-2672
3F-1956	Cap - Frame Sup	226-7987
3F-1972	Retainer As	226-7988
3H-3378	Gear As - Pump	298-2795
3K-3124	Muffler - Trap	247-2673
3L-1425	Bearing - Ball	311-9356
3P-3623	Lock - Adjustable Nut	226-7989
3P-5754	Hub - Gear	219-2976
3P-5755	Extension - Final Drive	226-7990
3S-0311	Rod Gp	226-4953
3S-7153	Gear - Sliding	227-0024
3S-7504	Gear - Idler	226-6084
4F-4974	Clamp	311-9373
4H-4021	Plate As - Loading	229-8219
4H-9040	Nut	226-7996
4K-4780	Strip As - Wear	299-2063
4N-2954	Sleeve - Camshaft	299-2059
4N-3281	Line As - Fuel Injector	247-3362
4N-3282	Line As - Fuel Injector	247-3363
4N-3283	Line As - Fuel Injector	247-3364
4N-3284	Line As - Fuel Injector	247-3365
4N-4864	Pump Gp - Fuel Transfer	242-3442
4N-7693	Crankshaft As	242-3439
4N-7982	Pulley	264-5880
4N-8814	Line As - Fuel Injector	247-3366
4N-9587	Shield - Heat	297-7260
4P-0660	Muffler As	298-2787
4P-3546	Valve As - Relief	325-6236
4S-6189	Pinion - Reverse	226-6077
4S-6190	Pinion - Forward	226-6078
4S-8005	Pinion - Final Drive	226-6076
4W-0452	Seal As - Camshaft	325-6191
5A-9551	Gear - Final Drive	226-7979
5F-2256	Cage - Bearing	226-7973
5G-3612	Cap Gp	295-6419
5H-5500	Collar - Flywheel	302-2704
5M-7342	Flange - Shaft	215-1696
5P-7807	Bearing - Ball	314-8502
5S-0726	Hub As - Sprocket	227-4769
5S-1211	Cover - Valve	314-8665
5S-1822	Chamber As	248-5406
5S-1833	Chamber As	247-3298
5S-4557	Bearing	311-9360
5S-6795	Chamber As	242-3437
5S-7609	Pulley - Alt Drive	264-5881
5S-8767	Gear - First	226-6085
5S-9062	Spacer	363-7463
5S-9080	Pulley - Alt Drive	264-5883
6B-7178	Fork - Band Adjustable	299-2009
6H-3957	Bearing - Ball	311-9358
6I-1346	Pump Gp - Oil	295-5674
6N-1036	Gear - Oil Pump	279-4991
6N-1965	Line As - Fuel Injector	250-7535
6N-1966	Line As - Fuel Injector	250-7536
6N-8413	Housing - Pump	325-6110
6P-0169	Hub - Flywheel Clutch	297-7204
6T-6053	Pinion - Shaft & Gear	226-6079
7B-2420	Ferrule - Director	314-8517
7B-5088	Drum - Steering	223-4813
7C-4297	Seal As - Camshaft	325-6192
7F-9547	Pin As - Drawbar	295-0414
7G-2037	Joint Gp - Univ	226-8017
7G-2038	Tube - Univ Joint	297-7268
7G-3815	Pump Gp	226-0171
7G-6044	Cage As	216-7857
7H-1318	Coupling - Steering	226-8002
7H-2424	Sleeve - Spring	226-4852
7M-0820	Gear - Sliding	226-6086
7M-2167	Ring - Governor Control	308-9919
7M-4204	Manifold - Exhaust	261-0901
7M-4603	Body - Fuel Valve	311-9348
7M-5002	Drum - Steering	226-7992
7M-5050	Collar - Front Idler	226-4958
7M-7358	Valve - Inlet	298-2774
7M-9398	Plate - Guide	297-7230
7N-0128	Core As - Oil Cooler	299-1994
7N-0165	Core As - Oil Cooler	295-5670
7N-2871	Line As - Fuel Injector	319-8172

(Continued)

Sales Model 561C (Continued)

Original Part Number	Part Name	Classic Part Number
7N-2872	Line As - Fuel Injector	319-8173
7N-2874	Line As - Fuel Injector	298-2779
7N-2875	Line As - Fuel Injector	298-2780
7N-2876	Line As - Fuel Injector	298-2781
7N-2957	Cover - Rad Cap	361-1722
7N-3515	Gear - Camshaft	314-8669
7N-3536	Gear - Fuel	279-4993
7N-5910	Impeller - Pump	314-8686
7N-9146	Gear - Flywheel Starter	279-4995
7N-9805	Pin - Piston	295-6438
7S-3161	Lifter - Valve	279-4996
7S-6531	Guard As - Rh	226-4939
7S-6532	Guard As - Lh	226-4940
7S-6537	Guard As - Rh Basic	226-4941
7S-6538	Guard As - Lh Basic	226-4942
7S-6723	Bracket - Alternator	299-1978
7S-7625	Support As	226-6095
7S-7809	Cap As - Radiator	295-6417
7S-8213	Guard As - Final Drive Wear	226-4943
7S-8214	Guard As - Final Drive Wear	226-4944
7S-9749	Pulley - Gen Drive	264-5888
7T-0203	Guide	226-4959
7T-2036	Cap As - Filter	361-1721
7W-0450	Gear - Water Pump	279-4997
7W-0507	Gear - Oil Pump Drive	279-4998
7W-0508	Gear - Fuel Pump Drive	296-1351
8B-5972	Bearing - Ball	314-8503
8H-9379	Nut - Brake Band Adjustable	299-2029
8H-9806	Gear - Shaft Drive	325-6091
8K-5587	Rod Gp - Recoil	226-4954
8M-0874	Plunger As - Valve	311-9439
8M-3224	Muffler	247-2676
8M-6676	Cylinder - Adjustable	226-4960
8M-7166	Housing - Screen	297-7192
8N-0002	Trunnion As	314-8728
8N-0875	Valve - Exhaust	247-6893 (Valve), 241-3381 (Valve Kit)
8N-1187	Head Gp - Cylinder	242-3435
8N-1721	Rod As - Conn	269-5291
8N-1984	Rod As - Conn	242-3441
8N-3180	Body As - Piston	250-6563
8N-3181	Piston Gp - Basic	250-6555 (Liner Kit)
8N-3182	Body As - Piston	250-6564 (Piston As), 250-6556 (Liner Kits)
8N-3183	Piston Gp - Basic	250-6556 (Liner Kit)
8N-3251	Shaft As - Rocker Arm	314-8711
8N-3325	Arm Gp - Rocker	314-8623
8N-3327	Arm Gp - Rocker	314-8624
8N-5305	Spacer	363-7464
8N-5929	Cover - Water Pump	296-1349
8N-7315	Tube As - Outlet	325-6232
8N-7780	Shield - Oil	314-8544
8N-8225	Bearing - Main	314-8652
8N-9733	Line As - Fuel Injector	319-8174
8P-1182	Shaft	227-4771
8P-1183	Gear - Bevel	226-7980
8P-1853	Nut - Adjusting	226-7997
8P-1855	Hub As - Sprocket	227-4770
8S-0248	Breather As	325-6033
8S-0493	Shaft As - Pump	325-6198
8S-1831	Guard As - Sprocket	226-4947
8S-1832	Guard As - Sprocket	226-4948
8S-2140	Trunnion - Gear	226-8020
8S-3970	Chamber As	242-3438
8S-5722	Plate - Pressure	226-8009
9F-7101	Bushing - Collar	299-1988
9G-8302	Guide	226-4853
9H-2256	Pump Gp	311-9443
9H-4104	Pilot - Spring	226-4962
9H-7670	Piston	226-4961
9M-4163	Valve - Exhaust	298-2773
9M-4789	Shaft - Gov Control	297-7256
9M-4955	Pump Gp - Fuel Transfer	242-3443
9M-8117	Shaft - Flywheel Clutch	226-6073
9M-8119	Retainer - Inlet	226-8022
9N-5769	Cover - Housing	325-6050
9S-2355	Manifold - Exhaust	261-0891
9S-3321	Cage - Pinion Bearing	226-7974
9S-8245	Strip - Track	226-0243
9S-8246	Strip - Track	226-0244
9S-8257	Guard As - Guiding	226-0238
9S-8258	Guard As - Guiding	226-0239
9S-8353	Strip - Track	226-4854
9S-8354	Strip - Track	226-4855
9S-8358	Guard As - Guiding	226-4856
9S-8359	Guard As - Guiding	226-4857
9S-8679	Chamber As	325-6042

Sales Model 561D

Original Part Number	Part Name	Classic Part Number
100-7860	Valve - Inlet	270-4360 (Valve), 270-4362 (Valve Kit)
111-8015	Gasket As - Head	279-4977
121-7746	Precleaner As	360-2311
131-3815	Seal Gp - Basic	325-6193
148-7455	Valve - Exhaust	270-4361
165-4262	Body As - Piston	270-4351
172-5185	Shaft - Water Pump	325-6201
172-5188	Shaft - Water Pump	325-6202
172-5189	Impeller - Pump	295-5687
172-5190	Impeller - Pump	325-6111
172-6712	Impeller - Pump	325-6112
172-7767	Pump Gp - Water	296-1365
190-8609	Valve - Fill	360-2288
196-0028	Gear As - Idler	364-5259
1M-7250	Bowl - Precleaner	360-2296
1M-9444	Retainer - Spring	299-2046
1N-3576	Block Gp - Cylinder	279-4978
1N-3958	Elbow	325-6087
1P-9945	Bracket As - Fan	296-1344
1P-9946	Shaft - Fan	325-6194
1P-9952	Impeller - Pump	314-8685
1S-1888	Bracket - Lamp	297-7147
1S-4701	Pulley - Alt	264-5866
1S-6422	Pilot As - Spring	226-4849
1T-0521	Retainer - Bearing	325-6180
1T-1350	Torque Converter	235-0912 (Repair Kit)
1T-1993	Wheel - Turbine	235-0920
1T-2052	Stator As	295-5683
1W-1219	Trunnion As	314-8724
1W-4402	Gear - Camshaft	279-4981
1W-4405	Gear - Crankshaft	279-4982
244-1090	Alarm - Back up	360-2345
2F-5721	Bearing - Ball	311-9354
2F-7576	Shaft - Sprocket	226-6071
2P-1170	Shaft As - Gear	296-1367
2P-1738	Plate As - Oil Pan	325-6164
2P-1739	Tube As - Pump	325-6229
2P-1757	Hub - Fan Pulley	296-1357
2P-1781	Spacer - Oil Pump	325-6214
2P-2519	Tube As - Inlet	325-6230
2P-6245	Shaft As - Pump	325-6197
2P-7622	Bolt - Spring	226-4850
2P-9660	Gear - Final Drive	226-5995
2P-9672	Cage - Pinion Bearing	226-7972
2S-1477	Holder As - Cage	226-7985
2W-1086	Cover As - Cylinder Head	325-6049
2W-2621	Valve - Inlet	247-6892 (Valve), 241-3381 (Valve Kit)
2W-7255	Shaft - Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-9978	Core As - Oil Cooler	279-4983
3F-1956	Cap - Frame Sup	226-7987
3F-1972	Retainer As	226-7988
3L-1425	Bearing - Ball	311-9356
3P-3623	Lock - Adjustable Nut	226-7989
3P-5754	Hub - Gear	219-2976
3P-5755	Extension - Final Drive	226-7990
3S-0311	Rod Gp	226-4953
3S-1167	Gear - Planet	221-9101
3S-2712	Gear - Transfer	226-7977
3T-1900	Drum	226-7991
4F-4974	Clamp	311-9373
4H-9040	Nut	226-7996
4K-4780	Strip As - Wear	299-2063
4N-2954	Sleeve - Camshaft	299-2059
4N-3281	Line As - Fuel Injector	247-3362
4N-3282	Line As - Fuel Injector	247-3363
4N-3283	Line As - Fuel Injector	247-3364
4N-3284	Line As - Fuel Injector	247-3365
4N-4864	Pump Gp - Fuel Transfer	242-3442
4N-7693	Crankshaft As	242-3439
4N-7982	Pulley	264-5880
4N-8814	Line As - Fuel Injector	247-3366
4N-9587	Shield - Heat	297-7260
4P-0660	Muffler As	298-2787
4P-3546	Valve As - Relief	325-6236
4S-5943	Piston - Clutch	221-9112
4S-5944	Gear - Sun	221-9078
4S-5945	Gear - Sun	221-9079
4S-5947	Gear - Ring	221-9080
4S-5948	Gear - Ring	221-9082
4S-5979	Carrier As	216-7843
4S-5981	Gear - Ring	221-9084
4S-8530	Shaft - Planet	221-9111
4S-8534	Shaft As - Planet	221-9116
4S-8716	Gear - Transfer	226-7978
4W-0452	Seal As - Camshaft	325-6191
5A-6897	Guard - Idler Rh	226-4951
5A-6898	Guard - Idler Lh	226-4952
5A-9551	Gear - Final Drive	226-7979
5P-7807	Bearing - Ball	314-8502
5S-0726	Hub As - Sprocket	227-4769

(Continued)

Sales Model 561D (Continued)

Original Part Number	Part Name	Classic Part Number
5S-4493	Carrier - Planet	223-6321
5S-6795	Chamber As	242-3437
5S-6972	Gear - Sun	221-9087
5S-6978	Shaft - Planet	221-9103
5S-7009	Plate As - End	226-4957
5S-7010	Shaft - Planet	221-9104
5S-7013	Gear - Ring	221-9088
5S-7023	Carrier - Planet	226-5986
5S-7609	Pulley - Alt Drive	264-5881
5S-9062	Spacer	363-7463
5S-9080	Pulley - Alt Drive	264-5883
6H-3957	Bearing - Ball	311-9358
6I-1346	Pump Gp - Oil	295-5674
6N-1036	Gear - Oil Pump	279-4991
6N-1965	Line As - Fuel Injector	250-7535
6N-1966	Line As - Fuel Injector	250-7536
6N-8413	Housing - Pump	325-6110
6T-0443	Pinion - Shaft & Bevel	226-7999
7F-9547	Pin As - Drawbar	295-0414
7G-2477	Gear - Planet	221-9090
7G-2487	Gear - Planet	221-9092
7G-2520	Gear - Planet	221-9094
7G-6044	Cage As	216-7857
7G-8459	Hub - Gear	221-1070
7H-2424	Sleeve - Spring	226-4852
7M-2167	Ring - Governor Control	308-9919
7M-5050	Collar - Front Idler	226-4958
7M-9398	Plate - Guide	297-7230
7N-0128	Core As - Oil Cooler	299-1994
7N-0165	Core As - Oil Cooler	295-5670
7N-2871	Line As - Fuel Injector	319-8172
7N-2872	Line As - Fuel Injector	319-8173
7N-2874	Line As - Fuel Injector	298-2779
7N-2875	Line As - Fuel Injector	298-2780
7N-2876	Line As - Fuel Injector	298-2781
7N-3515	Gear - Camshaft	314-8669
7N-3536	Gear - Fuel	279-4993
7N-5910	Impeller - Pump	314-8686
7N-9146	Gear - Flywheel Starter	279-4995
7N-9805	Pin - Piston	295-6438
7S-3161	Lifter - Valve	279-4996
7S-6531	Guard As - Rh	226-4939
7S-6532	Guard As - Lh	226-4940
7S-6537	Guard As - Rh Basic	226-4941
7S-6538	Guard As - Lh Basic	226-4942
7S-6723	Bracket - Alternator	299-1978
7S-7625	Support As	226-6095
7S-7809	Cap As - Radiator	295-6417
7S-8213	Guard As - Final Drive Wear	226-4943
7S-8214	Guard As - Final Drive Wear	226-4944
7S-8572	Gear - Ring	221-9095
7S-8660	Pump Gp - Transmission	226-0175
7T-0203	Guide	226-4959
7T-2036	Cap As - Filter	361-1721
7W-0450	Gear - Water Pump	279-4997
7W-0507	Gear - Oil Pump Drive	279-4998
7W-0508	Gear - Fuel Pump Drive	296-1351
8B-5972	Bearing - Ball	314-8503
8H-2810	Case As - Filter	314-8512
8H-9806	Gear - Shaft Drive	325-6091
8K-5587	Rod Gp - Recoil	226-4954
8M-0874	Plunger As - Valve	311-9439
8M-6676	Cylinder - Adjustable	226-4960
8M-7166	Housing - Screen	297-7192
8N-0002	Trunnion As	314-8728
8N-0875	Valve - Exhaust	247-6893 (Valve), 241-3381 (Valve Kit)
8N-1187	Head Gp - Cylinder	242-3435
8N-1721	Rod As - Conn	269-5291
8N-1984	Rod As - Conn	242-3441
8N-3180	Body As - Piston	250-6563
8N-3181	Piston Gp - Basic	250-6555 (Liner Kit)
8N-3251	Shaft As - Rocker Arm	314-8711
8N-3325	Arm Gp - Rocker	314-8623
8N-3327	Arm Gp - Rocker	314-8624
8N-5305	Spacer	363-7464
8N-5929	Cover - Water Pump	296-1349
8N-6796	Head Gp - Cylinder	269-5290
8N-7315	Tube As - Outlet	325-6232
8N-7780	Shield - Oil	314-8544
8N-8225	Bearing - Main	314-8652
8N-9733	Line As - Fuel Injector	319-8174
8P-0203	Drum	226-8004
8P-1182	Shaft	227-4771
8P-1183	Gear - Bevel	226-7980
8P-1324	Cage - Gr Shft Bearing	229-8239
8P-1325	Hub - Steering	226-8005
8P-1326	Pilot - Piston	226-6097
8P-1327	Pinion - Final Drive	226-8000
8P-1328	Flange - Drive Drum	226-8006
8P-1353	Piston - Steering	226-8007
8P-1656	Plate - Clutch	367-6071
8P-1774	Pinion - Final Drive	226-8001

(Continued)

Sales Model 561D (Continued)

Original Part Number	Part Name	Classic Part Number
8P-1853	Nut - Adjusting	226-7997
8P-1855	Hub As - Sprocket	227-4770
8P-2430	Shaft As	297-7258
8P-8570	Pilot As - Piston	226-6097
8S-0248	Breather As	325-6033
8S-0493	Shaft As - Pump	325-6198
8S-0556	Coupling	221-9114
8S-1831	Guard As - Sprocket	226-4947
8S-1832	Guard As - Sprocket	226-4948
8S-3970	Chamber As	242-3438
9G-8302	Guide	226-4853
9H-2256	Pump Gp	311-9443
9H-4104	Pilot - Spring	226-4962
9H-7670	Piston	226-4961
9K-8757	Rod End - Bearing	311-9361
9M-2049	Gear - Ring	214-0533
9M-4789	Shaft - Gov Control	297-7256
9M-8281	Gear As - Oil Pump	325-6089
9N-5769	Cover - Housing	325-6050
9S-2355	Manifold - Exhaust	261-0891
9S-3321	Cage - Pinion Bearing	226-7974
9S-8258	Guard As - Guiding	226-0239
9S-8358	Guard As - Guiding	226-4856
9S-8359	Guard As - Guiding	226-4857
9S-8679	Chamber As	325-6042

Sales Model 561H

Original Part Number	Part Name	Classic Part Number
100-7860	Valve - Inlet	270-4360 (Valve), 270-4362 (Valve Kit)
104-4253	Line As - Fuel Injector	279-4988
104-4254	Line As - Fuel Injector	279-4989
111-8015	Gasket As - Head	279-4977
121-7746	Precleaner As	360-2311
131-3815	Seal Gp - Basic	325-6193
148-7455	Valve - Exhaust	270-4361
172-5185	Shaft - Water Pump	325-6201
172-5188	Shaft - Water Pump	325-6202
172-5189	Impeller - Pump	295-5687
172-5190	Impeller - Pump	325-6111
172-6712	Impeller - Pump	325-6112
172-7767	Pump Gp - Water	296-1365
190-8609	Valve - Fill	360-2288
196-0028	Gear As - Idler	364-5259
1M-7250	Bowl - Precleaner	360-2296
1N-3576	Block Gp - Cylinder	279-4978
1N-3958	Elbow	325-6087
1N-4304	Head Gp - Cylinder	269-8761
1P-1216	Manifold - Exhaust	261-0902
1P-1721	Gear - Balance	298-2769
1P-1722	Gear - Balance	298-2770
1P-9945	Bracket As - Fan	296-1344
1P-9946	Shaft - Fan	325-6194
1S-4701	Pulley - Alt	264-5866
1T-0020	Wheel - Turbine	297-4862
1T-1428	Retainer - Bearing	300-2587
1T-1691	Impeller - Converter	297-4863
1T-1987	Housing - Rotating	297-4864
1W-1669	Piston	325-6158
1W-1695	Pump Gp	279-4980
1W-1698	Housing - Transfer Pump	296-1356
1W-2870	Shaft As - Balance	314-8715
1W-2871	Shaft As - Balance	314-8716
1W-4402	Gear - Camshaft	279-4981
1W-4405	Gear - Crankshaft	279-4982
1W-4407	Hub - Fan Pulley	296-1358
1W-5912	Tappet As - Guide	325-6223
1W-6541	Plunger As	325-6173
244-1090	Alarm - Back up	360-2345
2F-5721	Bearing - Ball	311-9354
2P-1170	Shaft As - Gear	296-1367
2P-1757	Hub - Fan Pulley	296-1357
2P-1781	Spacer - Oil Pump	325-6214
2P-2519	Tube As - Inlet	325-6230
2P-6245	Shaft As - Pump	325-6197
2P-7828	Pan - Oil	314-8691
2W-1086	Cover As - Cylinder Head	325-6049
2W-2621	Valve - Inlet	247-6892 (Valve), 241-3381 (Valve Kit)
2W-7255	Shaft - Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
3L-1425	Bearing - Ball	311-9356
3T-3447	Gear As - Sun	302-2676
3T-6795	Piston - Clutch	281-1693

(Continued)

Sales Model 561H (Continued)

Original Part Number	Part Name	Classic Part Number
4F-4974	Clamp	311-9373
4N-4782	Pulley	325-6176
4N-7692	Crankshaft As	242-3440
4N-7693	Crankshaft As	242-3439
4P-3546	Valve As - Relief	325-6236
4P-9381	Line As - Fuel Injector	279-4984
4P-9382	Line As - Fuel Injector	279-4985
4P-9961	Line As - Fuel Injector	325-6115
4P-9962	Line As - Fuel Injector	325-6116
4P-9963	Line As - Fuel Injector	298-2777
4P-9964	Line As - Fuel Injector	298-2778
4W-0452	Seal As - Camshaft	325-6191
5K-7995	Bearing - Sleeve	308-9820
5P-7807	Bearing - Ball	314-8502
5S-6795	Chamber As	242-3437
5S-9062	Spacer	363-7463
5S-9080	Pulley - Alt Drive	264-5883
5T-1362	Bearing - Spider	325-6011
6H-3957	Bearing - Ball	311-9358
6I-1346	Pump Gp - Oil	295-5674
6N-1036	Gear - Oil Pump	279-4991
6N-8413	Housing - Pump	325-6110
6P-2233	Gear - Planet	281-1690
6P-7742	Shaft - Planet	281-1695
6P-7743	Shaft - Planet	281-1696
6P-8005	Gear - Planet	281-1691
7G-3707	Piston - Clutch	302-2691
7G-3708	Piston - Clutch	300-2585
7G-4302	Housing - Clutch	302-2708
7G-4758	Gear - Planet	288-8723
7G-5444	Carrier - Planet	297-7165
7G-5593	Gear - Sun	300-2581
7G-5614	Shaft - Planet	281-1697
7N-0165	Core As - Oil Cooler	295-5670
7N-5910	Impeller - Pump	314-8686
7N-9145	Gear - Fly-wheel	279-4994
7N-9805	Pin - Piston	295-6438
7S-3161	Lifter - Valve	279-4996
7W-0450	Gear - Water Pump	279-4997
7W-0507	Gear - Oil Pump Drive	279-4998
7W-0508	Gear - Fuel Pump Drive	296-1351
7W-3042	Tube As - Drain	325-6231
8G-3102	Piston	325-6162
8N-0875	Valve - Ex-haust	247-6893 (Valve), 241-3381 (Valve Kit)
8N-1187	Head Gp - Cylinder	242-3435
8N-1188	Head Gp - Cylinder	242-3436
8N-1721	Rod As - Conn	269-5291
8N-2510	Shaft	325-6208
8N-2641	Sleeve	325-6210
8N-3251	Shaft As - Rocker Arm	314-8711
8N-3312	Shaft As - Rocker Arm	325-6200
8N-3325	Arm Gp - Rocker	314-8623
8N-3327	Arm Gp - Rocker	314-8624
8N-5305	Spacer	363-7464
8N-5929	Cover - Water Pump	296-1349
8N-6796	Head Gp - Cylinder	269-5290
8N-7315	Tube As - Outlet	325-6232
8N-8225	Bearing - Main	314-8652
8N-9402	Coupling	325-6048
8S-0248	Breather As	325-6033
8S-0493	Shaft As - Pump	325-6198
8S-3970	Chamber As	242-3438
9G-1231	Plate	297-7232
9M-1328	Bearing - Aligning	325-6018
9N-5769	Cover - Hous-ing	325-6050
9S-8679	Chamber As	325-6042
9W-9930	Mount As	295-6437
9Y-2992	Bearing - Sleeve	325-6032

Sales Model 571A

Original Part Number	Part Name	Classic Part Number
112-3249	Muffler As	247-2661
190-8609	Valve - Fill	360-2288
1A-2846	Cap As - Filler	311-9368
1F-2254	Bushing - Stem	314-8510
1M-0598	Gear - Trans-mission	213-8636
1M-2607	Cage - Bear-ing	239-7970
1M-2626	Cage - Carrier Bearing	216-7458
1M-2635	Housing - Clutch	216-3549
1M-2637	Housing - Clutch	216-3550
1M-4486	Piston - Clutch	215-1660
1M-5151	Pinion - Bevel	215-1661
1M-5270	Pipe - Exten-sion	367-6065
1M-8647	Housing As	215-1662
1M-9029	Guard	226-0219
1M-9444	Retainer - Spring	299-2046
1P-0005	Pump Gp - Fuel Transfer	256-4756
1P-0965	Gear - Bevel	213-8215
1P-4145	Valve Gp - Press	247-4436
1P-7590	Support As	213-4400
1S-0876	Bolt - Spring	226-0224
1S-1888	Bracket - Lamp	297-7147

(Continued)

Sales Model 571A (Continued)

Original Part Number	Part Name	Classic Part Number
1S-4701	Pulley - Alt	264-5866
1T-0256	Gear - Pump Drive	239-7930
2F-0025	Tube	325-6233
2F-5721	Bearing - Ball	311-9354
2K-4502	Bearing - Sleeve	299-1986
2M-0125	Cylinder - Adjustable	226-0215
2M-0365	Stop - Spring Rh	226-0230
2M-0366	Stop - Spring Lh	226-0231
2M-0369	Pilot - Spring Recoil	226-0226
2M-0398	Sleeve - Bolt	226-0235
2P-0483	Chamber As	256-4760
2P-0484	Chamber As	247-3296
2P-3424	Gear - First Reduction	215-1675
2P-3425	Pinion - Sec Reduction	217-7697
2P-3992	Gear - Bevel	219-9666
2S-3946	Gear - Final Drive	215-1678
2S-3966	Ring - Seal	297-7237
2S-4015	Plunger As - Valve	311-9438
2S-7063	Nut	300-2584
2S-7064	Cap - Shaft Bearing	299-1991
2S-7099	Hub - Gear	219-2962
2S-7527	Flange - Drum	213-8163
2S-7596	Retainer	215-1679
2S-7873	Pump Gp	226-0162
2S-7917	Gear - Pump Drive	247-4119
2S-7920	Pump Gp - Scavenge	217-2594
2S-8356	Rod Gp - Track Adjustable	226-0199
3B-1464	Cap - Bearing	226-0206
3F-7445	Bearing - Sleeve	314-8508
3H-3378	Gear As - Pump	298-2795
3K-2230	Gear - Planet	219-9658
3L-1425	Bearing - Ball	311-9356
3P-3623	Lock - Adjustable Nut	226-7989
3P-6293	Pump Gp	217-2597
3P-6560	Stop - Recoil Spring	226-0232
3P-6561	Stop - Recoil Spring	226-0233
3S-3917	Guard As - Sprocket	226-0188
3S-3918	Guard As - Sprocket	226-4950
3T-1921	Drum - Inner	229-8227 (Drum), 230-7116 (Steering Clutch Kit)
3T-4482	Guide - Front Idler	226-0248
4F-4974	Clamp	311-9373
4M-7099	Gear - Ring	214-0521
4M-7100	Gear - Ring	214-0522
4M-7102	Gear - Ring	214-0523
4M-9215	Gear - Pump Idler	311-9391
4N-7000	Head As - Cylinder	325-6105
4N-7526	Seal As - Pump	311-9454
4N-9180	Seal As - Pump	311-9455
5G-3612	Cap Gp	295-6419
5M-1988	Piston - Steer	219-9691
5M-1990	Pilot - Piston	229-8233
5M-1998	Drum Steering	213-6952
5M-2026	Hubdriving	216-4471
5M-3470	Gear - Transmission	224-1305
5M-3474	Shaft - Output	215-1690
5M-3499	Shaft - Planet	319-3475
5M-3906	Gear - Ring	214-0526
5M-3907	Carrier - Planet	210-8475
5M-3941	Shaft - Planet	215-1691
5M-3942	Shaft - Planet	215-1692
5M-5037	Hub - Gear	219-2980
5M-7900	Bolt - Hex Head	311-9349
5P-7807	Bearing - Ball	314-8502
5S-0073	Plate - Steering	302-2692
5S-1211	Cover - Valve	314-8665
5S-4863	Holder As - Cage	215-1732
5S-6796	Drum - Inner	213-6953 (Drum), 230-7115 (Steering Clutch Kit)
5S-9080	Pulley - Alt Drive	264-5883
6H-3957	Bearing - Ball	311-9358
6L-7816	Seal - o-Ring	314-8542
6P-4948	Cap - Final Drive Bearing	226-0205
6P-6653	Plate - Guide	226-0208
6T-1980	Collar - Idler End	226-0210
7B-2420	Ferrule - Director	314-8517
7F-9541	Pin As - Drawbar	296-1361
7G-2517	Gear - Planet	213-8747
7G-2521	Gear - Planet	213-8749
7G-6576	Cage As	216-7859
7H-0602	Dog - Clutch	314-8515
7M-4603	Body - Fuel Valve	311-9348
7M-4926	Retainer - Pin	314-8538
7M-8453	Piston - Clutch	215-1755
7N-0128	Core As - Oil Cooler	299-1994
7N-2957	Cover - Rad Cap	361-1722
7S-7809	Cap As - Radiator	295-6417
7S-7973	Guard - Final Drive Wear	213-9110
7T-0119	Support As	299-2066
7T-0204	Bearing - Brace	247-4126
7T-2036	Cap As - Filter	361-1721
8F-5104	Screen As - Oil Pan	314-8539
8H-1383	Rod - Tie	299-2051
8H-1993	Valve - Inlet	256-4765 (Valve Kit)
8H-1994	Valve - Exhaust	256-4765 (Valve Kit)
8H-2810	Case As - Filter	314-8512
8H-7980	Piston	226-0249
8M-2549	Rod As - Connector	314-8537
8M-7166	Housing - Screen	297-7192

(Continued)

Sales Model 571A (Continued)

Original Part Number	Part Name	Classic Part Number
8P-0187	Nut - Adjusting	219-9676
8P-6274	Guard As - Lh	226-4949
8P-6275	Guard As - Rh	226-0191
8S-0905	Muffler As	302-2690

Original Part Number	Part Name	Classic Part Number
8S-1061	Pilot As - Spring	226-0227
8S-7818	Bracket	226-0211
8S-9071	Cage - Bearing	216-7869
9P-0418	Cage	223-6311

Original Part Number	Part Name	Classic Part Number
9P-0620	Cage - Pinion Bearing	221-1052
9S-3955	Cage - Gear Bearing	216-7874
9S-6875	Pinion - Final Drive	217-7705
9S-6948	Shaft - Center	213-9966
9S-8493	Bolt - Connecting Rod	311-9351

Sales Model 571F

Original Part Number	Part Name	Classic Part Number
111-8015	Gasket As - Head	279-4977
115-0637	Pump Gp	226-0160
131-3815	Seal Gp - Basic	325-6193
172-5188	Shaft - Water Pump	325-6202
172-6712	Impeller - Pump	325-6112
190-8609	Valve - Fill	360-2288
196-0028	Gear As - Idler	364-5259
1M-0598	Gear - Transmission	213-8636
1M-2607	Cage - Bearing	239-7970
1M-2626	Cage - Carrier Bearing	216-7458
1M-2635	Housing - Clutch	216-3549
1M-2637	Housing - Clutch	216-3550
1M-4486	Piston - Clutch	215-1660
1M-5151	Pinion - Bevel	215-1661
1M-8647	Housing As	215-1662
1M-9029	Guard	226-0219
1M-9444	Retainer - Spring	299-2046
1N-3576	Block Gp - Cylinder	279-4978
1P-0579	Housing As	219-9678
1P-0965	Gear - Bevel	213-8215
1P-2187	Pump Gp	299-2044
1P-4303	Head As - Cylinder	242-3434
1P-7590	Support As	213-4400
1P-8835	Shaft As	215-1672

Original Part Number	Part Name	Classic Part Number
1P-9945	Bracket As - Fan	296-1344
1P-9946	Shaft - Fan	325-6194
1P-9952	Impeller - Pump	314-8685
1S-0876	Bolt - Spring	226-0224
1S-1532	Flange - Shaft	215-1673
1S-1888	Bracket - Lamp	297-7147
1S-4701	Pulley - Alt	264-5866
1T-0421	Flange As - Output	295-5442
1T-0436	Gear - Pump Drive	247-3367
1T-0437	Housing - Rotating	295-5685
1T-0438	Retainer - Bearing	295-0410
1T-0443	Carrier As - Guide	247-3368
1T-0447	Carrier - Ring	295-0409
1T-0930	Torque Converter	235-0913 (Repair Kit)
1T-1993	Wheel - Turbine	235-0920
1T-2052	Stator As	295-5683
1W-4402	Gear - Camshaft	279-4981
1W-4405	Gear - Crankshaft	279-4982
2F-0025	Tube	325-6233
2F-5721	Bearing - Ball	311-9354
2K-4502	Bearing - Sleeve	299-1986
2M-0125	Cylinder - Adjustable	226-0215
2M-0365	Stop - Spring Rh	226-0230

Original Part Number	Part Name	Classic Part Number
2M-0366	Stop - Spring Lh	226-0231
2M-0369	Pilot - Spring Recoil	226-0226
2M-0398	Sleeve - Bolt	226-0235
2P-1170	Shaft As - Gear	296-1367
2P-1738	Plate As - Oil Pan	325-6164
2P-1739	Tube As - Pump	325-6229
2P-1757	Hub - Fan Pulley	296-1357
2P-1781	Spacer - Oil Pump	325-6214
2P-2519	Tube As - Inlet	325-6230
2P-2784	Ejector As - Exh	367-6063
2P-3424	Gear - First Reduction	215-1675
2P-3425	Pinion - Sec Reduction	217-7697
2P-3598	Shaft - Output	215-1676
2P-3669	Pinion - Bevel	215-1677
2P-3992	Gear - Bevel	219-9666
2P-4701	Shaft As - Gear	297-7257
2P-6245	Shaft As - Pump	325-6197
2S-3946	Gear - Final Drive	215-1678
2S-4015	Plunger As - Valve	311-9438
2S-6739	Pulley - Tightener	298-2794
2S-7063	Nut	300-2584
2S-7064	Cap - Shaft Bearing	299-1991
2S-7099	Hub - Gear	219-2962

(Continued)

Sales Model 571F (Continued)

Original Part Number	Part Name	Classic Part Number
2S-7527	Flange - Drum	213-8163
2S-7596	Retainer	215-1679
2S-8356	Rod Gp - Track Adjustable	226-0199
2W-1086	Cover As - Cylinder Head	325-6049
2W-2621	Valve - Inlet	247-6892 (Valve), 241-3381 (Valve Kit)
2W-7458	Crankshaft As	242-3439
3K-2230	Gear - Planet	219-9658
3L-1425	Bearing - Ball	311-9356
3P-0214	Gear - Transfer	219-9681
3P-0215	Gear - Transfer	219-9682
3P-0395	Cage - Carrier Bearing	217-7723
3P-6560	Stop - Recoil Spring	226-0232
3P-6561	Stop - Recoil Spring	226-0233
3P-8283	Spacer	325-6215
3S-3917	Guard As - Sprocket	226-0188
3S-3918	Guard As - Sprocket	226-4950
3T-1921	Drum - Inner	229-8227 (Drum), 230-7116 (Steering Clutch Kit)
3T-4482	Guide - Front Idler	226-0248
4M-7099	Gear - Ring	214-0521
4M-7100	Gear - Ring	214-0522
4M-7102	Gear - Ring	214-0523
4N-2954	Sleeve - Camshaft	299-2059
4N-3281	Line As - Fuel Injector	247-3362
4N-3282	Line As - Fuel Injector	247-3363
4N-3283	Line As - Fuel Injector	247-3364
4N-4356	Pulley - Camshaft	264-5878
4N-4864	Pump Gp - Fuel Transfer	242-3442
4N-7693	Crankshaft As	242-3439
4N-8814	Line As - Fuel Injector	247-3366
4N-9587	Shield - Heat	297-7260
4P-3546	Valve As - Relief	325-6236
4S-6707	Piston - Clutch	215-1686
4S-8472	Hood As	296-1355
4S-8708	Housing - Clutch	216-3557
4W-0452	Seal As - Camshaft	325-6191
5G-3612	Cap Gp	295-6419
5M-1988	Piston - Steer	219-9691
5M-1990	Pilot - Piston	229-8233
5M-1998	Drum Steering	213-6952
5M-2026	Hubdriving	216-4471
5M-3470	Gear - Transmission	224-1305
5M-3474	Shaft - Output	215-1690
5M-3499	Shaft - Planet	319-3475
5M-3906	Gear - Ring	214-0526
5M-3907	Carrier - Planet	210-8475
5M-3941	Shaft - Planet	215-1691
5M-3942	Shaft - Planet	215-1692
5M-5822	Gear - Pump Drive	247-4120
5M-6120	Gear - Sun	213-8740
5M-6198	Shaft - Planet	297-7245
5M-6199	Shaft As - Planet	215-1694
5M-6208	Gear - Ring	247-4121
5M-6210	Shaft - Planet	219-9683
5M-6211	Shaft - Planet	219-9684
5M-7841	Gear - Ring	214-0525
5M-7864	Pump Gp - Scavenge	226-0169
5M-7869	Gear - Ring	214-0530
5M-7875	Carrier - Front	213-4495
5M-7900	Bolt - Hex Head	311-9349
5P-7807	Bearing - Ball	314-8502
5S-0073	Plate - Steering	302-2692
5S-1211	Cover - Valve	314-8665
5S-4470	Gear - Transfer	224-1304
5S-4557	Bearing	311-9360
5S-4863	Holder As - Cage	215-1732
5S-6795	Chamber As	242-3437
5S-6796	Drum - Inner	213-6953 (Drum), 230-7115 (Steering Clutch Kit)
5S-9062	Spacer	363-7463
5S-9080	Pulley - Alt Drive	264-5883
6H-3957	Bearing - Ball	311-9358
6I-1346	Pump Gp - Oil	295-5674
6N-0714	Pulley - Alt	264-5884
6N-1036	Gear - Oil Pump	279-4991
6N-1965	Line As - Fuel Injector	250-7535
6N-1966	Line As - Fuel Injector	250-7536
6N-8413	Housing - Pump	325-6110
6P-4948	Cap - Final Drive Bearing	226-0205
6P-6653	Plate - Guide	226-0208
6T-1980	Collar - Idler End	226-0210
7C-4297	Seal As - Camshaft	325-6192
7F-9541	Pin As - Drawbar	296-1361
7G-2037	Joint Gp - Univ	226-8017
7G-2038	Tube - Univ Joint	297-7268
7G-2474	Gear - Planet	300-2577
7G-2475	Gear - Planet	223-4815
7G-2476	Gear - Planet	223-4816
7G-2513	Gear - Planet	215-1734
7G-2517	Gear - Planet	213-8747
7G-2521	Gear - Planet	213-8749
7G-6576	Cage As	216-7859
7M-2167	Ring - Governor Control	308-9919
7M-8453	Piston - Clutch	215-1755
7N-0165	Core As - Oil Cooler	295-5670
7N-2949	Pulley	264-5887
7N-2957	Cover - Rad Cap	361-1722
7N-3515	Gear - Camshaft	314-8669
7N-3536	Gear - Fuel	279-4993
7N-5810	Gear As - Idler	233-2179

(Continued)

Sales Model 571F (Continued)

Original Part Number	Part Name	Classic Part Number
7N-5815	Gear - Camshaft Rr	233-2181
7N-5819	Gear - Hyd Pump Drive	215-1758
7N-9146	Gear - Flywheel Starter	279-4995
7N-9312	Damper As - Camshaft	299-2005
7N-9805	Pin - Piston	295-6438
7S-3161	Lifter - Valve	279-4996
7S-6723	Bracket - Alternator	299-1978
7S-6964	Gear - Ring	214-0532
7S-7809	Cap As - Radiator	295-6417
7S-7973	Guard - Final Drive Wear	213-9110
7T-0119	Support As	299-2066
7T-2036	Cap As - Filter	361-1721
7W-0450	Gear - Water Pump	279-4997
7W-0507	Gear - Oil Pump Drive	279-4998
8H-1383	Rod - Tie	299-2051
8H-2810	Case As - Filter	314-8512
8H-7980	Piston	226-0249
8H-9806	Gear - Shaft Drive	325-6091
8M-0874	Plunger As - Valve	311-9439
8M-7166	Housing - Screen	297-7192
8M-8619	Cage - Bearing	217-7725
8M-8623	Gear - Sun	213-8755
8M-8628	Flange - Joint	217-9776
8M-8642	Housing - Clutch	219-9669
8M-8644	Housing - Clutch	215-1782
8M-8646	Plate As - Center	216-3583
8M-8650	Piston - Clutch	217-9778
8M-8652	Shaft	297-7252
8M-8677	Carrier - Planet	213-4449
8N-0002	Trunnion As	314-8728
8N-0875	Valve - Exhaust	247-6893 (Valve), 241-3381 (Valve Kit)
8N-1187	Head Gp - Cylinder	242-3435
8N-1721	Rod As - Conn	269-5291
8N-1984	Rod As - Conn	242-3441
8N-3180	Body As - Piston	250-6563
8N-3181	Piston Gp - Basic	250-6555 (Liner Kit)
8N-3182	Body As - Piston	250-6564 (Piston As), 250-6556 (Liner Kits)
8N-3183	Piston Gp - Basic	250-6556 (Liner Kit)
8N-3325	Arm Gp - Rocker	314-8623
8N-3327	Arm Gp - Rocker	314-8624
8N-5305	Spacer	363-7464
8N-5929	Cover - Water Pump	296-1349
8N-7315	Tube As - Outlet	325-6232
8N-8225	Bearing - Main	314-8652
8P-0187	Nut - Adjusting	219-9676
8P-6274	Guard As - Lh	226-4949
8P-6275	Guard As - Rh	226-0191
8P-7790	Valve Gp - Press	247-4437
8S-0248	Breather As	325-6033
8S-0493	Shaft As - Pump	325-6198
8S-1061	Pilot As - Spring	226-0227
8S-3970	Chamber As	242-3438
8S-7818	Bracket	226-0211
8S-9070	Carrier - Front	213-4464
8S-9071	Cage - Bearing	216-7869
9H-2256	Pump Gp	311-9443
9M-1500	Shaft - Planet	219-9685
9M-1502	Cage - Bearing	219-9686
9M-1995	Gear - Sun	213-8756
9M-1996	Shaft - Planet	215-1875
9M-2028	Gear - Sun	214-0959
9M-2049	Gear - Ring	214-0533
9M-3025	Cover As	299-2001
9M-4789	Shaft - Gov Control	297-7256
9N-5251	Piston Gp - Basic	250-6557 (Liner Kit)
9N-5769	Cover - Housing	325-6050
9P-0418	Cage	223-6311
9P-0620	Cage - Pinion Bearing	221-1052
9P-5363	Piston - Clutch	219-9687
9P-5379	Housing - Clutch	215-1904
9S-2354	Manifold - Exhaust	261-0888
9S-2355	Manifold - Exhaust	261-0891
9S-3955	Cage - Gear Bearing	216-7874
9S-5265	Shaft As	215-1945
9S-5277	Gear - Transfer	213-8758
9S-6129	Pulley - Alternator Drive	264-5891
9S-6788	Pump Gp - Oil	217-2602
9S-6875	Pinion - Final Drive	217-7705
9S-6948	Shaft - Center	213-9966
9S-8679	Chamber As	325-6042
9S-8789	Plate - Clutch	302-2712
9S-8802	Gear - Ring	214-0952

Sales Model 571G

Original Part Number	Part Name	Classic Part Number
100-7860	Valve - Inlet	270-4360 (Valve), 270-4362 (Valve Kit)
104-4253	Line As - Fuel Injector	279-4988
104-4254	Line As - Fuel Injector	279-4989
111-8015	Gasket As - Head	279-4977
115-0637	Pump Gp	226-0160
122-9405	Bracket As	325-6005
131-3815	Seal Gp - Basic	325-6193
148-7455	Valve - Exhaust	270-4361
165-4262	Body As - Piston	270-4351
167-8123	Damper As	299-2006
172-5185	Shaft - Water Pump	325-6201
172-5188	Shaft - Water Pump	325-6202
172-5189	Impeller - Pump	295-5687
172-5190	Impeller - Pump	325-6111
172-6712	Impeller - Pump	325-6112
172-7767	Pump Gp - Water	296-1365
190-8609	Valve - Fill	360-2288
196-0028	Gear As - Idler	364-5259
1M-9029	Guard	226-0219
1M-9444	Retainer - Spring	299-2046
1N-3576	Block Gp - Cylinder	279-4978
1N-3958	Elbow	325-6087
1P-0579	Housing As	219-9678
1P-0965	Gear - Bevel	213-8215
1P-7590	Support As	213-4400
1P-8554	Coupling - Exhaust	325-6052
1P-8835	Shaft As	215-1672
1P-9945	Bracket As - Fan	296-1344
1P-9946	Shaft - Fan	325-6194
1P-9952	Impeller - Pump	314-8685
1S-0876	Bolt - Spring	226-0224
1S-1888	Bracket - Lamp	297-7147
1S-4701	Pulley - Alt	264-5866
1T-0421	Flange As - Output	295-5442
1T-0436	Gear - Pump Drive	247-3367
1T-0437	Housing - Rotating	295-5685
1T-0438	Retainer - Bearing	295-0410
1T-0443	Carrier As - Guide	247-3368
1T-0447	Carrier - Ring	295-0409
1T-0930	Torque Converter	235-0913 (Repair Kit)
1T-1993	Wheel - Turbine	235-0920
1T-2052	Stator As	295-5683
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1695	Pump Gp	279-4980
1W-1698	Housing - Transfer Pump	296-1356
1W-4402	Gear - Camshaft	279-4981
1W-4405	Gear - Crankshaft	279-4982
1W-5912	Tappet As - Guide	325-6223
1W-6541	Plunger As	325-6173
244-1090	Alarm - Back up	360-2345
2F-0025	Tube	325-6233
2F-5721	Bearing - Ball	311-9354
2K-4502	Bearing - Sleeve	299-1986
2M-0125	Cylinder - Adjustable	226-0215
2M-0365	Stop - Spring Rh	226-0230
2M-0366	Stop - Spring Lh	226-0231
2M-0369	Pilot - Spring Recoil	226-0226
2M-0398	Sleeve - Bolt	226-0235
2P-1170	Shaft As - Gear	296-1367
2P-1738	Plate As - Oil Pan	325-6164
2P-1739	Tube As - Pump	325-6229
2P-1757	Hub - Fan Pulley	296-1357
2P-1781	Spacer - Oil Pump	325-6214
2P-2519	Tube As - Inlet	325-6230
2P-2784	Ejector As - Exh	367-6063
2P-2922	Gear - Transfer	219-9679
2P-2923	Gear - Transfer	219-9680
2P-3424	Gear - First Reduction	215-1675
2P-3425	Pinion - Sec Reduction	217-7697
2P-3598	Shaft - Output	215-1676
2P-3669	Pinion - Bevel	215-1677
2P-3992	Gear - Bevel	219-9666
2P-4701	Shaft As - Gear	297-7257
2P-5608	Pipe - Extension	367-6066
2P-6245	Shaft As - Pump	325-6197
2S-3946	Gear - Final Drive	215-1678
2S-6739	Pulley - Tightener	298-2794
2S-7063	Nut	300-2584
2S-7064	Cap - Shaft Bearing	299-1991
2S-7099	Hub - Gear	219-2962
2S-7527	Flange - Drum	213-8163
2S-7596	Retainer	215-1679
2S-8356	Rod Gp - Track Adjustable	226-0199
2W-1086	Cover As - Cylinder Head	325-6049
2W-2621	Valve - Inlet	247-6892 (Valve), 241-3381 (Valve Kit)
2W-5540	Core, Radiator (Folded)	363-7452
2W-7255	Shaft - Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
3L-1425	Bearing - Ball	311-9356
3P-0395	Cage - Carrier Bearing	217-7723

(Continued)

Sales Model 571G (Continued)

Original Part Number	Part Name	Classic Part Number
3P-4157	Yoke As - Idler	226-0221
3P-6560	Stop - Recoil Spring	226-0232
3P-6561	Stop - Recoil Spring	226-0233
3P-8283	Spacer	325-6215
3S-3917	Guard As - Sprocket	226-0188
3S-3918	Guard As - Sprocket	226-4950
3T-1921	Drum - Inner	229-8227 (Drum), 230-7116 (Steering Clutch Kit)
3T-4482	Guide - Front Idler	226-0248
4J-6167	Bearing - Sleeve	325-6009
4N-2954	Sleeve - Camshaft	299-2059
4N-3281	Line As - Fuel Injector	247-3362
4N-3282	Line As - Fuel Injector	247-3363
4N-3283	Line As - Fuel Injector	247-3364
4N-4356	Pulley - Camshaft	264-5878
4N-4864	Pump Gp - Fuel Transfer	242-3442
4N-5191	Muffler As	298-2785
4N-7693	Crankshaft As	242-3439
4N-8814	Line As - Fuel Injector	247-3366
4N-9587	Shield - Heat	297-7260
4P-3546	Valve As - Relief	325-6236
4P-9381	Line As - Fuel Injector	279-4984
4P-9382	Line As - Fuel Injector	279-4985
4P-9385	Line As - Fuel Injector	279-4986
4P-9386	Line As - Fuel Injector	279-4987
4S-6707	Piston - Clutch	215-1686
4S-8472	Hood As	296-1355
4S-8708	Housing - Clutch	216-3557
4W-0452	Seal As - Camshaft	325-6191
4W-2446	Damper As	279-4990
5G-3612	Cap Gp	295-6419
5M-1988	Piston - Steer	219-9691
5M-1990	Pilot - Piston	229-8233
5M-1998	Drum Steering	213-6952
5M-2026	Hubdriving	216-4471
5M-5822	Gear - Pump Drive	247-4120
5M-6120	Gear - Sun	213-8740
5M-6198	Shaft - Planet	297-7245
5M-6199	Shaft As - Planet	215-1694
5M-6208	Gear - Ring	247-4121
5M-6210	Shaft - Planet	219-9683
5M-6211	Shaft - Planet	219-9684
5M-7841	Gear - Ring	214-0525
5M-7864	Pump Gp - Scavenge	226-0169
5M-7869	Gear - Ring	214-0530
5M-7875	Carrier - Front	213-4495
5M-7900	Bolt - Hex Head	311-9349
5P-7807	Bearing - Ball	314-8502
5S-0073	Plate - Steering	302-2692
5S-1211	Cover - Valve	314-8665
5S-4557	Bearing	311-9360
5S-4863	Holder As - Cage	215-1732
5S-6795	Chamber As	242-3437
5S-6796	Drum - Inner	213-6953 (Drum), 230-7115 (Steering Clutch Kit)
5S-9062	Spacer	363-7463
5S-9080	Pulley - Alt Drive	264-5883
6H-3957	Bearing - Ball	311-9358
6I-1346	Pump Gp - Oil	295-5674
6N-0714	Pulley - Alt	264-5884
6N-1036	Gear - Oil Pump	279-4991
6N-1965	Line As - Fuel Injector	250-7535
6N-1966	Line As - Fuel Injector	250-7536
6N-8413	Housing - Pump	325-6110
6P-4948	Cap - Final Drive Bearing	226-0205
6P-6653	Plate - Guide	226-0208
6T-1980	Collar - Idler End	226-0210
7C-4297	Seal As - Camshaft	325-6192
7F-9541	Pin As - Drawbar	296-1361
7G-2037	Joint Gp - Univ	226-8017
7G-2038	Tube - Univ Joint	297-7268
7G-2474	Gear - Planet	300-2577
7G-2475	Gear - Planet	223-4815
7G-2476	Gear - Planet	223-4816
7G-2513	Gear - Planet	215-1734
7G-6576	Cage As	216-7859
7J-1333	Bearing - Sleeve	295-6408
7J-1334	Bearing - Sleeve	325-6015
7J-4827	Yoke	299-2070
7N-0165	Core As - Oil Cooler	295-5670
7N-2871	Line As - Fuel Injector	319-8172
7N-2872	Line As - Fuel Injector	319-8173
7N-2874	Line As - Fuel Injector	298-2779
7N-2875	Line As - Fuel Injector	298-2780
7N-2876	Line As - Fuel Injector	298-2781
7N-2949	Pulley	264-5887
7N-2957	Cover - Rad Cap	361-1722
7N-3515	Gear - Camshaft	314-8669
7N-3536	Gear - Fuel	279-4993
7N-5810	Gear As - Idler	233-2179
7N-5815	Gear - Camshaft Rr	233-2181
7N-5819	Gear - Hyd Pump Drive	215-1758
7N-5910	Impeller - Pump	314-8686
7N-9146	Gear - Flywheel Starter	279-4995
7N-9312	Damper As - Camshaft	299-2005
7N-9805	Pin - Piston	295-6438
7S-3161	Lifter - Valve	279-4996

(Continued)

Sales Model 571G (Continued)

Original Part Number	Part Name	Classic Part Number
7S-6723	Bracket - Alternator	299-1978
7S-6964	Gear - Ring	214-0532
7S-7809	Cap As - Radiator	295-6417
7S-7973	Guard - Final Drive Wear	213-9110
7T-0119	Support As	299-2066
7T-2036	Cap As - Filter	361-1721
7W-0450	Gear - Water Pump	279-4997
7W-0507	Gear - Oil Pump Drive	279-4998
7W-0508	Gear - Fuel Pump Drive	296-1351
7W-5687	Hub - Camshaft	314-8684
8H-1383	Rod - Tie	299-2051
8H-2810	Case As - Filter	314-8512
8H-7980	Piston	226-0249
8H-9806	Gear - Shaft Drive	325-6091
8J-2880	Cap - Bearing	295-6420
8M-0874	Plunger As - Valve	311-9439
8M-7166	Housing - Screen	297-7192
8M-8619	Cage - Bearing	217-7725
8M-8623	Gear - Sun	213-8755
8M-8628	Flange - Joint	217-9776
8M-8642	Housing - Clutch	219-9669
8M-8644	Housing - Clutch	215-1782
8M-8646	Plate As - Center	216-3583
8M-8650	Piston - Clutch	217-9778
8M-8652	Shaft	297-7252
8M-8677	Carrier - Planet	213-4449
8N-0002	Trunnion As	314-8728
8N-0875	Valve - Exhaust	247-6893 (Valve), 241-3381 (Valve Kit)
8N-1187	Head Gp - Cylinder	242-3435
8N-1721	Rod As - Conn	269-5291
8N-2510	Shaft	325-6208
8N-2641	Sleeve	325-6210
8N-3251	Shaft As - Rocker Arm	314-8711
8N-3325	Arm Gp - Rocker	314-8623
8N-3327	Arm Gp - Rocker	314-8624
8N-5305	Spacer	363-7464
8N-5929	Cover - Water Pump	296-1349
8N-6796	Head Gp - Cylinder	269-5290
8N-7315	Tube As - Outlet	325-6232
8N-8225	Bearing - Main	314-8652
8N-9733	Line As - Fuel Injector	319-8174
8P-0187	Nut - Adjusting	219-9676
8P-6274	Guard As - Lh	226-4949
8P-6275	Guard As - Rh	226-0191
8P-7790	Valve Gp - Press	247-4437
8S-0248	Breather As	325-6033
8S-0493	Shaft As - Pump	325-6198
8S-1061	Pilot As - Spring	226-0227
8S-3970	Chamber As	242-3438
8S-7818	Bracket	226-0211
9K-8757	Rod End - Bearing	311-9361
9M-1500	Shaft - Planet	219-9685
9M-1502	Cage - Bearing	219-9686
9M-1995	Gear - Sun	213-8756
9M-1996	Shaft - Planet	215-1875
9M-2028	Gear - Sun	214-0959
9M-2049	Gear - Ring	214-0533
9M-3025	Cover As	299-2001
9M-4789	Shaft - Gov Control	297-7256
9N-5251	Piston Gp - Basic	250-6557 (Liner Kit)
9N-5769	Cover - Housing	325-6050
9P-0418	Cage	223-6311
9P-0620	Cage - Pinion Bearing	221-1052
9P-5363	Piston - Clutch	219-9687
9P-5379	Housing - Clutch	215-1904
9S-2354	Manifold - Exhaust	261-0888
9S-2355	Manifold - Exhaust	261-0891
9S-3955	Cage - Gear Bearing	216-7874
9S-5265	Shaft As	215-1945
9S-6875	Pinion - Final Drive	217-7705
9S-8679	Chamber As	325-6042
9S-8789	Plate - Clutch	302-2712

Sales Model 572C, 572D

Original Part Number	Part Name	Classic Part Number
121-7746	Precleaner As	360-2311
1A-2846	Cap As - Filler	311-9368
1F-2254	Bushing - Stem	314-8510
1M-7250	Bowl - Precleaner	360-2296
2D-5658	Bearing - Ball	301-4628
2F-0025	Tube	325-6233
2F-5721	Bearing - Ball	311-9354
2K-3632	Yoke As	297-4866
2P-0483	Chamber As	256-4760
2S-3966	Ring - Seal	297-7237
2S-4015	Plunger As - Valve	311-9438
3F-7445	Bearing - Sleeve	314-8508
3H-3378	Gear As - Pump	298-2795
3L-1425	Bearing - Ball	311-9356
3P-3623	Lock - Adjustable Nut	226-7989

(Continued)

Sales Model 572C, 572D (Continued)

Original Part Number	Part Name	Classic Part Number
3S-2420	Pilot As - Spring	226-2733
4B-1455	Cap As - Filter	361-1719
4F-4974	Clamp	311-9373
4N-7526	Seal As - Pump	311-9454
4N-9180	Seal As - Pump	311-9455
5F-2256	Cage - Bearing	226-7973
5S-1211	Cover - Valve	314-8665
6B-7178	Fork - Band Adjustable	299-2009
6H-3957	Bearing - Ball	311-9358
7B-2420	Ferrule - Director	314-8517
7H-0602	Dog - Clutch	314-8515
7M-4603	Body - Fuel Valve	311-9348
7M-4926	Retainer - Pin	314-8538
7M-5002	Drum - Steering	226-7992
7S-7809	Cap As - Radiator	295-6417
8F-5104	Screen As - Oil Pan	314-8539
8H-1383	Rod - Tie	299-2051
8H-1993	Valve - Inlet	256-4765 (Valve Kit)
8H-1994	Valve - Exhaust	256-4765 (Valve Kit)
8H-9379	Nut - Brake Band Adjustable	299-2029
8M-0493	Cage - Outer Bearing	216-7866
8S-5722	Plate - Pressure	226-8009
9S-8493	Bolt - Connecting Rod	311-9351

Sales Model 572E

Original Part Number	Part Name	Classic Part Number
112-3249	Muffler As	247-2661
190-8609	Valve - Fill	360-2288
1A-2846	Cap As - Filler	311-9368
1F-2254	Bushing - Stem	314-8510
1M-0598	Gear - Transmission	213-8636
1M-2607	Cage - Bearing	239-7970
1M-2626	Cage - Carrier Bearing	216-7458
1M-2635	Housing - Clutch	216-3549
1M-2637	Housing - Clutch	216-3550
1M-4486	Piston - Clutch	215-1660
1M-5151	Pinion - Bevel	215-1661
1M-5270	Pipe - Extension	367-6065
1M-8647	Housing As	215-1662
1M-9029	Guard	226-0219
1M-9444	Retainer - Spring	299-2046
1P-0005	Pump Gp - Fuel Transfer	256-4756
1P-0965	Gear - Bevel	213-8215
1P-4145	Valve Gp - Press	247-4436
1P-7590	Support As	213-4400
1S-0876	Bolt - Spring	226-0224
1S-1888	Bracket - Lamp	297-7147
1S-4701	Pulley - Alt	264-5866
1T-0256	Gear - Pump Drive	239-7930
2D-5658	Bearing - Ball	301-4628
2F-0025	Tube	325-6233
2F-5721	Bearing - Ball	311-9354
2K-3632	Yoke As	297-4866
2M-0125	Cylinder - Adjustable	226-0215
2M-0365	Stop - Spring Rh	226-0230
2M-0366	Stop - Spring Lh	226-0231
2M-0369	Pilot - Spring Recoil	226-0226
2M-0398	Sleeve - Bolt	226-0235
2P-0483	Chamber As	256-4760
2P-0484	Chamber As	247-3296
2P-3424	Gear - First Reduction	215-1675
2P-3425	Pinion - Sec Reduction	217-7697
2P-3992	Gear - Bevel	219-9666
2S-3946	Gear - Final Drive	215-1678
2S-3966	Ring - Seal	297-7237
2S-4015	Plunger As - Valve	311-9438
2S-7063	Nut	300-2584
2S-7064	Cap - Shaft Bearing	299-1991
2S-7527	Flange - Drum	213-8163
2S-7596	Retainer	215-1679
2S-7873	Pump Gp	226-0162
2S-7917	Gear - Pump Drive	247-4119
2S-7920	Pump Gp - Scavenge	217-2594
3F-7445	Bearing - Sleeve	314-8508
3H-3378	Gear As - Pump	298-2795
3K-2230	Gear - Planet	219-9658
3P-3623	Lock - Adjustable Nut	226-7989
3P-6293	Pump Gp	217-2597
3S-3917	Guard As - Sprocket	226-0188
3S-3918	Guard As - Sprocket	226-4950
3T-1921	Drum - Inner	229-8227 (Drum), 230-7116 (Steering Clutch Kit)
3T-4482	Guide - Front Idler	226-0248
4F-4974	Clamp	311-9373
4M-7099	Gear - Ring	214-0521
4M-7100	Gear - Ring	214-0522
4M-7102	Gear - Ring	214-0523
4M-9215	Gear - Pump Idler	311-9391
4N-7000	Head As - Cylinder	325-6105
4N-7526	Seal As - Pump	311-9454
4N-9180	Seal As - Pump	311-9455
5G-3612	Cap Gp	295-6419

(Continued)

Sales Model 572E (Continued)

Original Part Number	Part Name	Classic Part Number
5M-1988	Piston - Steer	219-9691
5M-1990	Pilot - Piston	229-8233
5M-1998	Drum Steering	213-6952
5M-2026	Hubdriving	216-4471
5M-3470	Gear - Transmission	224-1305
5M-3474	Shaft - Output	215-1690
5M-3499	Shaft - Planet	319-3475
5M-3906	Gear - Ring	214-0526
5M-3907	Carrier - Planet	210-8475
5M-3941	Shaft - Planet	215-1691
5M-3942	Shaft - Planet	215-1692
5M-5037	Hub - Gear	219-2980
5M-7900	Bolt - Hex Head	311-9349
5P-7807	Bearing - Ball	314-8502
5S-0073	Plate - Steering	302-2692
5S-1211	Cover - Valve	314-8665
5S-4863	Holder As - Cage	215-1732
5S-6796	Drum - Inner	213-6953 (Drum), 230-7115 (Steering Clutch Kit)
5S-9080	Pulley - Alt Drive	264-5883
6H-3957	Bearing - Ball	311-9358
6L-7816	Seal - o-Ring	314-8542
6P-6653	Plate - Guide	226-0208
6T-1980	Collar - Idler End	226-0210
7B-2420	Ferrule - Director	314-8517
7G-2517	Gear - Planet	213-8747
7G-2521	Gear - Planet	213-8749
7G-6576	Cage As	216-7859
7H-0602	Dog - Clutch	314-8515
7M-4603	Body - Fuel Valve	311-9348
7M-4926	Retainer - Pin	314-8538
7M-8453	Piston - Clutch	215-1755
7N-0128	Core As - Oil Cooler	299-1994
7N-2957	Cover - Rad Cap	361-1722
7S-7809	Cap As - Radiator	295-6417
7S-7973	Guard - Final Drive Wear	213-9110
7T-0119	Support As	299-2066
7T-2036	Cap As - Filter	361-1721
8F-5104	Screen As - Oil Pan	314-8539
8H-1383	Rod - Tie	299-2051
8H-1993	Valve - Inlet	256-4765 (Valve Kit)
8H-1994	Valve - Exhaust	256-4765 (Valve Kit)
8H-2810	Case As - Filter	314-8512
8H-7980	Piston	226-0249
8M-2549	Rod As - Connector	314-8537
8M-7166	Housing - Screen	297-7192
8P-0187	Nut - Adjusting	219-9676
8S-0905	Muffler As	302-2690
8S-1061	Pilot As - Spring	226-0227
8S-7818	Bracket	226-0211
8S-9071	Cage - Bearing	216-7869
9P-0418	Cage	223-6311
9P-0620	Cage - Pinion Bearing	221-1052
9S-3955	Cage - Gear Bearing	216-7874
9S-6875	Pinion - Final Drive	217-7705
9S-6948	Shaft - Center	213-9966
9S-8493	Bolt - Connecting Rod	311-9351

Sales Model 572F

Original Part Number	Part Name	Classic Part Number
111-8015	Gasket As - Head	279-4977
115-0637	Pump Gp	226-0160
131-3815	Seal Gp - Basic	325-6193
172-5188	Shaft - Water Pump	325-6202
172-6712	Impeller - Pump	325-6112
190-8609	Valve - Fill	360-2288
196-0028	Gear As - Idler	364-5259
1M-0598	Gear - Transmission	213-8636
1M-2607	Cage - Bearing	239-7970
1M-2626	Cage - Carrier Bearing	216-7458
1M-2635	Housing - Clutch	216-3549
1M-2637	Housing - Clutch	216-3550
1M-4486	Piston - Clutch	215-1660
1M-5151	Pinion - Bevel	215-1661
1M-8647	Housing As	215-1662
1M-9029	Guard	226-0219
1M-9444	Retainer - Spring	299-2046
1N-3576	Block Gp - Cylinder	279-4978
1P-0579	Housing As	219-9678
1P-0965	Gear - Bevel	213-8215
1P-2187	Pump Gp	299-2044
1P-4303	Head As - Cylinder	242-3434
1P-7590	Support As	213-4400
1P-8835	Shaft As	215-1672
1P-9945	Bracket As - Fan	296-1344
1P-9946	Shaft - Fan	325-6194
1P-9952	Impeller - Pump	314-8685
1S-0876	Bolt - Spring	226-0224
1S-1532	Flange - Shaft	215-1673
1S-1888	Bracket - Lamp	297-7147
1S-4701	Pulley - Alt	264-5866
1T-0421	Flange As - Output	295-5442
1T-0436	Gear - Pump Drive	247-3367
1T-0437	Housing - Rotating	295-5685

(Continued)

Sales Model 572F (Continued)

Original Part Number	Part Name	Classic Part Number
1T-0438	Retainer - Bearing	295-0410
1T-0443	Carrier As - Guide	247-3368
1T-0447	Carrier - Ring	295-0409
1T-0930	Torque Converter	235-0913 (Repair Kit)
1T-1993	Wheel - Turbine	235-0920
1T-2052	Stator As	295-5683
1W-4402	Gear - Camshaft	279-4981
1W-4405	Gear - Crankshaft	279-4982
2D-5658	Bearing - Ball	301-4628
2F-0025	Tube	325-6233
2F-5721	Bearing - Ball	311-9354
2K-3632	Yoke As	297-4866
2M-0125	Cylinder - Adjustable	226-0215
2M-0365	Stop - Spring Rh	226-0230
2M-0366	Stop - Spring Lh	226-0231
2M-0369	Pilot - Spring Recoil	226-0226
2M-0398	Sleeve - Bolt	226-0235
2P-1170	Shaft As - Gear	296-1367
2P-1738	Plate As - Oil Pan	325-6164
2P-1739	Tube As - Pump	325-6229
2P-1757	Hub - Fan Pulley	296-1357
2P-1781	Spacer - Oil Pump	325-6214
2P-2519	Tube As - Inlet	325-6230
2P-2784	Ejector As - Exh	367-6063
2P-3424	Gear - First Reduction	215-1675
2P-3425	Pinion - Sec Reduction	217-7697
2P-3598	Shaft - Output	215-1676
2P-3669	Pinion - Bevel	215-1677
2P-3992	Gear - Bevel	219-9666
2P-4701	Shaft As - Gear	297-7257
2P-6245	Shaft As - Pump	325-6197
2S-3946	Gear - Final Drive	215-1678
2S-4015	Plunger As - Valve	311-9438
2S-6739	Pulley - Tightener	298-2794
2S-7063	Nut	300-2584
2S-7064	Cap - Shaft Bearing	299-1991
2S-7527	Flange - Drum	213-8163
2S-7596	Retainer	215-1679
2W-1086	Cover As - Cylinder Head	325-6049
2W-2621	Valve - Inlet	247-6892 (Valve), 241-3381 (Valve Kit)
2W-7458	Crankshaft As	242-3439
3K-2230	Gear - Planet	219-9658
3L-1425	Bearing - Ball	311-9356
3P-0214	Gear - Transfer	219-9681
3P-0215	Gear - Transfer	219-9682
3P-0395	Cage - Carrier Bearing	217-7723
3P-8283	Spacer	325-6215
3S-3917	Guard As - Sprocket	226-0188
3S-3918	Guard As - Sprocket	226-4950
3T-1921	Drum - Inner	229-8227 (Drum), 230-7116 (Steering Clutch Kit)
3T-4482	Guide - Front Idler	226-0248
4M-7099	Gear - Ring	214-0521
4M-7100	Gear - Ring	214-0522
4M-7102	Gear - Ring	214-0523
4N-2954	Sleeve - Camshaft	299-2059
4N-3281	Line As - Fuel Injector	247-3362
4N-3282	Line As - Fuel Injector	247-3363
4N-3283	Line As - Fuel Injector	247-3364
4N-4356	Pulley - Camshaft	264-5878
4N-4864	Pump Gp - Fuel Transfer	242-3442
4N-7693	Crankshaft As	242-3439
4N-8814	Line As - Fuel Injector	247-3366
4N-9587	Shield - Heat	297-7260
4P-3546	Valve As - Relief	325-6236
4S-6707	Piston - Clutch	215-1686
4S-8472	Hood As	296-1355
4S-8708	Housing - Clutch	216-3557
4W-0452	Seal As - Camshaft	325-6191
5G-3612	Cap Gp	295-6419
5M-1988	Piston - Steer	219-9691
5M-1990	Pilot - Piston	229-8233
5M-1998	Drum Steering	213-6952
5M-2026	Hubdriving	216-4471
5M-3470	Gear - Transmission	224-1305
5M-3474	Shaft - Output	215-1690
5M-3499	Shaft - Planet	319-3475
5M-3906	Gear - Ring	214-0526
5M-3907	Carrier - Planet	210-8475
5M-3941	Shaft - Planet	215-1691
5M-3942	Shaft - Planet	215-1692
5M-5822	Gear - Pump Drive	247-4120
5M-6120	Gear - Sun	213-8740
5M-6198	Shaft - Planet	297-7245
5M-6199	Shaft As - Planet	215-1694
5M-6208	Gear - Ring	247-4121
5M-6210	Shaft - Planet	219-9683
5M-6211	Shaft - Planet	219-9684
5M-7841	Gear - Ring	214-0525
5M-7864	Pump Gp - Scavenge	226-0169
5M-7869	Gear - Ring	214-0530
5M-7875	Carrier - Front	213-4495
5M-7900	Bolt - Hex Head	311-9349
5P-7807	Bearing - Ball	314-8502
5S-0073	Plate - Steering	302-2692
5S-1211	Cover - Valve	314-8665
5S-4470	Gear - Transfer	224-1304
5S-4557	Bearing	311-9360

(Continued)

Sales Model 572F (Continued)

Original Part Number	Part Name	Classic Part Number
5S-4863	Holder As - Cage	215-1732
5S-6795	Chamber As	242-3437
5S-6796	Drum - Inner	213-6953 (Drum), 230-7115 (Steering Clutch Kit)
5S-9062	Spacer	363-7463
5S-9080	Pulley - Alt Drive	264-5883
6H-3957	Bearing - Ball	311-9358
6I-1346	Pump Gp - Oil	295-5674
6N-0714	Pulley - Alt	264-5884
6N-1036	Gear - Oil Pump	279-4991
6N-1965	Line As - Fuel Injector	250-7535
6N-1966	Line As - Fuel Injector	250-7536
6N-8413	Housing - Pump	325-6110
6P-6653	Plate - Guide	226-0208
6T-1980	Collar - Idler End	226-0210
7C-4297	Seal As - Camshaft	325-6192
7G-2474	Gear - Planet	300-2577
7G-2475	Gear - Planet	223-4815
7G-2476	Gear - Planet	223-4816
7G-2513	Gear - Planet	215-1734
7G-2517	Gear - Planet	213-8747
7G-2521	Gear - Planet	213-8749
7G-6576	Cage As	216-7859
7M-2167	Ring - Governor Control	308-9919
7M-8453	Piston - Clutch	215-1755
7N-0165	Core As - Oil Cooler	295-5670
7N-2949	Pulley	264-5887
7N-2957	Cover - Rad Cap	361-1722
7N-3515	Gear - Camshaft	314-8669
7N-3536	Gear - Fuel	279-4993
7N-5810	Gear As - Idler	233-2179
7N-5815	Gear - Camshaft Rr	233-2181
7N-5819	Gear - Hyd Pump Drive	215-1758
7N-5825	Gear - Drive	215-1759
7N-9146	Gear - Flywheel Starter	279-4995
7N-9312	Damper As - Camshaft	299-2005
7N-9805	Pin - Piston	295-6438
7S-3161	Lifter - Valve	279-4996
7S-6723	Bracket - Alternator	299-1978
7S-6964	Gear - Ring	214-0532
7S-7809	Cap As - Radiator	295-6417
7S-7973	Guard - Final Drive Wear	213-9110
7T-0119	Support As	299-2066
7T-2036	Cap As - Filter	361-1721
7W-0450	Gear - Water Pump	279-4997
7W-0507	Gear - Oil Pump Drive	279-4998
8H-1383	Rod - Tie	299-2051
8H-2810	Case As - Filter	314-8512
8H-7980	Piston	226-0249
8H-9806	Gear - Shaft Drive	325-6091
8M-0874	Plunger As - Valve	311-9439
8M-7166	Housing - Screen	297-7192
8M-8619	Cage - Bearing	217-7725
8M-8623	Gear - Sun	213-8755
8M-8628	Flange - Joint	217-9776
8M-8642	Housing - Clutch	219-9669
8M-8644	Housing - Clutch	215-1782
8M-8646	Plate As - Center	216-3583
8M-8650	Piston - Clutch	217-9778
8M-8652	Shaft	297-7252
8M-8677	Carrier - Planet	213-4449
8N-0002	Trunnion As	314-8728
8N-0875	Valve - Exhaust	247-6893 (Valve), 241-3381 (Valve Kit)
8N-1187	Head Gp - Cylinder	242-3435
8N-1721	Rod As - Conn	269-5291
8N-1984	Rod As - Conn	242-3441
8N-3180	Body As - Piston	250-6563
8N-3181	Piston Gp - Basic	250-6555 (Liner Kit)
8N-3183	Piston Gp - Basic	250-6556 (Liner Kit)
8N-3325	Arm Gp - Rocker	314-8623
8N-3327	Arm Gp - Rocker	314-8624
8N-5305	Spacer	363-7464
8N-5929	Cover - Water Pump	296-1349
8N-7315	Tube As - Outlet	325-6232
8N-8225	Bearing - Main	314-8652
8P-0187	Nut - Adjusting	219-9676
8P-7790	Valve Gp - Press	247-4437
8S-0248	Breather As	325-6033
8S-0493	Shaft As - Pump	325-6198
8S-1061	Pilot As - Spring	226-0227
8S-3970	Chamber As	242-3438
8S-7818	Bracket	226-0211
8S-9070	Carrier - Front	213-4464
8S-9071	Cage - Bearing	216-7869
9H-2256	Pump Gp	311-9443
9M-1500	Shaft - Planet	219-9685
9M-1502	Cage - Bearing	219-9686
9M-1995	Gear - Sun	213-8756
9M-1996	Shaft - Planet	215-1875
9M-2028	Gear - Sun	214-0959
9M-2049	Gear - Ring	214-0533
9M-3025	Cover As	299-2001
9M-4789	Shaft - Gov Control	297-7256
9N-5251	Piston Gp - Basic	250-6557 (Liner Kit)
9N-5769	Cover - Housing	325-6050
9P-0418	Cage	223-6311
9P-0620	Cage - Pinion Bearing	221-1052

(Continued)

Sales Model 572F (Continued)

Original Part Number	Part Name	Classic Part Number
9P-5363	Piston - Clutch	219-9687
9P-5379	Housing - Clutch	215-1904
9S-2354	Manifold - Exhaust	261-0888
9S-2355	Manifold - Exhaust	261-0891
9S-3955	Cage - Gear Bearing	216-7874
9S-5265	Shaft As	215-1945
9S-5277	Gear - Transfer	213-8758
9S-6129	Pulley - Alternator Drive	264-5891
9S-6788	Pump Gp - Oil	217-2602
9S-6875	Pinion - Final Drive	217-7705
9S-6948	Shaft - Center	213-9966
9S-8679	Chamber As	325-6042
9S-8789	Plate - Clutch	302-2712
9S-8802	Gear - Ring	214-0952

Sales Model 572G

Original Part Number	Part Name	Classic Part Number
100-7860	Valve - Inlet	270-4360 (Valve), 270-4362 (Valve Kit)
104-4253	Line As - Fuel Injector	279-4988
104-4254	Line As - Fuel Injector	279-4989
111-8015	Gasket As - Head	279-4977
115-0637	Pump Gp	226-0160
122-9405	Bracket As	325-6005
131-3815	Seal Gp - Basic	325-6193
148-7455	Valve - Exhaust	270-4361
165-4262	Body As - Piston	270-4351
167-8123	Damper As	299-2006
172-5185	Shaft - Water Pump	325-6201
172-5188	Shaft - Water Pump	325-6202
172-5189	Impeller - Pump	295-5687
172-5190	Impeller - Pump	325-6111
172-6712	Impeller - Pump	325-6112
172-7767	Pump Gp - Water	296-1365
190-8609	Valve - Fill	360-2288
196-0028	Gear As - Idler	364-5259
1M-9029	Guard	226-0219
1M-9444	Retainer - Spring	299-2046
1N-3576	Block Gp - Cylinder	279-4978
1N-3958	Elbow	325-6087
1P-0579	Housing As	219-9678
1P-0965	Gear - Bevel	213-8215
1P-2187	Pump Gp	299-2044
1P-7590	Support As	213-4400
1P-8554	Coupling - Exhaust	325-6052
1P-8835	Shaft As	215-1672
1P-9945	Bracket As - Fan	296-1344
1P-9946	Shaft - Fan	325-6194
1P-9952	Impeller - Pump	314-8685
1S-0876	Bolt - Spring	226-0224
1S-1888	Bracket - Lamp	297-7147
1S-4701	Pulley - Alt	264-5866
1T-0421	Flange As - Output	295-5442
1T-0436	Gear - Pump Drive	247-3367
1T-0437	Housing - Rotating	295-5685
1T-0438	Retainer - Bearing	295-0410
1T-0443	Carrier As - Guide	247-3368
1T-0447	Carrier - Ring	295-0409
1T-0930	Torque Converter	235-0913 (Repair Kit)
1T-1993	Wheel - Turbine	235-0920
1T-2052	Stator As	295-5683
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1695	Pump Gp	279-4980
1W-1698	Housing - Transfer Pump	296-1356
1W-4402	Gear - Camshaft	279-4981
1W-4405	Gear - Crankshaft	279-4982
1W-5912	Tappet As - Guide	325-6223
1W-6541	Plunger As	325-6173
244-1090	Alarm - Back up	360-2345
2D-5658	Bearing - Ball	301-4628
2F-0025	Tube	325-6233
2F-5721	Bearing - Ball	311-9354
2K-3632	Yoke As	297-4866
2K-5073	Bushing	299-1989
2M-0125	Cylinder - Adjustable	226-0215
2M-0365	Stop - Spring Rh	226-0230
2M-0366	Stop - Spring Lh	226-0231
2M-0369	Pilot - Spring Recoil	226-0226
2M-0398	Sleeve - Bolt	226-0235
2P-1170	Shaft As - Gear	296-1367
2P-1738	Plate As - Oil Pan	325-6164
2P-1739	Tube As - Pump	325-6229
2P-1757	Hub - Fan Pulley	296-1357
2P-1781	Spacer - Oil Pump	325-6214
2P-2519	Tube As - Inlet	325-6230

(Continued)

Sales Model 572G (Continued)

Original Part Number	Part Name	Classic Part Number
2P-2784	Ejector As - Exh	367-6063
2P-2922	Gear - Transfer	219-9679
2P-2923	Gear - Transfer	219-9680
2P-3424	Gear - First Reduction	215-1675
2P-3425	Pinion - Sec Reduction	217-7697
2P-3598	Shaft - Output	215-1676
2P-3669	Pinion - Bevel	215-1677
2P-3992	Gear - Bevel	219-9666
2P-4701	Shaft As - Gear	297-7257
2P-5608	Pipe - Extension	367-6066
2P-6245	Shaft As - Pump	325-6197
2S-3946	Gear - Final Drive	215-1678
2S-6739	Pulley - Tightener	298-2794
2S-7063	Nut	300-2584
2S-7064	Cap - Shaft Bearing	299-1991
2S-7527	Flange - Drum	213-8163
2S-7596	Retainer	215-1679
2W-1086	Cover As - Cylinder Head	325-6049
2W-2621	Valve - Inlet	247-6892 (Valve), 241-3381 (Valve Kit)
2W-5540	Core, Radiator (Folded)	363-7452
2W-7255	Shaft - Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
3L-1425	Bearing - Ball	311-9356
3P-0395	Cage - Carrier Bearing	217-7723
3P-8283	Spacer	325-6215
3S-3917	Guard As - Sprocket	226-0188
3S-3918	Guard As - Sprocket	226-4950
3T-1921	Drum - Inner	229-8227 (Drum), 230-7116 (Steering Clutch Kit)
3T-4482	Guide - Front Idler	226-0248
4J-6167	Bearing - Sleeve	325-6009
4N-2954	Sleeve - Camshaft	299-2059
4N-3281	Line As - Fuel Injector	247-3362
4N-3282	Line As - Fuel Injector	247-3363
4N-3283	Line As - Fuel Injector	247-3364
4N-4356	Pulley - Camshaft	264-5878
4N-4539	Sleeve	314-8720
4N-4864	Pump Gp - Fuel Transfer	242-3442
4N-5191	Muffler As	298-2785
4N-7693	Crankshaft As	242-3439
4N-8814	Line As - Fuel Injector	247-3366
4N-9587	Shield - Heat	297-7260
4P-3546	Valve As - Relief	325-6236
4P-9381	Line As - Fuel Injector	279-4984
4P-9382	Line As - Fuel Injector	279-4985
4P-9385	Line As - Fuel Injector	279-4986
4P-9386	Line As - Fuel Injector	279-4987
4S-6707	Piston - Clutch	215-1686
4S-8472	Hood As	296-1355
4S-8708	Housing - Clutch	216-3557
4W-0452	Seal As - Camshaft	325-6191
4W-2446	Damper As	279-4990
5G-3612	Cap Gp	295-6419
5M-1988	Piston - Steer	219-9691
5M-1990	Pilot - Piston	229-8233
5M-1998	Drum Steering	213-6952
5M-2026	Hubdriving	216-4471
5M-5822	Gear - Pump Drive	247-4120
5M-6120	Gear - Sun	213-8740
5M-6198	Shaft - Planet	297-7245
5M-6199	Shaft As - Planet	215-1694
5M-6208	Gear - Ring	247-4121
5M-6210	Shaft - Planet	219-9683
5M-6211	Shaft - Planet	219-9684
5M-7841	Gear - Ring	214-0525
5M-7864	Pump Gp - Scavenge	226-0169
5M-7869	Gear - Ring	214-0530
5M-7875	Carrier - Front	213-4495
5M-7900	Bolt - Hex Head	311-9349
5P-7807	Bearing - Ball	314-8502
5S-0073	Plate - Steering	302-2692
5S-1211	Cover - Valve	314-8665
5S-4557	Bearing	311-9360
5S-4863	Holder As - Cage	215-1732
5S-6795	Chamber As	242-3437
5S-6796	Drum - Inner	213-6953 (Drum), 230-7115 (Steering Clutch Kit)
5S-9062	Spacer	363-7463
5S-9080	Pulley - Alt Drive	264-5883
6H-3957	Bearing - Ball	311-9358
6I-1346	Pump Gp - Oil	295-5674
6N-0714	Pulley - Alt	264-5884
6N-1036	Gear - Oil Pump	279-4991
6N-1965	Line As - Fuel Injector	250-7535
6N-1966	Line As - Fuel Injector	250-7536
6N-8413	Housing - Pump	325-6110
6P-6653	Plate - Guide	226-0208
6T-1980	Collar - Idler End	226-0210
7C-4297	Seal As - Camshaft	325-6192
7G-2474	Gear - Planet	300-2577
7G-2475	Gear - Planet	223-4815
7G-2476	Gear - Planet	223-4816
7G-2513	Gear - Planet	215-1734
7G-6576	Cage As	216-7859
7J-1333	Bearing - Sleeve	295-6408
7J-1334	Bearing - Sleeve	325-6015
7J-4827	Yoke	299-2070
7N-0165	Core As - Oil Cooler	295-5670

(Continued)

Sales Model 572G (Continued)

Original Part Number	Part Name	Classic Part Number
7N-2871	Line As - Fuel Injector	319-8172
7N-2872	Line As - Fuel Injector	319-8173
7N-2874	Line As - Fuel Injector	298-2779
7N-2875	Line As - Fuel Injector	298-2780
7N-2876	Line As - Fuel Injector	298-2781
7N-2949	Pulley	264-5887
7N-2957	Cover - Rad Cap	361-1722
7N-3515	Gear - Camshaft	314-8669
7N-3536	Gear - Fuel	279-4993
7N-5810	Gear As - Idler	233-2179
7N-5815	Gear - Camshaft Rr	233-2181
7N-5819	Gear - Hyd Pump Drive	215-1758
7N-5825	Gear - Drive	215-1759
7N-5910	Impeller - Pump	314-8686
7N-9146	Gear - Flywheel Starter	279-4995
7N-9312	Damper As - Camshaft	299-2005
7N-9805	Pin - Piston	295-6438
7S-3161	Lifter - Valve	279-4996
7S-6723	Bracket - Alternator	299-1978
7S-6964	Gear - Ring	214-0532
7S-7809	Cap As - Radiator	295-6417
7S-7973	Guard - Final Drive Wear	213-9110
7T-0119	Support As	299-2066
7T-2036	Cap As - Filter	361-1721
7W-0450	Gear - Water Pump	279-4997
7W-0507	Gear - Oil Pump Drive	279-4998
7W-0508	Gear - Fuel Pump Drive	296-1351
7W-5687	Hub - Camshaft	314-8684
8H-1383	Rod - Tie	299-2051
8H-2810	Case As - Filter	314-8512
8H-7980	Piston	226-0249
8H-9806	Gear - Shaft Drive	325-6091
8J-2652	Shaft	299-2054
8J-2653	Lever As	299-2015
8J-2654	Lever As	299-2016
8J-2880	Cap - Bearing	295-6420
8M-0874	Plunger As - Valve	311-9439
8M-7166	Housing - Screen	297-7192
8M-8619	Cage - Bearing	217-7725
8M-8623	Gear - Sun	213-8755
8M-8628	Flange - Joint	217-9776
8M-8642	Housing - Clutch	219-9669
8M-8644	Housing - Clutch	215-1782
8M-8646	Plate As - Center	216-3583
8M-8650	Piston - Clutch	217-9778
8M-8652	Shaft	297-7252
8M-8677	Carrier - Planet	213-4449
8N-0002	Trunnion As	314-8728
8N-0875	Valve - Exhaust	247-6893 (Valve), 241-3381 (Valve Kit)
8N-1187	Head Gp - Cylinder	242-3435
8N-1721	Rod As - Conn	269-5291
8N-2510	Shaft	325-6208
8N-2641	Sleeve	325-6210
8N-3251	Shaft As - Rocker Arm	314-8711
8N-3325	Arm Gp - Rocker	314-8623
8N-3327	Arm Gp - Rocker	314-8624
8N-5305	Spacer	363-7464
8N-5929	Cover - Water Pump	296-1349
8N-6796	Head Gp - Cylinder	269-5290
8N-7315	Tube As - Outlet	325-6232
8N-8225	Bearing - Main	314-8652
8N-9733	Line As - Fuel Injector	319-8174
8P-0187	Nut - Adjusting	219-9676
8P-7790	Valve Gp - Press	247-4437
8S-0248	Breather As	325-6033
8S-0493	Shaft As - Pump	325-6198
8S-1061	Pilot As - Spring	226-0227
8S-3970	Chamber As	242-3438
8S-7818	Bracket	226-0211
9M-1500	Shaft - Planet	219-9685
9M-1502	Cage - Bearing	219-9686
9M-1995	Gear - Sun	213-8756
9M-1996	Shaft - Planet	215-1875
9M-2028	Gear - Sun	214-0959
9M-2049	Gear - Ring	214-0533
9M-3025	Cover As	299-2001
9M-4789	Shaft - Gov Control	297-7256
9N-5251	Piston Gp - Basic	250-6557 (Liner Kit)
9N-5769	Cover - Housing	325-6050
9P-0418	Cage	223-6311
9P-0620	Cage - Pinion Bearing	221-1052
9P-5363	Piston - Clutch	219-9687
9P-5379	Housing - Clutch	215-1904
9S-2354	Manifold - Exhaust	261-0888
9S-2355	Manifold - Exhaust	261-0891
9S-3955	Cage - Gear Bearing	216-7874
9S-5265	Shaft As	215-1945
9S-6875	Pinion - Final Drive	217-7705
9S-8679	Chamber As	325-6042
9S-8789	Plate - Clutch	302-2712

Sales Model 583

Original Part Number	Part Name	Classic Part Number
2S-2140	Nut (7/8-14)	188-5857
2S-6346	Shoe -Track	188-5311
2S-6347	Shoe -Track	188-5613
2S-6357	Shoe -Track	281-6373
2S-6364	Shoe -Track	188-5615
6L-9212	Idler Gp	200-9238
6T-6782	Segment Gp - Sprocket	188-5641 (sprocket)
7H-3599	Bolt - Track	188-5639
7S-9093	Shoe -Track	188-5617
7S-9094	Shoe -Track	188-5313
7S-9096	Shoe -Track	281-6370
7S-9101	Shoe -Track	281-6372
8P-6256	Roller Gp - Carrier	188-5612
8S-0386	Shoe -Track Master	188-5312
8S-0387	Shoe -Track Master	188-5614
8S-0388	Shoe -Track Master	188-5616
8S-0390	Shoe -Track Master	281-6371
8S-0391	Shoe -Track Master	188-5618
8S-0392	Shoe -Track Master	188-5314
8S-0394	Shoe -Track Master	315-6693
8S-0395	Bolt Master	188-5640
8S-0915	Shoe -Track Master	281-6374
9S-7221	Idler As.	188-5610
9W-8937	Link As	188-5310

Sales Model 583C, 583E

Original Part Number	Part Name	Classic Part Number
1A-2846	Cap As - Filler	311-9368
1F-2254	Bushing - Stem	314-8510
1M-7250	Bowl - Pre-cleaner	360-2296
1M-9444	Retainer - Spring	299-2046
2D-5658	Bearing - Ball	301-4628
2F-5721	Bearing - Ball	311-9354
2K-3632	Yoke As	297-4866
2P-0483	Chamber As	256-4760
2S-3966	Ring - Seal	297-7237
2S-4015	Plunger As - Valve	311-9438
3F-7445	Bearing - Sleeve	314-8508
3H-3378	Gear As - Pump	298-2795
3L-1425	Bearing - Ball	311-9356
3S-2420	Pilot As - Spring	226-2733
4B-1455	Cap As - Filter	361-1719
4F-4974	Clamp	311-9373
4N-7526	Seal As - Pump	311-9454
4N-9180	Seal As - Pump	311-9455
5S-1211	Cover - Valve	314-8665
6H-3957	Bearing - Ball	311-9358
6L-7816	Seal - o-Ring	314-8542
7B-2420	Ferrule - Director	314-8517
7H-0602	Dog - Clutch	314-8515
7M-4603	Body - Fuel Valve	311-9348
7M-4926	Retainer - Pin	314-8538
7S-7809	Cap As - Radiator	295-6417
8F-5104	Screen As - Oil Pan	314-8539
8H-1993	Valve - Inlet	256-4765 (Valve Kit)
8H-1994	Valve - Exhaust	256-4765 (Valve Kit)
9S-8493	Bolt - Connecting Rod	311-9351

Sales Model 583H

Original Part Number	Part Name	Classic Part Number
115-0637	Pump Gp	226-0160
190-8609	Valve - Fill	360-2288
1A-2846	Cap As - Filler	311-9368
1F-2254	Bushing - Stem	314-8510
1M-4153	Carrier - Planet	213-1114
1M-4155	Gear - Ring	214-0519
1M-4156	Gear - Ring	214-0520
1M-4167	Shaft - Planet	219-9700
1M-4171	Cage - Bearing	216-7460
1M-4344	Cage As	216-7466
1M-6603	Gear - Transfer	217-7720
1M-6604	Gear - Transfer	217-7715
1M-9444	Retainer - Spring	299-2046
1P-0005	Pump Gp - Fuel Transfer	256-4756
1P-4145	Valve Gp - Press	247-4436
1S-1888	Bracket - Lamp	297-7147
1S-2268	Piston	226-2726
1S-2269	Sleeve	226-2720
1S-4701	Pulley - Alt	264-5866
1S-8753	Plate - Coupling	308-9910
1S-8754	Joint Gp - Univ	308-9873
1T-0224	Carrier - Ring	239-7928
1T-0228	Housing - Rotating	216-7467
1T-0231	Retainer - Bearing	319-3471
1T-0237	Flange As - Output	239-7929
1T-0256	Gear - Pump Drive	239-7930

(Continued)

Sales Model 583H (Continued)

Original Part Number	Part Name	Classic Part Number
1T-0595	Carrier - Wheel	239-7939
1T-0611	Converter As	235-1804 (Repair Kit)
1T-0670	Converter As	235-1805 (Repair Kit)
1T-1389	Carrier - Bearing	247-4124
2D-5658	Bearing - Ball	301-4628
2F-5721	Bearing - Ball	311-9354
2K-3592	Boss	314-8501
2K-3632	Yoke As	297-4866
2M-3339	Piston - Clutch	221-7944
2N-9297	Retainer - Spring	314-8535
2P-0483	Chamber As	256-4760
2P-0484	Chamber As	247-3296
2P-1604	Piston - Steering	219-9694
2P-1605	Pilot - Piston	219-9695
2P-4611	Pipe - Exhaust	365-8821
2P-9038	Drum - Steering	216-7821
2S-3913	Cage - Gear Bearing	217-7722
2S-3966	Ring - Seal	297-7237
2S-4015	Plunger As - Valve	311-9438
2S-4357	Pinion - Final Drive	217-7706
2S-7873	Pump Gp	226-0162
2S-7917	Gear - Pump Drive	247-4119
2S-7920	Pump Gp - Scavenge	217-2594
2S-8892	Pulley - Fan Drive	264-5874
3B-6218	Muffler As	247-2672
3F-7445	Bearing - Sleeve	314-8508
3H-3378	Gear As - Pump	298-2795
3K-3124	Muffler - Trap	247-2673
3L-1425	Bearing - Ball	311-9356
3P-3259	Cage - Bearing	217-7728
3P-4002	Pump Gp - Gear	217-2595
3P-4850	Gear As - Oil Pump	308-9848
3P-4855	Pump Gp	217-2596
3P-9394	Shaft - Planet	215-1680
3S-1262	Retainer	308-9915
3S-1274	Shaft - Center	215-1681
3S-2252	Manifold - Exhaust	261-0887
3S-2420	Pilot As - Spring	226-2733
3S-6989	Nut - Spanner	219-9701
3S-7306	Flange - Drum	216-7827
3S-7308	Cage - Pinion Bearing	219-9702
3S-7517	Pulley - Belt Adjustable	264-5876
3S-7519	Pulley - Damper As	264-5877
3S-8735	Guard As	226-2723
3S-8736	Guard As	226-9992
3S-9919	Shaft As	239-7959
4F-4974	Clamp	311-9373
4M-0503	Gear As - Oil Pump	297-7184
4M-8967	Gear - Sun	219-9661
4M-9215	Gear - Pump Idler	311-9391
4N-4577	Muffler As	308-9877
4N-4880	Pump Gp - Fuel Transfer	256-4758
4N-7526	Seal As - Pump	311-9454
4N-9180	Seal As - Pump	311-9455
4S-5833	Spacer	239-7961
4S-7793	Thrower - Crankshaft Oil	367-6085
4S-8472	Hood As	296-1355
5G-3612	Cap Gp	295-6419
5H-1719	Pump Gp - Final Drive Oil	226-0168
5L-8856	Coupling - Exhaust	311-9379
5M-0549	Gear - Transmission	215-1689
5M-3947	Shaft - Planet	223-6318
5M-3996	Gear - Ring	214-0527
5M-3998	Gear - Ring	214-0528
5M-3999	Shaft - Transmission	215-1693
5M-4427	Gear - Sun	214-0529
5M-6673	Guard - F Idler Rh	226-2735
5M-6674	Guard - F Idler Lh	226-2736
5M-7306	Cylinder	226-2737
5M-7953	Carrier As	239-7977
5M-7955	Shaft As - Planet	364-5273
5M-8007	Gear - Ring	239-7932
5N-8501	Head As - Cylinder	256-4762
5N-8657	Manifold - Exhaust	261-0886
5P-7807	Bearing - Ball	314-8502
5S-0135	Cage - Pinion Bearing	222-1766
5S-0464	Gear - First Reduction	216-7852
5S-0465	Pinion - Reduction	216-7853
5S-1211	Cover - Valve	314-8665
5S-4557	Bearing	311-9360
5S-9080	Pulley - Alt Drive	264-5883
6H-3957	Bearing - Ball	311-9358
6L-7816	Seal - o-Ring	314-8542
6L-8968	Coupling - Exhaust	311-9381
6N-8847	Guide - Valve	314-8523
6P-0549	Guard - Final Drive Wear	223-4812
6P-2776	Gear - Final Drive	217-7718
6P-3593	Support	229-8231
6P-3596	Hub	222-1764
6P-3597	Retainer	222-1770
6T-4481	Shaft - Planet	221-7946
7B-2420	Ferrule - Director	314-8517
7G-2492	Gear - Planet	239-7933
7H-0602	Dog - Clutch	314-8515
7H-7630	Spacer	239-7962
7M-1184	Housing As	219-9704
7M-1185	Housing As	219-9705
7M-1186	Housing As	219-9706
7M-1195	Housing - Clutch	219-9707
7M-4603	Body - Fuel Valve	311-9348
7M-4926	Retainer - Pin	314-8538
7M-5289	Hub - Steering	217-7736
7M-5756	Gear - Ring	214-0531

(Continued)

Sales Model 583H (Continued)

Original Part Number	Part Name	Classic Part Number
7M-6621	Pump Gp - Oil	226-0172
7N-2957	Cover - Rad Cap	361-1722
7S-7400	Pump Gp	226-0173
7S-7809	Cap As - Radiator	295-6417
7T-2036	Cap As - Filter	361-1721
7Y-1517	Pipe As - Tail	301-5246
8E-7455	Gear - Planet	221-7947
8E-7456	Gear - Planet	221-7948
8F-5104	Screen As - Oil Pan	314-8539
8H-1993	Valve - Inlet	256-4765 (Valve Kit)
8H-1994	Valve - Exhaust	256-4765 (Valve Kit)

Original Part Number	Part Name	Classic Part Number
8H-2434	Drum - Steering	216-7862
8H-2810	Case As - Filter	314-8512
8H-9806	Gear - Shaft Drive	325-6091
8M-0874	Plunger As - Valve	311-9439
8M-2549	Rod As - Connector	314-8537
8M-7166	Housing - Screen	297-7192
8M-8161	Flange - Shaft	215-1781
8N-6004	Head As - Cylinder	247-3369
8P-5849	Plate As	223-6323
8P-8221	Plate - Guide	226-2748

Original Part Number	Part Name	Classic Part Number
8S-2123	Cage - Final Drive Bearing	217-7726
8S-2126	Spacer - Hub Bearing	222-1767
9H-1918	Gear - Bevel	219-9698
9H-1980	Pinion - Bevel	219-9699
9H-5233	Piston - Clutch	219-9708
9H-5433	Spacer	239-7963
9M-3025	Cover As	299-2001
9M-4789	Shaft - Gov Control	297-7256
9P-3663	Carrier - Planet	213-6939
9P-6592	Gear - Planet	215-1915
9P-6594	Gear - Planet	215-1921
9S-1026	Cage - Gear Bearing	216-7873
9S-8493	Bolt - Connecting Rod	311-9351

Sales Model 583K

Original Part Number	Part Name	Classic Part Number
115-0637	Pump Gp	226-0160
190-8609	Valve - Fill	360-2288
1M-4153	Carrier - Planet	213-1114
1M-4155	Gear - Ring	214-0519
1M-4156	Gear - Ring	214-0520
1M-4167	Shaft - Planet	219-9700
1M-4171	Cage - Bearing	216-7460
1M-4344	Cage As	216-7466
1M-6603	Gear - Transfer	217-7720
1M-6604	Gear - Transfer	217-7715
1M-9444	Retainer - Spring	299-2046
1P-4145	Valve Gp - Press	247-4436
1S-1888	Bracket - Lamp	297-7147
1S-2268	Piston	226-2726
1S-2269	Sleeve	226-2720
1S-4701	Pulley - Alt	264-5866
1T-0224	Carrier - Ring	239-7928
1T-0228	Housing - Rotating	216-7467
1T-0231	Retainer - Bearing	319-3471

Original Part Number	Part Name	Classic Part Number
1T-0237	Flange As - Output	239-7929
1T-0256	Gear - Pump Drive	239-7930
1T-0595	Carrier - Wheel	239-7939
1T-0611	Converter As	235-1804 (Repair Kit)
1T-0670	Converter As	235-1805 (Repair Kit)
1T-1389	Carrier - Bearing	247-4124
244-1090	Alarm - Back up	360-2345
2D-5658	Bearing - Ball	301-4628
2F-5721	Bearing - Ball	311-9354
2K-3632	Yoke As	297-4866
2M-3339	Piston - Clutch	221-7944
2N-9297	Retainer - Spring	314-8535
2P-0484	Chamber As	247-3296
2P-1126	Pulley - Camshaft	264-5868
2P-1129	Pulley - Tightener	264-5869
2P-1604	Piston - Steering	219-9694

Original Part Number	Part Name	Classic Part Number
2P-1605	Pilot - Piston	219-9695
2P-9037	Drum - Steering Clutch	219-9696
2P-9038	Drum - Steering	216-7821
2P-9039	Hub - Steering	219-9697
2S-3913	Cage - Gear Bearing	217-7722
2S-3966	Ring - Seal	297-7237
2S-4357	Pinion - Final Drive	217-7706
2S-7917	Gear - Pump Drive	247-4119
3H-3378	Gear As - Pump	298-2795
3L-1425	Bearing - Ball	311-9356
3P-1757	Yoke As - Idler	226-2729
3P-3259	Cage - Bearing	217-7728
3P-4002	Pump Gp - Gear	217-2595
3P-4850	Gear As - Oil Pump	308-9848
3P-4855	Pump Gp	217-2596
3P-9394	Shaft - Planet	215-1680
3S-1262	Retainer	308-9915

(Continued)

Sales Model 583K (Continued)

Original Part Number	Part Name	Classic Part Number
3S-1274	Shaft - Center	215-1681
3S-2252	Manifold - Exhaust	261-0887
3S-2420	Pilot As - Spring	226-2733
3S-6989	Nut - Spanner	219-9701
3S-7306	Flange - Drum	216-7827
3S-7308	Cage - Pinion Bearing	219-9702
3S-8735	Guard As	226-2723
3S-8736	Guard As	226-9992
3S-9919	Shaft As	239-7959
4M-0503	Gear As - Oil Pump	297-7184
4M-8967	Gear - Sun	219-9661
4N-4577	Muffler As	308-9877
4N-4880	Pump Gp - Fuel Transfer	256-4758
4N-5390	Pulley - Alt Drive	264-5879
4N-7526	Seal As - Pump	311-9454
4N-9180	Seal As - Pump	311-9455
4S-5833	Spacer	239-7961
4S-7793	Thrower - Crankshaft Oil	367-6085
4S-8472	Hood As	296-1355
5G-3612	Cap Gp	295-6419
5H-1719	Pump Gp - Final Drive Oil	226-0168
5M-0549	Gear - Transmission	215-1689
5M-3947	Shaft - Planet	223-6318
5M-3996	Gear - Ring	214-0527
5M-3999	Shaft - Transmission	215-1693
5M-4427	Gear - Sun	214-0529
5M-6673	Guard - F Idler Rh	226-2735
5M-6674	Guard - F Idler Lh	226-2736
5M-7306	Cylinder	226-2737
5M-7953	Carrier As	239-7977
5M-7955	Shaft As - Planet	364-5273
5M-8007	Gear - Ring	239-7932

Original Part Number	Part Name	Classic Part Number
5N-8501	Head As - Cylinder	256-4762
5N-8657	Manifold - Exhaust	261-0886
5P-7807	Bearing - Ball	314-8502
5S-0135	Cage - Pinion Bearing	222-1766
5S-0464	Gear - First Reduction	216-7852
5S-0465	Pinion - Reduction	216-7853
5S-1211	Cover - Valve	314-8665
5S-4557	Bearing	311-9360
5S-9080	Pulley - Alt Drive	264-5883
6H-3957	Bearing - Ball	311-9358
6L-7816	Seal - o-Ring	314-8542
6L-8968	Coupling - Exhaust	311-9381
6N-0762	Pulley - Fan	264-5885
6N-5437	Muffler As	247-2674
6P-0549	Guard - Final Drive Wear	223-4812
6P-2776	Gear - Final Drive	217-7718
6P-3593	Support	229-8231
6P-3596	Hub	222-1764
6P-3597	Retainer	222-1770
6T-1933	Collar - Idler End	226-2746
6T-4481	Shaft - Planet	221-7946
7B-2420	Ferrule - Director	314-8517
7G-2492	Gear - Planet	239-7933
7H-7630	Spacer	239-7962
7M-1184	Housing As	219-9704
7M-1185	Housing As	219-9705
7M-1186	Housing As	219-9706
7M-1195	Housing - Clutch	219-9707
7M-4603	Body - Fuel Valve	311-9348
7M-4926	Retainer - Pin	314-8538
7M-5756	Gear - Ring	214-0531
7M-8395	Piston - Clutch	223-6322

Original Part Number	Part Name	Classic Part Number
7N-2957	Cover - Rad Cap	361-1722
7N-3350	Gear As - Pump Drive	319-3437
7S-7400	Pump Gp	226-0173
7S-7809	Cap As - Radiator	295-6417
7T-2036	Cap As - Filter	361-1721
8E-7455	Gear - Planet	221-7947
8E-7456	Gear - Planet	221-7948
8H-1993	Valve - Inlet	256-4765 (Valve Kit)
8H-1994	Valve - Exhaust	256-4765 (Valve Kit)
8H-2810	Case As - Filter	314-8512
8H-9806	Gear - Shaft Drive	325-6091
8M-0874	Plunger As - Valve	311-9439
8M-7166	Housing - Screen	297-7192
8M-8161	Flange - Shaft	215-1781
8N-6004	Head As - Cylinder	247-3369
8P-5849	Plate As	223-6323
8P-8221	Plate - Guide	226-2748
8S-2123	Cage - Final Drive Bearing	217-7726
8S-2126	Spacer - Hub Bearing	222-1767
8S-3487	Gear As - Ring	221-7949
8S-3491	Housing As	221-7950
9H-1918	Gear - Bevel	219-9698
9H-1980	Pinion - Bevel	219-9699
9H-5233	Piston - Clutch	219-9708
9H-5433	Spacer	239-7963
9M-3025	Cover As	299-2001
9M-4789	Shaft - Gov Control	297-7256
9P-3663	Carrier - Planet	213-6939
9P-6592	Gear - Planet	215-1915
9P-6594	Gear - Planet	215-1921
9S-1026	Cage - Gear Bearing	216-7873
9S-8493	Bolt - Connecting Rod	311-9351

Sales Model 594

Original Part Number	Part Name	Classic Part Number
102-1561	Lifter As - Valve	311-9402
1A-2846	Cap As - Filler	311-9368
1M-4153	Carrier - Planet	213-1114
1M-4155	Gear - Ring	214-0519
1M-4156	Gear - Ring	214-0520
1M-4167	Shaft - Planet	219-9700
1M-4171	Cage - Bearing	216-7460
1P-4145	Valve Gp - Press	247-4436
1P-8005	Gasket - Chamber	314-8527
1S-1888	Bracket - Lamp	297-7147
1S-4701	Pulley - Alt	264-5866
1S-8753	Plate - Coupling	308-9910
1S-8754	Joint Gp - Univ	308-9873
1T-0224	Carrier - Ring	239-7928
1T-0228	Housing - Rotating	216-7467
1T-0231	Retainer - Bearing	319-3471
1T-0237	Flange As - Output	239-7929
1T-0256	Gear - Pump Drive	239-7930
1T-0595	Carrier - Wheel	239-7939
1T-0611	Converter As	235-1804 (Repair Kit)
1T-1389	Carrier - Bearing	247-4124
1W-3062	Retainer As	311-9445
1W-5105	Ring Gp - Piston	311-9446
2D-5658	Bearing - Ball	301-4628
2F-5721	Bearing - Ball	311-9354
2K-3632	Yoke As	297-4866
2M-1129	Cap - Support	239-7974
2M-2150	Nut - Spanner	239-7965
2M-3339	Piston - Clutch	221-7944
2M-5588	Gear - Final Drive	239-7936
2M-5589	Pinion - Final Drive	239-7942
2M-6920	Hub - Steering	239-7968
2M-6960	Cage - Gear Bearing	239-7971
2M-6984	Drum	239-7946
2M-8762	Drum - Steering	239-7944
2N-3220	Gear - Oil Pump Drive	311-9392
2N-9297	Retainer - Spring	314-8535
2P-1554	Gear - Ring	239-7931
2P-1606	Piston - Steering	239-7948
2P-1607	Pilot - Piston	239-7975
2P-6159	Pulley - Fan Drive	264-5873
2S-3966	Ring - Seal	297-7237
2S-7264	Pump As - Fuel Injector	311-9442
2S-7873	Pump Gp	226-0162
2S-7917	Gear - Pump Drive	247-4119
2S-7920	Pump Gp - Scavenge	217-2594
2S-8961	Pulley - Tightener	264-5875
3F-7445	Bearing - Sleeve	314-8508
3P-2811	Flange	239-7976
3P-3259	Cage - Bearing	217-7728
3P-4002	Pump Gp - Gear	217-2595
3P-4850	Gear As - Oil Pump	308-9848
3P-4855	Pump Gp	217-2596
3P-6269	Cage - Pinion Bearing	239-7972
3P-9394	Shaft - Planet	215-1680
3S-1261	Shaft - Center	239-7958
3S-1262	Retainer	308-9915
3S-9919	Shaft As	239-7959
4M-0433	Shaft - Steer	239-7960
4M-0503	Gear As - Oil Pump	297-7184
4M-1001	Pump Gp - Final Drive Oil	226-0166
4M-8967	Gear - Sun	219-9661
4M-9214	Shaft - Pump Drive	314-8543
4M-9215	Gear - Pump Idler	311-9391
4M-9216	Gear - Pump Drive	311-9390
4N-3664	Guide - Valve	314-8524
4N-7526	Seal As - Pump	311-9454
4N-9180	Seal As - Pump	311-9455
4S-5833	Spacer	239-7961
4S-8906	Insert	311-9397
4S-8908	Insert	311-9399
4S-8909	Insert - Valve Seat	311-9400
5G-3612	Cap Gp	295-6419
5H-5553	Screw -Tappet Adjustable	311-9451
5M-0549	Gear - Transmission	215-1689
5M-3947	Shaft - Planet	223-6318
5M-3996	Gear - Ring	214-0527
5M-3999	Shaft - Transmission	215-1693
5M-4427	Gear - Sun	214-0529
5M-7953	Carrier As	239-7977
5M-7990	Gear - Sun	239-7938
5M-8007	Gear - Ring	239-7932
5N-8879	Manifold - Exhaust	261-0898
5N-9055	Manifold - Exhaust	261-0890
5P-7807	Bearing - Ball	314-8502
5S-1211	Cover - Valve	314-8665
5S-1757	Insert - Seat	311-9401
5S-5746	Retainer - Guard	319-3472
5S-9080	Pulley - Alt Drive	264-5883
6H-3957	Bearing - Ball	311-9358
6L-7816	Seal - o-Ring	314-8542
6L-8585	Gear - Gov Drive	314-8526
6N-6969	Chamber As	247-3299
6N-7295	Manifold - Exhaust	261-0903
6N-8847	Guide - Valve	314-8523
6T-4481	Shaft - Planet	221-7946
7B-2420	Ferrule - Director	314-8517
7G-2492	Gear - Planet	239-7933
7H-0602	Dog - Clutch	314-8515
7H-7630	Spacer	239-7962

(Continued)

Sales Model 594 (Continued)

Original Part Number	Part Name	Classic Part Number
7M-1184	Housing As	219-9704
7M-1185	Housing As	219-9705
7M-1186	Housing As	219-9706
7M-1195	Housing - Clutch	219-9707
7M-1249	Piston - Clutch	215-1748
7M-4603	Body - Fuel Valve	311-9348
7M-4926	Retainer - Pin	314-8538
7M-5756	Gear - Ring	214-0531
7M-7431	Service Gp - Valve	314-8550
7M-7817	Valve - Inlet	311-9474
7M-8395	Piston - Clutch	223-6322
7M-8397	Housing As	239-7956
7N-9810	Pin - Piston	311-9432
7S-1579	Nut - Spanner	239-7964
7S-5787	Chamber As	247-3300
7S-6104	Gear - Sun	239-7934
7S-7400	Pump Gp	226-0173
7S-7809	Cap As - Radiator	295-6417
7S-7975	Guard - Final Drive Wear	239-7966
8E-7455	Gear - Planet	221-7947
8E-7456	Gear - Planet	221-7948
8F-5104	Screen As - Oil Pan	314-8539
8F-8858	Button Valve	314-8511
8H-2810	Case As - Filter	314-8512
8M-0874	Plunger As - Valve	311-9439
8M-2549	Rod As - Connector	314-8537
8M-4014	Insert - Seat Exhaust	311-9398
8M-7166	Housing - Screen	297-7192
8M-8161	Flange - Shaft	215-1781
8N-2275	Bearing - Sleeve	311-9365
8N-3723	Valve - Exhaust	311-9472
8N-7780	Shield - Oil	314-8544
8N-9174	Liner - Cylinder	314-8531
8P-5849	Plate As	223-6323
8P-7396	Hub - Planet Gear	239-7967
8P-7595	Washer - Thrust	239-7940
8P-7639	Gear - Planet	239-7935
8S-3487	Gear As - Ring	221-7949
8S-3491	Housing As	221-7950
8S-3617	Chamber As	247-3302
9G-7993	Cage - Gr Bearing Rh	239-7973
9H-5233	Piston - Clutch	219-9708
9H-5433	Spacer	239-7963
9M-3025	Cover As	299-2001
9P-3663	Carrier - Planet	213-6939
9P-6592	Gear - Planet	215-1915
9P-6594	Gear - Planet	215-1921
9S-8493	Bolt - Connecting Rod	311-9351
7T-2036	Cap As - Filter	361-1721
8S-5438	Muffler As	360-7896
5M-7955	Shaft As - Planet	364-5273
7N-2957	Cover - Rad Cap	361-1722
190-8609	Valve - Fill	360-2288

Sales Model 594H

Original Part Number	Part Name	Classic Part Number
102-1561	Lifter As - Valve	311-9402
115-0637	Pump Gp	226-0160
190-8609	Valve - Fill	360-2288
1M-4153	Carrier - Planet	213-1114
1M-4155	Gear - Ring	214-0519
1M-4156	Gear - Ring	214-0520
1M-4167	Shaft - Planet	219-9700
1M-4171	Cage - Bearing	216-7460
1P-4145	Valve Gp - Press	247-4436
1P-8005	Gasket - Chamber	314-8527
1S-1888	Bracket - Lamp	297-7147
1S-4701	Pulley - Alt	264-5866
1S-8753	Plate - Coupling	308-9910
1S-8754	Joint Gp - Univ	308-9873
1T-0224	Carrier - Ring	239-7928
1T-0228	Housing - Rotating	216-7467
1T-0231	Retainer - Bearing	319-3471
1T-0237	Flange As - Output	239-7929
1T-0256	Gear - Pump Drive	239-7930
1T-0595	Carrier - Wheel	239-7939
1T-0611	Converter As	235-1804 (Repair Kit)
1T-1389	Carrier - Bearing	247-4124
1W-3062	Retainer As	311-9445
244-1090	Alarm - Backup	360-2345
2D-5658	Bearing - Ball	301-4628
2F-5721	Bearing - Ball	311-9354
2K-3632	Yoke As	297-4866
2M-1129	Cap - Support	239-7974
2M-2150	Nut - Spanner	239-7965
2M-3339	Piston - Clutch	221-7944
2M-5588	Gear - Final Drive	239-7936
2M-5589	Pinion - Final Drive	239-7942
2M-6920	Hub - Steering	239-7968
2M-6960	Cage - Gear Bearing	239-7971
2M-6984	Drum	239-7946
2M-8762	Drum - Steering	239-7944
2N-3220	Gear - Oil Pump Drive	311-9392

(Continued)

Sales Model 594H (Continued)

Original Part Number	Part Name	Classic Part Number
2N-9297	Retainer - Spring	314-8535
2P-1554	Gear - Ring	239-7931
2P-1606	Piston - Steering	239-7948
2P-1607	Pilot - Piston	239-7975
2P-6159	Pulley - Fan Drive	264-5873
2S-3966	Ring - Seal	297-7237
2S-7264	Pump As - Fuel Injector	311-9442
2S-7917	Gear - Pump Drive	247-4119
2S-8961	Pulley - Tightener	264-5875
3F-7445	Bearing - Sleeve	314-8508
3P-2811	Flange	239-7976
3P-3259	Cage - Bearing	217-7728
3P-4089	Gear As - Ring	239-7952
3P-4094	Housing As	239-7954
3P-4096	Gear As - Ring	239-7953
3P-6269	Cage - Pinion Bearing	239-7972
3P-9394	Shaft - Planet	215-1680
3S-1261	Shaft - Center	239-7958
3S-1262	Retainer	308-9915
3S-9919	Shaft As	239-7959
4M-0433	Shaft - Steer	239-7960
4M-1001	Pump Gp - Final Drive Oil	226-0166
4M-8967	Gear - Sun	219-9661
4M-9214	Shaft - Pump Drive	314-8543
4M-9215	Gear - Pump Idler	311-9391
4M-9216	Gear - Pump Drive	311-9390
4N-3664	Guide - Valve	314-8524
4N-5184	Muffler As	360-7874
4N-7526	Seal As - Pump	311-9454
4N-9180	Seal As - Pump	311-9455
4S-5833	Spacer	239-7961
4S-8906	Insert	311-9397
4S-8908	Insert	311-9399
4S-8909	Insert - Valve Seat	311-9400
5G-3612	Cap Gp	295-6419
5H-5553	Screw -Tappet Adjustable	311-9451
5M-0549	Gear - Transmission	215-1689
5M-3947	Shaft - Planet	223-6318
5M-3996	Gear - Ring	214-0527
5M-3999	Shaft - Transmission	215-1693
5M-4427	Gear - Sun	214-0529
5M-7953	Carrier As	239-7977
5M-7955	Shaft As - Planet	364-5273
5M-7990	Gear - Sun	239-7938
5M-8007	Gear - Ring	239-7932
5N-8879	Manifold - Exhaust	261-0898
5N-9055	Manifold - Exhaust	261-0890
5P-7807	Bearing - Ball	314-8502
5S-1211	Cover - Valve	314-8665
5S-1757	Insert - Seat	311-9401
5S-5746	Retainer - Guard	319-3472
5S-9080	Pulley - Alt Drive	264-5883
6H-3957	Bearing - Ball	311-9358
6L-7816	Seal - o-Ring	314-8542
6L-8585	Gear - Gov Drive	314-8526
6N-6969	Chamber As	247-3299
6N-7295	Manifold - Exhaust	261-0903
6N-8847	Guide - Valve	314-8523
6T-4481	Shaft - Planet	221-7946
7B-2420	Ferrule - Director	314-8517
7G-2492	Gear - Planet	239-7933
7H-0602	Dog - Clutch	314-8515
7M-1185	Housing As	219-9705
7M-1186	Housing As	219-9706
7M-1195	Housing - Clutch	219-9707
7M-4603	Body - Fuel Valve	311-9348
7M-4926	Retainer - Pin	314-8538
7M-7817	Valve - Inlet	311-9474
7N-2957	Cover - Rad Cap	361-1722
7N-9810	Pin - Piston	311-9432
7S-1579	Nut - Spanner	239-7964
7S-5787	Chamber As	247-3300
7S-6104	Gear - Sun	239-7934
7S-7400	Pump Gp	226-0173
7S-7809	Cap As - Radiator	295-6417
7S-7975	Guard - Final Drive Wear	239-7966
7T-2036	Cap As - Filter	361-1721
8E-7455	Gear - Planet	221-7947
8E-7456	Gear - Planet	221-7948
8F-8858	Button Valve	314-8511
8H-2810	Case As - Filter	314-8512
8M-0874	Plunger As - Valve	311-9439
8M-2549	Rod As - Connector	314-8537
8M-4014	Insert - Seat Exhaust	311-9398
8M-7166	Housing - Screen	297-7192
8M-8161	Flange - Shaft	215-1781
8N-0597	Pulley	264-5890
8N-2275	Bearing - Sleeve	311-9365
8N-3723	Valve - Exhaust	311-9472
8N-7780	Shield - Oil	314-8544
8N-9174	Liner - Cylinder	314-8531
8P-4734	Housing As	239-7955
8P-4735	Piston - Clutch	239-7949
8P-7396	Hub - Planet Gear	239-7967
8P-7595	Washer - Thrust	239-7940
8P-7639	Gear - Planet	239-7935
8S-3617	Chamber As	247-3302
9G-7993	Cage - Gr Bearing Rh	239-7973
9H-5233	Piston - Clutch	219-9708
9H-5433	Spacer	239-7963
9M-3025	Cover As	299-2001
9P-3663	Carrier - Planet	213-6939
9P-6592	Gear - Planet	215-1915
9P-6594	Gear - Planet	215-1921
9S-8493	Bolt - Connecting Rod	311-9351

Cat® Classic™ Parts for Scrapers

Scrapers have long, productive lives. They are designed to load, haul, dump, and compact at maximum efficiency. Maintenance costs, to keep the machines running efficiently at all times, need to be re-evaluated as the machine ages. To help you manage your maintenance costs, Caterpillar offers Classic parts for several models of scrapers.

Cat® Classic™ parts provide owners of older Cat products with low cost repair alternatives that minimize the risk associated with non-genuine parts.

Cat Classic parts coverage for scrapers includes:

- Differential
- Engine
- Final Drive
- Hitch
- Moving Undercarriage
- Transmission
- ...and many more.

Sales Model 613

Original Part Number	Part Name	Classic Part Number
121-7746	Precleaner As	360-2311
1M-7250	Bowl - Precleaner	360-2296
1S-4701	Pulley - Alt	264-5866
1T-0020	Wheel - Turbine	297-4862
1T-1987	Housing - Rotating	297-4864
1V-1080	Housing - Bearing Spt	260-0775
1V-1687	Wheel	226-5990
1V-2281	Carrier - Planet	226-5984
1V-2992	Gear - Diff Bevel	224-1301
1V-5724	Diff Gp	260-0776
244-1090	Alarm - Back up	360-2345
2D-5658	Bearing - Ball	301-4628
2F-5721	Bearing - Ball	311-9354
2K-0535	Nut	299-2026
2K-5073	Bushing	299-1989
2K-5977	Yoke	226-5992
2P-4404	Housing As	226-8027
2P-4409	Gear - Ring	226-7981
2P-4611	Pipe - Exhaust	365-8821
2P-5081	Muffler As	360-7872
2V-6220	Shaft - Planet	221-9073
3J-9133	Bearing - Sleeve	361-1691
3K-7020	Gear - Planet	221-9074
3K-7021	Gear - Ring	221-9075
3P-5672	Yoke	223-6313
3S-7987	Shaft - Planet	226-6074
3S-7996	Gear - Ring	226-6087
3V-8777	Gear - Spiral	297-7176
4B-1455	Cap As - Filter	361-1719
4E-8534	Retainer - Seal	300-2588
4F-4974	Clamp	311-9373
4K-6212	Shaft - Bevel Pinion	223-4806
4K-9598	Retainer	297-7235
4N-2954	Sleeve - Camshaft	299-2059
4N-4539	Sleeve	314-8720
4S-8670	Shaft - Planet	300-2590
4S-8687	Piston - Clutch	226-8008
4S-8713	Gear - Ring	226-6090
4W-2042	Spacer	325-6217
5D-0470	Valve Gp	314-8549
5K-1068	Retainer - Seal	260-0786
5K-5933	Cover As	247-4125
5P-7807	Bearing - Ball	314-8502
5S-0884	Gear - Ring	226-7982
5S-1211	Cover - Valve	314-8665
5S-9062	Spacer	363-7463
5S-9080	Pulley - Alt Drive	264-5883
5V-1271	Diff Gp	299-2008
5V-5917	Pinion - Diff Bevel	297-7224
6K-2085	Shaft - Bevel Pinion	221-9102
6P-7704	Carrier - Ring	314-8658
6W-1629	Shaft - Bevel Pinion	297-7250
7G-2480	Gear - Planet	226-6091
7G-2481	Gear - Planet	226-6092
7G-2485	Gear - Planet	226-7983
7G-2830	Ring - Seal	295-6441
7J-1309	Bearing - Aligning	360-2275
7J-6883	Shaft	256-4778
7J-6886	Pin	256-4787
7N-2957	Cover - Rad Cap	361-1722
7S-7809	Cap As - Radiator	295-6417
7S-8443	Muffler	247-2675
7T-2036	Cap As - Filter	361-1721
8B-5972	Bearing - Ball	314-8503
8D-2628	Nut	299-2027
8H-2810	Case As - Filter	314-8512
8J-3431	Pin	256-4789
8K-6015	Gear - Bevel Ring	221-9076
8K-6283	Gear - Sun	221-9077
8V-3134	Pinion - Bevel	260-0788
8V-3135	Gear - Differential Bevel	260-0783
8V-3136	Gear - Differential Bevel	253-1442
9C-4811	Hub As	224-1300

(Continued)

Sales Model 613 (Continued)

Original Part Number	Part Name	Classic Part Number
9C-8204	Shaft - Bevel Pinion	319-3474
9C-8205	Gear - Bevel	319-8175
9C-9773	Gear - Differential Bevel	302-2672

Original Part Number	Part Name	Classic Part Number
9K-3413	Gear - Bevel Ring	223-4807

Sales Model 613B

Original Part Number	Part Name	Classic Part Number
121-7746	Precleaner As	360-2311
1M-7250	Bowl - Precleaner	360-2296
1T-0020	Wheel - Turbine	297-4862
1T-1987	Housing - Rotating	297-4864
1V-1080	Housing - Bearing Spt	260-0775
1V-1687	Wheel	226-5990
1V-2281	Carrier - Planet	226-5984
1V-2992	Gear - Diff Bevel	224-1301
1V-5724	Diff Gp	260-0776
244-1090	Alarm - Back up	360-2345
2D-5658	Bearing - Ball	301-4628
2K-0535	Nut	299-2026
2K-5073	Bushing	299-1989
2K-5977	Yoke	226-5992
2P-4404	Housing As	226-8027
2P-4409	Gear - Ring	226-7981
2P-5081	Muffler As	360-7872
2V-6220	Shaft - Planet	221-9073
3J-9133	Bearing - Sleeve	361-1691
3K-7020	Gear - Planet	221-9074
3K-7021	Gear - Ring	221-9075
3P-5672	Yoke	223-6313

Original Part Number	Part Name	Classic Part Number
3S-7987	Shaft - Planet	226-6074
3S-7996	Gear - Ring	226-6087
3V-8777	Gear - Spiral	297-7176
4B-1455	Cap As - Filter	361-1719
4E-8534	Retainer - Seal	300-2588
4F-4974	Clamp	311-9373
4K-6212	Shaft - Bevel Pinion	223-4806
4K-9598	Retainer	297-7235
4N-2954	Sleeve - Camshaft	299-2059
4N-4539	Sleeve	314-8720
4S-8670	Shaft - Planet	300-2590
4S-8687	Piston - Clutch	226-8008
4S-8713	Gear - Ring	226-6090
4W-2042	Spacer	325-6217
5K-1068	Retainer - Seal	260-0786
5K-5933	Cover As	247-4125
5P-7807	Bearing - Ball	314-8502
5S-0884	Gear - Ring	226-7982
5S-1211	Cover - Valve	314-8665
5S-9062	Spacer	363-7463
5V-1271	Diff Gp	299-2008
5V-5917	Pinion - Diff Bevel	297-7224
6K-2085	Shaft - Bevel Pinion	221-9102
6P-7704	Carrier - Ring	314-8658

Original Part Number	Part Name	Classic Part Number
6W-1629	Shaft - Bevel Pinion	297-7250
7G-2480	Gear - Planet	226-6091
7G-2481	Gear - Planet	226-6092
7G-2485	Gear - Planet	226-7983
7G-2830	Ring - Seal	295-6441
7J-1309	Bearing - Aligning	360-2275
7S-7809	Cap As - Radiator	295-6417
7S-8443	Muffler	247-2675
7T-2036	Cap As - Filter	361-1721
8D-2628	Nut	299-2027
8H-2810	Case As - Filter	314-8512
8J-3431	Pin	256-4789
8K-6015	Gear - Bevel Ring	221-9076
8K-6283	Gear - Sun	221-9077
8V-3134	Pinion - Bevel	260-0788
8V-3135	Gear - Differential Bevel	260-0783
8V-3136	Gear - Differential Bevel	253-1442
9C-4811	Hub As	224-1300
9C-8204	Shaft - Bevel Pinion	319-3474
9C-8205	Gear - Bevel	319-8175
9C-9773	Gear - Differential Bevel	302-2672
9K-3413	Gear - Bevel Ring	223-4807

Sales Model 613C

Original Part Number	Part Name	Classic Part Number
176-9273	Piston	297-4860
1S-4701	Pulley - Alt	264-5866
1T-0020	Wheel - Turbine	297-4862
1T-1987	Housing - Rotating	297-4864

Original Part Number	Part Name	Classic Part Number
1W-4623	Muffler As	360-9622
244-1090	Alarm - Back up	360-2345
2F-5721	Bearing - Ball	311-9354
2K-0535	Nut	299-2026
2V-5715	Bushing	299-1987

Original Part Number	Part Name	Classic Part Number
3J-9133	Bearing - Sleeve	361-1691
3P-5672	Yoke	223-6313
3T-9496	Plate - Retainer	299-2042
3V-8777	Gear - Spiral	297-7176

(Continued)

Sales Model 613C (Continued)

Original Part Number	Part Name	Classic Part Number
4E-8534	Retainer - Seal	300-2588
4K-9598	Retainer	297-7235
4N-2954	Sleeve - Camshaft	299-2059
4N-4539	Sleeve	314-8720
4V-7543	Retainer	281-1699
4V-8534	Shaft - Planet	281-1700
4V-8538	Gear - Ring	288-8720
4W-2042	Spacer	325-6217
5D-0470	Valve Gp	314-8549
5G-3612	Cap Gp	295-6419
5P-7807	Bearing - Ball	314-8502
5S-4557	Bearing	311-9360
5S-9062	Spacer	363-7463
5S-9080	Pulley - Alt Drive	264-5883

Original Part Number	Part Name	Classic Part Number
5T-1362	Bearing - Spider	325-6011
5V-1271	Diff Gp	299-2008
5V-5917	Pinion - Diff Bevel	297-7224
6P-7742	Shaft - Planet	281-1695
6P-8003	Gear - Planet	281-1689
6T-3009	Piston - Clutch	297-7226
6T-6987	Piston - Clutch	297-7227
6W-1629	Shaft - Bevel Pinion	297-7250
7G-3454	Gear - Planet	300-2578
7G-3707	Piston - Clutch	302-2691
7G-4281	Housing As - Support	297-7201
7J-6461	Crown	325-6054
7T-2036	Cap As - Filter	361-1721

Original Part Number	Part Name	Classic Part Number
8B-5972	Bearing - Ball	314-8503
8D-2628	Nut	299-2027
8H-2810	Case As - Filter	314-8512
8K-6282	Gear - Sun	281-1698
8V-3134	Pinion - Bevel	260-0788
8V-3135	Gear - Differential Bevel	260-0783
8V-3136	Gear - Differential Bevel	253-1442
9C-1528	Gear - Planet	223-4802
9C-8204	Shaft - Bevel Pinion	319-3474
9C-8205	Gear - Bevel	319-8175
9C-9773	Gear - Differential Bevel	302-2672
9G-1231	Plate	297-7232
9G-8117	Housing As	302-2686
9G-9764	Yoke As	319-3478
9N-4460	Housing As	297-7203

Sales Model 621

Original Part Number	Part Name	Classic Part Number
100-7860	Valve - Inlet	270-4360 (Valve), 270-4362 (Valve Kit)
104-4253	Line As - Fuel Injector	279-4988
104-4254	Line As - Fuel Injector	279-4989
111-8015	Gasket As - Head	279-4977
122-9405	Bracket As	325-6005
131-3815	Seal Gp - Basic	325-6193
148-7455	Valve - Exhaust	270-4361
167-8123	Damper As	299-2006
172-5185	Shaft - Water Pump	325-6201
172-5188	Shaft - Water Pump	325-6202
172-5189	Impeller - Pump	295-5687
172-5190	Impeller - Pump	325-6111
172-6712	Impeller - Pump	325-6112
172-7767	Pump Gp - Water	296-1365

Original Part Number	Part Name	Classic Part Number
196-0028	Gear As - Idler	364-5259
1A-2846	Cap As - Filler	311-9368
1J-6746	Pin	256-4817
1N-3576	Block Gp - Cylinder	279-4978
1N-3958	Elbow	325-6087
1P-9945	Bracket As - Fan	296-1344
1P-9946	Shaft - Fan	325-6194
1S-4701	Pulley - Alt	264-5866
1T-0662	Turbine - Conv	235-1819
1T-0665	Ring - Clamp	308-9918
1W-1669	Piston	325-6158
1W-1695	Pump Gp	279-4980
1W-1698	Housing - Transfer Pump	296-1356
1W-4402	Gear - Camshaft	279-4981
1W-4405	Gear - Crankshaft	279-4982
1W-5912	Tappet As - Guide	325-6223
1W-6541	Plunger As	325-6173

Original Part Number	Part Name	Classic Part Number
244-1090	Alarm - Back up	360-2345
2D-7694	Shaft - Pivot	256-4774
2F-5721	Bearing - Ball	311-9354
2J-5394	Collar	256-4779
2J-5531	Collar	256-4780
2J-5662	Shaft - Pivot	256-4775
2P-1170	Shaft As - Gear	296-1367
2P-1738	Plate As - Oil Pan	325-6164
2P-1739	Tube As - Pump	325-6229
2P-1757	Hub - Fan Pulley	296-1357
2P-1781	Spacer - Oil Pump	325-6214
2P-2519	Tube As - Inlet	325-6230
2P-2719	Pipe	363-7454
2P-6128	Pulley	264-5872
2P-6245	Shaft As - Pump	325-6197
2S-2781	Plunger - Relief	311-9435
2S-4015	Plunger As - Valve	311-9438

(Continued)

Sales Model 621 (Continued)

Original Part Number	Part Name	Classic Part Number
2W-1086	Cover As - Cylinder Head	325-6049
2W-2621	Valve - Inlet	247-6892 (Valve), 241-3381 (Valve Kit)
2W-7255	Shaft - Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear - Water Pump	325-6088
3H-7161	Pin	256-4819
3H-7162	Collar	256-4830
3J-5190	Cap - Bearing	256-4837
3J-6497	Screw - Adjusting	256-4825
3J-9133	Bearing - Sleeve	361-1691
3J-9710	Bearing - Sleeve	256-4793
3L-1425	Bearing - Ball	311-9356
3S-2710	Shaft - Planet	260-0779
3S-9466	Bearing - Sleeve	314-8509
3S-9975	Piston - Clutch	260-0778
4B-1455	Cap As - Filter	361-1719
4E-0403	Gear - Planet	260-0781
4M-9215	Gear - Pump Idler	311-9391
4N-2954	Sleeve - Camshaft	299-2059
4N-4864	Pump Gp - Fuel Transfer	242-3442
4N-7693	Crankshaft As	242-3439
4N-9587	Shield - Heat	297-7260
4P-3546	Valve As - Relief	325-6236
4P-9381	Line As - Fuel Injector	279-4984
4P-9382	Line As - Fuel Injector	279-4985
4P-9385	Line As - Fuel Injector	279-4986
4P-9386	Line As - Fuel Injector	279-4987
4W-0452	Seal As - Camshaft	325-6191
4W-2446	Damper As	279-4990
5D-0470	Valve Gp	314-8549
5F-6393	Shaft	308-9928
5J-1825	Pin	367-6080
5J-4924	Shaft - Pivot	256-4777
5J-4929	Bearing	256-4796
5J-7980	Pin	256-4783
5J-7981	Pin	256-4784
5J-7983	Pin	256-4785
5J-8052	Trunnion	256-4843
5P-7807	Bearing - Ball	314-8502
5S-1211	Cover - Valve	314-8665
5S-4557	Bearing	311-9360
5S-6795	Chamber As	242-3437
5S-9062	Spacer	363-7463
5S-9080	Pulley - Alt Drive	264-5883
6H-3957	Bearing - Ball	311-9358
6I-1346	Pump Gp - Oil	295-5674
6N-1036	Gear - Oil Pump	279-4991
6N-8413	Housing - Pump	325-6110
7B-0503	Ballstud	308-9801
7C-4297	Seal As - Camshaft	325-6192
7G-2500	Gear - Planet	296-1350
7J-3390	Pin - Hitch	256-4786
7N-0110	Core As - Oil Cooler	319-3435
7N-1164	Mount As	295-5451
7N-2871	Line As - Fuel Injector	319-8172
7N-2872	Line As - Fuel Injector	319-8173
7N-2874	Line As - Fuel Injector	298-2779
7N-2875	Line As - Fuel Injector	298-2780
7N-2876	Line As - Fuel Injector	298-2781
7N-3515	Gear - Camshaft	314-8669
7N-3536	Gear - Fuel	279-4993
7N-5910	Impeller - Pump	314-8686
7N-9146	Gear - Flywheel Starter	279-4995
7N-9312	Damper As - Camshaft	299-2005
7N-9805	Pin - Piston	295-6438
7S-3161	Lifter - Valve	279-4996
7S-6723	Bracket - Alternator	299-1978
7S-7809	Cap As - Radiator	295-6417
7W-0450	Gear - Water Pump	279-4997
7W-0507	Gear - Oil Pump Drive	279-4998
7W-0508	Gear - Fuel Pump Drive	296-1351
8H-2810	Case As - Filter	314-8512
8H-9806	Gear - Shaft Drive	325-6091
8J-1300	Pin As	256-4788
8M-0874	Plunger As - Valve	311-9439
8M-2549	Rod As - Connector	314-8537
8M-8652	Shaft	297-7252
8N-0002	Trunnion As	314-8728
8N-0875	Valve - Exhaust	247-6893 (Valve), 241-3381 (Valve Kit)
8N-1187	Head Gp - Cylinder	242-3435
8N-1721	Rod As - Conn	269-5291
8N-2510	Shaft	325-6208
8N-2641	Sleeve	325-6210
8N-3251	Shaft As - Rocker Arm	314-8711
8N-3325	Arm Gp - Rocker	314-8623
8N-3327	Arm Gp - Rocker	314-8624
8N-5305	Spacer	363-7464
8N-5929	Cover - Water Pump	296-1349
8N-6796	Head Gp - Cylinder	269-5290
8N-7315	Tube As - Outlet	325-6232
8N-8225	Bearing - Main	314-8652
8N-9733	Line As - Fuel Injector	319-8174
8P-6949	Plate - Retainer	260-0787
8S-0248	Breather As	325-6033
8S-0493	Shaft As - Pump	325-6198
8S-3970	Chamber As	242-3438
8S-7716	Manifold - Exhaust	295-0415

(Continued)

Sales Model 621 (Continued)

Original Part Number	Part Name	Classic Part Number
8S-7717	Manifold - Exhaust	261-0894
8S-7718	Manifold - Exhaust	295-0416
8S-9184	Gear As	260-0785

Original Part Number	Part Name	Classic Part Number
9J-3346	Plate As - Trunnion	256-4839
9J-9427	Bearing - Sleeve	361-1695
9J-9543	Pin As	256-4791

Original Part Number	Part Name	Classic Part Number
9M-4789	Shaft - Gov Control	297-7256
9N-5404	Piston Gp - Basic	250-6558 (Liner Kit)
9N-5769	Cover - Housing	325-6050
9S-8679	Chamber As	325-6042
9S-8789	Plate - Clutch	302-2712

Sales Model 621B

Original Part Number	Part Name	Classic Part Number
111-8015	Gasket As - Head	279-4977
129-3068	Rebuild Kit, W/P (Str Brgs)	363-7455
131-3815	Seal Gp - Basic	325-6193
167-8123	Damper As	299-2006
172-5185	Shaft - Water Pump	325-6201
172-5188	Shaft - Water Pump	325-6202
172-5189	Impeller - Pump	295-5687
172-5190	Impeller - Pump	325-6111
172-6712	Impeller - Pump	325-6112
172-7767	Pump Gp - Water	296-1365
177-9024	Adapter - Damper	299-1956
180-3767	Adapter - Damper	299-1957
196-0028	Gear As - Idler	364-5259
1N-3576	Block Gp - Cylinder	279-4978
1N-3958	Elbow	325-6087
1P-9945	Bracket As - Fan	296-1344
1P-9946	Shaft - Fan	325-6194
1S-4701	Pulley - Alt	264-5866
1T-0662	Turbine - Conv	235-1819
1T-0665	Ring - Clamp	308-9918
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1698	Housing - Transfer Pump	296-1356

Original Part Number	Part Name	Classic Part Number
1W-2491	Muffler As	360-7871
1W-4402	Gear - Camshaft	279-4981
1W-4405	Gear - Crankshaft	279-4982
244-1090	Alarm - Back up	360-2345
2F-5721	Bearing - Ball	311-9354
2N-7942	Spacer	363-7462
2P-1170	Shaft As - Gear	296-1367
2P-1738	Plate As - Oil Pan	325-6164
2P-1739	Tube As - Pump	325-6229
2P-1757	Hub - Fan Pulley	296-1357
2P-1781	Spacer - Oil Pump	325-6214
2P-2519	Tube As - Inlet	325-6230
2P-5680	Turbine - Converter	308-9942
2P-6245	Shaft As - Pump	325-6197
2S-4015	Plunger As - Valve	311-9438
2W-1086	Cover As - Cylinder Head	325-6049
2W-2621	Valve - Inlet	247-6892 (Valve), 241-3381 (Valve Kit)
2W-5540	Core, Radiator (Folded)	363-7452
2W-7255	Shaft - Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear - Water Pump	325-6088
3L-1425	Bearing - Ball	311-9356

Original Part Number	Part Name	Classic Part Number
3S-2710	Shaft - Planet	260-0779
3S-9975	Piston - Clutch	260-0778
4B-1455	Cap As - Filter	361-1719
4E-0403	Gear - Planet	260-0781
4N-3714	Chamber, Precom	363-7450
4N-4864	Pump Gp - Fuel Transfer	242-3442
4N-7693	Crankshaft As	242-3439
4P-3546	Valve As - Relief	325-6236
4S-8472	Hood As	296-1355
4W-0452	Seal As - Camshaft	325-6191
5F-6393	Shaft	308-9928
5J-1825	Pin	367-6080
5L-8856	Coupling - Exhaust	311-9379
5P-7807	Bearing - Ball	314-8502
5S-1211	Cover - Valve	314-8665
5S-4557	Bearing	311-9360
5S-6795	Chamber As	242-3437
5S-9062	Spacer	363-7463
5S-9080	Pulley - Alt Drive	264-5883
6H-3957	Bearing - Ball	311-9358
6I-1346	Pump Gp - Oil	295-5674
6N-1036	Gear - Oil Pump	279-4991
6N-8413	Housing - Pump	325-6110
6N-9743	Support - Muffler	308-9940
7C-0942	Adapter As	302-2636
7C-3039	Core, Oil Cooler	363-7451
7G-2500	Gear - Planet	296-1350

(Continued)

Sales Model 621B (Continued)

Original Part Number	Part Name	Classic Part Number
7N-0110	Core As - Oil Cooler	319-3435
7N-1164	Mount As	295-5451
7N-2957	Cover - Rad Cap	361-1722
7N-3515	Gear - Camshaft	314-8669
7N-3536	Gear - Fuel	279-4993
7N-5910	Impeller - Pump	314-8686
7N-9146	Gear - Flywheel Starter	279-4995
7N-9805	Pin - Piston	295-6438
7S-3161	Lifter - Valve	279-4996
7S-6723	Bracket - Alternator	299-1978
7S-7809	Cap As - Radiator	295-6417
7T-2036	Cap As - Filter	361-1721
7W-0450	Gear - Water Pump	279-4997
7W-0507	Gear - Oil Pump Drive	279-4998
7W-0508	Gear - Fuel Pump Drive	296-1351
7W-1902	Adapter - Fuel Nozzle	299-1955

Original Part Number	Part Name	Classic Part Number
7W-2164	Core As - Oil Cooler	299-1996
8D-4402	Yoke	365-8823
8D-8829	Bearing - Sleeve	361-1692
8H-2810	Case As - Filter	314-8512
8H-9806	Gear - Shaft Drive	325-6091
8J-7596	Bearing - Sleeve	361-1693
8M-0874	Plunger As - Valve	311-9439
8M-8652	Shaft	297-7252
8N-0875	Valve - Exhaust	247-6893 (Valve), 241-3381 (Valve Kit)
8N-1187	Head Gp - Cylinder	242-3435
8N-1721	Rod As - Conn	269-5291
8N-2510	Shaft	325-6208
8N-2641	Sleeve	325-6210
8N-3251	Shaft As - Rocker Arm	314-8711

Original Part Number	Part Name	Classic Part Number
8N-3325	Arm Gp - Rocker	314-8623
8N-3327	Arm Gp - Rocker	314-8624
8N-5305	Spacer	363-7464
8N-5929	Cover - Water Pump	296-1349
8N-7315	Tube As - Outlet	325-6232
8N-8225	Bearing - Main	314-8652
8P-6949	Plate - Retainer	260-0787
8S-0248	Breather As	325-6033
8S-0493	Shaft As - Pump	325-6198
8S-3970	Chamber As	242-3438
8S-9184	Gear As	260-0785
9J-8323	Trunnion	361-1713
9J-9427	Bearing - Sleeve	361-1695
9M-4789	Shaft - Gov Control	297-7256
9S-8679	Chamber As	325-6042
9W-4702	Stator - Converter	308-9939
9W-9930	Mount As	295-6437
9Y-2988	Breather As	361-1716

Sales Model 621E

Original Part Number	Part Name	Classic Part Number
129-3068	Rebuild Kit, W/P (Str Brgs)	363-7455
131-3815	Seal Gp - Basic	325-6193
177-9024	Adapter - Damper	299-1956
180-3767	Adapter - Damper	299-1957
196-0028	Gear As - Idler	364-5259
1S-4701	Pulley - Alt	264-5866
1T-0662	Turbine - Conv	235-1819
1T-0665	Ring - Clamp	308-9918
1W-1669	Piston	325-6158
1W-1698	Housing - Transfer Pump	296-1356
1W-2491	Muffler As	360-7871

Original Part Number	Part Name	Classic Part Number
244-1090	Alarm - Back up	360-2345
2F-5721	Bearing - Ball	311-9354
2N-7942	Spacer	363-7462
2P-5680	Turbine - Converter	308-9942
2W-5540	Core, Radiator (Folded)	363-7452
3L-1425	Bearing - Ball	311-9356
3S-2710	Shaft - Planet	260-0779
4E-0403	Gear - Planet	260-0781
4N-3714	Chamber, Precom	363-7450
4P-9961	Line As - Fuel Injector	325-6115
4S-8472	Hood As	296-1355
5D-0470	Valve Gp	314-8549
5J-1825	Pin	367-6080
5P-7807	Bearing - Ball	314-8502

Original Part Number	Part Name	Classic Part Number
5S-1211	Cover - Valve	314-8665
5S-9062	Spacer	363-7463
5S-9080	Pulley - Alt Drive	264-5883
6H-3957	Bearing - Ball	311-9358
7C-0942	Adapter As	302-2636
7C-3039	Core, Oil Cooler	363-7451
7G-2500	Gear - Planet	296-1350
7G-2516	Gear - Planet	283-5203
7N-1164	Mount As	295-5451
7S-7809	Cap As - Radiator	295-6417
7T-2036	Cap As - Filter	361-1721
7W-1902	Adapter - Fuel Nozzle	299-1955
7W-2164	Core As - Oil Cooler	299-1996
8D-8829	Bearing - Sleeve	361-1692

(Continued)

Sales Model 621E (Continued)

Original Part Number	Part Name	Classic Part Number
8H-2810	Case As - Filter	314-8512
8J-7596	Bearing - Sleeve	361-1693
8N-2510	Shaft	325-6208
8N-2641	Sleeve	325-6210
8P-6949	Plate - Retainer	260-0787
8S-9184	Gear As	260-0785
9J-8323	Trunnion	361-1713
9J-9427	Bearing - Sleeve	361-1695
9L-6371	Rod	363-7459
9W-4702	Stator - Converter	308-9939
9W-9930	Mount As	295-6437
9Y-2988	Breather As	361-1716

Sales Model 627

Original Part Number	Part Name	Classic Part Number
111-8015	Gasket As - Head	279-4977
131-3815	Seal Gp - Basic	325-6193
172-5188	Shaft - Water Pump	325-6202
172-6712	Impeller - Pump	325-6112
196-0028	Gear As - Idler	364-5259
1J-6746	Pin	256-4817
1N-3576	Block Gp - Cylinder	279-4978
1P-4303	Head As - Cylinder	242-3434
1P-9945	Bracket As - Fan	296-1344
1P-9946	Shaft - Fan	325-6194
1P-9952	Impeller - Pump	314-8685
1S-4701	Pulley - Alt	264-5866
1T-0662	Turbine - Conv	235-1819
1T-0665	Ring - Clamp	308-9918
1T-1993	Wheel - Turbine	235-0920
1T-2052	Stator As	295-5683
1W-4405	Gear - Crankshaft	279-4982
244-1090	Alarm - Back up	360-2345
2D-7694	Shaft - Pivot	256-4774
2F-5721	Bearing - Ball	311-9354
2J-5394	Collar	256-4779
2J-5531	Collar	256-4780
2J-5662	Shaft - Pivot	256-4775
2P-1170	Shaft As - Gear	296-1367
2P-1738	Plate As - Oil Pan	325-6164
2P-1739	Tube As - Pump	325-6229
2P-1757	Hub - Fan Pulley	296-1357
2P-1781	Spacer - Oil Pump	325-6214
2P-2519	Tube As - Inlet	325-6230
2P-2719	Pipe	363-7454
2P-6128	Pulley	264-5872
2P-6245	Shaft As - Pump	325-6197
2S-2781	Plunger - Relief	311-9435
2S-4015	Plunger As - Valve	311-9438
2S-6739	Pulley - Tightener	298-2794
2W-1086	Cover As - Cylinder Head	325-6049
2W-2621	Valve - Inlet	247-6892 (Valve), 241-3381 (Valve Kit)
2W-7458	Crankshaft As	242-3439
2W-7678	Gear - Water Pump	325-6088
2W-9978	Core As - Oil Cooler	279-4983
3F-6185	Pin	295-5694
3H-7161	Pin	256-4819
3H-7162	Collar	256-4830
3J-5190	Cap - Bearing	256-4837
3J-6497	Screw - Adjusting	256-4825
3J-6559	Cap - Bearing	296-1346
3J-9133	Bearing - Sleeve	361-1691
3J-9710	Bearing - Sleeve	256-4793
3L-1425	Bearing - Ball	311-9356
3S-1262	Retainer	308-9915
3S-2710	Shaft - Planet	260-0779
3S-9466	Bearing - Sleeve	314-8509
3S-9975	Piston - Clutch	260-0778
4B-1455	Cap As - Filter	361-1719
4E-0403	Gear - Planet	260-0781
4J-2414	Trunnion	296-1370
4J-6374	Bearing - Sleeve	295-6407
4M-9215	Gear - Pump Idler	311-9391
4N-7693	Crankshaft As	242-3439
4P-3546	Valve As - Relief	325-6236
4S-8472	Hood As	296-1355
4W-0452	Seal As - Camshaft	325-6191
5D-0470	Valve Gp	314-8549
5F-6393	Shaft	308-9928
5J-1825	Pin	367-6080
5J-4924	Shaft - Pivot	256-4777
5J-4929	Bearing	256-4796
5J-7980	Pin	256-4783
5J-7981	Pin	256-4784
5J-7983	Pin	256-4785
5J-8052	Trunnion	256-4843
5M-7841	Gear - Ring	214-0525
5P-7807	Bearing - Ball	314-8502
5S-1211	Cover - Valve	314-8665
5S-4557	Bearing	311-9360
5S-6795	Chamber As	242-3437
5S-9062	Spacer	363-7463
5S-9080	Pulley - Alt Drive	264-5883
6H-3957	Bearing - Ball	311-9358
6I-1346	Pump Gp - Oil	295-5674
6N-1036	Gear - Oil Pump	279-4991

(Continued)

Sales Model 627 (Continued)

Original Part Number	Part Name	Classic Part Number
6N-8413	Housing - Pump	325-6110
6P-6739	Shaft - Planet	308-9929
7B-0503	Ballstud	308-9801
7C-4297	Seal As - Camshaft	325-6192
7G-2476	Gear - Planet	223-4816
7G-2500	Gear - Planet	296-1350
7J-1309	Bearing - Aligning	360-2275
7J-3390	Pin - Hitch	256-4786
7M-2167	Ring - Governor Control	308-9919
7N-0110	Core As - Oil Cooler	319-3435
7N-1164	Mount As	295-5451
7N-9145	Gear - Flywheel	279-4994
7N-9146	Gear - Flywheel Starter	279-4995
7N-9312	Damper As - Camshaft	299-2005
7N-9805	Pin - Piston	295-6438
7S-3161	Lifter - Valve	279-4996
7S-6723	Bracket - Alternator	299-1978
7S-7809	Cap As - Radiator	295-6417
7W-0450	Gear - Water Pump	279-4997
7W-0507	Gear - Oil Pump Drive	279-4998
7W-5687	Hub - Camshaft	314-8684
7Y-1517	Pipe As - Tail	301-5246

Original Part Number	Part Name	Classic Part Number
8H-9806	Gear - Shaft Drive	325-6091
8J-1300	Pin As	256-4788
8M-0874	Plunger As - Valve	311-9439
8M-2549	Rod As - Connector	314-8537
8M-7166	Housing - Screen	297-7192
8M-8652	Shaft	297-7252
8N-0002	Trunnion As	314-8728
8N-0875	Valve - Exhaust	247-6893 (Valve), 241-3381 (Valve Kit)
8N-1187	Head Gp - Cylinder	242-3435
8N-1721	Rod As - Conn	269-5291
8N-3180	Body As - Piston	250-6563
8N-3181	Piston Gp - Basic	250-6555 (Liner Kit)
8N-3182	Body As - Piston	250-6564 (Piston As), 250-6556 (Liner Kits)
8N-3183	Piston Gp - Basic	250-6556 (Liner Kit)
8N-3325	Arm Gp - Rocker	314-8623
8N-3327	Arm Gp - Rocker	314-8624
8N-5305	Spacer	363-7464
8N-5929	Cover - Water Pump	296-1349

Original Part Number	Part Name	Classic Part Number
8N-7315	Tube As - Outlet	325-6232
8N-8225	Bearing - Main	314-8652
8P-6949	Plate - Retainer	260-0787
8S-0248	Breather As	325-6033
8S-0493	Shaft As - Pump	325-6198
8S-0905	Muffler As	302-2690
8S-3970	Chamber As	242-3438
8S-7716	Manifold - Exhaust	295-0415
8S-7717	Manifold - Exhaust	261-0894
8S-7718	Manifold - Exhaust	295-0416
8S-9184	Gear As	260-0785
9H-2256	Pump Gp	311-9443
9J-3346	Plate As - Trunnion	256-4839
9J-9427	Bearing - Sleeve	361-1695
9J-9543	Pin As	256-4791
9M-1328	Bearing - Aligning	325-6018
9M-4789	Shaft - Gov Control	297-7256
9N-5251	Piston Gp - Basic	250-6557 (Liner Kit)
9N-5769	Cover - Housing	325-6050
9S-6129	Pulley - Alternator Drive	264-5891
9S-7079	Muffler As	247-2669
9S-8679	Chamber As	325-6042
9S-8789	Plate - Clutch	302-2712

Sales Model 627B

Original Part Number	Part Name	Classic Part Number
100-7860	Valve - Inlet	270-4360 (Valve), 270-4362 (Valve Kit)
102-1561	Lifter As - Valve	311-9402
104-4253	Line As - Fuel Injector	279-4988
104-4254	Line As - Fuel Injector	279-4989
111-8015	Gasket As - Head	279-4977

Original Part Number	Part Name	Classic Part Number
122-9405	Bracket As	325-6005
131-3815	Seal Gp - Basic	325-6193
148-7455	Valve - Exhaust	270-4361
160-6305	Cap - Bearing	295-5686
167-8123	Damper As	299-2006
170-0560	Rebuild Kit	363-7458
172-5185	Shaft - Water Pump	325-6201

Original Part Number	Part Name	Classic Part Number
172-5188	Shaft - Water Pump	325-6202
172-5189	Impeller - Pump	295-5687
172-5190	Impeller - Pump	325-6111
172-6712	Impeller - Pump	325-6112
172-7767	Pump Gp - Water	296-1365

(Continued)

Sales Model 627B (Continued)

Original Part Number	Part Name	Classic Part Number
177-9024	Adapter - Damper	299-1956
180-3767	Adapter - Damper	299-1957
196-0028	Gear As - Idler	364-5259
1A-2846	Cap As - Filler	311-9368
1F-2254	Bushing - Stem	314-8510
1H-4106	Pin As - Drawbar	325-6126
1J-6749	Screw - Adjustable	256-4824
1M-4153	Carrier - Planet	213-1114
1M-4155	Gear - Ring	214-0519
1M-4156	Gear - Ring	214-0520
1M-4167	Shaft - Planet	219-9700
1M-4171	Cage - Bearing	216-7460
1N-3576	Block Gp - Cylinder	279-4978
1N-3958	Elbow	325-6087
1P-4145	Valve Gp - Press	247-4436
1P-8005	Gasket - Chamber	314-8527
1P-9945	Bracket As - Fan	296-1344
1P-9946	Shaft - Fan	325-6194
1P-9952	Impeller - Pump	314-8685
1S-4701	Pulley - Alt	264-5866
1S-7114	Bolt	314-8500
1S-8753	Plate - Coupling	308-9910
1S-8754	Joint Gp - Univ	308-9873
1T-0224	Carrier - Ring	239-7928
1T-0228	Housing - Rotating	216-7467
1T-0231	Retainer - Bearing	319-3471
1T-0237	Flange As - Output	239-7929
1T-0256	Gear - Pump Drive	239-7930
1T-0595	Carrier - Wheel	239-7939
1T-0611	Converter As	235-1804 (Repair Kit)
1T-0662	Turbine - Conv	235-1819
1T-0665	Ring - Clamp	308-9918
1T-1389	Carrier - Bearing	247-4124
1T-1993	Wheel - Turbine	235-0920
1T-2052	Stator As	295-5683
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1695	Pump Gp	279-4980
1W-1698	Housing - Transfer Pump	296-1356
1W-3062	Retainer As	311-9445
1W-4402	Gear - Camshaft	279-4981
1W-4405	Gear - Crankshaft	279-4982
1W-5912	Tappet As - Guide	325-6223
1W-6541	Plunger As	325-6173
244-1090	Alarm - Back up	360-2345
2F-5721	Bearing - Ball	311-9354
2J-5394	Collar	256-4779
2J-5468	Pin - Pivot	256-4781
2J-5531	Collar	256-4780
2J-5649	Pin - Cylinder	256-4782
2J-5662	Shaft - Pivot	256-4775
2J-8489	Bearing - Sleeve	295-5691
2K-0535	Nut	299-2026
2L-4731	Adapter - Housing	311-9343
2M-1129	Cap - Support	239-7974
2M-2150	Nut - Spanner	239-7965
2M-3339	Piston - Clutch	221-7944
2M-5588	Gear - Final Drive	239-7936
2M-5589	Pinion - Final Drive	239-7942
2M-6920	Hub - Steering	239-7968
2M-6960	Cage - Gear Bearing	239-7971
2M-6984	Drum	239-7946
2M-8762	Drum - Steering	239-7944
2N-3220	Gear - Oil Pump Drive	311-9392
2N-7942	Spacer	363-7462
2N-9297	Retainer - Spring	314-8535
2P-0483	Chamber As	256-4760
2P-0484	Chamber As	247-3296
2P-1170	Shaft As - Gear	296-1367
2P-1554	Gear - Ring	239-7931
2P-1606	Piston - Steering	239-7948
2P-1607	Pilot - Piston	239-7975
2P-1738	Plate As - Oil Pan	325-6164
2P-1739	Tube As - Pump	325-6229
2P-1757	Hub - Fan Pulley	296-1357
2P-1781	Spacer - Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2519	Tube As - Inlet	325-6230
2P-2719	Pipe	363-7454
2P-3586	Piston - Clutch	260-0777
2P-5680	Turbine - Converter	308-9942
2P-6128	Pulley	264-5872
2P-6159	Pulley - Fan Drive	264-5873
2P-6245	Shaft As - Pump	325-6197
2S-2781	Plunger - Relief	311-9435
2S-3966	Ring - Seal	297-7237
2S-4015	Plunger As - Valve	311-9438
2S-6739	Pulley - Tightener	298-2794
2S-7264	Pump As - Fuel Injector	311-9442
2S-7873	Pump Gp	226-0162
2S-7917	Gear - Pump Drive	247-4119
2S-7920	Pump Gp - Scavenge	217-2594
2S-8961	Pulley - Tightener	264-5875
2V-5697	Cover As	299-1999
2V-5714	Gear - Ring	288-8716
2V-5715	Bushing	299-1987
2V-5722	Carrier - Planet	297-7164

(Continued)

Sales Model 627B (Continued)

Original Part Number	Part Name	Classic Part Number
2W-1086	Cover As - Cylinder Head	325-6049
2W-2621	Valve - Inlet	247-6892 (Valve), 241-3381 (Valve Kit)
2W-6757	Trunnion As	295-5678
2W-7255	Shaft - Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear - Water Pump	325-6088
2W-8494	Pulley - Alt	295-5692
2W-9978	Core As - Oil Cooler	279-4983
3F-4971	Pin	295-5693
3F-6185	Pin	295-5694
3F-6446	Pivot - Push Pole	256-4827
3F-6523	Pin - Clevis	256-4818
3F-6561	Arm As - Brace	256-4828
3F-6611	Socket - Joint	256-4829
3F-6612	Cap - Ball Joint	297-7155
3F-7445	Bearing - Sleeve	314-8508
3H-3378	Gear As - Pump	298-2795
3J-6043	Trunnion	319-3477
3J-9710	Bearing - Sleeve	256-4793
3K-5461	Wheel - Steering	308-9945
3L-1425	Bearing - Ball	311-9356
3N-3368	Pipe - Exhaust	311-9434
3P-2811	Flange	239-7976
3P-3208	Flange - Joint	301-4647
3P-3259	Cage - Bearing	217-7728
3P-4002	Pump Gp - Gear	217-2595
3P-4850	Gear As - Oil Pump	308-9848
3P-4855	Pump Gp	217-2596
3P-6269	Cage - Pinion Bearing	239-7972
3P-9394	Shaft - Planet	215-1680
3S-1261	Shaft - Center	239-7958
3S-1262	Retainer	308-9915
3S-2710	Shaft - Planet	260-0779
3S-9466	Bearing - Sleeve	314-8509
3S-9919	Shaft As	239-7959
3S-9975	Piston - Clutch	260-0778
3V-8777	Gear - Spiral	297-7176
4B-1455	Cap As - Filter	361-1719
4E-0403	Gear - Planet	260-0781
4E-8534	Retainer - Seal	300-2588
4F-4974	Clamp	311-9373
4J-1999	Ballstud	314-8625
4J-3583	Screw - Adjusting	297-7242
4K-6810	Retainer - Seal	300-2586
4K-8225	Pin - Cylinder	297-7215
4M-0433	Shaft - Steer	239-7960
4M-0503	Gear As - Oil Pump	297-7184
4M-1001	Pump Gp - Final Drive Oil	226-0166
4M-8845	Shaft - Planet	215-1685
4M-8967	Gear - Sun	219-9661
4M-9214	Shaft - Pump Drive	314-8543
4M-9215	Gear - Pump Idler	311-9391
4M-9216	Gear - Pump Drive	311-9390
4N-2954	Sleeve - Camshaft	299-2059
4N-3281	Line As - Fuel Injector	247-3362
4N-3282	Line As - Fuel Injector	247-3363
4N-3283	Line As - Fuel Injector	247-3364
4N-3284	Line As - Fuel Injector	247-3365
4N-3664	Guide - Valve	314-8524
4N-3714	Chamber, Precom	363-7450
4N-7526	Seal As - Pump	311-9454
4N-7693	Crankshaft As	242-3439
4N-8814	Line As - Fuel Injector	247-3366
4N-9180	Seal As - Pump	311-9455
4N-9587	Shield - Heat	297-7260
4P-3546	Valve As - Relief	325-6236
4P-9381	Line As - Fuel Injector	279-4984
4P-9382	Line As - Fuel Injector	279-4985
4P-9385	Line As - Fuel Injector	279-4986
4P-9386	Line As - Fuel Injector	279-4987
4S-5833	Spacer	239-7961
4S-8472	Hood As	296-1355
4S-8906	Insert	311-9397
4S-8908	Insert	311-9399
4S-8909	Insert - Valve Seat	311-9400
4V-5213	Spindle	299-2060
4W-0452	Seal As - Camshaft	325-6191
4W-2042	Spacer	325-6217
4W-2446	Damper As	279-4990
4W-9989	Gear As - Idler	302-2677
5D-0470	Valve Gp	314-8549
5F-6393	Shaft	308-9928
5F-7404	Nut - Bearing Lock	308-9878
5F-7993	Pin	319-3454
5H-5553	Screw -Tappet Adjustable	311-9451
5J-1825	Pin	367-6080
5J-4321	Trunnion	302-2700
5J-4798	Bearing As	256-4840
5J-4924	Shaft - Pivot	256-4777
5J-4929	Bearing	256-4796
5J-6417	Bearing	256-4798
5J-6418	Bearing - Sleeve	256-4799
5J-6419	Bearing - Sleeve	256-4800
5J-6421	Bearing	256-4801
5J-7980	Pin	256-4783
5J-7981	Pin	256-4784
5J-7983	Pin	256-4785
5J-8052	Trunnion	256-4843
5L-8856	Coupling - Exhaust	311-9379
5L-9738	Coupling - Exhaust	311-9380
5M-0549	Gear - Transmission	215-1689

(Continued)

Sales Model 627B (Continued)

Original Part Number	Part Name	Classic Part Number
5M-3947	Shaft - Planet	223-6318
5M-3996	Gear - Ring	214-0527
5M-3999	Shaft - Transmission	215-1693
5M-4427	Gear - Sun	214-0529
5M-7841	Gear - Ring	214-0525
5M-7900	Bolt - Hex Head	311-9349
5M-7953	Carrier As	239-7977
5M-7990	Gear - Sun	239-7938
5M-8007	Gear - Ring	239-7932
5N-8501	Head As - Cylinder	256-4762
5N-9055	Manifold - Exhaust	261-0890
5P-7807	Bearing - Ball	314-8502
5P-8194	Ring - Retaining	308-9920
5S-1211	Cover - Valve	314-8665
5S-1757	Insert - Seat	311-9401
5S-4557	Bearing	311-9360
5S-6795	Chamber As	242-3437
5S-9062	Spacer	363-7463
5S-9080	Pulley - Alt Drive	264-5883
5V-1271	Diff Gp	299-2008
5V-1480	Gear - Sun	288-8721
5V-4075	Gear - Planet	288-8722
5V-5917	Pinion - Diff Bevel	297-7224
6F-3183	Cap - Bearing	325-6038
6F-7523	Cap - Bearing	325-6039
6H-3957	Bearing - Ball	311-9358
6I-0341	Line As - Fuel Injector	325-6117
6I-0342	Line As - Fuel Injector	325-6118
6I-0343	Line As - Fuel Injector	325-6119
6I-0344	Line As - Fuel Injector	325-6120
6I-0345	Line As - Fuel Injector	325-6121
6I-0346	Line As - Fuel Injector	325-6122
6I-1346	Pump Gp - Oil	295-5674
6J-2326	Pin	319-3458
6J-7563	Pin	319-3459
6J-8805	Bearing As	256-4841
6J-9793	Bearing	256-4835
6L-7816	Seal - o-Ring	314-8542
6L-8585	Gear - Gov Drive	314-8526
6L-8968	Coupling - Exhaust	311-9381
6N-1036	Gear - Oil Pump	279-4991
6N-1965	Line As - Fuel Injector	250-7535
6N-1966	Line As - Fuel Injector	250-7536
6N-2789	Pulley	264-5886
6N-6969	Chamber As	247-3299
6N-7295	Manifold - Exhaust	261-0903
6N-8413	Housing - Pump	325-6110
6N-8847	Guide - Valve	314-8523
6N-9743	Support - Muffler	308-9940
6P-6739	Shaft - Planet	308-9929
6P-7704	Carrier - Ring	314-8658
6T-4481	Shaft - Planet	221-7946
6W-1629	Shaft - Bevel Pinion	297-7250
7B-0503	Ballstud	308-9801
7B-2420	Ferrule - Director	314-8517
7C-0942	Adapter As	302-2636
7C-3039	Core, Oil Cooler	363-7451
7C-4297	Seal As - Camshaft	325-6192
7G-2476	Gear - Planet	223-4816
7G-2492	Gear - Planet	239-7933
7G-2500	Gear - Planet	296-1350
7G-2511	Gear - Planet	260-0782
7G-2516	Gear - Planet	283-5203
7G-2830	Ring - Seal	295-6441
7G-5618	Manifold As	283-5204
7G-7724	Piston - Clutch	283-5206
7G-9555	Bearing - Spider	314-8721
7H-0602	Dog - Clutch	314-8515
7H-7630	Spacer	239-7962
7J-3390	Pin - Hitch	256-4786
7M-1184	Housing As	219-9704
7M-1185	Housing As	219-9705
7M-1186	Housing As	219-9706
7M-1195	Housing - Clutch	219-9707
7M-1249	Piston - Clutch	215-1748
7M-2167	Ring - Governor Control	308-9919
7M-4603	Body - Fuel Valve	311-9348
7M-4926	Retainer - Pin	314-8538
7M-5756	Gear - Ring	214-0531
7M-7431	Service Gp - Valve	314-8550
7M-7817	Valve - Inlet	311-9474
7M-8395	Piston - Clutch	223-6322
7M-8397	Housing As	239-7956
7N-0110	Core As - Oil Cooler	319-3435
7N-1164	Mount As	295-5451
7N-2871	Line As - Fuel Injector	319-8172
7N-2872	Line As - Fuel Injector	319-8173
7N-2874	Line As - Fuel Injector	298-2779
7N-2875	Line As - Fuel Injector	298-2780
7N-2876	Line As - Fuel Injector	298-2781
7N-2949	Pulley	264-5887
7N-3515	Gear - Camshaft	314-8669
7N-3536	Gear - Fuel	279-4993
7N-5910	Impeller - Pump	314-8686
7N-9145	Gear - Flywheel	279-4994
7N-9146	Gear - Flywheel Starter	279-4995
7N-9312	Damper As - Camshaft	299-2005
7N-9805	Pin - Piston	295-6438
7N-9810	Pin - Piston	311-9432
7S-1579	Nut - Spanner	239-7964
7S-3161	Lifter - Valve	279-4996
7S-5787	Chamber As	247-3300
7S-6104	Gear - Sun	239-7934
7S-6723	Bracket - Alternator	299-1978
7S-7400	Pump Gp	226-0173
7S-7809	Cap As - Radiator	295-6417
7S-7975	Guard - Final Drive Wear	239-7966

(Continued)

Sales Model 627B (Continued)

Original Part Number	Part Name	Classic Part Number
7S-8631	Shaft As	275-5296
7S-9749	Pulley - Gen Drive	264-5888
7T-2036	Cap As - Filter	361-1721
7W-0450	Gear - Water Pump	279-4997
7W-0507	Gear - Oil Pump Drive	279-4998
7W-0508	Gear - Fuel Pump Drive	296-1351
7W-1902	Adapter - Fuel Nozzle	299-1955
7W-2164	Core As - Oil Cooler	299-1996
7W-5687	Hub - Camshaft	314-8684
7W-5698	Pulley - Camshaft	295-5679
8D-2628	Nut	299-2027
8D-4402	Yoke	365-8823
8D-8829	Bearing - Sleeve	361-1692
8E-7455	Gear - Planet	221-7947
8E-7456	Gear - Planet	221-7948
8E-9795	Connector As	256-4851
8F-5104	Screen As - Oil Pan	314-8539
8F-8858	Button Valve	314-8511
8F-9365	Pin	319-3463
8H-1993	Valve - Inlet	256-4765 (Valve Kit)
8H-1994	Valve - Exhaust	256-4765 (Valve Kit)
8H-2810	Case As - Filter	314-8512
8H-9806	Gear - Shaft Drive	325-6091
8J-2652	Shaft	299-2054
8J-2653	Lever As	299-2015
8J-2654	Lever As	299-2016
8J-7596	Bearing - Sleeve	361-1693
8M-0874	Plunger As - Valve	311-9439
8M-2549	Rod As - Connector	314-8537
8M-4014	Insert - Seat Exhaust	311-9398
8M-7166	Housing - Screen	297-7192
8M-8161	Flange - Shaft	215-1781
8M-8652	Shaft	297-7252
8N-0002	Trunnion As	314-8728
8N-0875	Valve - Exhaust	247-6893 (Valve), 241-3381 (Valve Kit)
8N-1187	Head Gp - Cylinder	242-3435
8N-1721	Rod As - Conn	269-5291
8N-2275	Bearing - Sleeve	311-9365
8N-2510	Shaft	325-6208
8N-2641	Sleeve	325-6210
8N-3251	Shaft As - Rocker Arm	314-8711
8N-3325	Arm Gp - Rocker	314-8623
8N-3327	Arm Gp - Rocker	314-8624
8N-3723	Valve - Exhaust	311-9472
8N-5305	Spacer	363-7464
8N-5779	Coupling - Exhaust	325-6047
8N-5929	Cover - Water Pump	296-1349
8N-6004	Head As - Cylinder	247-3369
8N-6796	Head Gp - Cylinder	269-5290
8N-7315	Tube As - Outlet	325-6232
8N-7780	Shield - Oil	314-8544
8N-8225	Bearing - Main	314-8652
8N-9174	Liner - Cylinder	314-8531
8N-9489	Chamber As	247-3301
8N-9733	Line As - Fuel Injector	319-8174
8P-0953	Turbine - Converter	297-7269
8P-1919	Gear - Planet	300-2579
8P-5849	Plate As	223-6323
8P-6949	Plate - Retainer	260-0787
8P-7396	Hub - Planet Gear	239-7967
8P-7595	Washer - Thrust	239-7940
8P-7639	Gear - Planet	239-7935
8P-8677	Hub - Impeller	297-7205
8P-9507	Piston - Clutch	283-5212
8S-0248	Breather As	325-6033
8S-0493	Shaft As - Pump	325-6198
8S-0905	Muffler As	302-2690
8S-3487	Gear As - Ring	221-7949
8S-3491	Housing As	221-7950
8S-3617	Chamber As	247-3302
8S-3970	Chamber As	242-3438
8S-7716	Manifold - Exhaust	295-0415
8S-7717	Manifold - Exhaust	261-0894
8S-7718	Manifold - Exhaust	295-0416
8S-9184	Gear As	260-0785
8V-3134	Pinion - Bevel	260-0788
8V-3135	Gear - Differential Bevel	260-0783
8V-3136	Gear - Differential Bevel	253-1442
9C-5852	Hub As	297-7208
9C-8205	Gear - Bevel	319-8175
9C-9773	Gear - Differential Bevel	302-2672
9G-0280	Piston - Clutch	283-5213
9G-0284	Housing - Clutch	283-5214
9G-0285	Piston - Clutch	283-5215
9G-7993	Cage - Gr Bearing Rh	239-7973
9H-2256	Pump Gp	311-9443
9H-5233	Piston - Clutch	219-9708
9H-5433	Spacer	239-7963
9J-3346	Plate As - Trunnion	256-4839
9J-8323	Trunnion	361-1713
9J-9543	Pin As	256-4791
9L-6371	Rod	363-7459
9M-1328	Bearing - Aligning	325-6018
9N-5251	Piston Gp - Basic	250-6557 (Liner Kit)
9N-5769	Cover - Housing	325-6050
9P-3663	Carrier - Planet	213-6939

(Continued)

Sales Model 627B (Continued)

Original Part Number	Part Name	Classic Part Number
9P-6592	Gear - Planet	215-1915
9P-6594	Gear - Planet	215-1921
9S-6129	Pulley - Alternator Drive	264-5891
9S-6743	Chamber As	247-3303
9S-7079	Muffler As	247-2669
9S-8493	Bolt - Connecting Rod	311-9351
9S-8679	Chamber As	325-6042
9S-8789	Plate - Clutch	302-2712
9U-3124	Gear - Planet	288-8806
9U-3125	Gear - Sun	288-8807
9W-1677	Bearing	297-7145
9W-3605	Carrier - Ring	314-8662
9W-4702	Stator - Converter	308-9939
9W-9930	Mount As	295-6437

Sales Model 627E

Original Part Number	Part Name	Classic Part Number
100-7860	Valve - Inlet	270-4360 (Valve), 270-4362 (Valve Kit)
104-4253	Line As - Fuel Injector	279-4988
104-4254	Line As - Fuel Injector	279-4989
111-8015	Gasket As - Head	279-4977
122-9405	Bracket As	325-6005
129-3068	Rebuild Kit, W/P (Str Brgs)	363-7455
131-3815	Seal Gp - Basic	325-6193
148-7455	Valve - Exhaust	270-4361
167-8123	Damper As	299-2006
172-5185	Shaft - Water Pump	325-6201
172-5188	Shaft - Water Pump	325-6202
172-5189	Impeller - Pump	295-5687
172-5190	Impeller - Pump	325-6111
172-6712	Impeller - Pump	325-6112
172-7767	Pump Gp - Water	296-1365
177-9024	Adapter - Damper	299-1956
180-3767	Adapter - Damper	299-1957
196-0028	Gear As - Idler	364-5259
1N-3576	Block Gp - Cylinder	279-4978
1N-3958	Elbow	325-6087
1P-9945	Bracket As - Fan	296-1344
1P-9946	Shaft - Fan	325-6194
1S-4701	Pulley - Alt	264-5866
1T-0665	Ring - Clamp	308-9918
1T-1993	Wheel - Turbine	235-0920
1T-2052	Stator As	295-5683
1W-1669	Piston	325-6158
1W-1695	Pump Gp	279-4980
1W-1698	Housing - Transfer Pump	296-1356
1W-2491	Muffler As	360-7871
1W-4402	Gear - Camshaft	279-4981
1W-4405	Gear - Crankshaft	279-4982
1W-5912	Tappet As - Guide	325-6223
1W-6541	Plunger As	325-6173
244-1090	Alarm - Back up	360-2345
2F-5721	Bearing - Ball	311-9354
2N-7942	Spacer	363-7462
2P-1170	Shaft As - Gear	296-1367
2P-1738	Plate As - Oil Pan	325-6164
2P-1739	Tube As - Pump	325-6229
2P-1757	Hub - Fan Pulley	296-1357
2P-1781	Spacer - Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2519	Tube As - Inlet	325-6230
2P-2719	Pipe	363-7454
2P-5680	Turbine - Converter	308-9942
2P-6128	Pulley	264-5872
2P-6245	Shaft As - Pump	325-6197
2W-1086	Cover As - Cylinder Head	325-6049
2W-2621	Valve - Inlet	247-6892 (Valve), 241-3381 (Valve Kit)
2W-5540	Core, Radiator (Folded)	363-7452
2W-6757	Trunnion As	295-5678
2W-7255	Shaft - Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear - Water Pump	325-6088
2W-8494	Pulley - Alt	295-5692
3F-6185	Pin	295-5694
3L-1425	Bearing - Ball	311-9356
3P-2768	Piston - Clutch	308-9909
3S-1262	Retainer	308-9915
3S-2710	Shaft - Planet	260-0779
4E-0403	Gear - Planet	260-0781
4N-3714	Chamber, Precom	363-7450
4N-7693	Crankshaft As	242-3439
4P-3546	Valve As - Relief	325-6236
4P-9381	Line As - Fuel Injector	279-4984
4P-9382	Line As - Fuel Injector	279-4985
4P-9385	Line As - Fuel Injector	279-4986
4P-9386	Line As - Fuel Injector	279-4987
4P-9961	Line As - Fuel Injector	325-6115
4S-8472	Hood As	296-1355
4W-0452	Seal As - Camshaft	325-6191
4W-2042	Spacer	325-6217
4W-2446	Damper As	279-4990

(Continued)

Sales Model 627E (Continued)

Original Part Number	Part Name	Classic Part Number
5D-0470	Valve Gp	314-8549
5J-1825	Pin	367-6080
5P-7807	Bearing - Ball	314-8502
5S-1211	Cover - Valve	314-8665
5S-4557	Bearing	311-9360
5S-6795	Chamber As	242-3437
5S-9062	Spacer	363-7463
5S-9080	Pulley - Alt Drive	264-5883
6H-3957	Bearing - Ball	311-9358
6I-0341	Line As - Fuel Injector	325-6117
6I-0342	Line As - Fuel Injector	325-6118
6I-0343	Line As - Fuel Injector	325-6119
6I-0344	Line As - Fuel Injector	325-6120
6I-0345	Line As - Fuel Injector	325-6121
6I-0346	Line As - Fuel Injector	325-6122
6I-1346	Pump Gp - Oil	295-5674
6N-1036	Gear - Oil Pump	279-4991
6N-2789	Pulley	264-5886
6N-8413	Housing - Pump	325-6110
6P-6739	Shaft - Planet	308-9929
7C-0942	Adapter As	302-2636
7C-3039	Core, Oil Cooler	363-7451
7C-4297	Seal As - Camshaft	325-6192
7E-0853	Muffler As	360-7887
7G-2500	Gear - Planet	296-1350
7G-2516	Gear - Planet	283-5203
7N-0110	Core As - Oil Cooler	319-3435
7N-1164	Mount As	295-5451
7N-5910	Impeller - Pump	314-8686
7N-9145	Gear - Fly-wheel	279-4994
7N-9146	Gear - Fly-wheel Starter	279-4995
7N-9805	Pin - Piston	295-6438
7S-3161	Lifter - Valve	279-4996
7S-6723	Bracket - Alternator	299-1978
7S-7809	Cap As - Radiator	295-6417
7T-2036	Cap As - Filter	361-1721
7W-0450	Gear - Water Pump	279-4997
7W-0507	Gear - Oil Pump Drive	279-4998
7W-0508	Gear - Fuel Pump Drive	296-1351
7W-1902	Adapter - Fuel Nozzle	299-1955
7W-2164	Core As - Oil Cooler	299-1996
7W-5687	Hub - Cam-shaft	314-8684
7W-5698	Pulley - Cam-shaft	295-5679
8D-8829	Bearing - Sleeve	361-1692
8H-2810	Case As - Filter	314-8512
8J-7596	Bearing - Sleeve	361-1693
8M-7166	Housing - Screen	297-7192
8N-0875	Valve - Ex-haust	247-6893 (Valve), 241-3381 (Valve Kit)
8N-1187	Head Gp - Cylinder	242-3435
8N-1721	Rod As - Conn	269-5291
8N-2510	Shaft	325-6208
8N-2641	Sleeve	325-6210
8N-3251	Shaft As - Rocker Arm	314-8711
8N-3325	Arm Gp - Rocker	314-8623
8N-3327	Arm Gp - Rocker	314-8624
8N-5305	Spacer	363-7464
8N-5779	Coupling - Exhaust	325-6047
8N-5929	Cover - Water Pump	296-1349
8N-6796	Head Gp - Cylinder	269-5290
8N-7315	Tube As - Outlet	325-6232
8N-8225	Bearing - Main	314-8652
8P-6949	Plate - Re-tainer	260-0787
8S-0248	Breather As	325-6033
8S-0493	Shaft As - Pump	325-6198
8S-3970	Chamber As	242-3438
8S-7716	Manifold - Exhaust	295-0415
8S-7717	Manifold - Exhaust	261-0894
8S-7718	Manifold - Exhaust	295-0416
8S-9184	Gear As	260-0785
9J-8323	Trunnion	361-1713
9J-9427	Bearing - Sleeve	361-1695
9L-6371	Rod	363-7459
9M-1328	Bearing - Aligning	325-6018
9N-5769	Cover - Hous-ing	325-6050
9S-8679	Chamber As	325-6042
9W-4702	Stator - Con-verter	308-9939
9W-9930	Mount As	295-6437
9Y-2988	Breather As	361-1716

Sales Model 631A

Original Part Number	Part Name	Classic Part Number
1A-2846	Cap As - Filler	311-9368
1F-2254	Bushing - Stem	314-8510
2J-5394	Collar	256-4779
2J-5468	Pin - Pivot	256-4781
2J-5531	Collar	256-4780
2J-5649	Pin - Cylinder	256-4782
2J-5662	Shaft - Pivot	256-4775
2P-3586	Piston - Clutch	260-0777
2S-3966	Ring - Seal	297-7237
3J-9133	Bearing - Sleeve	361-1691
3L-1425	Bearing - Ball	311-9356
4B-1455	Cap As - Filter	361-1719

(Continued)

Sales Model 631A (Continued)

Original Part Number	Part Name	Classic Part Number
4M-8845	Shaft - Planet	215-1685
4N-7526	Seal As - Pump	311-9454
4N-9180	Seal As - Pump	311-9455
5D-0470	Valve Gp	314-8549
5F-6393	Shaft	308-9928
5J-4929	Bearing	256-4796
5S-1211	Cover - Valve	314-8665
7B-0503	Ballstud	308-9801
7G-2511	Gear - Planet	260-0782
7G-2830	Ring - Seal	295-6441
7H-0602	Dog - Clutch	314-8515
7M-1249	Piston - Clutch	215-1748
7S-7809	Cap As - Radiator	295-6417
8F-5104	Screen As - Oil Pan	314-8539

Sales Model 631B

Original Part Number	Part Name	Classic Part Number
190-8609	Valve - Fill	360-2288
1A-2846	Cap As - Filler	311-9368
1F-2254	Bushing - Stem	314-8510
1S-4701	Pulley - Alt	264-5866
2F-5721	Bearing - Ball	311-9354
2J-5394	Collar	256-4779
2J-5468	Pin - Pivot	256-4781
2J-5531	Collar	256-4780
2J-5649	Pin - Cylinder	256-4782
2J-5662	Shaft - Pivot	256-4775
2P-3586	Piston - Clutch	260-0777
2S-2781	Plunger - Relief	311-9435
2S-3966	Ring - Seal	297-7237
2S-4015	Plunger As - Valve	311-9438
3J-9133	Bearing - Sleeve	361-1691
3J-9710	Bearing - Sleeve	256-4793
3L-1425	Bearing - Ball	311-9356
4B-1455	Cap As - Filter	361-1719
4M-8845	Shaft - Planet	215-1685
4M-9215	Gear - Pump Idler	311-9391
4N-7526	Seal As - Pump	311-9454
4N-9180	Seal As - Pump	311-9455
5D-0470	Valve Gp	314-8549
5F-6393	Shaft	308-9928
5J-4924	Shaft - Pivot	256-4777
5J-4929	Bearing	256-4796
5J-6417	Bearing	256-4798
5J-6418	Bearing - Sleeve	256-4799
5J-6419	Bearing - Sleeve	256-4800
5J-6421	Bearing	256-4801
5J-7980	Pin	256-4783
5J-7981	Pin	256-4784
5J-7983	Pin	256-4785
5P-7807	Bearing - Ball	314-8502
5S-1211	Cover - Valve	314-8665
5S-9080	Pulley - Alt Drive	264-5883
5V-4075	Gear - Planet	288-8722
6F-3183	Cap - Bearing	325-6038
6H-3957	Bearing - Ball	311-9358
7B-0503	Ballstud	308-9801
7G-2511	Gear - Planet	260-0782
7G-2830	Ring - Seal	295-6441
7H-0602	Dog - Clutch	314-8515
7M-1249	Piston - Clutch	215-1748
7N-2957	Cover - Rad Cap	361-1722
7S-7809	Cap As - Radiator	295-6417
8F-5104	Screen As - Oil Pan	314-8539
8H-2810	Case As - Filter	314-8512
8H-9806	Gear - Shaft Drive	325-6091
8M-0874	Plunger As - Valve	311-9439
8M-2549	Rod As - Connector	314-8537
9J-9543	Pin As	256-4791

Sales Model 631C

Original Part Number	Part Name	Classic Part Number
131-3815	Seal Gp - Basic	325-6193
177-9024	Adapter - Damper	299-1956
180-3767	Adapter - Damper	299-1957
1P-9946	Shaft - Fan	325-6194
1S-4701	Pulley - Alt	264-5866
1T-0662	Turbine - Conv	235-1819
1T-0665	Ring - Clamp	308-9918
244-1090	Alarm - Back up	360-2345
2F-5721	Bearing - Ball	311-9354
2J-5394	Collar	256-4779
2J-5531	Collar	256-4780
2J-5662	Shaft - Pivot	256-4775
2N-7942	Spacer	363-7462
2P-1757	Hub - Fan Pulley	296-1357
2S-2781	Plunger - Relief	311-9435
2S-3966	Ring - Seal	297-7237
3J-9133	Bearing - Sleeve	361-1691
3J-9710	Bearing - Sleeve	256-4793
3L-1425	Bearing - Ball	311-9356
3S-9975	Piston - Clutch	260-0778
4B-1455	Cap As - Filter	361-1719
4N-3714	Chamber, Precom	363-7450

(Continued)

Sales Model 631C (Continued)

Original Part Number	Part Name	Classic Part Number
4N-7526	Seal As - Pump	311-9454
4N-9180	Seal As - Pump	311-9455
5D-0470	Valve Gp	314-8549
5F-6393	Shaft	308-9928
5J-4924	Shaft - Pivot	256-4777
5J-4929	Bearing	256-4796
5J-6417	Bearing	256-4798
5J-6418	Bearing - Sleeve	256-4799
5J-6419	Bearing - Sleeve	256-4800
5J-6421	Bearing	256-4801
5J-7980	Pin	256-4783
5J-7981	Pin	256-4784
5J-7983	Pin	256-4785
5P-7807	Bearing - Ball	314-8502
5S-1211	Cover - Valve	314-8665
5S-9062	Spacer	363-7463
5S-9080	Pulley - Alt Drive	264-5883
5V-1480	Gear - Sun	288-8721
5V-4075	Gear - Planet	288-8722
6H-3957	Bearing - Ball	311-9358
7B-0503	Ballstud	308-9801
7C-3039	Core, Oil Cooler	363-7451
7C-3567	Mount As	314-8689
7G-2516	Gear - Planet	283-5203
7J-3390	Pin - Hitch	256-4786
7N-1164	Mount As	295-5451
7S-7809	Cap As - Radiator	295-6417
7S-8631	Shaft As	275-5296
7W-1902	Adapter - Fuel Nozzle	299-1955
7W-2164	Core As - Oil Cooler	299-1996
8H-2810	Case As - Filter	314-8512
8H-9806	Gear - Shaft Drive	325-6091
8M-0874	Plunger As - Valve	311-9439
8M-8652	Shaft	297-7252
8P-6949	Plate - Retainer	260-0787
8S-9184	Gear As	260-0785
9D-0120	Gear - Planet	288-8737
9D-0127	Gear - Sun	288-8738
9J-0940	Pin	319-3467
9J-9427	Bearing - Sleeve	361-1695
9J-9543	Pin As	256-4791
9S-8789	Plate - Clutch	302-2712
9W-9930	Mount As	295-6437

Sales Model 631D

Original Part Number	Part Name	Classic Part Number
129-3068	Rebuild Kit, W/P (Str Brgs)	363-7455
131-3815	Seal Gp - Basic	325-6193
177-9024	Adapter - Damper	299-1956
180-3767	Adapter - Damper	299-1957
1P-9946	Shaft - Fan	325-6194
1S-4701	Pulley - Alt	264-5866
1T-0662	Turbine - Conv	235-1819
1T-0665	Ring - Clamp	308-9918
244-1090	Alarm - Back up	360-2345
2F-5721	Bearing - Ball	311-9354
2N-7942	Spacer	363-7462
2P-1757	Hub - Fan Pulley	296-1357
307-1303	Muffler As	361-6574
3G-0034	Trunnion	361-1712
3J-9133	Bearing - Sleeve	361-1691
3L-1425	Bearing - Ball	311-9356
3S-9975	Piston - Clutch	260-0778
4B-1455	Cap As - Filter	361-1719
4N-3714	Chamber, Precom	363-7450
4N-6302	Belt Set - Vee	314-8495
5D-0470	Valve Gp	314-8549
5F-6393	Shaft	308-9928
5F-7404	Nut - Bearing Lock	308-9878
5J-7983	Pin	256-4785
5P-7807	Bearing - Ball	314-8502
5S-1211	Cover - Valve	314-8665
5S-4557	Bearing	311-9360
5S-9062	Spacer	363-7463
5S-9080	Pulley - Alt Drive	264-5883
5V-1480	Gear - Sun	288-8721
5V-4075	Gear - Planet	288-8722
6H-3957	Bearing - Ball	311-9358
7C-3039	Core, Oil Cooler	363-7451
7C-3567	Mount As	314-8689
7G-2516	Gear - Planet	283-5203
7N-1164	Mount As	295-5451
7S-7809	Cap As - Radiator	295-6417
7S-8631	Shaft As	275-5296
7T-2036	Cap As - Filter	361-1721
7W-1902	Adapter - Fuel Nozzle	299-1955
7W-2164	Core As - Oil Cooler	299-1996
8H-2810	Case As - Filter	314-8512
8M-0874	Plunger As - Valve	311-9439
8M-8652	Shaft	297-7252
8N-5305	Spacer	363-7464
8P-6949	Plate - Retainer	260-0787
8S-9184	Gear As	260-0785
9D-0120	Gear - Planet	288-8737
9D-0127	Gear - Sun	288-8738
9J-0940	Pin	319-3467
9J-1105	Pin As	256-4790
9Y-2988	Breather As	361-1716

Cat® Classic™ Parts for Track Loaders

Track Loaders have long, productive lives. Their usage changes as the machine ages, so maintenance costs need to be re-evaluated. Caterpillar offers Classic parts for several models of track loaders to ensure a value priced repair option is available.

Cat® Classic™ parts provide owners of older Cat products with low cost repair alternatives that minimize the risk associated with non-genuine parts.

Cat Classic parts coverage for track loaders includes:

- Engine
- Final Drive
- Linkage Pins
- Moving Undercarriage
- Non-Moving Undercarriage
- Steering
- Torque Converter
- Transmission
- Trunnion/Blade Support
- ...and many more.

Sales Model 931, 931B, 931C, 933, 933C, 935B, 935C

Original Part Number	Part Name	Classic Part Number
164-1047	Idler Gp	275-3581
185-4037	Idler Gp	275-3581
190-8609	Valve - Fill	360-2288
244-1090	Alarm - Back up	360-2345
281-8338	Roller - DF	275-3580
281-8339	Roller - SF	275-3579

Original Part Number	Part Name	Classic Part Number
2K-6413	Pin	360-2270
323-8756	Link As	257-1992
323-8757	Link As	257-1990
323-8758	Link As	257-1994
323-8759	Link As	257-1991
4B-1455	Cap As - Filter	361-1719
4N-6638	Muffler As	360-7875

Original Part Number	Part Name	Classic Part Number
5A-3187	Bolt Master	257-7773
6S-3609	Roller - Carrier	275-3578
6Y-1711	Link As	261-8008
6Y-1713	Link As	257-1993
7T-2036	Cap As - Filter	361-1721
9Y-9431	Precleaner As	361-1718

Sales Model 941

Original Part Number	Part Name	Classic Part Number
100-7860	Valve - Inlet	270-4360 (Valve), 270-4362 (Valve Kit)
104-4253	Line As - Fuel Injector	279-4988
104-4254	Line As - Fuel Injector	279-4989
111-8015	Gasket As - Head	279-4977
121-7746	Precleaner As	360-2311
131-3815	Seal Gp - Basic	325-6193
148-7455	Valve - Exhaust	270-4361
165-4262	Body As - Piston	270-4351
172-5185	Shaft - Water Pump	325-6201

Original Part Number	Part Name	Classic Part Number
172-5188	Shaft - Water Pump	325-6202
172-5189	Impeller - Pump	295-5687
172-5190	Impeller - Pump	325-6111
172-6712	Impeller - Pump	325-6112
172-7767	Pump Gp - Water	296-1365
190-8609	Valve - Fill	360-2288
196-0028	Gear As - Idler	364-5259
1H-8262	Shaft	226-8016
1H-8382	Gear - Oil Pump Drive	226-6103
1H-8938	Lever	226-8028
1K-7974	Gear - Transmission Shaft	226-7984
1M-1663	Collar As - Retain	226-8030

Original Part Number	Part Name	Classic Part Number
1M-1930	Cage - Pinion Bearing	217-7727
1M-1947	Support As	226-6096
1M-7250	Bowl - Precleaner	360-2296
1M-9177	Flywheel	226-6112
1N-3576	Block Gp - Cylinder	279-4978
1N-3958	Elbow	325-6087
1N-4304	Head Gp - Cylinder	269-8761
1P-1216	Manifold - Exhaust	261-0902
1P-1721	Gear - Balance	298-2769
1P-1722	Gear - Balance	298-2770
1P-7044	Cage	226-7975
1P-9945	Bracket As - Fan	296-1344

(Continued)

Sales Model 941 (Continued)

Original Part Number	Part Name	Classic Part Number
1P-9946	Shaft - Fan	325-6194
1P-9952	Impeller - Pump	314-8685
1S-1888	Bracket - Lamp	297-7147
1S-4701	Pulley - Alt	264-5866
1S-8764	Ring - Flywheel Clutch Adjustable	226-8014
1T-0020	Wheel - Turbine	297-4862
1V-3242	Cage - Release Bearing	216-7475
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1695	Pump Gp	279-4980
1W-1698	Housing - Transfer Pump	296-1356
1W-2870	Shaft As - Balance	314-8715
1W-2871	Shaft As - Balance	314-8716
1W-4402	Gear - Camshaft	279-4981
1W-4405	Gear - Crankshaft	279-4982
1W-5912	Tappet As - Guide	325-6223
1W-6541	Plunger As	325-6173
2B-8824	Drum	216-7817
2D-5658	Bearing - Ball	301-4628
2F-5721	Bearing - Ball	311-9354
2H-4338	Plate - Pressure	226-8010
2H-4450	Washer - Thrust	325-6237
2H-4482	Collar	229-8218
2H-5046	Link - Flycam	299-2024
2K-3592	Boss	314-8501
2K-4442	Bearing - Sleeve	308-9812
2K-4502	Bearing - Sleeve	299-1986
2K-6413	Pin	360-2270
2M-1086	Plate As - Press	226-8023
2M-2290	Bracket - Ring	299-1979
2M-4668	Retainer - Guard	297-4867
2P-1170	Shaft As - Gear	296-1367
2P-1757	Hub - Fan Pulley	296-1357
2P-1781	Spacer - Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2519	Tube As - Inlet	325-6230
2P-2719	Pipe	363-7454
2P-4404	Housing As	226-8027
2P-4409	Gear - Ring	226-7981
2P-6128	Pulley	264-5872
2P-6245	Shaft As - Pump	325-6197
2P-6255	Muffler As	247-2666
2P-7828	Pan - Oil	314-8691
2V-7198	Pilot As - Recoil Spring	302-2709
2W-1086	Cover As - Cylinder Head	325-6049
2W-2621	Valve - Inlet	247-6892 (Valve), 241-3381 (Valve Kit)
2W-7255	Shaft - Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear - Water Pump	325-6088
3F-1537	Nut - Spanner	226-6098
3K-3124	Muffler - Trap	247-2673
3L-1425	Bearing - Ball	311-9356
3S-7987	Shaft - Planet	226-6074
3S-7996	Gear - Ring	226-6087
3S-8800	Gear - Driven	325-6090
3V-5916	Plate As - Press	226-8025
4F-4974	Clamp	311-9373
4H-4021	Plate As - Loading	229-8219
4K-0255	Retainer As	226-6102
4K-0300	Bearing - Sleeve	308-9817
4K-1328	Drum - Steering	216-7840 (Drum), 230-7112 (Steering Clutch Kit)
4K-4632	Gear - Bevel	216-7842
4K-4780	Strip As - Wear	299-2063
4K-5074	Pinion	215-1683
4K-5086	Yoke	215-1684
4K-5109	Gear - Reverse	219-9659
4N-2954	Sleeve - Camshaft	299-2059
4N-3281	Line As - Fuel Injector	247-3362
4N-3282	Line As - Fuel Injector	247-3363
4N-3283	Line As - Fuel Injector	247-3364
4N-3284	Line As - Fuel Injector	247-3365
4N-4539	Sleeve	314-8720
4N-4864	Pump Gp - Fuel Transfer	242-3442
4N-7692	Crankshaft As	242-3440
4N-7693	Crankshaft As	242-3439
4N-7977	Shaft As - Balance	314-8709
4N-7978	Shaft As - Balance	314-8710
4N-9587	Shield - Heat	297-7260
4P-3546	Valve As - Relief	325-6236
4P-9381	Line As - Fuel Injector	279-4984
4P-9382	Line As - Fuel Injector	279-4985
4P-9961	Line As - Fuel Injector	325-6115
4P-9962	Line As - Fuel Injector	325-6116
4P-9963	Line As - Fuel Injector	298-2777
4P-9964	Line As - Fuel Injector	298-2778
4S-8660	Pump Gp - Transmission	226-0167
4S-8670	Shaft - Planet	300-2590
4S-8687	Piston - Clutch	226-8008
4S-8707	Shaft & Sun Gear	226-6089
4S-8713	Gear - Ring	226-6090
4V-2744	Gear	224-1303
4V-3396	Hub - Gear	222-1763
4V-3397	Hub - Gear	219-2979
4W-0452	Seal As - Camshaft	325-6191
5G-3612	Cap Gp	295-6419

(Continued)

Sales Model 941 (Continued)

Original Part Number	Part Name	Classic Part Number
5H-5500	Collar - Flywheel	302-2704
5K-6090	Flange	216-7844
5K-8606	Cage - Gear Bearing	223-6310
5P-7807	Bearing - Ball	314-8502
5S-0884	Gear - Ring	226-7982
5S-0885	Plate - Front	229-8234
5S-0894	Shaft - Center	226-6075
5S-6795	Chamber As	242-3437
5S-7609	Pulley - Alt Drive	264-5881
5S-8038	Pulley - Crankshaft	264-5882
5S-9062	Spacer	363-7463
5S-9080	Pulley - Alt Drive	264-5883
6H-3957	Bearing - Ball	311-9358
6I-1346	Pump Gp - Oil	295-5674
6I-8132	Pinion	226-6080
6K-3447	Pin	241-2576
6K-3937	Pin	241-2557
6N-1036	Gear - Oil Pump	279-4991
6N-1553	Coupling - Exhaust	295-6422
6N-2789	Pulley	264-5886
6N-8413	Housing - Pump	325-6110
6P-0169	Hub - Flywheel Clutch	297-7204
6P-7704	Carrier - Ring	314-8658
6Y-0710	Gear	226-6104
7C-4297	Seal As - Camshaft	325-6192
7G-2480	Gear - Planet	226-6091
7G-2481	Gear - Planet	226-6092
7G-2485	Gear - Planet	226-7983
7G-2830	Ring - Seal	295-6441
7H-2742	Nut	229-8220
7J-9682	Bearing - Sleeve	360-2335
7K-3582	Nut - Adjusting	226-6099
7K-4458	Gear - Final Drive	226-6093
7K-4512	Pinion - Final Drive	226-6081
7K-4770	Pinion	226-6082
7K-4771	Gear	229-8221
7K-8237	Drum	226-6100
7K-8238	Flange	213-8166
7K-9360	Pin	319-3461
7K-9361	Pin	241-2565
7M-2167	Ring - Governor Control	308-9919
7M-4603	Body - Fuel Valve	311-9348
7N-0128	Core As - Oil Cooler	299-1994
7N-0165	Core As - Oil Cooler	295-5670
7N-2871	Line As - Fuel Injector	319-8172
7N-2872	Line As - Fuel Injector	319-8173
7N-2874	Line As - Fuel Injector	298-2779
7N-2949	Pulley	264-5887
7N-3515	Gear - Camshaft	314-8669
7N-3536	Gear - Fuel	279-4993
7N-5910	Impeller - Pump	314-8686
7N-8117	Muffler As	247-2668
7N-9146	Gear - Flywheel Starter	279-4995
7N-9805	Pin - Piston	295-6438
7S-3161	Lifter - Valve	279-4996
7S-6723	Bracket - Alternator	299-1978
7S-7070	Head As - Cylinder	325-6107
7S-7602	Pump Gp	226-0174
7S-7809	Cap As - Radiator	295-6417
7S-8443	Muffler	247-2675
7S-9749	Pulley - Gen Drive	264-5888
7T-2036	Cap As - Filter	361-1721
7V-5249	Shaft - Steering	215-1761
7W-0450	Gear - Water Pump	279-4997
7W-0507	Gear - Oil Pump Drive	279-4998
7W-0508	Gear - Fuel Pump Drive	296-1351
7W-5687	Hub - Camshaft	314-8684
8H-1174	Drum - Steering	226-6101 (Drum), 231-1937 (Steering Clutch Kit)
8H-2810	Case As - Filter	314-8512
8H-9806	Gear - Shaft Drive	325-6091
8M-0874	Plunger As - Valve	311-9439
8M-6676	Cylinder - Adjustable	226-4960
8N-0002	Trunnion As	314-8728
8N-0875	Valve - Exhaust	247-6893 (Valve), 241-3381 (Valve Kit)
8N-1187	Head Gp - Cylinder	242-3435
8N-1188	Head Gp - Cylinder	242-3436
8N-1721	Rod As - Conn	269-5291
8N-1984	Rod As - Conn	242-3441
8N-2510	Shaft	325-6208
8N-2641	Sleeve	325-6210
8N-3180	Body As - Piston	250-6563
8N-3181	Piston Gp - Basic	250-6555 (Liner Kit)
8N-3182	Body As - Piston	250-6564 (Piston As), 250-6556 (Liner Kits)
8N-3183	Piston Gp - Basic	250-6556 (Liner Kit)
8N-3251	Shaft As - Rocker Arm	314-8711
8N-3311	Shaft As - Rocker Arm	325-6199
8N-3312	Shaft As - Rocker Arm	325-6200
8N-3325	Arm Gp - Rocker	314-8623
8N-3327	Arm Gp - Rocker	314-8624
8N-5305	Spacer	363-7464
8N-5929	Cover - Water Pump	296-1349
8N-6796	Head Gp - Cylinder	269-5290
8N-7315	Tube As - Outlet	325-6232
8N-7780	Shield - Oil	314-8544
8N-8225	Bearing - Main	314-8652

(Continued)

Sales Model 941 (Continued)

Original Part Number	Part Name	Classic Part Number
8N-9733	Line As - Fuel Injector	319-8174
8S-0248	Breather As	325-6033
8S-0493	Shaft As - Pump	325-6198
8S-2809	Muffler	247-2677
8S-3970	Chamber As	242-3438
9F-7101	Bushing - Collar	299-1988

Original Part Number	Part Name	Classic Part Number
9H-2256	Pump Gp	311-9443
9H-6980	Shaft - Pinion	226-6110
9H-7670	Piston	226-4961
9K-6842	Cage As	216-7872
9K-9271	Holder As - Cage	217-7730
9K-9273	Nut - Adjusting	226-7998
9M-4789	Shaft - Gov Control	297-7256

Original Part Number	Part Name	Classic Part Number
9N-5769	Cover - Housing	325-6050
9S-2356	Manifold - Exhaust	261-0905
9S-6129	Pulley - Alternator Drive	264-5891
9S-8679	Chamber As	325-6042
9V-4333	Gear - Oil Pump Input	226-6105
9Y-2992	Bearing - Sleeve	325-6032

Sales Model 941B

Original Part Number	Part Name	Classic Part Number
100-7860	Valve - Inlet	270-4360 (Valve), 270-4362 (Valve Kit)
104-4253	Line As - Fuel Injector	279-4988
104-4254	Line As - Fuel Injector	279-4989
111-8015	Gasket As - Head	279-4977
121-7746	Precleaner As	360-2311
131-3815	Seal Gp - Basic	325-6193
148-7455	Valve - Exhaust	270-4361
172-5185	Shaft - Water Pump	325-6201
172-5188	Shaft - Water Pump	325-6202
172-5189	Impeller - Pump	295-5687
172-5190	Impeller - Pump	325-6111
172-6712	Impeller - Pump	325-6112
172-7767	Pump Gp - Water	296-1365
190-8609	Valve - Fill	360-2288
196-0028	Gear As - Idler	364-5259
1M-1930	Cage - Pinion Bearing	217-7727
1M-1947	Support As	226-6096
1M-7250	Bowl - Precleaner	360-2296
1N-3576	Block Gp - Cylinder	279-4978

Original Part Number	Part Name	Classic Part Number
1N-3958	Elbow	325-6087
1N-4304	Head Gp - Cylinder	269-8761
1P-1216	Manifold - Exhaust	261-0902
1P-1721	Gear - Balance	298-2769
1P-1722	Gear - Balance	298-2770
1P-9945	Bracket As - Fan	296-1344
1P-9946	Shaft - Fan	325-6194
1P-9952	Impeller - Pump	314-8685
1S-1888	Bracket - Lamp	297-7147
1S-4701	Pulley - Alt	264-5866
1T-0020	Wheel - Turbine	297-4862
1V-3242	Cage - Release Bearing	216-7475
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1695	Pump Gp	279-4980
1W-1698	Housing - Transfer Pump	296-1356
1W-2870	Shaft As - Balance	314-8715
1W-2871	Shaft As - Balance	314-8716
1W-4402	Gear - Camshaft	279-4981
1W-4405	Gear - Crankshaft	279-4982
1W-5912	Tappet As - Guide	325-6223
1W-6541	Plunger As	325-6173

Original Part Number	Part Name	Classic Part Number
244-1090	Alarm - Back up	360-2345
2B-8824	Drum	216-7817
2D-5658	Bearing - Ball	301-4628
2F-5721	Bearing - Ball	311-9354
2K-3592	Boss	314-8501
2K-4442	Bearing - Sleeve	308-9812
2K-4502	Bearing - Sleeve	299-1986
2K-6413	Pin	360-2270
2M-1086	Plate As - Press	226-8023
2M-4668	Retainer - Guard	297-4867
2P-1170	Shaft As - Gear	296-1367
2P-1757	Hub - Fan Pulley	296-1357
2P-1781	Spacer - Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2519	Tube As - Inlet	325-6230
2P-4404	Housing As	226-8027
2P-4409	Gear - Ring	226-7981
2P-6128	Pulley	264-5872
2P-6245	Shaft As - Pump	325-6197
2P-6255	Muffler As	247-2666
2P-7828	Pan - Oil	314-8691
2V-7198	Pilot As - Recoil Spring	302-2709
2W-1086	Cover As - Cylinder Head	325-6049

(Continued)

Sales Model 941B (Continued)

Original Part Number	Part Name	Classic Part Number
2W-2621	Valve - Inlet	247-6892 (Valve), 241-3381 (Valve Kit)
2W-7255	Shaft - Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear - Water Pump	325-6088
3F-1537	Nut - Spanner	226-6098
3K-3124	Muffler - Trap	247-2673
3L-1425	Bearing - Ball	311-9356
3S-7987	Shaft - Planet	226-6074
3S-7996	Gear - Ring	226-6087
3V-5916	Plate As - Press	226-8025
4F-4974	Clamp	311-9373
4K-0255	Retainer As	226-6102
4K-0300	Bearing - Sleeve	308-9817
4K-1328	Drum - Steering	216-7840 (Drum), 230-7112 (Steering Clutch Kit)
4K-4632	Gear - Bevel	216-7842
4K-4780	Strip As - Wear	299-2063
4N-2954	Sleeve - Camshaft	299-2059
4N-3281	Line As - Fuel Injector	247-3362
4N-3282	Line As - Fuel Injector	247-3363
4N-3283	Line As - Fuel Injector	247-3364
4N-3284	Line As - Fuel Injector	247-3365
4N-4539	Sleeve	314-8720
4N-4864	Pump Gp - Fuel Transfer	242-3442
4N-7692	Crankshaft As	242-3440
4N-7693	Crankshaft As	242-3439
4N-7977	Shaft As - Balance	314-8709
4N-7978	Shaft As - Balance	314-8710
4N-9587	Shield - Heat	297-7260
4P-3546	Valve As - Relief	325-6236
4P-9381	Line As - Fuel Injector	279-4984
4P-9382	Line As - Fuel Injector	279-4985
4P-9961	Line As - Fuel Injector	325-6115
4P-9962	Line As - Fuel Injector	325-6116
4P-9963	Line As - Fuel Injector	298-2777
4P-9964	Line As - Fuel Injector	298-2778
4S-8660	Pump Gp - Transmission	226-0167
4S-8670	Shaft - Planet	300-2590
4S-8687	Piston - Clutch	226-8008
4S-8707	Shaft & Sun Gear	226-6089
4S-8713	Gear - Ring	226-6090
4V-2744	Gear	224-1303
4V-3396	Hub - Gear	222-1763
4V-3397	Hub - Gear	219-2979
4W-0452	Seal As - Camshaft	325-6191
5G-3612	Cap Gp	295-6419
5K-6090	Flange	216-7844
5K-8606	Cage - Gear Bearing	223-6310
5P-7807	Bearing - Ball	314-8502
5S-0884	Gear - Ring	226-7982
5S-0885	Plate - Front	229-8234
5S-0894	Shaft - Center	226-6075
5S-6795	Chamber As	242-3437
5S-7609	Pulley - Alt Drive	264-5881
5S-8038	Pulley - Crankshaft	264-5882
5S-9062	Spacer	363-7463
5S-9080	Pulley - Alt Drive	264-5883
6H-3957	Bearing - Ball	311-9358
6I-1346	Pump Gp - Oil	295-5674
6I-8132	Pinion	226-6080
6K-3447	Pin	241-2576
6K-3937	Pin	241-2557
6N-1036	Gear - Oil Pump	279-4991
6N-1553	Coupling - Exhaust	295-6422
6N-2789	Pulley	264-5886
6N-8413	Housing - Pump	325-6110
6P-7704	Carrier - Ring	314-8658
7C-4297	Seal As - Camshaft	325-6192
7G-2480	Gear - Planet	226-6091
7G-2481	Gear - Planet	226-6092
7G-2485	Gear - Planet	226-7983
7G-2830	Ring - Seal	295-6441
7H-2742	Nut	229-8220
7J-9682	Bearing - Sleeve	360-2335
7K-3582	Nut - Adjusting	226-6099
7K-4458	Gear - Final Drive	226-6093
7K-4512	Pinion - Final Drive	226-6081
7K-4770	Pinion	226-6082
7K-4771	Gear	229-8221
7K-8237	Drum	226-6100
7K-8238	Flange	213-8166
7K-9360	Pin	319-3461
7K-9361	Pin	241-2565
7M-2167	Ring - Governor Control	308-9919
7M-4603	Body - Fuel Valve	311-9348
7N-0128	Core As - Oil Cooler	299-1994
7N-0165	Core As - Oil Cooler	295-5670
7N-2871	Line As - Fuel Injector	319-8172
7N-2872	Line As - Fuel Injector	319-8173
7N-2874	Line As - Fuel Injector	298-2779
7N-2949	Pulley	264-5887
7N-3515	Gear - Camshaft	314-8669
7N-3536	Gear - Fuel	279-4993
7N-5910	Impeller - Pump	314-8686
7N-8117	Muffler As	247-2668
7N-9146	Gear - Flywheel Starter	279-4995
7N-9805	Pin - Piston	295-6438
7S-3161	Lifter - Valve	279-4996
7S-6723	Bracket - Alternator	299-1978
7S-7070	Head As - Cylinder	325-6107
7S-7809	Cap As - Radiator	295-6417
7S-8443	Muffler	247-2675

(Continued)

Sales Model 941B (Continued)

Original Part Number	Part Name	Classic Part Number
7S-9749	Pulley - Gen Drive	264-5888
7T-2036	Cap As - Filter	361-1721
7V-5249	Shaft - Steering	215-1761
7W-0450	Gear - Water Pump	279-4997
7W-0507	Gear - Oil Pump Drive	279-4998
7W-0508	Gear - Fuel Pump Drive	296-1351
7W-5687	Hub - Camshaft	314-8684
8H-1174	Drum - Steering	226-6101 (Drum), 231-1937 (Steering Clutch Kit)
8H-2810	Case As - Filter	314-8512
8H-9806	Gear - Shaft Drive	325-6091
8M-0874	Plunger As - Valve	311-9439
8M-6676	Cylinder - Adjustable	226-4960
8N-0002	Trunnion As	314-8728
8N-0875	Valve - Exhaust	247-6893 (Valve), 241-3381 (Valve Kit)
8N-1187	Head Gp - Cylinder	242-3435
8N-1188	Head Gp - Cylinder	242-3436
8N-1721	Rod As - Conn	269-5291
8N-1984	Rod As - Conn	242-3441
8N-2510	Shaft	325-6208
8N-2641	Sleeve	325-6210
8N-3181	Piston Gp - Basic	250-6555 (Liner Kit)
8N-3183	Piston Gp - Basic	250-6556 (Liner Kit)
8N-3251	Shaft As - Rocker Arm	314-8711
8N-3311	Shaft As - Rocker Arm	325-6199
8N-3312	Shaft As - Rocker Arm	325-6200
8N-3325	Arm Gp - Rocker	314-8623
8N-3327	Arm Gp - Rocker	314-8624
8N-5305	Spacer	363-7464
8N-5929	Cover - Water Pump	296-1349
8N-6796	Head Gp - Cylinder	269-5290
8N-7315	Tube As - Outlet	325-6232
8N-7780	Shield - Oil	314-8544
8N-8225	Bearing - Main	314-8652
8N-9733	Line As - Fuel Injector	319-8174
8S-0248	Breather As	325-6033
8S-0493	Shaft As - Pump	325-6198
8S-2809	Muffler	247-2677
8S-3970	Chamber As	242-3438
9H-2256	Pump Gp	311-9443
9H-7670	Piston	226-4961
9K-6842	Cage As	216-7872
9K-9271	Holder As - Cage	217-7730
9K-9273	Nut - Adjusting	226-7998
9M-4789	Shaft - Gov Control	297-7256
9N-5769	Cover - Housing	325-6050
9S-2356	Manifold - Exhaust	261-0905
9S-6129	Pulley - Alternator Drive	264-5891
9S-8679	Chamber As	325-6042
9Y-2992	Bearing - Sleeve	325-6032

Sales Model 951

Original Part Number	Part Name	Classic Part Number
100-7860	Valve - Inlet	270-4360 (Valve), 270-4362 (Valve Kit)
121-7746	Precleaner As	360-2311
131-3815	Seal Gp - Basic	325-6193
148-7455	Valve - Exhaust	270-4361
165-4262	Body As - Piston	270-4351
190-8609	Valve - Fill	360-2288
196-0028	Gear As - Idler	364-5259
1A-2846	Cap As - Filler	311-9368
1H-8262	Shaft	226-8016
1H-8382	Gear - Oil Pump Drive	226-6103
1H-8938	Lever	226-8028
1K-7974	Gear - Transmission Shaft	226-7984
1M-1663	Collar As - Retain	226-8030
1M-1930	Cage - Pinion Bearing	217-7727
1M-1947	Support As	226-6096
1M-7250	Bowl - Precleaner	360-2296
1M-9177	Flywheel	226-6112
1N-4304	Head Gp - Cylinder	269-8761
1P-1721	Gear - Balance	298-2769
1P-1722	Gear - Balance	298-2770
1P-7044	Cage	226-7975
1S-1888	Bracket - Lamp	297-7147
1S-6422	Pilot As - Spring	226-4849
1S-8764	Ring - Flywheel Clutch Adjustable	226-8014
1V-3242	Cage - Release Bearing	216-7475
1W-4402	Gear - Camshaft	279-4981
1W-4405	Gear - Crankshaft	279-4982
2B-8824	Drum	216-7817
2F-5721	Bearing - Ball	311-9354

(Continued)

Sales Model 951 (Continued)

Original Part Number	Part Name	Classic Part Number
2H-4338	Plate - Pressure	226-8010
2H-4450	Washer - Thrust	325-6237
2H-4482	Collar	229-8218
2H-5046	Link - Flycam	299-2024
2K-4502	Bearing - Sleeve	299-1986
2K-4512	Bearing - Sleeve	308-9813
2K-4513	Bearing - Sleeve	308-9814
2K-6413	Pin	360-2270
2K-7418	Pin	241-2572
2M-1086	Plate As - Press	226-8023
2M-2290	Bracket - Ring	299-1979
2P-1170	Shaft As - Gear	296-1367
2P-1781	Spacer - Oil Pump	325-6214
2P-6245	Shaft As - Pump	325-6197
2P-7622	Bolt - Spring	226-4850
2P-7828	Pan - Oil	314-8691
2S-4015	Plunger As - Valve	311-9438
2W-2621	Valve - Inlet	247-6892 (Valve), 241-3381 (Valve Kit)
3F-1537	Nut - Spanner	226-6098
3H-3378	Gear As - Pump	298-2795
3K-3124	Muffler - Trap	247-2673
3L-1425	Bearing - Ball	311-9356
3S-8800	Gear - Driven	325-6090
3V-5916	Plate As - Press	226-8025
4H-4021	Plate As - Loading	229-8219
4J-2414	Trunnion	296-1370
4K-0255	Retainer As	226-6102
4K-1328	Drum - Steering	216-7840 (Drum), 230-7112 (Steering Clutch Kit)
4K-4632	Gear - Bevel	216-7842
4K-4780	Strip As - Wear	299-2063
4K-5074	Pinion	215-1683
4K-5086	Yoke	215-1684
4K-5109	Gear - Reverse	219-9659
4K-6702	Pin	241-2573
4K-7386	Plate - Guide	226-4851
4K-9559	Hub - Gear	219-2978
4N-4864	Pump Gp - Fuel Transfer	242-3442
4N-7692	Crankshaft As	242-3440
4N-7977	Shaft As - Balance	314-8709
4N-7978	Shaft As - Balance	314-8710
4P-3546	Valve As - Relief	325-6236
4V-3396	Hub - Gear	222-1763
5F-1401	Pin - Pivot	297-7216
5H-5500	Collar - Flywheel	302-2704
5K-6090	Flange	216-7844
5K-7995	Bearing - Sleeve	308-9820
5K-8606	Cage - Gear Bearing	223-6310
5S-1211	Cover - Valve	314-8665
5S-1822	Chamber As	248-5406
5S-1833	Chamber As	247-3298
5S-6795	Chamber As	242-3437
5S-8038	Pulley - Crankshaft	264-5882
5S-9062	Spacer	363-7463
6F-3183	Cap - Bearing	325-6038
6J-0800	Bearing	297-7140
6N-1036	Gear - Oil Pump	279-4991
6P-0169	Hub - Flywheel Clutch	297-7204
6Y-0710	Gear	226-6104
7B-2420	Ferrule - Director	314-8517
7C-4297	Seal As - Camshaft	325-6192
7H-2424	Sleeve - Spring	226-4852
7H-2742	Nut	229-8220
7J-9682	Bearing - Sleeve	360-2335
7K-3582	Nut - Adjusting	226-6099
7K-4458	Gear - Final Drive	226-6093
7K-4512	Pinion - Final Drive	226-6081
7K-4770	Pinion	226-6082
7K-4771	Gear	229-8221
7K-8237	Drum	226-6100
7K-8238	Flange	213-8166
7M-2167	Ring - Governor Control	308-9919
7M-4603	Body - Fuel Valve	311-9348
7M-7358	Valve - Inlet	298-2774
7M-9398	Plate - Guide	297-7230
7N-9805	Pin - Piston	295-6438
7S-3161	Lifter - Valve	279-4996
7S-7070	Head As - Cylinder	325-6107
7S-7602	Pump Gp	226-0174
7S-7809	Cap As - Radiator	295-6417
7S-9749	Pulley - Gen Drive	264-5888
7T-2036	Cap As - Filter	361-1721
7V-5249	Shaft - Steering	215-1761
7W-0507	Gear - Oil Pump Drive	279-4998
7W-0508	Gear - Fuel Pump Drive	296-1351
8H-1174	Drum - Steering	226-6101 (Drum), 231-1937 (Steering Clutch Kit)
8H-9806	Gear - Shaft Drive	325-6091
8K-5587	Rod Gp - Recoil	226-4954
8M-0874	Plunger As - Valve	311-9439
8M-6676	Cylinder - Adjustable	226-4960
8N-0875	Valve - Exhaust	247-6893 (Valve), 241-3381 (Valve Kit)
8N-1188	Head Gp - Cylinder	242-3436
8N-1984	Rod As - Conn	242-3441
8N-3181	Piston Gp - Basic	250-6555 (Liner Kit)

(Continued)

Sales Model 951 (Continued)

Original Part Number	Part Name	Classic Part Number
8N-3182	Body As - Piston	250-6564 (Piston As), 250-6556 (Liner Kits)
8N-3183	Piston Gp - Basic	250-6556 (Liner Kit)
8N-3251	Shaft As - Rocker Arm	314-8711
8N-3311	Shaft As - Rocker Arm	325-6199
8N-3312	Shaft As - Rocker Arm	325-6200
8N-3325	Arm Gp - Rocker	314-8623
8N-3327	Arm Gp - Rocker	314-8624

Original Part Number	Part Name	Classic Part Number
8N-8225	Bearing - Main	314-8652
8S-0248	Breather As	325-6033
8S-0493	Shaft As - Pump	325-6198
8S-2560	Idler Gp, Idler As.	200-9235 (Complete Idler Group), 175-8255 (Idler As.)
8S-3970	Chamber As	242-3438
9F-7101	Bushing - Collar	299-1988
9H-2256	Pump Gp	311-9443
9H-4104	Pilot - Spring	226-4962
9H-6980	Shaft - Pinion	226-6110
9H-7670	Piston	226-4961

Original Part Number	Part Name	Classic Part Number
9K-6842	Cage As	216-7872
9K-9271	Holder As - Cage	217-7730
9K-9273	Nut - Adjusting	226-7998
9M-4163	Valve - Exhaust	298-2773
9M-4789	Shaft - Gov Control	297-7256
9M-4955	Pump Gp - Fuel Transfer	242-3443
9S-2356	Manifold - Exhaust	261-0905
9W-1677	Bearing	297-7145
9Y-2992	Bearing - Sleeve	325-6032
9Y-9431	Precleaner As	361-1718

Sales Model 951B

Original Part Number	Part Name	Classic Part Number
100-7860	Valve - Inlet	270-4360 (Valve), 270-4362 (Valve Kit)
104-4253	Line As - Fuel Injector	279-4988
104-4254	Line As - Fuel Injector	279-4989
111-8015	Gasket As - Head	279-4977
121-7746	Precleaner As	360-2311
131-3815	Seal Gp - Basic	325-6193
148-7455	Valve - Exhaust	270-4361
165-4262	Body As - Piston	270-4351
172-5185	Shaft - Water Pump	325-6201
172-5188	Shaft - Water Pump	325-6202
172-5189	Impeller - Pump	295-5687
172-5190	Impeller - Pump	325-6111
172-6712	Impeller - Pump	325-6112
172-7767	Pump Gp - Water	296-1365
190-8609	Valve - Fill	360-2288

Original Part Number	Part Name	Classic Part Number
196-0028	Gear As - Idler	364-5259
1A-2846	Cap As - Filler	311-9368
1H-8262	Shaft	226-8016
1H-8382	Gear - Oil Pump Drive	226-6103
1H-8938	Lever	226-8028
1K-7974	Gear - Transmission Shaft	226-7984
1M-1663	Collar As - Retain	226-8030
1M-1930	Cage - Pinion Bearing	217-7727
1M-1947	Support As	226-6096
1M-9177	Flywheel	226-6112
1N-3576	Block Gp - Cylinder	279-4978
1N-3958	Elbow	325-6087
1N-4304	Head Gp - Cylinder	269-8761
1P-1721	Gear - Balance	298-2769
1P-1722	Gear - Balance	298-2770
1P-7044	Cage	226-7975
1P-9945	Bracket As - Fan	296-1344
1P-9946	Shaft - Fan	325-6194
1P-9952	Impeller - Pump	314-8685

Original Part Number	Part Name	Classic Part Number
1S-1888	Bracket - Lamp	297-7147
1S-4701	Pulley - Alt	264-5866
1S-6422	Pilot As - Spring	226-4849
1S-8764	Ring - Flywheel Clutch Adjustable	226-8014
1T-0020	Wheel - Turbine	297-4862
1V-3242	Cage - Release Bearing	216-7475
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1695	Pump Gp	279-4980
1W-1698	Housing - Transfer Pump	296-1356
1W-2870	Shaft As - Balance	314-8715
1W-2871	Shaft As - Balance	314-8716
1W-4402	Gear - Camshaft	279-4981
1W-4405	Gear - Crankshaft	279-4982
1W-5912	Tappet As - Guide	325-6223
1W-6541	Plunger As	325-6173
2B-8824	Drum	216-7817
2D-5658	Bearing - Ball	301-4628

(Continued)

Sales Model 951B (Continued)

Original Part Number	Part Name	Classic Part Number
2F-5721	Bearing - Ball	311-9354
2H-4338	Plate - Pressure	226-8010
2H-4450	Washer - Thrust	325-6237
2H-4482	Collar	229-8218
2H-5046	Link - Flycam	299-2024
2K-3592	Boss	314-8501
2K-4442	Bearing - Sleeve	308-9812
2K-4502	Bearing - Sleeve	299-1986
2K-6413	Pin	360-2270
2M-1086	Plate As - Press	226-8023
2M-2290	Bracket - Ring	299-1979
2M-4668	Retainer - Guard	297-4867
2P-1170	Shaft As - Gear	296-1367
2P-1757	Hub - Fan Pulley	296-1357
2P-1781	Spacer - Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2519	Tube As - Inlet	325-6230
2P-2719	Pipe	363-7454
2P-4404	Housing As	226-8027
2P-4409	Gear - Ring	226-7981
2P-5081	Muffler As	360-7872
2P-6128	Pulley	264-5872
2P-6245	Shaft As - Pump	325-6197
2P-6255	Muffler As	247-2666
2P-7622	Bolt - Spring	226-4850
2P-7828	Pan - Oil	314-8691
2W-1086	Cover As - Cylinder Head	325-6049
2W-2621	Valve - Inlet	247-6892 (Valve), 241-3381 (Valve Kit)
2W-7255	Shaft - Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear - Water Pump	325-6088
3F-1537	Nut - Spanner	226-6098
3H-3378	Gear As - Pump	298-2795
3K-3124	Muffler - Trap	247-2673
3L-1425	Bearing - Ball	311-9356
3S-7987	Shaft - Planet	226-6074
3S-7996	Gear - Ring	226-6087
3S-8800	Gear - Driven	325-6090
3V-5916	Plate As - Press	226-8025
4F-4974	Clamp	311-9373
4H-4021	Plate As - Loading	229-8219
4K-0255	Retainer As	226-6102
4K-0300	Bearing - Sleeve	308-9817
4K-1328	Drum - Steering	216-7840 (Drum), 230-7112 (Steering Clutch Kit)
4K-4632	Gear - Bevel	216-7842
4K-4780	Strip As - Wear	299-2063
4K-5074	Pinion	215-1683
4K-5086	Yoke	215-1684
4K-5109	Gear - Reverse	219-9659
4K-7386	Plate - Guide	226-4851
4N-2954	Sleeve - Camshaft	299-2059
4N-3281	Line As - Fuel Injector	247-3362
4N-3282	Line As - Fuel Injector	247-3363
4N-3283	Line As - Fuel Injector	247-3364
4N-3284	Line As - Fuel Injector	247-3365
4N-4539	Sleeve	314-8720
4N-4864	Pump Gp - Fuel Transfer	242-3442
4N-7692	Crankshaft As	242-3440
4N-7693	Crankshaft As	242-3439
4N-7977	Shaft As - Balance	314-8709
4N-7978	Shaft As - Balance	314-8710
4N-9587	Shield - Heat	297-7260
4P-3546	Valve As - Relief	325-6236
4P-9381	Line As - Fuel Injector	279-4984
4P-9382	Line As - Fuel Injector	279-4985
4P-9961	Line As - Fuel Injector	325-6115
4P-9962	Line As - Fuel Injector	325-6116
4P-9963	Line As - Fuel Injector	298-2777
4P-9964	Line As - Fuel Injector	298-2778
4S-8660	Pump Gp - Transmission	226-0167
4S-8670	Shaft - Planet	300-2590
4S-8687	Piston - Clutch	226-8008
4S-8707	Shaft & Sun Gear	226-6089
4S-8713	Gear - Ring	226-6090
4V-2744	Gear	224-1303
4V-3396	Hub - Gear	222-1763
4V-3397	Hub - Gear	219-2979
4W-0452	Seal As - Camshaft	325-6191
5G-3612	Cap Gp	295-6419
5H-5500	Collar - Flywheel	302-2704
5K-6090	Flange	216-7844
5K-8606	Cage - Gear Bearing	223-6310
5P-7807	Bearing - Ball	314-8502
5S-0884	Gear - Ring	226-7982
5S-0885	Plate - Front	229-8234
5S-0894	Shaft - Center	226-6075
5S-1822	Chamber As	248-5406
5S-4557	Bearing	311-9360
5S-6795	Chamber As	242-3437
5S-7609	Pulley - Alt Drive	264-5881
5S-8038	Pulley - Crankshaft	264-5882
5S-9062	Spacer	363-7463
5S-9080	Pulley - Alt Drive	264-5883
6H-3957	Bearing - Ball	311-9358
6I-1346	Pump Gp - Oil	295-5674
6I-8132	Pinion	226-6080
6K-3447	Pin	241-2576
6K-3937	Pin	241-2557
6N-1036	Gear - Oil Pump	279-4991
6N-2789	Pulley	264-5886
6N-8413	Housing - Pump	325-6110

(Continued)

Sales Model 951B (Continued)

Original Part Number	Part Name	Classic Part Number
6P-0169	Hub - Fly-wheel Clutch	297-7204
6P-7704	Carrier - Ring	314-8658
6Y-0710	Gear	226-6104
7B-2420	Ferrule - Director	314-8517
7C-4297	Seal As - Camshaft	325-6192
7G-2480	Gear - Planet	226-6091
7G-2481	Gear - Planet	226-6092
7G-2485	Gear - Planet	226-7983
7G-2830	Ring - Seal	295-6441
7H-2424	Sleeve - Spring	226-4852
7H-2742	Nut	229-8220
7J-9682	Bearing - Sleeve	360-2335
7K-3582	Nut - Adjust-ing	226-6099
7K-4458	Gear - Final Drive	226-6093
7K-4512	Pinion - Final Drive	226-6081
7K-4770	Pinion	226-6082
7K-4771	Gear	229-8221
7K-8237	Drum	226-6100
7K-8238	Flange	213-8166
7K-9360	Pin	319-3461
7K-9361	Pin	241-2565
7M-2167	Ring - Gover-nor Control	308-9919
7M-4358	Manifold - Exhaust	261-0907
7M-4603	Body - Fuel Valve	311-9348
7M-7358	Valve - Inlet	298-2774
7N-0128	Core As - Oil Cooler	299-1994
7N-0165	Core As - Oil Cooler	295-5670
7N-2871	Line As - Fuel Injector	319-8172
7N-2872	Line As - Fuel Injector	319-8173
7N-2874	Line As - Fuel Injector	298-2779
7N-2949	Pulley	264-5887
7N-3515	Gear - Cam-shaft	314-8669
7N-3536	Gear - Fuel	279-4993
7N-5910	Impeller - Pump	314-8686
7N-8117	Muffler As	247-2668
7N-9146	Gear - Fly-wheel Starter	279-4995
7N-9805	Pin - Piston	295-6438
7S-3161	Lifter - Valve	279-4996
7S-6723	Bracket - Alternator	299-1978
7S-7070	Head As - Cylinder	325-6107
7S-7602	Pump Gp	226-0174
7S-7809	Cap As - Radiator	295-6417
7S-8443	Muffler	247-2675
7S-9749	Pulley - Gen Drive	264-5888
7T-2036	Cap As - Filter	361-1721
7V-5249	Shaft - Steer-ing	215-1761
7W-0450	Gear - Water Pump	279-4997
7W-0507	Gear - Oil Pump Drive	279-4998
7W-0508	Gear - Fuel Pump Drive	296-1351
7W-5687	Hub - Cam-shaft	314-8684
8H-1174	Drum - Steer-ing	226-6101 (Drum), 231-1937 (Steer-ing Clutch Kit)
8H-2810	Case As - Filter	314-8512
8H-9806	Gear - Shaft Drive	325-6091
8K-5587	Rod Gp - Recoil	226-4954
8K-9661	Gear - Bevel	213-8218
8M-0874	Plunger As - Valve	311-9439
8M-6676	Cylinder - Adjustable	226-4960
8N-0002	Trunnion As	314-8728
8N-0875	Valve - Ex-haust	247-6893 (Valve), 241-3381 (Valve Kit)
8N-1187	Head Gp - Cylinder	242-3435
8N-1188	Head Gp - Cylinder	242-3436
8N-1721	Rod As - Conn	269-5291
8N-1984	Rod As - Conn	242-3441
8N-2510	Shaft	325-6208
8N-2641	Sleeve	325-6210
8N-3180	Body As - Piston	250-6563
8N-3181	Piston Gp - Basic	250-6555 (Liner Kit)
8N-3182	Body As - Piston	250-6564 (Piston As), 250-6556 (Liner Kits)
8N-3183	Piston Gp - Basic	250-6556 (Liner Kit)
8N-3251	Shaft As - Rocker Arm	314-8711
8N-3311	Shaft As - Rocker Arm	325-6199
8N-3312	Shaft As - Rocker Arm	325-6200
8N-3325	Arm Gp - Rocker	314-8623
8N-3327	Arm Gp - Rocker	314-8624
8N-5929	Cover - Water Pump	296-1349
8N-6796	Head Gp - Cylinder	269-5290
8N-7315	Tube As - Outlet	325-6232
8N-7780	Shield - Oil	314-8544
8N-8225	Bearing - Main	314-8652
8N-9733	Line As - Fuel Injector	319-8174
8S-0248	Breather As	325-6033
8S-0493	Shaft As - Pump	325-6198
8S-2809	Muffler	247-2677
8S-3970	Chamber As	242-3438
9F-7101	Bushing - Collar	299-1988
9G-8302	Guide	226-4853
9H-2256	Pump Gp	311-9443
9H-4104	Pilot - Spring	226-4962
9H-6980	Shaft - Pinion	226-6110
9H-7670	Piston	226-4961
9K-6842	Cage As	216-7872
9K-9271	Holder As - Cage	217-7730
9K-9273	Nut - Adjust-ing	226-7998

(Continued)

Sales Model 951B (Continued)

Original Part Number	Part Name	Classic Part Number
9M-4163	Valve - Exhaust	298-2773
9M-4789	Shaft - Gov Control	297-7256
9N-5769	Cover - Housing	325-6050
9S-2356	Manifold - Exhaust	261-0905
9S-6129	Pulley - Alternator Drive	264-5891
9S-8679	Chamber As	325-6042
9V-4333	Gear - Oil Pump Input	226-6105
9Y-2992	Bearing - Sleeve	325-6032
9Y-9431	Precleaner As	361-1718

Sales Model 951C

Original Part Number	Part Name	Classic Part Number
100-7860	Valve - Inlet	270-4360 (Valve), 270-4362 (Valve Kit)
104-4253	Line As - Fuel Injector	279-4988
104-4254	Line As - Fuel Injector	279-4989
111-8015	Gasket As - Head	279-4977
121-7746	Precleaner As	360-2311
131-3815	Seal Gp - Basic	325-6193
148-7455	Valve - Exhaust	270-4361
165-4262	Body As - Piston	270-4351
172-5185	Shaft - Water Pump	325-6201
172-5188	Shaft - Water Pump	325-6202
172-5189	Impeller - Pump	295-5687
172-5190	Impeller - Pump	325-6111
172-6712	Impeller - Pump	325-6112
172-7767	Pump Gp - Water	296-1365
190-8609	Valve - Fill	360-2288
196-0028	Gear As - Idler	364-5259
1H-8262	Shaft	226-8016
1H-8382	Gear - Oil Pump Drive	226-6103
1H-8938	Lever	226-8028
1K-7974	Gear - Transmission Shaft	226-7984
1M-1663	Collar As - Retain	226-8030
1M-1930	Cage - Pinion Bearing	217-7727
1M-1947	Support As	226-6096
1M-7250	Bowl - Precleaner	360-2296
1M-9177	Flywheel	226-6112
1N-3576	Block Gp - Cylinder	279-4978
1N-3958	Elbow	325-6087
1N-4304	Head Gp - Cylinder	269-8761
1P-1721	Gear - Balance	298-2769
1P-1722	Gear - Balance	298-2770
1P-7044	Cage	226-7975
1P-9945	Bracket As - Fan	296-1344
1P-9946	Shaft - Fan	325-6194
1P-9952	Impeller - Pump	314-8685
1S-1888	Bracket - Lamp	297-7147
1S-4701	Pulley - Alt	264-5866
1S-6422	Pilot As - Spring	226-4849
1S-8764	Ring - Flywheel Clutch Adjustable	226-8014
1T-0020	Wheel - Turbine	297-4862
1V-3242	Cage - Release Bearing	216-7475
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1695	Pump Gp	279-4980
1W-1698	Housing - Transfer Pump	296-1356
1W-2870	Shaft As - Balance	314-8715
1W-2871	Shaft As - Balance	314-8716
1W-4402	Gear - Camshaft	279-4981
1W-4405	Gear - Crankshaft	279-4982
1W-5912	Tappet As - Guide	325-6223
1W-6541	Plunger As	325-6173
244-1090	Alarm - Back up	360-2345
2B-8824	Drum	216-7817
2D-5658	Bearing - Ball	301-4628
2F-5721	Bearing - Ball	311-9354
2H-4338	Plate - Pressure	226-8010
2H-4450	Washer - Thrust	325-6237
2H-4482	Collar	229-8218
2H-5046	Link - Flycam	299-2024
2K-3592	Boss	314-8501
2K-4442	Bearing - Sleeve	308-9812
2K-4502	Bearing - Sleeve	299-1986
2K-6413	Pin	360-2270
2M-1086	Plate As - Press	226-8023
2M-2290	Bracket - Ring	299-1979
2M-4668	Retainer - Guard	297-4867
2P-1170	Shaft As - Gear	296-1367
2P-1757	Hub - Fan Pulley	296-1357
2P-1781	Spacer - Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2519	Tube As - Inlet	325-6230
2P-2719	Pipe	363-7454
2P-4404	Housing As	226-8027
2P-4409	Gear - Ring	226-7981

(Continued)

Sales Model 951C (Continued)

Original Part Number	Part Name	Classic Part Number
2P-6128	Pulley	264-5872
2P-6245	Shaft As - Pump	325-6197
2P-6255	Muffler As	247-2666
2P-7622	Bolt - Spring	226-4850
2P-7828	Pan - Oil	314-8691
2W-1086	Cover As - Cylinder Head	325-6049
2W-2621	Valve - Inlet	247-6892 (Valve), 241-3381 (Valve Kit)
2W-7255	Shaft - Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear - Water Pump	325-6088
3F-1537	Nut - Spanner	226-6098
3K-3124	Muffler - Trap	247-2673
3L-1425	Bearing - Ball	311-9356
3S-7987	Shaft - Planet	226-6074
3S-7996	Gear - Ring	226-6087
3S-8800	Gear - Driven	325-6090
3V-5916	Plate As - Press	226-8025
4F-4974	Clamp	311-9373
4H-4021	Plate As - Loading	229-8219
4K-0255	Retainer As	226-6102
4K-0300	Bearing - Sleeve	308-9817
4K-1328	Drum - Steering	216-7840 (Drum), 230-7112 (Steering Clutch Kit)
4K-4632	Gear - Bevel	216-7842
4K-4780	Strip As - Wear	299-2063
4K-5074	Pinion	215-1683
4K-5086	Yoke	215-1684
4K-5109	Gear - Reverse	219-9659
4K-7386	Plate - Guide	226-4851
4N-2954	Sleeve - Camshaft	299-2059
4N-3281	Line As - Fuel Injector	247-3362
4N-3282	Line As - Fuel Injector	247-3363
4N-3283	Line As - Fuel Injector	247-3364
4N-3284	Line As - Fuel Injector	247-3365
4N-4539	Sleeve	314-8720
4N-4864	Pump Gp - Fuel Transfer	242-3442
4N-7692	Crankshaft As	242-3440
4N-7693	Crankshaft As	242-3439
4N-7977	Shaft As - Balance	314-8709
4N-7978	Shaft As - Balance	314-8710
4N-9587	Shield - Heat	297-7260
4P-3546	Valve As - Relief	325-6236
4P-9381	Line As - Fuel Injector	279-4984
4P-9382	Line As - Fuel Injector	279-4985
4P-9961	Line As - Fuel Injector	325-6115
4P-9962	Line As - Fuel Injector	325-6116
4P-9963	Line As - Fuel Injector	298-2777
4P-9964	Line As - Fuel Injector	298-2778
4S-8660	Pump Gp - Transmission	226-0167
4S-8670	Shaft - Planet	300-2590
4S-8687	Piston - Clutch	226-8008
4S-8707	Shaft & Sun Gear	226-6089
4S-8713	Gear - Ring	226-6090
4V-2744	Gear	224-1303
4V-3396	Hub - Gear	222-1763
4V-3397	Hub - Gear	219-2979
4W-0452	Seal As - Camshaft	325-6191
5G-3612	Cap Gp	295-6419
5H-5500	Collar - Flywheel	302-2704
5K-6090	Flange	216-7844
5K-8606	Cage - Gear Bearing	223-6310
5P-7807	Bearing - Ball	314-8502
5S-0884	Gear - Ring	226-7982
5S-0885	Plate - Front	229-8234
5S-0894	Shaft - Center	226-6075
5S-6795	Chamber As	242-3437
5S-7609	Pulley - Alt Drive	264-5881
5S-8038	Pulley - Crankshaft	264-5882
5S-9062	Spacer	363-7463
5S-9080	Pulley - Alt Drive	264-5883
6H-3957	Bearing - Ball	311-9358
6I-1346	Pump Gp - Oil	295-5674
6I-8132	Pinion	226-6080
6K-3447	Pin	241-2576
6K-3937	Pin	241-2557
6N-1036	Gear - Oil Pump	279-4991
6N-2789	Pulley	264-5886
6N-8413	Housing - Pump	325-6110
6P-0169	Hub - Flywheel Clutch	297-7204
6P-7704	Carrier - Ring	314-8658
6Y-0710	Gear	226-6104
7C-4297	Seal As - Camshaft	325-6192
7G-2480	Gear - Planet	226-6091
7G-2481	Gear - Planet	226-6092
7G-2485	Gear - Planet	226-7983
7G-2830	Ring - Seal	295-6441
7H-2424	Sleeve - Spring	226-4852
7H-2742	Nut	229-8220
7K-3582	Nut - Adjusting	226-6099
7K-4458	Gear - Final Drive	226-6093
7K-4512	Pinion - Final Drive	226-6081
7K-4770	Pinion	226-6082
7K-4771	Gear	229-8221
7K-8237	Drum	226-6100
7K-8238	Flange	213-8166
7K-9360	Pin	319-3461
7K-9361	Pin	241-2565
7M-2167	Ring - Governor Control	308-9919
7M-4603	Body - Fuel Valve	311-9348
7N-0128	Core As - Oil Cooler	299-1994
7N-0165	Core As - Oil Cooler	295-5670
7N-2871	Line As - Fuel Injector	319-8172
7N-2872	Line As - Fuel Injector	319-8173

(Continued)

Sales Model 951C (Continued)

Original Part Number	Part Name	Classic Part Number
7N-2874	Line As - Fuel Injector	298-2779
7N-2949	Pulley	264-5887
7N-3515	Gear - Camshaft	314-8669
7N-3536	Gear - Fuel	279-4993
7N-5910	Impeller - Pump	314-8686
7N-9146	Gear - Flywheel Starter	279-4995
7N-9805	Pin - Piston	295-6438
7S-3161	Lifter - Valve	279-4996
7S-6723	Bracket - Alternator	299-1978
7S-7070	Head As - Cylinder	325-6107
7S-7602	Pump Gp	226-0174
7S-7809	Cap As - Radiator	295-6417
7S-9749	Pulley - Gen Drive	264-5888
7V-5249	Shaft - Steering	215-1761
7W-0450	Gear - Water Pump	279-4997
7W-0507	Gear - Oil Pump Drive	279-4998
7W-0508	Gear - Fuel Pump Drive	296-1351
7W-5687	Hub - Camshaft	314-8684
8H-1174	Drum - Steering	226-6101 (Drum), 231-1937 (Steering Clutch Kit)
8H-2810	Case As - Filter	314-8512
8H-9806	Gear - Shaft Drive	325-6091
8K-5587	Rod Gp - Recoil	226-4954
8K-9661	Gear - Bevel	213-8218
8M-0874	Plunger As - Valve	311-9439
8M-6676	Cylinder - Adjustable	226-4960
8N-0002	Trunnion As	314-8728
8N-0875	Valve - Exhaust	247-6893 (Valve), 241-3381 (Valve Kit)
8N-1187	Head Gp - Cylinder	242-3435
8N-1188	Head Gp - Cylinder	242-3436
8N-1721	Rod As - Conn	269-5291
8N-1984	Rod As - Conn	242-3441
8N-2510	Shaft	325-6208
8N-2641	Sleeve	325-6210
8N-3180	Body As - Piston	250-6563
8N-3181	Piston Gp - Basic	250-6555 (Liner Kit)
8N-3182	Body As - Piston	250-6564 (Piston As), 250-6556 (Liner Kits)
8N-3183	Piston Gp - Basic	250-6556 (Liner Kit)
8N-3251	Shaft As - Rocker Arm	314-8711
8N-3311	Shaft As - Rocker Arm	325-6199
8N-3312	Shaft As - Rocker Arm	325-6200
8N-3325	Arm Gp - Rocker	314-8623
8N-3327	Arm Gp - Rocker	314-8624
8N-5305	Spacer	363-7464
8N-5929	Cover - Water Pump	296-1349
8N-6796	Head Gp - Cylinder	269-5290
8N-7315	Tube As - Outlet	325-6232
8N-7780	Shield - Oil	314-8544
8N-8225	Bearing - Main	314-8652
8N-9733	Line As - Fuel Injector	319-8174
8S-0248	Breather As	325-6033
8S-0493	Shaft As - Pump	325-6198
8S-3970	Chamber As	242-3438
9F-7101	Bushing - Collar	299-1988
9G-8302	Guide	226-4853
9H-2256	Pump Gp	311-9443
9H-4104	Pilot - Spring	226-4962
9H-6980	Shaft - Pinion	226-6110
9H-7670	Piston	226-4961
9K-6842	Cage As	216-7872
9K-9271	Holder As - Cage	217-7730
9K-9273	Nut - Adjusting	226-7998
9M-4789	Shaft - Gov Control	297-7256
9N-5769	Cover - Housing	325-6050
9S-2356	Manifold - Exhaust	261-0905
9S-6129	Pulley - Alternator Drive	264-5891
9S-8679	Chamber As	325-6042
9V-4333	Gear - Oil Pump Input	226-6105
9Y-2992	Bearing - Sleeve	325-6032

Sales Model 955C, 955E

Original Part Number	Part Name	Classic Part Number
0T-0259	Nut - Bearing Sleeve	311-9431
1H-8382	Gear - Oil Pump Drive	226-6103
1M-9177	Flywheel	226-6112
1S-1888	Bracket - Lamp	297-7147
1S-1967	Chamber As	247-3291
1S-1970	Chamber As	247-3292
1S-6422	Pilot As - Spring	226-4849
1S-8764	Ring - Flywheel Clutch Adjustable	226-8014
2B-8824	Drum	216-7817
2F-5721	Bearing - Ball	311-9354
2H-4338	Plate - Pressure	226-8010
2H-4450	Washer - Thrust	325-6237
2H-4482	Collar	229-8218

(Continued)

Sales Model 955C, 955E (Continued)

Original Part Number	Part Name	Classic Part Number
2H-5046	Link - Flycam	299-2024
2K-3592	Boss	314-8501
2K-4177	Pin - Lock	308-9893
2K-4502	Bearing - Sleeve	299-1986
2K-4512	Bearing - Sleeve	308-9813
2K-4513	Bearing - Sleeve	308-9814
2K-7418	Pin	241-2572
2M-1086	Plate As - Press	226-8023
2M-2290	Bracket - Ring	299-1979
2P-7622	Bolt - Spring	226-4850
2S-1273	Chamber As	319-3434
2S-4015	Plunger As - Valve	311-9438
3B-6218	Muffler As	247-2672
3F-1537	Nut - Spanner	226-6098
3K-3124	Muffler - Trap	247-2673
4F-4974	Clamp	311-9373
4H-4021	Plate As - Loading	229-8219
4J-2414	Trunnion	296-1370
4K-0255	Retainer As	226-6102
4N-7526	Seal As - Pump	311-9454
4N-9180	Seal As - Pump	311-9455

Original Part Number	Part Name	Classic Part Number
5F-1401	Pin - Pivot	297-7216
5H-5500	Collar - Flywheel	302-2704
5K-7995	Bearing - Sleeve	308-9820
5S-1211	Cover - Valve	314-8665
6F-3183	Cap - Bearing	325-6038
6H-3957	Bearing - Ball	311-9358
6J-0800	Bearing	297-7140
6P-0169	Hub - Flywheel Clutch	297-7204
6W-0240	Bearing - Brace	297-7143
7B-2420	Ferrule - Director	314-8517
7H-0602	Dog - Clutch	314-8515
7H-2424	Sleeve - Spring	226-4852
7H-2742	Nut	229-8220
7J-9682	Bearing - Sleeve	360-2335
7M-4603	Body - Fuel Valve	311-9348
7M-5050	Collar - Front Idler	226-4958
7M-9398	Plate - Guide	297-7230
7S-7809	Cap As - Radiator	295-6417
7Y-2348	Pin	314-8697
7Y-2349	Pin	301-4556

Original Part Number	Part Name	Classic Part Number
7Y-2357	Pin	301-4564
7Y-2391	Link As	301-5240
7Y-2392	Link - Rh	301-4765
7Y-3428	Bearing - Sleeve	314-8647
7Y-5128	Bearing - Sleeve	314-8648
7Y-5131	Bearing - Sleeve	301-4626
8B-5972	Bearing - Ball	314-8503
8H-1174	Drum - Steering	226-6101 (Drum), 231-1937 (Steering Clutch Kit)
8H-2300	Pinion - Final Drive	226-6083
8M-6676	Cylinder - Adjustable	226-4960
9F-5224	Gear - Final Drive	226-6094
9F-7101	Bushing - Collar	299-1988
9H-4104	Pilot - Spring	226-4962
9H-7670	Piston	226-4961
9K-9271	Holder As - Cage	217-7730
9K-9273	Nut - Adjusting	226-7998
9W-1677	Bearing	297-7145
9Y-9431	Precleaner As	361-1718

Sales Model 955H

Original Part Number	Part Name	Classic Part Number
121-7746	Precleaner As	360-2311
190-8609	Valve - Fill	360-2288
1A-2846	Cap As - Filler	311-9368
1M-5270	Pipe - Extension	367-6065
1M-7250	Bowl - Precleaner	360-2296
1P-1721	Gear - Balance	298-2769
1P-1722	Gear - Balance	298-2770
1S-1888	Bracket - Lamp	297-7147
1S-4701	Pulley - Alt	264-5866
1S-6422	Pilot As - Spring	226-4849

Original Part Number	Part Name	Classic Part Number
1T-0020	Wheel - Turbine	297-4862
1T-1428	Retainer - Bearing	300-2587
1T-1987	Housing - Rotating	297-4864
1V-0940	Holder - Bearing Cage	216-7472
1V-3242	Cage - Release Bearing	216-7475
1V-3676	Case - Drive Gear	216-7799
1V-3677	Case - Final Drive Gear	216-7802
1W-4405	Gear - Crankshaft	279-4982
2B-8824	Drum	216-7817
2F-5721	Bearing - Ball	311-9354

Original Part Number	Part Name	Classic Part Number
2K-3592	Boss	314-8501
2K-4502	Bearing - Sleeve	299-1986
2K-4512	Bearing - Sleeve	308-9813
2K-4513	Bearing - Sleeve	308-9814
2K-6413	Pin	360-2270
2K-7418	Pin	241-2572
2M-4668	Retainer - Guard	297-4867
2P-7622	Bolt - Spring	226-4850
2S-1477	Holder As - Cage	226-7985
2S-4015	Plunger As - Valve	311-9438
3F-1972	Retainer As	226-7988

(Continued)

Sales Model 955H (Continued)

Original Part Number	Part Name	Classic Part Number
3H-3378	Gear As - Pump	298-2795
3K-2230	Gear - Planet	219-9658
3K-2498	Shaft - Planet	216-7824
3K-3774	Gear - Final Drive	217-7716
3K-3814	Gear & Pinion - Final Drive	216-7825
3P-3623	Lock - Adjustable Nut	226-7989
3V-5916	Plate As - Press	226-8025
4F-4974	Clamp	311-9373
4H-9040	Nut	226-7996
4J-2414	Trunnion	296-1370
4K-1328	Drum - Steering	216-7840 (Drum), 230-7112 (Steering Clutch Kit)
4K-4632	Gear - Bevel	216-7842
4K-4780	Strip As - Wear	299-2063
4K-6702	Pin	241-2573
4K-7386	Plate - Guide	226-4851
5F-1401	Pin - Pivot	297-7216
5K-2888	Hub - Gear	219-2967
5K-2893	Shaft - Sprocket	221-7953
5K-6090	Flange	216-7844
5K-7995	Bearing - Sleeve	308-9820
5K-8606	Cage - Gear Bearing	223-6310
5P-7807	Bearing - Ball	314-8502
5S-1211	Cover - Valve	314-8665
5S-1822	Chamber As	248-5406
5S-1833	Chamber As	247-3298
5S-4557	Bearing	311-9360
5S-9080	Pulley - Alt Drive	264-5883
6F-3183	Cap - Bearing	325-6038
6J-0800	Bearing	297-7140
7B-2420	Ferrule - Director	314-8517
7G-2522	Gear - Planet	216-7855
7G-6044	Cage As	216-7857
7H-2424	Sleeve - Spring	226-4852
7H-2742	Nut	229-8220
7J-9682	Bearing - Sleeve	360-2335
7K-1311	Hub As - Sprocket	224-1313
7M-2167	Ring - Governor Control	308-9919
7M-4358	Manifold - Exhaust	261-0907
7M-4603	Body - Fuel Valve	311-9348
7M-7358	Valve - Inlet	298-2774
7M-9398	Plate - Guide	297-7230
7N-0128	Core As - Oil Cooler	299-1994
7S-7809	Cap As - Radiator	295-6417
7S-9749	Pulley - Gen Drive	264-5888
7T-2036	Cap As - Filter	361-1721
8B-5972	Bearing - Ball	314-8503
8H-9806	Gear - Shaft Drive	325-6091
8K-5587	Rod Gp - Recoil	226-4954
8M-3224	Muffler	247-2676
8M-6676	Cylinder - Adjustable	226-4960
8N-8225	Bearing - Main	314-8652
9H-2256	Pump Gp	311-9443
9H-4104	Pilot - Spring	226-4962
9H-7670	Piston	226-4961
9K-6841	Cage As	216-7871
9M-4163	Valve - Exhaust	298-2773
9M-4955	Pump Gp - Fuel Transfer	242-3443
9W-1677	Bearing	297-7145

Sales Model 955K

Original Part Number	Part Name	Classic Part Number
100-7860	Valve - Inlet	270-4360 (Valve), 270-4362 (Valve Kit)
121-7746	Precleaner As	360-2311
131-3815	Seal Gp - Basic	325-6193
148-7455	Valve - Exhaust	270-4361
165-4262	Body As - Piston	270-4351
172-5185	Shaft - Water Pump	325-6201
172-5188	Shaft - Water Pump	325-6202
172-5189	Impeller - Pump	295-5687
172-5190	Impeller - Pump	325-6111
172-6712	Impeller - Pump	325-6112
172-7767	Pump Gp - Water	296-1365
190-8609	Valve - Fill	360-2288
1A-2846	Cap As - Filler	311-9368
1J-6746	Pin	256-4817
1J-6749	Screw - Adjustable	256-4824
1M-7250	Bowl - Precleaner	360-2296
1N-3958	Elbow	325-6087
1N-4304	Head Gp - Cylinder	269-8761
1P-0963	Guard As - Roller	226-0179
1P-1216	Manifold - Exhaust	261-0902
1P-1721	Gear - Balance	298-2769
1P-1722	Gear - Balance	298-2770
1P-6160	Gear - Pump Driven	231-8760
1P-9945	Bracket As - Fan	296-1344
1P-9946	Shaft - Fan	325-6194
1P-9952	Impeller - Pump	314-8685
1S-1888	Bracket - Lamp	297-7147
1S-4701	Pulley - Alt	264-5866
1S-5331	Cylinder - Adjustable	226-0214

(Continued)

Sales Model 955K (Continued)

Original Part Number	Part Name	Classic Part Number
1S-6422	Pilot As - Spring	226-4849
1T-0724	Impeller - Converter	216-7469
1T-0727	Hub - Impeller	229-8236
1T-0947	Flange As - Input	229-8224
1T-0949	Housing - Rotating	217-7732
1T-0972	Carrier As	216-7470
1T-1255	Torque Converter	235-1806 (Repair Kit)
1T-1285	Gear As - Drive	217-7734
1T-1331	Stator - Converter	229-8237
1V-0940	Holder - Bearing Cage	216-7472
1V-3242	Cage - Release Bearing	216-7475
1V-3676	Case - Drive Gear	216-7799
1V-3677	Case - Final Drive Gear	216-7802
1V-7556	Support	216-7804
1W-1219	Trunnion As	314-8724
1W-4402	Gear - Camshaft	279-4981
1W-4405	Gear - Crankshaft	279-4982
2B-8824	Drum	216-7817
2F-5721	Bearing - Ball	311-9354
2J-8489	Bearing - Sleeve	295-5691
2K-4502	Bearing - Sleeve	299-1986
2K-4507	Bearing - Sleeve	325-6021
2K-6413	Pin	360-2270
2M-4668	Retainer - Guard	297-4867
2P-1170	Shaft As - Gear	296-1367
2P-1757	Hub - Fan Pulley	296-1357
2P-1781	Spacer - Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2519	Tube As - Inlet	325-6230
2P-2744	Muffler As	247-2664
2P-5081	Muffler As	360-7872
2P-6128	Pulley	264-5872
2P-6245	Shaft As - Pump	325-6197
2P-7828	Pan - Oil	314-8691
2S-4015	Plunger As - Valve	311-9438
2V-5551	Pinion - Final Drive	216-7822
2V-5552	Gear & Pinion - Final Drive	216-7823
2W-2621	Valve - Inlet	247-6892 (Valve), 241-3381 (Valve Kit)
2W-7255	Shaft - Water Pump	325-6203
2W-9978	Core As - Oil Cooler	279-4983
3F-6185	Pin	295-5694
3H-3378	Gear As - Pump	298-2795
3K-3774	Gear - Final Drive	217-7716
3K-3814	Gear & Pinion - Final Drive	216-7825
3L-1425	Bearing - Ball	311-9356
3P-3623	Lock - Adjustable Nut	226-7989
3S-1167	Gear - Planet	221-9101
3S-4386	Pump Gp - Steering	217-2599
3V-1133	Strip	226-0203
3V-2042	Hub - Gear	217-7735
3V-2771	Retainer	216-7830
3V-5604	Pinion - Final Drive	216-7832
3V-5605	Gear - Final Drive & Pinion	216-7833
3V-5778	Shaft - Sprocket	216-7834
3V-5916	Plate As - Press	226-8025
3V-5918	Gear - Final Drive	217-7717
3V-5920	Hub - Gear	222-1762
3V-7365	Hub - Gear	219-2965
4F-4974	Clamp	311-9373
4K-1328	Drum - Steering	216-7840 (Drum), 230-7112 (Steering Clutch Kit)
4K-3004	Bearing - Trunnion Support	314-8632
4K-3128	Bearing - Sleeve	314-8633
4K-4632	Gear - Bevel	216-7842
4K-4780	Strip As - Wear	299-2063
4K-7386	Plate - Guide	226-4851
4N-2954	Sleeve - Camshaft	299-2059
4N-3281	Line As - Fuel Injector	247-3362
4N-3282	Line As - Fuel Injector	247-3363
4N-3283	Line As - Fuel Injector	247-3364
4N-3284	Line As - Fuel Injector	247-3365
4N-4539	Sleeve	314-8720
4N-4864	Pump Gp - Fuel Transfer	242-3442
4N-7692	Crankshaft As	242-3440
4N-7977	Shaft As - Balance	314-8709
4N-7978	Shaft As - Balance	314-8710
4N-9587	Shield - Heat	297-7260
4P-3546	Valve As - Relief	325-6236
4S-5943	Piston - Clutch	221-9112
4S-5944	Gear - Sun	221-9078
4S-5945	Gear - Sun	221-9079
4S-5946	Shaft - Center	229-8238
4S-5947	Gear - Ring	221-9080
4S-5948	Gear - Ring	221-9082
4S-5979	Carrier As	216-7843
4S-5981	Gear - Ring	221-9084
4S-8530	Shaft - Planet	221-9111
4S-8534	Shaft As - Planet	221-9116
4V-7344	Pin	241-2574
4W-0452	Seal As - Camshaft	325-6191
5F-7993	Pin	319-3454
5G-3612	Cap Gp	295-6419
5J-4798	Bearing As	256-4840
5J-8052	Trunnion	256-4843
5K-2893	Shaft - Sprocket	221-7953
5K-6090	Flange	216-7844

(Continued)

Sales Model 955K (Continued)

Original Part Number	Part Name	Classic Part Number
5K-6142	Cage - Final Drive Gear Bearing	223-4811
5K-7027	Pin	241-2575
5K-8330	Holder - Tooth	299-2013
5K-8606	Cage - Gear Bearing	223-6310
5K-8628	Cage	216-7845
5P-7807	Bearing - Ball	314-8502
5S-1822	Chamber As	248-5406
5S-4493	Carrier - Planet	223-6321
5S-4557	Bearing	311-9360
5S-6795	Chamber As	242-3437
5S-6972	Gear - Sun	221-9087
5S-6978	Shaft - Planet	221-9103
5S-7009	Plate As - End	226-4957
5S-7010	Shaft - Planet	221-9104
5S-7013	Gear - Ring	221-9088
5S-7023	Carrier - Planet	226-5986
5S-7609	Pulley - Alt Drive	264-5881
5S-7894	Flange As	216-7854
5S-8038	Pulley - Crankshaft	264-5882
5S-9062	Spacer	363-7463
5S-9080	Pulley - Alt Drive	264-5883
6H-3957	Bearing - Ball	311-9358
6I-1346	Pump Gp - Oil	295-5674
6J-2326	Pin	319-3458
6J-7563	Pin	319-3459
6J-8805	Bearing As	256-4841
6J-9793	Bearing	256-4835
6K-3447	Pin	241-2576
6N-1036	Gear - Oil Pump	279-4991
6N-1553	Coupling - Exhaust	295-6422
6N-2789	Pulley	264-5886
6N-8413	Housing - Pump	325-6110
7B-2420	Ferrule - Director	314-8517
7C-4297	Seal As - Camshaft	325-6192
7G-2477	Gear - Planet	221-9090
7G-2487	Gear - Planet	221-9092
7G-2520	Gear - Planet	221-9094
7H-2742	Nut	229-8220
7J-9708	Bearing - Sleeve	299-1964
7K-1311	Hub As - Sprocket	224-1313
7K-8237	Drum	226-6100
7K-8238	Flange	213-8166
7K-9372	Pin	241-2577
7K-9488	Pin	241-2578
7K-9499	Pin	241-2579
7K-9502	Pin	241-2580
7K-9503	Pin	241-2581
7K-9504	Pin	241-2582
7K-9505	Pin	241-2583
7K-9506	Pin	241-2584
7K-9515	Pin	241-2589
7K-9642	Bearing - Sleeve	360-2340
7M-1776	Plate - Idler Guide	226-0222
7M-1856	Pilot - Recoil Spring	226-0225
7M-1859	Pilot As - Spring	226-0207
7M-1861	Stop - Spring Rh	226-0228
7M-1862	Stop - Spring Lh	226-0229
7M-2167	Ring - Governor Control	308-9919
7M-2531	Rod - Tie	297-7239
7M-4358	Manifold - Exhaust	261-0907
7M-4603	Body - Fuel Valve	311-9348
7M-7358	Valve - Inlet	298-2774
7N-0128	Core As - Oil Cooler	299-1994
7N-0165	Core As - Oil Cooler	295-5670
7N-1164	Mount As	295-5451
7N-2871	Line As - Fuel Injector	319-8172
7N-2872	Line As - Fuel Injector	319-8173
7N-2874	Line As - Fuel Injector	298-2779
7N-2949	Pulley	264-5887
7N-2957	Cover - Rad Cap	361-1722
7N-3515	Gear - Camshaft	314-8669
7N-3536	Gear - Fuel	279-4993
7N-5910	Impeller - Pump	314-8686
7N-8117	Muffler As	247-2668
7N-9146	Gear - Flywheel Starter	279-4995
7N-9805	Pin - Piston	295-6438
7S-3161	Lifter - Valve	279-4996
7S-6723	Bracket - Alternator	299-1978
7S-6875	Pump Gp - Transmission	217-2601
7S-7070	Head As - Cylinder	325-6107
7S-7809	Cap As - Radiator	295-6417
7S-8443	Muffler	247-2675
7S-8572	Gear - Ring	221-9095
7S-9749	Pulley - Gen Drive	264-5888
7T-2036	Cap As - Filter	361-1721
7V-5249	Shaft - Steering	215-1761
7W-0450	Gear - Water Pump	279-4997
7W-0507	Gear - Oil Pump Drive	279-4998
7W-0508	Gear - Fuel Pump Drive	296-1351
7W-5687	Hub - Camshaft	314-8684
8B-5972	Bearing - Ball	314-8503
8E-9795	Connector As	256-4851
8G-1682	Pin	241-2585
8H-7980	Piston	226-0249
8H-9806	Gear - Shaft Drive	325-6091
8K-6357	Pin	241-2586
8K-6358	Pin	241-2587
8K-6359	Pin	241-2588
8K-9661	Gear - Bevel	213-8218
8M-0874	Plunger As - Valve	311-9439
8M-3224	Muffler	247-2676
8M-6676	Cylinder - Adjustable	226-4960
8N-0002	Trunnion As	314-8728
8N-0875	Valve - Exhaust	247-6893 (Valve), 241-3381 (Valve Kit)
8N-1188	Head Gp - Cylinder	242-3436

(Continued)

Sales Model 955K (Continued)

Original Part Number	Part Name	Classic Part Number
8N-1984	Rod As - Conn	242-3441
8N-3180	Body As - Piston	250-6563
8N-3181	Piston Gp - Basic	250-6555 (Liner Kit)
8N-3182	Body As - Piston	250-6564 (Piston As), 250-6556 (Liner Kits)
8N-3183	Piston Gp - Basic	250-6556 (Liner Kit)
8N-3251	Shaft As - Rocker Arm	314-8711
8N-3311	Shaft As - Rocker Arm	325-6199
8N-3312	Shaft As - Rocker Arm	325-6200
8N-3325	Arm Gp - Rocker	314-8623
8N-3327	Arm Gp - Rocker	314-8624
8N-5929	Cover - Water Pump	296-1349
8N-7315	Tube As - Outlet	325-6232
8N-8225	Bearing - Main	314-8652
8N-9733	Line As - Fuel Injector	319-8174
8P-0025	Gear - Idler	217-7721
8P-1656	Plate - Clutch	367-6071
8P-5197	Bearing As	295-6413
8S-0248	Breather As	325-6033
8S-0493	Shaft As - Pump	325-6198
8S-0556	Coupling	221-9114
8S-2809	Muffler	247-2677
8S-3970	Chamber As	242-3438
9G-3526	Gear - Pump Drive	231-8763
9G-8302	Guide	226-4853
9G-8303	Collar - Idler End	226-0242
9H-2256	Pump Gp	311-9443
9H-7670	Piston	226-4961
9K-0447	Shaft - Bevel Pinion	216-7870
9K-6841	Cage As	216-7871
9M-4163	Valve - Exhaust	298-2773
9M-4789	Shaft - Gov Control	297-7256
9M-4955	Pump Gp - Fuel Transfer	242-3443
9N-5769	Cover - Housing	325-6050
9S-6129	Pulley - Alternator Drive	264-5891
9S-8253	Guard As - Roller	226-0182
9Y-2992	Bearing - Sleeve	325-6032

Sales Model 955L

Original Part Number	Part Name	Classic Part Number
100-7860	Valve - Inlet	270-4360 (Valve), 270-4362 (Valve Kit)
111-8015	Gasket As - Head	279-4977
117-1616	Segment Gp - Sprocket	260-5851 (sprocket group)
118-1617	Roller Gp - SF	188-5272
118-1618	Roller Gp - DF	188-5271
121-7746	Precleaner As	360-2311
131-3815	Seal Gp - Basic	325-6193
148-7455	Valve - Exhaust	270-4361
165-4262	Body As - Piston	270-4351
172-5185	Shaft - Water Pump	325-6201
172-5188	Shaft - Water Pump	325-6202
172-5189	Impeller - Pump	295-5687
172-5190	Impeller - Pump	325-6111
172-6712	Impeller - Pump	325-6112
172-7767	Pump Gp - Water	296-1365
190-8609	Valve - Fill	360-2288
196-0028	Gear As - Idler	364-5259
1J-6746	Pin	256-4817
1J-6749	Screw - Adjustable	256-4824
1M-7250	Bowl - Precleaner	360-2296
1N-3576	Block Gp - Cylinder	279-4978
1N-3958	Elbow	325-6087
1N-4304	Head Gp - Cylinder	269-8761
1P-0963	Guard As - Roller	226-0179
1P-1216	Manifold - Exhaust	261-0902
1P-1721	Gear - Balance	298-2769
1P-1722	Gear - Balance	298-2770
1P-5480	Cover As - End	299-1998
1P-6160	Gear - Pump Driven	231-8760
1P-9945	Bracket As - Fan	296-1344
1P-9946	Shaft - Fan	325-6194
1P-9952	Impeller - Pump	314-8685
1S-1859	Bolt - Track	188-5633
1S-1888	Bracket - Lamp	297-7147
1S-4701	Pulley - Alt	264-5866
1S-5331	Cylinder - Adjustable	226-0214
1S-6422	Pilot As - Spring	226-4849
1T-0724	Impeller - Converter	216-7469
1T-0727	Hub - Impeller	229-8236
1T-0947	Flange As - Input	229-8224
1T-0949	Housing - Rotating	217-7732
1T-0972	Carrier As	216-7470
1T-1255	Torque Converter	235-1806 (Repair Kit)

(Continued)

Sales Model 955L (Continued)

Original Part Number	Part Name	Classic Part Number
1T-1285	Gear As - Drive	217-7734
1T-1331	Stator - Converter	229-8237
1V-0940	Holder - Bearing Cage	216-7472
1V-3242	Cage - Release Bearing	216-7475
1V-3676	Case - Drive Gear	216-7799
1V-3677	Case - Final Drive Gear	216-7802
1V-7556	Support	216-7804
1W-1219	Trunnion As	314-8724
1W-2870	Shaft As - Balance	314-8715
1W-2871	Shaft As - Balance	314-8716
1W-4402	Gear - Camshaft	279-4981
1W-4405	Gear - Crankshaft	279-4982
236-9861	Link As	175-8555
236-9864	Link As	188-5527
236-9866	Link As.	188-5588
238-9951	Link As	290-6589
244-1090	Alarm - Back up	360-2345
2B-8824	Drum	216-7817
2F-5721	Bearing - Ball	311-9354
2J-8489	Bearing - Sleeve	295-5691
2K-4502	Bearing - Sleeve	299-1986
2K-4507	Bearing - Sleeve	325-6021
2K-6413	Pin	360-2270
2M-4668	Retainer - Guard	297-4867
2P-1170	Shaft As - Gear	296-1367
2P-1757	Hub - Fan Pulley	296-1357
2P-1781	Spacer - Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2519	Tube As - Inlet	325-6230
2P-2719	Pipe	363-7454
2P-2744	Muffler As	247-2664
2P-5081	Muffler As	360-7872
2P-6128	Pulley	264-5872
2P-6245	Shaft As - Pump	325-6197
2P-7828	Pan - Oil	314-8691
2V-5551	Pinion - Final Drive	216-7822
2V-5552	Gear & Pinion - Final Drive	216-7823
2W-1086	Cover As - Cylinder Head	325-6049
2W-2621	Valve - Inlet	247-6892 (Valve), 241-3381 (Valve Kit)
2W-7255	Shaft - Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear - Water Pump	325-6088
2W-9978	Core As - Oil Cooler	279-4983
3F-6185	Pin	295-5694
3K-3774	Gear - Final Drive	217-7716
3K-3814	Gear & Pinion - Final Drive	216-7825
3L-1425	Bearing - Ball	311-9356
3P-3623	Lock - Adjustable Nut	226-7989
3S-1167	Gear - Planet	221-9101
3S-4386	Pump Gp - Steering	217-2599
3T-3206	Roller Gp - Carrier	188-5590
3V-1133	Strip	226-0203
3V-2042	Hub - Gear	217-7735
3V-2771	Retainer	216-7830
3V-5604	Pinion - Final Drive	216-7832
3V-5605	Gear - Final Drive & Pinion	216-7833
3V-5778	Shaft - Sprocket	216-7834
3V-5916	Plate As - Press	226-8025
3V-5918	Gear - Final Drive	217-7717
3V-5920	Hub - Gear	222-1762
3V-7365	Hub - Gear	219-2965
4F-4974	Clamp	311-9373
4J-2414	Trunnion	296-1370
4K-1328	Drum - Steering	216-7840 (Drum), 230-7112 (Steering Clutch Kit)
4K-3004	Bearing - Trunnion Support	314-8632
4K-3128	Bearing - Sleeve	314-8633
4K-4632	Gear - Bevel	216-7842
4K-4780	Strip As - Wear	299-2063
4K-7386	Plate - Guide	226-4851
4N-2954	Sleeve - Camshaft	299-2059
4N-3281	Line As - Fuel Injector	247-3362
4N-3282	Line As - Fuel Injector	247-3363
4N-3283	Line As - Fuel Injector	247-3364
4N-3284	Line As - Fuel Injector	247-3365
4N-4539	Sleeve	314-8720
4N-4864	Pump Gp - Fuel Transfer	242-3442
4N-7692	Crankshaft As	242-3440
4N-7693	Crankshaft As	242-3439
4N-7977	Shaft As - Balance	314-8709
4N-7978	Shaft As - Balance	314-8710
4N-9587	Shield - Heat	297-7260
4P-3546	Valve As - Relief	325-6236
4S-5943	Piston - Clutch	221-9112
4S-5944	Gear - Sun	221-9078
4S-5945	Gear - Sun	221-9079
4S-5946	Shaft - Center	229-8238
4S-5947	Gear - Ring	221-9080
4S-5948	Gear - Ring	221-9082
4S-5979	Carrier As	216-7843
4S-5981	Gear - Ring	221-9084
4S-8530	Shaft - Planet	221-9111
4S-8534	Shaft As - Planet	221-9116
4V-7344	Pin	241-2574
4W-0452	Seal As - Camshaft	325-6191
5F-0736	Pin - Pivot	256-4823
5F-7993	Pin	319-3454

(Continued)

Sales Model 955L (Continued)

Original Part Number	Part Name	Classic Part Number
5G-3612	Cap Gp	295-6419
5J-4798	Bearing As	256-4840
5J-8052	Trunnion	256-4843
5K-2893	Shaft - Sprocket	221-7953
5K-6090	Flange	216-7844
5K-6142	Cage - Final Drive Gear Bearing	223-4811
5K-7027	Pin	241-2575
5K-8330	Holder - Tooth	299-2013
5K-8606	Cage - Gear Bearing	223-6310
5K-8628	Cage	216-7845
5P-7807	Bearing - Ball	314-8502
5S-4493	Carrier - Planet	223-6321
5S-4557	Bearing	311-9360
5S-6795	Chamber As	242-3437
5S-6972	Gear - Sun	221-9087
5S-6978	Shaft - Planet	221-9103
5S-7009	Plate As - End	226-4957
5S-7010	Shaft - Planet	221-9104
5S-7013	Gear - Ring	221-9088
5S-7023	Carrier - Planet	226-5986
5S-7609	Pulley - Alt Drive	264-5881
5S-7894	Flange As	216-7854
5S-8038	Pulley - Crankshaft	264-5882
5S-9062	Spacer	363-7463
5S-9080	Pulley - Alt Drive	264-5883
6H-3957	Bearing - Ball	311-9358
6I-1346	Pump Gp - Oil	295-5674
6J-2326	Pin	319-3458
6J-7563	Pin	319-3459
6J-8805	Bearing As	256-4841
6J-9793	Bearing	256-4835
6K-3447	Pin	241-2576
6L-9210	Idler Gp (Complete Idler Group)	175-8038 (Idler As.), 200-9236
6N-1036	Gear - Oil Pump	279-4991
6N-1553	Coupling - Exhaust	295-6422
6N-2789	Pulley	264-5886
6N-8413	Housing - Pump	325-6110
6Y-6289	Shoe -Track	188-5270
6Y-6290	Shoe -Track Master	175-8728
6Y-6291	Shoe -Track	175-8031
6Y-6292	Shoe -Track Master	175-8032
6Y-6293	Shoe -Track	175-8369
6Y-6294	Shoe -Track Master	175-8370
6Y-6295	Shoe -Track	175-8371
6Y-6296	Shoe -Track Master	175-8372
6Y-6394	Shoe -Track Master	188-5591
6Y-6395	Shoe -Track	188-5396
6Y-6397	Shoe -Track Master	188-5594
6Y-6398	Shoe -Track	188-5593
6Y-6411	Shoe -Track	188-5397
6Y-6412	Shoe -Track Master	188-5592
7C-4297	Seal As - Camshaft	325-6192
7G-2477	Gear - Planet	221-9090
7G-2487	Gear - Planet	221-9092
7G-2520	Gear - Planet	221-9094
7H-2742	Nut	229-8220
7J-9708	Bearing - Sleeve	299-1964
7K-1311	Hub As - Sprocket	224-1313
7K-8237	Drum	226-6100
7K-8238	Flange	213-8166
7K-9372	Pin	241-2577
7K-9488	Pin	241-2578
7K-9499	Pin	241-2579
7K-9502	Pin	241-2580
7K-9503	Pin	241-2581
7K-9504	Pin	241-2582
7K-9505	Pin	241-2583
7K-9506	Pin	241-2584
7K-9515	Pin	241-2589
7K-9642	Bearing - Sleeve	360-2340
7M-1776	Plate - Idler Guide	226-0222
7M-1856	Pilot - Recoil Spring	226-0225
7M-1859	Pilot As - Spring	226-0207
7M-1861	Stop - Spring Rh	226-0228
7M-1862	Stop - Spring Lh	226-0229
7M-2167	Ring - Governor Control	308-9919
7M-2531	Rod - Tie	297-7239
7M-4603	Body - Fuel Valve	311-9348
7N-0128	Core As - Oil Cooler	299-1994
7N-0165	Core As - Oil Cooler	295-5670
7N-1164	Mount As	295-5451
7N-2871	Line As - Fuel Injector	319-8172
7N-2872	Line As - Fuel Injector	319-8173
7N-2874	Line As - Fuel Injector	298-2779
7N-2949	Pulley	264-5887
7N-3515	Gear - Camshaft	314-8669
7N-3536	Gear - Fuel	279-4993
7N-5910	Impeller - Pump	314-8686
7N-8117	Muffler As	247-2668
7N-9146	Gear - Flywheel Starter	279-4995
7N-9805	Pin - Piston	295-6438
7S-3161	Lifter - Valve	279-4996
7S-6723	Bracket - Alternator	299-1978
7S-6875	Pump Gp - Transmission	217-2601
7S-7070	Head As - Cylinder	325-6107
7S-7809	Cap As - Radiator	295-6417
7S-8443	Muffler	247-2675
7S-8572	Gear - Ring	221-9095
7S-9749	Pulley - Gen Drive	264-5888
7T-2036	Cap As - Filter	361-1721
7T-4562	Idler As	175-8263
7V-5249	Shaft - Steering	215-1761
7W-0450	Gear - Water Pump	279-4997
7W-0507	Gear - Oil Pump Drive	279-4998

(Continued)

Sales Model 955L (Continued)

Original Part Number	Part Name	Classic Part Number
7W-0508	Gear - Fuel Pump Drive	296-1351
7W-5687	Hub - Camshaft	314-8684
8B-5972	Bearing - Ball	314-8503
8E-4365	Segment Gp - Sprocket	188-5635 (sprocket group), 188-5589 (segment)
8E-4499	Shoe -Track	188-5383
8E-4500	Shoe -Track Master	188-5387
8E-4501	Shoe -Track	188-5381
8E-4502	Shoe -Track Master	188-5385
8E-9795	Connector As	256-4851
8G-1682	Pin	241-2585
8H-2810	Case As - Filter	314-8512
8H-7980	Piston	226-0249
8H-9806	Gear - Shaft Drive	325-6091
8K-6357	Pin	241-2586
8K-6358	Pin	241-2587
8K-6359	Pin	241-2588
8K-9661	Gear - Bevel	213-8218
8M-0874	Plunger As - Valve	311-9439
8M-6676	Cylinder - Adjustable	226-4960
8M-7166	Housing - Screen	297-7192
8N-0002	Trunnion As	314-8728
8N-0875	Valve - Exhaust	247-6893 (Valve), 241-3381 (Valve Kit)
8N-1187	Head Gp - Cylinder	242-3435
8N-1188	Head Gp - Cylinder	242-3436
8N-1721	Rod As - Conn	269-5291
8N-1984	Rod As - Conn	242-3441
8N-3181	Piston Gp - Basic	250-6555 (Liner Kit)
8N-3182	Body As - Piston	250-6564 (Piston As), 250-6556 (Liner Kits)
8N-3183	Piston Gp - Basic	250-6556 (Liner Kit)
8N-3251	Shaft As - Rocker Arm	314-8711
8N-3311	Shaft As - Rocker Arm	325-6199
8N-3312	Shaft As - Rocker Arm	325-6200
8N-3325	Arm Gp - Rocker	314-8623
8N-3327	Arm Gp - Rocker	314-8624
8N-5305	Spacer	363-7464
8N-5929	Cover - Water Pump	296-1349
8N-6796	Head Gp - Cylinder	269-5290
8N-7315	Tube As - Outlet	325-6232
8N-8225	Bearing - Main	314-8652
8N-9733	Line As - Fuel Injector	319-8174
8P-0025	Gear - Idler	217-7721
8P-1656	Plate - Clutch	367-6071
8P-5197	Bearing As	295-6413
8S-0248	Breather As	325-6033
8S-0493	Shaft As - Pump	325-6198
8S-0556	Coupling	221-9114
8S-2809	Muffler	247-2677
8S-3970	Chamber As	242-3438
9G-3526	Gear - Pump Drive	231-8763
9G-8302	Guide	226-4853
9G-8303	Collar - Idler End	226-0242
9H-2256	Pump Gp	311-9443
9H-7670	Piston	226-4961
9K-0447	Shaft - Bevel Pinion	216-7870
9K-6841	Cage As	216-7871
9M-3025	Cover As	299-2001
9M-4789	Shaft - Gov Control	297-7256
9N-5769	Cover - Housing	325-6050
9S-1838	Bolt Master	188-5634
9S-6129	Pulley - Alternator Drive	264-5891
9S-8253	Guard As - Roller	226-0182
9S-8679	Chamber As	325-6042
9W-1677	Bearing	297-7145
9Y-2992	Bearing - Sleeve	325-6032

Sales Model 977D, 977E

Original Part Number	Part Name	Classic Part Number
0T-0259	Nut - Bearing Sleeve	311-9431
121-7746	Precleaner As	360-2311
1A-2846	Cap As - Filler	311-9368
1F-2254	Bushing - Stem	314-8510
1H-8262	Shaft	226-8016
1H-8382	Gear - Oil Pump Drive	226-6103
1H-8937	Drumbrake	226-7993
1H-8938	Lever	226-8028
1M-0176	Flange - Drum	223-4810
1M-5165	Pinion - Final Drive	231-8766
1M-7250	Bowl - Precleaner	360-2296
1M-9177	Flywheel	226-6112
1P-0005	Pump Gp - Fuel Transfer	256-4756
1P-1931	Shaft - Steer	227-4772
1P-7044	Cage	226-7975
1S-1888	Bracket - Lamp	297-7147
1S-1967	Chamber As	247-3291
1S-1970	Chamber As	247-3292
1S-5331	Cylinder - Adjustable	226-0214
1S-6422	Pilot As - Spring	226-4849

(Continued)

Sales Model 977D, 977E (Continued)

Original Part Number	Part Name	Classic Part Number
1S-8764	Ring - Flywheel Clutch Adjustable	226-8014
2F-0025	Tube	325-6233
2F-5721	Bearing - Ball	311-9354
2F-7576	Shaft - Sprocket	226-6071
2H-4338	Plate - Pressure	226-8010
2H-4450	Washer - Thrust	325-6237
2H-4482	Collar	229-8218
2H-5046	Link - Flycam	299-2024
2K-3592	Boss	314-8501
2K-4442	Bearing - Sleeve	308-9812
2K-4507	Bearing - Sleeve	325-6021
2K-4513	Bearing - Sleeve	308-9814
2M-2290	Bracket - Ring	299-1979
2M-2417	Guard-spring - Rh	226-4934
2M-2418	Guard-spring - Lh	226-4935
2P-0483	Chamber As	256-4760
2P-7622	Bolt - Spring	226-4850
2P-9660	Gear - Final Drive	226-5995
2S-1273	Chamber As	319-3434
2S-1477	Holder As - Cage	226-7985
2S-3966	Ring - Seal	297-7237
2S-4015	Plunger As - Valve	311-9438
3B-6218	Muffler As	247-2672
3F-1956	Cap - Frame Sup	226-7987
3F-1972	Retainer As	226-7988
3F-7445	Bearing - Sleeve	314-8508
3H-3378	Gear As - Pump	298-2795
3P-3623	Lock - Adjustable Nut	226-7989
3P-5754	Hub - Gear	219-2976
3S-7153	Gear - Sliding	227-0024
3S-8800	Gear - Driven	325-6090
4F-1252	Pin	295-5704
4F-4974	Clamp	311-9373
4H-4021	Plate As - Loading	229-8219
4H-9040	Nut	226-7996
4K-4460	Pin	241-2609
4M-9215	Gear - Pump Idler	311-9391
4N-7526	Seal As - Pump	311-9454
4N-9180	Seal As - Pump	311-9455
4S-8005	Pinion - Final Drive	226-6076
5A-9551	Gear - Final Drive	226-7979
5F-0689	Pin	256-4821
5F-0706	Pin	256-4822
5F-0707	Collar	256-4831
5F-0736	Pin - Pivot	256-4823
5F-2256	Cage - Bearing	226-7973
5H-5500	Collar - Flywheel	302-2704
5M-5244	Hub - Gear	219-2982
5S-1211	Cover - Valve	314-8665
6B-7178	Fork - Band Adjustable	299-2009
6F-3183	Cap - Bearing	325-6038
6H-3957	Bearing - Ball	311-9358
6P-0169	Hub - Flywheel Clutch	297-7204
7B-2420	Ferrule - Director	314-8517
7B-5088	Drum - Steering	223-4813
7F-9547	Pin As - Drawbar	295-0414
7G-6044	Cage As	216-7857
7H-0602	Dog - Clutch	314-8515
7H-1318	Coupling - Steering	226-8002
7H-2424	Sleeve - Spring	226-4852
7J-9682	Bearing - Sleeve	360-2335
7M-0820	Gear - Sliding	226-6086
7M-4603	Body - Fuel Valve	311-9348
7M-4926	Retainer - Pin	314-8538
7M-5002	Drum - Steering	226-7992
7M-5050	Collar - Front Idler	226-4958
7M-9398	Plate - Guide	297-7230
7S-6537	Guard As - Rh Basic	226-4941
7S-6538	Guard As - Lh Basic	226-4942
7S-7602	Pump Gp	226-0174
7S-7625	Support As	226-6095
7S-7809	Cap As - Radiator	295-6417
7T-0206	Bearing - Brace	297-7144
8F-5104	Screen As - Oil Pan	314-8539
8H-1383	Rod - Tie	299-2051
8H-1993	Valve - Inlet	256-4765 (Valve Kit)
8H-1994	Valve - Exhaust	256-4765 (Valve Kit)
8H-2810	Case As - Filter	314-8512
8H-7980	Piston	226-0249
8H-9379	Nut - Brake Band Adjustable	299-2029
8M-6676	Cylinder - Adjustable	226-4960
8P-1182	Shaft	227-4771
8P-1183	Gear - Bevel	226-7980
8S-5722	Plate - Pressure	226-8009
9F-7101	Bushing - Collar	299-1988
9H-4104	Pilot - Spring	226-4962
9H-7670	Piston	226-4961
9M-8117	Shaft - Flywheel Clutch	226-6073
9M-8119	Retainer - Inlet	226-8022
9S-3321	Cage - Pinion Bearing	226-7974
9S-8493	Bolt - Connecting Rod	311-9351
9W-1677	Bearing	297-7145

Sales Model 977H

Original Part Number	Part Name	Classic Part Number
190-8609	Valve - Fill	360-2288
1A-2846	Cap As - Filler	311-9368
1M-0176	Flange - Drum	223-4810
1M-6128	Manifold - Exhaust	261-0906
1S-1888	Bracket - Lamp	297-7147
1S-4701	Pulley - Alt	264-5866
1S-5315	Cap As - Brace Bearing	226-4848
1S-5331	Cylinder - Adjustable	226-0214
1T-0699	Impeller - Converter	235-1808
1T-1993	Wheel - Turbine	235-0920
1W-4405	Gear - Crankshaft	279-4982
2F-5721	Bearing - Ball	311-9354
2K-4442	Bearing - Sleeve	308-9812
2K-4507	Bearing - Sleeve	325-6021
2K-4513	Bearing - Sleeve	308-9814
2M-4668	Retainer - Guard	297-4867
2M-8297	Pinion - Final Drive	218-4429
2M-8304	Shaft - Sprocket	221-1038
2S-3966	Ring - Seal	297-7237
2S-4015	Plunger As - Valve	311-9438
3H-3378	Gear As - Pump	298-2795
3K-2230	Gear - Planet	219-9658
3K-2498	Shaft - Planet	216-7824
3L-1425	Bearing - Ball	311-9356
3P-3623	Lock - Adjustable Nut	226-7989
4F-1252	Pin	295-5704
4K-4460	Pin	241-2609
4K-4780	Strip As - Wear	299-2063
4N-7526	Seal As - Pump	311-9454
4N-9180	Seal As - Pump	311-9455
5F-0689	Pin	256-4821
5F-0706	Pin	256-4822
5F-0707	Collar	256-4831
5F-0736	Pin - Pivot	256-4823
5P-7807	Bearing - Ball	314-8502
5S-1211	Cover - Valve	314-8665
5S-1822	Chamber As	248-5406
5S-1833	Chamber As	247-3298
5S-4557	Bearing	311-9360
5S-9080	Pulley - Alt Drive	264-5883
6B-7178	Fork - Band Adjustable	299-2009
6F-3183	Cap - Bearing	325-6038
7B-2420	Ferrule - Director	314-8517
7B-5088	Drum - Steering	223-4813
7F-9547	Pin As - Drawbar	295-0414
7G-2522	Gear - Planet	216-7855
7H-1318	Coupling - Steering	226-8002
7J-9682	Bearing - Sleeve	360-2335
7M-2167	Ring - Governor Control	308-9919
7M-4204	Manifold - Exhaust	261-0901
7M-4603	Body - Fuel Valve	311-9348
7M-5002	Drum - Steering	226-7992
7M-7358	Valve - Inlet	298-2774
7S-7809	Cap As - Radiator	295-6417
7S-9749	Pulley - Gen Drive	264-5888
7T-0203	Guide	226-4959
7T-0206	Bearing - Brace	297-7144
7T-2036	Cap As - Filter	361-1721
8H-1383	Rod - Tie	299-2051
8H-7980	Piston	226-0249
8H-9806	Gear - Shaft Drive	325-6091
8M-0493	Cage - Outer Bearing	216-7866
8M-3224	Muffler	247-2676
8N-8225	Bearing - Main	314-8652
8P-1182	Shaft	227-4771
8P-1183	Gear - Bevel	226-7980
8P-4112	Guard As	226-4946
8S-1832	Guard As - Sprocket	226-4948
8S-5722	Plate - Pressure	226-8009
9G-8302	Guide	226-4853
9H-2256	Pump Gp	311-9443
9J-9598	Pin	296-1362
9M-4163	Valve - Exhaust	298-2773
9M-4955	Pump Gp - Fuel Transfer	242-3443
9W-1677	Bearing	297-7145

Sales Model 977K

Original Part Number	Part Name	Classic Part Number
111-8015	Gasket As - Head	279-4977
131-3815	Seal Gp - Basic	325-6193
172-5185	Shaft - Water Pump	325-6201
172-5188	Shaft - Water Pump	325-6202
172-5189	Impeller - Pump	295-5687
172-5190	Impeller - Pump	325-6111
172-6712	Impeller - Pump	325-6112
172-7767	Pump Gp - Water	296-1365
190-8609	Valve - Fill	360-2288
1A-2846	Cap As - Filler	311-9368
1M-9444	Retainer - Spring	299-2046
1N-3576	Block Gp - Cylinder	279-4978
1N-3958	Elbow	325-6087
1P-1006	Strip - Guard	226-0245
1P-1897	Gear - Final Drive	215-1670

(Continued)

Sales Model 977K (Continued)

Original Part Number	Part Name	Classic Part Number
1P-4303	Head As - Cylinder	242-3434
1P-6160	Gear - Pump Driven	231-8760
1P-8554	Coupling - Exhaust	325-6052
1P-9663	Carrier - Bearing	217-7731
1P-9945	Bracket As - Fan	296-1344
1P-9946	Shaft - Fan	325-6194
1P-9952	Impeller - Pump	314-8685
1S-1888	Bracket - Lamp	297-7147
1S-4701	Pulley - Alt	264-5866
1S-5331	Cylinder - Adjustable	226-0214
1T-0662	Turbine - Conv	235-1819
1T-0665	Ring - Clamp	308-9918
1T-0987	Hub - Impeller	247-4118
1T-1089	Hub - Turbine	216-7471
1W-1219	Trunnion As	314-8724
1W-4402	Gear - Camshaft	279-4981
1W-4405	Gear - Crankshaft	279-4982
2F-0025	Tube	325-6233
2F-5721	Bearing - Ball	311-9354
2K-4442	Bearing - Sleeve	308-9812
2K-4507	Bearing - Sleeve	325-6021
2M-0369	Pilot - Spring Recoil	226-0226
2M-4668	Retainer - Guard	297-4867
2P-1170	Shaft As - Gear	296-1367
2P-1738	Plate As - Oil Pan	325-6164
2P-1739	Tube As - Pump	325-6229
2P-1757	Hub - Fan Pulley	296-1357
2P-1781	Spacer - Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2519	Tube As - Inlet	325-6230
2P-2744	Muffler As	247-2664
2P-3422	Gear - First Reduction	213-8451
2P-3423	Pinion - Sec Reduction	216-3553
2P-6245	Shaft As - Pump	325-6197
2S-3443	Drum - Steer	219-9689 (Drum), 230-7113 (Steering Clutch Kit)
2S-3966	Ring - Seal	297-7237
2S-4015	Plunger As - Valve	311-9438
2S-6344	Gear - Final Drive	297-7173
2S-7603	Drum	213-6951
2W-1086	Cover As - Cylinder Head	325-6049
2W-2621	Valve - Inlet	247-6892 (Valve), 241-3381 (Valve Kit)
2W-7255	Shaft - Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
3H-3378	Gear As - Pump	298-2795
3L-1425	Bearing - Ball	311-9356
3P-3623	Lock - Adjustable Nut	226-7989
3P-6318	Flange - Drum	213-8165
3S-0777	Bearing - Roller Frame	229-8226
3S-1691	Disc - Steering	302-2705
3S-2337	Shaft - Output	231-8765
3S-6907	Gear - Transfer	217-9774
3S-6908	Gear - Transfer	217-9775
3S-9199	Hub - Sprocket	224-1310
3T-4482	Guide - Front Idler	226-0248
4F-4974	Clamp	311-9373
4K-0300	Bearing - Sleeve	308-9817
4N-2954	Sleeve - Camshaft	299-2059
4N-3281	Line As - Fuel Injector	247-3362
4N-3282	Line As - Fuel Injector	247-3363
4N-3283	Line As - Fuel Injector	247-3364
4N-4864	Pump Gp - Fuel Transfer	242-3442
4N-7526	Seal As - Pump	311-9454
4N-7693	Crankshaft As	242-3439
4N-8591	Coupling - Exhaust	325-6053
4N-8814	Line As - Fuel Injector	247-3366
4N-9180	Seal As - Pump	311-9455
4N-9587	Shield - Heat	297-7260
4P-3546	Valve As - Relief	325-6236
4S-8708	Housing - Clutch	216-3557
4S-8718	Cage - Carrier Bearing	217-7724
4W-0452	Seal As - Camshaft	325-6191
5G-3612	Cap Gp	295-6419
5J-4542	Bearing - Sleeve	308-9818
5K-6377	Pin	241-2610
5K-6382	Pin	241-2611
5K-6383	Pin	241-2612
5K-7995	Bearing - Sleeve	308-9820
5K-9367	Pin	241-2613
5M-5822	Gear - Pump Drive	247-4120
5M-6120	Gear - Sun	213-8740
5M-6210	Shaft - Planet	219-9683
5M-6211	Shaft - Planet	219-9684
5M-6670	Shaft - Sprocket	216-7847
5M-6690	Hub - Steering	215-1695
5M-7290	Cage - Bearing	216-7848
5M-7740	Gear - Bevel	213-8216
5M-7841	Gear - Ring	214-0525
5M-7864	Pump Gp - Scavenge	226-0169
5M-7869	Gear - Ring	214-0530
5M-7875	Carrier - Front	213-4495
5M-7900	Bolt - Hex Head	311-9349
5M-7923	Shaft - Output	215-1697
5P-7807	Bearing - Ball	314-8502

(Continued)

Sales Model 977K (Continued)

Original Part Number	Part Name	Classic Part Number
5S-0073	Plate - Steering	302-2692
5S-0192	Pinion - Final Drive	215-1698
5S-1211	Cover - Valve	314-8665
5S-1822	Chamber As	248-5406
5S-1833	Chamber As	247-3298
5S-4557	Bearing	311-9360
5S-6795	Chamber As	242-3437
5S-9080	Pulley - Alt Drive	264-5883
6H-3957	Bearing - Ball	311-9358
6I-1346	Pump Gp - Oil	295-5674
6K-1983	Pin	241-2614
6N-1036	Gear - Oil Pump	279-4991
6N-1965	Line As - Fuel Injector	250-7535
6N-1966	Line As - Fuel Injector	250-7536
6N-2789	Pulley	264-5886
6N-8413	Housing - Pump	325-6110
6P-1382	Pin	241-2615
6P-1383	Pin	241-2616
6T-1980	Collar - Idler End	226-0210
7B-2420	Ferrule - Director	314-8517
7C-4297	Seal As - Camshaft	325-6192
7F-9547	Pin As - Drawbar	295-0414
7G-2475	Gear - Planet	223-4815
7G-2476	Gear - Planet	223-4816
7G-2513	Gear - Planet	215-1734
7G-5301	Pump Gp	217-2600
7G-5323	Pinion - Final Drive	231-8767
7G-6681	Cage As	216-7860
7J-9344	Bearing - Sleeve	360-2334
7J-9731	Bearing - Sleeve	308-9822
7J-9732	Bearing - Sleeve	308-9823
7K-9366	Pin	241-2617
7K-9370	Pin	241-2618
7K-9371	Pin	241-2619
7K-9373	Pin	241-2620
7K-9375	Pin	241-2621
7K-9528	Bearing - Sleeve	308-9828
7K-9530	Bearing - Sleeve	299-1967
7M-2167	Ring - Governor Control	308-9919
7M-4204	Manifold - Exhaust	261-0901
7M-4603	Body - Fuel Valve	311-9348
7M-7358	Valve - Inlet	298-2774
7N-0128	Core As - Oil Cooler	299-1994
7N-0165	Core As - Oil Cooler	295-5670
7N-1164	Mount As	295-5451
7N-2871	Line As - Fuel Injector	319-8172
7N-2872	Line As - Fuel Injector	319-8173
7N-2874	Line As - Fuel Injector	298-2779
7N-2875	Line As - Fuel Injector	298-2780
7N-2876	Line As - Fuel Injector	298-2781
7N-2949	Pulley	264-5887
7N-2957	Cover - Rad Cap	361-1722
7N-3486	Manifold - Exhaust	261-0899
7N-3515	Gear - Camshaft	314-8669
7N-3536	Gear - Fuel	279-4993
7N-5910	Impeller - Pump	314-8686
7N-9145	Gear - Flywheel	279-4994
7N-9312	Damper As - Camshaft	299-2005
7N-9805	Pin - Piston	295-6438
7S-3161	Lifter - Valve	279-4996
7S-6723	Bracket - Alternator	299-1978
7S-7809	Cap As - Radiator	295-6417
7S-8443	Muffler	247-2675
7S-9749	Pulley - Gen Drive	264-5888
7T-2036	Cap As - Filter	361-1721
7T-9963	Case As - Transfer Gear	219-9665
7W-0450	Gear - Water Pump	279-4997
7W-0507	Gear - Oil Pump Drive	279-4998
7W-5687	Hub - Camshaft	314-8684
8H-1383	Rod - Tie	299-2051
8H-7980	Piston	226-0249
8H-9806	Gear - Shaft Drive	325-6091
8M-0874	Plunger As - Valve	311-9439
8M-3224	Muffler	247-2676
8M-6191	Sleeve - Bolt	226-0234
8M-7166	Housing - Screen	297-7192
8M-8619	Cage - Bearing	217-7725
8M-8623	Gear - Sun	213-8755
8M-8628	Flange - Joint	217-9776
8M-8642	Housing - Clutch	219-9669
8M-8644	Housing - Clutch	215-1782
8M-8646	Plate As - Center	216-3583
8M-8649	Piston - Clutch	217-9777
8M-8650	Piston - Clutch	217-9778
8M-8652	Shaft	297-7252
8M-8677	Carrier - Planet	213-4449
8N-0002	Trunnion As	314-8728
8N-0875	Valve - Exhaust	247-6893 (Valve), 241-3381 (Valve Kit)
8N-1187	Head Gp - Cylinder	242-3435
8N-1721	Rod As - Conn	269-5291
8N-1984	Rod As - Conn	242-3441
8N-3180	Body As - Piston	250-6563
8N-3181	Piston Gp - Basic	250-6555 (Liner Kit)
8N-3182	Body As - Piston	250-6564 (Piston As), 250-6556 (Liner Kits)

(Continued)

Sales Model 977K (Continued)

Original Part Number	Part Name	Classic Part Number
8N-3183	Piston Gp - Basic	250-6556 (Liner Kit)
8N-3325	Arm Gp - Rocker	314-8623
8N-3327	Arm Gp - Rocker	314-8624
8N-5929	Cover - Water Pump	296-1349
8N-7315	Tube As - Outlet	325-6232
8N-8225	Bearing - Main	314-8652
8N-9733	Line As - Fuel Injector	319-8174
8P-0025	Gear - Idler	217-7721
8P-0605	Gear - First Reduction	213-8453
8P-0606	Pinion - Sec Reduction	215-1783
8P-0622	Hub - Sprocket	288-8731
8P-4537	Pinion - Reduction	216-7867
8P-4538	Gear - First Reduction	216-7868
8P-4539	Pinion - Final Drive	217-7711

Original Part Number	Part Name	Classic Part Number
8P-6495	Drum	213-6954 (Drum), 227-9302 (Steering Clutch Kit)
8P-6803	Shaft As	215-1842
8P-7790	Valve Gp - Press	247-4437
8S-0248	Breather As	325-6033
8S-0493	Shaft As - Pump	325-6198
8S-3970	Chamber As	242-3438
9G-0383	Hub - Gear	221-1064
9G-3526	Gear - Pump Drive	231-8763
9H-2256	Pump Gp	311-9443
9M-0701	Piston - Steer	219-9692
9M-0702	Pilot - Piston	229-8232
9M-1500	Shaft - Planet	219-9685
9M-1502	Cage - Bearing	219-9686
9M-1995	Gear - Sun	213-8756
9M-1996	Shaft - Planet	215-1875
9M-2013	Housing As	216-3585
9M-2045	Pinion - Bevel	215-1878
9M-2049	Gear - Ring	214-0533
9M-3025	Cover As	299-2001
9M-4163	Valve - Exhaust	298-2773
9M-4789	Shaft - Gov Control	297-7256

Original Part Number	Part Name	Classic Part Number
9M-4955	Pump Gp - Fuel Transfer	242-3443
9N-5769	Cover - Housing	325-6050
9P-0418	Cage	223-6311
9P-0620	Cage - Pinion Bearing	221-1052
9P-3436	Holder As - Cage	216-7875
9P-5363	Piston - Clutch	219-9687
9P-5379	Housing - Clutch	215-1904
9P-9000	Shaft - Steering	217-7738
9P-9575	Cage - Bevel Gr Bearing	216-7876
9S-1043	Guard As - Guiding	226-0240
9S-1044	Guard As - Guiding	226-0241
9S-1045	Strip - Guard	226-0246
9S-1046	Strip - Guard	226-0247
9S-2354	Manifold - Exhaust	261-0888
9S-2355	Manifold - Exhaust	261-0891
9S-6129	Pulley - Alternator Drive	264-5891
9S-8679	Chamber As	325-6042
9S-8789	Plate - Clutch	302-2712

Sales Model 977L

Original Part Number	Part Name	Classic Part Number
100-7860	Valve - Inlet	270-4360 (Valve), 270-4362 (Valve Kit)
111-8015	Gasket As - Head	279-4977
117-1024	Link As.	188-5595
118-1619	Roller Gp - Track	188-5257
118-1620	Roller Gp - DF	188-5258
118-1623	Roller Gp - Track	188-5596
118-1625	Roller Gp - Track	188-5597
131-3815	Seal Gp - Basic	325-6193
148-7455	Valve - Exhaust	270-4361

Original Part Number	Part Name	Classic Part Number
172-5185	Shaft - Water Pump	325-6201
172-5188	Shaft - Water Pump	325-6202
172-5189	Impeller - Pump	295-5687
172-5190	Impeller - Pump	325-6111
172-6712	Impeller - Pump	325-6112
172-7767	Pump Gp - Water	296-1365
190-8609	Valve - Fill	360-2288
196-0028	Gear As - Idler	364-5259
1M-9444	Retainer - Spring	299-2046

Original Part Number	Part Name	Classic Part Number
1N-3576	Block Gp - Cylinder	279-4978
1N-3958	Elbow	325-6087
1P-1006	Strip - Guard	226-0245
1P-1897	Gear - Final Drive	215-1670
1P-4303	Head As - Cylinder	242-3434
1P-6160	Gear - Pump Driven	231-8760
1P-8554	Coupling - Exhaust	325-6052
1P-8717	Roller Gp - Carrier	188-5600
1P-9663	Carrier - Bearing	217-7731
1P-9807	Shoe -Track	188-5333

(Continued)

Sales Model 977L (Continued)

Original Part Number	Part Name	Classic Part Number
1P-9808	Shoe -Track	175-8802
1P-9809	Shoe -Track	175-8882
1P-9810	Shoe -Track	188-5334
1P-9945	Bracket As - Fan	296-1344
1P-9946	Shaft - Fan	325-6194
1P-9952	Impeller - Pump	314-8685
1S-1860	Nut (3/4-16)	188-5856
1S-4701	Pulley - Alt	264-5866
1S-5331	Cylinder - Adjustable	226-0214
1S-8186	Idler As.	188-5268
1T-0662	Turbine - Conv	235-1819
1T-0665	Ring - Clamp	308-9918
1T-0987	Hub - Impeller	247-4118
1T-1089	Hub - Turbine	216-7471
1W-1219	Trunnion As	314-8724
1W-4402	Gear - Camshaft	279-4981
1W-4405	Gear - Crankshaft	279-4982
244-1090	Alarm - Back up	360-2345
2F-0025	Tube	325-6233
2F-5721	Bearing - Ball	311-9354
2K-4442	Bearing - Sleeve	308-9812
2K-4507	Bearing - Sleeve	325-6021
2M-0369	Pilot - Spring Recoil	226-0226
2M-4668	Retainer - Guard	297-4867
2P-1170	Shaft As - Gear	296-1367
2P-1738	Plate As - Oil Pan	325-6164
2P-1739	Tube As - Pump	325-6229
2P-1757	Hub - Fan Pulley	296-1357
2P-1781	Spacer - Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2519	Tube As - Inlet	325-6230
2P-2719	Pipe	363-7454
2P-2744	Muffler As	247-2664
2P-2784	Ejector As - Exh	367-6063
2P-3422	Gear - First Reduction	213-8451
2P-3423	Pinion - Sec Reduction	216-3553
2P-4611	Pipe - Exhaust	365-8821
2P-6245	Shaft As - Pump	325-6197
2P-9669	Shoe -Track Master	188-5604
2P-9670	Bolt Master	188-5637
2S-3443	Drum - Steer	219-9689 (Drum), 230-7113 (Steering Clutch Kit)
2S-6344	Gear - Final Drive	297-7173
2S-7603	Drum	213-6951
2W-1086	Cover As - Cylinder Head	325-6049
2W-2621	Valve - Inlet	247-6892 (Valve), 241-3381 (Valve Kit)
2W-7255	Shaft - Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear - Water Pump	325-6088
2W-9978	Core As - Oil Cooler	279-4983
3L-1425	Bearing - Ball	311-9356
3P-0615	Shoe - Track Master	188-5601
3P-0616	Shoe - Track Master	175-8881
3P-0617	Shoe - Track Master	188-5246
3P-0618	Shoe - Track Master	188-5602
3P-0620	Shoe - Track Master	188-5606
3P-0628	Link As.	175-8759
3P-3623	Lock - Adjustable Nut	226-7989
3P-6318	Flange - Drum	213-8165
3S-0777	Bearing - Roller Frame	229-8226
3S-1691	Disc - Steering	302-2705
3S-2337	Shaft - Output	231-8765
3S-6907	Gear - Transfer	217-9774
3S-6908	Gear - Transfer	217-9775
3S-9199	Hub - Sprocket	224-1310
3T-4482	Guide - Front Idler	226-0248
4F-4974	Clamp	311-9373
4K-0300	Bearing - Sleeve	308-9817
4N-2954	Sleeve - Camshaft	299-2059
4N-3281	Line As - Fuel Injector	247-3362
4N-3282	Line As - Fuel Injector	247-3363
4N-3283	Line As - Fuel Injector	247-3364
4N-4864	Pump Gp - Fuel Transfer	242-3442
4N-7693	Crankshaft As	242-3439
4N-8591	Coupling - Exhaust	325-6053
4N-8814	Line As - Fuel Injector	247-3366
4N-9587	Shield - Heat	297-7260
4P-3546	Valve As - Relief	325-6236
4S-8708	Housing - Clutch	216-3557
4S-8718	Cage - Carrier Bearing	217-7724
4S-9062	Cap - Final Drive Bearing	226-0204
4W-0452	Seal As - Camshaft	325-6191
5G-3612	Cap Gp	295-6419
5J-4542	Bearing - Sleeve	308-9818
5K-6377	Pin	241-2610
5K-6382	Pin	241-2611
5K-6383	Pin	241-2612
5K-7995	Bearing - Sleeve	308-9820
5K-9367	Pin	241-2613
5M-5822	Gear - Pump Drive	247-4120
5M-6120	Gear - Sun	213-8740
5M-6210	Shaft - Planet	219-9683
5M-6211	Shaft - Planet	219-9684

(Continued)

Sales Model 977L (Continued)

Original Part Number	Part Name	Classic Part Number
5M-6670	Shaft - Sprocket	216-7847
5M-6690	Hub - Steering	215-1695
5M-7290	Cage - Bearing	216-7848
5M-7740	Gear - Bevel	213-8216
5M-7841	Gear - Ring	214-0525
5M-7864	Pump Gp - Scavenge	226-0169
5M-7869	Gear - Ring	214-0530
5M-7875	Carrier - Front	213-4495
5M-7900	Bolt - Hex Head	311-9349
5M-7923	Shaft - Output	215-1697
5P-7807	Bearing - Ball	314-8502
5S-0073	Plate - Steering	302-2692
5S-0192	Pinion - Final Drive	215-1698
5S-1211	Cover - Valve	314-8665
5S-4557	Bearing	311-9360
5S-6795	Chamber As	242-3437
5S-6910	Shoe -Track	188-5603
5S-6911	Shoe -Track	188-5605
5S-9062	Spacer	363-7463
5S-9080	Pulley - Alt Drive	264-5883
6H-3957	Bearing - Ball	311-9358
6I-1346	Pump Gp - Oil	295-5674
6K-1983	Pin	241-2614
6L-9211	Idler Gp	200-9237
6N-1036	Gear - Oil Pump	279-4991
6N-1965	Line As - Fuel Injector	250-7535
6N-1966	Line As - Fuel Injector	250-7536
6N-2789	Pulley	264-5886
6N-8413	Housing - Pump	325-6110
6P-1382	Pin	241-2615
6P-1383	Pin	241-2616
6T-1980	Collar - Idler End	226-0210
7C-4297	Seal As - Camshaft	325-6192
7F-9547	Pin As - Drawbar	295-0414
7G-2475	Gear - Planet	223-4815
7G-2476	Gear - Planet	223-4816
7G-2513	Gear - Planet	215-1734
7G-5301	Pump Gp	217-2600
7G-5323	Pinion - Final Drive	231-8767
7G-6681	Cage As	216-7860
7H-3598	Bolt - Track	188-5636
7J-9344	Bearing - Sleeve	360-2334
7J-9731	Bearing - Sleeve	308-9822
7J-9732	Bearing - Sleeve	308-9823
7K-9366	Pin	241-2617
7K-9370	Pin	241-2618
7K-9371	Pin	241-2619
7K-9373	Pin	241-2620
7K-9375	Pin	241-2621
7K-9528	Bearing - Sleeve	308-9828
7K-9530	Bearing - Sleeve	299-1967
7M-2167	Ring - Governor Control	308-9919
7N-0128	Core As - Oil Cooler	299-1994
7N-0165	Core As - Oil Cooler	295-5670
7N-1164	Mount As	295-5451
7N-2871	Line As - Fuel Injector	319-8172
7N-2872	Line As - Fuel Injector	319-8173
7N-2874	Line As - Fuel Injector	298-2779
7N-2875	Line As - Fuel Injector	298-2780
7N-2876	Line As - Fuel Injector	298-2781
7N-2949	Pulley	264-5887
7N-3486	Manifold - Exhaust	261-0899
7N-3515	Gear - Camshaft	314-8669
7N-3536	Gear - Fuel	279-4993
7N-5910	Impeller - Pump	314-8686
7N-9145	Gear - Flywheel	279-4994
7N-9312	Damper As - Camshaft	299-2005
7N-9805	Pin - Piston	295-6438
7S-3161	Lifter - Valve	279-4996
7S-6723	Bracket - Alternator	299-1978
7S-7809	Cap As - Radiator	295-6417
7S-8443	Muffler	247-2675
7S-9749	Pulley - Gen Drive	264-5888
7T-2036	Cap As - Filter	361-1721
7T-9963	Case As - Transfer Gear	219-9665
7W-0450	Gear - Water Pump	279-4997
7W-0507	Gear - Oil Pump Drive	279-4998
7W-0508	Gear - Fuel Pump Drive	296-1351
7W-5687	Hub - Camshaft	314-8684
8E-4434	Shoe -Track	188-5263
8E-4435	Shoe -Track Master	188-5264
8E-4436	Shoe -Track	188-5261
8E-4437	Shoe -Track Master	188-5262
8E-4675	Segment Gp - Sprocket	188-5599 (sprocket), 188-5638 (sprocket group)
8H-1383	Rod - Tie	299-2051
8H-2810	Case As - Filter	314-8512
8H-7980	Piston	226-0249
8H-9806	Gear - Shaft Drive	325-6091
8M-0874	Plunger As - Valve	311-9439
8M-6191	Sleeve - Bolt	226-0234
8M-7166	Housing - Screen	297-7192
8M-8619	Cage - Bearing	217-7725
8M-8623	Gear - Sun	213-8755
8M-8628	Flange - Joint	217-9776
8M-8642	Housing - Clutch	219-9669
8M-8644	Housing - Clutch	215-1782
8M-8646	Plate As - Center	216-3583
8M-8649	Piston - Clutch	217-9777

(Continued)

Sales Model 977L (Continued)

Original Part Number	Part Name	Classic Part Number
8M-8650	Piston - Clutch	217-9778
8M-8652	Shaft	297-7252
8M-8677	Carrier - Planet	213-4449
8N-0002	Trunnion As	314-8728
8N-0875	Valve - Exhaust	247-6893 (Valve), 241-3381 (Valve Kit)
8N-1187	Head Gp - Cylinder	242-3435
8N-1721	Rod As - Conn	269-5291
8N-1984	Rod As - Conn	242-3441
8N-3181	Piston Gp - Basic	250-6555 (Liner Kit)
8N-3182	Body As - Piston	250-6564 (Piston As), 250-6556 (Liner Kits)
8N-3183	Piston Gp - Basic	250-6556 (Liner Kit)
8N-3251	Shaft As - Rocker Arm	314-8711
8N-3325	Arm Gp - Rocker	314-8623
8N-3327	Arm Gp - Rocker	314-8624
8N-5305	Spacer	363-7464
8N-5929	Cover - Water Pump	296-1349
8N-6796	Head Gp - Cylinder	269-5290
8N-7315	Tube As - Outlet	325-6232
8N-8225	Bearing - Main	314-8652
8N-9733	Line As - Fuel Injector	319-8174
8P-0025	Gear - Idler	217-7721
8P-0605	Gear - First Reduction	213-8453
8P-0606	Pinion - Sec Reduction	215-1783
8P-0622	Hub - Sprocket	288-8731
8P-4537	Pinion - Reduction	216-7867
8P-4538	Gear - First Reduction	216-7868
8P-4539	Pinion - Final Drive	217-7711
8P-6495	Drum	213-6954 (Drum), 227-9302 (Steering Clutch Kit)
8P-6803	Shaft As	215-1842
8P-7790	Valve Gp - Press	247-4437
8P-9657	Pin	241-2622
8P-9658	Pin	241-2623
8S-0248	Breather As	325-6033
8S-0493	Shaft As - Pump	325-6198
8S-3970	Chamber As	242-3438
9G-0383	Hub - Gear	221-1064
9G-3526	Gear - Pump Drive	231-8763
9H-2256	Pump Gp	311-9443
9M-0701	Piston - Steer	219-9692
9M-0702	Pilot - Piston	229-8232
9M-1500	Shaft - Planet	219-9685
9M-1502	Cage - Bearing	219-9686
9M-1995	Gear - Sun	213-8756
9M-1996	Shaft - Planet	215-1875
9M-2013	Housing As	216-3585
9M-2045	Pinion - Bevel	215-1878
9M-2049	Gear - Ring	214-0533
9M-3025	Cover As	299-2001
9M-4789	Shaft - Gov Control	297-7256
9N-5769	Cover - Housing	325-6050
9P-0418	Cage	223-6311
9P-0620	Cage - Pinion Bearing	221-1052
9P-3436	Holder As - Cage	216-7875
9P-5363	Piston - Clutch	219-9687
9P-5379	Housing - Clutch	215-1904
9P-9000	Shaft - Steering	217-7738
9P-9360	Gear - First Reduction	213-8454
9P-9361	Gear - Final Drive	223-4809
9P-9362	Pinion - Final Drive	215-1944
9P-9363	Pinion - Reduction	219-9677
9P-9575	Cage - Bevel Gr Bearing	216-7876
9S-1043	Guard As - Guiding	226-0240
9S-1044	Guard As - Guiding	226-0241
9S-1045	Strip - Guard	226-0246
9S-1046	Strip - Guard	226-0247
9S-2354	Manifold - Exhaust	261-0888
9S-2355	Manifold - Exhaust	261-0891
9S-6129	Pulley - Alternator Drive	264-5891
9S-8257	Guard As - Guiding	226-0238
9S-8258	Guard As - Guiding	226-0239
9S-8679	Chamber As	325-6042
9S-8789	Plate - Clutch	302-2712

Sales Model 983

Original Part Number	Part Name	Classic Part Number
190-8609	Valve - Fill	360-2288
1M-0598	Gear - Transmission	213-8636
1M-2607	Cage - Bearing	239-7970
1M-2626	Cage - Carrier Bearing	216-7458
1M-2635	Housing - Clutch	216-3549
1M-2637	Housing - Clutch	216-3550
1M-4486	Piston - Clutch	215-1660
1M-8647	Housing As	215-1662
1M-9029	Guard	226-0219
1M-9444	Retainer - Spring	299-2046

(Continued)

Sales Model 983 (Continued)

Original Part Number	Part Name	Classic Part Number
1P-0965	Gear - Bevel	213-8215
1P-4145	Valve Gp - Press	247-4436
1P-6160	Gear - Pump Driven	231-8760
1P-7590	Support As	213-4400
1P-9663	Carrier - Bearing	217-7731
1S-4701	Pulley - Alt	264-5866
1T-0665	Ring - Clamp	308-9918
1T-0987	Hub - Impel-ler	247-4118
1T-1089	Hub - Turbine	216-7471
244-1090	Alarm - Back up	360-2345
2F-5721	Bearing - Ball	311-9354
2K-4507	Bearing - Sleeve	325-6021
2S-2781	Plunger - Relief	311-9435
2S-3946	Gear - Final Drive	215-1678
2S-3966	Ring - Seal	297-7237
2S-7063	Nut	300-2584
2S-7064	Cap - Shaft Bearing	299-1991
2S-7527	Flange - Drum	213-8163
2S-7596	Retainer	215-1679
3K-2230	Gear - Planet	219-9658
3L-1425	Bearing - Ball	311-9356
3P-1757	Yoke As - Idler	226-2729
3S-8735	Guard As	226-2723
3S-8736	Guard As	226-9992
4J-1612	Pin	308-9896
4M-7099	Gear - Ring	214-0521
4M-7100	Gear - Ring	214-0522
4M-7102	Gear - Ring	214-0523
4N-4864	Pump Gp - Fuel Transfer	242-3442
4N-7526	Seal As - Pump	311-9454
4N-9180	Seal As - Pump	311-9455
5G-3612	Cap Gp	295-6419
5J-3492	Bearing - Sleeve	308-9879
5M-1988	Piston - Steer	219-9691
5M-1990	Pilot - Piston	229-8233
5M-1998	Drum Steer-ing	213-6952
5M-2026	Hubdriving	216-4471
5M-3470	Gear - Trans-mission	224-1305
5M-3474	Shaft - Output	215-1690
5M-3499	Shaft - Planet	319-3475
5M-3906	Gear - Ring	214-0526
5M-3907	Carrier - Planet	210-8475
5M-3941	Shaft - Planet	215-1691
5M-3942	Shaft - Planet	215-1692
5M-5822	Gear - Pump Drive	247-4120
5M-6673	Guard - F Idler Rh	226-2735
5M-6674	Guard - F Idler Lh	226-2736
5M-7900	Bolt - Hex Head	311-9349
5P-7807	Bearing - Ball	314-8502
5S-0073	Plate - Steer-ing	302-2692
5S-1211	Cover - Valve	314-8665
5S-4470	Gear - Trans-fer	224-1304
5S-4863	Holder As - Cage	215-1732
5S-5746	Retainer - Guard	319-3472
5S-6796	Drum - Inner	213-6953 (Drum), 230-7115 (Steer-ing Clutch Kit)
5S-9080	Pulley - Alt Drive	264-5883
6H-3957	Bearing - Ball	311-9358
7F-9547	Pin As - Drawbar	295-0414
7G-2517	Gear - Planet	213-8747
7G-2521	Gear - Planet	213-8749
7G-6576	Cage As	216-7859
7J-9344	Bearing - Sleeve	360-2334
7M-2167	Ring - Gover-nor Control	308-9919
7N-2957	Cover - Rad Cap	361-1722
7S-7809	Cap As - Radiator	295-6417
7S-7973	Guard - Final Drive Wear	213-9110
7T-2036	Cap As - Filter	361-1721
8H-2810	Case As - Filter	314-8512
8H-9806	Gear - Shaft Drive	325-6091
8M-0874	Plunger As - Valve	311-9439
8M-7166	Housing - Screen	297-7192
8P-0025	Gear - Idler	217-7721
8P-0187	Nut - Adjust-ing	219-9676
8P-8221	Plate - Guide	226-2748
8S-9070	Carrier - Front	213-4464
8S-9071	Cage - Bear-ing	216-7869
9G-3526	Gear - Pump Drive	231-8763
9P-0418	Cage	223-6311
9P-0620	Cage - Pinion Bearing	221-1052
9S-3955	Cage - Gear Bearing	216-7874
9S-6875	Pinion - Final Drive	217-7705
9S-6948	Shaft - Center	213-9966

Sales Model 983B

Original Part Number	Part Name	Classic Part Number
129-3068	Rebuild Kit, W/P (Str Brgs)	363-7455
131-3815	Seal Gp - Basic	325-6193
177-9024	Adapter - Damper	299-1956
180-3767	Adapter - Damper	299-1957
190-8609	Valve - Fill	360-2288
1M-9444	Retainer - Spring	299-2046
1P-9663	Carrier - Bearing	217-7731
1P-9946	Shaft - Fan	325-6194
1S-4701	Pulley - Alt	264-5866
1T-0665	Ring - Clamp	308-9918
1T-0987	Hub - Impel-ler	247-4118
1T-1089	Hub - Turbine	216-7471
244-1090	Alarm - Back up	360-2345
2D-5658	Bearing - Ball	301-4628
2F-5721	Bearing - Ball	311-9354
2N-7942	Spacer	363-7462
2P-1757	Hub - Fan Pulley	296-1357
2S-7064	Cap - Shaft Bearing	299-1991
2S-7527	Flange - Drum	213-8163
2S-7596	Retainer	215-1679
3L-1425	Bearing - Ball	311-9356
3P-1757	Yoke As - Idler	226-2729
3P-2685	Piston - Clutch	308-9908
3P-2768	Piston - Clutch	308-9909
3P-3059	Gear - Sun	308-9861
3P-3096	Gear - Sun	308-9863
3P-3245	Shaft - Planet	308-9924
3P-3246	Shaft - Planet	308-9925
3S-8735	Guard As	226-2723
3S-8736	Guard As	226-9992
4J-1612	Pin	308-9896
4M-0503	Gear As - Oil Pump	297-7184
4N-3714	Chamber, Precom	363-7450
4S-8472	Hood As	296-1355
5J-3492	Bearing - Sleeve	308-9879
5M-1988	Piston - Steer	219-9691
5M-1990	Pilot - Piston	229-8233
5M-1998	Drum Steer-ing	213-6952
5M-2026	Hubdriving	216-4471
5M-5822	Gear - Pump Drive	247-4120
5M-6673	Guard - F Idler Rh	226-2735
5M-6674	Guard - F Idler Lh	226-2736
5P-7807	Bearing - Ball	314-8502
5S-0073	Plate - Steer-ing	302-2692
5S-1211	Cover - Valve	314-8665
5S-5746	Retainer - Guard	319-3472
5S-6796	Drum - Inner	213-6953 (Drum), 230-7115 (Steer-ing Clutch Kit)
5S-9062	Spacer	363-7463
5S-9080	Pulley - Alt Drive	264-5883
5V-5866	Pin As	361-1707
6H-3957	Bearing - Ball	311-9358
6L-8968	Coupling - Exhaust	311-9381
6N-1572	Mount As	308-9876
6P-6739	Shaft - Planet	308-9929
7C-3039	Core, Oil Cooler	363-7451
7F-9547	Pin As - Drawbar	295-0414
7G-2476	Gear - Planet	223-4816
7G-3457	Gear - Planet	308-9857
7G-6576	Cage As	216-7859
7S-7809	Cap As - Radiator	295-6417
7T-2036	Cap As - Filter	361-1721
7W-2164	Core As - Oil Cooler	299-1996
8H-2810	Case As - Filter	314-8512
8M-0874	Plunger As - Valve	311-9439
8M-7166	Housing - Screen	297-7192
8N-5305	Spacer	363-7464
8P-0187	Nut - Adjust-ing	219-9676
8P-8221	Plate - Guide	226-2748
9M-3025	Cover As	299-2001
9P-0418	Cage	223-6311
9P-0620	Cage - Pinion Bearing	221-1052
9S-3955	Cage - Gear Bearing	216-7874
9S-6875	Pinion - Final Drive	217-7705
9Y-2988	Breather As	361-1716

Cat® Classic™ Parts for Track-Type Tractors

Cat® track-type tractors have always been built to provide maximum productivity and profitability in any application. Caterpillar has been setting industry standards with this product line since its introduction. As the machine ages, maintenance costs need to be re-evaluated to continue to ensure that maximum profitability. Cat® Classic™ parts are offered for several models of track-type tractors as a competitively priced alternative to aftermarket parts. This parts product line is intended to help you manage these maintenance costs.

Cat Classic parts provide owners of older Cat products with low cost repair alternatives that minimize the risk associated with non-genuine parts.

Cat Classic parts coverage for track-type tractors includes:

- Engine
- Final Drive
- Moving U/C
- Non-moving U/C
- Steering
- Transmission
- Trunnion Assembly
- Winch
- ...and many more.

Sales Model D3

Original Part Number	Part Name	Classic Part Number
190-7396	Segment Gp	275-3576 (sprocket group), 275-4087 segment
190-8609	Valve - Fill	360-2288
1W-4402	Gear - Camshaft	279-4981
1W-4405	Gear - Crankshaft	279-4982
244-1090	Alarm - Back up	360-2345
2D-5658	Bearing - Ball	301-4628
2K-6413	Pin	360-2270
2M-1086	Plate As - Press	226-8023
3F-6185	Pin	295-5694
3F-6612	Cap - Ball Joint	297-7155

Original Part Number	Part Name	Classic Part Number
3J-6575	Trunnion	297-7265
3L-1425	Bearing - Ball	311-9356
4J-0121	Cap - Bearing	360-2344
4J-3015	Shaft	325-6204
4N-2954	Sleeve - Camshaft	299-2059
4N-4539	Sleeve	314-8720
4N-6638	Muffler As	360-7875
4N-8809	Chamber As	247-3297
5G-3612	Cap Gp	295-6419
5P-7807	Bearing - Ball	314-8502
6F-3183	Cap - Bearing	325-6038
6Y-1381	Shoe -Track	275-3564
6Y-1382	Shoe - Track	275-3565
6Y-1385	Shoe - Track	275-3570
6Y-1386	Shoe - Track	275-3571
6Y-5344	Shoe -Track	275-3566

Original Part Number	Part Name	Classic Part Number
6Y-5345	Shoe -Track	275-3567
7J-5131	Trunnion	296-1371
7J-6461	Crown	325-6054
7J-9884	Bearing - Sleeve	325-6016
7K-8238	Flange	213-8166
7N-3536	Gear - Fuel	279-4993
7T-2036	Cap As - Filter	361-1721
8J-2880	Cap - Bearing	295-6420
8S-0248	Breather As	325-6033
9K-8757	Rod End - Bearing	311-9361
9M-1328	Bearing - Aligning	325-6018
9M-4789	Shaft - Gov Control	297-7256
9W-1677	Bearing	297-7145
9Y-9431	Precleaner As	361-1718

Sales Model D3B

Original Part Number	Part Name	Classic Part Number
100-7860	Valve - Inlet	270-4360 (Valve), 270-4362 (Valve Kit)
104-4253	Line As - Fuel Injector	279-4988
104-4254	Line As - Fuel Injector	279-4989
111-8015	Gasket As - Head	279-4977
121-7746	Precleaner As	360-2311
122-9405	Bracket As	325-6005
127-5537	Core As	325-6045
131-3815	Seal Gp - Basic	325-6193
131-7736	Support As - Engine	325-6222
148-7455	Valve - Exhaust	270-4361
172-5185	Shaft - Water Pump	325-6201
172-5188	Shaft - Water Pump	325-6202
172-5189	Impeller - Pump	295-5687
172-5190	Impeller - Pump	325-6111
172-6712	Impeller - Pump	325-6112
172-7767	Pump Gp - Water	296-1365
190-8609	Valve - Fill	360-2288
1M-7250	Bowl - Precleaner	360-2296
1N-3576	Block Gp - Cylinder	279-4978
1N-3958	Elbow	325-6087
1S-1888	Bracket - Lamp	297-7147
1W-1669	Piston	325-6158
1W-1695	Pump Gp	279-4980
1W-1698	Housing - Transfer Pump	296-1356
1W-4369	Pulley - Alt	296-1340
1W-4402	Gear - Camshaft	279-4981
1W-4405	Gear - Crankshaft	279-4982
1W-4407	Hub - Fan Pulley	296-1358
1W-4737	Gear - Camshaft	295-5688
1W-4738	Bearing - Sleeve	325-6020
1W-4740	Gear As - Drive	295-5689
1W-4746	Retainer - Gear	295-5690
1W-5912	Tappet As - Guide	325-6223
1W-6541	Plunger As	325-6173
1W-9229	Muffler As	302-4282
244-1090	Alarm - Back up	360-2345
2D-5658	Bearing - Ball	301-4628
2M-1086	Plate As - Press	226-8023
2P-1170	Shaft As - Gear	296-1367
2P-1738	Plate As - Oil Pan	325-6164
2P-1739	Tube As - Pump	325-6229
2P-1757	Hub - Fan Pulley	296-1357
2P-1781	Spacer - Oil Pump	325-6214
2P-2519	Tube As - Inlet	325-6230
2P-6245	Shaft As - Pump	325-6197
2S-3803	Gear	226-6106
2W-1086	Cover As - Cylinder Head	325-6049
2W-2621	Valve - Inlet	247-6892 (Valve), 241-3381 (Valve Kit)
2W-6757	Trunnion As	295-5678
2W-7255	Shaft - Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-8494	Pulley - Alt	295-5692
3F-6185	Pin	295-5694
3F-6612	Cap - Ball Joint	297-7155
3J-6559	Cap - Bearing	296-1346
3J-6575	Trunnion	297-7265
3L-1425	Bearing - Ball	311-9356
3T-4516	Trunnion As	325-6226
3Y-9984	Manifold - Exhaust	325-6123
3Y-9985	Manifold - Exhaust	325-6124
4F-4974	Clamp	311-9373
4J-0121	Cap - Bearing	360-2344
4J-2414	Trunnion	296-1370
4J-3015	Shaft	325-6204
4N-4539	Sleeve	314-8720
4N-7693	Crankshaft As	242-3439
4P-3546	Valve As - Relief	325-6236
4P-9381	Line As - Fuel Injector	279-4984
4P-9382	Line As - Fuel Injector	279-4985
4P-9385	Line As - Fuel Injector	279-4986
4P-9386	Line As - Fuel Injector	279-4987
4W-0452	Seal As - Camshaft	325-6191
4W-2042	Spacer	325-6217
4W-2446	Damper As	279-4990
5P-7807	Bearing - Ball	314-8502
5S-4557	Bearing	311-9360
5S-6795	Chamber As	242-3437
5S-9062	Spacer	363-7463
6F-3183	Cap - Bearing	325-6038
6H-3957	Bearing - Ball	311-9358
6I-1346	Pump Gp - Oil	295-5674
6N-1036	Gear - Oil Pump	279-4991
6N-3256	Mount As	314-8688
6N-8413	Housing - Pump	325-6110
6P-2233	Gear - Planet	281-1690
7C-3567	Mount As	314-8689
7C-4297	Seal As - Camshaft	325-6192
7G-2480	Gear - Planet	226-6091
7J-5131	Trunnion	296-1371
7J-6461	Crown	325-6054
7J-9884	Bearing - Sleeve	325-6016
7K-8237	Drum	226-6100
7K-8238	Flange	213-8166
7K-9642	Bearing - Sleeve	360-2340
7N-0165	Core As - Oil Cooler	295-5670
7N-1164	Mount As	295-5451

(Continued)

Sales Model D3B (Continued)

Original Part Number	Part Name	Classic Part Number
7N-5910	Impeller - Pump	314-8686
7N-9146	Gear - Fly-wheel Starter	279-4995
7N-9805	Pin - Piston	295-6438
7S-3161	Lifter - Valve	279-4996
7W-0450	Gear - Water Pump	279-4997
7W-0507	Gear - Oil Pump Drive	279-4998
7W-0508	Gear - Fuel Pump Drive	296-1351
7W-5685	Pulley - Cam-shaft	298-2772
7W-5698	Pulley - Cam-shaft	295-5679
8H-2810	Case As - Filter	314-8512
8J-2880	Cap - Bearing	295-6420
8N-0875	Valve - Ex-haust	247-6893 (Valve), 241-3381 (Valve Kit)
8N-1187	Head Gp - Cylinder	242-3435
8N-1214	Mount As	325-6125
8N-1721	Rod As - Conn	269-5291
8N-2510	Shaft	325-6208
8N-2641	Sleeve	325-6210
8N-3251	Shaft As - Rocker Arm	314-8711
8N-3325	Arm Gp - Rocker	314-8623
8N-3327	Arm Gp - Rocker	314-8624
8N-5929	Cover - Water Pump	296-1349
8N-6796	Head Gp - Cylinder	269-5290
8N-7315	Tube As - Outlet	325-6232
8N-8225	Bearing - Main	314-8652
8S-0248	Breather As	325-6033
8S-0493	Shaft As - Pump	325-6198
8S-3970	Chamber As	242-3438
8S-7716	Manifold - Exhaust	295-0415
8S-7717	Manifold - Exhaust	261-0894
8S-7718	Manifold - Exhaust	295-0416
9K-8757	Rod End - Bearing	311-9361
9M-1328	Bearing - Aligning	325-6018
9M-4789	Shaft - Gov Control	297-7256
9N-5769	Cover - Hous-ing	325-6050
9N-6611	Pulley	325-6177
9P-3242	Plate - Clutch	325-6172
9S-8679	Chamber As	325-6042
9T-0066	Trunnion	325-6228
9W-1677	Bearing	297-7145
9Y-9431	Precleaner As	361-1718

Sales Model D3C

Original Part Number	Part Name	Classic Part Number
121-7746	Precleaner As	360-2311
164-1047	Idler Gp	275-3581
185-4037	Idler Gp	275-3581
190-8609	Valve - Fill	360-2288
1M-7250	Bowl - Pre-cleaner	360-2296
1S-1888	Bracket - Lamp	297-7147
1U-0612	Pin	325-6135
1W-4402	Gear - Cam-shaft	279-4981
1W-4405	Gear - Crank-shaft	279-4982
1W-6541	Plunger As	325-6173
244-1090	Alarm - Back up	360-2345
281-8338	Roller - DF	275-3580
281-8339	Roller - SF	275-3579
2D-5658	Bearing - Ball	301-4628
2M-1086	Plate As - Press	226-8023
323-8756	Link As	257-1992
323-8757	Link As	257-1990
323-8758	Link As	257-1994
323-8759	Link As	257-1991
3F-6185	Pin	295-5694
3F-6612	Cap - Ball Joint	297-7155
3G-8917	Pin	325-6141
3G-8932	Pin	325-6143
3J-6559	Cap - Bearing	296-1346
3J-6575	Trunnion	297-7265
3L-1425	Bearing - Ball	311-9356
3P-0324	Coupling	301-0234
4F-4974	Clamp	311-9373
4J-0121	Cap - Bearing	360-2344
4J-2414	Trunnion	296-1370
4J-3015	Shaft	325-6204
4J-6374	Bearing - Sleeve	295-6407
4N-4539	Sleeve	314-8720
4T-0998	Lever	314-8687
4W-2042	Spacer	325-6217
5A-3187	Bolt Master	257-7773
5G-3612	Cap Gp	295-6419
5P-7807	Bearing - Ball	314-8502
5S-9062	Spacer	363-7463
6F-3183	Cap - Bearing	325-6038
6H-3957	Bearing - Ball	311-9358
6P-2233	Gear - Planet	281-1690
6S-3609	Roller - Car-rier	275-3578
6Y-1711	Link As	261-8008
6Y-1713	Link As	257-1993
7G-2480	Gear - Planet	226-6091
7G-4758	Gear - Planet	288-8723
7J-5131	Trunnion	296-1371
7J-6461	Crown	325-6054
7J-9884	Bearing - Sleeve	325-6016
7K-8237	Drum	226-6100
7K-8238	Flange	213-8166
7K-9639	Bearing - Sleeve	314-8643
7T-2036	Cap As - Filter	361-1721
7W-0508	Gear - Fuel Pump Drive	296-1351
8H-2810	Case As - Filter	314-8512

(Continued)

Sales Model D3C (Continued)

Original Part Number	Part Name	Classic Part Number
8J-2880	Cap - Bearing	295-6420
8N-2510	Shaft	325-6208
8S-0248	Breather As	325-6033

Original Part Number	Part Name	Classic Part Number
9J-7964	Bearing - Spherical	325-6017
9K-8757	Rod End - Bearing	311-9361

Original Part Number	Part Name	Classic Part Number
9M-1328	Bearing - Aligning	325-6018
9P-3242	Plate - Clutch	325-6172
9T-4762	Head	325-6109
9W-1677	Bearing	297-7145
9Y-9431	Precleaner As	361-1718

Sales Model D4

Original Part Number	Part Name	Classic Part Number
0T-0259	Nut - Bearing Sleeve	311-9431
190-7396	Segment Gp	275-3576 (sprocket group), 275-4087 segment
1A-2846	Cap As - Filler	311-9368
1H-8382	Gear - Oil Pump Drive	226-6103
1M-1618	Collar As - Shift	226-8029
1M-7250	Bowl - Pre-cleaner	360-2296
1M-9177	Flywheel	226-6112
1S-1888	Bracket - Lamp	297-7147
1S-1967	Chamber As	247-3291
1S-1970	Chamber As	247-3292
1S-8764	Ring - Fly-wheel Clutch Adjustable	226-8014
2B-8824	Drum	216-7817
2D-5658	Bearing - Ball	301-4628
2F-5721	Bearing - Ball	311-9354
2H-4338	Plate - Pres-sure	226-8010
2H-4450	Washer - Thrust	325-6237
2H-4482	Collar	229-8218
2H-5046	Link - Flycam	299-2024
2H-6776	Plate - Pres-sure	226-8011
2H-6777	Plate - Fly-wheel	226-8012
2M-1086	Plate As - Press	226-8023
2M-2290	Bracket - Ring	299-1979

Original Part Number	Part Name	Classic Part Number
2S-1273	Chamber As	319-3434
2S-4015	Plunger As - Valve	311-9438
2V-7198	Pilot As - Re-coil Spring	302-2709
3B-6217	Muffler As	247-2671
3B-6218	Muffler As	247-2672
3F-1537	Nut - Spanner	226-6098
3K-3124	Muffler - Trap	247-2673
3L-1425	Bearing - Ball	311-9356
3N-3368	Pipe - Ex-haust	311-9434
4B-1455	Cap As - Filter	361-1719
4F-4974	Clamp	311-9373
4H-4021	Plate As - Loading	229-8219
4K-0255	Retainer As	226-6102
4K-9559	Hub - Gear	219-2978
4N-2954	Sleeve - Cam-shaft	299-2059
4N-7526	Seal As - Pump	311-9454
4N-9180	Seal As - Pump	311-9455
5F-0689	Pin	256-4821
5H-5500	Collar - Fly-wheel	302-2704
5L-8856	Coupling - Exhaust	311-9379
5P-7807	Bearing - Ball	314-8502
5S-1211	Cover - Valve	314-8665
5S-4557	Bearing	311-9360
6F-3183	Cap - Bearing	325-6038
6H-3957	Bearing - Ball	311-9358
6L-8968	Coupling - Exhaust	311-9381

Original Part Number	Part Name	Classic Part Number
6P-0169	Hub - Fly-wheel Clutch	297-7204
6W-0240	Bearing - Brace	297-7143
6Y-1381	Shoe -Track	275-3564
6Y-1382	Shoe - Track	275-3565
6Y-1385	Shoe - Track	275-3570
6Y-1386	Shoe - Track	275-3571
6Y-5344	Shoe -Track	275-3566
6Y-5345	Shoe -Track	275-3567
7B-2420	Ferrule - Director	314-8517
7H-0602	Dog - Clutch	314-8515
7H-2742	Nut	229-8220
7M-4603	Body - Fuel Valve	311-9348
7S-7809	Cap As - Radiator	295-6417
7T-2036	Cap As - Filter	361-1721
8B-5972	Bearing - Ball	314-8503
8H-1174	Drum - Steer-ing	226-6101 (Drum), 231-1937 (Steer-ing Clutch Kit)
8H-2300	Pinion - Final Drive	226-6083
8M-6676	Cylinder - Adjustable	226-4960
9F-5224	Gear - Final Drive	226-6094
9F-7101	Bushing - Collar	299-1988
9H-7670	Piston	226-4961
9K-9271	Holder As - Cage	217-7730
9K-9273	Nut - Adjust-ing	226-7998
9W-1677	Bearing	297-7145
9Y-9431	Precleaner As	361-1718

Sales Model D4B

Original Part Number	Part Name	Classic Part Number
190-8609	Valve - Fill	360-2288
1W-4402	Gear - Cam-shaft	279-4981
1W-4405	Gear - Crank-shaft	279-4982
1W-6541	Plunger As	325-6173
244-1090	Alarm - Back up	360-2345
2M-1086	Plate As - Press	226-8023
3L-1425	Bearing - Ball	311-9356
4J-3015	Shaft	325-6204
4N-4539	Sleeve	314-8720
5P-7807	Bearing - Ball	314-8502
6H-3957	Bearing - Ball	311-9358
6P-2233	Gear - Planet	281-1690
7G-2480	Gear - Planet	226-6091
7J-5131	Trunnion	296-1371
7J-6461	Crown	325-6054
7K-8237	Drum	226-6100
7K-8238	Flange	213-8166
7W-0508	Gear - Fuel Pump Drive	296-1351
8N-2510	Shaft	325-6208
9K-8757	Rod End - Bearing	311-9361
9M-1328	Bearing - Aligning	325-6018
9P-3242	Plate - Clutch	325-6172
9Y-9431	Precleaner As	361-1718

Sales Model D4C

Original Part Number	Part Name	Classic Part Number
121-7746	Precleaner As	360-2311
164-1047	Idler Gp	275-3581
185-4037	Idler Gp	275-3581
190-8609	Valve - Fill	360-2288
1A-2846	Cap As - Filler	311-9368
1H-8382	Gear - Oil Pump Drive	226-6103
1K-7974	Gear - Trans-mission Shaft	226-7984
1M-1618	Collar As - Shift	226-8029
1M-1663	Collar As - Retain	226-8030
1M-1698	Gear - Sliding	215-1659
1M-1809	Shaft - Tr Sprocket	231-3314
1M-1930	Cage - Pinion Bearing	217-7727
1M-1947	Support As	226-6096
1M-5270	Pipe - Exten-sion	367-6065
1M-7250	Bowl - Pre-cleaner	360-2296
1M-9177	Flywheel	226-6112
1P-1721	Gear - Bal-ance	298-2769
1P-1722	Gear - Bal-ance	298-2770
1S-1888	Bracket - Lamp	297-7147
1S-8764	Ring - Fly-wheel Clutch Adjustable	226-8014
1U-0105	Brace As	295-5684
1U-0612	Pin	325-6135
1W-4402	Gear - Cam-shaft	279-4981
1W-4405	Gear - Crank-shaft	279-4982
1W-6541	Plunger As	325-6173
244-1090	Alarm - Back up	360-2345
281-8338	Roller - DF	275-3580
281-8339	Roller - SF	275-3579
2B-8824	Drum	216-7817
2D-5658	Bearing - Ball	301-4628
2H-4338	Plate - Pres-sure	226-8010
2H-4450	Washer - Thrust	325-6237
2H-4482	Collar	229-8218
2H-5046	Link - Flycam	299-2024
2H-6776	Plate - Pres-sure	226-8011
2H-6777	Plate - Fly-wheel	226-8012
2K-3592	Boss	314-8501
2M-1086	Plate As - Press	226-8023
2M-2290	Bracket - Ring	299-1979
2M-4668	Retainer - Guard	297-4867
2S-4015	Plunger As - Valve	311-9438
2V-7198	Pilot As - Re-coil Spring	302-2709
3B-6218	Muffler As	247-2672
3F-1537	Nut - Spanner	226-6098
3F-6185	Pin	295-5694
3F-6523	Pin - Clevis	256-4818
3F-6611	Socket - Joint	256-4829
3F-6612	Cap - Ball Joint	297-7155
3G-8932	Pin	325-6143
3H-3378	Gear As - Pump	298-2795
3K-3124	Muffler - Trap	247-2673
3L-1425	Bearing - Ball	311-9356
3P-0324	Coupling	301-0234
4F-4974	Clamp	311-9373
4H-4021	Plate As - Loading	229-8219
4J-2414	Trunnion	296-1370
4J-3015	Shaft	325-6204
4K-0255	Retainer As	226-6102
4K-4632	Gear - Bevel	216-7842
4K-4780	Strip As - Wear	299-2063
4K-9559	Hub - Gear	219-2978
4N-4539	Sleeve	314-8720
4T-0998	Lever	314-8687
5F-0689	Pin	256-4821
5F-1401	Pin - Pivot	297-7216
5G-3612	Cap Gp	295-6419
5H-5500	Collar - Fly-wheel	302-2704
5K-6090	Flange	216-7844
5P-7807	Bearing - Ball	314-8502
5S-1211	Cover - Valve	314-8665
5S-1822	Chamber As	248-5406
5S-1833	Chamber As	247-3298
6F-3183	Cap - Bearing	325-6038
6H-3957	Bearing - Ball	311-9358
6J-0800	Bearing	297-7140
6P-0169	Hub - Fly-wheel Clutch	297-7204
6P-2233	Gear - Planet	281-1690

(Continued)

Sales Model D4C (Continued)

Original Part Number	Part Name	Classic Part Number
6S-3609	Roller - Carrier	275-3578
6W-0240	Bearing - Brace	297-7143
6Y-0710	Gear	226-6104
7B-2420	Ferrule - Director	314-8517
7G-2480	Gear - Planet	226-6091
7G-4758	Gear - Planet	288-8723
7H-2742	Nut	229-8220
7J-5131	Trunnion	296-1371
7J-6461	Crown	325-6054
7K-3582	Nut - Adjusting	226-6099
7K-4458	Gear - Final Drive	226-6093
7K-4512	Pinion - Final Drive	226-6081
7K-8237	Drum	226-6100
7K-8238	Flange	213-8166
7K-9639	Bearing - Sleeve	314-8643
7M-2167	Ring - Governor Control	308-9919
7M-4358	Manifold - Exhaust	261-0907
7M-4603	Body - Fuel Valve	311-9348
7M-7358	Valve - Inlet	298-2774
7S-9749	Pulley - Gen Drive	264-5888
7T-2036	Cap As - Filter	361-1721
7W-0508	Gear - Fuel Pump Drive	296-1351
8H-1174	Drum - Steering	226-6101 (Drum), 231-1937 (Steering Clutch Kit)
8H-2810	Case As - Filter	314-8512
8H-9806	Gear - Shaft Drive	325-6091
8M-3224	Muffler	247-2676
8M-6676	Cylinder - Adjustable	226-4960
8N-2510	Shaft	325-6208
8N-8225	Bearing - Main	314-8652
9F-7101	Bushing - Collar	299-1988
9H-2256	Pump Gp	311-9443
9H-6980	Shaft - Pinion	226-6110
9H-7670	Piston	226-4961
9J-7964	Bearing - Spherical	325-6017
9K-6842	Cage As	216-7872
9K-8757	Rod End - Bearing	311-9361
9K-9271	Holder As - Cage	217-7730
9K-9273	Nut - Adjusting	226-7998
9M-1328	Bearing - Aligning	325-6018
9M-4163	Valve - Exhaust	298-2773
9M-4955	Pump Gp - Fuel Transfer	242-3443
9P-3242	Plate - Clutch	325-6172
9W-1677	Bearing	297-7145
9Y-9431	Precleaner As	361-1718

Sales Model D4D

Original Part Number	Part Name	Classic Part Number
100-7860	Valve - Inlet	270-4360 (Valve), 270-4362 (Valve Kit)
104-4253	Line As - Fuel Injector	279-4988
104-4254	Line As - Fuel Injector	279-4989
111-8015	Gasket As - Head	279-4977
121-7746	Precleaner As	360-2311
131-3815	Seal Gp - Basic	325-6193
148-7455	Valve - Exhaust	270-4361
165-4262	Body As - Piston	270-4351
172-5185	Shaft - Water Pump	325-6201
172-5188	Shaft - Water Pump	325-6202
172-5189	Impeller - Pump	295-5687
172-5190	Impeller - Pump	325-6111
172-6712	Impeller - Pump	325-6112
172-7767	Pump Gp - Water	296-1365
190-8609	Valve - Fill	360-2288
196-0028	Gear As - Idler	364-5259
1A-2846	Cap As - Filler	311-9368
1H-8262	Shaft	226-8016
1H-8382	Gear - Oil Pump Drive	226-6103
1H-8938	Lever	226-8028
1K-7974	Gear - Transmission Shaft	226-7984
1M-1663	Collar As - Retain	226-8030
1M-1698	Gear - Sliding	215-1659
1M-1809	Shaft - Tr Sprocket	231-3314
1M-1930	Cage - Pinion Bearing	217-7727
1M-1947	Support As	226-6096
1M-7250	Bowl - Precleaner	360-2296
1M-9177	Flywheel	226-6112
1N-3576	Block Gp - Cylinder	279-4978
1N-3958	Elbow	325-6087
1N-4304	Head Gp - Cylinder	269-8761
1P-1721	Gear - Balance	298-2769
1P-1722	Gear - Balance	298-2770
1P-7044	Cage	226-7975
1P-9945	Bracket As - Fan	296-1344
1P-9946	Shaft - Fan	325-6194

(Continued)

Sales Model D4D (Continued)

Original Part Number	Part Name	Classic Part Number
1P-9952	Impeller - Pump	314-8685
1S-1888	Bracket - Lamp	297-7147
1S-4701	Pulley - Alt	264-5866
1S-8764	Ring - Flywheel Clutch Adjustable	226-8014
1T-0020	Wheel - Turbine	297-4862
1V-3242	Cage - Release Bearing	216-7475
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1695	Pump Gp	279-4980
1W-1698	Housing - Transfer Pump	296-1356
1W-2870	Shaft As - Balance	314-8715
1W-2871	Shaft As - Balance	314-8716
1W-4402	Gear - Camshaft	279-4981
1W-4405	Gear - Crankshaft	279-4982
1W-5912	Tappet As - Guide	325-6223
1W-6541	Plunger As	325-6173
2B-8824	Drum	216-7817
2D-5658	Bearing - Ball	301-4628
2F-5721	Bearing - Ball	311-9354
2H-4338	Plate - Pressure	226-8010
2H-4450	Washer - Thrust	325-6237
2H-4482	Collar	229-8218
2H-5046	Link - Flycam	299-2024
2H-6776	Plate - Pressure	226-8011
2H-6777	Plate - Flywheel	226-8012
2K-6413	Pin	360-2270
2M-1086	Plate As - Press	226-8023
2M-2290	Bracket - Ring	299-1979
2M-4668	Retainer - Guard	297-4867
2P-1170	Shaft As - Gear	296-1367
2P-1757	Hub - Fan Pulley	296-1357
2P-1781	Spacer - Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2519	Tube As - Inlet	325-6230
2P-2719	Pipe	363-7454
2P-4404	Housing As	226-8027
2P-4409	Gear - Ring	226-7981
2P-6128	Pulley	264-5872
2P-6245	Shaft As - Pump	325-6197
2P-6255	Muffler As	247-2666
2P-7828	Pan - Oil	314-8691
2S-4015	Plunger As - Valve	311-9438
2V-7198	Pilot As - Recoil Spring	302-2709
2W-1086	Cover As - Cylinder Head	325-6049
2W-2621	Valve - Inlet	247-6892 (Valve), 241-3381 (Valve Kit)
2W-7255	Shaft - Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear - Water Pump	325-6088
2Y-4213	Pulley	314-8703
3B-6218	Muffler As	247-2672
3F-1537	Nut - Spanner	226-6098
3F-6185	Pin	295-5694
3F-6523	Pin - Clevis	256-4818
3F-6611	Socket - Joint	256-4829
3F-6612	Cap - Ball Joint	297-7155
3H-3378	Gear As - Pump	298-2795
3J-6559	Cap - Bearing	296-1346
3K-3124	Muffler - Trap	247-2673
3L-1425	Bearing - Ball	311-9356
3S-7987	Shaft - Planet	226-6074
3S-7996	Gear - Ring	226-6087
3S-8800	Gear - Driven	325-6090
3S-9466	Bearing - Sleeve	314-8509
3V-1025	Shaft - Pinion	226-6109
3V-5916	Plate As - Press	226-8025
4F-4974	Clamp	311-9373
4H-4021	Plate As - Loading	229-8219
4J-2414	Trunnion	296-1370
4J-3583	Screw - Adjusting	297-7242
4J-6374	Bearing - Sleeve	295-6407
4K-0255	Retainer As	226-6102
4K-1328	Drum - Steering	216-7840 (Drum), 230-7112 (Steering Clutch Kit)
4K-4632	Gear - Bevel	216-7842
4K-4780	Strip As - Wear	299-2063
4K-5074	Pinion	215-1683
4K-5086	Yoke	215-1684
4K-5109	Gear - Reverse	219-9659
4K-9559	Hub - Gear	219-2978
4N-2954	Sleeve - Camshaft	299-2059
4N-3281	Line As - Fuel Injector	247-3362
4N-3282	Line As - Fuel Injector	247-3363
4N-3283	Line As - Fuel Injector	247-3364
4N-3284	Line As - Fuel Injector	247-3365
4N-4782	Pulley	325-6176
4N-4864	Pump Gp - Fuel Transfer	242-3442
4N-7692	Crankshaft As	242-3440
4N-7693	Crankshaft As	242-3439
4N-7977	Shaft As - Balance	314-8709
4N-7978	Shaft As - Balance	314-8710
4N-9587	Shield - Heat	297-7260
4P-3546	Valve As - Relief	325-6236
4P-9381	Line As - Fuel Injector	279-4984
4P-9382	Line As - Fuel Injector	279-4985
4P-9961	Line As - Fuel Injector	325-6115
4P-9962	Line As - Fuel Injector	325-6116
4P-9963	Line As - Fuel Injector	298-2777
4P-9964	Line As - Fuel Injector	298-2778

(Continued)

Sales Model D4D (Continued)

Original Part Number	Part Name	Classic Part Number
4S-8660	Pump Gp - Transmission	226-0167
4S-8670	Shaft - Planet	300-2590
4S-8687	Piston - Clutch	226-8008
4S-8707	Shaft & Sun Gear	226-6089
4S-8713	Gear - Ring	226-6090
4V-2744	Gear	224-1303
4V-3396	Hub - Gear	222-1763
4V-3397	Hub - Gear	219-2979
4V-6156	Saddle As	299-2052
4W-0452	Seal As - Camshaft	325-6191
5F-1401	Pin - Pivot	297-7216
5G-3612	Cap Gp	295-6419
5H-5500	Collar - Flywheel	302-2704
5K-6090	Flange	216-7844
5K-8606	Cage - Gear Bearing	223-6310
5L-8856	Coupling - Exhaust	311-9379
5P-7807	Bearing - Ball	314-8502
5S-0884	Gear - Ring	226-7982
5S-0885	Plate - Front	229-8234
5S-0894	Shaft - Center	226-6075
5S-1211	Cover - Valve	314-8665
5S-1822	Chamber As	248-5406
5S-1833	Chamber As	247-3298
5S-6795	Chamber As	242-3437
5S-7609	Pulley - Alt Drive	264-5881
5S-8038	Pulley - Crankshaft	264-5882
5S-9062	Spacer	363-7463
5S-9080	Pulley - Alt Drive	264-5883
6F-3183	Cap - Bearing	325-6038
6H-3957	Bearing - Ball	311-9358
6I-1346	Pump Gp - Oil	295-5674
6I-8132	Pinion	226-6080
6J-0800	Bearing	297-7140
6K-4617	Shaft - Sprocket	221-7951
6L-8968	Coupling - Exhaust	311-9381
6N-1036	Gear - Oil Pump	279-4991
6N-2789	Pulley	264-5886
6N-8413	Housing - Pump	325-6110
6P-0169	Hub - Flywheel Clutch	297-7204
6P-7704	Carrier - Ring	314-8658
6W-0240	Bearing - Brace	297-7143
6Y-0710	Gear	226-6104
7B-2420	Ferrule - Director	314-8517
7C-4297	Seal As - Camshaft	325-6192
7G-2480	Gear - Planet	226-6091
7G-2481	Gear - Planet	226-6092
7G-2485	Gear - Planet	226-7983
7G-2830	Ring - Seal	295-6441
7H-2742	Nut	229-8220
7K-3582	Nut - Adjusting	226-6099
7K-4458	Gear - Final Drive	226-6093
7K-4512	Pinion - Final Drive	226-6081
7K-4770	Pinion	226-6082
7K-4771	Gear	229-8221
7K-8237	Drum	226-6100
7K-8238	Flange	213-8166
7M-2167	Ring - Governor Control	308-9919
7M-4358	Manifold - Exhaust	261-0907
7M-4603	Body - Fuel Valve	311-9348
7M-7358	Valve - Inlet	298-2774
7N-0128	Core As - Oil Cooler	299-1994
7N-0165	Core As - Oil Cooler	295-5670
7N-1164	Mount As	295-5451
7N-2871	Line As - Fuel Injector	319-8172
7N-2872	Line As - Fuel Injector	319-8173
7N-2874	Line As - Fuel Injector	298-2779
7N-2949	Pulley	264-5887
7N-2957	Cover - Rad Cap	361-1722
7N-3515	Gear - Camshaft	314-8669
7N-3536	Gear - Fuel	279-4993
7N-5910	Impeller - Pump	314-8686
7N-9146	Gear - Flywheel Starter	279-4995
7N-9805	Pin - Piston	295-6438
7S-3161	Lifter - Valve	279-4996
7S-6723	Bracket - Alternator	299-1978
7S-7070	Head As - Cylinder	325-6107
7S-7602	Pump Gp	226-0174
7S-7809	Cap As - Radiator	295-6417
7S-9749	Pulley - Gen Drive	264-5888
7T-2036	Cap As - Filter	361-1721
7V-5249	Shaft - Steering	215-1761
7W-0450	Gear - Water Pump	279-4997
7W-0507	Gear - Oil Pump Drive	279-4998
7W-0508	Gear - Fuel Pump Drive	296-1351
7W-5687	Hub - Camshaft	314-8684
8H-1174	Drum - Steering	226-6101 (Drum), 231-1937 (Steering Clutch Kit)
8H-2810	Case As - Filter	314-8512
8H-9806	Gear - Shaft Drive	325-6091
8K-9661	Gear - Bevel	213-8218
8M-0874	Plunger As - Valve	311-9439
8M-3224	Muffler	247-2676
8M-6676	Cylinder - Adjustable	226-4960
8N-0002	Trunnion As	314-8728
8N-0875	Valve - Exhaust	247-6893 (Valve), 241-3381 (Valve Kit)
8N-1187	Head Gp - Cylinder	242-3435
8N-1188	Head Gp - Cylinder	242-3436
8N-1721	Rod As - Conn	269-5291
8N-1984	Rod As - Conn	242-3441

(Continued)

Sales Model D4D (Continued)

Original Part Number	Part Name	Classic Part Number
8N-2510	Shaft	325-6208
8N-2641	Sleeve	325-6210
8N-3180	Body As - Piston	250-6563
8N-3181	Piston Gp - Basic	250-6555 (Liner Kit)
8N-3182	Body As - Piston	250-6564 (Piston As), 250-6556 (Liner Kits)
8N-3183	Piston Gp - Basic	250-6556 (Liner Kit)
8N-3251	Shaft As - Rocker Arm	314-8711
8N-3311	Shaft As - Rocker Arm	325-6199
8N-3312	Shaft As - Rocker Arm	325-6200
8N-3325	Arm Gp - Rocker	314-8623
8N-3327	Arm Gp - Rocker	314-8624
8N-5305	Spacer	363-7464
8N-5929	Cover - Water Pump	296-1349
8N-6796	Head Gp - Cylinder	269-5290
8N-7315	Tube As - Outlet	325-6232
8N-7780	Shield - Oil	314-8544
8N-8225	Bearing - Main	314-8652
8N-9733	Line As - Fuel Injector	319-8174
8S-0248	Breather As	325-6033
8S-0493	Shaft As - Pump	325-6198
8S-3970	Chamber As	242-3438
9F-7101	Bushing - Collar	299-1988
9G-8302	Guide	226-4853
9H-2256	Pump Gp	311-9443
9H-6980	Shaft - Pinion	226-6110
9H-7670	Piston	226-4961
9K-0424	Shaft - Pinion	215-1874
9K-6842	Cage As	216-7872
9K-9271	Holder As - Cage	217-7730
9K-9273	Nut - Adjusting	226-7998
9M-4163	Valve - Exhaust	298-2773
9M-4789	Shaft - Gov Control	297-7256
9M-4955	Pump Gp - Fuel Transfer	242-3443
9M-8119	Retainer - Inlet	226-8022
9N-5769	Cover - Housing	325-6050
9S-2356	Manifold - Exhaust	261-0905
9S-6129	Pulley - Alternator Drive	264-5891
9S-8679	Chamber As	325-6042
9V-4333	Gear - Oil Pump Input	226-6105
9W-1677	Bearing	297-7145
9W-6358	Drum - Steering	226-7995
9Y-2992	Bearing - Sleeve	325-6032
9Y-9431	Precleaner As	361-1718

Sales Model D4E

Original Part Number	Part Name	Classic Part Number
100-7860	Valve - Inlet	270-4360 (Valve), 270-4362 (Valve Kit)
104-4253	Line As - Fuel Injector	279-4988
104-4254	Line As - Fuel Injector	279-4989
111-8015	Gasket As - Head	279-4977
112-3249	Muffler As	247-2661
121-7746	Precleaner As	360-2311
131-3815	Seal Gp - Basic	325-6193
148-7455	Valve - Exhaust	270-4361
165-4262	Body As - Piston	270-4351
170-0560	Rebuild Kit	363-7458
172-5185	Shaft - Water Pump	325-6201
172-5188	Shaft - Water Pump	325-6202
172-5189	Impeller - Pump	295-5687
172-5190	Impeller - Pump	325-6111
172-6712	Impeller - Pump	325-6112
172-7767	Pump Gp - Water	296-1365
190-8609	Valve - Fill	360-2288
196-0028	Gear As - Idler	364-5259
1H-8262	Shaft	226-8016
1H-8382	Gear - Oil Pump Drive	226-6103
1H-8937	Drumbrake	226-7993
1H-8938	Lever	226-8028
1K-7974	Gear - Transmission Shaft	226-7984
1M-1663	Collar As - Retain	226-8030
1M-1698	Gear - Sliding	215-1659
1M-1930	Cage - Pinion Bearing	217-7727
1M-1947	Support As	226-6096
1M-7250	Bowl - Precleaner	360-2296
1M-9177	Flywheel	226-6112
1N-3576	Block Gp - Cylinder	279-4978
1N-3958	Elbow	325-6087
1N-4304	Head Gp - Cylinder	269-8761
1P-1216	Manifold - Exhaust	261-0902
1P-1636	Lever As	226-8013
1P-1721	Gear - Balance	298-2769
1P-1722	Gear - Balance	298-2770
1P-7044	Cage	226-7975
1P-9945	Bracket As - Fan	296-1344
1P-9946	Shaft - Fan	325-6194

(Continued)

Sales Model D4E (Continued)

Original Part Number	Part Name	Classic Part Number
1P-9952	Impeller - Pump	314-8685
1S-1888	Bracket - Lamp	297-7147
1S-4701	Pulley - Alt	264-5866
1S-6422	Pilot As - Spring	226-4849
1S-8764	Ring - Flywheel Clutch Adjustable	226-8014
1T-0020	Wheel - Turbine	297-4862
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1695	Pump Gp	279-4980
1W-1698	Housing - Transfer Pump	296-1356
1W-2870	Shaft As - Balance	314-8715
1W-2871	Shaft As - Balance	314-8716
1W-4402	Gear - Camshaft	279-4981
1W-4405	Gear - Crankshaft	279-4982
1W-5912	Tappet As - Guide	325-6223
1W-6541	Plunger As	325-6173
244-1090	Alarm - Back up	360-2345
2D-5658	Bearing - Ball	301-4628
2F-5721	Bearing - Ball	311-9354
2H-4338	Plate - Pressure	226-8010
2H-4450	Washer - Thrust	325-6237
2H-4482	Collar	229-8218
2H-5046	Link - Flycam	299-2024
2K-4502	Bearing - Sleeve	299-1986
2K-4507	Bearing - Sleeve	325-6021
2K-6413	Pin	360-2270
2M-2290	Bracket - Ring	299-1979
2M-4668	Retainer - Guard	297-4867
2P-1170	Shaft As - Gear	296-1367
2P-1757	Hub - Fan Pulley	296-1357
2P-1781	Spacer - Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2519	Tube As - Inlet	325-6230
2P-2719	Pipe	363-7454
2P-4404	Housing As	226-8027
2P-4409	Gear - Ring	226-7981
2P-6128	Pulley	264-5872
2P-6245	Shaft As - Pump	325-6197
2P-6255	Muffler As	247-2666
2P-7828	Pan - Oil	314-8691
2V-7198	Pilot As - Recoil Spring	302-2709
2W-1086	Cover As - Cylinder Head	325-6049
2W-2621	Valve - Inlet	247-6892 (Valve), 241-3381 (Valve Kit)
2W-7255	Shaft - Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear - Water Pump	325-6088
2W-9978	Core As - Oil Cooler	279-4983
3F-1537	Nut - Spanner	226-6098
3F-6185	Pin	295-5694
3F-6523	Pin - Clevis	256-4818
3F-6611	Socket - Joint	256-4829
3F-6612	Cap - Ball Joint	297-7155
3J-6559	Cap - Bearing	296-1346
3K-3124	Muffler - Trap	247-2673
3L-1425	Bearing - Ball	311-9356
3P-0114	Elbow - Exhaust	314-8516
3P-3935	Shaft	299-2053
3S-7987	Shaft - Planet	226-6074
3S-7996	Gear - Ring	226-6087
3S-8800	Gear - Driven	325-6090
3V-1025	Shaft - Pinion	226-6109
3V-5916	Plate As - Press	226-8025
4F-4974	Clamp	311-9373
4H-4021	Plate As - Loading	229-8219
4J-2414	Trunnion	296-1370
4J-3583	Screw - Adjusting	297-7242
4J-6374	Bearing - Sleeve	295-6407
4K-3004	Bearing - Trunnion Support	314-8632
4K-3128	Bearing - Sleeve	314-8633
4K-4780	Strip As - Wear	299-2063
4K-5074	Pinion	215-1683
4K-5086	Yoke	215-1684
4K-5109	Gear - Reverse	219-9659
4N-2954	Sleeve - Camshaft	299-2059
4N-3281	Line As - Fuel Injector	247-3362
4N-3282	Line As - Fuel Injector	247-3363
4N-3283	Line As - Fuel Injector	247-3364
4N-3284	Line As - Fuel Injector	247-3365
4N-4539	Sleeve	314-8720
4N-4782	Pulley	325-6176
4N-4864	Pump Gp - Fuel Transfer	242-3442
4N-7692	Crankshaft As	242-3440
4N-7693	Crankshaft As	242-3439
4N-7977	Shaft As - Balance	314-8709
4N-7978	Shaft As - Balance	314-8710
4N-8591	Coupling - Exhaust	325-6053
4N-9587	Shield - Heat	297-7260
4P-3546	Valve As - Relief	325-6236
4P-9381	Line As - Fuel Injector	279-4984
4P-9382	Line As - Fuel Injector	279-4985
4P-9961	Line As - Fuel Injector	325-6115
4P-9962	Line As - Fuel Injector	325-6116
4P-9963	Line As - Fuel Injector	298-2777
4P-9964	Line As - Fuel Injector	298-2778
4S-8660	Pump Gp - Transmission	226-0167
4S-8670	Shaft - Planet	300-2590

(Continued)

Sales Model D4E (Continued)

Original Part Number	Part Name	Classic Part Number
4S-8687	Piston - Clutch	226-8008
4S-8707	Shaft & Sun Gear	226-6089
4S-8713	Gear - Ring	226-6090
4V-0381	Bearing - Sleeve	299-1963
4V-2744	Gear	224-1303
4V-3396	Hub - Gear	222-1763
4V-3397	Hub - Gear	219-2979
4V-6156	Saddle As	299-2052
4W-0452	Seal As - Camshaft	325-6191
5F-1401	Pin - Pivot	297-7216
5H-5500	Collar - Flywheel	302-2704
5K-8606	Cage - Gear Bearing	223-6310
5P-7807	Bearing - Ball	314-8502
5S-0884	Gear - Ring	226-7982
5S-0885	Plate - Front	229-8234
5S-0894	Shaft - Center	226-6075
5S-6795	Chamber As	242-3437
5S-9062	Spacer	363-7463
5S-9080	Pulley - Alt Drive	264-5883
5V-5661	Bearing - Sleeve	299-1965
6F-3183	Cap - Bearing	325-6038
6H-3957	Bearing - Ball	311-9358
6I-1346	Pump Gp - Oil	295-5674
6I-8132	Pinion	226-6080
6J-0800	Bearing	297-7140
6K-4617	Shaft - Sprocket	221-7951
6N-1036	Gear - Oil Pump	279-4991
6N-1553	Coupling - Exhaust	295-6422
6N-2789	Pulley	264-5886
6N-8413	Housing - Pump	325-6110
6P-0169	Hub - Flywheel Clutch	297-7204
6P-7704	Carrier - Ring	314-8658
6W-0240	Bearing - Brace	297-7143
6Y-0710	Gear	226-6104
7C-4297	Seal As - Camshaft	325-6192
7G-2480	Gear - Planet	226-6091
7G-2481	Gear - Planet	226-6092
7G-2485	Gear - Planet	226-7983
7G-2830	Ring - Seal	295-6441
7G-7681	Shaft As	307-1530
7H-2424	Sleeve - Spring	226-4852
7H-2742	Nut	229-8220
7J-6461	Crown	325-6054
7J-9842	Bearing - Sleeve	299-1968
7J-9884	Bearing - Sleeve	325-6016
7K-3582	Nut - Adjusting	226-6099
7K-4770	Pinion	226-6082
7K-4771	Gear	229-8221
7K-8237	Drum	226-6100
7K-8238	Flange	213-8166
7M-2167	Ring - Governor Control	308-9919
7N-0128	Core As - Oil Cooler	299-1994
7N-0165	Core As - Oil Cooler	295-5670
7N-1164	Mount As	295-5451
7N-2871	Line As - Fuel Injector	319-8172
7N-2872	Line As - Fuel Injector	319-8173
7N-2874	Line As - Fuel Injector	298-2779
7N-2949	Pulley	264-5887
7N-2957	Cover - Rad Cap	361-1722
7N-3515	Gear - Camshaft	314-8669
7N-3536	Gear - Fuel	279-4993
7N-5910	Impeller - Pump	314-8686
7N-9146	Gear - Flywheel Starter	279-4995
7N-9805	Pin - Piston	295-6438
7S-3161	Lifter - Valve	279-4996
7S-6723	Bracket - Alternator	299-1978
7S-7070	Head As - Cylinder	325-6107
7S-7602	Pump Gp	226-0174
7S-7809	Cap As - Radiator	295-6417
7S-8213	Guard As - Final Drive Wear	226-4943
7S-8214	Guard As - Final Drive Wear	226-4944
7S-8443	Muffler	247-2675
7T-2036	Cap As - Filter	361-1721
7V-5249	Shaft - Steering	215-1761
7W-0450	Gear - Water Pump	279-4997
7W-0507	Gear - Oil Pump Drive	279-4998
7W-0508	Gear - Fuel Pump Drive	296-1351
7W-3042	Tube As - Drain	325-6231
7W-5687	Hub - Camshaft	314-8684
7Y-1517	Pipe As - Tail	301-5246
8H-2810	Case As - Filter	314-8512
8H-9806	Gear - Shaft Drive	325-6091
8K-9661	Gear - Bevel	213-8218
8M-0874	Plunger As - Valve	311-9439
8M-6676	Cylinder - Adjustable	226-4960
8M-7166	Housing - Screen	297-7192
8N-0002	Trunnion As	314-8728
8N-0875	Valve - Exhaust	247-6893 (Valve), 241-3381 (Valve Kit)
8N-1187	Head Gp - Cylinder	242-3435
8N-1188	Head Gp - Cylinder	242-3436
8N-1721	Rod As - Conn	269-5291
8N-1984	Rod As - Conn	242-3441
8N-2510	Shaft	325-6208
8N-2641	Sleeve	325-6210
8N-3180	Body As - Piston	250-6563
8N-3181	Piston Gp - Basic	250-6555 (Liner Kit)

(Continued)

Sales Model D4E (Continued)

Original Part Number	Part Name	Classic Part Number
8N-3182	Body As - Piston	250-6564 (Piston As), 250-6556 (Liner Kits)
8N-3183	Piston Gp - Basic	250-6556 (Liner Kit)
8N-3251	Shaft As - Rocker Arm	314-8711
8N-3311	Shaft As - Rocker Arm	325-6199
8N-3312	Shaft As - Rocker Arm	325-6200
8N-3325	Arm Gp - Rocker	314-8623
8N-3327	Arm Gp - Rocker	314-8624
8N-5305	Spacer	363-7464
8N-5929	Cover - Water Pump	296-1349
8N-6796	Head Gp - Cylinder	269-5290
8N-7315	Tube As - Outlet	325-6232
8N-7780	Shield - Oil	314-8544
8N-8225	Bearing - Main	314-8652
8N-9733	Line As - Fuel Injector	319-8174
8P-2430	Shaft As	297-7258
8S-0248	Breather As	325-6033
8S-0493	Shaft As - Pump	325-6198
8S-0905	Muffler As	302-2690
8S-3970	Chamber As	242-3438
9F-7101	Bushing - Collar	299-1988
9G-8302	Guide	226-4853
9H-2256	Pump Gp	311-9443
9H-4104	Pilot - Spring	226-4962
9H-7670	Piston	226-4961
9K-6842	Cage As	216-7872
9K-8757	Rod End - Bearing	311-9361
9K-9271	Holder As - Cage	217-7730
9K-9273	Nut - Adjusting	226-7998
9M-4789	Shaft - Gov Control	297-7256
9M-8117	Shaft - Flywheel Clutch	226-6073
9M-8119	Retainer - Inlet	226-8022
9N-5769	Cover - Housing	325-6050
9S-2356	Manifold - Exhaust	261-0905
9S-6129	Pulley - Alternator Drive	264-5891
9S-8679	Chamber As	325-6042
9T-4761	Head	325-6108
9V-4333	Gear - Oil Pump Input	226-6105
9V-6775	Drum	226-7994
9W-1677	Bearing	297-7145
9W-6358	Drum - Steering	226-7995
9Y-2992	Bearing - Sleeve	325-6032

Sales Model D5

Original Part Number	Part Name	Classic Part Number
0T-0259	Nut - Bearing Sleeve	311-9431
111-8015	Gasket As - Head	279-4977
121-7746	Precleaner As	360-2311
131-3815	Seal Gp - Basic	325-6193
172-5185	Shaft - Water Pump	325-6201
172-5188	Shaft - Water Pump	325-6202
172-5189	Impeller - Pump	295-5687
172-5190	Impeller - Pump	325-6111
172-6712	Impeller - Pump	325-6112
172-7767	Pump Gp - Water	296-1365
190-8609	Valve - Fill	360-2288
196-0028	Gear As - Idler	364-5259
1A-2846	Cap As - Filler	311-9368
1H-8382	Gear - Oil Pump Drive	226-6103
1H-8937	Drumbrake	226-7993
1M-0176	Flange - Drum	223-4810
1M-1618	Collar As - Shift	226-8029
1M-5270	Pipe - Extension	367-6065
1M-6128	Manifold - Exhaust	261-0906
1M-7250	Bowl - Precleaner	360-2296
1M-9177	Flywheel	226-6112
1N-3576	Block Gp - Cylinder	279-4978
1N-3958	Elbow	325-6087
1P-1636	Lever As	226-8013
1P-1931	Shaft - Steer	227-4772
1P-4303	Head As - Cylinder	242-3434
1P-6273	Rod Gp - Recoil	226-4847
1P-6752	Pump Gp	226-0161
1P-7044	Cage	226-7975
1P-9024	Spring - Equalizer	231-3311
1P-9945	Bracket As - Fan	296-1344
1P-9946	Shaft - Fan	325-6194
1P-9952	Impeller - Pump	314-8685
1S-1888	Bracket - Lamp	297-7147
1S-4701	Pulley - Alt	264-5866
1S-5315	Cap As - Brace Bearing	226-4848
1S-6422	Pilot As - Spring	226-4849
1S-8734	Bracket - Roller	226-0212
1S-8764	Ring - Flywheel Clutch Adjustable	226-8014
1T-0521	Retainer - Bearing	325-6180
1T-0699	Impeller - Converter	235-1808

(Continued)

Sales Model D5 (Continued)

Original Part Number	Part Name	Classic Part Number
1T-1350	Torque Converter	235-0912 (Repair Kit)
1T-1993	Wheel - Turbine	235-0920
1T-2052	Stator As	295-5683
1W-4402	Gear - Camshaft	279-4981
1W-4405	Gear - Crankshaft	279-4982
244-1090	Alarm - Back up	360-2345
2B-8824	Drum	216-7817
2F-5721	Bearing - Ball	311-9354
2F-7576	Shaft - Sprocket	226-6071
2F-7577	Shaft	226-6072
2H-4338	Plate - Pressure	226-8010
2H-4450	Washer - Thrust	325-6237
2H-4482	Collar	229-8218
2H-5046	Link - Flycam	299-2024
2H-6776	Plate - Pressure	226-8011
2H-6777	Plate - Flywheel	226-8012
2K-4507	Bearing - Sleeve	325-6021
2M-1086	Plate As - Press	226-8023
2M-2290	Bracket - Ring	299-1979
2M-2415	Guard-idler - Rh	226-4931
2M-2416	Guard-idler - Lh	226-4933
2M-2417	Guard-spring - Rh	226-4934
2M-2418	Guard-spring - Lh	226-4935
2M-4668	Retainer - Guard	297-4867
2P-1005	Bearing - Sleeve	296-1342
2P-1170	Shaft As - Gear	296-1367
2P-1738	Plate As - Oil Pan	325-6164
2P-1739	Tube As - Pump	325-6229
2P-1757	Hub - Fan Pulley	296-1357
2P-1781	Spacer - Oil Pump	325-6214
2P-2519	Tube As - Inlet	325-6230
2P-4370	Plate - Clutch	325-6166
2P-6245	Shaft As - Pump	325-6197
2P-7622	Bolt - Spring	226-4850
2P-9660	Gear - Final Drive	226-5995
2P-9667	Cage - Shaft Bearing	226-7971
2P-9672	Cage - Pinion Bearing	226-7972
2S-1477	Holder As - Cage	226-7985
2S-4015	Plunger As - Valve	311-9438
2S-8277	Guard Gp - Spring	226-4936
2S-8278	Guard Gp - Spring	226-4937
2W-1086	Cover As - Cylinder Head	325-6049
2W-2621	Valve - Inlet	247-6892 (Valve), 241-3381 (Valve Kit)
2W-7255	Shaft - Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-9978	Core As - Oil Cooler	279-4983
3B-6218	Muffler As	247-2672
3F-1956	Cap - Frame Sup	226-7987
3F-1972	Retainer As	226-7988
3F-6185	Pin	295-5694
3F-6446	Pivot - Push Pole	256-4827
3F-6523	Pin - Clevis	256-4818
3F-6561	Arm As - Brace	256-4828
3F-6611	Socket - Joint	256-4829
3F-6612	Cap - Ball Joint	297-7155
3H-3378	Gear As - Pump	298-2795
3J-6559	Cap - Bearing	296-1346
3K-3124	Muffler - Trap	247-2673
3L-1425	Bearing - Ball	311-9356
3P-3623	Lock - Adjustable Nut	226-7989
3P-5736	Hub - Gear	219-2975
3P-5754	Hub - Gear	219-2976
3P-5755	Extension - Final Drive	226-7990
3S-0311	Rod Gp	226-4953
3S-1167	Gear - Planet	221-9101
3S-2712	Gear - Transfer	226-7977
3S-7153	Gear - Sliding	227-0024
3S-7504	Gear - Idler	226-6084
3S-8634	Hub - Gear	219-2977
3V-1133	Strip	226-0203
4B-1455	Cap As - Filter	361-1719
4F-1252	Pin	295-5704
4F-4974	Clamp	311-9373
4H-4021	Plate As - Loading	229-8219
4H-9040	Nut	226-7996
4J-2414	Trunnion	296-1370
4J-3583	Screw - Adjusting	297-7242
4J-6374	Bearing - Sleeve	295-6407
4K-4780	Strip As - Wear	299-2063
4K-7386	Plate - Guide	226-4851
4N-2954	Sleeve - Camshaft	299-2059
4N-3281	Line As - Fuel Injector	247-3362
4N-3282	Line As - Fuel Injector	247-3363
4N-3283	Line As - Fuel Injector	247-3364
4N-3284	Line As - Fuel Injector	247-3365
4N-4864	Pump Gp - Fuel Transfer	242-3442
4N-7693	Crankshaft As	242-3439
4N-7982	Pulley	264-5880
4N-8591	Coupling - Exhaust	325-6053
4N-8814	Line As - Fuel Injector	247-3366
4N-9587	Shield - Heat	297-7260
4P-0660	Muffler As	298-2787
4P-3546	Valve As - Relief	325-6236
4S-5943	Piston - Clutch	221-9112
4S-5944	Gear - Sun	221-9078
4S-5945	Gear - Sun	221-9079

(Continued)

Sales Model D5 (Continued)

Original Part Number	Part Name	Classic Part Number
4S-5947	Gear - Ring	221-9080
4S-5948	Gear - Ring	221-9082
4S-5979	Carrier As	216-7843
4S-5981	Gear - Ring	221-9084
4S-6189	Pinion - Reverse	226-6077
4S-6190	Pinion - Forward	226-6078
4S-6559	Tube	325-6234
4S-8005	Pinion - Final Drive	226-6076
4S-8530	Shaft - Planet	221-9111
4S-8534	Shaft As - Planet	221-9116
4S-8716	Gear - Transfer	226-7978
4W-0452	Seal As - Camshaft	325-6191
5A-4003	Shaft - Sprocket	229-8228
5A-5196	Hub - Gear	221-1066
5A-5740	Gear - Sliding	229-8229
5A-6897	Guard - Idler Rh	226-4951
5A-6898	Guard - Idler Lh	226-4952
5A-9551	Gear - Final Drive	226-7979
5F-0689	Pin	256-4821
5F-0706	Pin	256-4822
5F-0707	Collar	256-4831
5F-0736	Pin - Pivot	256-4823
5F-2256	Cage - Bearing	226-7973
5G-3612	Cap Gp	295-6419
5H-5500	Collar - Flywheel	302-2704
5M-7342	Flange - Shaft	215-1696
5P-7807	Bearing - Ball	314-8502
5S-0726	Hub As - Sprocket	227-4769
5S-1211	Cover - Valve	314-8665
5S-1822	Chamber As	248-5406
5S-1833	Chamber As	247-3298
5S-4023	Gear	229-8230
5S-4493	Carrier - Planet	223-6321
5S-4557	Bearing	311-9360
5S-6513	Guard As - Roller	226-4938
5S-6795	Chamber As	242-3437
5S-6972	Gear - Sun	221-9087
5S-6978	Shaft - Planet	221-9103
5S-7009	Plate As - End	226-4957
5S-7010	Shaft - Planet	221-9104
5S-7013	Gear - Ring	221-9088
5S-7023	Carrier - Planet	226-5986
5S-7609	Pulley - Alt Drive	264-5881
5S-8767	Gear - First	226-6085
5S-9062	Spacer	363-7463
5S-9080	Pulley - Alt Drive	264-5883
6B-7178	Fork - Band Adjustable	299-2009
6F-3183	Cap - Bearing	325-6038
6H-3957	Bearing - Ball	311-9358
6I-1346	Pump Gp - Oil	295-5674
6J-0800	Bearing	297-7140
6N-1036	Gear - Oil Pump	279-4991
6N-1965	Line As - Fuel Injector	250-7535
6N-1966	Line As - Fuel Injector	250-7536
6N-8413	Housing - Pump	325-6110
6P-0169	Hub - Flywheel Clutch	297-7204
6T-0443	Pinion - Shaft & Bevel	226-7999
6T-6053	Pinion - Shaft & Gear	226-6079
6W-0240	Bearing - Brace	297-7143
7B-2420	Ferrule - Director	314-8517
7B-5088	Drum - Steering	223-4813
7C-4297	Seal As - Camshaft	325-6192
7F-9541	Pin As - Drawbar	296-1361
7F-9547	Pin As - Drawbar	295-0414
7G-1013	Pump Gp	226-0170
7G-2037	Joint Gp - Univ	226-8017
7G-2038	Tube - Univ Joint	297-7268
7G-2477	Gear - Planet	221-9090
7G-2487	Gear - Planet	221-9092
7G-2520	Gear - Planet	221-9094
7G-3815	Pump Gp	226-0171
7G-6044	Cage As	216-7857
7H-0602	Dog - Clutch	314-8515
7H-1318	Coupling - Steering	226-8002
7H-2424	Sleeve - Spring	226-4852
7H-2742	Nut	229-8220
7H-4710	Bushing - Sleeve	299-1990
7J-6461	Crown	325-6054
7J-9884	Bearing - Sleeve	325-6016
7M-0820	Gear - Sliding	226-6086
7M-2167	Ring - Governor Control	308-9919
7M-4204	Manifold - Exhaust	261-0901
7M-4603	Body - Fuel Valve	311-9348
7M-5002	Drum - Steering	226-7992
7M-5050	Collar - Front Idler	226-4958
7M-7358	Valve - Inlet	298-2774
7M-9398	Plate - Guide	297-7230
7N-0128	Core As - Oil Cooler	299-1994
7N-0165	Core As - Oil Cooler	295-5670
7N-1164	Mount As	295-5451
7N-2871	Line As - Fuel Injector	319-8172
7N-2872	Line As - Fuel Injector	319-8173
7N-2874	Line As - Fuel Injector	298-2779
7N-2875	Line As - Fuel Injector	298-2780
7N-2876	Line As - Fuel Injector	298-2781
7N-2957	Cover - Rad Cap	361-1722
7N-3486	Manifold - Exhaust	261-0899
7N-3515	Gear - Camshaft	314-8669
7N-3536	Gear - Fuel	279-4993
7N-5910	Impeller - Pump	314-8686

(Continued)

Sales Model D5 (Continued)

Original Part Number	Part Name	Classic Part Number
7N-9146	Gear - Fly-wheel Starter	279-4995
7N-9312	Damper As - Camshaft	299-2005
7N-9805	Pin - Piston	295-6438
7S-3161	Lifter - Valve	279-4996
7S-6531	Guard As - Rh	226-4939
7S-6532	Guard As - Lh	226-4940
7S-6537	Guard As - Rh Basic	226-4941
7S-6538	Guard As - Lh Basic	226-4942
7S-6723	Bracket - Alternator	299-1978
7S-7625	Support As	226-6095
7S-7809	Cap As - Radiator	295-6417
7S-8213	Guard As - Final Drive Wear	226-4943
7S-8214	Guard As - Final Drive Wear	226-4944
7S-8443	Muffler	247-2675
7S-8572	Gear - Ring	221-9095
7S-8660	Pump Gp - Transmission	226-0175
7S-9749	Pulley - Gen Drive	264-5888
7T-0203	Guide	226-4959
7T-0206	Bearing - Brace	297-7144
7T-2036	Cap As - Filter	361-1721
7W-0450	Gear - Water Pump	279-4997
7W-0507	Gear - Oil Pump Drive	279-4998
8B-5972	Bearing - Ball	314-8503
8H-1174	Drum - Steering	226-6101 (Drum), 231-1937 (Steering Clutch Kit)
8H-9379	Nut - Brake Band Adjustable	299-2029
8H-9806	Gear - Shaft Drive	325-6091
8J-2652	Shaft	299-2054
8J-2653	Lever As	299-2015
8J-2654	Lever As	299-2016
8K-5587	Rod Gp - Recoil	226-4954
8M-0874	Plunger As - Valve	311-9439
8M-3224	Muffler	247-2676
8M-6219	Spring - Equalizer	293-7606
8M-6615	Leaf - Spring	293-7607
8M-6616	Leaf - Spring	293-7608
8M-6676	Cylinder - Adjustable	226-4960
8M-7166	Housing - Screen	297-7192
8N-0002	Trunnion As	314-8728
8N-0875	Valve - Exhaust	247-6893 (Valve), 241-3381 (Valve Kit)
8N-1187	Head Gp - Cylinder	242-3435
8N-1721	Rod As - Conn	269-5291
8N-1984	Rod As - Conn	242-3441
8N-3180	Body As - Piston	250-6563
8N-3181	Piston Gp - Basic	250-6555 (Liner Kit)
8N-3182	Body As - Piston	250-6564 (Piston As), 250-6556 (Liner Kits)
8N-3183	Piston Gp - Basic	250-6556 (Liner Kit)
8N-3325	Arm Gp - Rocker	314-8623
8N-3327	Arm Gp - Rocker	314-8624
8N-5305	Spacer	363-7464
8N-5929	Cover - Water Pump	296-1349
8N-7315	Tube As - Outlet	325-6232
8N-8225	Bearing - Main	314-8652
8N-9733	Line As - Fuel Injector	319-8174
8P-1182	Shaft	227-4771
8P-1183	Gear - Bevel	226-7980
8P-1656	Plate - Clutch	367-6071
8P-1853	Nut - Adjusting	226-7997
8P-1855	Hub As - Sprocket	227-4770
8P-4111	Guard As	226-4945
8P-4112	Guard As	226-4946
8S-0248	Breather As	325-6033
8S-0493	Shaft As - Pump	325-6198
8S-0556	Coupling	221-9114
8S-1831	Guard As - Sprocket	226-4947
8S-1832	Guard As - Sprocket	226-4948
8S-2140	Trunnion - Gear	226-8020
8S-3970	Chamber As	242-3438
8S-5722	Plate - Pressure	226-8009
9F-7101	Bushing - Collar	299-1988
9G-8246	Rod Gp - Idler Recoil	226-4955
9G-8302	Guide	226-4853
9H-2256	Pump Gp	311-9443
9H-4104	Pilot - Spring	226-4962
9H-7670	Piston	226-4961
9J-9598	Pin	296-1362
9M-2049	Gear - Ring	214-0533
9M-4163	Valve - Exhaust	298-2773
9M-4789	Shaft - Gov Control	297-7256
9M-4955	Pump Gp - Fuel Transfer	242-3443
9M-8117	Shaft - Fly-wheel Clutch	226-6073
9M-8119	Retainer - Inlet	226-8022
9M-8281	Gear As - Oil Pump	325-6089
9N-5769	Cover - Housing	325-6050
9S-2354	Manifold - Exhaust	261-0888
9S-2355	Manifold - Exhaust	261-0891
9S-3321	Cage - Pinion Bearing	226-7974
9S-6129	Pulley - Alternator Drive	264-5891
9S-8245	Strip - Track	226-0243
9S-8246	Strip - Track	226-0244
9S-8257	Guard As - Guiding	226-0238
9S-8258	Guard As - Guiding	226-0239

(Continued)

Sales Model D5 (Continued)

Original Part Number	Part Name	Classic Part Number
9S-8353	Strip - Track	226-4854
9S-8354	Strip - Track	226-4855
9S-8358	Guard As - Guiding	226-4856
9S-8359	Guard As - Guiding	226-4857
9S-8679	Chamber As	325-6042
9T-4761	Head	325-6108
9W-1677	Bearing	297-7145
9Y-9431	Precleaner As	361-1718

Sales Model D5B

Original Part Number	Part Name	Classic Part Number
100-7860	Valve - Inlet	270-4360 (Valve), 270-4362 (Valve Kit)
104-4253	Line As - Fuel Injector	279-4988
104-4254	Line As - Fuel Injector	279-4989
111-8015	Gasket As - Head	279-4977
118-1611	Roller Gp - SF	175-8024
118-1612	Roller Gp - DF	175-8025
122-9405	Bracket As	325-6005
131-3815	Seal Gp - Basic	325-6193
148-7455	Valve - Exhaust	270-4361
154-3662	Link As	257-8020
154-3667	Link As	260-1509
154-3676	Link As	257-8021
165-4262	Body As - Piston	270-4351
172-5185	Shaft - Water Pump	325-6201
172-5188	Shaft - Water Pump	325-6202
172-5189	Impeller - Pump	295-5687
172-5190	Impeller - Pump	325-6111
172-6712	Impeller - Pump	325-6112
172-7767	Pump Gp - Water	296-1365
185-6151	Segment, Segment Gp	260-1510, 260-1511 (sprocket group)
190-8609	Valve - Fill	360-2288
196-0028	Gear As - Idler	364-5259
1H-8382	Gear - Oil Pump Drive	226-6103
1H-8937	Drumbrake	226-7993
1M-1408	Nut (5/8-18)	200-9150
1M-7250	Bowl - Precleaner	360-2296
1M-9177	Flywheel	226-6112
1M-9444	Retainer - Spring	299-2046
1N-3576	Block Gp - Cylinder	279-4978
1N-3958	Elbow	325-6087
1P-1636	Lever As	226-8013
1P-6273	Rod Gp - Recoil	226-4847
1P-6752	Pump Gp	226-0161
1P-7044	Cage	226-7975
1P-9024	Spring - Equalizer	231-3311
1P-9945	Bracket As - Fan	296-1344
1P-9946	Shaft - Fan	325-6194
1P-9952	Impeller - Pump	314-8685
1S-1888	Bracket - Lamp	297-7147
1S-4701	Pulley - Alt	264-5866
1S-5315	Cap As - Brace Bearing	226-4848
1S-6422	Pilot As - Spring	226-4849
1S-8734	Bracket - Roller	226-0212
1S-8764	Ring - Flywheel Clutch Adjustable	226-8014
1T-0521	Retainer - Bearing	325-6180
1T-1350	Torque Converter	235-0912 (Repair Kit)
1T-1993	Wheel - Turbine	235-0920
1T-2052	Stator As	295-5683
1W-0777	Muffler As	247-2662
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1695	Pump Gp	279-4980
1W-1698	Housing - Transfer Pump	296-1356
1W-4402	Gear - Camshaft	279-4981
1W-4405	Gear - Crankshaft	279-4982
1W-5912	Tappet As - Guide	325-6223
1W-6541	Plunger As	325-6173
244-1090	Alarm - Back up	360-2345
2F-5721	Bearing - Ball	311-9354
2F-7576	Shaft - Sprocket	226-6071
2F-7577	Shaft	226-6072
2G-8872	Shaft - Bevel	275-5271
2H-4338	Plate - Pressure	226-8010
2H-4450	Washer - Thrust	325-6237
2H-4482	Collar	229-8218
2H-5046	Link - Flycam	299-2024
2J-8489	Bearing - Sleeve	295-5691
2K-3592	Boss	314-8501
2K-4502	Bearing - Sleeve	299-1986
2K-4507	Bearing - Sleeve	325-6021
2M-2290	Bracket - Ring	299-1979
2M-2415	Guard-idler - Rh	226-4931
2M-2416	Guard-idler - Lh	226-4933
2M-2417	Guard-spring - Rh	226-4934
2M-2418	Guard-spring - Lh	226-4935
2M-4668	Retainer - Guard	297-4867

(Continued)

Sales Model D5B (Continued)

Original Part Number	Part Name	Classic Part Number
2P-1005	Bearing - Sleeve	296-1342
2P-1170	Shaft As - Gear	296-1367
2P-1738	Plate As - Oil Pan	325-6164
2P-1739	Tube As - Pump	325-6229
2P-1757	Hub - Fan Pulley	296-1357
2P-1781	Spacer - Oil Pump	325-6214
2P-2519	Tube As - Inlet	325-6230
2P-2744	Muffler As	247-2664
2P-4370	Plate - Clutch	325-6166
2P-4611	Pipe - Exhaust	365-8821
2P-6245	Shaft As - Pump	325-6197
2P-7622	Bolt - Spring	226-4850
2P-9660	Gear - Final Drive	226-5995
2P-9672	Cage - Pinion Bearing	226-7972
2S-1477	Holder As - Cage	226-7985
2S-8277	Guard Gp - Spring	226-4936
2S-8278	Guard Gp - Spring	226-4937
2W-1086	Cover As - Cylinder Head	325-6049
2W-2621	Valve - Inlet	247-6892 (Valve), 241-3381 (Valve Kit)
2W-7255	Shaft - Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear - Water Pump	325-6088
2W-9978	Core As - Oil Cooler	279-4983
3F-1956	Cap - Frame Sup	226-7987
3F-1972	Retainer As	226-7988
3F-6185	Pin	295-5694
3F-6446	Pivot - Push Pole	256-4827
3F-6523	Pin - Clevis	256-4818
3F-6561	Arm As - Brace	256-4828
3F-6611	Socket - Joint	256-4829
3F-6612	Cap - Ball Joint	297-7155
3J-6559	Cap - Bearing	296-1346
3K-3124	Muffler - Trap	247-2673
3L-1425	Bearing - Ball	311-9356
3P-2274	Bolt Master	200-9133
3P-3623	Lock - Adjustable Nut	226-7989
3P-3889	Shoe - Track Master	175-8021
3P-3890	Shoe - Track Master	175-8366
3P-3891	Shoe - Track Master	175-8368
3P-3892	Shoe - Track Master	175-8674
3P-3896	Shoe - Track Master	175-8023
3P-3935	Shaft	299-2053
3P-5736	Hub - Gear	219-2975
3P-5754	Hub - Gear	219-2976
3P-5755	Extension - Final Drive	226-7990
3P-5762	Link As	257-8022
3S-0311	Rod Gp	226-4953
3S-1167	Gear - Planet	221-9101
3S-2712	Gear - Transfer	226-7977
3S-7153	Gear - Sliding	227-0024
3S-7504	Gear - Idler	226-6084
3S-8634	Hub - Gear	219-2977
3T-1900	Drum	226-7991
3T-3690	Shoe -Track	175-8553
3V-1133	Strip	226-0203
4F-1252	Pin	295-5704
4F-4974	Clamp	311-9373
4H-4021	Plate As - Loading	229-8219
4H-9040	Nut	226-7996
4J-2414	Trunnion	296-1370
4J-3583	Screw - Adjusting	297-7242
4J-6374	Bearing - Sleeve	295-6407
4K-4780	Strip As - Wear	299-2063
4K-7386	Plate - Guide	226-4851
4N-2954	Sleeve - Camshaft	299-2059
4N-3281	Line As - Fuel Injector	247-3362
4N-3282	Line As - Fuel Injector	247-3363
4N-3283	Line As - Fuel Injector	247-3364
4N-3284	Line As - Fuel Injector	247-3365
4N-4864	Pump Gp - Fuel Transfer	242-3442
4N-7693	Crankshaft As	242-3439
4N-7982	Pulley	264-5880
4N-8591	Coupling - Exhaust	325-6053
4N-8814	Line As - Fuel Injector	247-3366
4N-9587	Shield - Heat	297-7260
4P-0660	Muffler As	298-2787
4P-3546	Valve As - Relief	325-6236
4P-9381	Line As - Fuel Injector	279-4984
4P-9382	Line As - Fuel Injector	279-4985
4P-9385	Line As - Fuel Injector	279-4986
4P-9386	Line As - Fuel Injector	279-4987
4S-5943	Piston - Clutch	221-9112
4S-5944	Gear - Sun	221-9078
4S-5945	Gear - Sun	221-9079
4S-5947	Gear - Ring	221-9080
4S-5948	Gear - Ring	221-9082
4S-5979	Carrier As	216-7843
4S-5981	Gear - Ring	221-9084
4S-6189	Pinion - Reverse	226-6077
4S-6190	Pinion - Forward	226-6078
4S-6559	Tube	325-6234
4S-8530	Shaft - Planet	221-9111
4S-8534	Shaft As - Planet	221-9116
4S-8716	Gear - Transfer	226-7978
4W-0452	Seal As - Camshaft	325-6191
5A-4003	Shaft - Sprocket	229-8228
5A-5740	Gear - Sliding	229-8229

(Continued)

Sales Model D5B (Continued)

Original Part Number	Part Name	Classic Part Number
5A-6897	Guard - Idler Rh	226-4951
5A-6898	Guard - Idler Lh	226-4952
5A-8374	Roller Gp - Carrier	200-9185
5A-9551	Gear - Final Drive	226-7979
5F-0689	Pin	256-4821
5F-0706	Pin	256-4822
5F-0707	Collar	256-4831
5F-0736	Pin - Pivot	256-4823
5H-5500	Collar - Fly-wheel	302-2704
5M-7342	Flange - Shaft	215-1696
5P-7807	Bearing - Ball	314-8502
5S-0726	Hub As - Sprocket	227-4769
5S-0821	Shoe -Track	175-8020
5S-0822	Shoe -Track	175-8365
5S-0823	Shoe -Track	175-8367
5S-1211	Cover - Valve	314-8665
5S-4023	Gear	229-8230
5S-4493	Carrier - Planet	223-6321
5S-6513	Guard As - Roller	226-4938
5S-6795	Chamber As	242-3437
5S-6972	Gear - Sun	221-9087
5S-6978	Shaft - Planet	221-9103
5S-7009	Plate As - End	226-4957
5S-7010	Shaft - Planet	221-9104
5S-7013	Gear - Ring	221-9088
5S-7023	Carrier - Planet	226-5986
5S-7609	Pulley - Alt Drive	264-5881
5S-8767	Gear - First	226-6085
5S-9062	Spacer	363-7463
5S-9080	Pulley - Alt Drive	264-5883
6B-7178	Fork - Band Adjustable	299-2009
6F-3183	Cap - Bearing	325-6038
6H-3957	Bearing - Ball	311-9358
6I-1346	Pump Gp - Oil	295-5674
6J-0800	Bearing	297-7140
6N-1036	Gear - Oil Pump	279-4991
6N-1965	Line As - Fuel Injector	250-7535
6N-1966	Line As - Fuel Injector	250-7536
6N-8413	Housing - Pump	325-6110
6P-0169	Hub - Fly-wheel Clutch	297-7204
6T-0443	Pinion - Shaft & Bevel	226-7999
6T-6053	Pinion - Shaft & Gear	226-6079
7C-4297	Seal As - Camshaft	325-6192
7F-9541	Pin As - Drawbar	296-1361
7F-9547	Pin As - Drawbar	295-0414
7G-1013	Pump Gp	226-0170
7G-2037	Joint Gp - Univ	226-8017
7G-2038	Tube - Univ Joint	297-7268
7G-2477	Gear - Planet	221-9090
7G-2487	Gear - Planet	221-9092
7G-2520	Gear - Planet	221-9094
7G-6044	Cage As	216-7857
7G-8459	Hub - Gear	221-1070
7H-2424	Sleeve - Spring	226-4852
7H-4710	Bushing - Sleeve	299-1990
7J-6461	Crown	325-6054
7J-9842	Bearing - Sleeve	299-1968
7J-9884	Bearing - Sleeve	325-6016
7M-0820	Gear - Sliding	226-6086
7M-2167	Ring - Gover-nor Control	308-9919
7M-5050	Collar - Front Idler	226-4958
7M-9398	Plate - Guide	297-7230
7N-0128	Core As - Oil Cooler	299-1994
7N-0165	Core As - Oil Cooler	295-5670
7N-1164	Mount As	295-5451
7N-2871	Line As - Fuel Injector	319-8172
7N-2872	Line As - Fuel Injector	319-8173
7N-2874	Line As - Fuel Injector	298-2779
7N-2875	Line As - Fuel Injector	298-2780
7N-2876	Line As - Fuel Injector	298-2781
7N-3486	Manifold - Exhaust	261-0899
7N-3515	Gear - Cam-shaft	314-8669
7N-3536	Gear - Fuel	279-4993
7N-5910	Impeller - Pump	314-8686
7N-8117	Muffler As	247-2668
7N-9146	Gear - Fly-wheel Starter	279-4995
7N-9805	Pin - Piston	295-6438
7S-0706	Shoe -Track	175-8673
7S-3161	Lifter - Valve	279-4996
7S-6531	Guard As - Rh	226-4939
7S-6532	Guard As - Lh	226-4940
7S-6537	Guard As - Rh Basic	226-4941
7S-6538	Guard As - Lh Basic	226-4942
7S-6723	Bracket - Alternator	299-1978
7S-7625	Support As	226-6095
7S-7809	Cap As - Radiator	295-6417
7S-8213	Guard As - Final Drive Wear	226-4943
7S-8214	Guard As - Final Drive Wear	226-4944
7S-8443	Muffler	247-2675
7S-8572	Gear - Ring	221-9095
7S-8660	Pump Gp - Transmission	226-0175
7S-9567	Shoe -Track	175-8022
7T-0203	Guide	226-4959
7T-0206	Bearing - Brace	297-7144
7T-2036	Cap As - Filter	361-1721
7W-0450	Gear - Water Pump	279-4997
7W-0507	Gear - Oil Pump Drive	279-4998
7W-0508	Gear - Fuel Pump Drive	296-1351
8H-2810	Case As - Filter	314-8512

(Continued)

Sales Model D5B (Continued)

Original Part Number	Part Name	Classic Part Number
8H-9379	Nut - Brake Band Adjustable	299-2029
8H-9806	Gear - Shaft Drive	325-6091
8J-2652	Shaft	299-2054
8J-2653	Lever As	299-2015
8J-2654	Lever As	299-2016
8K-5587	Rod Gp - Recoil	226-4954
8M-0874	Plunger As - Valve	311-9439
8M-6219	Spring - Equalizer	293-7606
8M-6615	Leaf - Spring	293-7607
8M-6616	Leaf - Spring	293-7608
8M-6676	Cylinder - Adjustable	226-4960
8M-7166	Housing - Screen	297-7192
8N-0002	Trunnion As	314-8728
8N-0875	Valve - Exhaust	247-6893 (Valve), 241-3381 (Valve Kit)
8N-1187	Head Gp - Cylinder	242-3435
8N-1721	Rod As - Conn	269-5291
8N-1984	Rod As - Conn	242-3441
8N-2510	Shaft	325-6208
8N-2641	Sleeve	325-6210
8N-3180	Body As - Piston	250-6563
8N-3181	Piston Gp - Basic	250-6555 (Liner Kit)
8N-3183	Piston Gp - Basic	250-6556 (Liner Kit)
8N-3251	Shaft As - Rocker Arm	314-8711
8N-3325	Arm Gp - Rocker	314-8623
8N-3327	Arm Gp - Rocker	314-8624
8N-5305	Spacer	363-7464
8N-5929	Cover - Water Pump	296-1349
8N-6796	Head Gp - Cylinder	269-5290
8N-7315	Tube As - Outlet	325-6232
8N-7780	Shield - Oil	314-8544
8N-8225	Bearing - Main	314-8652
8N-9733	Line As - Fuel Injector	319-8174
8P-0203	Drum	226-8004
8P-1182	Shaft	227-4771
8P-1183	Gear - Bevel	226-7980
8P-1324	Cage - Gr Shft Bearing	229-8239
8P-1325	Hub - Steering	226-8005
8P-1326	Pilot - Piston	226-6097
8P-1327	Pinion - Final Drive	226-8000
8P-1328	Flange - Drive Drum	226-8006
8P-1353	Piston - Steering	226-8007
8P-1656	Plate - Clutch	367-6071
8P-1774	Pinion - Final Drive	226-8001
8P-1853	Nut - Adjusting	226-7997
8P-1855	Hub As - Sprocket	227-4770
8P-2430	Shaft As	297-7258
8P-4111	Guard As	226-4945
8P-4112	Guard As	226-4946
8P-8570	Pilot As - Piston	226-6097
8S-0248	Breather As	325-6033
8S-0493	Shaft As - Pump	325-6198
8S-0556	Coupling	221-9114
8S-1831	Guard As - Sprocket	226-4947
8S-1832	Guard As - Sprocket	226-4948
8S-2140	Trunnion - Gear	226-8020
8S-2560	Idler Gp, Idler As.	200-9235 (Complete Idler Group), 175-8255 (Idler As.)
8S-2809	Muffler	247-2677
8S-3970	Chamber As	242-3438
9F-7101	Bushing - Collar	299-1988
9G-8246	Rod Gp - Idler Recoil	226-4955
9G-8302	Guide	226-4853
9H-2256	Pump Gp	311-9443
9H-4104	Pilot - Spring	226-4962
9H-7670	Piston	226-4961
9J-9598	Pin	296-1362
9K-8757	Rod End - Bearing	311-9361
9M-2049	Gear - Ring	214-0533
9M-4789	Shaft - Gov Control	297-7256
9M-8117	Shaft - Flywheel Clutch	226-6073
9M-8119	Retainer - Inlet	226-8022
9M-8281	Gear As - Oil Pump	325-6089
9N-5769	Cover - Housing	325-6050
9S-2355	Manifold - Exhaust	261-0891
9S-3321	Cage - Pinion Bearing	226-7974
9S-6129	Pulley - Alternator Drive	264-5891
9S-8245	Strip - Track	226-0243
9S-8246	Strip - Track	226-0244
9S-8257	Guard As - Guiding	226-0238
9S-8258	Guard As - Guiding	226-0239
9S-8353	Strip - Track	226-4854
9S-8354	Strip - Track	226-4855
9S-8358	Guard As - Guiding	226-4856
9S-8359	Guard As - Guiding	226-4857
9S-8679	Chamber As	325-6042
9T-4761	Head	325-6108
9W-1677	Bearing	297-7145

Sales Model D5H

Original Part Number	Part Name	Classic Part Number
100-7860	Valve - Inlet	270-4360 (Valve), 270-4362 (Valve Kit)
104-4253	Line As - Fuel Injector	279-4988
104-4254	Line As - Fuel Injector	279-4989
111-8015	Gasket As - Head	279-4977
131-3815	Seal Gp - Basic	325-6193
148-7455	Valve - Exhaust	270-4361
165-4262	Body As - Piston	270-4351
172-5185	Shaft - Water Pump	325-6201
172-5188	Shaft - Water Pump	325-6202
172-5189	Impeller - Pump	295-5687
172-5190	Impeller - Pump	325-6111
172-6712	Impeller - Pump	325-6112
172-7767	Pump Gp - Water	296-1365
196-0028	Gear As - Idler	364-5259
1N-3576	Block Gp - Cylinder	279-4978
1N-3958	Elbow	325-6087
1N-4304	Head Gp - Cylinder	269-8761
1P-1216	Manifold - Exhaust	261-0902
1P-1721	Gear - Balance	298-2769
1P-1722	Gear - Balance	298-2770
1P-9945	Bracket As - Fan	296-1344
1P-9946	Shaft - Fan	325-6194
1S-4701	Pulley - Alt	264-5866
1U-0105	Brace As	295-5684
1U-0159	Pin	325-6134
1U-0928	Screw - Adjusting	325-6187
1U-1267	Brace As	296-1343
1W-1669	Piston	325-6158
1W-1695	Pump Gp	279-4980
1W-1698	Housing - Transfer Pump	296-1356
1W-2870	Shaft As - Balance	314-8715
1W-2871	Shaft As - Balance	314-8716
1W-4402	Gear - Camshaft	279-4981
1W-4405	Gear - Crankshaft	279-4982
1W-4407	Hub - Fan Pulley	296-1358
1W-5912	Tappet As - Guide	325-6223
1W-6541	Plunger As	325-6173
2F-5721	Bearing - Ball	311-9354
2J-8489	Bearing - Sleeve	295-5691
2K-4502	Bearing - Sleeve	299-1986
2K-4507	Bearing - Sleeve	325-6021
2P-1005	Bearing - Sleeve	296-1342
2P-1170	Shaft As - Gear	296-1367
2P-1438	Pipe - Exhaust Ext	325-6157
2P-1757	Hub - Fan Pulley	296-1357
2P-1781	Spacer - Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2519	Tube As - Inlet	325-6230
2P-6128	Pulley	264-5872
2P-6245	Shaft As - Pump	325-6197
2P-7828	Pan - Oil	314-8691
2W-1086	Cover As - Cylinder Head	325-6049
2W-2621	Valve - Inlet	247-6892 (Valve), 241-3381 (Valve Kit)
2W-5540	Core, Radiator (Folded)	363-7452
2W-7255	Shaft - Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
3F-4971	Pin	295-5693
3F-6185	Pin	295-5694
3F-6523	Pin - Clevis	256-4818
3F-6612	Cap - Ball Joint	297-7155
3G-6313	Bearing	325-6007
3G-6565	Bearing - Sleeve	325-6008
3G-8900	Pin	325-6140
3G-8917	Pin	325-6141
3G-8932	Pin	325-6143
3J-2452	Cap - Ball Joint	297-7156
3J-6167	Bearing - Sleeve	299-1960
3J-6182	Pin As	325-6128
3J-6204	Pin As	325-6129
3J-6442	Bearing - Sleeve	299-1961
3J-6559	Cap - Bearing	296-1346
3J-6560	Screw - Adjustable	297-7240
3J-6573	Screw - Adjusting	302-2714
3L-1425	Bearing - Ball	311-9356
3T-1162	Sleeve - Wear	325-6209
3T-2145	Carrier As	325-6041
3T-3447	Gear As - Sun	302-2676
3T-6795	Piston - Clutch	281-1693
3T-9496	Plate - Retainer	299-2042
3W-0640	Piston	325-6160
3W-0643	Cylinder	325-6061
4F-1252	Pin	295-5704
4F-4974	Clamp	311-9373
4J-1616	Bracket	299-1982
4J-1641	Trunnion	314-8725
4J-2414	Trunnion	296-1370
4J-3015	Shaft	325-6204
4J-3583	Screw - Adjusting	297-7242
4K-3004	Bearing - Trunnion Support	314-8632
4K-3128	Bearing - Sleeve	314-8633
4N-4782	Pulley	325-6176
4N-7692	Crankshaft As	242-3440
4N-7693	Crankshaft As	242-3439
4P-3546	Valve As - Relief	325-6236

(Continued)

Sales Model D5H (Continued)

Original Part Number	Part Name	Classic Part Number
4P-9381	Line As - Fuel Injector	279-4984
4P-9382	Line As - Fuel Injector	279-4985
4P-9961	Line As - Fuel Injector	325-6115
4P-9962	Line As - Fuel Injector	325-6116
4P-9963	Line As - Fuel Injector	298-2777
4P-9964	Line As - Fuel Injector	298-2778
4S-6559	Tube	325-6234
4T-0732	Bracket	314-8627
4T-0998	Lever	314-8687
4T-1504	Trunnion	314-8727
4T-5172	Seal As	325-6189
4T-5495	Ballstud	314-8626
4W-0452	Seal As - Camshaft	325-6191
4W-2042	Spacer	325-6217
5G-3612	Cap Gp	295-6419
5P-7807	Bearing - Ball	314-8502
5S-6795	Chamber As	242-3437
5S-9062	Spacer	363-7463
5S-9080	Pulley - Alt Drive	264-5883
5T-1362	Bearing - Spider	325-6011
6D-0217	Bearing - Sleeve	325-6022
6F-3183	Cap - Bearing	325-6038
6H-3957	Bearing - Ball	311-9358
6I-1346	Pump Gp - Oil	295-5674
6J-0800	Bearing	297-7140
6N-1036	Gear - Oil Pump	279-4991
6N-2789	Pulley	264-5886
6N-8413	Housing - Pump	325-6110
6P-2233	Gear - Planet	281-1690
6P-7742	Shaft - Planet	281-1695
6P-7743	Shaft - Planet	281-1696
6P-8005	Gear - Planet	281-1691
6T-3009	Piston - Clutch	297-7226
6Y-4027	Pin	325-6148
6Y-6126	Plate - Wear	325-6174
6Y-6127	Plate - Wear	325-6175
6Y-6134	Bearing - Sleeve	325-6013
6Y-6234	Bearing - Sleeve	325-6014
6Y-6236	Bearing - Sleeve	325-6024
6Y-6775	Pin	325-6151
6Y-8248	Pin	325-6154
7C-4297	Seal As - Camshaft	325-6192
7G-3707	Piston - Clutch	302-2691
7G-3708	Piston - Clutch	300-2585
7G-4302	Housing - Clutch	302-2708
7G-4306	Plate - Center	297-7229
7G-5444	Carrier - Planet	297-7165
7G-5593	Gear - Sun	300-2581
7G-5614	Shaft - Planet	281-1697
7G-7681	Shaft As	307-1530
7G-9555	Bearing - Spider	314-8721
7J-1333	Bearing - Sleeve	295-6408
7J-5131	Trunnion	296-1371
7J-6461	Crown	325-6054
7J-9732	Bearing - Sleeve	308-9823
7J-9842	Bearing - Sleeve	299-1968
7J-9884	Bearing - Sleeve	325-6016
7N-0128	Core As - Oil Cooler	299-1994
7N-0165	Core As - Oil Cooler	295-5670
7N-2949	Pulley	264-5887
7N-5910	Impeller - Pump	314-8686
7N-9145	Gear - Flywheel	279-4994
7N-9805	Pin - Piston	295-6438
7P-6596	Bearing - Sleeve	295-6409
7S-3161	Lifter - Valve	279-4996
7T-5038	Housing As	297-7202
7W-0450	Gear - Water Pump	279-4997
7W-0507	Gear - Oil Pump Drive	279-4998
7W-0508	Gear - Fuel Pump Drive	296-1351
7W-3042	Tube As - Drain	325-6231
8E-6221	Pin	325-6155
8E-9214	Pin	325-6156
8G-3102	Piston	325-6162
8G-4187	Pin As	295-5676
8G-4189	Bearing - Aligning	295-6411
8G-4190	Seal - Ebar	296-1366
8H-2810	Case As - Filter	314-8512
8J-2880	Cap - Bearing	295-6420
8N-0875	Valve - Exhaust	247-6893 (Valve), 241-3381 (Valve Kit)
8N-1187	Head Gp - Cylinder	242-3435
8N-1188	Head Gp - Cylinder	242-3436
8N-1721	Rod As - Conn	269-5291
8N-2510	Shaft	325-6208
8N-2641	Sleeve	325-6210
8N-3251	Shaft As - Rocker Arm	314-8711
8N-3312	Shaft As - Rocker Arm	325-6200
8N-3325	Arm Gp - Rocker	314-8623
8N-3327	Arm Gp - Rocker	314-8624
8N-5305	Spacer	363-7464
8N-5929	Cover - Water Pump	296-1349
8N-6796	Head Gp - Cylinder	269-5290
8N-7315	Tube As - Outlet	325-6232
8N-8225	Bearing - Main	314-8652
8N-9402	Coupling	325-6048
8P-8677	Hub - Impeller	297-7205
8S-0248	Breather As	325-6033
8S-0493	Shaft As - Pump	325-6198
8S-3970	Chamber As	242-3438
8Y-1198	Strip	325-6220
8Y-1199	Strip	325-6221
9G-1231	Plate	297-7232

(Continued)

Sales Model D5H (Continued)

Original Part Number	Part Name	Classic Part Number
9G-1491	Carrier - Planet	281-1685
9G-9349	Retainer	295-0411
9J-2365	Retainer	325-6186
9J-5875	Bearing - Sleeve	308-9830
9J-7964	Bearing - Spherical	325-6017
9J-9147	Nut	299-2028
9J-9598	Pin	296-1362
9M-1328	Bearing - Aligning	325-6018
9N-4460	Housing As	297-7203
9N-5769	Cover - Housing	325-6050
9P-3242	Plate - Clutch	325-6172
9S-8679	Chamber As	325-6042
9T-8424	Bearing - Sleeve	325-6030
9W-0099	Bearing - Sleeve	314-8639
9W-0517	Carrier - Planet	281-1686
9W-1677	Bearing	297-7145
9W-2579	Plate	314-8701
9W-8384	Hub - Turbine	297-7207
9W-9930	Mount As	295-6437
9Y-2992	Bearing - Sleeve	325-6032

Sales Model D6

Original Part Number	Part Name	Classic Part Number
0T-0259	Nut - Bearing Sleeve	311-9431
100-7860	Valve - Inlet	270-4360 (Valve), 270-4362 (Valve Kit)
102-1561	Lifter As - Valve	311-9402
104-4253	Line As - Fuel Injector	279-4988
104-4254	Line As - Fuel Injector	279-4989
111-8015	Gasket As - Head	279-4977
118-1611	Roller Gp - SF	175-8024
118-1612	Roller Gp - DF	175-8025
121-7746	Precleaner As	360-2311
122-9405	Bracket As	325-6005
131-3815	Seal Gp - Basic	325-6193
148-7455	Valve - Exhaust	270-4361
154-3662	Link As	257-8020
154-3667	Link As	260-1509
154-3676	Link As	257-8021
160-6305	Cap - Bearing	295-5686
167-8123	Damper As	299-2006
172-5185	Shaft - Water Pump	325-6201
172-5188	Shaft - Water Pump	325-6202
172-5189	Impeller - Pump	295-5687
172-5190	Impeller - Pump	325-6111
172-6712	Impeller - Pump	325-6112
172-7767	Pump Gp - Water	296-1365
185-6151	Segment, Segment Gp	260-1510, 260-1511 (sprocket group)
1A-2846	Cap As - Filler	311-9368
1D-3996	Fork - Knuckle	228-9428
1F-2254	Bushing - Stem	314-8510
1F-4419	Gasket - Cover	311-9393
1H-8262	Shaft	226-8016
1H-8382	Gear - Oil Pump Drive	226-6103
1H-8937	Drumbrake	226-7993
1H-8938	Lever	226-8028
1M-0176	Flange - Drum	223-4810
1M-1408	Nut (5/8-18)	200-9150
1M-5165	Pinion - Final Drive	231-8766
1M-7250	Bowl - Precleaner	360-2296
1M-9177	Flywheel	226-6112
1N-3576	Block Gp - Cylinder	279-4978
1N-3958	Elbow	325-6087
1P-1931	Shaft - Steer	227-4772
1P-4303	Head As - Cylinder	242-3434
1P-5480	Cover As - End	299-1998
1P-7044	Cage	226-7975
1P-9945	Bracket As - Fan	296-1344
1P-9946	Shaft - Fan	325-6194
1P-9952	Impeller - Pump	314-8685
1S-1888	Bracket - Lamp	297-7147
1S-1967	Chamber As	247-3291
1S-1970	Chamber As	247-3292
1S-4701	Pulley - Alt	264-5866
1S-5315	Cap As - Brace Bearing	226-4848
1S-5738	Insert - Seat Exhaust	311-9396
1S-6422	Pilot As - Spring	226-4849
1S-8764	Ring - Flywheel Clutch Adjustable	226-8014
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1695	Pump Gp	279-4980
1W-1698	Housing - Transfer Pump	296-1356
1W-3062	Retainer As	311-9445
1W-4402	Gear - Camshaft	279-4981
1W-4405	Gear - Crankshaft	279-4982
1W-5912	Tappet As - Guide	325-6223
1W-6541	Plunger As	325-6173
2B-3708	Chamber As	247-3293
2D-5658	Bearing - Ball	301-4628
2F-5721	Bearing - Ball	311-9354
2F-7576	Shaft - Sprocket	226-6071
2F-7577	Shaft	226-6072

(Continued)

Sales Model D6 (Continued)

Original Part Number	Part Name	Classic Part Number
2H-4338	Plate - Pressure	226-8010
2H-4450	Washer - Thrust	325-6237
2H-4482	Collar	229-8218
2H-5046	Link - Flycam	299-2024
2K-3592	Boss	314-8501
2K-4177	Pin - Lock	308-9893
2K-4502	Bearing - Sleeve	299-1986
2K-4507	Bearing - Sleeve	325-6021
2M-2290	Bracket - Ring	299-1979
2N-3227	Bracket - Lft Guide	311-9367
2N-9297	Retainer - Spring	314-8535
2P-1170	Shaft As - Gear	296-1367
2P-1738	Plate As - Oil Pan	325-6164
2P-1739	Tube As - Pump	325-6229
2P-1757	Hub - Fan Pulley	296-1357
2P-1781	Spacer - Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2519	Tube As - Inlet	325-6230
2P-4701	Shaft As - Gear	297-7257
2P-6128	Pulley	264-5872
2P-6245	Shaft As - Pump	325-6197
2P-7622	Bolt - Spring	226-4850
2P-7830	Pump Gp	314-8533
2P-9660	Gear - Final Drive	226-5995
2S-1273	Chamber As	319-3434
2S-1477	Holder As - Cage	226-7985
2S-4015	Plunger As - Valve	311-9438
2S-6739	Pulley - Tightener	298-2794
2W-1086	Cover As - Cylinder Head	325-6049
2W-2621	Valve - Inlet	247-6892 (Valve), 241-3381 (Valve Kit)
2W-3211	Valve - Exhaust	311-9471
2W-7255	Shaft - Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear - Water Pump	325-6088
2W-9978	Core As - Oil Cooler	279-4983
3B-1464	Cap - Bearing	226-0206
3B-6217	Muffler As	247-2671
3B-6218	Muffler As	247-2672
3F-1956	Cap - Frame Sup	226-7987
3F-1972	Retainer As	226-7988
3F-4971	Pin	295-5693
3F-6185	Pin	295-5694
3F-6446	Pivot - Push Pole	256-4827
3F-6561	Arm As - Brace	256-4828
3F-6611	Socket - Joint	256-4829
3F-6612	Cap - Ball Joint	297-7155
3F-7445	Bearing - Sleeve	314-8508
3H-3378	Gear As - Pump	298-2795
3K-3124	Muffler - Trap	247-2673
3L-1425	Bearing - Ball	311-9356
3N-3368	Pipe - Exhaust	311-9434
3P-2274	Bolt Master	200-9133
3P-3623	Lock - Adjustable Nut	226-7989
3P-3889	Shoe - Track Master	175-8021
3P-3890	Shoe - Track Master	175-8366
3P-3891	Shoe - Track Master	175-8368
3P-3892	Shoe - Track Master	175-8674
3P-3896	Shoe - Track Master	175-8023
3P-5754	Hub - Gear	219-2976
3P-5762	Link As	257-8022
3S-7153	Gear - Sliding	227-0024
3S-8634	Hub - Gear	219-2977
3S-8800	Gear - Driven	325-6090
3S-9466	Bearing - Sleeve	314-8509
3T-3690	Shoe -Track	175-8553
3V-1133	Strip	226-0203
4B-1455	Cap As - Filter	361-1719
4F-4974	Clamp	311-9373
4H-4021	Plate As - Loading	229-8219
4H-9040	Nut	226-7996
4J-1999	Ballstud	314-8625
4L-7820	Rod Assembly	311-9449
4M-9215	Gear - Pump Idler	311-9391
4N-2954	Sleeve - Camshaft	299-2059
4N-3281	Line As - Fuel Injector	247-3362
4N-3282	Line As - Fuel Injector	247-3363
4N-3283	Line As - Fuel Injector	247-3364
4N-3284	Line As - Fuel Injector	247-3365
4N-4356	Pulley - Camshaft	264-5878
4N-4577	Muffler As	308-9877
4N-4864	Pump Gp - Fuel Transfer	242-3442
4N-5503	Adapter - Exhaust	299-1954
4N-7526	Seal As - Pump	311-9454
4N-7693	Crankshaft As	242-3439
4N-7982	Pulley	264-5880
4N-8591	Coupling - Exhaust	325-6053
4N-8814	Line As - Fuel Injector	247-3366
4N-9180	Seal As - Pump	311-9455
4N-9587	Shield - Heat	297-7260
4P-3546	Valve As - Relief	325-6236
4P-9381	Line As - Fuel Injector	279-4984
4P-9382	Line As - Fuel Injector	279-4985
4P-9385	Line As - Fuel Injector	279-4986
4P-9386	Line As - Fuel Injector	279-4987
4S-8005	Pinion - Final Drive	226-6076

(Continued)

Sales Model D6 (Continued)

Original Part Number	Part Name	Classic Part Number
4S-8472	Hood As	296-1355
4S-8908	Insert	311-9399
4S-8909	Insert - Valve Seat	311-9400
4W-0452	Seal As - Camshaft	325-6191
4W-2446	Damper As	279-4990
4W-9989	Gear As - Idler	302-2677
5A-8374	Roller Gp - Carrier	200-9185
5A-9551	Gear - Final Drive	226-7979
5D-0470	Valve Gp	314-8549
5F-0689	Pin	256-4821
5F-2256	Cage - Bearing	226-7973
5F-7993	Pin	319-3454
5H-5500	Collar - Flywheel	302-2704
5L-3980	V - Belt Set	314-8498
5L-8856	Coupling - Exhaust	311-9379
5L-9371	Connector - Inlet	311-9375
5M-5244	Hub - Gear	219-2982
5P-7807	Bearing - Ball	314-8502
5S-0726	Hub As - Sprocket	227-4769
5S-0821	Shoe -Track	175-8020
5S-0822	Shoe -Track	175-8365
5S-0823	Shoe -Track	175-8367
5S-1211	Cover - Valve	314-8665
5S-1757	Insert - Seat	311-9401
5S-4557	Bearing	311-9360
5S-6513	Guard As - Roller	226-4938
5S-6795	Chamber As	242-3437
5S-7609	Pulley - Alt Drive	264-5881
5S-9080	Pulley - Alt Drive	264-5883
6B-7178	Fork - Band Adjustable	299-2009
6F-2904	Bearing	295-5673
6F-3183	Cap - Bearing	325-6038
6H-3217	Shaft As - Rocker	311-9457
6H-3957	Bearing - Ball	311-9358
6I-1346	Pump Gp - Oil	295-5674
6L-7816	Seal - o-Ring	314-8542
6L-8968	Coupling - Exhaust	311-9381
6N-0714	Pulley - Alt	264-5884
6N-1036	Gear - Oil Pump	279-4991
6N-1965	Line As - Fuel Injector	250-7535
6N-1966	Line As - Fuel Injector	250-7536
6N-2789	Pulley	264-5886
6N-8413	Housing - Pump	325-6110
6P-0169	Hub - Flywheel Clutch	297-7204
7B-0503	Ballstud	308-9801
7B-2420	Ferrule - Director	314-8517
7B-5088	Drum - Steering	223-4813
7C-4297	Seal As - Camshaft	325-6192
7C-5920	Insert - Seat	314-8528
7C-5921	Insert - Seat	314-8529
7C-5922	Insert - Seat	314-8530
7D-6841	Joint As - Univ	228-9566
7F-9541	Pin As - Drawbar	296-1361
7F-9547	Pin As - Drawbar	295-0414
7G-6044	Cage As	216-7857
7H-0602	Dog - Clutch	314-8515
7H-1318	Coupling - Steering	226-8002
7H-2424	Sleeve - Spring	226-4852
7M-2167	Ring - Governor Control	308-9919
7M-4603	Body - Fuel Valve	311-9348
7M-4926	Retainer - Pin	314-8538
7M-5002	Drum - Steering	226-7992
7M-5050	Collar - Front Idler	226-4958
7M-9398	Plate - Guide	297-7230
7N-0110	Core As - Oil Cooler	319-3435
7N-0128	Core As - Oil Cooler	299-1994
7N-0165	Core As - Oil Cooler	295-5670
7N-2871	Line As - Fuel Injector	319-8172
7N-2872	Line As - Fuel Injector	319-8173
7N-2874	Line As - Fuel Injector	298-2779
7N-2875	Line As - Fuel Injector	298-2780
7N-2876	Line As - Fuel Injector	298-2781
7N-2949	Pulley	264-5887
7N-3486	Manifold - Exhaust	261-0899
7N-3515	Gear - Camshaft	314-8669
7N-3536	Gear - Fuel	279-4993
7N-5511	Gear As - Idler	233-2180
7N-5810	Gear As - Idler	233-2179
7N-5815	Gear - Camshaft Rr	233-2181
7N-5819	Gear - Hyd Pump Drive	215-1758
7N-5825	Gear - Drive	215-1759
7N-5910	Impeller - Pump	314-8686
7N-9145	Gear - Flywheel	279-4994
7N-9146	Gear - Flywheel Starter	279-4995
7N-9312	Damper As - Camshaft	299-2005
7N-9805	Pin - Piston	295-6438
7S-0706	Shoe -Track	175-8673
7S-3161	Lifter - Valve	279-4996
7S-6537	Guard As - Rh Basic	226-4941
7S-6538	Guard As - Lh Basic	226-4942
7S-6723	Bracket - Alternator	299-1978
7S-7602	Pump Gp	226-0174
7S-7625	Support As	226-6095
7S-7809	Cap As - Radiator	295-6417
7S-8213	Guard As - Final Drive Wear	226-4943
7S-8214	Guard As - Final Drive Wear	226-4944
7S-8443	Muffler	247-2675

(Continued)

Sales Model D6 (Continued)

Original Part Number	Part Name	Classic Part Number
7S-9567	Shoe -Track	175-8022
7T-0204	Bearing - Brace	247-4126
7T-0206	Bearing - Brace	297-7144
7W-0450	Gear - Water Pump	279-4997
7W-0507	Gear - Oil Pump Drive	279-4998
7W-0508	Gear - Fuel Pump Drive	296-1351
7W-5687	Hub - Camshaft	314-8684
8B-5972	Bearing - Ball	314-8503
8F-8858	Button Valve	314-8511
8H-1993	Valve - Inlet	256-4765 (Valve Kit)
8H-1994	Valve - Exhaust	256-4765 (Valve Kit)
8H-2434	Drum - Steering	216-7862
8H-2810	Case As - Filter	314-8512
8H-9379	Nut - Brake Band Adjustable	299-2029
8H-9806	Gear - Shaft Drive	325-6091
8L-4529	Pulley - Alternator	264-5889
8M-0874	Plunger As - Valve	311-9439
8M-6676	Cylinder - Adjustable	226-4960
8N-0002	Trunnion As	314-8728
8N-0875	Valve - Exhaust	247-6893 (Valve), 241-3381 (Valve Kit)

Original Part Number	Part Name	Classic Part Number
8N-1187	Head Gp - Cylinder	242-3435
8N-1721	Rod As - Conn	269-5291
8N-1984	Rod As - Conn	242-3441
8N-2510	Shaft	325-6208
8N-2641	Sleeve	325-6210
8N-3181	Piston Gp - Basic	250-6555 (Liner Kit)
8N-3251	Shaft As - Rocker Arm	314-8711
8N-3325	Arm Gp - Rocker	314-8623
8N-3327	Arm Gp - Rocker	314-8624
8N-5929	Cover - Water Pump	296-1349
8N-6796	Head Gp - Cylinder	269-5290
8N-7315	Tube As - Outlet	325-6232
8N-7780	Shield - Oil	314-8544
8N-8225	Bearing - Main	314-8652
8N-9733	Line As - Fuel Injector	319-8174
8P-1182	Shaft	227-4771
8P-1183	Gear - Bevel	226-7980
8S-0248	Breather As	325-6033
8S-0493	Shaft As - Pump	325-6198
8S-2560	Idler Gp, Idler As.	200-9235 (Complete Idler Group), 175-8255 (Idler As.)
8S-3970	Chamber As	242-3438
8S-5722	Plate - Pressure	226-8009

Original Part Number	Part Name	Classic Part Number
8S-7716	Manifold - Exhaust	295-0415
8S-7717	Manifold - Exhaust	261-0894
8S-7718	Manifold - Exhaust	295-0416
9F-7101	Bushing - Collar	299-1988
9G-8302	Guide	226-4853
9H-2256	Pump Gp	311-9443
9H-4104	Pilot - Spring	226-4962
9H-7670	Piston	226-4961
9J-9598	Pin	296-1362
9M-3025	Cover As	299-2001
9M-4789	Shaft - Gov Control	297-7256
9M-8117	Shaft - Flywheel Clutch	226-6073
9M-8119	Retainer - Inlet	226-8022
9N-5251	Piston Gp - Basic	250-6557 (Liner Kit)
9N-5404	Piston Gp - Basic	250-6558 (Liner Kit)
9N-5769	Cover - Housing	325-6050
9S-2354	Manifold - Exhaust	261-0888
9S-2355	Manifold - Exhaust	261-0891
9S-3321	Cage - Pinion Bearing	226-7974
9S-6129	Pulley - Alternator Drive	264-5891
9S-8493	Bolt - Connecting Rod	311-9351
9S-8679	Chamber As	325-6042
9W-1677	Bearing	297-7145
9Y-9431	Precleaner As	361-1718

Sales Model D6B

Original Part Number	Part Name	Classic Part Number
121-7746	Precleaner As	360-2311
190-8609	Valve - Fill	360-2288
1A-2846	Cap As - Filler	311-9368
1H-8262	Shaft	226-8016
1H-8382	Gear - Oil Pump Drive	226-6103
1H-8937	Drumbrake	226-7993

Original Part Number	Part Name	Classic Part Number
1H-8938	Lever	226-8028
1M-0176	Flange - Drum	223-4810
1M-5165	Pinion - Final Drive	231-8766
1M-5270	Pipe - Extension	367-6065
1M-6128	Manifold - Exhaust	261-0906

Original Part Number	Part Name	Classic Part Number
1M-7250	Bowl - Precleaner	360-2296
1M-9177	Flywheel	226-6112
1P-1931	Shaft - Steer	227-4772
1P-7044	Cage	226-7975
1P-9024	Spring - Equalizer	231-3311

(Continued)

Sales Model D6B (Continued)

Original Part Number	Part Name	Classic Part Number
1S-1888	Bracket - Lamp	297-7147
1S-5315	Cap As - Brace Bearing	226-4848
1S-6422	Pilot As - Spring	226-4849
1S-8764	Ring - Flywheel Clutch Adjustable	226-8014
1W-4405	Gear - Crankshaft	279-4982
2F-5721	Bearing - Ball	311-9354
2F-7576	Shaft - Sprocket	226-6071
2F-7577	Shaft	226-6072
2H-4338	Plate - Pressure	226-8010
2H-4450	Washer - Thrust	325-6237
2H-4482	Collar	229-8218
2H-5046	Link - Flycam	299-2024
2J-8489	Bearing - Sleeve	295-5691
2K-4507	Bearing - Sleeve	325-6021
2M-2290	Bracket - Ring	299-1979
2M-2415	Guard-idler - Rh	226-4931
2M-2416	Guard-idler - Lh	226-4933
2M-2417	Guard-spring - Rh	226-4934
2M-2418	Guard-spring - Lh	226-4935
2M-4668	Retainer - Guard	297-4867
2P-7622	Bolt - Spring	226-4850
2P-9660	Gear - Final Drive	226-5995
2S-1477	Holder As - Cage	226-7985
2S-4015	Plunger As - Valve	311-9438
2S-8277	Guard Gp - Spring	226-4936
2S-8278	Guard Gp - Spring	226-4937
3B-6218	Muffler As	247-2672
3F-1956	Cap - Frame Sup	226-7987
3F-1972	Retainer As	226-7988
3F-6185	Pin	295-5694
3F-6446	Pivot - Push Pole	256-4827
3F-6523	Pin - Clevis	256-4818
3F-6561	Arm As - Brace	256-4828
3F-6611	Socket - Joint	256-4829
3F-6612	Cap - Ball Joint	297-7155
3H-3378	Gear As - Pump	298-2795
3J-6559	Cap - Bearing	296-1346
3K-3124	Muffler - Trap	247-2673
3P-3623	Lock - Adjustable Nut	226-7989
3P-5754	Hub - Gear	219-2976
3S-0311	Rod Gp	226-4953
3S-7153	Gear - Sliding	227-0024
3S-8634	Hub - Gear	219-2977
3S-8800	Gear - Driven	325-6090
3V-1133	Strip	226-0203
4F-1252	Pin	295-5704
4F-4974	Clamp	311-9373
4H-4021	Plate As - Loading	229-8219
4H-9040	Nut	226-7996
4J-2414	Trunnion	296-1370
4J-3583	Screw - Adjusting	297-7242
4J-6374	Bearing - Sleeve	295-6407
4K-4780	Strip As - Wear	299-2063
4K-7386	Plate - Guide	226-4851
4S-6559	Tube	325-6234
4S-8005	Pinion - Final Drive	226-6076
5A-4003	Shaft - Sprocket	229-8228
5A-9551	Gear - Final Drive	226-7979
5F-0689	Pin	256-4821
5F-0706	Pin	256-4822
5F-0707	Collar	256-4831
5F-0736	Pin - Pivot	256-4823
5F-2256	Cage - Bearing	226-7973
5H-5500	Collar - Flywheel	302-2704
5M-5244	Hub - Gear	219-2982
5P-7807	Bearing - Ball	314-8502
5S-0726	Hub As - Sprocket	227-4769
5S-1211	Cover - Valve	314-8665
5S-1822	Chamber As	248-5406
5S-1833	Chamber As	247-3298
5S-6513	Guard As - Roller	226-4938
6B-7178	Fork - Band Adjustable	299-2009
6F-3183	Cap - Bearing	325-6038
6H-3957	Bearing - Ball	311-9358
6J-0800	Bearing	297-7140
6P-0169	Hub - Flywheel Clutch	297-7204
7B-2420	Ferrule - Director	314-8517
7B-5088	Drum - Steering	223-4813
7F-9547	Pin As - Drawbar	295-0414
7G-6044	Cage As	216-7857
7H-1318	Coupling - Steering	226-8002
7H-2424	Sleeve - Spring	226-4852
7H-4710	Bushing - Sleeve	299-1990
7M-0820	Gear - Sliding	226-6086
7M-2167	Ring - Governor Control	308-9919
7M-4204	Manifold - Exhaust	261-0901
7M-4603	Body - Fuel Valve	311-9348
7M-5002	Drum - Steering	226-7992
7M-5050	Collar - Front Idler	226-4958
7M-7358	Valve - Inlet	298-2774
7M-9398	Plate - Guide	297-7230
7N-0128	Core As - Oil Cooler	299-1994
7N-2957	Cover - Rad Cap	361-1722
7N-9146	Gear - Flywheel Starter	279-4995
7S-6531	Guard As - Rh	226-4939
7S-6532	Guard As - Lh	226-4940
7S-6537	Guard As - Rh Basic	226-4941
7S-6538	Guard As - Lh Basic	226-4942

(Continued)

Sales Model D6B (Continued)

Original Part Number	Part Name	Classic Part Number
7S-7602	Pump Gp	226-0174
7S-7625	Support As	226-6095
7S-7809	Cap As - Radiator	295-6417
7S-8213	Guard As - Final Drive Wear	226-4943
7S-8214	Guard As - Final Drive Wear	226-4944
7S-9749	Pulley - Gen Drive	264-5888
7T-0203	Guide	226-4959
7T-0206	Bearing - Brace	297-7144
7T-2036	Cap As - Filter	361-1721
8H-9379	Nut - Brake Band Adjustable	299-2029
8H-9806	Gear - Shaft Drive	325-6091
8M-3224	Muffler	247-2676
8M-6219	Spring - Equalizer	293-7606
8M-6615	Leaf - Spring	293-7607
8M-6616	Leaf - Spring	293-7608
8M-6676	Cylinder - Adjustable	226-4960
8N-8225	Bearing - Main	314-8652
8P-1182	Shaft	227-4771
8P-1183	Gear - Bevel	226-7980
8P-4111	Guard As	226-4945
8P-4112	Guard As	226-4946
8S-1831	Guard As - Sprocket	226-4947
8S-1832	Guard As - Sprocket	226-4948
8S-5722	Plate - Pressure	226-8009
9F-7101	Bushing - Collar	299-1988
9G-8302	Guide	226-4853
9H-2256	Pump Gp	311-9443
9H-4104	Pilot - Spring	226-4962
9H-7670	Piston	226-4961
9J-9598	Pin	296-1362
9M-4163	Valve - Exhaust	298-2773
9M-4955	Pump Gp - Fuel Transfer	242-3443
9M-8117	Shaft - Flywheel Clutch	226-6073
9M-8119	Retainer - Inlet	226-8022
9S-3321	Cage - Pinion Bearing	226-7974
9S-8245	Strip - Track	226-0243
9S-8246	Strip - Track	226-0244
9S-8257	Guard As - Guiding	226-0238
9S-8258	Guard As - Guiding	226-0239
9S-8353	Strip - Track	226-4854
9S-8354	Strip - Track	226-4855
9S-8358	Guard As - Guiding	226-4856
9S-8359	Guard As - Guiding	226-4857
9W-1677	Bearing	297-7145

Sales Model D6C

Original Part Number	Part Name	Classic Part Number
100-7860	Valve - Inlet	270-4360 (Valve), 270-4362 (Valve Kit)
104-4253	Line As - Fuel Injector	279-4988
104-4254	Line As - Fuel Injector	279-4989
111-8015	Gasket As - Head	279-4977
112-3249	Muffler As	247-2661
118-1614	Roller Gp - SF	175-8035
118-1615	Roller Gp - DF	175-8036
121-7746	Precleaner As	360-2311
122-9405	Bracket As	325-6005
131-3815	Seal Gp - Basic	325-6193
148-7455	Valve - Exhaust	270-4361
160-6305	Cap - Bearing	295-5686
165-4262	Body As - Piston	270-4351
172-5185	Shaft - Water Pump	325-6201
172-5188	Shaft - Water Pump	325-6202
172-5189	Impeller - Pump	295-5687
172-5190	Impeller - Pump	325-6111
172-6712	Impeller - Pump	325-6112
172-7767	Pump Gp - Water	296-1365
190-8609	Valve - Fill	360-2288
196-0028	Gear As - Idler	364-5259
1A-2846	Cap As - Filler	311-9368
1H-8262	Shaft	226-8016
1H-8382	Gear - Oil Pump Drive	226-6103
1H-8937	Drumbrake	226-7993
1H-8938	Lever	226-8028
1M-1663	Collar As - Retain	226-8030
1M-1698	Gear - Sliding	215-1659
1M-1930	Cage - Pinion Bearing	217-7727
1M-1947	Support As	226-6096
1M-5270	Pipe - Extension	367-6065
1M-7250	Bowl - Precleaner	360-2296
1M-9177	Flywheel	226-6112
1M-9444	Retainer - Spring	299-2046
1N-3576	Block Gp - Cylinder	279-4978
1N-3958	Elbow	325-6087
1N-4304	Head Gp - Cylinder	269-8761
1P-0963	Guard As - Roller	226-0179
1P-1605	Gear - Forward	215-1663
1P-1608	Gear - Forward	302-2707
1P-1636	Lever As	226-8013

(Continued)

Sales Model D6C (Continued)

Original Part Number	Part Name	Classic Part Number
1P-1721	Gear - Balance	298-2769
1P-1722	Gear - Balance	298-2770
1P-1897	Gear - Final Drive	215-1670
1P-3759	Rod Gp - Recoil	302-2713
1P-4303	Head As - Cylinder	242-3434
1P-6265	Gear - Bevel	221-9177
1P-6752	Pump Gp	226-0161
1P-7044	Cage	226-7975
1P-8554	Coupling - Exhaust	325-6052
1P-9945	Bracket As - Fan	296-1344
1P-9946	Shaft - Fan	325-6194
1P-9952	Impeller - Pump	314-8685
1S-1888	Bracket - Lamp	297-7147
1S-4701	Pulley - Alt	264-5866
1S-5331	Cylinder - Adjustable	226-0214
1S-8734	Bracket - Roller	226-0212
1S-8764	Ring - Flywheel Clutch Adjustable	226-8014
1T-0300	Converter As	235-1803 (Repair Kit)
1T-0421	Flange As - Output	295-5442
1T-0436	Gear - Pump Drive	247-3367
1T-0437	Housing - Rotating	295-5685
1T-0438	Retainer - Bearing	295-0410
1T-0443	Carrier As - Guide	247-3368
1T-0447	Carrier - Ring	295-0409
1T-0930	Torque Converter	235-0913 (Repair Kit)
1T-1993	Wheel - Turbine	235-0920
1T-2052	Stator As	295-5683
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1695	Pump Gp	279-4980
1W-1698	Housing - Transfer Pump	296-1356
1W-4402	Gear - Camshaft	279-4981
1W-4405	Gear - Crankshaft	279-4982
1W-5912	Tappet As - Guide	325-6223
1W-6541	Plunger As	325-6173
244-1090	Alarm - Back up	360-2345
2B-8824	Drum	216-7817
2F-5721	Bearing - Ball	311-9354
2H-4338	Plate - Pressure	226-8010
2H-4450	Washer - Thrust	325-6237
2H-4482	Collar	229-8218
2H-5046	Link - Flycam	299-2024
2J-5462	Trunnion	297-7264
2J-8489	Bearing - Sleeve	295-5691
2K-4507	Bearing - Sleeve	325-6021
2M-1086	Plate As - Press	226-8023
2M-2290	Bracket - Ring	299-1979
2M-4668	Retainer - Guard	297-4867
2P-1005	Bearing - Sleeve	296-1342
2P-1170	Shaft As - Gear	296-1367
2P-1502	Gear - Shaft	214-0956
2P-1503	Gear - First	213-8637
2P-1738	Plate As - Oil Pan	325-6164
2P-1739	Tube As - Pump	325-6229
2P-1757	Hub - Fan Pulley	296-1357
2P-1781	Spacer - Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2519	Tube As - Inlet	325-6230
2P-2719	Pipe	363-7454
2P-3422	Gear - First Reduction	213-8451
2P-3423	Pinion - Sec Reduction	216-3553
2P-4370	Plate - Clutch	325-6166
2P-6128	Pulley	264-5872
2P-6245	Shaft As - Pump	325-6197
2P-7828	Pan - Oil	314-8691
2P-7984	Yoke As - Idler	226-0220
2S-3188	Plate	299-2041
2S-3443	Drum - Steer	219-9689 (Drum), 230-7113 (Steering Clutch Kit)
2S-3803	Gear	226-6106
2S-3804	Gear - Sliding	226-6107
2S-3966	Ring - Seal	297-7237
2S-4015	Plunger As - Valve	311-9438
2S-4365	Retainer As	216-3554
2S-6263	Guard Gp - Spring	226-0192
2S-6264	Guard Gp - Spring	226-0193
2S-6265	Rod Gp - Recoil	226-0197
2S-6344	Gear - Final Drive	297-7173
2S-6739	Pulley - Tightener	298-2794
2S-7603	Drum	213-6951
2V-7198	Pilot As - Recoil Spring	302-2709
2W-1086	Cover As - Cylinder Head	325-6049
2W-2621	Valve - Inlet	247-6892 (Valve), 241-3381 (Valve Kit)
2W-7255	Shaft - Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear - Water Pump	325-6088
2W-9978	Core As - Oil Cooler	279-4983
3F-1537	Nut - Spanner	226-6098
3F-4971	Pin	295-5693
3F-6149	Pin	299-2033
3F-6185	Pin	295-5694
3F-6523	Pin - Clevis	256-4818
3F-6611	Socket - Joint	256-4829
3F-6612	Cap - Ball Joint	297-7155

(Continued)

Sales Model D6C (Continued)

Original Part Number	Part Name	Classic Part Number
3H-3378	Gear As - Pump	298-2795
3J-2452	Cap - Ball Joint	297-7156
3J-2682	Bracket	296-1345
3J-4284	Cap - Bearing	314-8656
3J-4352	Arm As - Brace	297-7137
3J-5432	Pin - Pivot	361-1711
3J-6559	Cap - Bearing	296-1346
3J-6560	Screw - Adjustable	297-7240
3J-6561	Screw - Adjustable	297-7241
3J-6570	Support - Bearing	299-2069
3J-6573	Screw - Adjusting	302-2714
3J-6575	Trunnion	297-7265
3J-6577	Pin - Brace	367-6077
3K-3124	Muffler - Trap	247-2673
3L-1425	Bearing - Ball	311-9356
3P-3241	Plate - Pressure	325-6167
3P-3623	Lock - Adjustable Nut	226-7989
3P-3935	Shaft	299-2053
3P-6318	Flange - Drum	213-8165
3P-6814	Pump Gp	226-0163
3P-6816	Pump Gp	226-0164
3P-7640	Gear - Ctrshft	325-6093
3P-7641	Gear - Ctrshft	325-6094
3P-7642	Gear - Ctrshft	302-2668
3P-7643	Gear - Pinion Shft	302-2669
3P-7644	Gear - Pinion Shft	302-2706
3S-1691	Disc - Steering	302-2705
3S-8800	Gear - Driven	325-6090
3T-1898	Drum	219-9674
3T-1899	Drum	219-9690 (Drum), 230-7114 (Steering Clutch Kit)
3V-1133	Strip	226-0203
4F-1121	Bracket	299-1981
4F-1252	Pin	295-5704
4F-4974	Clamp	311-9373
4H-4021	Plate As - Loading	229-8219
4J-1612	Pin	308-9896
4J-1614	Pin - Pivot	297-7214
4J-1616	Bracket	299-1982
4J-1999	Ballstud	314-8625
4J-2414	Trunnion	296-1370
4J-2585	Pin	299-2034
4J-2590	Bearing	299-1958
4J-2847	Trunnion As	297-7267
4J-3583	Screw - Adjusting	297-7242
4J-3589	Cap - Ball Joint	297-7157
4J-3590	Bearing	297-7139
4J-3591	Bracket - Rh	299-1983
4J-6374	Bearing - Sleeve	295-6407
4K-0255	Retainer As	226-6102
4K-4780	Strip As - Wear	299-2063
4K-5074	Pinion	215-1683
4K-5086	Yoke	215-1684
4K-5109	Gear - Reverse	219-9659
4M-0503	Gear As - Oil Pump	297-7184
4N-2954	Sleeve - Camshaft	299-2059
4N-3281	Line As - Fuel Injector	247-3362
4N-3282	Line As - Fuel Injector	247-3363
4N-3283	Line As - Fuel Injector	247-3364
4N-3284	Line As - Fuel Injector	247-3365
4N-4539	Sleeve	314-8720
4N-4782	Pulley	325-6176
4N-4864	Pump Gp - Fuel Transfer	242-3442
4N-7526	Seal As - Pump	311-9454
4N-7692	Crankshaft As	242-3440
4N-7693	Crankshaft As	242-3439
4N-7977	Shaft As - Balance	314-8709
4N-7978	Shaft As - Balance	314-8710
4N-8591	Coupling - Exhaust	325-6053
4N-8814	Line As - Fuel Injector	247-3366
4N-9180	Seal As - Pump	311-9455
4N-9587	Shield - Heat	297-7260
4P-0660	Muffler As	298-2787
4P-3546	Valve As - Relief	325-6236
4P-9381	Line As - Fuel Injector	279-4984
4P-9382	Line As - Fuel Injector	279-4985
4P-9385	Line As - Fuel Injector	279-4986
4P-9386	Line As - Fuel Injector	279-4987
4S-5049	Guard As - Rh	226-0183
4S-5050	Guard As - Lh	226-0184
4S-6256	Nut - Bearing Adjustable	235-8008
4S-8472	Hood As	296-1355
4S-8708	Housing - Clutch	216-3557
4S-8718	Cage - Carrier Bearing	217-7724
4S-9062	Cap - Final Drive Bearing	226-0204
4T-6151	Trunnion	295-5671
4V-2744	Gear	224-1303
4V-3396	Hub - Gear	222-1763
4V-6156	Saddle As	299-2052
4W-0452	Seal As - Camshaft	325-6191
4W-9771	Gear - Crankshaft	302-2674
4W-9989	Gear As - Idler	302-2677
5A-7840	Shaft - Track Sprocket	215-1687
5A-7841	Hub - Gear	219-2966
5G-3612	Cap Gp	295-6419
5H-5500	Collar - Flywheel	302-2704
5K-6090	Flange	216-7844
5M-5073	Joint Gp - Univ	325-6113
5M-5822	Gear - Pump Drive	247-4120
5M-6120	Gear - Sun	213-8740
5M-6198	Shaft - Planet	297-7245
5M-6199	Shaft As - Planet	215-1694
5M-6208	Gear - Ring	247-4121
5M-6210	Shaft - Planet	219-9683
5M-6211	Shaft - Planet	219-9684

(Continued)

Sales Model D6C (Continued)

Original Part Number	Part Name	Classic Part Number
5M-6636	Support - Frame	235-8007
5M-6651	Hub - Gear	211-2135
5M-6670	Shaft - Sprocket	216-7847
5M-6690	Hub - Steering	215-1695
5M-7290	Cage - Bearing	216-7848
5M-7336	Retainer - Washer	325-6181
5M-7340	Cage - Bearing	325-6034
5M-7342	Flange - Shaft	215-1696
5M-7344	Gear - Bevel	213-8741
5M-7345	Gear - Bevel	214-0957
5M-7346	Gear - Bevel	214-0958
5M-7348	Gear - Bevel	215-1699
5M-7349	Gear - Bevel	213-8742
5M-7352	Gear - Bevel	217-7713
5M-7353	Gear - Bevel	217-7714
5M-7355	Gear - Reverse	216-3581
5M-7740	Gear - Bevel	213-8216
5M-7841	Gear - Ring	214-0525
5M-7864	Pump Gp - Scavenge	226-0169
5M-7869	Gear - Ring	214-0530
5M-7875	Carrier - Front	213-4495
5M-7882	Joint Gp - Univ	297-7210
5M-7900	Bolt - Hex Head	311-9349
5M-7923	Shaft - Output	215-1697
5P-7807	Bearing - Ball	314-8502
5S-0073	Plate - Steering	302-2692
5S-0192	Pinion - Final Drive	215-1698
5S-1211	Cover - Valve	314-8665
5S-1822	Chamber As	248-5406
5S-1833	Chamber As	247-3298
5S-4557	Bearing	311-9360
5S-6531	Holder As - Cage	214-2078
5S-6795	Chamber As	242-3437
5S-7609	Pulley - Alt Drive	264-5881
5S-9062	Spacer	363-7463
5S-9080	Pulley - Alt Drive	264-5883
6F-2904	Bearing	295-5673
6F-3183	Cap - Bearing	325-6038
6H-3957	Bearing - Ball	311-9358
6I-1346	Pump Gp - Oil	295-5674
6I-8132	Pinion	226-6080
6J-0774	Trunnion	256-4844
6K-4617	Shaft - Sprocket	221-7951
6L-9210	Idler Gp (Complete Idler Group)	175-8038 (Idler As.), 200-9236
6N-1036	Gear - Oil Pump	279-4991
6N-1965	Line As - Fuel Injector	250-7535
6N-1966	Line As - Fuel Injector	250-7536
6N-2789	Pulley	264-5886
6N-3256	Mount As	314-8688
6N-8413	Housing - Pump	325-6110
6P-0169	Hub - Flywheel Clutch	297-7204
6T-0956	Pad As	367-6088
6W-0240	Bearing - Brace	297-7143
6Y-0710	Gear	226-6104
7B-2420	Ferrule - Director	314-8517
7C-4297	Seal As - Camshaft	325-6192
7F-9541	Pin As - Drawbar	296-1361
7F-9547	Pin As - Drawbar	295-0414
7G-1013	Pump Gp	226-0170
7G-2474	Gear - Planet	300-2577
7G-2475	Gear - Planet	223-4815
7G-2476	Gear - Planet	223-4816
7G-2513	Gear - Planet	215-1734
7G-5323	Pinion - Final Drive	231-8767
7G-6042	Cage As	216-7856
7G-8513	Guard As	361-1714
7G-8517	Guard As	361-1715
7H-2742	Nut	229-8220
7J-6461	Crown	325-6054
7J-9344	Bearing - Sleeve	360-2334
7J-9842	Bearing - Sleeve	299-1968
7J-9884	Bearing - Sleeve	325-6016
7K-3582	Nut - Adjusting	226-6099
7K-4458	Gear - Final Drive	226-6093
7K-4512	Pinion - Final Drive	226-6081
7K-4770	Pinion	226-6082
7K-4771	Gear	229-8221
7K-8237	Drum	226-6100
7K-8238	Flange	213-8166
7M-0457	Guard - Frame	226-0217
7M-0665	Bar As - Equalizer	231-3312
7M-0699	Cap - Brace Bearing	247-4123
7M-0859	Fork As - Shift	297-7172
7M-1776	Plate - Idler Guide	226-0222
7M-1851	Bolt - Spring	226-0223
7M-1856	Pilot - Recoil Spring	226-0225
7M-1859	Pilot As - Spring	226-0207
7M-1861	Stop - Spring Rh	226-0228
7M-1862	Stop - Spring Lh	226-0229
7M-2167	Ring - Governor Control	308-9919
7M-2531	Rod - Tie	297-7239
7M-4204	Manifold - Exhaust	261-0901
7M-4603	Body - Fuel Valve	311-9348
7M-7358	Valve - Inlet	298-2774
7N-0128	Core As - Oil Cooler	299-1994
7N-0165	Core As - Oil Cooler	295-5670
7N-2871	Line As - Fuel Injector	319-8172
7N-2872	Line As - Fuel Injector	319-8173
7N-2874	Line As - Fuel Injector	298-2779
7N-2875	Line As - Fuel Injector	298-2780
7N-2876	Line As - Fuel Injector	298-2781
7N-2949	Pulley	264-5887

(Continued)

Sales Model D6C (Continued)

Original Part Number	Part Name	Classic Part Number
7N-2957	Cover - Rad Cap	361-1722
7N-3486	Manifold - Exhaust	261-0899
7N-3515	Gear - Camshaft	314-8669
7N-3536	Gear - Fuel	279-4993
7N-5503	Gear - Camshaft Rr	233-2182
7N-5511	Gear As - Idler	233-2180
7N-5910	Impeller - Pump	314-8686
7N-6677	Core As - Oil Cooler	299-1995
7N-9146	Gear - Flywheel Starter	279-4995
7N-9312	Damper As - Camshaft	299-2005
7N-9805	Pin - Piston	295-6438
7S-3161	Lifter - Valve	279-4996
7S-6723	Bracket - Alternator	299-1978
7S-7602	Pump Gp	226-0174
7S-7809	Cap As - Radiator	295-6417
7S-8443	Muffler	247-2675
7S-9749	Pulley - Gen Drive	264-5888
7T-0205	Bearing - Brace	247-4127
7T-2036	Cap As - Filter	361-1721
7T-4562	Idler As	175-8263
7T-9931	Countershaft	215-1760
7T-9963	Case As - Transfer Gear	219-9665
7V-5249	Shaft - Steering	215-1761
7W-0450	Gear - Water Pump	279-4997
7W-0507	Gear - Oil Pump Drive	279-4998
7W-0508	Gear - Fuel Pump Drive	296-1351
7W-5687	Hub - Camshaft	314-8684
8E-5993	Gear As - Idler	215-1903
8H-1174	Drum - Steering	226-6101 (Drum), 231-1937 (Steering Clutch Kit)
8H-2810	Case As - Filter	314-8512
8H-7980	Piston	226-0249
8H-9806	Gear - Shaft Drive	325-6091
8J-2652	Shaft	299-2054
8J-2653	Lever As	299-2015
8J-2654	Lever As	299-2016
8K-9661	Gear - Bevel	213-8218
8M-0874	Plunger As - Valve	311-9439
8M-3224	Muffler	247-2676
8M-6191	Sleeve - Bolt	226-0234
8M-6676	Cylinder - Adjustable	226-4960
8M-7166	Housing - Screen	297-7192
8M-7207	Guard As - Rh	226-0236
8M-7208	Guard As - Frame	226-0237
8M-8619	Cage - Bearing	217-7725
8M-8623	Gear - Sun	213-8755
8M-8628	Flange - Joint	217-9776
8M-8642	Housing - Clutch	219-9669
8M-8644	Housing - Clutch	215-1782
8M-8646	Plate As - Center	216-3583
8M-8649	Piston - Clutch	217-9777
8M-8650	Piston - Clutch	217-9778
8M-8652	Shaft	297-7252
8M-8677	Carrier - Planet	213-4449
8N-0002	Trunnion As	314-8728
8N-0875	Valve - Exhaust	247-6893 (Valve), 241-3381 (Valve Kit)
8N-1187	Head Gp - Cylinder	242-3435
8N-1188	Head Gp - Cylinder	242-3436
8N-1721	Rod As - Conn	269-5291
8N-1984	Rod As - Conn	242-3441
8N-2510	Shaft	325-6208
8N-2641	Sleeve	325-6210
8N-3180	Body As - Piston	250-6563
8N-3181	Piston Gp - Basic	250-6555 (Liner Kit)
8N-3182	Body As - Piston	250-6564 (Piston As), 250-6556 (Liner Kits)
8N-3183	Piston Gp - Basic	250-6556 (Liner Kit)
8N-3251	Shaft As - Rocker Arm	314-8711
8N-3311	Shaft As - Rocker Arm	325-6199
8N-3312	Shaft As - Rocker Arm	325-6200
8N-3325	Arm Gp - Rocker	314-8623
8N-3327	Arm Gp - Rocker	314-8624
8N-5305	Spacer	363-7464
8N-5929	Cover - Water Pump	296-1349
8N-6796	Head Gp - Cylinder	269-5290
8N-7315	Tube As - Outlet	325-6232
8N-8225	Bearing - Main	314-8652
8N-9733	Line As - Fuel Injector	319-8174
8P-0605	Gear - First Reduction	213-8453
8P-0606	Pinion - Sec Reduction	215-1783
8P-1851	Hub As - Sprocket	224-1314
8P-5197	Bearing As	295-6413
8P-6495	Drum	213-6954 (Drum), 227-9302 (Steering Clutch Kit)
8P-6803	Shaft As	215-1842
8P-7790	Valve Gp - Press	247-4437
8S-0248	Breather As	325-6033
8S-0493	Shaft As - Pump	325-6198
8S-0569	Gear - Transfer	213-8754
8S-0573	Gear - Transfer	215-1844
8S-3970	Chamber As	242-3438

(Continued)

Sales Model D6C (Continued)

Original Part Number	Part Name	Classic Part Number
9F-7101	Bushing - Collar	299-1988
9G-8303	Collar - Idler End	226-0242
9H-2256	Pump Gp	311-9443
9H-6980	Shaft - Pinion	226-6110
9H-7670	Piston	226-4961
9J-2332	Bearing - Pivot	299-1969
9J-8427	Bracket	299-1984
9J-9147	Nut	299-2028
9J-9598	Pin	296-1362
9K-0424	Shaft - Pinion	215-1874
9K-6842	Cage As	216-7872
9K-9271	Holder As - Cage	217-7730
9K-9273	Nut - Adjusting	226-7998
9M-0701	Piston - Steer	219-9692
9M-0702	Pilot - Piston	229-8232
9M-1500	Shaft - Planet	219-9685
9M-1502	Cage - Bearing	219-9686
9M-1995	Gear - Sun	213-8756
9M-1996	Shaft - Planet	215-1875
9M-2013	Housing As	216-3585
9M-2028	Gear - Sun	214-0959
9M-2038	Gear - Transfer Driven	215-1876
9M-2039	Gear - Transfer Driving	219-9672
9M-2045	Pinion - Bevel	215-1878
9M-2049	Gear - Ring	214-0533
9M-3025	Cover As	299-2001
9M-4163	Valve - Exhaust	298-2773
9M-4789	Shaft - Gov Control	297-7256
9M-4955	Pump Gp - Fuel Transfer	242-3443
9M-5045	Guard As - Wear	213-9111
9M-8117	Shaft - Flywheel Clutch	226-6073
9M-8119	Retainer - Inlet	226-8022
9N-5769	Cover - Housing	325-6050
9P-0418	Cage	223-6311
9P-0620	Cage - Pinion Bearing	221-1052
9P-5363	Piston - Clutch	219-9687
9P-5379	Housing - Clutch	215-1904
9P-9000	Shaft - Steering	217-7738
9P-9360	Gear - First Reduction	213-8454
9P-9361	Gear - Final Drive	223-4809
9P-9362	Pinion - Final Drive	215-1944
9P-9363	Pinion - Reduction	219-9677
9P-9575	Cage - Bevel Gr Bearing	216-7876
9S-2354	Manifold - Exhaust	261-0888
9S-2355	Manifold - Exhaust	261-0891
9S-2356	Manifold - Exhaust	261-0905
9S-5265	Shaft As	215-1945
9S-6129	Pulley - Alternator Drive	264-5891
9S-6590	Pump Gp - Oil	226-0176
9S-8245	Strip - Track	226-0243
9S-8246	Strip - Track	226-0244
9S-8251	Guard As - Roller	226-0180
9S-8252	Guard As - Roller	226-0181
9S-8253	Guard As - Roller	226-0182
9S-8257	Guard As - Guiding	226-0238
9S-8258	Guard As - Guiding	226-0239
9S-8679	Chamber As	325-6042
9S-8789	Plate - Clutch	302-2712
9S-9385	Gear As - Oil Pump	297-7185
9T-4761	Head	325-6108
9W-0318	Spacer	325-6218
9W-0550	Shaft - Transmission Upper	226-6000
9W-0552	Shaft - Pinion	226-6001
9W-1677	Bearing	297-7145
9Y-2992	Bearing - Sleeve	325-6032

Sales Model D6D

Original Part Number	Part Name	Classic Part Number
0T-0259	Nut - Bearing Sleeve	311-9431
100-7860	Valve - Inlet	270-4360 (Valve), 270-4362 (Valve Kit)
104-4253	Line As - Fuel Injector	279-4988
104-4254	Line As - Fuel Injector	279-4989
111-8015	Gasket As - Head	279-4977
112-3249	Muffler As	247-2661
112-5585	Shaft - Planet	308-9932
112-8041	Carrier - Planet	295-5681
117-1616	Segment Gp - Sprocket	260-5851 (sprocket group)
118-1617	Roller Gp - SF	188-5272
118-1618	Roller Gp - DF	188-5271
121-7583	Gear - Planet	364-5257
122-9405	Bracket As	325-6005
129-2339	Spider	308-9936
131-3815	Seal Gp - Basic	325-6193
131-7736	Support As - Engine	325-6222
148-7455	Valve - Exhaust	270-4361
160-6305	Cap - Bearing	295-5686
167-8123	Damper As	299-2006
172-5185	Shaft - Water Pump	325-6201
172-5188	Shaft - Water Pump	325-6202
172-5189	Impeller - Pump	295-5687

(Continued)

Sales Model D6D (Continued)

Original Part Number	Part Name	Classic Part Number
172-5190	Impeller - Pump	325-6111
172-6712	Impeller - Pump	325-6112
172-7767	Pump Gp - Water	296-1365
190-8609	Valve - Fill	360-2288
196-0028	Gear As - Idler	364-5259
1A-2846	Cap As - Filler	311-9368
1F-2254	Bushing - Stem	314-8510
1F-4419	Gasket - Cover	311-9393
1H-8262	Shaft	226-8016
1H-8382	Gear - Oil Pump Drive	226-6103
1H-8937	Drumbrake	226-7993
1M-9177	Flywheel	226-6112
1M-9444	Retainer - Spring	299-2046
1N-3576	Block Gp - Cylinder	279-4978
1N-3958	Elbow	325-6087
1P-0963	Guard As - Roller	226-0179
1P-1605	Gear - Forward	215-1663
1P-1608	Gear - Forward	302-2707
1P-1636	Lever As	226-8013
1P-1897	Gear - Final Drive	215-1670
1P-3759	Rod Gp - Recoil	302-2713
1P-6265	Gear - Bevel	221-9177
1P-6752	Pump Gp	226-0161
1P-7044	Cage	226-7975
1P-8554	Coupling - Exhaust	325-6052
1P-9945	Bracket As - Fan	296-1344
1P-9946	Shaft - Fan	325-6194
1P-9952	Impeller - Pump	314-8685
1S-1859	Bolt - Track	188-5633
1S-1888	Bracket - Lamp	297-7147
1S-4701	Pulley - Alt	264-5866
1S-5331	Cylinder - Adjustable	226-0214
1S-8734	Bracket - Roller	226-0212
1S-8764	Ring - Flywheel Clutch Adjustable	226-8014
1T-0300	Converter As	235-1803 (Repair Kit)
1T-0421	Flange As - Output	295-5442
1T-0436	Gear - Pump Drive	247-3367
1T-0437	Housing - Rotating	295-5685
1T-0438	Retainer - Bearing	295-0410
1T-0443	Carrier As - Guide	247-3368
1T-0447	Carrier - Ring	295-0409
1T-0930	Torque Converter	235-0913 (Repair Kit)
1T-1993	Wheel - Turbine	235-0920
1T-2052	Stator As	295-5683
1V-8604	Gear - Ring	308-9853
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1695	Pump Gp	279-4980
1W-1698	Housing - Transfer Pump	296-1356
1W-1766	Muffler As	298-2783
1W-4402	Gear - Camshaft	279-4981
1W-4405	Gear - Crankshaft	279-4982
1W-5912	Tappet As - Guide	325-6223
1W-6541	Plunger As	325-6173
236-9861	Link As	175-8555
236-9864	Link As	188-5527
236-9866	Link As.	188-5588
238-9951	Link As	290-6589
244-1090	Alarm - Back up	360-2345
2D-5658	Bearing - Ball	301-4628
2D-9130	Washer - Thrust	308-9943
2F-5721	Bearing - Ball	311-9354
2G-8872	Shaft - Bevel	275-5271
2H-4338	Plate - Pressure	226-8010
2H-4450	Washer - Thrust	325-6237
2H-4482	Collar	229-8218
2H-5046	Link - Flycam	299-2024
2J-5462	Trunnion	297-7264
2J-5596	Pin - Pivot	297-7211
2J-8489	Bearing - Sleeve	295-5691
2K-3592	Boss	314-8501
2K-4507	Bearing - Sleeve	325-6021
2M-2290	Bracket - Ring	299-1979
2M-4668	Retainer - Guard	297-4867
2P-1005	Bearing - Sleeve	296-1342
2P-1170	Shaft As - Gear	296-1367
2P-1438	Pipe - Exhaust Ext	325-6157
2P-1502	Gear - Shaft	214-0956
2P-1503	Gear - First	213-8637
2P-1738	Plate As - Oil Pan	325-6164
2P-1739	Tube As - Pump	325-6229
2P-1757	Hub - Fan Pulley	296-1357
2P-1781	Spacer - Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2519	Tube As - Inlet	325-6230
2P-2719	Pipe	363-7454
2P-2744	Muffler As	247-2664
2P-3422	Gear - First Reduction	213-8451
2P-3423	Pinion - Sec Reduction	216-3553
2P-3424	Gear - First Reduction	215-1675
2P-3425	Pinion - Sec Reduction	217-7697
2P-4370	Plate - Clutch	325-6166
2P-4611	Pipe - Exhaust	365-8821
2P-5608	Pipe - Extension	367-6066
2P-5680	Turbine - Converter	308-9942

(Continued)

Sales Model D6D (Continued)

Original Part Number	Part Name	Classic Part Number
2P-5693	Housing - Rotating	308-9866
2P-6128	Pulley	264-5872
2P-6245	Shaft As - Pump	325-6197
2P-7984	Yoke As - Idler	226-0220
2S-3188	Plate	299-2041
2S-3443	Drum - Steer	219-9689 (Drum), 230-7113 (Steering Clutch Kit)
2S-3803	Gear	226-6106
2S-3804	Gear - Sliding	226-6107
2S-4365	Retainer As	216-3554
2S-6263	Guard Gp - Spring	226-0192
2S-6264	Guard Gp - Spring	226-0193
2S-6265	Rod Gp - Recoil	226-0197
2S-6344	Gear - Final Drive	297-7173
2S-6739	Pulley - Tightener	298-2794
2S-7596	Retainer	215-1679
2S-7603	Drum	213-6951
2V-7170	Yoke	308-9948
2V-7393	Retainer	308-9914
2W-1086	Cover As - Cylinder Head	325-6049
2W-2621	Valve - Inlet	247-6892 (Valve), 241-3381 (Valve Kit)
2W-6757	Trunnion As	295-5678
2W-7255	Shaft - Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear - Water Pump	325-6088
2W-9978	Core As - Oil Cooler	279-4983
2Y-4213	Pulley	314-8703
3F-4971	Pin	295-5693
3F-6149	Pin	299-2033
3F-6185	Pin	295-5694
3F-6612	Cap - Ball Joint	297-7155
3F-7445	Bearing - Sleeve	314-8508
3J-2452	Cap - Ball Joint	297-7156
3J-2682	Bracket	296-1345
3J-4284	Cap - Bearing	314-8656
3J-4352	Arm As - Brace	297-7137
3J-5432	Pin - Pivot	361-1711
3J-6559	Cap - Bearing	296-1346
3J-6560	Screw - Adjustable	297-7240
3J-6561	Screw - Adjustable	297-7241
3J-6570	Support - Bearing	299-2069
3J-6573	Screw - Adjusting	302-2714
3J-6575	Trunnion	297-7265
3J-6577	Pin - Brace	367-6077
3K-2230	Gear - Planet	219-9658
3L-1425	Bearing - Ball	311-9356
3P-2685	Piston - Clutch	308-9908
3P-2768	Piston - Clutch	308-9909
3P-3059	Gear - Sun	308-9861
3P-3060	Gear - Sun	308-9862
3P-3096	Gear - Sun	308-9863
3P-3241	Plate - Pressure	325-6167
3P-3242	Shaft - Planet	308-9923
3P-3245	Shaft - Planet	308-9924
3P-3246	Shaft - Planet	308-9925
3P-3623	Lock - Adjustable Nut	226-7989
3P-3935	Shaft	299-2053
3P-6318	Flange - Drum	213-8165
3P-6814	Pump Gp	226-0163
3P-6816	Pump Gp	226-0164
3P-7640	Gear - Ctrshft	325-6093
3P-7641	Gear - Ctrshft	325-6094
3P-7642	Gear - Ctrshft	302-2668
3P-7643	Gear - Pinion Shft	302-2669
3P-7644	Gear - Pinion Shft	302-2706
3S-1691	Disc - Steering	302-2705
3S-8800	Gear - Driven	325-6090
3T-1898	Drum	219-9674
3T-1899	Drum	219-9690 (Drum), 230-7114 (Steering Clutch Kit)
3T-3206	Roller Gp - Carrier	188-5590
3V-1133	Strip	226-0203
4E-5882	Shaft - Axle	308-9921
4F-1121	Bracket	299-1981
4F-1252	Pin	295-5704
4F-4974	Clamp	311-9373
4H-4021	Plate As - Loading	229-8219
4J-1612	Pin	308-9896
4J-1614	Pin - Pivot	297-7214
4J-1616	Bracket	299-1982
4J-1999	Ballstud	314-8625
4J-2414	Trunnion	296-1370
4J-2585	Pin	299-2034
4J-2590	Bearing	299-1958
4J-2847	Trunnion As	297-7267
4J-3583	Screw - Adjusting	297-7242
4J-3589	Cap - Ball Joint	297-7157
4J-3590	Bearing	297-7139
4J-3591	Bracket - Rh	299-1983
4J-6374	Bearing - Sleeve	295-6407
4M-0503	Gear As - Oil Pump	297-7184
4M-8845	Shaft - Planet	215-1685
4N-2954	Sleeve - Camshaft	299-2059
4N-3281	Line As - Fuel Injector	247-3362
4N-3282	Line As - Fuel Injector	247-3363
4N-3283	Line As - Fuel Injector	247-3364
4N-4539	Sleeve	314-8720
4N-4782	Pulley	325-6176
4N-4864	Pump Gp - Fuel Transfer	242-3442
4N-7693	Crankshaft As	242-3439
4N-8591	Coupling - Exhaust	325-6053
4N-8814	Line As - Fuel Injector	247-3366
4N-9587	Shield - Heat	297-7260
4P-0660	Muffler As	298-2787

(Continued)

Sales Model D6D (Continued)

Original Part Number	Part Name	Classic Part Number
4P-3546	Valve As - Relief	325-6236
4P-9381	Line As - Fuel Injector	279-4984
4P-9382	Line As - Fuel Injector	279-4985
4P-9385	Line As - Fuel Injector	279-4986
4P-9386	Line As - Fuel Injector	279-4987
4S-5049	Guard As - Rh	226-0183
4S-5050	Guard As - Lh	226-0184
4S-6256	Nut - Bearing Adjustable	235-8008
4S-8472	Hood As	296-1355
4S-8708	Housing - Clutch	216-3557
4S-8718	Cage - Carrier Bearing	217-7724
4S-9062	Cap - Final Drive Bearing	226-0204
4T-6151	Trunnion	295-5671
4W-0452	Seal As - Camshaft	325-6191
4W-2446	Damper As	279-4990
4W-9771	Gear - Crankshaft	302-2674
4W-9989	Gear As - Idler	302-2677
5A-7840	Shaft - Track Sprocket	215-1687
5A-7841	Hub - Gear	219-2966
5H-5500	Collar - Flywheel	302-2704
5M-5073	Joint Gp - Univ	325-6113
5M-5822	Gear - Pump Drive	247-4120
5M-6120	Gear - Sun	213-8740
5M-6198	Shaft - Planet	297-7245
5M-6199	Shaft As - Planet	215-1694
5M-6208	Gear - Ring	247-4121
5M-6210	Shaft - Planet	219-9683
5M-6211	Shaft - Planet	219-9684
5M-6636	Support - Frame	235-8007
5M-6651	Hub - Gear	211-2135
5M-6670	Shaft - Sprocket	216-7847
5M-6690	Hub - Steering	215-1695
5M-7290	Cage - Bearing	216-7848
5M-7336	Retainer - Washer	325-6181
5M-7340	Cage - Bearing	325-6034
5M-7342	Flange - Shaft	215-1696
5M-7344	Gear - Bevel	213-8741
5M-7345	Gear - Bevel	214-0957
5M-7346	Gear - Bevel	214-0958
5M-7348	Gear - Bevel	215-1699
5M-7349	Gear - Bevel	213-8742
5M-7352	Gear - Bevel	217-7713
5M-7353	Gear - Bevel	217-7714
5M-7355	Gear - Reverse	216-3581
5M-7740	Gear - Bevel	213-8216
5M-7841	Gear - Ring	214-0525
5M-7864	Pump Gp - Scavenge	226-0169
5M-7869	Gear - Ring	214-0530
5M-7875	Carrier - Front	213-4495
5M-7882	Joint Gp - Univ	297-7210
5M-7900	Bolt - Hex Head	311-9349
5M-7923	Shaft - Output	215-1697
5P-7807	Bearing - Ball	314-8502
5P-8194	Ring - Retaining	308-9920
5S-0073	Plate - Steering	302-2692
5S-0192	Pinion - Final Drive	215-1698
5S-1211	Cover - Valve	314-8665
5S-4557	Bearing	311-9360
5S-6531	Holder As - Cage	214-2078
5S-6795	Chamber As	242-3437
5S-9062	Spacer	363-7463
5S-9080	Pulley - Alt Drive	264-5883
6F-2904	Bearing	295-5673
6H-3957	Bearing - Ball	311-9358
6I-1346	Pump Gp - Oil	295-5674
6J-0774	Trunnion	256-4844
6L-9210	Idler Gp (Complete Idler Group)	175-8038 (Idler As.), 200-9236
6N-1036	Gear - Oil Pump	279-4991
6N-1965	Line As - Fuel Injector	250-7535
6N-1966	Line As - Fuel Injector	250-7536
6N-2789	Pulley	264-5886
6N-3256	Mount As	314-8688
6N-8413	Housing - Pump	325-6110
6P-0169	Hub - Flywheel Clutch	297-7204
6P-6556	Carrier As	308-9836
6P-6739	Shaft - Planet	308-9929
6P-7704	Carrier - Ring	314-8658
6S-3457	Pin	325-6147
6S-3759	Pin As	241-2543
6T-0956	Pad As	367-6088
6T-1702	Support As	299-2065
6T-1724	Bar As - Equalizer	283-5223
6W-7290	Shaft - Planet	308-9930
6W-7331	Cover As	308-9845
6Y-2054	Plate As	302-2695
6Y-6289	Shoe -Track	188-5270
6Y-6290	Shoe -Track Master	175-8728
6Y-6291	Shoe -Track	175-8031
6Y-6292	Shoe -Track Master	175-8032
6Y-6293	Shoe -Track	175-8369
6Y-6294	Shoe -Track Master	175-8370
6Y-6295	Shoe -Track	175-8371
6Y-6296	Shoe -Track Master	175-8372
6Y-6394	Shoe -Track Master	188-5591
6Y-6395	Shoe -Track	188-5396
6Y-6397	Shoe -Track Master	188-5594
6Y-6398	Shoe -Track	188-5593
6Y-6411	Shoe -Track	188-5397
6Y-6412	Shoe -Track Master	188-5592
7C-3567	Mount As	314-8689
7C-4297	Seal As - Camshaft	325-6192
7F-9541	Pin As - Drawbar	296-1361
7F-9547	Pin As - Drawbar	295-0414
7G-1013	Pump Gp	226-0170

(Continued)

Sales Model D6D (Continued)

Original Part Number	Part Name	Classic Part Number
7G-2037	Joint Gp - Univ	226-8017
7G-2038	Tube - Univ Joint	297-7268
7G-2474	Gear - Planet	300-2577
7G-2475	Gear - Planet	223-4815
7G-2476	Gear - Planet	223-4816
7G-2513	Gear - Planet	215-1734
7G-2516	Gear - Planet	283-5203
7G-2830	Ring - Seal	295-6441
7G-3457	Gear - Planet	308-9857
7G-5323	Pinion - Final Drive	231-8767
7G-6042	Cage As	216-7856
7G-7218	Carrier - Planet	283-5205
7G-7724	Piston - Clutch	283-5206
7G-8389	Guard	226-0202
7G-8513	Guard As	361-1714
7G-8517	Guard As	361-1715
7H-0602	Dog - Clutch	314-8515
7J-6461	Crown	325-6054
7J-9344	Bearing - Sleeve	360-2334
7J-9842	Bearing - Sleeve	299-1968
7J-9884	Bearing - Sleeve	325-6016
7K-9360	Pin	319-3461
7M-0457	Guard - Frame	226-0217
7M-0665	Bar As - Equalizer	231-3312
7M-0699	Cap - Brace Bearing	247-4123
7M-0859	Fork As - Shift	297-7172
7M-1249	Piston - Clutch	215-1748
7M-1776	Plate - Idler Guide	226-0222
7M-1851	Bolt - Spring	226-0223
7M-1856	Pilot - Recoil Spring	226-0225
7M-1859	Pilot As - Spring	226-0207
7M-1861	Stop - Spring Rh	226-0228
7M-1862	Stop - Spring Lh	226-0229
7M-2167	Ring - Governor Control	308-9919
7M-2531	Rod - Tie	297-7239
7M-4603	Body - Fuel Valve	311-9348
7M-4926	Retainer - Pin	314-8538
7N-0110	Core As - Oil Cooler	319-3435
7N-0128	Core As - Oil Cooler	299-1994
7N-0165	Core As - Oil Cooler	295-5670
7N-1164	Mount As	295-5451
7N-2871	Line As - Fuel Injector	319-8172
7N-2872	Line As - Fuel Injector	319-8173
7N-2874	Line As - Fuel Injector	298-2779
7N-2875	Line As - Fuel Injector	298-2780
7N-2876	Line As - Fuel Injector	298-2781
7N-2949	Pulley	264-5887
7N-2957	Cover - Rad Cap	361-1722
7N-3486	Manifold - Exhaust	261-0899
7N-3515	Gear - Camshaft	314-8669
7N-3536	Gear - Fuel	279-4993
7N-5503	Gear - Camshaft Rr	233-2182
7N-5511	Gear As - Idler	233-2180
7N-5910	Impeller - Pump	314-8686
7N-8117	Muffler As	247-2668
7N-9146	Gear - Flywheel Starter	279-4995
7N-9312	Damper As - Camshaft	299-2005
7N-9805	Pin - Piston	295-6438
7S-3161	Lifter - Valve	279-4996
7S-6723	Bracket - Alternator	299-1978
7S-6964	Gear - Ring	214-0532
7S-7809	Cap As - Radiator	295-6417
7S-8443	Muffler	247-2675
7T-0205	Bearing - Brace	247-4127
7T-2036	Cap As - Filter	361-1721
7T-4562	Idler As	175-8263
7T-9370	Gear - Sun	283-5207
7T-9931	Countershaft	215-1760
7T-9963	Case As - Transfer Gear	219-9665
7W-0450	Gear - Water Pump	279-4997
7W-0507	Gear - Oil Pump Drive	279-4998
7W-0508	Gear - Fuel Pump Drive	296-1351
7W-5687	Hub - Camshaft	314-8684
8B-5972	Bearing - Ball	314-8503
8E-4365	Segment Gp - Sprocket	188-5635 (sprocket group), 188-5589 (segment)
8E-4499	Shoe -Track	188-5383
8E-4500	Shoe -Track Master	188-5387
8E-4501	Shoe -Track	188-5381
8E-4502	Shoe -Track Master	188-5385
8E-5993	Gear As - Idler	215-1903
8F-5104	Screen As - Oil Pan	314-8539
8H-1993	Valve - Inlet	256-4765 (Valve Kit)
8H-1994	Valve - Exhaust	256-4765 (Valve Kit)
8H-2810	Case As - Filter	314-8512
8H-7980	Piston	226-0249
8H-9806	Gear - Shaft Drive	325-6091
8J-2652	Shaft	299-2054
8J-2653	Lever As	299-2015
8J-2654	Lever As	299-2016
8M-0874	Plunger As - Valve	311-9439
8M-6191	Sleeve - Bolt	226-0234
8M-7166	Housing - Screen	297-7192
8M-7207	Guard As - Rh	226-0236
8M-7208	Guard As - Frame	226-0237
8M-8619	Cage - Bearing	217-7725
8M-8623	Gear - Sun	213-8755
8M-8628	Flange - Joint	217-9776

(Continued)

Sales Model D6D (Continued)

Original Part Number	Part Name	Classic Part Number
8M-8642	Housing - Clutch	219-9669
8M-8644	Housing - Clutch	215-1782
8M-8646	Plate As - Center	216-3583
8M-8649	Piston - Clutch	217-9777
8M-8650	Piston - Clutch	217-9778
8M-8652	Shaft	297-7252
8M-8677	Carrier - Planet	213-4449
8N-0002	Trunnion As	314-8728
8N-0875	Valve - Exhaust	247-6893 (Valve), 241-3381 (Valve Kit)
8N-1187	Head Gp - Cylinder	242-3435
8N-1721	Rod As - Conn	269-5291
8N-1984	Rod As - Conn	242-3441
8N-2510	Shaft	325-6208
8N-2641	Sleeve	325-6210
8N-3182	Body As - Piston	250-6564 (Piston As), 250-6556 (Liner Kits)
8N-3183	Piston Gp - Basic	250-6556 (Liner Kit)
8N-3251	Shaft As - Rocker Arm	314-8711
8N-3325	Arm Gp - Rocker	314-8623
8N-3327	Arm Gp - Rocker	314-8624
8N-5305	Spacer	363-7464
8N-5779	Coupling - Exhaust	325-6047
8N-5929	Cover - Water Pump	296-1349
8N-6796	Head Gp - Cylinder	269-5290
8N-7315	Tube As - Outlet	325-6232
8N-8225	Bearing - Main	314-8652
8N-9733	Line As - Fuel Injector	319-8174
8P-0514	Yoke As	308-9947
8P-0605	Gear - First Reduction	213-8453
8P-0606	Pinion - Sec Reduction	215-1783
8P-0769	Hub - Turbine	308-9870
8P-1851	Hub As - Sprocket	224-1314
8P-1892	Piston - Clutch	283-5208
8P-1916	Gear - Planet	283-5209
8P-1918	Gear - Planet	283-5210
8P-1919	Gear - Planet	300-2579
8P-2042	Shaft - Planet	283-5211
8P-2430	Shaft As	297-7258
8P-5197	Bearing As	295-6413
8P-6495	Drum	213-6954 (Drum), 227-9302 (Steering Clutch Kit)
8P-6803	Shaft As	215-1842
8P-7790	Valve Gp - Press	247-4437
8P-9507	Piston - Clutch	283-5212
8R-4821	Carrier - Planet	308-9837
8R-7425	Retainer	308-9917
8S-0248	Breather As	325-6033
8S-0493	Shaft As - Pump	325-6198
8S-0569	Gear - Transfer	213-8754
8S-0573	Gear - Transfer	215-1844
8S-2809	Muffler	247-2677
8S-3970	Chamber As	242-3438
8S-7716	Manifold - Exhaust	295-0415
8S-7717	Manifold - Exhaust	261-0894
8S-7718	Manifold - Exhaust	295-0416
8V-6382	Hub As	308-9868
8V-6384	Spacer As	308-9935
9C-8074	Gear - Planet	308-9858
9C-8075	Gear - Sun	308-9864
9C-8277	Gear - Bevel	308-9851
9F-7101	Bushing - Collar	299-1988
9G-0280	Piston - Clutch	283-5213
9G-0284	Housing - Clutch	283-5214
9G-0285	Piston - Clutch	283-5215
9G-0289	Shaft - Planet	283-5216
9G-0290	Hub - Clutch	283-5217
9G-6476	Rod Gp - Idler Recoil	226-0198
9G-7412	Gear As - Oil Pump	297-7183
9G-8303	Collar - Idler End	226-0242
9H-2256	Pump Gp	311-9443
9J-2332	Bearing - Pivot	299-1969
9J-8427	Bracket	299-1984
9J-9147	Nut	299-2028
9J-9598	Pin	296-1362
9K-8757	Rod End - Bearing	311-9361
9M-0701	Piston - Steer	219-9692
9M-0702	Pilot - Piston	229-8232
9M-1328	Bearing - Aligning	325-6018
9M-1500	Shaft - Planet	219-9685
9M-1502	Cage - Bearing	219-9686
9M-1995	Gear - Sun	213-8756
9M-1996	Shaft - Planet	215-1875
9M-2013	Housing As	216-3585
9M-2028	Gear - Sun	214-0959
9M-2038	Gear - Transfer Driven	215-1876
9M-2039	Gear - Transfer Driving	219-9672
9M-2045	Pinion - Bevel	215-1878
9M-2049	Gear - Ring	214-0533
9M-4789	Shaft - Gov Control	297-7256
9M-5045	Guard As - Wear	213-9111
9M-8117	Shaft - Flywheel Clutch	226-6073
9M-8119	Retainer - Inlet	226-8022
9N-5251	Piston Gp - Basic	250-6557 (Liner Kit)
9N-5404	Piston Gp - Basic	250-6558 (Liner Kit)
9N-5769	Cover - Housing	325-6050
9P-0418	Cage	223-6311

(Continued)

Sales Model D6D (Continued)

Original Part Number	Part Name	Classic Part Number
9P-0620	Cage - Pinion Bearing	221-1052
9P-5363	Piston - Clutch	219-9687
9P-5379	Housing - Clutch	215-1904
9P-7757	Gear - Sun	283-5218
9P-8623	Shaft - Planet	314-8719
9P-8624	Shaft - Planet	295-5446
9P-8626	Gear - Sun	283-5219
9P-9000	Shaft - Steering	217-7738
9P-9031	Gear - Sun	283-5220
9P-9360	Gear - First Reduction	213-8454
9P-9361	Gear - Final Drive	223-4809
9P-9362	Pinion - Final Drive	215-1944
9P-9363	Pinion - Reduction	219-9677

Original Part Number	Part Name	Classic Part Number
9P-9575	Cage - Bevel Gr Bearing	216-7876
9S-1838	Bolt Master	188-5634
9S-2354	Manifold - Exhaust	261-0888
9S-2355	Manifold - Exhaust	261-0891
9S-5265	Shaft As	215-1945
9S-6129	Pulley - Alternator Drive	264-5891
9S-6590	Pump Gp - Oil	226-0176
9S-6875	Pinion - Final Drive	217-7705
9S-7079	Muffler As	247-2669
9S-8245	Strip - Track	226-0243
9S-8246	Strip - Track	226-0244
9S-8251	Guard As - Roller	226-0180
9S-8252	Guard As - Roller	226-0181
9S-8253	Guard As - Roller	226-0182

Original Part Number	Part Name	Classic Part Number
9S-8257	Guard As - Guiding	226-0238
9S-8258	Guard As - Guiding	226-0239
9S-8493	Bolt - Connecting Rod	311-9351
9S-8679	Chamber As	325-6042
9S-8789	Plate - Clutch	302-2712
9S-9385	Gear As - Oil Pump	297-7185
9T-4761	Head	325-6108
9W-0318	Spacer	325-6218
9W-0550	Shaft - Transmission Upper	226-6000
9W-0552	Shaft - Pinion	226-6001
9W-4702	Stator - Converter	308-9939
9W-6433	Impeller - Converter	308-9871
9W-6435	Flange - Drive	308-9846
9W-8270	Gear - Ring	308-9859
9W-8433	Shaft As - Output	302-4249
9W-8437	Gear - Sun	283-5222

Sales Model D6H

Original Part Number	Part Name	Classic Part Number
100-7860	Valve - Inlet	270-4360 (Valve), 270-4362 (Valve Kit)
104-4253	Line As - Fuel Injector	279-4988
104-4254	Line As - Fuel Injector	279-4989
111-8015	Gasket As - Head	279-4977
112-5585	Shaft - Planet	308-9932
112-8041	Carrier - Planet	295-5681
122-9405	Bracket As	325-6005
127-5537	Core As	325-6045
128-0307	Plate	325-6165
131-3815	Seal Gp - Basic	325-6193
131-7736	Support As - Engine	325-6222
148-7455	Valve - Exhaust	270-4361
160-6305	Cap - Bearing	295-5686

Original Part Number	Part Name	Classic Part Number
160-6308	Cap - Bearing	325-6036
172-5185	Shaft - Water Pump	325-6201
172-5188	Shaft - Water Pump	325-6202
172-5189	Impeller - Pump	295-5687
172-5190	Impeller - Pump	325-6111
172-6712	Impeller - Pump	325-6112
172-7767	Pump Gp - Water	296-1365
179-6152	Bearing	361-1704
190-8609	Valve - Fill	360-2288
196-0028	Gear As - Idler	364-5259
1N-3576	Block Gp - Cylinder	279-4978
1N-3958	Elbow	325-6087
1P-9945	Bracket As - Fan	296-1344
1P-9946	Shaft - Fan	325-6194

Original Part Number	Part Name	Classic Part Number
1P-9989	Pipe	363-7453
1S-4701	Pulley - Alt	264-5866
1T-0421	Flange As - Output	295-5442
1T-0437	Housing - Rotating	295-5685
1T-0438	Retainer - Bearing	295-0410
1T-0447	Carrier - Ring	295-0409
1T-0521	Retainer - Bearing	325-6180
1T-0699	Impeller - Converter	235-1808
1T-1790	Carrier As	296-1347
1T-1880	Carrier - Ring	295-0408
1T-1993	Wheel - Turbine	235-0920
1T-2052	Stator As	295-5683
1U-0105	Brace As	295-5684
1U-0159	Pin	325-6134
1U-0612	Pin	325-6135
1U-0725	Retainer	314-8707

(Continued)

Sales Model D6H (Continued)

Original Part Number	Part Name	Classic Part Number
1U-0899	Pin	296-1363
1U-0928	Screw - Adjusting	325-6187
1U-1267	Brace As	296-1343
1U-4103	Trunnion	295-5680
1W-1669	Piston	325-6158
1W-1695	Pump Gp	279-4980
1W-1698	Housing - Transfer Pump	296-1356
1W-4369	Pulley - Alt	296-1340
1W-4402	Gear - Camshaft	279-4981
1W-4405	Gear - Crankshaft	279-4982
1W-4407	Hub - Fan Pulley	296-1358
1W-4737	Gear - Camshaft	295-5688
1W-4738	Bearing - Sleeve	325-6020
1W-4740	Gear As - Drive	295-5689
1W-4746	Retainer - Gear	295-5690
1W-5912	Tappet As - Guide	325-6223
1W-6541	Plunger As	325-6173
1W-7940	Spider As - Fan	295-5443
244-1090	Alarm - Back up	360-2345
2D-5658	Bearing - Ball	301-4628
2F-5721	Bearing - Ball	311-9354
2J-8489	Bearing - Sleeve	295-5691
2K-4507	Bearing - Sleeve	325-6021
2P-1005	Bearing - Sleeve	296-1342
2P-1170	Shaft As - Gear	296-1367
2P-1738	Plate As - Oil Pan	325-6164
2P-1739	Tube As - Pump	325-6229
2P-1757	Hub - Fan Pulley	296-1357
2P-1781	Spacer - Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2519	Tube As - Inlet	325-6230
2P-4370	Plate - Clutch	325-6166
2P-6245	Shaft As - Pump	325-6197
2R-0179	Pin As	325-6127
2W-0994	Body As - Preclnr	367-6084
2W-1086	Cover As - Cylinder Head	325-6049
2W-2621	Valve - Inlet	247-6892 (Valve), 241-3381 (Valve Kit)
2W-5540	Core, Radiator (Folded)	363-7452
2W-6030	Tube	314-8729
2W-6757	Trunnion As	295-5678
2W-7255	Shaft - Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear - Water Pump	325-6088
2W-8494	Pulley - Alt	295-5692
2W-9978	Core As - Oil Cooler	279-4983
3F-4971	Pin	295-5693
3F-6185	Pin	295-5694
3G-8917	Pin	325-6141
3J-2452	Cap - Ball Joint	297-7156
3J-2682	Bracket	296-1345
3J-4284	Cap - Bearing	314-8656
3J-6559	Cap - Bearing	296-1346
3J-6560	Screw - Adjustable	297-7240
3J-6561	Screw - Adjustable	297-7241
3J-6573	Screw - Adjusting	302-2714
3L-1425	Bearing - Ball	311-9356
3T-0996	Bearing - Sleeve	295-5695
3T-0997	Bearing - Sleeve	307-1524
3T-1162	Sleeve - Wear	325-6209
3T-1446	Pump Gp	325-6178
3T-1554	Guard As	295-5696
3T-2481	Strip	295-5448
3T-2849	Strip	295-5697
3T-4008	Gear - Planet	295-5444
3T-4011	Shaft As - Planet	295-5698
3T-4308	Bearing - Sleeve	296-1341
3T-4568	Shaft - Planet	314-8712
3T-4824	Gear - Planet	295-5699
3T-5021	Carrier - Planet	295-5700
3T-5200	Carrier - Planet	295-5701
3T-5672	Gear As - Oil Pump	295-5447
3T-5674	Gear As - Oil Pump	295-5449
3T-6247	Shaft	314-8713
3W-0630	Pin	307-1525
3W-0640	Piston	325-6160
3W-0643	Cylinder	325-6061
3W-3284	Strip	296-1368
3W-3285	Strip	296-1369
3W-3628	Guard As	295-5677
3W-6551	Shaft	295-5702
3W-6555	Shaft	295-5703
4F-1252	Pin	295-5704
4F-4974	Clamp	311-9373
4J-0121	Cap - Bearing	360-2344
4J-1616	Bracket	299-1982
4J-1641	Trunnion	314-8725
4J-1999	Ballstud	314-8625
4J-2414	Trunnion	296-1370
4J-3583	Screw - Adjusting	297-7242
4J-6374	Bearing - Sleeve	295-6407
4K-1102	Bearing - Sleeve	325-6010
4K-3004	Bearing - Trunnion Support	314-8632
4K-3128	Bearing - Sleeve	314-8633
4N-7693	Crankshaft As	242-3439
4P-3546	Valve As - Relief	325-6236
4P-9381	Line As - Fuel Injector	279-4984
4P-9382	Line As - Fuel Injector	279-4985
4P-9385	Line As - Fuel Injector	279-4986
4P-9386	Line As - Fuel Injector	279-4987
4S-8472	Hood As	296-1355
4T-0732	Bracket	314-8627

(Continued)

Sales Model D6H (Continued)

Original Part Number	Part Name	Classic Part Number
4T-0998	Lever	314-8687
4T-1504	Trunnion	314-8727
4T-5495	Ballstud	314-8626
4T-6151	Trunnion	295-5671
4W-0452	Seal As - Camshaft	325-6191
4W-2042	Spacer	325-6217
4W-2446	Damper As	279-4990
4Y-2817	Ejector As	295-6423
5G-3612	Cap Gp	295-6419
5G-9075	Strip	295-0412
5G-9076	Strip	295-0413
5P-7807	Bearing - Ball	314-8502
5P-8194	Ring - Retaining	308-9920
5S-1211	Cover - Valve	314-8665
5S-6795	Chamber As	242-3437
5S-9062	Spacer	363-7463
5S-9080	Pulley - Alt Drive	264-5883
6F-2904	Bearing	295-5673
6F-3183	Cap - Bearing	325-6038
6H-3957	Bearing - Ball	311-9358
6I-0341	Line As - Fuel Injector	325-6117
6I-0342	Line As - Fuel Injector	325-6118
6I-0343	Line As - Fuel Injector	325-6119
6I-0344	Line As - Fuel Injector	325-6120
6I-0345	Line As - Fuel Injector	325-6121
6I-0346	Line As - Fuel Injector	325-6122
6I-1346	Pump Gp - Oil	295-5674
6I-8736	Guard As	295-6434
6I-9034	Guard As	295-6435
6N-1036	Gear - Oil Pump	279-4991
6N-1553	Coupling - Exhaust	295-6422
6N-2789	Pulley	264-5886
6N-8413	Housing - Pump	325-6110
6P-5404	Plate & Brake	325-6168
6P-7704	Carrier - Ring	314-8658
6T-0064	Shaft - Planet	295-6442
6T-0234	Retainer	325-6183
6T-0240	Retainer	325-6184
6T-0241	Piston	325-6161
6T-0243	Plate - Thrust	325-6169
6T-0248	Ring - Seal	295-6440
6T-3080	Plate& Brake	325-6170
6T-7882	Gear - Planet	296-1352
6Y-0926	Gear - Planet	295-6427
6Y-0984	Gear - Ring	295-6428
6Y-3896	Pin As	325-6132
6Y-4819	Carrier - Planet	296-1348
6Y-6751	Pin	325-6149
6Y-7471	Pin - Pivot	325-6152
6Y-9468	Retainer As	325-6185
7C-3567	Mount As	314-8689
7C-4297	Seal As - Camshaft	325-6192
7F-9541	Pin As - Drawbar	296-1361
7F-9547	Pin As - Drawbar	295-0414
7G-2500	Gear - Planet	296-1350
7G-2516	Gear - Planet	283-5203
7G-2824	Piston	295-6439
7G-2828	Plate - Clutch	325-6171
7G-2830	Ring - Seal	295-6441
7G-6489	Spring - Recoil	314-8722
7G-7013	Coupling - Pump Drive	295-5450
7G-7218	Carrier - Planet	283-5205
7G-7681	Shaft As	307-1530
7G-7724	Piston - Clutch	283-5206
7G-9555	Bearing - Spider	314-8721
7J-1333	Bearing - Sleeve	295-6408
7J-5131	Trunnion	296-1371
7J-6461	Crown	325-6054
7J-9884	Bearing - Sleeve	325-6016
7K-7195	Bearing - Sleeve	325-6025
7N-0165	Core As - Oil Cooler	295-5670
7N-1164	Mount As	295-5451
7N-3486	Manifold - Exhaust	261-0899
7N-5910	Impeller - Pump	314-8686
7N-9146	Gear - Flywheel Starter	279-4995
7N-9805	Pin - Piston	295-6438
7P-6596	Bearing - Sleeve	295-6409
7P-8370	Bearing	295-6410
7S-3161	Lifter - Valve	279-4996
7S-7809	Cap As - Radiator	295-6417
7T-2036	Cap As - Filter	361-1721
7T-3952	Gear - Transfer	295-6429
7T-8136	Shaft - Planet	314-8714
7T-9272	Gear - Sun	296-1354
7T-9370	Gear - Sun	283-5207
7T-9586	Bearing	314-8645
7W-0450	Gear - Water Pump	279-4997
7W-0507	Gear - Oil Pump Drive	279-4998
7W-0508	Gear - Fuel Pump Drive	296-1351
7W-5684	Pulley - Camshaft	298-2771
7W-5698	Pulley - Camshaft	295-5679
8G-4187	Pin As	295-5676
8G-4189	Bearing - Aligning	295-6411
8G-4190	Seal - Ebar	296-1366
8G-8311	Bearing - Sleeve	295-6412
8H-2810	Case As - Filter	314-8512
8J-2880	Cap - Bearing	295-6420
8M-8628	Flange - Joint	217-9776
8N-0875	Valve - Exhaust	247-6893 (Valve), 241-3381 (Valve Kit)
8N-1187	Head Gp - Cylinder	242-3435
8N-1721	Rod As - Conn	269-5291
8N-2510	Shaft	325-6208
8N-2641	Sleeve	325-6210
8N-3251	Shaft As - Rocker Arm	314-8711
8N-3325	Arm Gp - Rocker	314-8623
8N-3327	Arm Gp - Rocker	314-8624
8N-5305	Spacer	363-7464

(Continued)

Sales Model D6H (Continued)

Original Part Number	Part Name	Classic Part Number
8N-5929	Cover - Water Pump	296-1349
8N-6796	Head Gp - Cylinder	269-5290
8N-7315	Tube As - Outlet	325-6232
8N-8225	Bearing - Main	314-8652
8P-1892	Piston - Clutch	283-5208
8P-1916	Gear - Planet	283-5209
8P-5197	Bearing As	295-6413
8P-9507	Piston - Clutch	283-5212
8S-0248	Breather As	325-6033
8S-0493	Shaft As - Pump	325-6198
8S-3970	Chamber As	242-3438
8S-7716	Manifold - Exhaust	295-0415
8S-7718	Manifold - Exhaust	295-0416
8S-7818	Bracket	226-0211
8Y-1624	Guard As	295-6432
8Y-1625	Guard As	295-6433
9G-0280	Piston - Clutch	283-5213
9G-0284	Housing - Clutch	283-5214
9G-0285	Piston - Clutch	283-5215
9G-0289	Shaft - Planet	283-5216
9G-0290	Hub - Clutch	283-5217
9G-1499	Gear - Oil Pump	295-6424
9G-8638	Gear - Planet	295-6425
9G-9174	Gear - Sun	295-6430
9G-9178	Spindle	295-6443
9G-9180	Hub - Sprocket	295-6436
9G-9183	Shaft	295-0417
9G-9349	Retainer	295-0411
9G-9543	Gear - Oil Pump	295-6426
9J-7964	Bearing - Spherical	325-6017
9J-9147	Nut	299-2028
9J-9598	Pin	296-1362
9M-8281	Gear As - Oil Pump	325-6089
9N-5769	Cover - Housing	325-6050
9N-6611	Pulley	325-6177
9P-7757	Gear - Sun	283-5218
9P-8283	Plate - Clutch	296-1364
9P-8521	Gear - Ring	296-1353
9P-8623	Shaft - Planet	314-8719
9P-8624	Shaft - Planet	295-5446
9P-8626	Gear - Sun	283-5219
9S-2355	Manifold - Exhaust	261-0891
9S-8679	Chamber As	325-6042
9T-0064	Bearing	361-1706
9T-0066	Trunnion	325-6228
9T-4762	Head	325-6109
9U-8481	Pin As	295-5675
9W-0099	Bearing - Sleeve	314-8639
9W-0876	Bearing - Sleeve	325-6031
9W-2344	Coupling - Pump Drive	314-8666
9W-2579	Plate	314-8701
9W-3605	Carrier - Ring	314-8662
9W-4897	Bracket As	295-6414
9W-7481	Gear - Planet	295-6431
9W-7839	Carrier - Planet	295-6421
9W-8270	Gear - Ring	308-9859
9W-9930	Mount As	295-6437

Sales Model D7

Original Part Number	Part Name	Classic Part Number
0T-0259	Nut - Bearing Sleeve	311-9431
121-7746	Precleaner As	360-2311
160-6305	Cap - Bearing	295-5686
1A-2846	Cap As - Filler	311-9368
1D-3996	Fork - Knuckle	228-9428
1F-2254	Bushing - Stem	314-8510
1M-7250	Bowl - Precleaner	360-2296
1P-1931	Shaft - Steer	227-4772
1S-1888	Bracket - Lamp	297-7147
1S-5331	Cylinder - Adjustable	226-0214
2B-3708	Chamber As	247-3293
2D-5658	Bearing - Ball	301-4628
2F-0025	Tube	325-6233
2S-4015	Plunger As - Valve	311-9438
3B-1464	Cap - Bearing	226-0206
3B-6218	Muffler As	247-2672
3F-4971	Pin	295-5693
3F-7445	Bearing - Sleeve	314-8508
3H-3378	Gear As - Pump	298-2795
3K-3124	Muffler - Trap	247-2673
3L-1425	Bearing - Ball	311-9356
3P-3623	Lock - Adjustable Nut	226-7989
4B-1455	Cap As - Filter	361-1719
4F-4974	Clamp	311-9373
4J-1999	Ballstud	314-8625
4N-7526	Seal As - Pump	311-9454
4N-9180	Seal As - Pump	311-9455
5F-0689	Pin	256-4821
5F-2256	Cage - Bearing	226-7973
5F-7993	Pin	319-3454
5L-9371	Connector - Inlet	311-9375
5S-1211	Cover - Valve	314-8665
6B-7178	Fork - Band Adjustable	299-2009
6F-2904	Bearing	295-5673
6H-3957	Bearing - Ball	311-9358
6L-7816	Seal - o-Ring	314-8542
7B-5088	Drum - Steering	223-4813
7D-6841	Joint As - Univ	228-9566
7F-9541	Pin As - Drawbar	296-1361
7F-9547	Pin As - Drawbar	295-0414

(Continued)

Sales Model D7 (Continued)

Original Part Number	Part Name	Classic Part Number
7M-4926	Retainer - Pin	314-8538
7S-7809	Cap As - Radiator	295-6417
7T-0204	Bearing - Brace	247-4126
8B-5972	Bearing - Ball	314-8503
8H-1383	Rod - Tie	299-2051

Original Part Number	Part Name	Classic Part Number
8H-1993	Valve - Inlet	256-4765 (Valve Kit)
8H-1994	Valve - Exhaust	256-4765 (Valve Kit)
8H-2434	Drum - Steering	216-7862
8H-7980	Piston	226-0249

Original Part Number	Part Name	Classic Part Number
8H-9379	Nut - Brake Band Adjustable	299-2029
8M-0493	Cage - Outer Bearing	216-7866
9F-7101	Bushing - Collar	299-1988
9S-8493	Bolt - Connecting Rod	311-9351

Sales Model D7C, D7D

Original Part Number	Part Name	Classic Part Number
1M-7250	Bowl - Precleaner	360-2296
121-7746	Precleaner As	360-2311
4B-1455	Cap As - Filter	361-1719
160-6305	Cap - Bearing	295-5686
1A-2846	Cap As - Filler	311-9368
1F-2254	Bushing - Stem	314-8510
1P-0005	Pump Gp - Fuel Transfer	256-4756
1S-1888	Bracket - Lamp	297-7147
1S-5331	Cylinder - Adjustable	226-0214
2D-5658	Bearing - Ball	301-4628
2F-0025	Tube	325-6233
2F-5721	Bearing - Ball	311-9354
2P-0483	Chamber As	256-4760
2S-3966	Ring - Seal	297-7237
2S-4015	Plunger As - Valve	311-9438
3F-6149	Pin	299-2033
3F-6185	Pin	295-5694
3F-7445	Bearing - Sleeve	314-8508

Original Part Number	Part Name	Classic Part Number
3H-3378	Gear As - Pump	298-2795
3P-3623	Lock - Adjustable Nut	226-7989
4F-1121	Bracket	299-1981
4F-1252	Pin	295-5704
4F-4974	Clamp	311-9373
4M-9215	Gear - Pump Idler	311-9391
4N-7526	Seal As - Pump	311-9454
4N-9180	Seal As - Pump	311-9455
5F-2256	Cage - Bearing	226-7973
5S-1211	Cover - Valve	314-8665
6B-7178	Fork - Band Adjustable	299-2009
6F-2904	Bearing	295-5673
6H-3957	Bearing - Ball	311-9358
6L-7816	Seal - o-Ring	314-8542
6T-1980	Collar - Idler End	226-0210
7B-2420	Ferrule - Director	314-8517

Original Part Number	Part Name	Classic Part Number
7B-5088	Drum - Steering	223-4813
7F-9541	Pin As - Drawbar	296-1361
7F-9547	Pin As - Drawbar	295-0414
7H-0602	Dog - Clutch	314-8515
7M-4603	Body - Fuel Valve	311-9348
7M-4926	Retainer - Pin	314-8538
7S-7809	Cap As - Radiator	295-6417
8F-5104	Screen As - Oil Pan	314-8539
8H-1383	Rod - Tie	299-2051
8H-1993	Valve - Inlet	256-4765 (Valve Kit)
8H-1994	Valve - Exhaust	256-4765 (Valve Kit)
8H-2810	Case As - Filter	314-8512
8H-7980	Piston	226-0249
8H-9379	Nut - Brake Band Adjustable	299-2029
8M-0493	Cage - Outer Bearing	216-7866
9S-8493	Bolt - Connecting Rod	311-9351

Sales Model D7E

Original Part Number	Part Name	Classic Part Number
112-3249	Muffler As	247-2661
160-6305	Cap - Bearing	295-5686
190-8609	Valve - Fill	360-2288
1A-2846	Cap As - Filler	311-9368
1F-2254	Bushing - Stem	314-8510

Original Part Number	Part Name	Classic Part Number
1M-0598	Gear - Transmission	213-8636
1M-2607	Cage - Bearing	239-7970
1M-2626	Cage - Carrier Bearing	216-7458

Original Part Number	Part Name	Classic Part Number
1M-2635	Housing - Clutch	216-3549
1M-2637	Housing - Clutch	216-3550
1M-4486	Piston - Clutch	215-1660
1M-5151	Pinion - Bevel	215-1661

(Continued)

Sales Model D7E (Continued)

Original Part Number	Part Name	Classic Part Number
1M-5270	Pipe - Extension	367-6065
1M-8647	Housing As	215-1662
1M-9029	Guard	226-0219
1M-9444	Retainer - Spring	299-2046
1P-0005	Pump Gp - Fuel Transfer	256-4756
1P-0965	Gear - Bevel	213-8215
1P-4145	Valve Gp - Press	247-4436
1P-7590	Support As	213-4400
1S-0876	Bolt - Spring	226-0224
1S-1532	Flange - Shaft	215-1673
1S-1801	Shaft As - Transmission	215-1674
1S-1888	Bracket - Lamp	297-7147
1S-4701	Pulley - Alt	264-5866
1T-0256	Gear - Pump Drive	239-7930
2D-5658	Bearing - Ball	301-4628
2F-0025	Tube	325-6233
2F-5721	Bearing - Ball	311-9354
2J-3271	Pin	319-3452
2J-5462	Trunnion	297-7264
2J-5596	Pin - Pivot	297-7211
2M-0125	Cylinder - Adjustable	226-0215
2M-0365	Stop - Spring Rh	226-0230
2M-0366	Stop - Spring Lh	226-0231
2M-0369	Pilot - Spring Recoil	226-0226
2M-0398	Sleeve - Bolt	226-0235
2M-4668	Retainer - Guard	297-4867
2P-0483	Chamber As	256-4760
2P-0484	Chamber As	247-3296
2P-3424	Gear - First Reduction	215-1675
2P-3425	Pinion - Sec Reduction	217-7697
2P-3992	Gear - Bevel	219-9666
2S-3946	Gear - Final Drive	215-1678
2S-3966	Ring - Seal	297-7237
2S-4015	Plunger As - Valve	311-9438
2S-7062	Shaft - Sprocket	219-9673
2S-7063	Nut	300-2584
2S-7064	Cap - Shaft Bearing	299-1991
2S-7099	Hub - Gear	219-2962
2S-7527	Flange - Drum	213-8163
2S-7596	Retainer	215-1679
2S-7873	Pump Gp	226-0162
2S-7917	Gear - Pump Drive	247-4119
2S-7920	Pump Gp - Scavenge	217-2594
2S-8356	Rod Gp - Track Adjustable	226-0199
3B-1464	Cap - Bearing	226-0206
3F-4971	Pin	295-5693
3F-6149	Pin	299-2033
3F-7445	Bearing - Sleeve	314-8508
3H-3378	Gear As - Pump	298-2795
3J-2452	Cap - Ball Joint	297-7156
3J-2682	Bracket	296-1345
3J-6167	Bearing - Sleeve	299-1960
3J-6182	Pin As	325-6128
3J-6204	Pin As	325-6129
3J-6442	Bearing - Sleeve	299-1961
3J-6502	Pin	319-3453
3J-6559	Cap - Bearing	296-1346
3J-6560	Screw - Adjustable	297-7240
3J-6561	Screw - Adjustable	297-7241
3J-6570	Support - Bearing	299-2069
3J-6573	Screw - Adjusting	302-2714
3J-6575	Trunnion	297-7265
3J-6576	Bearing	256-4833
3J-6577	Pin - Brace	367-6077
3K-2230	Gear - Planet	219-9658
3P-3623	Lock - Adjustable Nut	226-7989
3P-6293	Pump Gp	217-2597
3P-6560	Stop - Recoil Spring	226-0232
3P-6561	Stop - Recoil Spring	226-0233
3S-3917	Guard As - Sprocket	226-0188
3S-3918	Guard As - Sprocket	226-4950
3T-1921	Drum - Inner	229-8227 (Drum), 230-7116 (Steering Clutch Kit)
3T-4482	Guide - Front Idler	226-0248
4F-1121	Bracket	299-1981
4F-1252	Pin	295-5704
4F-4974	Clamp	311-9373
4J-1612	Pin	308-9896
4J-1614	Pin - Pivot	297-7214
4J-1616	Bracket	299-1982
4J-1641	Trunnion	314-8725
4J-1999	Ballstud	314-8625
4J-6167	Bearing - Sleeve	325-6009
4M-7099	Gear - Ring	214-0521
4M-7100	Gear - Ring	214-0522
4M-7102	Gear - Ring	214-0523
4M-9215	Gear - Pump Idler	311-9391
4N-7000	Head As - Cylinder	325-6105
4N-7526	Seal As - Pump	311-9454
4N-9180	Seal As - Pump	311-9455
5F-7993	Pin	319-3454
5J-2602	Plate As - Trunnion	256-4838
5J-4321	Trunnion	302-2700
5J-5643	Connector	325-6043
5M-1127	Countershaft	216-3558
5M-1133	Gear - Idler	214-0524
5M-1137	Gear As - Ctrshft	214-0960
5M-1139	Gear As - Ctrshft	214-0961
5M-1141	Gear As - Ctrshft	214-0962
5M-1143	Gear As	214-0963
5M-1145	Gear As - Forward	214-0964
5M-1147	Gear As - Reverse	214-0965
5M-1988	Piston - Steer	219-9691
5M-1990	Pilot - Piston	229-8233

(Continued)

Sales Model D7E (Continued)

Original Part Number	Part Name	Classic Part Number
5M-1998	Drum Steering	213-6952
5M-2026	Hubdriving	216-4471
5M-2971	Guard As - Front Idler	226-0190
5M-3470	Gear - Transmission	224-1305
5M-3474	Shaft - Output	215-1690
5M-3499	Shaft - Planet	319-3475
5M-3906	Gear - Ring	214-0526
5M-3907	Carrier - Planet	210-8475
5M-3941	Shaft - Planet	215-1691
5M-3942	Shaft - Planet	215-1692
5M-5037	Hub - Gear	219-2980
5M-7900	Bolt - Hex Head	311-9349
5P-7807	Bearing - Ball	314-8502
5S-0073	Plate - Steering	302-2692
5S-1211	Cover - Valve	314-8665
5S-4863	Holder As - Cage	215-1732
5S-6796	Drum - Inner	213-6953 (Drum), 230-7115 (Steering Clutch Kit)
5S-9080	Pulley - Alt Drive	264-5883
6F-2904	Bearing	295-5673
6F-7523	Cap - Bearing	325-6039
6H-3957	Bearing - Ball	311-9358
6J-5342	Retainer	325-6182
6J-5354	Bearing	297-7142
6J-6229	Pin	299-2030
6J-9258	Trunnion As	256-4846
6L-7816	Seal - o-Ring	314-8542
6P-4948	Cap - Final Drive Bearing	226-0205
6P-6653	Plate - Guide	226-0208
6T-0960	Pad As	367-6089
6T-1980	Collar - Idler End	226-0210
7B-2420	Ferrule - Director	314-8517
7F-9541	Pin As - Drawbar	296-1361
7G-2517	Gear - Planet	213-8747
7G-2521	Gear - Planet	213-8749
7G-6576	Cage As	216-7859
7H-0602	Dog - Clutch	314-8515
7J-1185	Bearing As	297-7146
7J-1333	Bearing - Sleeve	295-6408
7J-1334	Bearing - Sleeve	325-6015
7J-5131	Trunnion	296-1371
7J-7488	Bearing	256-4836
7M-1840	Gear As - Ctrshft	214-0966
7M-1842	Gear As-ctr - Shft	214-0967
7M-1889	Guard As	213-9108
7M-1890	Guard As - Final Drive Wear	213-9109
7M-4603	Body - Fuel Valve	311-9348
7M-4926	Retainer - Pin	314-8538
7M-8453	Piston - Clutch	215-1755
7N-0128	Core As - Oil Cooler	299-1994
7N-2957	Cover - Rad Cap	361-1722
7S-7809	Cap As - Radiator	295-6417
7S-7973	Guard - Final Drive Wear	213-9110
7S-9749	Pulley - Gen Drive	264-5888
7T-0119	Support As	299-2066
7T-0204	Bearing - Brace	247-4126
7T-2036	Cap As - Filter	361-1721
8E-6754	Connector As	325-6044
8E-6755	Bearing - Sleeve	325-6026
8E-6756	Bearing - Sleeve	325-6027
8F-5104	Screen As - Oil Pan	314-8539
8H-1383	Rod - Tie	299-2051
8H-1993	Valve - Inlet	256-4765 (Valve Kit)
8H-1994	Valve - Exhaust	256-4765 (Valve Kit)
8H-2810	Case As - Filter	314-8512
8H-7810	Gear	213-8753
8H-7813	Collar	215-1780
8H-7980	Piston	226-0249
8J-2880	Cap - Bearing	295-6420
8M-2549	Rod As - Connector	314-8537
8M-7166	Housing - Screen	297-7192
8P-0187	Nut - Adjusting	219-9676
8P-1865	Bar As - Equalizer	231-3313
8P-6274	Guard As - Lh	226-4949
8P-6275	Guard As - Rh	226-0191
8S-0905	Muffler As	302-2690
8S-1061	Pilot As - Spring	226-0227
8S-7818	Bracket	226-0211
8S-9071	Cage - Bearing	216-7869
9P-0418	Cage	223-6311
9P-0620	Cage - Pinion Bearing	221-1052
9S-1043	Guard As - Guiding	226-0240
9S-1044	Guard As - Guiding	226-0241
9S-1045	Strip - Guard	226-0246
9S-1046	Strip - Guard	226-0247
9S-3955	Cage - Gear Bearing	216-7874
9S-4732	Guard Gp - Spring	226-0195
9S-6875	Pinion - Final Drive	217-7705
9S-6948	Shaft - Center	213-9966
9S-8493	Bolt - Connecting Rod	311-9351
9Y-2988	Breather As	361-1716

Sales Model D7F

Original Part Number	Part Name	Classic Part Number
100-7860	Valve - Inlet	270-4360 (Valve), 270-4362 (Valve Kit)
104-4253	Line As - Fuel Injector	279-4988
104-4254	Line As - Fuel Injector	279-4989
111-8015	Gasket As - Head	279-4977
115-0637	Pump Gp	226-0160
117-1024	Link As.	188-5595
118-1619	Roller Gp - Track	188-5257
118-1620	Roller Gp - DF	188-5258
118-1623	Roller Gp - Track	188-5596
118-1625	Roller Gp - Track	188-5597
122-9405	Bracket As	325-6005
131-3815	Seal Gp - Basic	325-6193
148-7455	Valve - Exhaust	270-4361
160-6305	Cap - Bearing	295-5686
167-8123	Damper As	299-2006
172-5185	Shaft - Water Pump	325-6201
172-5188	Shaft - Water Pump	325-6202
172-5189	Impeller - Pump	295-5687
172-5190	Impeller - Pump	325-6111
172-6712	Impeller - Pump	325-6112
172-7767	Pump Gp - Water	296-1365
196-0028	Gear As - Idler	364-5259
1H-8382	Gear - Oil Pump Drive	226-6103
1M-0598	Gear - Transmission	213-8636
1M-2607	Cage - Bearing	239-7970
1M-2626	Cage - Carrier Bearing	216-7458
1M-2635	Housing - Clutch	216-3549
1M-2637	Housing - Clutch	216-3550
1M-4486	Piston - Clutch	215-1660
1M-5151	Pinion - Bevel	215-1661
1M-8647	Housing As	215-1662
1M-9029	Guard	226-0219
1M-9177	Flywheel	226-6112
1M-9444	Retainer - Spring	299-2046
1N-3576	Block Gp - Cylinder	279-4978
1N-3958	Elbow	325-6087
1P-0579	Housing As	219-9678
1P-0965	Gear - Bevel	213-8215
1P-1006	Strip - Guard	226-0245
1P-1636	Lever As	226-8013
1P-2187	Pump Gp	299-2044
1P-4303	Head As - Cylinder	242-3434
1P-7044	Cage	226-7975
1P-7590	Support As	213-4400
1P-8554	Coupling - Exhaust	325-6052
1P-8717	Roller Gp - Carrier	188-5600
1P-8835	Shaft As	215-1672
1P-9807	Shoe -Track	188-5333
1P-9808	Shoe -Track	175-8802
1P-9809	Shoe -Track	175-8882
1P-9810	Shoe -Track	188-5334
1P-9945	Bracket As - Fan	296-1344
1P-9946	Shaft - Fan	325-6194
1P-9952	Impeller - Pump	314-8685
1S-0876	Bolt - Spring	226-0224
1S-1532	Flange - Shaft	215-1673
1S-1801	Shaft As - Transmission	215-1674
1S-1860	Nut (3/4-16)	188-5856
1S-1888	Bracket - Lamp	297-7147
1S-4701	Pulley - Alt	264-5866
1S-8186	Idler As.	188-5268
1S-8764	Ring - Flywheel Clutch Adjustable	226-8014
1T-0421	Flange As - Output	295-5442
1T-0436	Gear - Pump Drive	247-3367
1T-0437	Housing - Rotating	295-5685
1T-0438	Retainer - Bearing	295-0410
1T-0443	Carrier As - Guide	247-3368
1T-0447	Carrier - Ring	295-0409
1T-0930	Torque Converter	235-0913 (Repair Kit)
1T-1993	Wheel - Turbine	235-0920
1T-2052	Stator As	295-5683
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1695	Pump Gp	279-4980
1W-1698	Housing - Transfer Pump	296-1356
1W-4402	Gear - Camshaft	279-4981
1W-4405	Gear - Crankshaft	279-4982
1W-5912	Tappet As - Guide	325-6223
1W-6541	Plunger As	325-6173
2F-0025	Tube	325-6233
2F-5721	Bearing - Ball	311-9354
2H-4450	Washer - Thrust	325-6237
2H-4482	Collar	229-8218
2H-5046	Link - Flycam	299-2024
2J-3271	Pin	319-3452
2J-5462	Trunnion	297-7264
2J-5596	Pin - Pivot	297-7211
2M-0125	Cylinder - Adjustable	226-0215
2M-0365	Stop - Spring Rh	226-0230
2M-0366	Stop - Spring Lh	226-0231
2M-0369	Pilot - Spring Recoil	226-0226
2M-0398	Sleeve - Bolt	226-0235
2M-2290	Bracket - Ring	299-1979
2M-4668	Retainer - Guard	297-4867
2P-1005	Bearing - Sleeve	296-1342
2P-1170	Shaft As - Gear	296-1367

(Continued)

Sales Model D7F (Continued)

Original Part Number	Part Name	Classic Part Number
2P-1738	Plate As - Oil Pan	325-6164
2P-1739	Tube As - Pump	325-6229
2P-1757	Hub - Fan Pulley	296-1357
2P-1781	Spacer - Oil Pump	325-6214
2P-2519	Tube As - Inlet	325-6230
2P-2784	Ejector As - Exh	367-6063
2P-2922	Gear - Transfer	219-9679
2P-2923	Gear - Transfer	219-9680
2P-3424	Gear - First Reduction	215-1675
2P-3425	Pinion - Sec Reduction	217-7697
2P-3598	Shaft - Output	215-1676
2P-3669	Pinion - Bevel	215-1677
2P-3992	Gear - Bevel	219-9666
2P-4370	Plate - Clutch	325-6166
2P-4701	Shaft As - Gear	297-7257
2P-5608	Pipe - Extension	367-6066
2P-6245	Shaft As - Pump	325-6197
2P-9669	Shoe -Track Master	188-5604
2S-3946	Gear - Final Drive	215-1678
2S-4015	Plunger As - Valve	311-9438
2S-6739	Pulley - Tightener	298-2794
2S-7062	Shaft - Sprocket	219-9673
2S-7063	Nut	300-2584
2S-7064	Cap - Shaft Bearing	299-1991
2S-7099	Hub - Gear	219-2962
2S-7527	Flange - Drum	213-8163
2S-7596	Retainer	215-1679
2S-8356	Rod Gp - Track Adjustable	226-0199
2W-1086	Cover As - Cylinder Head	325-6049
2W-2621	Valve - Inlet	247-6892 (Valve), 241-3381 (Valve Kit)
2W-7255	Shaft - Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear - Water Pump	325-6088
3B-1464	Cap - Bearing	226-0206
3F-4971	Pin	295-5693
3F-6149	Pin	299-2033
3J-2452	Cap - Ball Joint	297-7156
3J-2682	Bracket	296-1345
3J-6167	Bearing - Sleeve	299-1960
3J-6182	Pin As	325-6128
3J-6204	Pin As	325-6129
3J-6442	Bearing - Sleeve	299-1961
3J-6502	Pin	319-3453
3J-6559	Cap - Bearing	296-1346
3J-6560	Screw - Adjustable	297-7240
3J-6561	Screw - Adjustable	297-7241
3J-6570	Support - Bearing	299-2069
3J-6573	Screw - Adjusting	302-2714
3J-6575	Trunnion	297-7265
3J-6576	Bearing	256-4833
3J-6577	Pin - Brace	367-6077
3K-2230	Gear - Planet	219-9658
3L-1425	Bearing - Ball	311-9356
3P-0214	Gear - Transfer	219-9681
3P-0215	Gear - Transfer	219-9682
3P-0395	Cage - Carrier Bearing	217-7723
3P-0615	Shoe - Track Master	188-5601
3P-0616	Shoe - Track Master	175-8881
3P-0617	Shoe - Track Master	188-5246
3P-0618	Shoe - Track Master	188-5602
3P-0620	Shoe - Track Master	188-5606
3P-0628	Link As.	175-8759
3P-3241	Plate - Pressure	325-6167
3P-4142	Plate As	299-2039
3P-4157	Yoke As - Idler	226-0221
3P-4197	Guard As - Idler	226-0189
3P-6560	Stop - Recoil Spring	226-0232
3P-6561	Stop - Recoil Spring	226-0233
3P-6814	Pump Gp	226-0163
3P-8283	Spacer	325-6215
3S-3917	Guard As - Sprocket	226-0188
3S-3918	Guard As - Sprocket	226-4950
3S-8800	Gear - Driven	325-6090
3T-1921	Drum - Inner	229-8227 (Drum), 230-7116 (Steering Clutch Kit)
3T-4482	Guide - Front Idler	226-0248
4F-1121	Bracket	299-1981
4F-1252	Pin	295-5704
4H-4021	Plate As - Loading	229-8219
4J-1616	Bracket	299-1982
4J-1999	Ballstud	314-8625
4J-6167	Bearing - Sleeve	325-6009
4M-7099	Gear - Ring	214-0521
4M-7100	Gear - Ring	214-0522
4M-7102	Gear - Ring	214-0523
4N-2954	Sleeve - Camshaft	299-2059
4N-3281	Line As - Fuel Injector	247-3362
4N-3282	Line As - Fuel Injector	247-3363
4N-3283	Line As - Fuel Injector	247-3364
4N-4356	Pulley - Camshaft	264-5878
4N-4864	Pump Gp - Fuel Transfer	242-3442
4N-5191	Muffler As	298-2785
4N-7693	Crankshaft As	242-3439
4N-8814	Line As - Fuel Injector	247-3366

(Continued)

Sales Model D7F (Continued)

Original Part Number	Part Name	Classic Part Number
4N-9587	Shield - Heat	297-7260
4P-3546	Valve As - Relief	325-6236
4P-9381	Line As - Fuel Injector	279-4984
4P-9382	Line As - Fuel Injector	279-4985
4P-9385	Line As - Fuel Injector	279-4986
4P-9386	Line As - Fuel Injector	279-4987
4S-6707	Piston - Clutch	215-1686
4S-8472	Hood As	296-1355
4S-8708	Housing - Clutch	216-3557
4W-0452	Seal As - Camshaft	325-6191
4W-2446	Damper As	279-4990
5F-7993	Pin	319-3454
5G-3612	Cap Gp	295-6419
5H-5500	Collar - Fly-wheel	302-2704
5J-4321	Trunnion	302-2700
5J-5643	Connector	325-6043
5M-1127	Countershaft	216-3558
5M-1133	Gear - Idler	214-0524
5M-1137	Gear As - Ctrshft	214-0960
5M-1139	Gear As - Ctrshft	214-0961
5M-1141	Gear As - Ctrshft	214-0962
5M-1143	Gear As	214-0963
5M-1145	Gear As - Forward	214-0964
5M-1147	Gear As - Reverse	214-0965
5M-1988	Piston - Steer	219-9691
5M-1990	Pilot - Piston	229-8233
5M-1998	Drum Steer-ing	213-6952
5M-2026	Hubdriving	216-4471
5M-2971	Guard As - Front Idler	226-0190
5M-3470	Gear - Trans-mission	224-1305
5M-3474	Shaft - Output	215-1690
5M-3499	Shaft - Planet	319-3475
5M-3906	Gear - Ring	214-0526
5M-3907	Carrier - Planet	210-8475
5M-3941	Shaft - Planet	215-1691
5M-3942	Shaft - Planet	215-1692
5M-5822	Gear - Pump Drive	247-4120
5M-6120	Gear - Sun	213-8740
5M-6198	Shaft - Planet	297-7245
5M-6199	Shaft As - Planet	215-1694
5M-6208	Gear - Ring	247-4121
5M-6210	Shaft - Planet	219-9683
5M-6211	Shaft - Planet	219-9684
5M-7841	Gear - Ring	214-0525
5M-7864	Pump Gp - Scavenge	226-0169
5M-7869	Gear - Ring	214-0530
5M-7875	Carrier - Front	213-4495
5M-7900	Bolt - Hex Head	311-9349
5P-7807	Bearing - Ball	314-8502
5S-0073	Plate - Steer-ing	302-2692
5S-1211	Cover - Valve	314-8665
5S-4470	Gear - Trans-fer	224-1304
5S-4557	Bearing	311-9360
5S-4863	Holder As - Cage	215-1732
5S-6795	Chamber As	242-3437
5S-6796	Drum - Inner	213-6953 (Drum), 230-7115 (Steer-ing Clutch Kit)
5S-6910	Shoe -Track	188-5603
5S-6911	Shoe -Track	188-5605
5S-9062	Spacer	363-7463
5S-9080	Pulley - Alt Drive	264-5883
6F-2904	Bearing	295-5673
6F-7523	Cap - Bearing	325-6039
6H-3957	Bearing - Ball	311-9358
6I-1346	Pump Gp - Oil	295-5674
6J-5342	Retainer	325-6182
6J-5354	Bearing	297-7142
6J-6229	Pin	299-2030
6J-9258	Trunnion As	256-4846
6N-0714	Pulley - Alt	264-5884
6N-1036	Gear - Oil Pump	279-4991
6N-1965	Line As - Fuel Injector	250-7535
6N-1966	Line As - Fuel Injector	250-7536
6N-8413	Housing - Pump	325-6110
6P-0169	Hub - Fly-wheel Clutch	297-7204
6P-4948	Cap - Final Drive Bearing	226-0205
6P-5172	Guard Gp - Recoil	226-0196
6P-5173	Guard Gp - Recoil	229-8617
6P-5343	Rod Gp - Track Adjust-able	226-0200
6P-6653	Plate - Guide	226-0208
6P-7625	Guard As - Track Roller	226-0185
6P-7626	Guard As - Track Roller	226-0186
6P-7627	Guard As - Track Roller	226-0187
6T-0960	Pad As	367-6089
6T-1980	Collar - Idler End	226-0210
7C-4297	Seal As - Camshaft	325-6192
7F-9541	Pin As - Drawbar	296-1361
7F-9547	Pin As - Drawbar	295-0414
7G-2037	Joint Gp - Univ	226-8017
7G-2038	Tube - Univ Joint	297-7268
7G-2474	Gear - Planet	300-2577
7G-2475	Gear - Planet	223-4815
7G-2476	Gear - Planet	223-4816
7G-2500	Gear - Planet	296-1350
7G-2513	Gear - Planet	215-1734
7G-2517	Gear - Planet	213-8747
7G-2521	Gear - Planet	213-8749
7G-6576	Cage As	216-7859
7H-3598	Bolt - Track	188-5636
7J-1185	Bearing As	297-7146
7J-1333	Bearing - Sleeve	295-6408
7J-1334	Bearing - Sleeve	325-6015
7J-4827	Yoke	299-2070
7J-5131	Trunnion	296-1371
7J-7488	Bearing	256-4836

(Continued)

Sales Model D7F (Continued)

Original Part Number	Part Name	Classic Part Number
7J-9884	Bearing - Sleeve	325-6016
7M-1840	Gear As - Ctrshft	214-0966
7M-1842	Gear As-ctr - Shft	214-0967
7M-1889	Guard As	213-9108
7M-1890	Guard As - Final Drive Wear	213-9109
7M-2167	Ring - Governor Control	308-9919
7M-8453	Piston - Clutch	215-1755
7N-0110	Core As - Oil Cooler	319-3435
7N-0128	Core As - Oil Cooler	299-1994
7N-0165	Core As - Oil Cooler	295-5670
7N-2871	Line As - Fuel Injector	319-8172
7N-2872	Line As - Fuel Injector	319-8173
7N-2874	Line As - Fuel Injector	298-2779
7N-2875	Line As - Fuel Injector	298-2780
7N-2876	Line As - Fuel Injector	298-2781
7N-2949	Pulley	264-5887
7N-2957	Cover - Rad Cap	361-1722
7N-3515	Gear - Camshaft	314-8669
7N-3536	Gear - Fuel	279-4993
7N-5810	Gear As - Idler	233-2179
7N-5815	Gear - Camshaft Rr	233-2181
7N-5819	Gear - Hyd Pump Drive	215-1758
7N-5825	Gear - Drive	215-1759
7N-5910	Impeller - Pump	314-8686
7N-9146	Gear - Flywheel Starter	279-4995
7N-9312	Damper As - Camshaft	299-2005
7N-9805	Pin - Piston	295-6438
7S-3161	Lifter - Valve	279-4996
7S-6723	Bracket - Alternator	299-1978
7S-6964	Gear - Ring	214-0532
7S-7809	Cap As - Radiator	295-6417
7S-7973	Guard - Final Drive Wear	213-9110
7T-0119	Support As	299-2066
7T-0204	Bearing - Brace	247-4126
7W-0450	Gear - Water Pump	279-4997
7W-0507	Gear - Oil Pump Drive	279-4998
7W-0508	Gear - Fuel Pump Drive	296-1351
7W-5687	Hub - Camshaft	314-8684
8E-4434	Shoe -Track	188-5263
8E-4435	Shoe -Track Master	188-5264
8E-4436	Shoe -Track	188-5261
8E-4437	Shoe -Track Master	188-5262
8E-4675	Segment Gp - Sprocket	188-5599 (sprocket), 188-5638 (sprocket group)
8E-6754	Connector As	325-6044
8E-6755	Bearing - Sleeve	325-6026
8E-6756	Bearing - Sleeve	325-6027
8H-1383	Rod - Tie	299-2051
8H-2810	Case As - Filter	314-8512
8H-7810	Gear	213-8753
8H-7813	Collar	215-1780
8H-7980	Piston	226-0249
8H-9806	Gear - Shaft Drive	325-6091
8J-2880	Cap - Bearing	295-6420
8M-0874	Plunger As - Valve	311-9439
8M-7166	Housing - Screen	297-7192
8M-8619	Cage - Bearing	217-7725
8M-8623	Gear - Sun	213-8755
8M-8628	Flange - Joint	217-9776
8M-8642	Housing - Clutch	219-9669
8M-8644	Housing - Clutch	215-1782
8M-8646	Plate As - Center	216-3583
8M-8650	Piston - Clutch	217-9778
8M-8652	Shaft	297-7252
8M-8677	Carrier - Planet	213-4449
8N-0002	Trunnion As	314-8728
8N-0875	Valve - Exhaust	247-6893 (Valve), 241-3381 (Valve Kit)
8N-1187	Head Gp - Cylinder	242-3435
8N-1721	Rod As - Conn	269-5291
8N-1984	Rod As - Conn	242-3441
8N-2510	Shaft	325-6208
8N-2641	Sleeve	325-6210
8N-3180	Body As - Piston	250-6563
8N-3181	Piston Gp - Basic	250-6555 (Liner Kit)
8N-3182	Body As - Piston	250-6564 (Piston As), 250-6556 (Liner Kits)
8N-3183	Piston Gp - Basic	250-6556 (Liner Kit)
8N-3251	Shaft As - Rocker Arm	314-8711
8N-3325	Arm Gp - Rocker	314-8623
8N-3327	Arm Gp - Rocker	314-8624
8N-5305	Spacer	363-7464
8N-5929	Cover - Water Pump	296-1349
8N-6796	Head Gp - Cylinder	269-5290
8N-7315	Tube As - Outlet	325-6232
8N-8225	Bearing - Main	314-8652
8N-9733	Line As - Fuel Injector	319-8174
8P-0187	Nut - Adjusting	219-9676
8P-1865	Bar As - Equalizer	231-3313
8P-6274	Guard As - Lh	226-4949
8P-6275	Guard As - Rh	226-0191

(Continued)

Sales Model D7F (Continued)

Original Part Number	Part Name	Classic Part Number
8P-7790	Valve Gp - Press	247-4437
8S-0248	Breather As	325-6033
8S-0493	Shaft As - Pump	325-6198
8S-1061	Pilot As - Spring	226-0227
8S-3970	Chamber As	242-3438
8S-7818	Bracket	226-0211
8S-9070	Carrier - Front	213-4464
8S-9071	Cage - Bearing	216-7869
9F-7101	Bushing - Collar	299-1988
9H-2256	Pump Gp	311-9443
9K-8757	Rod End - Bearing	311-9361
9M-1500	Shaft - Planet	219-9685
9M-1502	Cage - Bearing	219-9686
9M-1995	Gear - Sun	213-8756
9M-1996	Shaft - Planet	215-1875
9M-2028	Gear - Sun	214-0959
9M-2049	Gear - Ring	214-0533
9M-3025	Cover As	299-2001
9M-4789	Shaft - Gov Control	297-7256
9M-8119	Retainer - Inlet	226-8022
9N-5251	Piston Gp - Basic	250-6557 (Liner Kit)
9N-5769	Cover - Housing	325-6050
9P-0418	Cage	223-6311
9P-0620	Cage - Pinion Bearing	221-1052
9P-5363	Piston - Clutch	219-9687
9P-5379	Housing - Clutch	215-1904
9S-1043	Guard As - Guiding	226-0240
9S-1044	Guard As - Guiding	226-0241
9S-1045	Strip - Guard	226-0246
9S-1046	Strip - Guard	226-0247
9S-2354	Manifold - Exhaust	261-0888
9S-2355	Manifold - Exhaust	261-0891
9S-3955	Cage - Gear Bearing	216-7874
9S-4732	Guard Gp - Spring	226-0195
9S-5265	Shaft As	215-1945
9S-5277	Gear - Transfer	213-8758
9S-6129	Pulley - Alternator Drive	264-5891
9S-6590	Pump Gp - Oil	226-0176
9S-6788	Pump Gp - Oil	217-2602
9S-6875	Pinion - Final Drive	217-7705
9S-6948	Shaft - Center	213-9966
9S-8679	Chamber As	325-6042
9S-8789	Plate - Clutch	302-2712
9S-8802	Gear - Ring	214-0952

Sales Model D7G

Original Part Number	Part Name	Classic Part Number
100-7860	Valve - Inlet	270-4360 (Valve), 270-4362 (Valve Kit)
104-4253	Line As - Fuel Injector	279-4988
104-4254	Line As - Fuel Injector	279-4989
111-8015	Gasket As - Head	279-4977
115-0637	Pump Gp	226-0160
117-1024	Link As.	188-5595
118-1619	Roller Gp - Track	188-5257
118-1620	Roller Gp - DF	188-5258
118-1623	Roller Gp - Track	188-5596
118-1625	Roller Gp - Track	188-5597
122-9405	Bracket As	325-6005
127-5537	Core As	325-6045
129-2381	Gear - Planet	275-5274
131-3815	Seal Gp - Basic	325-6193
148-7455	Valve - Exhaust	270-4361
160-6305	Cap - Bearing	295-5686
165-4262	Body As - Piston	270-4351
167-8123	Damper As	299-2006
172-5185	Shaft - Water Pump	325-6201
172-5188	Shaft - Water Pump	325-6202
172-5189	Impeller - Pump	295-5687
172-5190	Impeller - Pump	325-6111
172-6712	Impeller - Pump	325-6112
172-7767	Pump Gp - Water	296-1365
190-8609	Valve - Fill	360-2288
196-0028	Gear As - Idler	364-5259
1H-8382	Gear - Oil Pump Drive	226-6103
1M-9029	Guard	226-0219
1M-9177	Flywheel	226-6112
1M-9444	Retainer - Spring	299-2046
1N-3576	Block Gp - Cylinder	279-4978
1N-3958	Elbow	325-6087
1P-0579	Housing As	219-9678
1P-0965	Gear - Bevel	213-8215
1P-1006	Strip - Guard	226-0245
1P-1636	Lever As	226-8013
1P-2187	Pump Gp	299-2044
1P-7044	Cage	226-7975
1P-7590	Support As	213-4400
1P-8554	Coupling - Exhaust	325-6052
1P-8717	Roller Gp - Carrier	188-5600
1P-8835	Shaft As	215-1672
1P-9807	Shoe -Track	188-5333
1P-9808	Shoe -Track	175-8802
1P-9809	Shoe -Track	175-8882
1P-9810	Shoe -Track	188-5334
1P-9945	Bracket As - Fan	296-1344
1P-9946	Shaft - Fan	325-6194

(Continued)

Sales Model D7G (Continued)

Original Part Number	Part Name	Classic Part Number
1P-9952	Impeller - Pump	314-8685
1S-0876	Bolt - Spring	226-0224
1S-1532	Flange - Shaft	215-1673
1S-1801	Shaft As - Transmission	215-1674
1S-1860	Nut (3/4-16)	188-5856
1S-1888	Bracket - Lamp	297-7147
1S-4701	Pulley - Alt	264-5866
1S-8186	Idler As.	188-5268
1S-8764	Ring - Fly-wheel Clutch Adjustable	226-8014
1T-0421	Flange As - Output	295-5442
1T-0436	Gear - Pump Drive	247-3367
1T-0437	Housing - Rotating	295-5685
1T-0438	Retainer - Bearing	295-0410
1T-0443	Carrier As - Guide	247-3368
1T-0447	Carrier - Ring	295-0409
1T-0930	Torque Con-verter	235-0913 (Repair Kit)
1T-1993	Wheel - Tur-bine	235-0920
1T-2052	Stator As	295-5683
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1695	Pump Gp	279-4980
1W-1698	Housing - Transfer Pump	296-1356
1W-4402	Gear - Cam-shaft	279-4981
1W-4405	Gear - Crank-shaft	279-4982
1W-4407	Hub - Fan Pulley	296-1358
1W-5912	Tappet As - Guide	325-6223
1W-6541	Plunger As	325-6173
1W-9229	Muffler As	302-4282
236-7724	Retainer	299-2048
244-1090	Alarm - Back up	360-2345
2F-0025	Tube	325-6233
2F-5721	Bearing - Ball	311-9354

Original Part Number	Part Name	Classic Part Number
2H-4450	Washer - Thrust	325-6237
2H-4482	Collar	229-8218
2H-5046	Link - Flycam	299-2024
2J-5462	Trunnion	297-7264
2J-5596	Pin - Pivot	297-7211
2J-8489	Bearing - Sleeve	295-5691
2M-0125	Cylinder - Adjustable	226-0215
2M-0369	Pilot - Spring Recoil	226-0226
2M-0398	Sleeve - Bolt	226-0235
2M-2290	Bracket - Ring	299-1979
2M-4668	Retainer - Guard	297-4867
2P-1005	Bearing - Sleeve	296-1342
2P-1170	Shaft As - Gear	296-1367
2P-1738	Plate As - Oil Pan	325-6164
2P-1739	Tube As - Pump	325-6229
2P-1757	Hub - Fan Pulley	296-1357
2P-1781	Spacer - Oil Pump	325-6214
2P-2519	Tube As - Inlet	325-6230
2P-2719	Pipe	363-7454
2P-2784	Ejector As - Exh	367-6063
2P-2922	Gear - Trans-fer	219-9679
2P-2923	Gear - Trans-fer	219-9680
2P-3424	Gear - First Reduction	215-1675
2P-3425	Pinion - Sec Reduction	217-7697
2P-3598	Shaft - Output	215-1676
2P-3669	Pinion - Bevel	215-1677
2P-3992	Gear - Bevel	219-9666
2P-4370	Plate - Clutch	325-6166
2P-4701	Shaft As - Gear	297-7257
2P-5608	Pipe - Exten-sion	367-6066
2P-6245	Shaft As - Pump	325-6197

Original Part Number	Part Name	Classic Part Number
2P-9669	Shoe -Track Master	188-5604
2P-9670	Bolt Master	188-5637
2R-0179	Pin As	325-6127
2S-3946	Gear - Final Drive	215-1678
2S-6739	Pulley - Tight-ener	298-2794
2S-7062	Shaft - Sprocket	219-9673
2S-7063	Nut	300-2584
2S-7064	Cap - Shaft Bearing	299-1991
2S-7099	Hub - Gear	219-2962
2S-7527	Flange - Drum	213-8163
2S-7596	Retainer	215-1679
2W-1086	Cover As - Cylinder Head	325-6049
2W-2621	Valve - Inlet	247-6892 (Valve), 241-3381 (Valve Kit)
2W-5540	Core, Radia-tor (Folded)	363-7452
2W-7255	Shaft - Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear - Water Pump	325-6088
2W-9978	Core As - Oil Cooler	279-4983
3B-1464	Cap - Bearing	226-0206
3F-4971	Pin	295-5693
3F-6149	Pin	299-2033
3F-6185	Pin	295-5694
3F-6612	Cap - Ball Joint	297-7155
3J-2452	Cap - Ball Joint	297-7156
3J-2682	Bracket	296-1345
3J-4284	Cap - Bearing	314-8656
3J-4352	Arm As - Brace	297-7137
3J-6167	Bearing - Sleeve	299-1960
3J-6182	Pin As	325-6128
3J-6204	Pin As	325-6129
3J-6442	Bearing - Sleeve	299-1961
3J-6502	Pin	319-3453
3J-6559	Cap - Bearing	296-1346

(Continued)

Sales Model D7G (Continued)

Original Part Number	Part Name	Classic Part Number
3J-6560	Screw - Adjustable	297-7240
3J-6561	Screw - Adjustable	297-7241
3J-6570	Support - Bearing	299-2069
3J-6573	Screw - Adjusting	302-2714
3J-6575	Trunnion	297-7265
3J-6576	Bearing	256-4833
3J-6577	Pin - Brace	367-6077
3L-1425	Bearing - Ball	311-9356
3P-0395	Cage - Carrier Bearing	217-7723
3P-0615	Shoe - Track Master	188-5601
3P-0616	Shoe - Track Master	175-8881
3P-0617	Shoe - Track Master	188-5246
3P-0618	Shoe - Track Master	188-5602
3P-0620	Shoe - Track Master	188-5606
3P-0628	Link As.	175-8759
3P-3241	Plate - Pressure	325-6167
3P-3935	Shaft	299-2053
3P-4142	Plate As	299-2039
3P-4157	Yoke As - Idler	226-0221
3P-4197	Guard As - Idler	226-0189
3P-6560	Stop - Recoil Spring	226-0232
3P-6561	Stop - Recoil Spring	226-0233
3P-7623	Pump Gp	217-2598
3P-8283	Spacer	325-6215
3S-3917	Guard As - Sprocket	226-0188
3S-3918	Guard As - Sprocket	226-4950
3S-8800	Gear - Driven	325-6090
3T-1921	Drum - Inner	229-8227 (Drum), 230-7116 (Steering Clutch Kit)
3T-4482	Guide - Front Idler	226-0248
4F-1121	Bracket	299-1981
4F-1252	Pin	295-5704
4F-4974	Clamp	311-9373
4H-4021	Plate As - Loading	229-8219
4J-1612	Pin	308-9896
4J-1614	Pin - Pivot	297-7214
4J-1616	Bracket	299-1982
4J-2414	Trunnion	296-1370
4J-2847	Trunnion As	297-7267
4J-3583	Screw - Adjusting	297-7242
4J-3589	Cap - Ball Joint	297-7157
4J-3590	Bearing	297-7139
4J-3591	Bracket - Rh	299-1983
4J-6167	Bearing - Sleeve	325-6009
4N-2954	Sleeve - Camshaft	299-2059
4N-3281	Line As - Fuel Injector	247-3362
4N-3282	Line As - Fuel Injector	247-3363
4N-3283	Line As - Fuel Injector	247-3364
4N-4356	Pulley - Camshaft	264-5878
4N-4539	Sleeve	314-8720
4N-4782	Pulley	325-6176
4N-4864	Pump Gp - Fuel Transfer	242-3442
4N-5191	Muffler As	298-2785
4N-7693	Crankshaft As	242-3439
4N-8591	Coupling - Exhaust	325-6053
4N-8814	Line As - Fuel Injector	247-3366
4N-9587	Shield - Heat	297-7260
4P-3546	Valve As - Relief	325-6236
4P-9381	Line As - Fuel Injector	279-4984
4P-9382	Line As - Fuel Injector	279-4985
4P-9385	Line As - Fuel Injector	279-4986
4P-9386	Line As - Fuel Injector	279-4987
4S-6707	Piston - Clutch	215-1686
4S-8472	Hood As	296-1355
4S-8708	Housing - Clutch	216-3557
4V-3603	Pin As	319-3441
4W-0452	Seal As - Camshaft	325-6191
4W-2446	Damper As	279-4990
5G-3612	Cap Gp	295-6419
5H-5500	Collar - Flywheel	302-2704
5J-4321	Trunnion	302-2700
5J-5643	Connector	325-6043
5M-1127	Countershaft	216-3558
5M-1133	Gear - Idler	214-0524
5M-1137	Gear As - Ctrshft	214-0960
5M-1139	Gear As - Ctrshft	214-0961
5M-1141	Gear As - Ctrshft	214-0962
5M-1143	Gear As	214-0963
5M-1145	Gear As - Forward	214-0964
5M-1147	Gear As - Reverse	214-0965
5M-1988	Piston - Steer	219-9691
5M-1990	Pilot - Piston	229-8233
5M-1998	Drum Steering	213-6952
5M-2026	Hubdriving	216-4471
5M-5822	Gear - Pump Drive	247-4120
5M-6120	Gear - Sun	213-8740
5M-6198	Shaft - Planet	297-7245
5M-6199	Shaft As - Planet	215-1694
5M-6208	Gear - Ring	247-4121
5M-6210	Shaft - Planet	219-9683
5M-6211	Shaft - Planet	219-9684
5M-7841	Gear - Ring	214-0525
5M-7864	Pump Gp - Scavenge	226-0169
5M-7869	Gear - Ring	214-0530
5M-7875	Carrier - Front	213-4495
5M-7900	Bolt - Hex Head	311-9349
5P-7807	Bearing - Ball	314-8502
5S-0073	Plate - Steering	302-2692
5S-1211	Cover - Valve	314-8665
5S-4557	Bearing	311-9360
5S-4863	Holder As - Cage	215-1732
5S-6795	Chamber As	242-3437

(Continued)

Sales Model D7G (Continued)

Original Part Number	Part Name	Classic Part Number
5S-6796	Drum - Inner	213-6953 (Drum), 230-7115 (Steering Clutch Kit)
5S-6910	Shoe -Track	188-5603
5S-6911	Shoe -Track	188-5605
5S-7609	Pulley - Alt Drive	264-5881
5S-9062	Spacer	363-7463
5S-9080	Pulley - Alt Drive	264-5883
6F-7523	Cap - Bearing	325-6039
6H-3957	Bearing - Ball	311-9358
6I-1346	Pump Gp - Oil	295-5674
6J-0774	Trunnion	256-4844
6J-5342	Retainer	325-6182
6J-5354	Bearing	297-7142
6J-6229	Pin	299-2030
6J-9258	Trunnion As	256-4846
6L-9211	Idler Gp	200-9237
6N-0714	Pulley - Alt	264-5884
6N-1036	Gear - Oil Pump	279-4991
6N-1965	Line As - Fuel Injector	250-7535
6N-1966	Line As - Fuel Injector	250-7536
6N-8413	Housing - Pump	325-6110
6P-0169	Hub - Flywheel Clutch	297-7204
6P-4948	Cap - Final Drive Bearing	226-0205
6P-5172	Guard Gp - Recoil	226-0196
6P-5173	Guard Gp - Recoil	229-8617
6P-5343	Rod Gp - Track Adjustable	226-0200
6P-6653	Plate - Guide	226-0208
6P-7625	Guard As - Track Roller	226-0185
6P-7626	Guard As - Track Roller	226-0186
6P-7627	Guard As - Track Roller	226-0187
6T-0960	Pad As	367-6089
6T-1980	Collar - Idler End	226-0210
7C-4297	Seal As - Camshaft	325-6192
7D-7889	Gear - Ring	275-5276
7F-9541	Pin As - Drawbar	296-1361
7F-9547	Pin As - Drawbar	295-0414
7G-2037	Joint Gp - Univ	226-8017
7G-2038	Tube - Univ Joint	297-7268
7G-2474	Gear - Planet	300-2577
7G-2475	Gear - Planet	223-4815
7G-2476	Gear - Planet	223-4816
7G-2500	Gear - Planet	296-1350
7G-2513	Gear - Planet	215-1734
7G-6576	Cage As	216-7859
7G-7681	Shaft As	307-1530
7H-3598	Bolt - Track	188-5636
7J-1185	Bearing As	297-7146
7J-1333	Bearing - Sleeve	295-6408
7J-1334	Bearing - Sleeve	325-6015
7J-4827	Yoke	299-2070
7J-5131	Trunnion	296-1371
7J-7488	Bearing	256-4836
7J-9344	Bearing - Sleeve	360-2334
7J-9884	Bearing - Sleeve	325-6016
7K-9638	Bearing - Sleeve	365-8827
7M-1840	Gear As - Ctrshft	214-0966
7M-1842	Gear As-ctr - Shft	214-0967
7M-1889	Guard As	213-9108
7M-1890	Guard As - Final Drive Wear	213-9109
7N-0110	Core As - Oil Cooler	319-3435
7N-0128	Core As - Oil Cooler	299-1994
7N-0165	Core As - Oil Cooler	295-5670
7N-1164	Mount As	295-5451
7N-2871	Line As - Fuel Injector	319-8172
7N-2872	Line As - Fuel Injector	319-8173
7N-2874	Line As - Fuel Injector	298-2779
7N-2875	Line As - Fuel Injector	298-2780
7N-2876	Line As - Fuel Injector	298-2781
7N-2949	Pulley	264-5887
7N-2957	Cover - Rad Cap	361-1722
7N-3515	Gear - Camshaft	314-8669
7N-3536	Gear - Fuel	279-4993
7N-5810	Gear As - Idler	233-2179
7N-5815	Gear - Camshaft Rr	233-2181
7N-5819	Gear - Hyd Pump Drive	215-1758
7N-5825	Gear - Drive	215-1759
7N-5910	Impeller - Pump	314-8686
7N-9146	Gear - Flywheel Starter	279-4995
7N-9312	Damper As - Camshaft	299-2005
7N-9805	Pin - Piston	295-6438
7S-3161	Lifter - Valve	279-4996
7S-6723	Bracket - Alternator	299-1978
7S-6964	Gear - Ring	214-0532
7S-7809	Cap As - Radiator	295-6417
7S-7973	Guard - Final Drive Wear	213-9110
7T-0119	Support As	299-2066
7T-0204	Bearing - Brace	247-4126
7T-2036	Cap As - Filter	361-1721
7W-0450	Gear - Water Pump	279-4997
7W-0507	Gear - Oil Pump Drive	279-4998
7W-0508	Gear - Fuel Pump Drive	296-1351
7W-5687	Hub - Camshaft	314-8684
8D-3591	Carrier - Planet	301-4769
8D-3744	Shaft - Drive	275-5283
8D-3877	Gear - Sun	275-5278
8E-4434	Shoe -Track	188-5263
8E-4435	Shoe -Track Master	188-5264
8E-4436	Shoe -Track	188-5261

(Continued)

Sales Model D7G (Continued)

Original Part Number	Part Name	Classic Part Number
8E-4437	Shoe -Track Master	188-5262
8E-4675	Segment Gp - Sprocket	188-5599 (sprocket), 188-5638 (sprocket group)
8E-6754	Connector As	325-6044
8E-6755	Bearing - Sleeve	325-6026
8E-6756	Bearing - Sleeve	325-6027
8H-1383	Rod - Tie	299-2051
8H-2810	Case As - Filter	314-8512
8H-7810	Gear	213-8753
8H-7813	Collar	215-1780
8H-7980	Piston	226-0249
8H-9806	Gear - Shaft Drive	325-6091
8J-2880	Cap - Bearing	295-6420
8M-0874	Plunger As - Valve	311-9439
8M-7166	Housing - Screen	297-7192
8M-8619	Cage - Bearing	217-7725
8M-8623	Gear - Sun	213-8755
8M-8628	Flange - Joint	217-9776
8M-8642	Housing - Clutch	219-9669
8M-8644	Housing - Clutch	215-1782
8M-8646	Plate As - Center	216-3583
8M-8650	Piston - Clutch	217-9778
8M-8652	Shaft	297-7252
8M-8677	Carrier - Planet	213-4449
8N-0002	Trunnion As	314-8728
8N-0875	Valve - Exhaust	247-6893 (Valve), 241-3381 (Valve Kit)
8N-1187	Head Gp - Cylinder	242-3435
8N-1214	Mount As	325-6125
8N-1721	Rod As - Conn	269-5291
8N-1965	Tube - Disposal	325-6235
8N-2510	Shaft	325-6208
8N-2641	Sleeve	325-6210
8N-3251	Shaft As - Rocker Arm	314-8711
8N-3325	Arm Gp - Rocker	314-8623
8N-3327	Arm Gp - Rocker	314-8624
8N-5305	Spacer	363-7464
8N-5929	Cover - Water Pump	296-1349
8N-6796	Head Gp - Cylinder	269-5290
8N-7315	Tube As - Outlet	325-6232
8N-8225	Bearing - Main	314-8652
8N-9733	Line As - Fuel Injector	319-8174
8P-0187	Nut - Adjusting	219-9676
8P-1865	Bar As - Equalizer	231-3313
8P-6274	Guard As - Lh	226-4949
8P-6275	Guard As - Rh	226-0191
8P-7790	Valve Gp - Press	247-4437
8S-0248	Breather As	325-6033
8S-0493	Shaft As - Pump	325-6198
8S-1061	Pilot As - Spring	226-0227
8S-3970	Chamber As	242-3438
8S-7716	Manifold - Exhaust	295-0415
8S-7717	Manifold - Exhaust	261-0894
8S-7718	Manifold - Exhaust	295-0416
8S-7818	Bracket	226-0211
8W-2308	Shaft - Planet	275-5285
8W-8317	Sprocket	275-5287
9F-7101	Bushing - Collar	299-1988
9K-8757	Rod End - Bearing	311-9361
9M-1500	Shaft - Planet	219-9685
9M-1502	Cage - Bearing	219-9686
9M-1995	Gear - Sun	213-8756
9M-1996	Shaft - Planet	215-1875
9M-2028	Gear - Sun	214-0959
9M-2049	Gear - Ring	214-0533
9M-3025	Cover As	299-2001
9M-4789	Shaft - Gov Control	297-7256
9M-8119	Retainer - Inlet	226-8022
9N-5251	Piston Gp - Basic	250-6557 (Liner Kit)
9N-5404	Piston Gp - Basic	250-6558 (Liner Kit)
9N-5769	Cover - Housing	325-6050
9P-0418	Cage	223-6311
9P-0620	Cage - Pinion Bearing	221-1052
9P-3242	Plate - Clutch	325-6172
9P-5363	Piston - Clutch	219-9687
9P-5379	Housing - Clutch	215-1904
9S-1043	Guard As - Guiding	226-0240
9S-1044	Guard As - Guiding	226-0241
9S-1045	Strip - Guard	226-0246
9S-1046	Strip - Guard	226-0247
9S-2354	Manifold - Exhaust	261-0888
9S-2355	Manifold - Exhaust	261-0891
9S-3955	Cage - Gear Bearing	216-7874
9S-5265	Shaft As	215-1945
9S-6590	Pump Gp - Oil	226-0176
9S-6875	Pinion - Final Drive	217-7705
9S-8679	Chamber As	325-6042
9S-8789	Plate - Clutch	302-2712

Sales Model D7H

Original Part Number	Part Name	Classic Part Number
100-7860	Valve - Inlet	270-4360 (Valve), 270-4362 (Valve Kit)
104-4253	Line As - Fuel Injector	279-4988
104-4254	Line As - Fuel Injector	279-4989
111-0416	Guard As (rh)	325-6096
111-0419	Guard As (lh)	325-6097
111-0431	Guard As	325-6098
111-8015	Gasket As - Head	279-4977
112-5585	Shaft - Planet	308-9932
122-9405	Bracket As	325-6005
127-5537	Core As	325-6045
128-0307	Plate	325-6165
131-3815	Seal Gp - Basic	325-6193
131-7736	Support As - Engine	325-6222
148-7455	Valve - Exhaust	270-4361
155-2819	Ejector As - Exhaust	325-6078
160-6305	Cap - Bearing	295-5686
160-6308	Cap - Bearing	325-6036
165-4262	Body As - Piston	270-4351
165-7211	Strip	325-6219
172-5185	Shaft - Water Pump	325-6201
172-5188	Shaft - Water Pump	325-6202
172-5189	Impeller - Pump	295-5687
172-5190	Impeller - Pump	325-6111
172-6712	Impeller - Pump	325-6112
172-7767	Pump Gp - Water	296-1365
190-8609	Valve - Fill	360-2288
196-0028	Gear As - Idler	364-5259
1H-4106	Pin As - Drawbar	325-6126
1H-8262	Shaft	226-8016
1H-8382	Gear - Oil Pump Drive	226-6103
1H-8937	Drumbrake	226-7993
1M-9177	Flywheel	226-6112
1N-3576	Block Gp - Cylinder	279-4978
1N-3958	Elbow	325-6087
1P-1636	Lever As	226-8013
1P-7044	Cage	226-7975
1P-8554	Coupling - Exhaust	325-6052
1S-4701	Pulley - Alt	264-5866
1S-8764	Ring - Flywheel Clutch Adjustable	226-8014
1T-0421	Flange As - Output	295-5442
1T-0437	Housing - Rotating	295-5685
1T-0438	Retainer - Bearing	295-0410
1T-0447	Carrier - Ring	295-0409
1T-0521	Retainer - Bearing	325-6180
1T-0699	Impeller - Converter	235-1808
1T-1386	Yoke - Univ Joint	325-6239
1T-1880	Carrier - Ring	295-0408
1T-1993	Wheel - Turbine	235-0920
1T-2050	Carrier As - Stat	325-6040
1T-2052	Stator As	295-5683
1U-0612	Pin	325-6135
1U-0725	Retainer	314-8707
1U-0872	Pin	325-6136
1U-0873	Pin	325-6137
1U-0990	Pin	325-6138
1U-1204	Trunnion	325-6224
1W-1669	Piston	325-6158
1W-1695	Pump Gp	279-4980
1W-1698	Housing - Transfer Pump	296-1356
1W-4369	Pulley - Alt	296-1340
1W-4402	Gear - Camshaft	279-4981
1W-4405	Gear - Crankshaft	279-4982
1W-4407	Hub - Fan Pulley	296-1358
1W-4737	Gear - Camshaft	295-5688
1W-4738	Bearing - Sleeve	325-6020
1W-4740	Gear As - Drive	295-5689
1W-4746	Retainer - Gear	295-5690
1W-5912	Tappet As - Guide	325-6223
1W-6541	Plunger As	325-6173
1W-9229	Muffler As	302-4282
208-5026	Pin	325-6133
244-1090	Alarm - Back up	360-2345
258-2308	Bearing - Sleeve	325-6019
2D-5658	Bearing - Ball	301-4628
2F-0025	Tube	325-6233
2F-5721	Bearing - Ball	311-9354
2H-4450	Washer - Thrust	325-6237
2H-4482	Collar	229-8218
2H-5046	Link - Flycam	299-2024
2K-3592	Boss	314-8501
2M-2290	Bracket - Ring	299-1979
2P-1005	Bearing - Sleeve	296-1342
2P-1170	Shaft As - Gear	296-1367
2P-1502	Gear - Shaft	214-0956
2P-1503	Gear - First	213-8637
2P-1738	Plate As - Oil Pan	325-6164
2P-1739	Tube As - Pump	325-6229
2P-1757	Hub - Fan Pulley	296-1357
2P-1781	Spacer - Oil Pump	325-6214
2P-2519	Tube As - Inlet	325-6230
2P-2719	Pipe	363-7454
2P-4370	Plate - Clutch	325-6166
2P-6245	Shaft As - Pump	325-6197
2R-0179	Pin As	325-6127
2S-3803	Gear	226-6106
2S-3804	Gear - Sliding	226-6107
2W-1086	Cover As - Cylinder Head	325-6049
2W-2621	Valve - Inlet	247-6892 (Valve), 241-3381 (Valve Kit)

(Continued)

Sales Model D7H (Continued)

Original Part Number	Part Name	Classic Part Number
2W-5540	Core, Radiator (Folded)	363-7452
2W-6757	Trunnion As	295-5678
2W-7255	Shaft - Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear - Water Pump	325-6088
2W-8494	Pulley - Alt	295-5692
2W-9978	Core As - Oil Cooler	279-4983
3F-4971	Pin	295-5693
3G-0910	Cap - Bearing	325-6037
3G-1525	Bearing - Sleeve	325-6006
3G-4929	Pin	325-6139
3J-2682	Bracket	296-1345
3J-6167	Bearing - Sleeve	299-1960
3J-6182	Pin As	325-6128
3J-6442	Bearing - Sleeve	299-1961
3P-3241	Plate - Pressure	325-6167
3P-7640	Gear - Ctrshft	325-6093
3P-7641	Gear - Ctrshft	325-6094
3P-7642	Gear - Ctrshft	302-2668
3P-7643	Gear - Pinion Shft	302-2669
3P-7644	Gear - Pinion Shft	302-2706
3P-8283	Spacer	325-6215
3S-8800	Gear - Driven	325-6090
3T-0997	Bearing - Sleeve	307-1524
3T-1446	Pump Gp	325-6178
3T-4008	Gear - Planet	295-5444
3T-4011	Shaft As - Planet	295-5698
3T-4299	Joint Gp - Univ	325-6114
3T-4516	Trunnion As	325-6226
3T-4568	Shaft - Planet	314-8712
3T-4824	Gear - Planet	295-5699
3T-5021	Carrier - Planet	295-5700
3T-5200	Carrier - Planet	295-5701
3T-5294	Spacer	325-6216
3T-5297	Pin	325-6145
3T-5672	Gear As - Oil Pump	295-5447
3T-5674	Gear As - Oil Pump	295-5449
3T-5929	Gear	288-8718
3T-6247	Shaft	314-8713
3T-7192	Guard As	325-6100
3T-7195	Guard As	325-6101
3T-7399	Piston	325-6159
3T-7701	Cylinder As	325-6058
3T-7710	Guide	325-6102
3T-7711	Guide	325-6103
3W-0640	Piston	325-6160
3Y-9984	Manifold - Exhaust	325-6123
3Y-9985	Manifold - Exhaust	325-6124
4F-1252	Pin	295-5704
4H-4021	Plate As - Loading	229-8219
4J-2414	Trunnion	296-1370
4J-6167	Bearing - Sleeve	325-6009
4J-6374	Bearing - Sleeve	295-6407
4K-1102	Bearing - Sleeve	325-6010
4N-4864	Pump Gp - Fuel Transfer	242-3442
4N-7693	Crankshaft As	242-3439
4N-8591	Coupling - Exhaust	325-6053
4P-3546	Valve As - Relief	325-6236
4P-9381	Line As - Fuel Injector	279-4984
4P-9382	Line As - Fuel Injector	279-4985
4P-9385	Line As - Fuel Injector	279-4986
4P-9386	Line As - Fuel Injector	279-4987
4S-8472	Hood As	296-1355
4T-0202	Pin As	325-6130
4T-0998	Lever	314-8687
4T-5405	Trunnion As	319-3476
4T-5495	Ballstud	314-8626
4T-8088	Screw	325-6188
4T-9444	Pin	325-6146
4W-0452	Seal As - Camshaft	325-6191
4W-2042	Spacer	325-6217
4W-2446	Damper As	279-4990
5H-5500	Collar - Flywheel	302-2704
5J-1204	Pin As	325-6131
5J-4321	Trunnion	302-2700
5J-5643	Connector	325-6043
5M-5073	Joint Gp - Univ	325-6113
5M-7336	Retainer - Washer	325-6181
5M-7340	Cage - Bearing	325-6034
5M-7342	Flange - Shaft	215-1696
5M-7344	Gear - Bevel	213-8741
5M-7345	Gear - Bevel	214-0957
5M-7349	Gear - Bevel	213-8742
5M-7352	Gear - Bevel	217-7713
5M-7353	Gear - Bevel	217-7714
5M-7355	Gear - Reverse	216-3581
5P-7807	Bearing - Ball	314-8502
5P-8194	Ring - Retaining	308-9920
5S-1211	Cover - Valve	314-8665
5S-4557	Bearing	311-9360
5S-6795	Chamber As	242-3437
5S-9062	Spacer	363-7463
5S-9080	Pulley - Alt Drive	264-5883
6E-1108	Bearing - Sleeve	325-6023
6F-2904	Bearing	295-5673
6F-3183	Cap - Bearing	325-6038
6F-7523	Cap - Bearing	325-6039
6H-3957	Bearing - Ball	311-9358
6I-0341	Line As - Fuel Injector	325-6117
6I-0342	Line As - Fuel Injector	325-6118
6I-0343	Line As - Fuel Injector	325-6119
6I-0344	Line As - Fuel Injector	325-6120
6I-0345	Line As - Fuel Injector	325-6121
6I-0346	Line As - Fuel Injector	325-6122
6I-1346	Pump Gp - Oil	295-5674
6J-5342	Retainer	325-6182
6N-1036	Gear - Oil Pump	279-4991
6N-8413	Housing - Pump	325-6110

(Continued)

Sales Model D7H (Continued)

Original Part Number	Part Name	Classic Part Number
6P-0169	Hub - Fly-wheel Clutch	297-7204
6P-5404	Plate & Brake	325-6168
6P-7704	Carrier - Ring	314-8658
6S-3457	Pin	325-6147
6T-0064	Shaft - Planet	295-6442
6T-0234	Retainer	325-6183
6T-0240	Retainer	325-6184
6T-0241	Piston	325-6161
6T-0243	Plate - Thrust	325-6169
6T-0248	Ring - Seal	295-6440
6T-3080	Plate& Brake	325-6170
6T-7882	Gear - Planet	296-1352
6T-8250	Retainer	319-3473
6Y-0926	Gear - Planet	295-6427
6Y-0984	Gear - Ring	295-6428
6Y-4819	Carrier - Planet	296-1348
6Y-5812	Bearing - Sleeve	325-6012
6Y-6752	Pin	325-6150
6Y-6931	Shaft As	325-6206
6Y-7471	Pin - Pivot	325-6152
6Y-7474	Pin - Pivot	325-6153
6Y-9468	Retainer As	325-6185
7C-3567	Mount As	314-8689
7C-4297	Seal As - Camshaft	325-6192
7F-9541	Pin As - Drawbar	296-1361
7G-2500	Gear - Planet	296-1350
7G-2516	Gear - Planet	283-5203
7G-2824	Piston	295-6439
7G-2828	Plate - Clutch	325-6171
7G-2830	Ring - Seal	295-6441
7G-5776	Shaft - Planet	325-6195
7G-5780	Shaft - Planet	325-6196
7G-5783	Gear - Planet	288-8724
7G-5784	Gear - Planet	288-8725
7G-7013	Coupling - Pump Drive	295-5450
7G-7218	Carrier - Planet	283-5205
7G-7681	Shaft As	307-1530
7G-7724	Piston - Clutch	283-5206
7J-1333	Bearing - Sleeve	295-6408
7J-1334	Bearing - Sleeve	325-6015
7J-5131	Trunnion	296-1371
7J-6461	Crown	325-6054
7J-9884	Bearing - Sleeve	325-6016
7K-7195	Bearing - Sleeve	325-6025
7N-0110	Core As - Oil Cooler	319-3435
7N-0128	Core As - Oil Cooler	299-1994
7N-0165	Core As - Oil Cooler	295-5670
7N-1164	Mount As	295-5451
7N-2957	Cover - Rad Cap	361-1722
7N-3536	Gear - Fuel	279-4993
7N-5910	Impeller - Pump	314-8686
7N-9146	Gear - Fly-wheel Starter	279-4995
7N-9805	Pin - Piston	295-6438
7S-3161	Lifter - Valve	279-4996
7S-7809	Cap As - Radiator	295-6417
7T-2036	Cap As - Filter	361-1721
7T-2092	Washer - Thrust	325-6238
7T-3952	Gear - Trans-fer	295-6429
7T-6427	Pin	319-3462
7T-8136	Shaft - Planet	314-8714
7T-9272	Gear - Sun	296-1354
7T-9370	Gear - Sun	283-5207
7T-9586	Bearing	314-8645
7T-9931	Countershaft	215-1760
7W-0450	Gear - Water Pump	279-4997
7W-0507	Gear - Oil Pump Drive	279-4998
7W-0508	Gear - Fuel Pump Drive	296-1351
7W-5685	Pulley - Cam-shaft	298-2772
7W-5698	Pulley - Cam-shaft	295-5679
8E-5450	Seal - Ebar	325-6190
8E-5993	Gear As - Idler	215-1903
8E-6754	Connector As	325-6044
8E-6755	Bearing - Sleeve	325-6026
8E-6756	Bearing - Sleeve	325-6027
8G-4187	Pin As	295-5676
8G-4189	Bearing - Aligning	295-6411
8H-1383	Rod - Tie	299-2051
8H-2810	Case As - Filter	314-8512
8H-9806	Gear - Shaft Drive	325-6091
8J-2880	Cap - Bearing	295-6420
8J-5654	Bearing - Sleeve	325-6028
8M-0874	Plunger As - Valve	311-9439
8N-0875	Valve - Ex-haust	247-6893 (Valve), 241-3381 (Valve Kit)
8N-1187	Head Gp - Cylinder	242-3435
8N-1214	Mount As	325-6125
8N-1721	Rod As - Conn	269-5291
8N-1965	Tube - Dis-posal	325-6235
8N-2510	Shaft	325-6208
8N-2641	Sleeve	325-6210
8N-3251	Shaft As - Rocker Arm	314-8711
8N-3325	Arm Gp - Rocker	314-8623
8N-3327	Arm Gp - Rocker	314-8624
8N-5779	Coupling - Exhaust	325-6047
8N-5929	Cover - Water Pump	296-1349
8N-6796	Head Gp - Cylinder	269-5290
8N-7315	Tube As - Outlet	325-6232
8N-8225	Bearing - Main	314-8652
8P-1892	Piston - Clutch	283-5208
8P-1916	Gear - Planet	283-5209
8P-9507	Piston - Clutch	283-5212
8S-0248	Breather As	325-6033
8S-0493	Shaft As - Pump	325-6198
8S-3970	Chamber As	242-3438

(Continued)

Sales Model D7H (Continued)

Original Part Number	Part Name	Classic Part Number
8S-7716	Manifold - Exhaust	295-0415
8S-7717	Manifold - Exhaust	261-0894
8S-7718	Manifold - Exhaust	295-0416
9F-7101	Bushing - Collar	299-1988
9G-0280	Piston - Clutch	283-5213
9G-0284	Housing - Clutch	283-5214
9G-0285	Piston - Clutch	283-5215
9G-0289	Shaft - Planet	283-5216
9G-0290	Hub - Clutch	283-5217
9G-9543	Gear - Oil Pump	295-6426
9J-0123	Trunnion	325-6227

Original Part Number	Part Name	Classic Part Number
9J-5875	Bearing - Sleeve	308-9830
9M-4789	Shaft - Gov Control	297-7256
9M-8117	Shaft - Fly-wheel Clutch	226-6073
9M-8119	Retainer - Inlet	226-8022
9M-8281	Gear As - Oil Pump	325-6089
9N-4622	Pin	319-3468
9N-5769	Cover - Hous-ing	325-6050
9N-6611	Pulley	325-6177
9P-1779	Bearing - Sleeve	325-6029
9P-3242	Plate - Clutch	325-6172
9P-7757	Gear - Sun	283-5218
9P-8623	Shaft - Planet	314-8719
9P-8624	Shaft - Planet	295-5446
9P-8626	Gear - Sun	283-5219

Original Part Number	Part Name	Classic Part Number
9S-6590	Pump Gp - Oil	226-0176
9S-8679	Chamber As	325-6042
9T-0064	Bearing	361-1706
9T-0066	Trunnion	325-6228
9T-4761	Head	325-6108
9T-4762	Head	325-6109
9W-0318	Spacer	325-6218
9W-0550	Shaft - Transmission Upper	226-6000
9W-0552	Shaft - Pinion	226-6001
9W-1677	Bearing	297-7145
9W-2344	Coupling - Pump Drive	314-8666
9W-3605	Carrier - Ring	314-8662
9W-4897	Bracket As	295-6414
9W-7481	Gear - Planet	295-6431
9W-7839	Carrier - Planet	295-6421
9W-8270	Gear - Ring	308-9859
9W-9930	Mount As	295-6437

Sales Model D8

Original Part Number	Part Name	Classic Part Number
0T-0259	Nut - Bearing Sleeve	311-9431
160-6305	Cap - Bearing	295-5686
1A-2846	Cap As - Filler	311-9368
1D-3996	Fork - Knuckle	228-9428
1F-2254	Bushing - Stem	314-8510
1M-7250	Bowl - Pre-cleaner	360-2296
1S-1888	Bracket - Lamp	297-7147
2B-3708	Chamber As	247-3293
2D-5658	Bearing - Ball	301-4628
2S-4015	Plunger As - Valve	311-9438
3B-1464	Cap - Bearing	226-0206
3B-6218	Muffler As	247-2672
3F-4971	Pin	295-5693

Original Part Number	Part Name	Classic Part Number
3F-7445	Bearing - Sleeve	314-8508
3H-3378	Gear As - Pump	298-2795
3K-3124	Muffler - Trap	247-2673
3L-1425	Bearing - Ball	311-9356
4B-1455	Cap As - Filter	361-1719
4F-4974	Clamp	311-9373
4J-1999	Ballstud	314-8625
5F-0689	Pin	256-4821
5F-7993	Pin	319-3454
5L-9371	Connector - Inlet	311-9375
5S-1211	Cover - Valve	314-8665
6F-2904	Bearing	295-5673
6H-3957	Bearing - Ball	311-9358
7D-6841	Joint As - Univ	228-9566

Original Part Number	Part Name	Classic Part Number
7F-9541	Pin As - Drawbar	296-1361
7F-9547	Pin As - Drawbar	295-0414
7M-4926	Retainer - Pin	314-8538
7S-7809	Cap As - Radiator	295-6417
7T-0204	Bearing - Brace	247-4126
8B-5972	Bearing - Ball	314-8503
8H-1993	Valve - Inlet	256-4765 (Valve Kit)
8H-1994	Valve - Ex-haust	256-4765 (Valve Kit)
8H-2434	Drum - Steer-ing	216-7862
9F-7101	Bushing - Collar	299-1988
9S-8493	Bolt - Con-necting Rod	311-9351

Sales Model D8D

Original Part Number	Part Name	Classic Part Number
160-6305	Cap - Bearing	295-5686
1A-2846	Cap As - Filler	311-9368
1F-2254	Bushing - Stem	314-8510
1H-4106	Pin As - Drawbar	325-6126
1J-6744	Bearing	361-1705
1M-9444	Retainer - Spring	299-2046
2F-5721	Bearing - Ball	311-9354
2P-0483	Chamber As	256-4760
2S-3966	Ring - Seal	297-7237
2S-4015	Plunger As - Valve	311-9438
3B-1464	Cap - Bearing	226-0206
3F-6149	Pin	299-2033
3F-6185	Pin	295-5694

Original Part Number	Part Name	Classic Part Number
3F-7445	Bearing - Sleeve	314-8508
3H-3378	Gear As - Pump	298-2795
4F-1121	Bracket	299-1981
4F-1252	Pin	295-5704
4F-4974	Clamp	311-9373
4N-7526	Seal As - Pump	311-9454
4N-9180	Seal As - Pump	311-9455
5F-7993	Pin	319-3454
5J-4321	Trunnion	302-2700
5S-1211	Cover - Valve	314-8665
6F-2904	Bearing	295-5673
6F-7523	Cap - Bearing	325-6039
6H-3957	Bearing - Ball	311-9358
6L-7816	Seal - o-Ring	314-8542

Original Part Number	Part Name	Classic Part Number
7B-2420	Ferrule - Director	314-8517
7H-0602	Dog - Clutch	314-8515
7M-4603	Body - Fuel Valve	311-9348
7M-4926	Retainer - Pin	314-8538
7S-7809	Cap As - Radiator	295-6417
7T-0204	Bearing - Brace	247-4126
8F-5104	Screen As - Oil Pan	314-8539
8H-1993	Valve - Inlet	256-4765 (Valve Kit)
8H-1994	Valve - Exhaust	256-4765 (Valve Kit)
8H-2434	Drum - Steering	216-7862
9S-8493	Bolt - Connecting Rod	311-9351

Sales Model D8E, D8F

Original Part Number	Part Name	Classic Part Number
0T-0259	Nut - Bearing Sleeve	311-9431
160-6305	Cap - Bearing	295-5686
1A-2846	Cap As - Filler	311-9368
1F-2254	Bushing - Stem	314-8510
1H-4106	Pin As - Drawbar	325-6126
1J-6746	Pin	256-4817
1J-6747	Pin	367-6078
1J-6749	Screw - Adjustable	256-4824
1M-7250	Bowl - Precleaner	360-2296
1M-9444	Retainer - Spring	299-2046
1P-0005	Pump Gp - Fuel Transfer	256-4756
1S-1888	Bracket - Lamp	297-7147
1S-4701	Pulley - Alt	264-5866
2D-5658	Bearing - Ball	301-4628
2F-5721	Bearing - Ball	311-9354
2P-0483	Chamber As	256-4760
2S-3966	Ring - Seal	297-7237
2S-4015	Plunger As - Valve	311-9438

Original Part Number	Part Name	Classic Part Number
3B-1464	Cap - Bearing	226-0206
3F-4971	Pin	295-5693
3F-7445	Bearing - Sleeve	314-8508
3H-3378	Gear As - Pump	298-2795
3S-2420	Pilot As - Spring	226-2733
4B-1455	Cap As - Filter	361-1719
4F-4974	Clamp	311-9373
4J-1999	Ballstud	314-8625
4M-9215	Gear - Pump Idler	311-9391
4N-7526	Seal As - Pump	311-9454
4N-9180	Seal As - Pump	311-9455
5F-0689	Pin	256-4821
5F-7993	Pin	319-3454
5J-4321	Trunnion	302-2700
5P-7807	Bearing - Ball	314-8502
5S-1211	Cover - Valve	314-8665
5S-9080	Pulley - Alt Drive	264-5883
6F-2904	Bearing	295-5673
6F-3183	Cap - Bearing	325-6038

Original Part Number	Part Name	Classic Part Number
6F-7523	Cap - Bearing	325-6039
6H-3957	Bearing - Ball	311-9358
6L-7816	Seal - o-Ring	314-8542
7B-2420	Ferrule - Director	314-8517
7H-0602	Dog - Clutch	314-8515
7M-4603	Body - Fuel Valve	311-9348
7M-4926	Retainer - Pin	314-8538
7S-7809	Cap As - Radiator	295-6417
7T-0204	Bearing - Brace	247-4126
8F-5104	Screen As - Oil Pan	314-8539
8H-1993	Valve - Inlet	256-4765 (Valve Kit)
8H-1994	Valve - Exhaust	256-4765 (Valve Kit)
8H-2434	Drum - Steering	216-7862
8H-2810	Case As - Filter	314-8512
9F-7101	Bushing - Collar	299-1988
9S-8493	Bolt - Connecting Rod	311-9351
9W-1677	Bearing	297-7145

Sales Model D8G

Original Part Number	Part Name	Classic Part Number
160-6305	Cap - Bearing	295-5686
1A-2846	Cap As - Filler	311-9368
1F-2254	Bushing - Stem	314-8510
1H-4106	Pin As - Drawbar	325-6126
1M-7250	Bowl - Pre-cleaner	360-2296
1M-9444	Retainer - Spring	299-2046
2F-5721	Bearing - Ball	311-9354
2P-0483	Chamber As	256-4760
2S-3966	Ring - Seal	297-7237
2S-4015	Plunger As - Valve	311-9438
3B-1464	Cap - Bearing	226-0206
3F-6149	Pin	299-2033
3F-6185	Pin	295-5694
3F-7445	Bearing - Sleeve	314-8508
3H-3378	Gear As - Pump	298-2795
4B-1455	Cap As - Filter	361-1719
4F-1121	Bracket	299-1981
4F-1252	Pin	295-5704
4F-4974	Clamp	311-9373
4N-7526	Seal As - Pump	311-9454
4N-9180	Seal As - Pump	311-9455
5F-7993	Pin	319-3454
5J-4321	Trunnion	302-2700
5S-1211	Cover - Valve	314-8665
6F-2904	Bearing	295-5673
6F-7523	Cap - Bearing	325-6039
6H-3957	Bearing - Ball	311-9358
6L-7816	Seal - o-Ring	314-8542
7B-2420	Ferrule - Director	314-8517
7H-0602	Dog - Clutch	314-8515
7M-4603	Body - Fuel Valve	311-9348
7M-4926	Retainer - Pin	314-8538
7S-7809	Cap As - Radiator	295-6417
7T-0204	Bearing - Brace	247-4126
8F-5104	Screen As - Oil Pan	314-8539
8H-1993	Valve - Inlet	256-4765 (Valve Kit)
8H-1994	Valve - Exhaust	256-4765 (Valve Kit)
8H-2434	Drum - Steering	216-7862
9S-8493	Bolt - Connecting Rod	311-9351

Sales Model D8H

Original Part Number	Part Name	Classic Part Number
0T-0259	Nut - Bearing Sleeve	311-9431
115-0637	Pump Gp	226-0160
190-8609	Valve - Fill	360-2288
1A-2846	Cap As - Filler	311-9368
1F-2254	Bushing - Stem	314-8510
1H-4106	Pin As - Drawbar	325-6126
1J-1738	Pin	319-3448
1J-6744	Bearing	361-1705
1J-6746	Pin	256-4817
1J-6747	Pin	367-6078
1J-6749	Screw - Adjustable	256-4824
1M-3925	Gear - Shaft Idler	216-7459
1M-4153	Carrier - Planet	213-1114
1M-4155	Gear - Ring	214-0519
1M-4156	Gear - Ring	214-0520
1M-4167	Shaft - Planet	219-9700
1M-4171	Cage - Bearing	216-7460
1M-4344	Cage As	216-7466
1M-6603	Gear - Transfer	217-7720
1M-6604	Gear - Transfer	217-7715
1M-9444	Retainer - Spring	299-2046
1P-0005	Pump Gp - Fuel Transfer	256-4756
1P-2187	Pump Gp	299-2044
1P-4145	Valve Gp - Press	247-4436
1S-1888	Bracket - Lamp	297-7147
1S-2268	Piston	226-2726
1S-2269	Sleeve	226-2720
1S-4701	Pulley - Alt	264-5866
1S-8753	Plate - Coupling	308-9910
1S-8754	Joint Gp - Univ	308-9873
1T-0224	Carrier - Ring	239-7928
1T-0228	Housing - Rotating	216-7467
1T-0231	Retainer - Bearing	319-3471
1T-0237	Flange As - Output	239-7929
1T-0256	Gear - Pump Drive	239-7930
1T-0595	Carrier - Wheel	239-7939
1T-0611	Converter As	235-1804 (Repair Kit)
1T-0670	Converter As	235-1805 (Repair Kit)
1T-1389	Carrier - Bearing	247-4124
2F-5721	Bearing - Ball	311-9354
2J-1506	Pin	319-3451
2J-2622	Bracket	256-4826
2J-3271	Pin	319-3452
2K-4507	Bearing - Sleeve	325-6021
2M-3339	Piston - Clutch	221-7944
2N-9297	Retainer - Spring	314-8535
2P-0483	Chamber As	256-4760
2P-0484	Chamber As	247-3296
2P-1005	Bearing - Sleeve	296-1342
2P-1604	Piston - Steering	219-9694
2P-1605	Pilot - Piston	219-9695
2P-4370	Plate - Clutch	325-6166
2P-4611	Pipe - Exhaust	365-8821
2S-2140	Nut (7/8-14)	188-5857

(Continued)

Sales Model D8H (Continued)

Original Part Number	Part Name	Classic Part Number
2S-3913	Cage - Gear Bearing	217-7722
2S-3966	Ring - Seal	297-7237
2S-4015	Plunger As - Valve	311-9438
2S-4357	Pinion - Final Drive	217-7706
2S-6346	Shoe -Track	188-5311
2S-6347	Shoe -Track	188-5613
2S-6357	Shoe -Track	281-6373
2S-6364	Shoe -Track	188-5615
2S-7873	Pump Gp	226-0162
2S-7917	Gear - Pump Drive	247-4119
2S-7920	Pump Gp - Scavenge	217-2594
2S-8892	Pulley - Fan Drive	264-5874
3F-6185	Pin	295-5694
3F-6523	Pin - Clevis	256-4818
3F-7445	Bearing - Sleeve	314-8508
3H-3378	Gear As - Pump	298-2795
3H-7161	Pin	256-4819
3H-7162	Collar	256-4830
3H-7164	Pin - Pivot	256-4820
3J-3493	Ballstud	256-4832
3J-5190	Cap - Bearing	256-4837
3J-6497	Screw - Adjusting	256-4825
3L-1425	Bearing - Ball	311-9356
3P-1757	Yoke As - Idler	226-2729
3P-3259	Cage - Bearing	217-7728
3P-3755	Guard As	226-2721
3P-3757	Guard As	226-2722
3P-4002	Pump Gp - Gear	217-2595
3P-4850	Gear As - Oil Pump	308-9848
3P-4855	Pump Gp	217-2596
3P-6293	Pump Gp	217-2597
3P-7482	Cap - Drive Bearing	226-2731
3P-9394	Shaft - Planet	215-1680
3S-1262	Retainer	308-9915
3S-1274	Shaft - Center	215-1681
3S-2252	Manifold - Exhaust	261-0887
3S-2420	Pilot As - Spring	226-2733
3S-6989	Nut - Spanner	219-9701
3S-7306	Flange - Drum	216-7827
3S-7308	Cage - Pinion Bearing	219-9702
3S-7517	Pulley - Belt Adjustable	264-5876
3S-7519	Pulley - Damper As	264-5877
3S-8735	Guard As	226-2723
3S-8736	Guard As	226-9992
3S-9919	Shaft As	239-7959
4M-0503	Gear As - Oil Pump	297-7184
4M-8967	Gear - Sun	219-9661
4M-9215	Gear - Pump Idler	311-9391
4N-4577	Muffler As	308-9877
4N-4880	Pump Gp - Fuel Transfer	256-4758
4N-7526	Seal As - Pump	311-9454
4N-9180	Seal As - Pump	311-9455
4S-5833	Spacer	239-7961
4S-7793	Thrower - Crankshaft Oil	367-6085
4S-8472	Hood As	296-1355
5F-7993	Pin	319-3454
5G-3612	Cap Gp	295-6419
5H-1719	Pump Gp - Final Drive Oil	226-0168
5J-0698	Pin	319-3456
5J-1204	Pin As	325-6131
5J-2602	Plate As - Trunnion	256-4838
5J-4321	Trunnion	302-2700
5L-8856	Coupling - Exhaust	311-9379
5M-0549	Gear - Transmission	215-1689
5M-3947	Shaft - Planet	223-6318
5M-3996	Gear - Ring	214-0527
5M-3998	Gear - Ring	214-0528
5M-3999	Shaft - Transmission	215-1693
5M-4427	Gear - Sun	214-0529
5M-6673	Guard - F Idler Rh	226-2735
5M-6674	Guard - F Idler Lh	226-2736
5M-7306	Cylinder	226-2737
5M-7953	Carrier As	239-7977
5M-7955	Shaft As - Planet	364-5273
5M-8007	Gear - Ring	239-7932
5N-8501	Head As - Cylinder	256-4762
5N-8657	Manifold - Exhaust	261-0886
5P-7807	Bearing - Ball	314-8502
5S-0135	Cage - Pinion Bearing	222-1766
5S-0160	Strip - Guard	226-2738
5S-0161	Strip - Guard	226-2739
5S-0162	Guard As - Guiding	226-2740
5S-0163	Guard As - Guiding	226-2741
5S-0464	Gear - First Reduction	216-7852
5S-0465	Pinion - Reduction	216-7853
5S-1211	Cover - Valve	314-8665
5S-4557	Bearing	311-9360
5S-5746	Retainer - Guard	319-3472
5S-9080	Pulley - Alt Drive	264-5883
6F-7523	Cap - Bearing	325-6039
6H-3957	Bearing - Ball	311-9358
6J-2326	Pin	319-3458
6J-9258	Trunnion As	256-4846
6J-9474	Pin As	319-3444
6J-9793	Bearing	256-4835
6L-7816	Seal - o-Ring	314-8542
6L-8968	Coupling - Exhaust	311-9381
6L-9212	Idler Gp	200-9238
6N-8847	Guide - Valve	314-8523
6P-0549	Guard - Final Drive Wear	223-4812
6P-2776	Gear - Final Drive	217-7718
6P-3593	Support	229-8231
6P-3596	Hub	222-1764
6P-3597	Retainer	222-1770
6P-8884	Guard As - Idler	226-2742
6P-8904	Guard Gp - Track Adjustable	226-2744
6T-0952	Pad As	367-6087

(Continued)

Sales Model D8H (Continued)

Original Part Number	Part Name	Classic Part Number
6T-1933	Collar - Idler End	226-2746
6T-4481	Shaft - Planet	221-7946
6T-6782	Segment Gp - Sprocket	188-5641 (sprocket)
7B-2420	Ferrule - Director	314-8517
7G-2492	Gear - Planet	239-7933
7G-2500	Gear - Planet	296-1350
7H-0602	Dog - Clutch	314-8515
7H-3599	Bolt - Track	188-5639
7H-7630	Spacer	239-7962
7J-0086	Bearing As	256-4842
7J-9884	Bearing - Sleeve	325-6016
7M-1184	Housing As	219-9704
7M-1185	Housing As	219-9705
7M-1186	Housing As	219-9706
7M-1195	Housing - Clutch	219-9707
7M-4603	Body - Fuel Valve	311-9348
7M-4926	Retainer - Pin	314-8538
7M-5289	Hub - Steering	217-7736
7M-5756	Gear - Ring	214-0531
7M-6621	Pump Gp - Oil	226-0172
7N-2957	Cover - Rad Cap	361-1722
7S-7400	Pump Gp	226-0173
7S-7809	Cap As - Radiator	295-6417
7S-9093	Shoe -Track	188-5617
7S-9094	Shoe -Track	188-5313
7S-9096	Shoe -Track	281-6370
7S-9101	Shoe -Track	281-6372
7S-9749	Pulley - Gen Drive	264-5888
7T-2036	Cap As - Filter	361-1721
7Y-1517	Pipe As - Tail	301-5246
8E-7455	Gear - Planet	221-7947
8E-7456	Gear - Planet	221-7948
8F-5104	Screen As - Oil Pan	314-8539
8H-1993	Valve - Inlet	256-4765 (Valve Kit)
8H-1994	Valve - Exhaust	256-4765 (Valve Kit)
8H-2434	Drum - Steering	216-7862
8H-2810	Case As - Filter	314-8512
8H-7810	Gear	213-8753
8H-7813	Collar	215-1780
8H-9806	Gear - Shaft Drive	325-6091
8M-0874	Plunger As - Valve	311-9439
8M-2549	Rod As - Connector	314-8537
8M-7166	Housing - Screen	297-7192
8M-8161	Flange - Shaft	215-1781
8N-6004	Head As - Cylinder	247-3369
8P-3252	Pin	319-3464
8P-5117	Rod Gp - Track Adjustable	226-2747
8P-5849	Plate As	223-6323
8P-6256	Roller Gp - Carrier	188-5612
8P-8221	Plate - Guide	226-2748
8S-0386	Shoe -Track Master	188-5312
8S-0387	Shoe -Track Master	188-5614
8S-0388	Shoe -Track Master	188-5616
8S-0390	Shoe -Track Master	281-6371
8S-0391	Shoe -Track Master	188-5618
8S-0392	Shoe -Track Master	188-5314
8S-0394	Shoe -Track Master	315-6693
8S-0395	Bolt Master	188-5640
8S-0915	Shoe -Track Master	281-6374
8S-1194	Shaft - Sprocket	217-7733
8S-1198	Hub - Gear	219-2969
8S-2123	Cage - Final Drive Bearing	217-7726
8S-2126	Spacer - Hub Bearing	222-1767
9F-7101	Bushing - Collar	299-1988
9H-1918	Gear - Bevel	219-9698
9H-1980	Pinion - Bevel	219-9699
9H-5233	Piston - Clutch	219-9708
9H-5433	Spacer	239-7963
9J-5273	Trunnion As	256-4848
9M-1328	Bearing - Aligning	325-6018
9M-3025	Cover As	299-2001
9M-4789	Shaft - Gov Control	297-7256
9P-3663	Carrier - Planet	213-6939
9P-6592	Gear - Planet	215-1915
9P-6594	Gear - Planet	215-1921
9S-1026	Cage - Gear Bearing	216-7873
9S-7221	Idler As.	188-5610
9S-8493	Bolt - Connecting Rod	311-9351
9W-8937	Link As	188-5310

Sales Model D8K

Original Part Number	Part Name	Classic Part Number
0T-0259	Nut - Bearing Sleeve	311-9431
115-0637	Pump Gp	226-0160
131-3815	Seal Gp - Basic	325-6193
172-5185	Shaft - Water Pump	325-6201
172-5189	Impeller - Pump	295-5687
177-9024	Adapter - Damper	299-1956
180-3767	Adapter - Damper	299-1957
190-8609	Valve - Fill	360-2288
1H-4106	Pin As - Drawbar	325-6126
1J-1738	Pin	319-3448
1J-6744	Bearing	361-1705
1J-6746	Pin	256-4817
1J-6749	Screw - Adjustable	256-4824

(Continued)

Sales Model D8K (Continued)

Original Part Number	Part Name	Classic Part Number
1M-3925	Gear - Shaft Idler	216-7459
1M-4153	Carrier - Planet	213-1114
1M-4155	Gear - Ring	214-0519
1M-4156	Gear - Ring	214-0520
1M-4167	Shaft - Planet	219-9700
1M-4171	Cage - Bearing	216-7460
1M-4344	Cage As	216-7466
1M-6603	Gear - Transfer	217-7720
1M-6604	Gear - Transfer	217-7715
1M-9444	Retainer - Spring	299-2046
1P-2187	Pump Gp	299-2044
1P-4145	Valve Gp - Press	247-4436
1S-1888	Bracket - Lamp	297-7147
1S-2268	Piston	226-2726
1S-2269	Sleeve	226-2720
1S-4701	Pulley - Alt	264-5866
1S-8753	Plate - Coupling	308-9910
1S-8754	Joint Gp - Univ	308-9873
1T-0224	Carrier - Ring	239-7928
1T-0228	Housing - Rotating	216-7467
1T-0231	Retainer - Bearing	319-3471
1T-0237	Flange As - Output	239-7929
1T-0256	Gear - Pump Drive	239-7930
1T-0595	Carrier - Wheel	239-7939
1T-0611	Converter As	235-1804 (Repair Kit)
1T-0670	Converter As	235-1805 (Repair Kit)
1T-1389	Carrier - Bearing	247-4124
1W-1669	Piston	325-6158
1W-1698	Housing - Transfer Pump	296-1356
1W-4738	Bearing - Sleeve	325-6020
244-1090	Alarm - Back up	360-2345
2F-5721	Bearing - Ball	311-9354
2J-1506	Pin	319-3451
2J-2622	Bracket	256-4826
2M-3339	Piston - Clutch	221-7944
2N-7942	Spacer	363-7462
2N-9297	Retainer - Spring	314-8535
2P-0484	Chamber As	247-3296
2P-1005	Bearing - Sleeve	296-1342
2P-1126	Pulley - Camshaft	264-5868
2P-1129	Pulley - Tightener	264-5869
2P-1604	Piston - Steering	219-9694
2P-1605	Pilot - Piston	219-9695
2P-4370	Plate - Clutch	325-6166
2P-9037	Drum - Steering Clutch	219-9696
2P-9038	Drum - Steering	216-7821
2P-9039	Hub - Steering	219-9697
2S-2140	Nut (7/8-14)	188-5857
2S-3913	Cage - Gear Bearing	217-7722
2S-3966	Ring - Seal	297-7237
2S-4357	Pinion - Final Drive	217-7706
2S-6346	Shoe -Track	188-5311
2S-6347	Shoe -Track	188-5613
2S-6357	Shoe -Track	281-6373
2S-6364	Shoe -Track	188-5615
2S-7917	Gear - Pump Drive	247-4119
3F-6185	Pin	295-5694
3F-6523	Pin - Clevis	256-4818
3G-0910	Cap - Bearing	325-6037
3H-3378	Gear As - Pump	298-2795
3H-7161	Pin	256-4819
3H-7162	Collar	256-4830
3H-7164	Pin - Pivot	256-4820
3J-3493	Ballstud	256-4832
3J-5190	Cap - Bearing	256-4837
3J-6497	Screw - Adjusting	256-4825
3L-1425	Bearing - Ball	311-9356
3P-1757	Yoke As - Idler	226-2729
3P-3259	Cage - Bearing	217-7728
3P-3755	Guard As	226-2721
3P-3757	Guard As	226-2722
3P-3935	Shaft	299-2053
3P-4850	Gear As - Oil Pump	308-9848
3P-4855	Pump Gp	217-2596
3P-6293	Pump Gp	217-2597
3P-7482	Cap - Drive Bearing	226-2731
3P-9394	Shaft - Planet	215-1680
3S-1262	Retainer	308-9915
3S-1274	Shaft - Center	215-1681
3S-2252	Manifold - Exhaust	261-0887
3S-2420	Pilot As - Spring	226-2733
3S-6989	Nut - Spanner	219-9701
3S-7306	Flange - Drum	216-7827
3S-7308	Cage - Pinion Bearing	219-9702
3S-8735	Guard As	226-2723
3S-8736	Guard As	226-9992
3S-9919	Shaft As	239-7959
4M-8967	Gear - Sun	219-9661
4N-3714	Chamber, Precom	363-7450
4N-4577	Muffler As	308-9877
4N-4880	Pump Gp - Fuel Transfer	256-4758
4N-5390	Pulley - Alt Drive	264-5879
4N-7526	Seal As - Pump	311-9454
4N-9180	Seal As - Pump	311-9455
4P-9961	Line As - Fuel Injector	325-6115
4S-5833	Spacer	239-7961
4S-7793	Thrower - Crankshaft Oil	367-6085
4S-8472	Hood As	296-1355
5F-7993	Pin	319-3454
5G-3612	Cap Gp	295-6419
5H-1719	Pump Gp - Final Drive Oil	226-0168
5J-1204	Pin As	325-6131
5J-4321	Trunnion	302-2700

(Continued)

Sales Model D8K (Continued)

Original Part Number	Part Name	Classic Part Number
5L-9738	Coupling - Exhaust	311-9380
5M-0549	Gear - Transmission	215-1689
5M-3947	Shaft - Planet	223-6318
5M-3996	Gear - Ring	214-0527
5M-3999	Shaft - Transmission	215-1693
5M-4427	Gear - Sun	214-0529
5M-6673	Guard - F Idler Rh	226-2735
5M-6674	Guard - F Idler Lh	226-2736
5M-7306	Cylinder	226-2737
5M-7953	Carrier As	239-7977
5M-7955	Shaft As - Planet	364-5273
5M-8007	Gear - Ring	239-7932
5N-8501	Head As - Cylinder	256-4762
5N-8657	Manifold - Exhaust	261-0886
5P-7807	Bearing - Ball	314-8502
5S-0135	Cage - Pinion Bearing	222-1766
5S-0160	Strip - Guard	226-2738
5S-0161	Strip - Guard	226-2739
5S-0162	Guard As - Guiding	226-2740
5S-0163	Guard As - Guiding	226-2741
5S-0464	Gear - First Reduction	216-7852
5S-0465	Pinion - Reduction	216-7853
5S-1211	Cover - Valve	314-8665
5S-4557	Bearing	311-9360
5S-5746	Retainer - Guard	319-3472
5S-9080	Pulley - Alt Drive	264-5883
6F-7523	Cap - Bearing	325-6039
6H-3957	Bearing - Ball	311-9358
6J-2326	Pin	319-3458
6J-9474	Pin As	319-3444
6J-9793	Bearing	256-4835
6L-7816	Seal - o-Ring	314-8542
6L-8968	Coupling - Exhaust	311-9381
6L-9212	Idler Gp	200-9238
6N-0762	Pulley - Fan	264-5885
6N-5437	Muffler As	247-2674
6P-0549	Guard - Final Drive Wear	223-4812
6P-2776	Gear - Final Drive	217-7718
6P-3593	Support	229-8231
6P-3596	Hub	222-1764
6P-3597	Retainer	222-1770
6P-8884	Guard As - Idler	226-2742
6P-8904	Guard Gp - Track Adjustable	226-2744
6T-0952	Pad As	367-6087
6T-1933	Collar - Idler End	226-2746
6T-4481	Shaft - Planet	221-7946
6T-6782	Segment Gp - Sprocket	188-5641 (sprocket)
7B-2420	Ferrule - Director	314-8517
7C-0942	Adapter As	302-2636
7C-3039	Core, Oil Cooler	363-7451
7G-2492	Gear - Planet	239-7933
7G-2500	Gear - Planet	296-1350
7H-3599	Bolt - Track	188-5639
7H-7630	Spacer	239-7962
7J-0086	Bearing As	256-4842
7J-9884	Bearing - Sleeve	325-6016
7M-1184	Housing As	219-9704
7M-1185	Housing As	219-9705
7M-1186	Housing As	219-9706
7M-1195	Housing - Clutch	219-9707
7M-4603	Body - Fuel Valve	311-9348
7M-4926	Retainer - Pin	314-8538
7M-5756	Gear - Ring	214-0531
7M-8395	Piston - Clutch	223-6322
7N-2957	Cover - Rad Cap	361-1722
7N-3350	Gear As - Pump Drive	319-3437
7S-7400	Pump Gp	226-0173
7S-7809	Cap As - Radiator	295-6417
7S-9093	Shoe -Track	188-5617
7S-9094	Shoe -Track	188-5313
7S-9096	Shoe -Track	281-6370
7S-9101	Shoe -Track	281-6372
7T-2036	Cap As - Filter	361-1721
7W-1902	Adapter - Fuel Nozzle	299-1955
7W-2164	Core As - Oil Cooler	299-1996
8E-7455	Gear - Planet	221-7947
8E-7456	Gear - Planet	221-7948
8H-1993	Valve - Inlet	256-4765 (Valve Kit)
8H-1994	Valve - Exhaust	256-4765 (Valve Kit)
8H-2810	Case As - Filter	314-8512
8H-7810	Gear	213-8753
8H-7813	Collar	215-1780
8H-9806	Gear - Shaft Drive	325-6091
8M-0874	Plunger As - Valve	311-9439
8M-7166	Housing - Screen	297-7192
8M-8161	Flange - Shaft	215-1781
8N-2510	Shaft	325-6208
8N-2641	Sleeve	325-6210
8N-6004	Head As - Cylinder	247-3369
8P-3252	Pin	319-3464
8P-5117	Rod Gp - Track Adjustable	226-2747
8P-5849	Plate As	223-6323
8P-6256	Roller Gp - Carrier	188-5612
8P-8221	Plate - Guide	226-2748
8S-0386	Shoe -Track Master	188-5312
8S-0388	Shoe -Track Master	188-5616
8S-0390	Shoe -Track Master	281-6371
8S-0391	Shoe -Track Master	188-5618
8S-0392	Shoe -Track Master	188-5314
8S-0394	Shoe -Track Master	315-6693
8S-0395	Bolt Master	188-5640
8S-0915	Shoe -Track Master	281-6374
8S-1194	Shaft - Sprocket	217-7733

(Continued)

Sales Model D8K (Continued)

Original Part Number	Part Name	Classic Part Number
8S-2123	Cage - Final Drive Bearing	217-7726
8S-2126	Spacer - Hub Bearing	222-1767
8S-3487	Gear As - Ring	221-7949
8S-3491	Housing As	221-7950
9F-7101	Bushing - Collar	299-1988
9H-1918	Gear - Bevel	219-9698
9H-1980	Pinion - Bevel	219-9699
9H-5233	Piston - Clutch	219-9708
9H-5433	Spacer	239-7963
9J-0123	Trunnion	325-6227
9J-5273	Trunnion As	256-4848
9K-8757	Rod End - Bearing	311-9361
9M-3025	Cover As	299-2001
9M-4789	Shaft - Gov Control	297-7256
9P-3663	Carrier - Planet	213-6939
9P-6592	Gear - Planet	215-1915
9P-6594	Gear - Planet	215-1921
9S-1026	Cage - Gear Bearing	216-7873
9S-7221	Idler As.	188-5610
9S-8493	Bolt - Connecting Rod	311-9351
9W-8937	Link As	188-5310

Sales Model D9D

Original Part Number	Part Name	Classic Part Number
0T-0259	Nut - Bearing Sleeve	311-9431
102-1561	Lifter As - Valve	311-9402
1A-2846	Cap As - Filler	311-9368
1F-2254	Bushing - Stem	314-8510
1H-4106	Pin As - Drawbar	325-6126
1J-1738	Pin	319-3448
1J-6746	Pin	256-4817
1M-7250	Bowl - Precleaner	360-2296
1M-9444	Retainer - Spring	299-2046
1P-8005	Gasket - Chamber	314-8527
1W-3062	Retainer As	311-9445
1W-5105	Ring Gp - Piston	311-9446
2F-5721	Bearing - Ball	311-9354
2N-9297	Retainer - Spring	314-8535
2S-3966	Ring - Seal	297-7237
3F-7445	Bearing - Sleeve	314-8508
3H-7161	Pin	256-4819
3H-7162	Collar	256-4830
3H-7164	Pin - Pivot	256-4820
3J-5190	Cap - Bearing	256-4837
3J-6497	Screw - Adjusting	256-4825
3L-1425	Bearing - Ball	311-9356
4B-1455	Cap As - Filter	361-1719
4F-1252	Pin	295-5704
4M-9214	Shaft - Pump Drive	314-8543
4M-9215	Gear - Pump Idler	311-9391
4M-9216	Gear - Pump Drive	311-9390
4N-3664	Guide - Valve	314-8524
4N-7526	Seal As - Pump	311-9454
4N-9180	Seal As - Pump	311-9455
4S-8906	Insert	311-9397
4S-8908	Insert	311-9399
4S-8909	Insert - Valve Seat	311-9400
5H-1719	Pump Gp - Final Drive Oil	226-0168
5H-5553	Screw -Tappet Adjustable	311-9451
5J-4321	Trunnion	302-2700
5N-9055	Manifold - Exhaust	261-0890
5S-1757	Insert - Seat	311-9401
6F-7523	Cap - Bearing	325-6039
6H-3957	Bearing - Ball	311-9358
6L-7816	Seal - o-Ring	314-8542
6N-6969	Chamber As	247-3299
6N-8847	Guide - Valve	314-8523
7B-2420	Ferrule - Director	314-8517
7H-0602	Dog - Clutch	314-8515
7M-4603	Body - Fuel Valve	311-9348
7M-4926	Retainer - Pin	314-8538
7M-7817	Valve - Inlet	311-9474
7S-5787	Chamber As	247-3300
7S-7809	Cap As - Radiator	295-6417
8F-5104	Screen As - Oil Pan	314-8539
8F-8858	Button Valve	314-8511
8H-2810	Case As - Filter	314-8512
8M-0874	Plunger As - Valve	311-9439
8M-4014	Insert - Seat Exhaust	311-9398
8N-3723	Valve - Exhaust	311-9472
8N-7780	Shield - Oil	314-8544
8N-9174	Liner - Cylinder	314-8531
8S-3617	Chamber As	247-3302
9F-7101	Bushing - Collar	299-1988
9S-8493	Bolt - Connecting Rod	311-9351

Sales Model D9E

Original Part Number	Part Name	Classic Part Number
1F-2254	Bushing - Stem	314-8510
1H-4106	Pin As - Drawbar	325-6126
1J-6744	Bearing	361-1705
1P-8005	Gasket - Chamber	314-8527
1S-1888	Bracket - Lamp	297-7147
1W-5105	Ring Gp - Piston	311-9446
2S-3966	Ring - Seal	297-7237
3J-6043	Trunnion	319-3477
4N-3664	Guide - Valve	314-8524
4N-7526	Seal As - Pump	311-9454
4N-9180	Seal As - Pump	311-9455
4S-8906	Insert	311-9397
4S-8908	Insert	311-9399
4S-8909	Insert - Valve Seat	311-9400
5J-4321	Trunnion	302-2700
5S-1211	Cover - Valve	314-8665
5S-1757	Insert - Seat	311-9401
6F-7523	Cap - Bearing	325-6039
6L-7816	Seal - o-Ring	314-8542
6N-8847	Guide - Valve	314-8523
7B-2420	Ferrule - Director	314-8517
7M-7817	Valve - Inlet	311-9474
7S-5787	Chamber As	247-3300
7S-7809	Cap As - Radiator	295-6417
7T-2036	Cap As - Filter	361-1721
8F-5104	Screen As - Oil Pan	314-8539
8M-4014	Insert - Seat Exhaust	311-9398
8N-3723	Valve - Exhaust	311-9472
8N-9174	Liner - Cylinder	314-8531

Sales Model D9G

Original Part Number	Part Name	Classic Part Number
102-1561	Lifter As - Valve	311-9402
190-8609	Valve - Fill	360-2288
1A-2846	Cap As - Filler	311-9368
1F-2254	Bushing - Stem	314-8510
1H-4106	Pin As - Drawbar	325-6126
1J-6744	Bearing	361-1705
1J-6746	Pin	256-4817
1J-6749	Screw - Adjustable	256-4824
1M-4153	Carrier - Planet	213-1114
1M-4155	Gear - Ring	214-0519
1M-4156	Gear - Ring	214-0520
1M-4167	Shaft - Planet	219-9700
1M-4171	Cage - Bearing	216-7460
1P-2187	Pump Gp	299-2044
1P-4145	Valve Gp - Press	247-4436
1P-8005	Gasket - Chamber	314-8527
1S-1888	Bracket - Lamp	297-7147
1S-4701	Pulley - Alt	264-5866
1S-8753	Plate - Coupling	308-9910
1S-8754	Joint Gp - Univ	308-9873
1T-0224	Carrier - Ring	239-7928
1T-0228	Housing - Rotating	216-7467
1T-0231	Retainer - Bearing	319-3471
1T-0237	Flange As - Output	239-7929
1T-0256	Gear - Pump Drive	239-7930
1T-0595	Carrier - Wheel	239-7939
1T-0611	Converter As	235-1804 (Repair Kit)
1T-1389	Carrier - Bearing	247-4124
1W-3062	Retainer As	311-9445
1W-5105	Ring Gp - Piston	311-9446
244-1090	Alarm - Back up	360-2345
2F-0025	Tube	325-6233
2F-5721	Bearing - Ball	311-9354
2K-3592	Boss	314-8501
2K-4507	Bearing - Sleeve	325-6021
2M-1129	Cap - Support	239-7974
2M-2150	Nut - Spanner	239-7965
2M-3339	Piston - Clutch	221-7944
2M-5588	Gear - Final Drive	239-7936
2M-5589	Pinion - Final Drive	239-7942
2M-6920	Hub - Steering	239-7968
2M-6960	Cage - Gear Bearing	239-7971
2M-6984	Drum	239-7946
2M-8762	Drum - Steering	239-7944
2N-3220	Gear - Oil Pump Drive	311-9392
2N-9297	Retainer - Spring	314-8535
2P-1005	Bearing - Sleeve	296-1342
2P-1554	Gear - Ring	239-7931
2P-1606	Piston - Steering	239-7948
2P-1607	Pilot - Piston	239-7975
2P-4370	Plate - Clutch	325-6166
2P-6159	Pulley - Fan Drive	264-5873
2S-3966	Ring - Seal	297-7237
2S-7264	Pump As - Fuel Injector	311-9442
2S-7873	Pump Gp	226-0162
2S-7917	Gear - Pump Drive	247-4119
2S-7920	Pump Gp - Scavenge	217-2594
2S-8961	Pulley - Tightener	264-5875
3F-6185	Pin	295-5694
3F-6523	Pin - Clevis	256-4818

(Continued)

Sales Model D9G (Continued)

Original Part Number	Part Name	Classic Part Number
3F-7445	Bearing - Sleeve	314-8508
3H-7161	Pin	256-4819
3H-7162	Collar	256-4830
3J-5190	Cap - Bearing	256-4837
3J-6043	Trunnion	319-3477
3J-6497	Screw - Adjusting	256-4825
3L-1425	Bearing - Ball	311-9356
3P-1849	Ring - Sealing	360-2259
3P-2811	Flange	239-7976
3P-3259	Cage - Bearing	217-7728
3P-4002	Pump Gp - Gear	217-2595
3P-4850	Gear As - Oil Pump	308-9848
3P-4855	Pump Gp	217-2596
3P-6269	Cage - Pinion Bearing	239-7972
3P-9394	Shaft - Planet	215-1680
3S-1261	Shaft - Center	239-7958
3S-1262	Retainer	308-9915
3S-9919	Shaft As	239-7959
4M-0433	Shaft - Steer	239-7960
4M-0503	Gear As - Oil Pump	297-7184
4M-1001	Pump Gp - Final Drive Oil	226-0166
4M-8967	Gear - Sun	219-9661
4M-9214	Shaft - Pump Drive	314-8543
4M-9215	Gear - Pump Idler	311-9391
4M-9216	Gear - Pump Drive	311-9390
4N-3664	Guide - Valve	314-8524
4N-7526	Seal As - Pump	311-9454
4N-9180	Seal As - Pump	311-9455
4S-5833	Spacer	239-7961
4S-8472	Hood As	296-1355
4S-8906	Insert	311-9397
4S-8908	Insert	311-9399
4S-8909	Insert - Valve Seat	311-9400
5D-0470	Valve Gp	314-8549
5F-7993	Pin	319-3454
5G-3612	Cap Gp	295-6419
5H-5553	Screw -Tappet Adjustable	311-9451
5J-4321	Trunnion	302-2700
5J-4798	Bearing As	256-4840
5J-8052	Trunnion	256-4843
5M-0549	Gear - Transmission	215-1689
5M-3947	Shaft - Planet	223-6318
5M-3996	Gear - Ring	214-0527
5M-3999	Shaft - Transmission	215-1693
5M-4427	Gear - Sun	214-0529
5M-7953	Carrier As	239-7977
5M-7955	Shaft As - Planet	364-5273
5M-7990	Gear - Sun	239-7938
5M-8007	Gear - Ring	239-7932
5N-8879	Manifold - Exhaust	261-0898
5N-9055	Manifold - Exhaust	261-0890
5P-7807	Bearing - Ball	314-8502
5S-1211	Cover - Valve	314-8665
5S-1757	Insert - Seat	311-9401
5S-5746	Retainer - Guard	319-3472
5S-9080	Pulley - Alt Drive	264-5883
6F-7523	Cap - Bearing	325-6039
6H-3957	Bearing - Ball	311-9358
6J-2326	Pin	319-3458
6J-7563	Pin	319-3459
6J-8805	Bearing As	256-4841
6J-9793	Bearing	256-4835
6L-7816	Seal - o-Ring	314-8542
6L-8585	Gear - Gov Drive	314-8526
6N-6969	Chamber As	247-3299
6N-7295	Manifold - Exhaust	261-0903
6N-8847	Guide - Valve	314-8523
6T-4481	Shaft - Planet	221-7946
7B-2420	Ferrule - Director	314-8517
7G-2492	Gear - Planet	239-7933
7G-2500	Gear - Planet	296-1350
7H-0602	Dog - Clutch	314-8515
7H-7630	Spacer	239-7962
7J-9884	Bearing - Sleeve	325-6016
7M-1184	Housing As	219-9704
7M-1185	Housing As	219-9705
7M-1186	Housing As	219-9706
7M-1195	Housing - Clutch	219-9707
7M-1249	Piston - Clutch	215-1748
7M-2167	Ring - Governor Control	308-9919
7M-4603	Body - Fuel Valve	311-9348
7M-4926	Retainer - Pin	314-8538
7M-5756	Gear - Ring	214-0531
7M-6621	Pump Gp - Oil	226-0172
7M-7431	Service Gp - Valve	314-8550
7M-7817	Valve - Inlet	311-9474
7M-8395	Piston - Clutch	223-6322
7M-8397	Housing As	239-7956
7N-2957	Cover - Rad Cap	361-1722
7N-9810	Pin - Piston	311-9432
7S-1579	Nut - Spanner	239-7964
7S-5787	Chamber As	247-3300
7S-6104	Gear - Sun	239-7934
7S-7400	Pump Gp	226-0173
7S-7809	Cap As - Radiator	295-6417
7S-7975	Guard - Final Drive Wear	239-7966
7S-9749	Pulley - Gen Drive	264-5888
7T-2036	Cap As - Filter	361-1721
8B-5972	Bearing - Ball	314-8503
8E-7455	Gear - Planet	221-7947
8E-7456	Gear - Planet	221-7948
8E-9795	Connector As	256-4851
8F-5104	Screen As - Oil Pan	314-8539
8F-8858	Button Valve	314-8511
8H-2810	Case As - Filter	314-8512
8M-0874	Plunger As - Valve	311-9439
8M-2549	Rod As - Connector	314-8537
8M-4014	Insert - Seat Exhaust	311-9398
8M-7166	Housing - Screen	297-7192
8M-8161	Flange - Shaft	215-1781

(Continued)

Sales Model D9G (Continued)

Original Part Number	Part Name	Classic Part Number
8N-2275	Bearing - Sleeve	311-9365
8N-3723	Valve - Exhaust	311-9472
8N-7780	Shield - Oil	314-8544
8N-9174	Liner - Cylinder	314-8531
8P-5849	Plate As	223-6323
8P-7396	Hub - Planet Gear	239-7967
8P-7595	Washer - Thrust	239-7940
8P-7639	Gear - Planet	239-7935
8S-3487	Gear As - Ring	221-7949
8S-3491	Housing As	221-7950
8S-3617	Chamber As	247-3302
8S-5438	Muffler As	360-7896
9G-7993	Cage - Gr Bearing Rh	239-7973
9H-5233	Piston - Clutch	219-9708
9H-5433	Spacer	239-7963
9J-3346	Plate As - Trunnion	256-4839
9M-1328	Bearing - Aligning	325-6018
9M-3025	Cover As	299-2001
9P-3663	Carrier - Planet	213-6939
9P-6592	Gear - Planet	215-1915
9P-6594	Gear - Planet	215-1921
9S-8493	Bolt - Connecting Rod	311-9351

Sales Model D9H

Original Part Number	Part Name	Classic Part Number
095-2927	Valve - Fill	360-2292
095-9291	Valve - Fill	360-2293
102-1561	Lifter As - Valve	311-9402
115-0637	Pump Gp	226-0160
190-8609	Valve - Fill	360-2288
1H-4106	Pin As - Drawbar	325-6126
1J-6746	Pin	256-4817
1J-6749	Screw - Adjustable	256-4824
1M-4153	Carrier - Planet	213-1114
1M-4155	Gear - Ring	214-0519
1M-4156	Gear - Ring	214-0520
1M-4167	Shaft - Planet	219-9700
1M-4171	Cage - Bearing	216-7460
1P-2187	Pump Gp	299-2044
1P-4145	Valve Gp - Press	247-4436
1P-8005	Gasket - Chamber	314-8527
1S-1888	Bracket - Lamp	297-7147
1S-4701	Pulley - Alt	264-5866
1S-8753	Plate - Coupling	308-9910
1S-8754	Joint Gp - Univ	308-9873
1T-0224	Carrier - Ring	239-7928
1T-0228	Housing - Rotating	216-7467
1T-0231	Retainer - Bearing	319-3471
1T-0237	Flange As - Output	239-7929
1T-0256	Gear - Pump Drive	239-7930
1T-0595	Carrier - Wheel	239-7939
1T-0611	Converter As	235-1804 (Repair Kit)
1T-1389	Carrier - Bearing	247-4124
1W-3062	Retainer As	311-9445
244-1090	Alarm - Back up	360-2345
2F-5721	Bearing - Ball	311-9354
2M-1129	Cap - Support	239-7974
2M-2150	Nut - Spanner	239-7965
2M-3339	Piston - Clutch	221-7944
2M-5588	Gear - Final Drive	239-7936
2M-5589	Pinion - Final Drive	239-7942
2M-6920	Hub - Steering	239-7968
2M-6960	Cage - Gear Bearing	239-7971
2M-6984	Drum	239-7946
2M-8762	Drum - Steering	239-7944
2N-3220	Gear - Oil Pump Drive	311-9392
2N-7942	Spacer	363-7462
2N-9297	Retainer - Spring	314-8535
2P-1005	Bearing - Sleeve	296-1342
2P-1554	Gear - Ring	239-7931
2P-1606	Piston - Steering	239-7948
2P-1607	Pilot - Piston	239-7975
2P-4370	Plate - Clutch	325-6166
2P-6159	Pulley - Fan Drive	264-5873
2S-3966	Ring - Seal	297-7237
2S-7264	Pump As - Fuel Injector	311-9442
2S-7917	Gear - Pump Drive	247-4119
2S-8961	Pulley - Tightener	264-5875
2W-9978	Core As - Oil Cooler	279-4983
3F-6185	Pin	295-5694
3F-6523	Pin - Clevis	256-4818
3F-7445	Bearing - Sleeve	314-8508
3H-7161	Pin	256-4819
3H-7162	Collar	256-4830
3J-5190	Cap - Bearing	256-4837
3J-6043	Trunnion	319-3477
3J-6497	Screw - Adjusting	256-4825
3L-1425	Bearing - Ball	311-9356
3P-2811	Flange	239-7976
3P-3259	Cage - Bearing	217-7728
3P-3935	Shaft	299-2053
3P-4089	Gear As - Ring	239-7952
3P-4094	Housing As	239-7954

(Continued)

Sales Model D9H (Continued)

Original Part Number	Part Name	Classic Part Number
3P-4096	Gear As - Ring	239-7953
3P-6269	Cage - Pinion Bearing	239-7972
3P-9394	Shaft - Planet	215-1680
3S-1261	Shaft - Center	239-7958
3S-1262	Retainer	308-9915
3S-9919	Shaft As	239-7959
4M-0433	Shaft - Steer	239-7960
4M-1001	Pump Gp - Final Drive Oil	226-0166
4M-8967	Gear - Sun	219-9661
4M-9214	Shaft - Pump Drive	314-8543
4M-9215	Gear - Pump Idler	311-9391
4M-9216	Gear - Pump Drive	311-9390
4N-3664	Guide - Valve	314-8524
4N-3714	Chamber, Precom	363-7450
4N-5184	Muffler As	360-7874
4N-7526	Seal As - Pump	311-9454
4N-9180	Seal As - Pump	311-9455
4S-5833	Spacer	239-7961
4S-8906	Insert	311-9397
4S-8908	Insert	311-9399
4S-8909	Insert - Valve Seat	311-9400
5D-0470	Valve Gp	314-8549
5F-7993	Pin	319-3454
5G-3612	Cap Gp	295-6419
5H-5553	Screw -Tappet Adjustable	311-9451
5J-4798	Bearing As	256-4840
5J-8052	Trunnion	256-4843
5M-0549	Gear - Transmission	215-1689
5M-3947	Shaft - Planet	223-6318
5M-3996	Gear - Ring	214-0527
5M-3999	Shaft - Transmission	215-1693
5M-4427	Gear - Sun	214-0529
5M-7953	Carrier As	239-7977
5M-7955	Shaft As - Planet	364-5273
5M-7990	Gear - Sun	239-7938
5M-8007	Gear - Ring	239-7932
5N-8879	Manifold - Exhaust	261-0898
5N-9055	Manifold - Exhaust	261-0890
5P-7807	Bearing - Ball	314-8502
5S-1211	Cover - Valve	314-8665
5S-1757	Insert - Seat	311-9401
5S-5746	Retainer - Guard	319-3472
5S-9080	Pulley - Alt Drive	264-5883
6H-3957	Bearing - Ball	311-9358
6J-2326	Pin	319-3458
6J-7563	Pin	319-3459
6J-8805	Bearing As	256-4841
6J-9793	Bearing	256-4835
6L-7816	Seal - o-Ring	314-8542
6L-8585	Gear - Gov Drive	314-8526
6N-6969	Chamber As	247-3299
6N-7295	Manifold - Exhaust	261-0903
6N-8847	Guide - Valve	314-8523
6T-4481	Shaft - Planet	221-7946
7B-2420	Ferrule - Director	314-8517
7C-3039	Core, Oil Cooler	363-7451
7G-2492	Gear - Planet	239-7933
7G-2500	Gear - Planet	296-1350
7H-0602	Dog - Clutch	314-8515
7J-9884	Bearing - Sleeve	325-6016
7M-1185	Housing As	219-9705
7M-1186	Housing As	219-9706
7M-1195	Housing - Clutch	219-9707
7M-4603	Body - Fuel Valve	311-9348
7M-4926	Retainer - Pin	314-8538
7M-7817	Valve - Inlet	311-9474
7N-2957	Cover - Rad Cap	361-1722
7N-9810	Pin - Piston	311-9432
7S-1579	Nut - Spanner	239-7964
7S-5787	Chamber As	247-3300
7S-6104	Gear - Sun	239-7934
7S-7400	Pump Gp	226-0173
7S-7809	Cap As - Radiator	295-6417
7S-7975	Guard - Final Drive Wear	239-7966
7T-2036	Cap As - Filter	361-1721
8E-7455	Gear - Planet	221-7947
8E-7456	Gear - Planet	221-7948
8E-9795	Connector As	256-4851
8F-8858	Button Valve	314-8511
8H-2810	Case As - Filter	314-8512
8M-0874	Plunger As - Valve	311-9439
8M-2549	Rod As - Connector	314-8537
8M-4014	Insert - Seat Exhaust	311-9398
8M-7166	Housing - Screen	297-7192
8M-8161	Flange - Shaft	215-1781
8N-0597	Pulley	264-5890
8N-2275	Bearing - Sleeve	311-9365
8N-3723	Valve - Exhaust	311-9472
8N-7780	Shield - Oil	314-8544
8N-9174	Liner - Cylinder	314-8531
8P-4734	Housing As	239-7955
8P-4735	Piston - Clutch	239-7949
8P-7396	Hub - Planet Gear	239-7967
8P-7595	Washer - Thrust	239-7940
8P-7639	Gear - Planet	239-7935
8S-3617	Chamber As	247-3302
9G-7993	Cage - Gr Bearing Rh	239-7973
9H-5233	Piston - Clutch	219-9708
9H-5433	Spacer	239-7963
9J-3346	Plate As - Trunnion	256-4839
9K-8757	Rod End - Bearing	311-9361
9M-3025	Cover As	299-2001
9P-3663	Carrier - Planet	213-6939
9P-6592	Gear - Planet	215-1915
9P-6594	Gear - Planet	215-1921

(Continued)

Sales Model D9H (Continued)

Original Part Number	Part Name	Classic Part Number
9S-8493	Bolt - Connecting Rod	311-9351

Cat® Classic™ Parts for Wheel Loaders

Cat® wheel loaders are designed to deliver exceptional performance, ease of serviceability, and to have long, productive lives. The residual value of a machine depreciates as it gets older, so maintenance costs often need to be re-evaluated. Caterpillar offers Cat® Classic™ parts for several models of wheel loaders (920, 930, 950/B/E, 966A/B/C/D/E, 980/B/C) to help you manage those maintenance costs.

Cat Classic parts provide owners of older Cat products with low cost repair alternatives that minimize the risk associated with non-genuine parts.

Cat Classic parts coverage for wheel loaders includes:

- Axle Final Drive
- Circle/Center Shift Linkage Pin
- Differential Torque Converter
- Engine
- Final Drive
- Transmission
- ...and many more.

Sales Model 920

Original Part Number	Part Name	Classic Part Number
100-7860	Valve - Inlet	270-4360 (Valve), 270-4362 (Valve Kit)
104-4253	Line As - Fuel Injector	279-4988
104-4254	Line As - Fuel Injector	279-4989
111-8015	Gasket As - Head	279-4977
121-7746	Precleaner As	360-2311
131-3815	Seal Gp - Basic	325-6193
148-7455	Valve - Exhaust	270-4361
165-4262	Body As - Piston	270-4351
170-0560	Rebuild Kit	363-7458
172-5185	Shaft - Water Pump	325-6201
172-5188	Shaft - Water Pump	325-6202
172-5189	Impeller - Pump	295-5687
172-5190	Impeller - Pump	325-6111
172-6712	Impeller - Pump	325-6112
172-7767	Pump Gp - Water	296-1365
196-0028	Gear As - Idler	364-5259
1M-7250	Bowl - Precleaner	360-2296
1N-3576	Block Gp - Cylinder	279-4978
1N-3958	Elbow	325-6087
1N-4304	Head Gp - Cylinder	269-8761
1P-1216	Manifold - Exhaust	261-0902
1P-1721	Gear - Balance	298-2769
1P-1722	Gear - Balance	298-2770
1P-5480	Cover As - End	299-1998
1P-9945	Bracket As - Fan	296-1344
1P-9946	Shaft - Fan	325-6194
1P-9952	Impeller - Pump	314-8685
1S-1888	Bracket - Lamp	297-7147
1S-4701	Pulley - Alt	264-5866
1T-0020	Wheel - Turbine	297-4862
1T-0851	Impeller - Converter	253-1418
1T-1428	Retainer - Bearing	300-2587
1T-1987	Housing - Rotating	297-4864
1V-1409	Carrier - Planet	253-1423
1V-1554	Spindle	219-2972
1V-4838	Link As - Spring	308-9874
1W-0777	Muffler As	247-2662
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1695	Pump Gp	279-4980
1W-1698	Housing - Transfer Pump	296-1356
1W-1766	Muffler As	298-2783
1W-2870	Shaft As - Balance	314-8715
1W-2871	Shaft As - Balance	314-8716
1W-4402	Gear - Camshaft	279-4981
1W-4405	Gear - Crankshaft	279-4982
1W-5912	Tappet As - Guide	325-6223
1W-6541	Plunger As	325-6173
244-1090	Alarm - Back up	360-2345
2F-5721	Bearing - Ball	311-9354
2K-4502	Bearing - Sleeve	299-1986
2P-1170	Shaft As - Gear	296-1367
2P-1757	Hub - Fan Pulley	296-1357
2P-1781	Spacer - Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2519	Tube As - Inlet	325-6230
2P-2719	Pipe	363-7454

(Continued)

Sales Model 920 (Continued)

Original Part Number	Part Name	Classic Part Number
2P-4404	Housing As	226-8027
2P-4409	Gear - Ring	226-7981
2P-6128	Pulley	264-5872
2P-6245	Shaft As - Pump	325-6197
2P-6255	Muffler As	247-2666
2P-7828	Pan - Oil	314-8691
2W-1086	Cover As - Cylinder Head	325-6049
2W-2621	Valve - Inlet	247-6892 (Valve), 241-3381 (Valve Kit)
2W-7255	Shaft - Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear - Water Pump	325-6088
3K-3124	Muffler - Trap	247-2673
3K-5461	Wheel - Steering	308-9945
3L-1425	Bearing - Ball	311-9356
3P-3208	Flange - Joint	301-4647
3S-2616	Pump Gp - Transmission	226-0165
3S-7987	Shaft - Planet	226-6074
3S-7996	Gear - Ring	226-6087
3V-7427	Housing As	297-7197
4F-4974	Clamp	311-9373
4J-3015	Shaft	325-6204
4N-2954	Sleeve - Camshaft	299-2059
4N-3281	Line As - Fuel Injector	247-3362
4N-3282	Line As - Fuel Injector	247-3363
4N-3283	Line As - Fuel Injector	247-3364
4N-3284	Line As - Fuel Injector	247-3365
4N-4864	Pump Gp - Fuel Transfer	242-3442
4N-7692	Crankshaft As	242-3440
4N-7693	Crankshaft As	242-3439
4N-7977	Shaft As - Balance	314-8709
4N-7978	Shaft As - Balance	314-8710
4N-9587	Shield - Heat	297-7260
4P-0660	Muffler As	298-2787
4P-3546	Valve As - Relief	325-6236
4P-9381	Line As - Fuel Injector	279-4984
4P-9382	Line As - Fuel Injector	279-4985
4P-9961	Line As - Fuel Injector	325-6115
4P-9962	Line As - Fuel Injector	325-6116
4P-9963	Line As - Fuel Injector	298-2777
4P-9964	Line As - Fuel Injector	298-2778
4S-8670	Shaft - Planet	300-2590
4S-8687	Piston - Clutch	226-8008
4S-8713	Gear - Ring	226-6090
4V-9577	Shaft - Planet	231-0001
4W-0452	Seal As - Camshaft	325-6191
5G-3612	Cap Gp	295-6419
5M-7882	Joint Gp - Univ	297-7210
5P-7807	Bearing - Ball	314-8502
5S-0884	Gear - Ring	226-7982
5S-1211	Cover - Valve	314-8665
5S-6795	Chamber As	242-3437
5S-7609	Pulley - Alt Drive	264-5881
5S-8038	Pulley - Crankshaft	264-5882
5S-9062	Spacer	363-7463
5S-9080	Pulley - Alt Drive	264-5883
6H-3957	Bearing - Ball	311-9358
6I-1346	Pump Gp - Oil	295-5674
6K-0053	Housing	297-7191
6K-2034	Shaft	297-7249
6K-2036	Rack	299-2045
6K-2703	Pin - Lower	252-6853
6K-2704	Pin - Upper	252-6873
6K-2707	Plate - Lock	319-3470
6K-3447	Pin	241-2576
6K-3674	Shaft - Bevel Pinion	253-1427
6K-5448	Pin	252-6856
6K-5472	Pin	252-6857
6K-5619	Shaft	253-1429
6K-5621	Retainer - Oil Seal	253-1443
6K-5625	Gear - Bevel Ring	253-1438
6K-6175	Pin	241-2606
6K-6185	Pin - Cylinder	252-6859
6K-6349	Pin	252-6860
6K-7285	Pin	252-6861
6K-7288	Pin	252-6862
6K-8314	Pin	252-6863
6K-8316	Pin	252-6865
6K-8542	Pin	252-6867
6K-8544	Pin	252-6874
6K-8546	Pin	252-6868
6N-1036	Gear - Oil Pump	279-4991
6N-1553	Coupling - Exhaust	295-6422
6N-2789	Pulley	264-5886
6N-8413	Housing - Pump	325-6110
6P-7704	Carrier - Ring	314-8658
6S-3759	Pin As	241-2543
7C-4297	Seal As - Camshaft	325-6192
7G-2480	Gear - Planet	226-6091
7G-2481	Gear - Planet	226-6092
7G-2485	Gear - Planet	226-7983
7G-2830	Ring - Seal	295-6441
7J-6461	Crown	325-6054
7J-9682	Bearing - Sleeve	360-2335
7J-9842	Bearing - Sleeve	299-1968
7K-0252	Gear - Ring	231-0008
7K-5213	Pin	252-6869
7K-6497	Pin	252-6870
7K-7237	Gear - Planet	231-0009
7K-9346	Pin	252-6871
7K-9347	Pin	252-6875
7K-9348	Pin	252-6872
7K-9591	Bearing - Sleeve	365-8826
7K-9592	Bearing - Sleeve	360-2336
7K-9593	Bearing - Sleeve	360-2337
7M-2167	Ring - Governor Control	308-9919
7M-4603	Body - Fuel Valve	311-9348
7N-0128	Core As - Oil Cooler	299-1994
7N-0165	Core As - Oil Cooler	295-5670

(Continued)

Sales Model 920 (Continued)

Original Part Number	Part Name	Classic Part Number
7N-1164	Mount As	295-5451
7N-2871	Line As - Fuel Injector	319-8172
7N-2872	Line As - Fuel Injector	319-8173
7N-2874	Line As - Fuel Injector	298-2779
7N-2949	Pulley	264-5887
7N-2957	Cover - Rad Cap	361-1722
7N-3515	Gear - Camshaft	314-8669
7N-3536	Gear - Fuel	279-4993
7N-5910	Impeller - Pump	314-8686
7N-9145	Gear - Flywheel	279-4994
7N-9805	Pin - Piston	295-6438
7S-3161	Lifter - Valve	279-4996
7S-6723	Bracket - Alternator	299-1978
7S-7070	Head As - Cylinder	325-6107
7S-7809	Cap As - Radiator	295-6417
7S-9749	Pulley - Gen Drive	264-5888
7T-2036	Cap As - Filter	361-1721
7W-0450	Gear - Water Pump	279-4997
7W-0507	Gear - Oil Pump Drive	279-4998
7W-0508	Gear - Fuel Pump Drive	296-1351
7W-5687	Hub - Camshaft	314-8684
8H-2810	Case As - Filter	314-8512
8H-9806	Gear - Shaft Drive	325-6091
8K-6320	Shaft - Axle	253-1430
8K-6321	Gear - Sun	253-1441
8M-0874	Plunger As - Valve	311-9439
8N-0002	Trunnion As	314-8728
8N-0875	Valve - Exhaust	247-6893 (Valve), 241-3381 (Valve Kit)
8N-1187	Head Gp - Cylinder	242-3435
8N-1188	Head Gp - Cylinder	242-3436
8N-1721	Rod As - Conn	269-5291
8N-1965	Tube - Disposal	325-6235
8N-1984	Rod As - Conn	242-3441
8N-2510	Shaft	325-6208
8N-2641	Sleeve	325-6210
8N-3180	Body As - Piston	250-6563
8N-3181	Piston Gp - Basic	250-6555 (Liner Kit)
8N-3182	Body As - Piston	250-6564 (Piston As), 250-6556 (Liner Kits)
8N-3183	Piston Gp - Basic	250-6556 (Liner Kit)
8N-3251	Shaft As - Rocker Arm	314-8711
8N-3311	Shaft As - Rocker Arm	325-6199
8N-3312	Shaft As - Rocker Arm	325-6200
8N-3325	Arm Gp - Rocker	314-8623
8N-3327	Arm Gp - Rocker	314-8624
8N-5305	Spacer	363-7464
8N-5929	Cover - Water Pump	296-1349
8N-6796	Head Gp - Cylinder	269-5290
8N-7315	Tube As - Outlet	325-6232
8N-7780	Shield - Oil	314-8544
8N-8225	Bearing - Main	314-8652
8N-9733	Line As - Fuel Injector	319-8174
8S-0248	Breather As	325-6033
8S-0493	Shaft As - Pump	325-6198
8S-3970	Chamber As	242-3438
8V-3134	Pinion - Bevel	260-0788
8V-3135	Gear - Differential Bevel	260-0783
8V-3136	Gear - Differential Bevel	253-1442
9H-2256	Pump Gp	311-9443
9M-4789	Shaft - Gov Control	297-7256
9N-5769	Cover - Housing	325-6050
9S-2356	Manifold - Exhaust	261-0905
9S-6129	Pulley - Alternator Drive	264-5891
9S-8679	Chamber As	325-6042
9Y-2992	Bearing - Sleeve	325-6032

Sales Model 930

Original Part Number	Part Name	Classic Part Number
100-7860	Valve - Inlet	270-4360 (Valve), 270-4362 (Valve Kit)
104-4253	Line As - Fuel Injector	279-4988
104-4254	Line As - Fuel Injector	279-4989
111-8015	Gasket As - Head	279-4977
112-3249	Muffler As	247-2661
121-7746	Precleaner As	360-2311
131-3815	Seal Gp - Basic	325-6193
148-7455	Valve - Exhaust	270-4361
165-4262	Body As - Piston	270-4351
170-0560	Rebuild Kit	363-7458
172-5185	Shaft - Water Pump	325-6201
172-5188	Shaft - Water Pump	325-6202
172-5189	Impeller - Pump	295-5687
172-5190	Impeller - Pump	325-6111

(Continued)

Sales Model 930 (Continued)

Original Part Number	Part Name	Classic Part Number
172-6712	Impeller - Pump	325-6112
172-7767	Pump Gp - Water	296-1365
196-0028	Gear As - Idler	364-5259
1M-7250	Bowl - Pre-cleaner	360-2296
1N-3576	Block Gp - Cylinder	279-4978
1N-3958	Elbow	325-6087
1N-4304	Head Gp - Cylinder	269-8761
1P-1216	Manifold - Exhaust	261-0902
1P-1721	Gear - Balance	298-2769
1P-1722	Gear - Balance	298-2770
1P-5480	Cover As - End	299-1998
1P-9945	Bracket As - Fan	296-1344
1P-9946	Shaft - Fan	325-6194
1P-9952	Impeller - Pump	314-8685
1S-4701	Pulley - Alt	264-5866
1T-0020	Wheel - Turbine	297-4862
1T-0851	Impeller - Converter	253-1418
1T-1428	Retainer - Bearing	300-2587
1T-1987	Housing - Rotating	297-4864
1V-3335	Carrier - Planet	253-1424
1V-4718	Spindle	223-4817
1V-4838	Link As - Spring	308-9874
1W-0777	Muffler As	247-2662
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1695	Pump Gp	279-4980
1W-1698	Housing - Transfer Pump	296-1356
1W-2870	Shaft As - Balance	314-8715
1W-2871	Shaft As - Balance	314-8716
1W-4402	Gear - Camshaft	279-4981
1W-4405	Gear - Crankshaft	279-4982
1W-5912	Tappet As - Guide	325-6223
1W-6541	Plunger As	325-6173
244-1090	Alarm - Back up	360-2345
2F-5721	Bearing - Ball	311-9354
2K-0535	Nut	299-2026
2K-3592	Boss	314-8501
2K-4502	Bearing - Sleeve	299-1986
2K-4513	Bearing - Sleeve	308-9814
2K-8753	Gear - Diff	253-1432
2K-8754	Gear - Diff Bevel	253-1433
2P-1170	Shaft As - Gear	296-1367
2P-1757	Hub - Fan Pulley	296-1357
2P-1781	Spacer - Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2519	Tube As - Inlet	325-6230
2P-2719	Pipe	363-7454
2P-4404	Housing As	226-8027
2P-4409	Gear - Ring	226-7981
2P-6128	Pulley	264-5872
2P-6245	Shaft As - Pump	325-6197
2P-6255	Muffler As	247-2666
2P-7828	Pan - Oil	314-8691
2V-1074	Shaft - Planet	364-5262
2V-5881	Gear - Bevel Ring	253-1434
2W-1086	Cover As - Cylinder Head	325-6049
2W-2621	Valve - Inlet	247-6892 (Valve), 241-3381 (Valve Kit)
2W-6757	Trunnion As	295-5678
2W-7255	Shaft - Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear - Water Pump	325-6088
2W-9978	Core As - Oil Cooler	279-4983
2Y-4213	Pulley	314-8703
3J-6502	Pin	319-3453
3K-3124	Muffler - Trap	247-2673
3K-5461	Wheel - Steering	308-9945
3K-7110	Gear - Planet	253-1435
3K-7111	Gear - Sun	253-1436
3K-7112	Gear - Ring	253-1437
3L-1425	Bearing - Ball	311-9356
3P-0114	Elbow - Exhaust	314-8516
3P-3208	Flange - Joint	301-4647
3S-2616	Pump Gp - Transmission	226-0165
3S-7987	Shaft - Planet	226-6074
3S-7996	Gear - Ring	226-6087
3V-7427	Housing As	297-7197
4F-4974	Clamp	311-9373
4J-3015	Shaft	325-6204
4N-2954	Sleeve - Camshaft	299-2059
4N-3281	Line As - Fuel Injector	247-3362
4N-3282	Line As - Fuel Injector	247-3363
4N-3283	Line As - Fuel Injector	247-3364
4N-3284	Line As - Fuel Injector	247-3365
4N-4864	Pump Gp - Fuel Transfer	242-3442
4N-7692	Crankshaft As	242-3440
4N-7693	Crankshaft As	242-3439
4N-7977	Shaft As - Balance	314-8709
4N-7978	Shaft As - Balance	314-8710
4N-8591	Coupling - Exhaust	325-6053
4N-9587	Shield - Heat	297-7260
4P-0660	Muffler As	298-2787
4P-3546	Valve As - Relief	325-6236
4P-9381	Line As - Fuel Injector	279-4984
4P-9382	Line As - Fuel Injector	279-4985
4P-9961	Line As - Fuel Injector	325-6115
4P-9962	Line As - Fuel Injector	325-6116
4P-9963	Line As - Fuel Injector	298-2777

(Continued)

Sales Model 930 (Continued)

Original Part Number	Part Name	Classic Part Number
4P-9964	Line As - Fuel Injector	298-2778
4S-8670	Shaft - Planet	300-2590
4S-8687	Piston - Clutch	226-8008
4S-8713	Gear - Ring	226-6090
4W-0452	Seal As - Camshaft	325-6191
5G-3612	Cap Gp	295-6419
5K-7995	Bearing - Sleeve	308-9820
5M-7882	Joint Gp - Univ	297-7210
5P-7807	Bearing - Ball	314-8502
5S-0884	Gear - Ring	226-7982
5S-1211	Cover - Valve	314-8665
5S-6795	Chamber As	242-3437
5S-7609	Pulley - Alt Drive	264-5881
5S-8038	Pulley - Crankshaft	264-5882
5S-9062	Spacer	363-7463
5S-9080	Pulley - Alt Drive	264-5883
6H-3957	Bearing - Ball	311-9358
6I-1346	Pump Gp - Oil	295-5674
6K-0053	Housing	297-7191
6K-2034	Shaft	297-7249
6K-2036	Rack	299-2045
6K-3447	Pin	241-2576
6K-4180	Pin - Upper	252-6854
6K-4189	Spacer	367-6075
6K-4190	Cap - Lower	297-7161
6K-4191	Cap - Upper	300-2576
6K-4192	Pin - Lower	252-6855
6K-4193	Plate - Lock	282-6566
6K-6046	Pin	241-2602
6K-6047	Pin	241-2603
6K-6051	Pin	252-6858
6K-6053	Pin	241-2604
6K-6054	Pin	241-2605
6K-6175	Pin	241-2606
6K-6185	Pin - Cylinder	252-6859
6K-6349	Pin	252-6860
6N-1036	Gear - Oil Pump	279-4991
6N-1553	Coupling - Exhaust	295-6422
6N-2789	Pulley	264-5886
6N-8413	Housing - Pump	325-6110
6P-7704	Carrier - Ring	314-8658
6S-3759	Pin As	241-2543
7C-4297	Seal As - Camshaft	325-6192
7G-2480	Gear - Planet	226-6091
7G-2481	Gear - Planet	226-6092
7G-2485	Gear - Planet	226-7983
7G-2830	Ring - Seal	295-6441
7J-9682	Bearing - Sleeve	360-2335
7J-9842	Bearing - Sleeve	299-1968
7K-7176	Pin	241-2570
7K-7195	Bearing - Sleeve	325-6025
7K-9343	Pin	241-2571
7K-9344	Pin	241-2607
7K-9345	Pin	241-2608
7K-9601	Bearing - Sleeve	360-2338
7K-9602	Bearing - Sleeve	360-2339
7K-9604	Bearing - Sleeve	308-9829
7M-2167	Ring - Governor Control	308-9919
7M-4603	Body - Fuel Valve	311-9348
7N-0128	Core As - Oil Cooler	299-1994
7N-0165	Core As - Oil Cooler	295-5670
7N-1164	Mount As	295-5451
7N-2871	Line As - Fuel Injector	319-8172
7N-2872	Line As - Fuel Injector	319-8173
7N-2874	Line As - Fuel Injector	298-2779
7N-2949	Pulley	264-5887
7N-2957	Cover - Rad Cap	361-1722
7N-3515	Gear - Camshaft	314-8669
7N-3536	Gear - Fuel	279-4993
7N-5910	Impeller - Pump	314-8686
7N-9145	Gear - Flywheel	279-4994
7N-9805	Pin - Piston	295-6438
7S-3161	Lifter - Valve	279-4996
7S-6723	Bracket - Alternator	299-1978
7S-7070	Head As - Cylinder	325-6107
7S-7809	Cap As - Radiator	295-6417
7S-8443	Muffler	247-2675
7S-9749	Pulley - Gen Drive	264-5888
7T-2036	Cap As - Filter	361-1721
7W-0450	Gear - Water Pump	279-4997
7W-0507	Gear - Oil Pump Drive	279-4998
7W-0508	Gear - Fuel Pump Drive	296-1351
7W-5687	Hub - Camshaft	314-8684
7Y-1517	Pipe As - Tail	301-5246
8H-2810	Case As - Filter	314-8512
8H-9806	Gear - Shaft Drive	325-6091
8K-5991	Gear - Diff Bevel	253-1439
8K-5999	Gear - Sun	253-1440
8M-0874	Plunger As - Valve	311-9439
8N-0002	Trunnion As	314-8728
8N-0875	Valve - Exhaust	247-6893 (Valve), 241-3381 (Valve Kit)
8N-1187	Head Gp - Cylinder	242-3435
8N-1188	Head Gp - Cylinder	242-3436
8N-1721	Rod As - Conn	269-5291
8N-1965	Tube - Disposal	325-6235
8N-1984	Rod As - Conn	242-3441
8N-2510	Shaft	325-6208
8N-2641	Sleeve	325-6210
8N-3180	Body As - Piston	250-6563
8N-3181	Piston Gp - Basic	250-6555 (Liner Kit)
8N-3182	Body As - Piston	250-6564 (Piston As), 250-6556 (Liner Kits)

(Continued)

Sales Model 930 (Continued)

Original Part Number	Part Name	Classic Part Number
8N-3183	Piston Gp - Basic	250-6556 (Liner Kit)
8N-3251	Shaft As - Rocker Arm	314-8711
8N-3311	Shaft As - Rocker Arm	325-6199
8N-3312	Shaft As - Rocker Arm	325-6200
8N-3325	Arm Gp - Rocker	314-8623
8N-3327	Arm Gp - Rocker	314-8624
8N-5305	Spacer	363-7464

Original Part Number	Part Name	Classic Part Number
8N-5929	Cover - Water Pump	296-1349
8N-6796	Head Gp - Cylinder	269-5290
8N-7315	Tube As - Outlet	325-6232
8N-7780	Shield - Oil	314-8544
8N-8225	Bearing - Main	314-8652
8N-9733	Line As - Fuel Injector	319-8174
8S-0248	Breather As	325-6033
8S-0493	Shaft As - Pump	325-6198

Original Part Number	Part Name	Classic Part Number
8S-0905	Muffler As	302-2690
8S-3970	Chamber As	242-3438
9H-2256	Pump Gp	311-9443
9M-4789	Shaft - Gov Control	297-7256
9N-5769	Cover - Housing	325-6050
9S-2356	Manifold - Exhaust	261-0905
9S-6129	Pulley - Alternator Drive	264-5891
9S-8679	Chamber As	325-6042
9Y-2992	Bearing - Sleeve	325-6032

Sales Model 950

Original Part Number	Part Name	Classic Part Number
100-7860	Valve - Inlet	270-4360 (Valve), 270-4362 (Valve Kit)
111-8015	Gasket As - Head	279-4977
121-7746	Precleaner As	360-2311
131-3815	Seal Gp - Basic	325-6193
148-7455	Valve - Exhaust	270-4361
165-4262	Body As - Piston	270-4351
170-0560	Rebuild Kit	363-7458
172-5185	Shaft - Water Pump	325-6201
172-5188	Shaft - Water Pump	325-6202
172-5189	Impeller - Pump	295-5687
172-5190	Impeller - Pump	325-6111
172-6712	Impeller - Pump	325-6112
172-7767	Pump Gp - Water	296-1365
196-0028	Gear As - Idler	364-5259
1A-2846	Cap As - Filler	311-9368
1M-7250	Bowl - Precleaner	360-2296
1N-3576	Block Gp - Cylinder	279-4978
1N-3958	Elbow	325-6087

Original Part Number	Part Name	Classic Part Number
1N-4304	Head Gp - Cylinder	269-8761
1P-0320	Retainer - Bearing	226-5987
1P-1216	Manifold - Exhaust	261-0902
1P-1721	Gear - Balance	298-2769
1P-1722	Gear - Balance	298-2770
1P-5262	Cage - Bearing	226-5989
1P-5480	Cover As - End	299-1998
1P-9945	Bracket As - Fan	296-1344
1P-9946	Shaft - Fan	325-6194
1P-9952	Impeller - Pump	314-8685
1S-1888	Bracket - Lamp	297-7147
1S-4701	Pulley - Alt	264-5866
1T-0020	Wheel - Turbine	297-4862
1T-1428	Retainer - Bearing	300-2587
1T-1987	Housing - Rotating	297-4864
1V-1080	Housing - Bearing Spt	260-0775
1V-1687	Wheel	226-5990
1V-2281	Carrier - Planet	226-5984
1V-2992	Gear - Diff Bevel	224-1301

Original Part Number	Part Name	Classic Part Number
1V-3995	Pin	319-3449
1V-5724	Diff Gp	260-0776
1V-8655	Lever As	226-5991
1V-9208	Link As - Rear	299-2020
1W-1219	Trunnion As	314-8724
1W-1766	Muffler As	298-2783
1W-2870	Shaft As - Balance	314-8715
1W-2871	Shaft As - Balance	314-8716
1W-4402	Gear - Camshaft	279-4981
1W-4405	Gear - Crankshaft	279-4982
244-1090	Alarm - Back up	360-2345
2F-5721	Bearing - Ball	311-9354
2J-1506	Pin	319-3451
2K-0535	Nut	299-2026
2K-0714	Plate - Thrust	299-2040
2K-3592	Boss	314-8501
2K-4502	Bearing - Sleeve	299-1986
2K-4507	Bearing - Sleeve	325-6021
2K-4513	Bearing - Sleeve	308-9814
2K-5073	Bushing	299-1989
2K-5977	Yoke	226-5992
2K-6000	Shaft - Planet	221-9106
2K-6001	Shaft - Planet	221-9107
2K-6413	Pin	360-2270
2K-8753	Gear - Diff	253-1432

(Continued)

Sales Model 950 (Continued)

Original Part Number	Part Name	Classic Part Number
2K-8754	Gear - Diff Bevel	253-1433
2P-1170	Shaft As - Gear	296-1367
2P-1738	Plate As - Oil Pan	325-6164
2P-1739	Tube As - Pump	325-6229
2P-1757	Hub - Fan Pulley	296-1357
2P-1781	Spacer - Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2519	Tube As - Inlet	325-6230
2P-2719	Pipe	363-7454
2P-2744	Muffler As	247-2664
2P-6245	Shaft As - Pump	325-6197
2P-7828	Pan - Oil	314-8691
2S-4015	Plunger As - Valve	311-9438
2V-1074	Shaft - Planet	364-5262
2V-5881	Gear - Bevel Ring	253-1434
2V-6220	Shaft - Planet	221-9073
2W-1086	Cover As - Cylinder Head	325-6049
2W-2621	Valve - Inlet	247-6892 (Valve), 241-3381 (Valve Kit)
2W-7255	Shaft - Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear - Water Pump	325-6088
3H-3378	Gear As - Pump	298-2795
3K-0963	Pin - Lock	308-9895
3K-2498	Shaft - Planet	216-7824
3K-5461	Wheel - Steering	308-9945
3K-7020	Gear - Planet	221-9074
3K-7021	Gear - Ring	221-9075
3K-7110	Gear - Planet	253-1435
3K-7111	Gear - Sun	253-1436
3K-7112	Gear - Ring	253-1437
3L-1425	Bearing - Ball	311-9356
3P-5672	Yoke	223-6313
3S-1167	Gear - Planet	221-9101
3S-2616	Pump Gp - Transmission	226-0165
3V-7427	Housing As	297-7197
4F-4974	Clamp	311-9373
4J-3015	Shaft	325-6204
4K-3004	Bearing - Trunnion Support	314-8632
4K-3128	Bearing - Sleeve	314-8633
4K-5109	Gear - Reverse	219-9659
4K-6212	Shaft - Bevel Pinion	223-4806
4K-7251	Cover	299-2003
4K-7269	Support	299-2067
4K-7420	Retainer	297-7234
4K-8416	Shaft	308-9927
4K-9598	Retainer	297-7235
4N-2954	Sleeve - Camshaft	299-2059
4N-3281	Line As - Fuel Injector	247-3362
4N-3282	Line As - Fuel Injector	247-3363
4N-3283	Line As - Fuel Injector	247-3364
4N-3284	Line As - Fuel Injector	247-3365
4N-7692	Crankshaft As	242-3440
4N-7693	Crankshaft As	242-3439
4N-7977	Shaft As - Balance	314-8709
4N-7978	Shaft As - Balance	314-8710
4N-8814	Line As - Fuel Injector	247-3366
4N-9587	Shield - Heat	297-7260
4P-0660	Muffler As	298-2787
4P-3546	Valve As - Relief	325-6236
4S-5943	Piston - Clutch	221-9112
4S-5944	Gear - Sun	221-9078
4S-5945	Gear - Sun	221-9079
4S-5947	Gear - Ring	221-9080
4S-5948	Gear - Ring	221-9082
4S-5981	Gear - Ring	221-9084
4S-8530	Shaft - Planet	221-9111
4S-8534	Shaft As - Planet	221-9116
4V-0015	Plate - Lock	282-6563
4V-0381	Bearing - Sleeve	299-1963
4V-5454	Link	299-2025
4W-0452	Seal As - Camshaft	325-6191
5D-0470	Valve Gp	314-8549
5F-6393	Shaft	308-9928
5G-3612	Cap Gp	295-6419
5K-0609	Cover	308-9843
5K-0871	Pin - Lower	282-6630
5K-0989	Cap - Upper	297-7158
5K-0990	Pin	299-2035
5K-0991	Cap - Lower	319-3433
5K-1068	Retainer - Seal	260-0786
5K-2570	Spacer	226-5996
5K-5933	Cover As	247-4125
5K-7995	Bearing - Sleeve	308-9820
5P-7807	Bearing - Ball	314-8502
5S-1211	Cover - Valve	314-8665
5S-1822	Chamber As	248-5406
5S-1833	Chamber As	247-3298
5S-4493	Carrier - Planet	223-6321
5S-4557	Bearing	311-9360
5S-6795	Chamber As	242-3437
5S-6972	Gear - Sun	221-9087
5S-6978	Shaft - Planet	221-9103
5S-7009	Plate As - End	226-4957
5S-7010	Shaft - Planet	221-9104
5S-7013	Gear - Ring	221-9088
5S-7023	Carrier - Planet	226-5986
5S-7609	Pulley - Alt Drive	264-5881
5S-7888	Retainer - Bearing	226-5988
5S-8038	Pulley - Crankshaft	264-5882
5S-9062	Spacer	363-7463
5S-9080	Pulley - Alt Drive	264-5883
5V-5661	Bearing - Sleeve	299-1965
6H-3957	Bearing - Ball	311-9358
6I-1346	Pump Gp - Oil	295-5674
6K-0053	Housing	297-7191
6K-2034	Shaft	297-7249
6K-2036	Rack	299-2045

(Continued)

Sales Model 950 (Continued)

Original Part Number	Part Name	Classic Part Number
6K-2085	Shaft - Bevel Pinion	221-9102
6K-3937	Pin	241-2557
6K-4600	Yoke	226-5993
6K-5513	Pin	241-2558
6K-7161	Pin	241-2559
6K-7162	Pin	241-2560
6K-7164	Pin	241-2561
6K-7165	Pin	241-2562
6K-7166	Pin - Arm Pivot	241-2563
6K-7167	Pin	241-2569
6K-7287	Pin	241-2564
6K-9841	Cam & Lever As	226-5997
6L-8968	Coupling - Exhaust	311-9381
6N-1036	Gear - Oil Pump	279-4991
6N-1553	Coupling - Exhaust	295-6422
6N-1965	Line As - Fuel Injector	250-7535
6N-1966	Line As - Fuel Injector	250-7536
6N-2789	Pulley	264-5886
6N-8413	Housing - Pump	325-6110
6S-3759	Pin As	241-2543
7B-0503	Ballstud	308-9801
7B-2420	Ferrule - Director	314-8517
7C-4297	Seal As - Camshaft	325-6192
7G-2477	Gear - Planet	221-9090
7G-2485	Gear - Planet	226-7983
7G-2487	Gear - Planet	221-9092
7G-2520	Gear - Planet	221-9094
7G-3454	Gear - Planet	300-2578
7J-6461	Crown	325-6054
7J-9344	Bearing - Sleeve	360-2334
7J-9682	Bearing - Sleeve	360-2335
7J-9884	Bearing - Sleeve	325-6016
7K-0686	Trunnion - Rear	297-7266
7K-1818	Cover	308-9844
7K-6260	Shaft - Sector	308-9931
7K-7176	Pin	241-2570
7K-7195	Bearing - Sleeve	325-6025
7K-9343	Pin	241-2571
7K-9361	Pin	241-2565
7M-2167	Ring - Governor Control	308-9919
7M-4358	Manifold - Exhaust	261-0907
7M-4603	Body - Fuel Valve	311-9348
7M-7358	Valve - Inlet	298-2774
7N-0128	Core As - Oil Cooler	299-1994
7N-0165	Core As - Oil Cooler	295-5670
7N-1164	Mount As	295-5451
7N-2871	Line As - Fuel Injector	319-8172
7N-2872	Line As - Fuel Injector	319-8173
7N-2874	Line As - Fuel Injector	298-2779
7N-2875	Line As - Fuel Injector	298-2780
7N-2876	Line As - Fuel Injector	298-2781
7N-2949	Pulley	264-5887
7N-2957	Cover - Rad Cap	361-1722
7N-3515	Gear - Camshaft	314-8669
7N-3536	Gear - Fuel	279-4993
7N-5910	Impeller - Pump	314-8686
7N-8117	Muffler As	247-2668
7N-9145	Gear - Flywheel	279-4994
7N-9312	Damper As - Camshaft	299-2005
7N-9805	Pin - Piston	295-6438
7S-2980	Plate - Reaction	226-5998
7S-3033	Hub - Clutch	226-5985
7S-3161	Lifter - Valve	279-4996
7S-4494	Piston - Clutch	226-5999
7S-4629	Pump Gp - Transfer	226-0158
7S-6723	Bracket - Alternator	299-1978
7S-7070	Head As - Cylinder	325-6107
7S-7809	Cap As - Radiator	295-6417
7S-8443	Muffler	247-2675
7S-8572	Gear - Ring	221-9095
7S-9749	Pulley - Gen Drive	264-5888
7T-2036	Cap As - Filter	361-1721
7W-0450	Gear - Water Pump	279-4997
7W-0507	Gear - Oil Pump Drive	279-4998
7W-0508	Gear - Fuel Pump Drive	296-1351
7W-5687	Hub - Camshaft	314-8684
8H-2810	Case As - Filter	314-8512
8H-9806	Gear - Shaft Drive	325-6091
8K-5283	Plate	299-2043
8K-5757	Bearing - Sleeve	367-6076
8K-5758	Pin	241-2566
8K-6015	Gear - Bevel Ring	221-9076
8K-6283	Gear - Sun	221-9077
8M-3224	Muffler	247-2676
8N-0002	Trunnion As	314-8728
8N-0875	Valve - Exhaust	247-6893 (Valve), 241-3381 (Valve Kit)
8N-1187	Head Gp - Cylinder	242-3435
8N-1188	Head Gp - Cylinder	242-3436
8N-1721	Rod As - Conn	269-5291
8N-1984	Rod As - Conn	242-3441
8N-3180	Body As - Piston	250-6563
8N-3181	Piston Gp - Basic	250-6555 (Liner Kit)
8N-3182	Body As - Piston	250-6564 (Piston As), 250-6556 (Liner Kits)
8N-3183	Piston Gp - Basic	250-6556 (Liner Kit)
8N-3251	Shaft As - Rocker Arm	314-8711

(Continued)

Sales Model 950 (Continued)

Original Part Number	Part Name	Classic Part Number
8N-3311	Shaft As - Rocker Arm	325-6199
8N-3312	Shaft As - Rocker Arm	325-6200
8N-3325	Arm Gp - Rocker	314-8623
8N-3327	Arm Gp - Rocker	314-8624
8N-5305	Spacer	363-7464
8N-5929	Cover - Water Pump	296-1349
8N-6796	Head Gp - Cylinder	269-5290
8N-7315	Tube As - Outlet	325-6232
8N-7780	Shield - Oil	314-8544
8N-8225	Bearing - Main	314-8652

Original Part Number	Part Name	Classic Part Number
8N-9733	Line As - Fuel Injector	319-8174
8P-1656	Plate - Clutch	367-6071
8P-1918	Gear - Planet	283-5210
8S-0248	Breather As	325-6033
8S-0493	Shaft As - Pump	325-6198
8S-0556	Coupling	221-9114
8S-2809	Muffler	247-2677
8S-3970	Chamber As	242-3438
8V-3134	Pinion - Bevel	260-0788
8V-3135	Gear - Differential Bevel	260-0783
8V-3136	Gear - Differential Bevel	253-1442
8V-7175	Pin	241-2567
8V-7176	Pin	241-2568

Original Part Number	Part Name	Classic Part Number
9C-4811	Hub As	224-1300
9H-2256	Pump Gp	311-9443
9K-3413	Gear - Bevel Ring	223-4807
9M-4163	Valve - Exhaust	298-2773
9M-4789	Shaft - Gov Control	297-7256
9N-5769	Cover - Housing	325-6050
9P-6888	Shaft - Output	221-9105
9S-2355	Manifold - Exhaust	261-0891
9S-6129	Pulley - Alternator Drive	264-5891
9S-8679	Chamber As	325-6042
9Y-2992	Bearing - Sleeve	325-6032

Sales Model 950B

Original Part Number	Part Name	Classic Part Number
100-7860	Valve - Inlet	270-4360 (Valve), 270-4362 (Valve Kit)
104-4253	Line As - Fuel Injector	279-4988
104-4254	Line As - Fuel Injector	279-4989
111-8015	Gasket As - Head	279-4977
114-9036	Shaft - Input	297-4859
115-0637	Pump Gp	226-0160
121-7746	Precleaner As	360-2311
122-9405	Bracket As	325-6005
127-5537	Core As	325-6045
131-3815	Seal Gp - Basic	325-6193
148-7455	Valve - Exhaust	270-4361
165-4262	Body As - Piston	270-4351
167-8123	Damper As	299-2006
172-5185	Shaft - Water Pump	325-6201
172-5188	Shaft - Water Pump	325-6202
172-5189	Impeller - Pump	295-5687
172-5190	Impeller - Pump	325-6111

Original Part Number	Part Name	Classic Part Number
172-6712	Impeller - Pump	325-6112
172-7767	Pump Gp - Water	296-1365
176-9273	Piston	297-4860
186-4440	Shaft - Planet	364-5261
196-0028	Gear As - Idler	364-5259
1M-7250	Bowl - Precleaner	360-2296
1N-2936	Muffler As	298-2782
1N-2946	Extension - Exh	367-6064
1N-3576	Block Gp - Cylinder	279-4978
1N-3958	Elbow	325-6087
1N-4304	Head Gp - Cylinder	269-8761
1P-1216	Manifold - Exhaust	261-0902
1P-1721	Gear - Balance	298-2769
1P-1722	Gear - Balance	298-2770
1P-5480	Cover As - End	299-1998
1P-7590	Support As	213-4400
1P-9945	Bracket As - Fan	296-1344
1P-9946	Shaft - Fan	325-6194

Original Part Number	Part Name	Classic Part Number
1S-1888	Bracket - Lamp	297-7147
1S-4701	Pulley - Alt	264-5866
1T-0020	Wheel - Turbine	297-4862
1T-1331	Stator - Converter	229-8237
1T-1428	Retainer - Bearing	300-2587
1T-1691	Impeller - Converter	297-4863
1T-1987	Housing - Rotating	297-4864
1V-3995	Pin	319-3449
1V-6342	Gear As	308-9847
1W-1669	Piston	325-6158
1W-1695	Pump Gp	279-4980
1W-1698	Housing - Transfer Pump	296-1356
1W-2870	Shaft As - Balance	314-8715
1W-2871	Shaft As - Balance	314-8716
1W-4369	Pulley - Alt	296-1340
1W-4402	Gear - Camshaft	279-4981
1W-4405	Gear - Crankshaft	279-4982

(Continued)

Sales Model 950B (Continued)

Original Part Number	Part Name	Classic Part Number
1W-4407	Hub - Fan Pulley	296-1358
1W-5912	Tappet As - Guide	325-6223
1W-6541	Plunger As	325-6173
244-1090	Alarm - Back up	360-2345
2F-5721	Bearing - Ball	311-9354
2K-0535	Nut	299-2026
2K-0714	Plate - Thrust	299-2040
2P-1170	Shaft As - Gear	296-1367
2P-1738	Plate As - Oil Pan	325-6164
2P-1739	Tube As - Pump	325-6229
2P-1757	Hub - Fan Pulley	296-1357
2P-1781	Spacer - Oil Pump	325-6214
2P-2519	Tube As - Inlet	325-6230
2P-6245	Shaft As - Pump	325-6197
2P-7828	Pan - Oil	314-8691
2S-7064	Cap - Shaft Bearing	299-1991
2V-5697	Cover As	299-1999
2V-5714	Gear - Ring	288-8716
2V-5715	Bushing	299-1987
2V-5722	Carrier - Planet	297-7164
2W-1086	Cover As - Cylinder Head	325-6049
2W-2621	Valve - Inlet	247-6892 (Valve), 241-3381 (Valve Kit)
2W-6030	Tube	314-8729
2W-6757	Trunnion As	295-5678
2W-7255	Shaft - Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear - Water Pump	325-6088
2W-8494	Pulley - Alt	295-5692
3G-8917	Pin	325-6141
3G-8932	Pin	325-6143
3L-1425	Bearing - Ball	311-9356
3P-3935	Shaft	299-2053
3P-8283	Spacer	325-6215
3T-3447	Gear As - Sun	302-2676
3T-4223	Gear - Transfer	319-3438
3T-4224	Gear - Transfer	297-7175
3T-6795	Piston - Clutch	281-1693
3T-9496	Plate - Retainer	299-2042
3V-2337	Pin As	319-3440
3V-8777	Gear - Spiral	297-7176
4E-3196	Pin As	361-1697
4E-3456	Lever As	367-6081
4E-5213	Cover As	299-2000
4E-8534	Retainer - Seal	300-2588
4F-4974	Clamp	311-9373
4J-6167	Bearing - Sleeve	325-6009
4K-6810	Retainer - Seal	300-2586
4K-7269	Support	299-2067
4N-4864	Pump Gp - Fuel Transfer	242-3442
4N-7692	Crankshaft As	242-3440
4N-7693	Crankshaft As	242-3439
4N-7977	Shaft As - Balance	314-8709
4N-7978	Shaft As - Balance	314-8710
4P-3546	Valve As - Relief	325-6236
4P-9381	Line As - Fuel Injector	279-4984
4P-9382	Line As - Fuel Injector	279-4985
4P-9385	Line As - Fuel Injector	279-4986
4P-9386	Line As - Fuel Injector	279-4987
4P-9961	Line As - Fuel Injector	325-6115
4P-9962	Line As - Fuel Injector	325-6116
4P-9963	Line As - Fuel Injector	298-2777
4P-9964	Line As - Fuel Injector	298-2778
4V-0015	Plate - Lock	282-6563
4V-2518	Shaft	297-7243
4V-3680	Bellcrank	308-9802
4V-5100	Support - Trunnion	299-2068
4V-5213	Spindle	299-2060
4V-6430	Bracket As	299-1974
4V-7105	Pin As	361-1699
4V-7543	Retainer	281-1699
4V-8534	Shaft - Planet	281-1700
4V-8538	Gear - Ring	288-8720
4V-8674	Bearing - Bushing	307-1529
4V-8687	Boss	299-1971
4V-8690	Boss	299-1972
4W-0452	Seal As - Camshaft	325-6191
4W-2446	Damper As	279-4990
5D-0470	Valve Gp	314-8549
5G-3612	Cap Gp	295-6419
5J-4321	Trunnion	302-2700
5K-0871	Pin - Lower	282-6630
5K-0989	Cap - Upper	297-7158
5K-0991	Cap - Lower	319-3433
5P-7807	Bearing - Ball	314-8502
5S-1211	Cover - Valve	314-8665
5S-4557	Bearing	311-9360
5S-6795	Chamber As	242-3437
5S-9080	Pulley - Alt Drive	264-5883
5V-1271	Diff Gp	299-2008
5V-1508	Pin As	361-1703
5V-1509	Pin As	319-3443
5V-1510	Pin As	252-6876
5V-1882	Pin As	361-1700
5V-5917	Pinion - Diff Bevel	297-7224
5V-8782	Lever As	299-2014
6H-3957	Bearing - Ball	311-9358
6I-1346	Pump Gp - Oil	295-5674
6I-9034	Guard As	295-6435
6J-9258	Trunnion As	256-4846
6K-8897	Bracket As	299-1977
6N-1036	Gear - Oil Pump	279-4991
6N-8413	Housing - Pump	325-6110
6P-2233	Gear - Planet	281-1690
6P-7742	Shaft - Planet	281-1695
6P-7743	Shaft - Planet	281-1696
6P-8003	Gear - Planet	281-1689
6P-8005	Gear - Planet	281-1691
6T-0830	Housing As	297-7199
6T-3009	Piston - Clutch	297-7226

(Continued)

Sales Model 950B (Continued)

Original Part Number	Part Name	Classic Part Number
6T-6987	Piston - Clutch	297-7227
6W-1629	Shaft - Bevel Pinion	297-7250
6Y-7877	Housing As	297-7200
7C-5851	Muffler As	298-2790
7G-3707	Piston - Clutch	302-2691
7G-3708	Piston - Clutch	300-2585
7G-4281	Housing As - Support	297-7201
7G-4302	Housing - Clutch	302-2708
7G-4306	Plate - Center	297-7229
7G-5444	Carrier - Planet	297-7165
7G-5572	Gear - Sun	300-2580
7G-5589	Gear - Ring	281-1692
7G-5593	Gear - Sun	300-2581
7G-5614	Shaft - Planet	281-1697
7G-6060	Plate - Center	302-2694
7G-6062	Gear - Ring	302-2678
7G-9721	Gear As - Oil Pump	297-7178
7G-9722	Gear - Pump Drive	297-7179
7J-1333	Bearing - Sleeve	295-6408
7J-1334	Bearing - Sleeve	325-6015
7J-4827	Yoke	299-2070
7J-6461	Crown	325-6054
7J-9884	Bearing - Sleeve	325-6016
7K-0686	Trunnion - Rear	297-7266
7K-9528	Bearing - Sleeve	308-9828
7N-0165	Core As - Oil Cooler	295-5670
7N-1164	Mount As	295-5451
7N-3515	Gear - Camshaft	314-8669
7N-3536	Gear - Fuel	279-4993
7N-5910	Impeller - Pump	314-8686
7N-9145	Gear - Flywheel	279-4994
7N-9312	Damper As - Camshaft	299-2005
7N-9805	Pin - Piston	295-6438
7S-3161	Lifter - Valve	279-4996
7S-7809	Cap As - Radiator	295-6417
7T-0119	Support As	299-2066
7T-1285	Gear - Planet	297-7190
7T-2036	Cap As - Filter	361-1721
7T-3343	Plate - Clutch	297-7231
7W-0450	Gear - Water Pump	279-4997
7W-0507	Gear - Oil Pump Drive	279-4998
7W-0508	Gear - Fuel Pump Drive	296-1351
7W-5684	Pulley - Camshaft	298-2771
7W-5685	Pulley - Camshaft	298-2772
7W-5698	Pulley - Camshaft	295-5679
8D-2628	Nut	299-2027
8E-6221	Pin	325-6155
8H-2810	Case As - Filter	314-8512
8H-9806	Gear - Shaft Drive	325-6091
8J-2880	Cap - Bearing	295-6420
8K-6282	Gear - Sun	281-1698
8K-6285	Shaft - Axle	299-2057
8M-0874	Plunger As - Valve	311-9439
8N-0875	Valve - Exhaust	247-6893 (Valve), 241-3381 (Valve Kit)
8N-1187	Head Gp - Cylinder	242-3435
8N-1188	Head Gp - Cylinder	242-3436
8N-1721	Rod As - Conn	269-5291
8N-1965	Tube - Disposal	325-6235
8N-2510	Shaft	325-6208
8N-2641	Sleeve	325-6210
8N-3251	Shaft As - Rocker Arm	314-8711
8N-3312	Shaft As - Rocker Arm	325-6200
8N-3325	Arm Gp - Rocker	314-8623
8N-3327	Arm Gp - Rocker	314-8624
8N-5388	Muffler As	360-7895
8N-5929	Cover - Water Pump	296-1349
8N-6796	Head Gp - Cylinder	269-5290
8N-7315	Tube As - Outlet	325-6232
8N-8225	Bearing - Main	314-8652
8N-9402	Coupling	325-6048
8S-0248	Breather As	325-6033
8S-0493	Shaft As - Pump	325-6198
8S-3970	Chamber As	242-3438
8V-1613	Lever	299-2017
8V-1624	Lever	299-2019
8V-3134	Pinion - Bevel	260-0788
8V-3135	Gear - Differential Bevel	260-0783
8V-3136	Gear - Differential Bevel	253-1442
8V-7659	Pin As	361-1702
9C-1528	Gear - Planet	223-4802
9C-5852	Hub As	297-7208
9C-8204	Shaft - Bevel Pinion	319-3474
9C-8205	Gear - Bevel	319-8175
9C-9191	Trunnion	302-2701
9C-9773	Gear - Differential Bevel	302-2672
9G-1231	Plate	297-7232
9G-1491	Carrier - Planet	281-1685
9G-7411	Gear - Oil Pump Drive	297-7182
9G-7412	Gear As - Oil Pump	297-7183
9G-8117	Housing As	302-2686
9G-9764	Yoke As	319-3478
9J-7964	Bearing - Spherical	325-6017
9K-8757	Rod End - Bearing	311-9361
9L-6371	Rod	363-7459
9M-1328	Bearing - Aligning	325-6018
9M-4789	Shaft - Gov Control	297-7256
9N-4460	Housing As	297-7203
9N-5251	Piston Gp - Basic	250-6557 (Liner Kit)

(Continued)

Sales Model 950B (Continued)

Original Part Number	Part Name	Classic Part Number
9N-5769	Cover - Housing	325-6050
9N-6611	Pulley	325-6177
9S-2354	Manifold - Exhaust	261-0888
9S-2355	Manifold - Exhaust	261-0891
9S-8679	Chamber As	325-6042

Original Part Number	Part Name	Classic Part Number
9U-3124	Gear - Planet	288-8806
9U-3125	Gear - Sun	288-8807
9V-2410	Housing - Bearing	302-2679
9V-2411	Housing - Bearing	302-2680
9V-3853	Pin	319-3469
9V-6523	Cap	297-7162

Original Part Number	Part Name	Classic Part Number
9V-6524	Cap	297-7163
9W-0517	Carrier - Planet	281-1686
9W-4949	Carrier - Planet	281-1687
9W-4950	Gear - Sun	281-1688
9Y-2992	Bearing - Sleeve	325-6032

Sales Model 950E

Original Part Number	Part Name	Classic Part Number
100-7860	Valve - Inlet	270-4360 (Valve), 270-4362 (Valve Kit)
104-4253	Line As - Fuel Injector	279-4988
104-4254	Line As - Fuel Injector	279-4989
111-8015	Gasket As - Head	279-4977
114-9036	Shaft - Input	297-4859
115-0637	Pump Gp	226-0160
121-7746	Precleaner As	360-2311
122-9405	Bracket As	325-6005
127-5537	Core As	325-6045
131-3815	Seal Gp - Basic	325-6193
148-7455	Valve - Exhaust	270-4361
167-8123	Damper As	299-2006
170-0560	Rebuild Kit	363-7458
172-5185	Shaft - Water Pump	325-6201
172-5188	Shaft - Water Pump	325-6202
172-5189	Impeller - Pump	295-5687
172-5190	Impeller - Pump	325-6111
172-6712	Impeller - Pump	325-6112
172-7767	Pump Gp - Water	296-1365
176-9273	Piston	297-4860
186-4440	Shaft - Planet	364-5261
196-0028	Gear As - Idler	364-5259
1M-7250	Bowl - Precleaner	360-2296

Original Part Number	Part Name	Classic Part Number
1N-2936	Muffler As	298-2782
1N-2946	Extension - Exh	367-6064
1N-3576	Block Gp - Cylinder	279-4978
1N-3958	Elbow	325-6087
1N-4304	Head Gp - Cylinder	269-8761
1P-1216	Manifold - Exhaust	261-0902
1P-1721	Gear - Balance	298-2769
1P-1722	Gear - Balance	298-2770
1P-5480	Cover As - End	299-1998
1P-7590	Support As	213-4400
1P-9945	Bracket As - Fan	296-1344
1P-9946	Shaft - Fan	325-6194
1P-9989	Pipe	363-7453
1S-1888	Bracket - Lamp	297-7147
1S-4701	Pulley - Alt	264-5866
1T-0020	Wheel - Turbine	297-4862
1T-1331	Stator - Converter	229-8237
1T-1428	Retainer - Bearing	300-2587
1T-1691	Impeller - Converter	297-4863
1T-1987	Housing - Rotating	297-4864
1V-3995	Pin	319-3449
1V-6342	Gear As	308-9847
1W-1669	Piston	325-6158
1W-1695	Pump Gp	279-4980

Original Part Number	Part Name	Classic Part Number
1W-1698	Housing - Transfer Pump	296-1356
1W-2870	Shaft As - Balance	314-8715
1W-2871	Shaft As - Balance	314-8716
1W-4369	Pulley - Alt	296-1340
1W-4402	Gear - Camshaft	279-4981
1W-4405	Gear - Crankshaft	279-4982
1W-4407	Hub - Fan Pulley	296-1358
1W-5912	Tappet As - Guide	325-6223
1W-6541	Plunger As	325-6173
244-1090	Alarm - Back up	360-2345
2F-5721	Bearing - Ball	311-9354
2K-0535	Nut	299-2026
2K-0714	Plate - Thrust	299-2040
2P-1170	Shaft As - Gear	296-1367
2P-1738	Plate As - Oil Pan	325-6164
2P-1739	Tube As - Pump	325-6229
2P-1757	Hub - Fan Pulley	296-1357
2P-1781	Spacer - Oil Pump	325-6214
2P-2519	Tube As - Inlet	325-6230
2P-2719	Pipe	363-7454
2P-6245	Shaft As - Pump	325-6197
2P-7828	Pan - Oil	314-8691
2S-7064	Cap - Shaft Bearing	299-1991

(Continued)

Sales Model 950E (Continued)

Original Part Number	Part Name	Classic Part Number
2V-5697	Cover As	299-1999
2V-5714	Gear - Ring	288-8716
2V-5715	Bushing	299-1987
2V-5722	Carrier - Planet	297-7164
2W-1086	Cover As - Cylinder Head	325-6049
2W-2621	Valve - Inlet	247-6892 (Valve), 241-3381 (Valve Kit)
2W-5540	Core, Radiator (Folded)	363-7452
2W-6030	Tube	314-8729
2W-6757	Trunnion As	295-5678
2W-7255	Shaft - Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear - Water Pump	325-6088
2W-8494	Pulley - Alt	295-5692
3G-8917	Pin	325-6141
3G-8932	Pin	325-6143
3L-1425	Bearing - Ball	311-9356
3P-3935	Shaft	299-2053
3P-8283	Spacer	325-6215
3T-3447	Gear As - Sun	302-2676
3T-4223	Gear - Transfer	319-3438
3T-4224	Gear - Transfer	297-7175
3T-6795	Piston - Clutch	281-1693
3T-9496	Plate - Retainer	299-2042
3V-2337	Pin As	319-3440
3V-8777	Gear - Spiral	297-7176
4E-3196	Pin As	361-1697
4E-3456	Lever As	367-6081
4E-5213	Cover As	299-2000
4E-8534	Retainer - Seal	300-2588
4F-4974	Clamp	311-9373
4J-6167	Bearing - Sleeve	325-6009
4K-6810	Retainer - Seal	300-2586
4K-7269	Support	299-2067
4N-4864	Pump Gp - Fuel Transfer	242-3442
4N-7692	Crankshaft As	242-3440
4N-7693	Crankshaft As	242-3439
4N-7977	Shaft As - Balance	314-8709
4N-7978	Shaft As - Balance	314-8710
4P-3546	Valve As - Relief	325-6236
4P-9381	Line As - Fuel Injector	279-4984
4P-9382	Line As - Fuel Injector	279-4985
4P-9385	Line As - Fuel Injector	279-4986
4P-9386	Line As - Fuel Injector	279-4987
4P-9961	Line As - Fuel Injector	325-6115
4P-9962	Line As - Fuel Injector	325-6116
4P-9963	Line As - Fuel Injector	298-2777
4P-9964	Line As - Fuel Injector	298-2778
4V-0015	Plate - Lock	282-6563
4V-2518	Shaft	297-7243
4V-3680	Bellcrank	308-9802
4V-5100	Support - Trunnion	299-2068
4V-5213	Spindle	299-2060
4V-6430	Bracket As	299-1974
4V-7105	Pin As	361-1699
4V-7543	Retainer	281-1699
4V-8534	Shaft - Planet	281-1700
4V-8538	Gear - Ring	288-8720
4V-8674	Bearing - Bushing	307-1529
4V-8687	Boss	299-1971
4V-8690	Boss	299-1972
4W-0452	Seal As - Camshaft	325-6191
4W-2446	Damper As	279-4990
5D-0470	Valve Gp	314-8549
5G-3612	Cap Gp	295-6419
5J-4321	Trunnion	302-2700
5K-0871	Pin - Lower	282-6630
5K-0989	Cap - Upper	297-7158
5K-0991	Cap - Lower	319-3433
5P-7807	Bearing - Ball	314-8502
5S-1211	Cover - Valve	314-8665
5S-4557	Bearing	311-9360
5S-6795	Chamber As	242-3437
5S-9062	Spacer	363-7463
5S-9080	Pulley - Alt Drive	264-5883
5V-1271	Diff Gp	299-2008
5V-1508	Pin As	361-1703
5V-1509	Pin As	319-3443
5V-1510	Pin As	252-6876
5V-1882	Pin As	361-1700
5V-5917	Pinion - Diff Bevel	297-7224
5V-8782	Lever As	299-2014
6H-3957	Bearing - Ball	311-9358
6I-1346	Pump Gp - Oil	295-5674
6I-9034	Guard As	295-6435
6J-9258	Trunnion As	256-4846
6K-8897	Bracket As	299-1977
6N-1036	Gear - Oil Pump	279-4991
6N-8413	Housing - Pump	325-6110
6P-2233	Gear - Planet	281-1690
6P-7742	Shaft - Planet	281-1695
6P-7743	Shaft - Planet	281-1696
6P-8003	Gear - Planet	281-1689
6P-8005	Gear - Planet	281-1691
6T-0830	Housing As	297-7199
6T-3009	Piston - Clutch	297-7226
6T-6987	Piston - Clutch	297-7227
6W-1629	Shaft - Bevel Pinion	297-7250
6Y-7877	Housing As	297-7200
7C-5851	Muffler As	298-2790
7G-3707	Piston - Clutch	302-2691
7G-3708	Piston - Clutch	300-2585
7G-4281	Housing As - Support	297-7201
7G-4302	Housing - Clutch	302-2708
7G-4306	Plate - Center	297-7229
7G-5444	Carrier - Planet	297-7165
7G-5572	Gear - Sun	300-2580
7G-5589	Gear - Ring	281-1692
7G-5593	Gear - Sun	300-2581
7G-5614	Shaft - Planet	281-1697
7G-6060	Plate - Center	302-2694
7G-6062	Gear - Ring	302-2678

(Continued)

Sales Model 950E (Continued)

Original Part Number	Part Name	Classic Part Number
7G-9721	Gear As - Oil Pump	297-7178
7G-9722	Gear - Pump Drive	297-7179
7J-1333	Bearing - Sleeve	295-6408
7J-1334	Bearing - Sleeve	325-6015
7J-4827	Yoke	299-2070
7J-6461	Crown	325-6054
7J-9884	Bearing - Sleeve	325-6016
7K-0686	Trunnion - Rear	297-7266
7K-9528	Bearing - Sleeve	308-9828
7N-0165	Core As - Oil Cooler	295-5670
7N-1164	Mount As	295-5451
7N-3515	Gear - Camshaft	314-8669
7N-3536	Gear - Fuel	279-4993
7N-5910	Impeller - Pump	314-8686
7N-9145	Gear - Flywheel	279-4994
7N-9312	Damper As - Camshaft	299-2005
7N-9805	Pin - Piston	295-6438
7S-3161	Lifter - Valve	279-4996
7S-7809	Cap As - Radiator	295-6417
7T-0119	Support As	299-2066
7T-1285	Gear - Planet	297-7190
7T-2036	Cap As - Filter	361-1721
7T-3343	Plate - Clutch	297-7231
7W-0450	Gear - Water Pump	279-4997
7W-0507	Gear - Oil Pump Drive	279-4998
7W-0508	Gear - Fuel Pump Drive	296-1351
7W-5684	Pulley - Camshaft	298-2771
7W-5685	Pulley - Camshaft	298-2772
7W-5698	Pulley - Camshaft	295-5679
8D-2628	Nut	299-2027
8E-6221	Pin	325-6155
8H-2810	Case As - Filter	314-8512
8H-9806	Gear - Shaft Drive	325-6091
8J-2880	Cap - Bearing	295-6420
8K-6282	Gear - Sun	281-1698
8K-6285	Shaft - Axle	299-2057
8M-0874	Plunger As - Valve	311-9439
8N-0875	Valve - Exhaust	247-6893 (Valve), 241-3381 (Valve Kit)
8N-1187	Head Gp - Cylinder	242-3435
8N-1188	Head Gp - Cylinder	242-3436
8N-1721	Rod As - Conn	269-5291
8N-1965	Tube - Disposal	325-6235
8N-2510	Shaft	325-6208
8N-2641	Sleeve	325-6210
8N-3251	Shaft As - Rocker Arm	314-8711
8N-3312	Shaft As - Rocker Arm	325-6200
8N-3325	Arm Gp - Rocker	314-8623
8N-3327	Arm Gp - Rocker	314-8624
8N-5305	Spacer	363-7464
8N-5388	Muffler As	360-7895
8N-5929	Cover - Water Pump	296-1349
8N-6796	Head Gp - Cylinder	269-5290
8N-7315	Tube As - Outlet	325-6232
8N-8225	Bearing - Main	314-8652
8N-9402	Coupling	325-6048
8S-0248	Breather As	325-6033
8S-0493	Shaft As - Pump	325-6198
8S-3970	Chamber As	242-3438
8V-1613	Lever	299-2017
8V-1624	Lever	299-2019
8V-3134	Pinion - Bevel	260-0788
8V-3135	Gear - Differential Bevel	260-0783
8V-3136	Gear - Differential Bevel	253-1442
8V-7659	Pin As	361-1702
9C-1528	Gear - Planet	223-4802
9C-5852	Hub As	297-7208
9C-8204	Shaft - Bevel Pinion	319-3474
9C-8205	Gear - Bevel	319-8175
9C-9191	Trunnion	302-2701
9C-9773	Gear - Differential Bevel	302-2672
9G-1231	Plate	297-7232
9G-1491	Carrier - Planet	281-1685
9G-7411	Gear - Oil Pump Drive	297-7182
9G-7412	Gear As - Oil Pump	297-7183
9G-8117	Housing As	302-2686
9G-9764	Yoke As	319-3478
9J-7964	Bearing - Spherical	325-6017
9K-8757	Rod End - Bearing	311-9361
9L-6371	Rod	363-7459
9M-1328	Bearing - Aligning	325-6018
9M-4789	Shaft - Gov Control	297-7256
9N-4460	Housing As	297-7203
9N-5251	Piston Gp - Basic	250-6557 (Liner Kit)
9N-5769	Cover - Housing	325-6050
9N-6611	Pulley	325-6177
9S-2354	Manifold - Exhaust	261-0888
9S-2355	Manifold - Exhaust	261-0891
9S-8679	Chamber As	325-6042
9U-3124	Gear - Planet	288-8806
9U-3125	Gear - Sun	288-8807
9V-2410	Housing - Bearing	302-2679
9V-2411	Housing - Bearing	302-2680
9V-3853	Pin	319-3469
9V-6523	Cap	297-7162
9V-6524	Cap	297-7163
9W-0517	Carrier - Planet	281-1686
9W-4949	Carrier - Planet	281-1687
9W-4950	Gear - Sun	281-1688

(Continued)

Sales Model 950E (Continued)

Original Part Number	Part Name	Classic Part Number
9Y-2992	Bearing - Sleeve	325-6032

Sales Model 966A

Original Part Number	Part Name	Classic Part Number
121-7746	Precleaner As	360-2311
1H-8262	Shaft	226-8016
1M-5270	Pipe - Extension	367-6065
1M-7250	Bowl - Precleaner	360-2296
1S-1888	Bracket - Lamp	297-7147
1T-0020	Wheel - Turbine	297-4862
1T-0553	Gear As - Pump Drive	226-5983
1T-1428	Retainer - Bearing	300-2587
1T-1987	Housing - Rotating	297-4864
1V-1080	Housing - Bearing Spt	260-0775
1V-2992	Gear - Diff Bevel	224-1301
1V-5724	Diff Gp	260-0776
1W-4405	Gear - Crankshaft	279-4982
2K-0535	Nut	299-2026
2K-0714	Plate - Thrust	299-2040
2K-3592	Boss	314-8501
2K-4442	Bearing - Sleeve	308-9812
2K-4507	Bearing - Sleeve	325-6021
2K-4513	Bearing - Sleeve	308-9814
2K-5073	Bushing	299-1989
2K-5977	Yoke	226-5992
2K-6000	Shaft - Planet	221-9106
2K-6001	Shaft - Planet	221-9107
2S-4015	Plunger As - Valve	311-9438
3H-3378	Gear As - Pump	298-2795
3K-0963	Pin - Lock	308-9895
3K-2498	Shaft - Planet	216-7824
3K-5461	Wheel - Steering	308-9945
3K-7020	Gear - Planet	221-9074
3K-7021	Gear - Ring	221-9075
3L-1425	Bearing - Ball	311-9356
3S-2616	Pump Gp - Transmission	226-0165
3V-2281	Link As	299-2023
4K-9598	Retainer	297-7235
5K-1068	Retainer - Seal	260-0786
5K-5927	Boss	299-1973
5K-7995	Bearing - Sleeve	308-9820
5K-8265	Pin	241-2590
5P-7807	Bearing - Ball	314-8502
5S-1211	Cover - Valve	314-8665
5S-1822	Chamber As	248-5406
5S-1833	Chamber As	247-3298
5V-5279	Bearing - Sleeve	299-1966
6K-7284	Pin	241-2591
6K-7286	Pin	241-2592
6K-8307	Pin	241-2593
6K-8308	Pin	241-2594
6K-8309	Pin	241-2595
6K-8311	Pin	241-2599
7B-2420	Ferrule - Director	314-8517
7G-3454	Gear - Planet	300-2578
7J-9344	Bearing - Sleeve	360-2334
7J-9682	Bearing - Sleeve	360-2335
7K-0686	Trunnion - Rear	297-7266
7K-9513	Pin	241-2596
7K-9514	Pin	241-2597
7K-9515	Pin	241-2589
7K-9638	Bearing - Sleeve	365-8827
7K-9639	Bearing - Sleeve	314-8643
7K-9642	Bearing - Sleeve	360-2340
7K-9644	Bearing - Sleeve	360-2341
7M-4204	Manifold - Exhaust	261-0901
7M-4603	Body - Fuel Valve	311-9348
7M-7358	Valve - Inlet	298-2774
7S-7809	Cap As - Radiator	295-6417
7S-9749	Pulley - Gen Drive	264-5888
7T-2036	Cap As - Filter	361-1721
8H-2810	Case As - Filter	314-8512
8H-9806	Gear - Shaft Drive	325-6091
8K-5283	Plate	299-2043
8K-5334	Pin	241-2598
8K-6015	Gear - Bevel Ring	221-9076
8M-3224	Muffler	247-2676
8N-8225	Bearing - Main	314-8652
8P-1918	Gear - Planet	283-5210
8V-3134	Pinion - Bevel	260-0788
8V-3135	Gear - Differential Bevel	260-0783
8V-3136	Gear - Differential Bevel	253-1442
9H-2256	Pump Gp	311-9443
9K-9156	Retainer As	297-7236
9K-9158	Bearing - Sleeve	299-1970
9M-4163	Valve - Exhaust	298-2773

Sales Model 966B

Original Part Number	Part Name	Classic Part Number
1A-2846	Cap As - Filler	311-9368
1M-5270	Pipe - Extension	367-6065
1S-1888	Bracket - Lamp	297-7147
1T-0020	Wheel - Turbine	297-4862
1T-0553	Gear As - Pump Drive	226-5983
1T-1428	Retainer - Bearing	300-2587
1T-1987	Housing - Rotating	297-4864
1V-1080	Housing - Bearing Spt	260-0775
1V-2992	Gear - Diff Bevel	224-1301
1V-5724	Diff Gp	260-0776
1W-4405	Gear - Crankshaft	279-4982
2J-1506	Pin	319-3451
2K-0535	Nut	299-2026
2K-0714	Plate - Thrust	299-2040
2K-3592	Boss	314-8501
2K-4442	Bearing - Sleeve	308-9812
2K-4507	Bearing - Sleeve	325-6021
2K-4513	Bearing - Sleeve	308-9814
2K-5073	Bushing	299-1989
2K-5977	Yoke	226-5992
2K-6000	Shaft - Planet	221-9106
2K-6001	Shaft - Planet	221-9107
2K-6413	Pin	360-2270
2S-4015	Plunger As - Valve	311-9438
2S-6739	Pulley - Tightener	298-2794
2V-4332	Collar	299-1993
2V-6221	Shaft - Planet	221-9108
3H-3378	Gear As - Pump	298-2795
3K-0963	Pin - Lock	308-9895
3K-2498	Shaft - Planet	216-7824
3K-5461	Wheel - Steering	308-9945
3K-7020	Gear - Planet	221-9074
3L-1425	Bearing - Ball	311-9356
3V-2281	Link As	299-2023
4K-3004	Bearing - Trunnion Support	314-8632
4K-3128	Bearing - Sleeve	314-8633
4K-6212	Shaft - Bevel Pinion	223-4806
4K-6558	Pin - Lower	302-2710
4K-6736	Drum - Brake	223-6320
4K-6737	Gear - Ring	221-9097
4K-6760	Cap - Lower	300-2574
4K-6761	Cap - Upper	300-2575
4K-6810	Retainer - Seal	300-2586
4K-7251	Cover	299-2003
4K-7269	Support	299-2067
4K-7420	Retainer	297-7234
4K-8225	Pin - Cylinder	297-7215
4K-8416	Shaft	308-9927
4K-8561	Pin	299-2036
4K-8734	Bearing - Sleeve	299-1962
4K-9598	Retainer	297-7235
4V-0015	Plate - Lock	282-6563
5F-6393	Shaft	308-9928
5K-0609	Cover	308-9843
5K-2570	Spacer	226-5996
5K-5927	Boss	299-1973
5K-5933	Cover As	247-4125
5K-7995	Bearing - Sleeve	308-9820
5K-8265	Pin	241-2590
5P-7807	Bearing - Ball	314-8502
5S-1211	Cover - Valve	314-8665
5S-1822	Chamber As	248-5406
5S-1833	Chamber As	247-3298
5S-4557	Bearing	311-9360
5V-5279	Bearing - Sleeve	299-1966
6K-4498	Bracket As - Lh	299-1976
6K-4600	Yoke	226-5993
6K-7284	Pin	241-2591
6K-7286	Pin	241-2592
6K-8307	Pin	241-2593
6K-8308	Pin	241-2594
6K-8309	Pin	241-2595
6K-8311	Pin	241-2599
7B-0503	Ballstud	308-9801
7B-2420	Ferrule - Director	314-8517
7G-3454	Gear - Planet	300-2578
7J-9344	Bearing - Sleeve	360-2334
7J-9366	Bearing - Sleeve	299-1985
7J-9682	Bearing - Sleeve	360-2335
7J-9731	Bearing - Sleeve	308-9822
7K-0449	Yoke As	297-7271
7K-0450	Yoke As	297-7272
7K-0686	Trunnion - Rear	297-7266
7K-1818	Cover	308-9844
7K-6260	Shaft - Sector	308-9931
7K-7200	Pin	241-2600
7K-7613	Joint Gp - Slip	302-2689
7K-9513	Pin	241-2596
7K-9514	Pin	241-2597
7K-9515	Pin	241-2589
7K-9638	Bearing - Sleeve	365-8827
7K-9639	Bearing - Sleeve	314-8643
7K-9642	Bearing - Sleeve	360-2340
7K-9644	Bearing - Sleeve	360-2341
7M-4204	Manifold - Exhaust	261-0901
7M-4603	Body - Fuel Valve	311-9348
7M-7358	Valve - Inlet	298-2774
7N-2957	Cover - Rad Cap	361-1722
7N-5511	Gear As - Idler	233-2180
7S-7809	Cap As - Radiator	295-6417
7S-9749	Pulley - Gen Drive	264-5888
7T-2036	Cap As - Filter	361-1721
8F-9365	Pin	319-3463
8H-2810	Case As - Filter	314-8512
8H-9806	Gear - Shaft Drive	325-6091
8K-5283	Plate	299-2043
8K-5334	Pin	241-2598
8M-3224	Muffler	247-2676

(Continued)

Sales Model 966B (Continued)

Original Part Number	Part Name	Classic Part Number
8N-8225	Bearing - Main	314-8652
8P-1918	Gear - Planet	283-5210
8V-3134	Pinion - Bevel	260-0788
8V-3135	Gear - Differential Bevel	260-0783
8V-3136	Gear - Differential Bevel	253-1442
9C-4811	Hub As	224-1300
9H-2256	Pump Gp	311-9443
9K-1193	Gear - Sun	221-9099
9K-3413	Gear - Bevel Ring	223-4807
9K-9156	Retainer As	297-7236
9K-9158	Bearing - Sleeve	299-1970
9M-4163	Valve - Exhaust	298-2773
9M-8281	Gear As - Oil Pump	325-6089
9M-8284	Pump Gp - Transmission	226-0159

Sales Model 966C

Original Part Number	Part Name	Classic Part Number
0T-0259	Nut - Bearing Sleeve	311-9431
100-7860	Valve - Inlet	270-4360 (Valve), 270-4362 (Valve Kit)
104-4253	Line As - Fuel Injector	279-4988
104-4254	Line As - Fuel Injector	279-4989
111-8015	Gasket As - Head	279-4977
114-9036	Shaft - Input	297-4859
115-0637	Pump Gp	226-0160
122-9405	Bracket As	325-6005
131-3815	Seal Gp - Basic	325-6193
148-7455	Valve - Exhaust	270-4361
165-4262	Body As - Piston	270-4351
170-0560	Rebuild Kit	363-7458
172-5185	Shaft - Water Pump	325-6201
172-5188	Shaft - Water Pump	325-6202
172-5189	Impeller - Pump	295-5687
172-5190	Impeller - Pump	325-6111
172-6712	Impeller - Pump	325-6112
172-7767	Pump Gp - Water	296-1365
176-9273	Piston	297-4860
196-0028	Gear As - Idler	364-5259
1A-2846	Cap As - Filler	311-9368
1F-2254	Bushing - Stem	314-8510
1F-4419	Gasket - Cover	311-9393
1N-3576	Block Gp - Cylinder	279-4978
1N-3958	Elbow	325-6087
1P-4231	Pump Gp - Gear	226-0156
1P-4303	Head As - Cylinder	242-3434
1P-5262	Cage - Bearing	226-5989
1P-8554	Coupling - Exhaust	325-6052
1P-9945	Bracket As - Fan	296-1344
1P-9946	Shaft - Fan	325-6194
1P-9952	Impeller - Pump	314-8685
1S-1888	Bracket - Lamp	297-7147
1S-4701	Pulley - Alt	264-5866
1T-0020	Wheel - Turbine	297-4862
1T-0553	Gear As - Pump Drive	226-5983
1T-1428	Retainer - Bearing	300-2587
1T-1691	Impeller - Converter	297-4863
1T-1987	Housing - Rotating	297-4864
1V-1080	Housing - Bearing Spt	260-0775
1V-2992	Gear - Diff Bevel	224-1301
1V-3995	Pin	319-3449
1V-5724	Diff Gp	260-0776
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1695	Pump Gp	279-4980
1W-1698	Housing - Transfer Pump	296-1356
1W-4402	Gear - Camshaft	279-4981
1W-4405	Gear - Crankshaft	279-4982
1W-5912	Tappet As - Guide	325-6223
1W-6541	Plunger As	325-6173
244-1090	Alarm - Back up	360-2345
2D-5658	Bearing - Ball	301-4628
2F-5721	Bearing - Ball	311-9354
2J-1506	Pin	319-3451
2K-0535	Nut	299-2026
2K-0714	Plate - Thrust	299-2040
2K-3592	Boss	314-8501
2K-4442	Bearing - Sleeve	308-9812
2K-4502	Bearing - Sleeve	299-1986
2K-4507	Bearing - Sleeve	325-6021
2K-4513	Bearing - Sleeve	308-9814
2K-5073	Bushing	299-1989
2K-5977	Yoke	226-5992
2K-6413	Pin	360-2270
2P-1170	Shaft As - Gear	296-1367
2P-1738	Plate As - Oil Pan	325-6164
2P-1739	Tube As - Pump	325-6229
2P-1757	Hub - Fan Pulley	296-1357

(Continued)

Sales Model 966C (Continued)

Original Part Number	Part Name	Classic Part Number
2P-1781	Spacer - Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2519	Tube As - Inlet	325-6230
2P-2719	Pipe	363-7454
2P-5608	Pipe - Extension	367-6066
2P-5609	Muffler As	247-2665
2P-6128	Pulley	264-5872
2P-6245	Shaft As - Pump	325-6197
2S-4015	Plunger As - Valve	311-9438
2V-4332	Collar	299-1993
2V-6221	Shaft - Planet	221-9108
2V-7083	Yoke	224-1302
2W-1086	Cover As - Cylinder Head	325-6049
2W-2621	Valve - Inlet	247-6892 (Valve), 241-3381 (Valve Kit)
2W-7255	Shaft - Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear - Water Pump	325-6088
2W-9978	Core As - Oil Cooler	279-4983
3F-7445	Bearing - Sleeve	314-8508
3K-0963	Pin - Lock	308-9895
3K-5461	Wheel - Steering	308-9945
3K-7020	Gear - Planet	221-9074
3L-1425	Bearing - Ball	311-9356
3P-3450	Yoke	229-8225
3P-5672	Yoke	223-6313
3S-1167	Gear - Planet	221-9101
3T-3447	Gear As - Sun	302-2676
3T-4223	Gear - Transfer	319-3438
3T-4224	Gear - Transfer	297-7175
3T-6795	Piston - Clutch	281-1693
3T-9496	Plate - Retainer	299-2042
3V-2281	Link As	299-2023
3V-7427	Housing As	297-7197
4F-4974	Clamp	311-9373
4K-3004	Bearing - Trunnion Support	314-8632
4K-3128	Bearing - Sleeve	314-8633
4K-6212	Shaft - Bevel Pinion	223-4806
4K-6558	Pin - Lower	302-2710
4K-6736	Drum - Brake	223-6320
4K-6737	Gear - Ring	221-9097
4K-6760	Cap - Lower	300-2574
4K-6761	Cap - Upper	300-2575
4K-6810	Retainer - Seal	300-2586
4K-7251	Cover	299-2003
4K-7269	Support	299-2067
4K-7420	Retainer	297-7234
4K-8225	Pin - Cylinder	297-7215
4K-8416	Shaft	308-9927
4K-8561	Pin	299-2036
4K-8734	Bearing - Sleeve	299-1962
4K-9598	Retainer	297-7235
4N-2954	Sleeve - Camshaft	299-2059
4N-3281	Line As - Fuel Injector	247-3362
4N-3282	Line As - Fuel Injector	247-3363
4N-3283	Line As - Fuel Injector	247-3364
4N-7692	Crankshaft As	242-3440
4N-7693	Crankshaft As	242-3439
4N-8591	Coupling - Exhaust	325-6053
4N-8814	Line As - Fuel Injector	247-3366
4N-9587	Shield - Heat	297-7260
4P-3546	Valve As - Relief	325-6236
4P-9381	Line As - Fuel Injector	279-4984
4P-9382	Line As - Fuel Injector	279-4985
4P-9385	Line As - Fuel Injector	279-4986
4P-9386	Line As - Fuel Injector	279-4987
4S-5943	Piston - Clutch	221-9112
4S-5944	Gear - Sun	221-9078
4S-5945	Gear - Sun	221-9079
4S-5947	Gear - Ring	221-9080
4S-5948	Gear - Ring	221-9082
4S-5981	Gear - Ring	221-9084
4S-8530	Shaft - Planet	221-9111
4S-8534	Shaft As - Planet	221-9116
4V-0015	Plate - Lock	282-6563
4W-0452	Seal As - Camshaft	325-6191
5D-0470	Valve Gp	314-8549
5F-6393	Shaft	308-9928
5G-3612	Cap Gp	295-6419
5K-0609	Cover	308-9843
5K-5927	Boss	299-1973
5K-5933	Cover As	247-4125
5K-7995	Bearing - Sleeve	308-9820
5K-8265	Pin	241-2590
5P-7807	Bearing - Ball	314-8502
5S-1211	Cover - Valve	314-8665
5S-4359	Pump Gp - Transmission	226-0157
5S-4493	Carrier - Planet	223-6321
5S-4557	Bearing	311-9360
5S-6795	Chamber As	242-3437
5S-6972	Gear - Sun	221-9087
5S-6978	Shaft - Planet	221-9103
5S-7009	Plate As - End	226-4957
5S-7010	Shaft - Planet	221-9104
5S-7013	Gear - Ring	221-9088
5S-7023	Carrier - Planet	226-5986
5S-7609	Pulley - Alt Drive	264-5881
5S-7888	Retainer - Bearing	226-5988
5S-9062	Spacer	363-7463
5S-9080	Pulley - Alt Drive	264-5883
5V-5279	Bearing - Sleeve	299-1966
6H-3957	Bearing - Ball	311-9358
6I-1346	Pump Gp - Oil	295-5674
6K-0053	Housing	297-7191
6K-2034	Shaft	297-7249
6K-2036	Rack	299-2045
6K-4498	Bracket As - Lh	299-1976
6K-4600	Yoke	226-5993
6K-6046	Pin	241-2602

(Continued)

Sales Model 966C (Continued)

Original Part Number	Part Name	Classic Part Number
6K-6047	Pin	241-2603
6K-6053	Pin	241-2604
6K-6054	Pin	241-2605
6K-6175	Pin	241-2606
6K-7284	Pin	241-2591
6K-7286	Pin	241-2592
6K-8307	Pin	241-2593
6K-8308	Pin	241-2594
6K-8309	Pin	241-2595
6K-8311	Pin	241-2599
6K-8897	Bracket As	299-1977
6N-1036	Gear - Oil Pump	279-4991
6N-1965	Line As - Fuel Injector	250-7535
6N-1966	Line As - Fuel Injector	250-7536
6N-2789	Pulley	264-5886
6N-8413	Housing - Pump	325-6110
6P-2233	Gear - Planet	281-1690
6P-7742	Shaft - Planet	281-1695
6P-7743	Shaft - Planet	281-1696
6P-8003	Gear - Planet	281-1689
6P-8005	Gear - Planet	281-1691
6T-0830	Housing As	297-7199
6T-3009	Piston - Clutch	297-7226
6T-6987	Piston - Clutch	297-7227
6Y-7877	Housing As	297-7200
7B-0503	Ballstud	308-9801
7C-4297	Seal As - Camshaft	325-6192
7G-2477	Gear - Planet	221-9090
7G-2487	Gear - Planet	221-9092
7G-2520	Gear - Planet	221-9094
7G-3707	Piston - Clutch	302-2691
7G-3708	Piston - Clutch	300-2585
7G-4281	Housing As - Support	297-7201
7G-4302	Housing - Clutch	302-2708
7G-4306	Plate - Center	297-7229
7G-5444	Carrier - Planet	297-7165
7G-5572	Gear - Sun	300-2580
7G-5589	Gear - Ring	281-1692
7G-5593	Gear - Sun	300-2581
7G-5614	Shaft - Planet	281-1697
7G-6060	Plate - Center	302-2694
7G-6062	Gear - Ring	302-2678
7G-9721	Gear As - Oil Pump	297-7178
7G-9722	Gear - Pump Drive	297-7179
7H-0602	Dog - Clutch	314-8515
7J-9344	Bearing - Sleeve	360-2334
7J-9366	Bearing - Sleeve	299-1985
7J-9682	Bearing - Sleeve	360-2335
7J-9731	Bearing - Sleeve	308-9822
7K-0449	Yoke As	297-7271
7K-0450	Yoke As	297-7272
7K-0686	Trunnion - Rear	297-7266
7K-1818	Cover	308-9844
7K-6260	Shaft - Sector	308-9931
7K-7176	Pin	241-2570
7K-7200	Pin	241-2600
7K-7613	Joint Gp - Slip	302-2689
7K-9343	Pin	241-2571
7K-9344	Pin	241-2607
7K-9345	Pin	241-2608
7K-9513	Pin	241-2596
7K-9514	Pin	241-2597
7K-9515	Pin	241-2589
7K-9601	Bearing - Sleeve	360-2338
7K-9602	Bearing - Sleeve	360-2339
7K-9604	Bearing - Sleeve	308-9829
7K-9638	Bearing - Sleeve	365-8827
7K-9639	Bearing - Sleeve	314-8643
7K-9642	Bearing - Sleeve	360-2340
7K-9644	Bearing - Sleeve	360-2341
7M-2167	Ring - Governor Control	308-9919
7M-4603	Body - Fuel Valve	311-9348
7M-4926	Retainer - Pin	314-8538
7N-0128	Core As - Oil Cooler	299-1994
7N-0165	Core As - Oil Cooler	295-5670
7N-1164	Mount As	295-5451
7N-2871	Line As - Fuel Injector	319-8172
7N-2872	Line As - Fuel Injector	319-8173
7N-2874	Line As - Fuel Injector	298-2779
7N-2875	Line As - Fuel Injector	298-2780
7N-2876	Line As - Fuel Injector	298-2781
7N-2957	Cover - Rad Cap	361-1722
7N-3486	Manifold - Exhaust	261-0899
7N-3515	Gear - Camshaft	314-8669
7N-3536	Gear - Fuel	279-4993
7N-5511	Gear As - Idler	233-2180
7N-5910	Impeller - Pump	314-8686
7N-9145	Gear - Flywheel	279-4994
7N-9312	Damper As - Camshaft	299-2005
7N-9805	Pin - Piston	295-6438
7S-2980	Plate - Reaction	226-5998
7S-3033	Hub - Clutch	226-5985
7S-3161	Lifter - Valve	279-4996
7S-4494	Piston - Clutch	226-5999
7S-6723	Bracket - Alternator	299-1978
7S-7809	Cap As - Radiator	295-6417
7S-8443	Muffler	247-2675
7S-8572	Gear - Ring	221-9095
7S-9749	Pulley - Gen Drive	264-5888
7T-1285	Gear - Planet	297-7190
7T-2036	Cap As - Filter	361-1721
7T-3343	Plate - Clutch	297-7231
7W-0450	Gear - Water Pump	279-4997
7W-0507	Gear - Oil Pump Drive	279-4998
7W-0508	Gear - Fuel Pump Drive	296-1351

(Continued)

Sales Model 966C (Continued)

Original Part Number	Part Name	Classic Part Number
7W-5687	Hub - Camshaft	314-8684
7Y-1517	Pipe As - Tail	301-5246
8B-5972	Bearing - Ball	314-8503
8F-5104	Screen As - Oil Pan	314-8539
8F-9365	Pin	319-3463
8H-1993	Valve - Inlet	256-4765 (Valve Kit)
8H-1994	Valve - Exhaust	256-4765 (Valve Kit)
8H-2810	Case As - Filter	314-8512
8H-9806	Gear - Shaft Drive	325-6091
8K-5283	Plate	299-2043
8K-5334	Pin	241-2598
8K-6015	Gear - Bevel Ring	221-9076
8K-6282	Gear - Sun	281-1698
8K-6285	Shaft - Axle	299-2057
8M-0874	Plunger As - Valve	311-9439
8N-0002	Trunnion As	314-8728
8N-0875	Valve - Exhaust	247-6893 (Valve), 241-3381 (Valve Kit)
8N-1187	Head Gp - Cylinder	242-3435
8N-1721	Rod As - Conn	269-5291
8N-1965	Tube - Disposal	325-6235
8N-1984	Rod As - Conn	242-3441
8N-2510	Shaft	325-6208
8N-2641	Sleeve	325-6210
8N-3180	Body As - Piston	250-6563
8N-3181	Piston Gp - Basic	250-6555 (Liner Kit)
8N-3182	Body As - Piston	250-6564 (Piston As), 250-6556 (Liner Kits)
8N-3183	Piston Gp - Basic	250-6556 (Liner Kit)
8N-3251	Shaft As - Rocker Arm	314-8711
8N-3325	Arm Gp - Rocker	314-8623
8N-3327	Arm Gp - Rocker	314-8624
8N-5305	Spacer	363-7464
8N-5929	Cover - Water Pump	296-1349
8N-6796	Head Gp - Cylinder	269-5290
8N-7315	Tube As - Outlet	325-6232
8N-8225	Bearing - Main	314-8652
8N-9733	Line As - Fuel Injector	319-8174
8P-1656	Plate - Clutch	367-6071
8S-0248	Breather As	325-6033
8S-0493	Shaft As - Pump	325-6198
8S-0556	Coupling	221-9114
8S-0905	Muffler As	302-2690
8S-3970	Chamber As	242-3438
8V-3134	Pinion - Bevel	260-0788
8V-3135	Gear - Differential Bevel	260-0783
8V-3136	Gear - Differential Bevel	253-1442
9C-1528	Gear - Planet	223-4802
9C-4811	Hub As	224-1300
9G-1231	Plate	297-7232
9G-1491	Carrier - Planet	281-1685
9G-7411	Gear - Oil Pump Drive	297-7182
9G-7412	Gear As - Oil Pump	297-7183
9G-8117	Housing As	302-2686
9H-2256	Pump Gp	311-9443
9K-1193	Gear - Sun	221-9099
9K-1759	Carrier - Planet	221-9113
9K-1773	Gear - Ring	221-9100
9K-3413	Gear - Bevel Ring	223-4807
9K-9156	Retainer As	297-7236
9K-9158	Bearing - Sleeve	299-1970
9M-1328	Bearing - Aligning	325-6018
9M-4789	Shaft - Gov Control	297-7256
9M-8281	Gear As - Oil Pump	325-6089
9N-4460	Housing As	297-7203
9N-5251	Piston Gp - Basic	250-6557 (Liner Kit)
9N-5769	Cover - Housing	325-6050
9P-6888	Shaft - Output	221-9105
9S-2354	Manifold - Exhaust	261-0888
9S-2355	Manifold - Exhaust	261-0891
9S-6129	Pulley - Alternator Drive	264-5891
9S-8493	Bolt - Connecting Rod	311-9351
9S-8679	Chamber As	325-6042
9W-0517	Carrier - Planet	281-1686
9W-4949	Carrier - Planet	281-1687
9W-4950	Gear - Sun	281-1688

Sales Model 966D

Original Part Number	Part Name	Classic Part Number
100-7860	Valve - Inlet	270-4360 (Valve), 270-4362 (Valve Kit)
104-4253	Line As - Fuel Injector	279-4988
104-4254	Line As - Fuel Injector	279-4989
111-8015	Gasket As - Head	279-4977
112-3818	Shaft - Input	302-2698
112-5585	Shaft - Planet	308-9932
112-8041	Carrier - Planet	295-5681
122-9405	Bracket As	325-6005
127-5537	Core As	325-6045
131-3815	Seal Gp - Basic	325-6193
148-7455	Valve - Exhaust	270-4361
160-1400	Yoke	319-3479
165-4262	Body As - Piston	270-4351
167-8123	Damper As	299-2006
172-5185	Shaft - Water Pump	325-6201
172-5188	Shaft - Water Pump	325-6202
172-5189	Impeller - Pump	295-5687
172-5190	Impeller - Pump	325-6111
172-6712	Impeller - Pump	325-6112
172-7767	Pump Gp - Water	296-1365
177-9024	Adapter - Damper	299-1956
180-3767	Adapter - Damper	299-1957
186-4440	Shaft - Planet	364-5261
196-0028	Gear As - Idler	364-5259
1N-2936	Muffler As	298-2782
1N-2946	Extension - Exh	367-6064
1N-3576	Block Gp - Cylinder	279-4978
1N-3958	Elbow	325-6087
1P-9945	Bracket As - Fan	296-1344
1P-9946	Shaft - Fan	325-6194
1P-9952	Impeller - Pump	314-8685
1S-4701	Pulley - Alt	264-5866
1V-3995	Pin	319-3449
1V-6342	Gear As	308-9847
1W-1669	Piston	325-6158
1W-1695	Pump Gp	279-4980
1W-1698	Housing - Transfer Pump	296-1356
1W-4369	Pulley - Alt	296-1340
1W-4402	Gear - Camshaft	279-4981
1W-4405	Gear - Crankshaft	279-4982
1W-4407	Hub - Fan Pulley	296-1358
1W-5912	Tappet As - Guide	325-6223
1W-6541	Plunger As	325-6173
244-1090	Alarm - Back up	360-2345
2F-5721	Bearing - Ball	311-9354
2K-0535	Nut	299-2026
2K-0714	Plate - Thrust	299-2040
2K-3592	Boss	314-8501
2K-4442	Bearing - Sleeve	308-9812
2P-1170	Shaft As - Gear	296-1367
2P-1738	Plate As - Oil Pan	325-6164
2P-1739	Tube As - Pump	325-6229
2P-1757	Hub - Fan Pulley	296-1357
2P-1781	Spacer - Oil Pump	325-6214
2P-2519	Tube As - Inlet	325-6230
2P-4611	Pipe - Exhaust	365-8821
2P-6245	Shaft As - Pump	325-6197
2V-5697	Cover As	299-1999
2V-5709	Shaft - Axle	299-2056
2V-5714	Gear - Ring	288-8716
2V-5715	Bushing	299-1987
2V-5722	Carrier - Planet	297-7164
2V-6551	Pin	297-7212
2W-1086	Cover As - Cylinder Head	325-6049
2W-2621	Valve - Inlet	247-6892 (Valve), 241-3381 (Valve Kit)
2W-6757	Trunnion As	295-5678
2W-7255	Shaft - Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear - Water Pump	325-6088
2W-8494	Pulley - Alt	295-5692
3G-2665	Cover	308-9842
3K-5461	Wheel - Steering	308-9945
3L-1425	Bearing - Ball	311-9356
3P-3208	Flange - Joint	301-4647
3P-8283	Spacer	325-6215
3T-2145	Carrier As	325-6041
3T-3203	Gear - Transfer	302-2675
3V-8777	Gear - Spiral	297-7176
4E-3196	Pin As	361-1697
4E-3456	Lever As	367-6081
4E-5213	Cover As	299-2000
4E-8534	Retainer - Seal	300-2588
4E-8535	Retainer - Seal	300-2589
4J-6374	Bearing - Sleeve	295-6407
4K-6558	Pin - Lower	302-2710
4K-6760	Cap - Lower	300-2574
4K-6761	Cap - Upper	300-2575
4K-6810	Retainer - Seal	300-2586
4K-7269	Support	299-2067
4N-2954	Sleeve - Camshaft	299-2059
4N-6302	Belt Set - Vee	314-8495
4N-7693	Crankshaft As	242-3439
4P-3546	Valve As - Relief	325-6236
4P-9381	Line As - Fuel Injector	279-4984
4P-9382	Line As - Fuel Injector	279-4985
4P-9385	Line As - Fuel Injector	279-4986
4P-9386	Line As - Fuel Injector	279-4987

(Continued)

Sales Model 966D (Continued)

Original Part Number	Part Name	Classic Part Number
4P-9961	Line As - Fuel Injector	325-6115
4S-8472	Hood As	296-1355
4V-0015	Plate - Lock	282-6563
4V-2518	Shaft	297-7243
4V-3680	Bellcrank	308-9802
4V-5100	Support - Trunnion	299-2068
4V-5213	Spindle	299-2060
4V-5388	Shaft - Bevel Pinion	297-7244
4V-5393	Gear - Bevel	297-7189
4V-5394	Gear - Diff Bevel	297-7177
4V-6040	Drum	297-7168
4V-6421	Pin As	319-3442
4V-6430	Bracket As	299-1974
4V-7082	Joint Gp - Slip	367-6068
4V-7099	Pin As	361-1698
4V-7105	Pin As	361-1699
4V-7543	Retainer	281-1699
4V-8519	Bearing - Sleeve	307-1526
4V-8520	Bearing - Sleeve	307-1527
4V-8673	Bearing - Sleeve	307-1528
4V-8674	Bearing - Bushing	307-1529
4V-8687	Boss	299-1971
4V-8690	Boss	299-1972
4W-0452	Seal As - Camshaft	325-6191
4W-2042	Spacer	325-6217
4W-2446	Damper As	279-4990
4W-5053	Muffler As	360-7881
5C-9207	Drum	301-4623
5D-0470	Valve Gp	314-8549
5G-3612	Cap Gp	295-6419
5P-7807	Bearing - Ball	314-8502
5P-8194	Ring - Retaining	308-9920
5S-4557	Bearing	311-9360
5S-6795	Chamber As	242-3437
5S-9080	Pulley - Alt Drive	264-5883
5V-1271	Diff Gp	299-2008
5V-5917	Pinion - Diff Bevel	297-7224
5V-8782	Lever As	299-2014
6H-3957	Bearing - Ball	311-9358
6I-1346	Pump Gp - Oil	295-5674
6K-6051	Pin	252-6858
6N-1036	Gear - Oil Pump	279-4991
6N-1572	Mount As	308-9876
6N-8413	Housing - Pump	325-6110
6N-9743	Support - Muffler	308-9940
6P-7704	Carrier - Ring	314-8658
6T-1705	Shaft - Pump Drive	283-5201
6T-1706	Gear - Pump Drive	283-5202
6W-1629	Shaft - Bevel Pinion	297-7250
6Y-2054	Plate As	302-2695
6Y-4819	Carrier - Planet	296-1348
6Y-4840	Plate As	297-7233
7C-0942	Adapter As	302-2636
7C-5851	Muffler As	298-2790
7G-2516	Gear - Planet	283-5203
7G-2830	Ring - Seal	295-6441
7G-5618	Manifold As	283-5204
7G-7218	Carrier - Planet	283-5205
7G-7724	Piston - Clutch	283-5206
7J-6461	Crown	325-6054
7J-9344	Bearing - Sleeve	360-2334
7J-9682	Bearing - Sleeve	360-2335
7K-0686	Trunnion - Rear	297-7266
7K-6497	Pin	252-6870
7N-0110	Core As - Oil Cooler	319-3435
7N-0165	Core As - Oil Cooler	295-5670
7N-1164	Mount As	295-5451
7N-2871	Line As - Fuel Injector	319-8172
7N-2872	Line As - Fuel Injector	319-8173
7N-2874	Line As - Fuel Injector	298-2779
7N-3515	Gear - Camshaft	314-8669
7N-5910	Impeller - Pump	314-8686
7N-9145	Gear - Flywheel	279-4994
7N-9146	Gear - Flywheel Starter	279-4995
7N-9312	Damper As - Camshaft	299-2005
7N-9805	Pin - Piston	295-6438
7S-3161	Lifter - Valve	279-4996
7S-4629	Pump Gp - Transfer	226-0158
7T-2036	Cap As - Filter	361-1721
7T-3370	Yoke As	302-2702
7T-5038	Housing As	297-7202
7T-9370	Gear - Sun	283-5207
7V-3842	Spider Gp - Brg	367-6069
7V-6715	Pin As	361-1701
7W-0450	Gear - Water Pump	279-4997
7W-0507	Gear - Oil Pump Drive	279-4998
7W-0508	Gear - Fuel Pump Drive	296-1351
7W-1902	Adapter - Fuel Nozzle	299-1955
7W-2164	Core As - Oil Cooler	299-1996
7W-5684	Pulley - Camshaft	298-2771
7W-5685	Pulley - Camshaft	298-2772
7W-5698	Pulley - Camshaft	295-5679
8D-2628	Nut	299-2027
8F-9365	Pin	319-3463
8H-2810	Case As - Filter	314-8512
8K-6285	Shaft - Axle	299-2057
8M-0874	Plunger As - Valve	311-9439
8N-0875	Valve - Exhaust	247-6893 (Valve), 241-3381 (Valve Kit)
8N-1187	Head Gp - Cylinder	242-3435
8N-1214	Mount As	325-6125
8N-1721	Rod As - Conn	269-5291
8N-1965	Tube - Disposal	325-6235
8N-2510	Shaft	325-6208

(Continued)

Sales Model 966D (Continued)

Original Part Number	Part Name	Classic Part Number
8N-2641	Sleeve	325-6210
8N-3251	Shaft As - Rocker Arm	314-8711
8N-3325	Arm Gp - Rocker	314-8623
8N-3327	Arm Gp - Rocker	314-8624
8N-5929	Cover - Water Pump	296-1349
8N-6796	Head Gp - Cylinder	269-5290
8N-7315	Tube As - Outlet	325-6232
8N-8225	Bearing - Main	314-8652
8N-9733	Line As - Fuel Injector	319-8174
8P-0953	Turbine - Converter	297-7269
8P-0957	Impeller - Converter	297-7209
8P-1121	Ring - Clamp	299-2049
8P-1892	Piston - Clutch	283-5208
8P-1916	Gear - Planet	283-5209
8P-1918	Gear - Planet	283-5210
8P-1919	Gear - Planet	300-2579
8P-2042	Shaft - Planet	283-5211
8P-8677	Hub - Impeller	297-7205
8P-9507	Piston - Clutch	283-5212
8R-0931	Housing - Pinion	302-4300
8R-3252	Shaft - Planet	297-7259
8R-3943	Collet	308-9840
8S-0248	Breather As	325-6033
8S-0493	Shaft As - Pump	325-6198
8S-3970	Chamber As	242-3438
8V-1613	Lever	299-2017
8V-1624	Lever	299-2019
8V-3134	Pinion - Bevel	260-0788
8V-3135	Gear - Differential Bevel	260-0783
8V-3136	Gear - Differential Bevel	253-1442
8V-7659	Pin As	361-1702
8V-7884	Housing - Support	302-2681
8V-7885	Housing - Support	297-7193
9C-1484	Pin As	319-3446
9C-4080	Yoke - Brake	302-2703
9C-5852	Hub As	297-7208
9C-6015	Pinion - Diff Bevel	297-7225
9C-6017	Gear - Diff Bevel	297-7187
9C-6027	Carrier - Planet	297-7166
9C-8218	Shaft - Bevel Pinion	302-2697
9C-8219	Gear - Bevel	297-7186
9C-9191	Trunnion	302-2701
9C-9748	Gear - Differential Bevel	302-2671
9C-9773	Gear - Differential Bevel	302-2672
9G-0280	Piston - Clutch	283-5213
9G-0284	Housing - Clutch	283-5214
9G-0285	Piston - Clutch	283-5215
9G-0289	Shaft - Planet	283-5216
9G-0290	Hub - Clutch	283-5217
9G-2413	Shaft - Output	297-7255
9G-7411	Gear - Oil Pump Drive	297-7182
9G-7412	Gear As - Oil Pump	297-7183
9K-8757	Rod End - Bearing	311-9361
9N-5404	Piston Gp - Basic	250-6558 (Liner Kit)
9N-5769	Cover - Housing	325-6050
9N-6611	Pulley	325-6177
9P-3731	Carrier - Planet	301-4767
9P-7757	Gear - Sun	283-5218
9P-8283	Plate - Clutch	296-1364
9P-8521	Gear - Ring	296-1353
9P-8623	Shaft - Planet	314-8719
9P-8624	Shaft - Planet	295-5446
9P-8626	Gear - Sun	283-5219
9P-8866	Gear - Transfer	299-2012
9P-9031	Gear - Sun	283-5220
9P-9517	Stator - Converter	297-7262
9P-9610	Pump Gp	283-5221
9P-9790	Shaft - Output	302-2696
9S-2354	Manifold - Exhaust	261-0888
9S-2355	Manifold - Exhaust	261-0891
9S-8679	Chamber As	325-6042
9U-2787	Gear - Planet	367-6093
9U-3124	Gear - Planet	288-8806
9U-3125	Gear - Sun	288-8807
9V-2410	Housing - Bearing	302-2679
9V-2411	Housing - Bearing	302-2680
9V-3853	Pin	319-3469
9V-6523	Cap	297-7162
9V-6524	Cap	297-7163
9W-3605	Carrier - Ring	314-8662
9W-8270	Gear - Ring	308-9859
9W-8384	Hub - Turbine	297-7207
9W-8433	Shaft As - Output	302-4249
9W-8437	Gear - Sun	283-5222
9W-9069	Shaft - Input	302-2715
9Y-2988	Breather As	361-1716

Sales Model 966E

Original Part Number	Part Name	Classic Part Number
100-7860	Valve - Inlet	270-4360 (Valve), 270-4362 (Valve Kit)
104-4253	Line As - Fuel Injector	279-4988
104-4254	Line As - Fuel Injector	279-4989
111-8015	Gasket As - Head	279-4977
112-3818	Shaft - Input	302-2698
112-5585	Shaft - Planet	308-9932
112-8041	Carrier - Planet	295-5681
122-9405	Bracket As	325-6005
127-5537	Core As	325-6045
131-3815	Seal Gp - Basic	325-6193
148-7455	Valve - Exhaust	270-4361
160-1400	Yoke	319-3479
167-8123	Damper As	299-2006
170-0560	Rebuild Kit	363-7458
172-5185	Shaft - Water Pump	325-6201
172-5188	Shaft - Water Pump	325-6202
172-5189	Impeller - Pump	295-5687
172-5190	Impeller - Pump	325-6111
172-6712	Impeller - Pump	325-6112
172-7767	Pump Gp - Water	296-1365
177-9024	Adapter - Damper	299-1956
180-3767	Adapter - Damper	299-1957
186-4440	Shaft - Planet	364-5261
196-0028	Gear As - Idler	364-5259
1N-2936	Muffler As	298-2782
1N-2946	Extension - Exh	367-6064
1N-3576	Block Gp - Cylinder	279-4978
1N-3958	Elbow	325-6087
1P-9945	Bracket As - Fan	296-1344
1P-9946	Shaft - Fan	325-6194
1P-9952	Impeller - Pump	314-8685
1S-4701	Pulley - Alt	264-5866
1V-3995	Pin	319-3449
1V-6342	Gear As	308-9847
1W-1669	Piston	325-6158
1W-1695	Pump Gp	279-4980
1W-1698	Housing - Transfer Pump	296-1356
1W-4369	Pulley - Alt	296-1340
1W-4402	Gear - Camshaft	279-4981
1W-4405	Gear - Crankshaft	279-4982
1W-4407	Hub - Fan Pulley	296-1358
1W-5912	Tappet As - Guide	325-6223
1W-6541	Plunger As	325-6173
244-1090	Alarm - Back up	360-2345
2F-5721	Bearing - Ball	311-9354
2K-0535	Nut	299-2026
2K-0714	Plate - Thrust	299-2040
2K-3592	Boss	314-8501
2K-4442	Bearing - Sleeve	308-9812
2N-7942	Spacer	363-7462
2P-1170	Shaft As - Gear	296-1367
2P-1738	Plate As - Oil Pan	325-6164
2P-1739	Tube As - Pump	325-6229
2P-1757	Hub - Fan Pulley	296-1357
2P-1781	Spacer - Oil Pump	325-6214
2P-2519	Tube As - Inlet	325-6230
2P-2719	Pipe	363-7454
2P-4611	Pipe - Exhaust	365-8821
2P-6245	Shaft As - Pump	325-6197
2V-5697	Cover As	299-1999
2V-5709	Shaft - Axle	299-2056
2V-5714	Gear - Ring	288-8716
2V-5715	Bushing	299-1987
2V-5722	Carrier - Planet	297-7164
2V-6551	Pin	297-7212
2W-1086	Cover As - Cylinder Head	325-6049
2W-2621	Valve - Inlet	247-6892 (Valve), 241-3381 (Valve Kit)
2W-5540	Core, Radiator (Folded)	363-7452
2W-6757	Trunnion As	295-5678
2W-7255	Shaft - Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear - Water Pump	325-6088
2W-8494	Pulley - Alt	295-5692
3G-2665	Cover	308-9842
3K-5461	Wheel - Steering	308-9945
3L-1425	Bearing - Ball	311-9356
3P-3208	Flange - Joint	301-4647
3P-8283	Spacer	325-6215
3T-2145	Carrier As	325-6041
3T-3203	Gear - Transfer	302-2675
3V-8777	Gear - Spiral	297-7176
4E-3196	Pin As	361-1697
4E-3456	Lever As	367-6081
4E-5213	Cover As	299-2000
4E-8534	Retainer - Seal	300-2588
4E-8535	Retainer - Seal	300-2589
4J-6374	Bearing - Sleeve	295-6407
4K-6558	Pin - Lower	302-2710
4K-6760	Cap - Lower	300-2574
4K-6761	Cap - Upper	300-2575
4K-6810	Retainer - Seal	300-2586
4K-7269	Support	299-2067
4N-2954	Sleeve - Camshaft	299-2059
4N-3714	Chamber, Precom	363-7450
4N-6302	Belt Set - Vee	314-8495
4N-7693	Crankshaft As	242-3439
4P-3546	Valve As - Relief	325-6236
4P-9381	Line As - Fuel Injector	279-4984
4P-9382	Line As - Fuel Injector	279-4985

(Continued)

Sales Model 966E (Continued)

Original Part Number	Part Name	Classic Part Number
4P-9385	Line As - Fuel Injector	279-4986
4P-9386	Line As - Fuel Injector	279-4987
4P-9961	Line As - Fuel Injector	325-6115
4S-8472	Hood As	296-1355
4V-0015	Plate - Lock	282-6563
4V-2518	Shaft	297-7243
4V-3680	Bellcrank	308-9802
4V-5100	Support - Trunnion	299-2068
4V-5213	Spindle	299-2060
4V-5388	Shaft - Bevel Pinion	297-7244
4V-5393	Gear - Bevel	297-7189
4V-5394	Gear - Diff Bevel	297-7177
4V-6040	Drum	297-7168
4V-6421	Pin As	319-3442
4V-6430	Bracket As	299-1974
4V-7082	Joint Gp - Slip	367-6068
4V-7099	Pin As	361-1698
4V-7105	Pin As	361-1699
4V-7543	Retainer	281-1699
4V-8519	Bearing - Sleeve	307-1526
4V-8520	Bearing - Sleeve	307-1527
4V-8673	Bearing - Sleeve	307-1528
4V-8674	Bearing - Bushing	307-1529
4V-8687	Boss	299-1971
4V-8690	Boss	299-1972
4W-0452	Seal As - Camshaft	325-6191
4W-2042	Spacer	325-6217
4W-2446	Damper As	279-4990
4W-5053	Muffler As	360-7881
5C-9207	Drum	301-4623
5D-0470	Valve Gp	314-8549
5G-3612	Cap Gp	295-6419
5P-7807	Bearing - Ball	314-8502
5P-8194	Ring - Retaining	308-9920
5S-4557	Bearing	311-9360
5S-6795	Chamber As	242-3437
5S-9062	Spacer	363-7463
5S-9080	Pulley - Alt Drive	264-5883
5V-1271	Diff Gp	299-2008
5V-5917	Pinion - Diff Bevel	297-7224
5V-8782	Lever As	299-2014
6H-3957	Bearing - Ball	311-9358
6I-1346	Pump Gp - Oil	295-5674
6K-6051	Pin	252-6858
6N-1036	Gear - Oil Pump	279-4991
6N-1572	Mount As	308-9876
6N-8413	Housing - Pump	325-6110
6N-9743	Support - Muffler	308-9940
6P-7704	Carrier - Ring	314-8658
6T-1705	Shaft - Pump Drive	283-5201
6T-1706	Gear - Pump Drive	283-5202
6W-1629	Shaft - Bevel Pinion	297-7250
6Y-2054	Plate As	302-2695
6Y-4819	Carrier - Planet	296-1348
6Y-4840	Plate As	297-7233
7C-0942	Adapter As	302-2636
7C-3039	Core, Oil Cooler	363-7451
7C-5851	Muffler As	298-2790
7G-2516	Gear - Planet	283-5203
7G-2830	Ring - Seal	295-6441
7G-5618	Manifold As	283-5204
7G-7218	Carrier - Planet	283-5205
7G-7724	Piston - Clutch	283-5206
7J-6461	Crown	325-6054
7J-9344	Bearing - Sleeve	360-2334
7J-9682	Bearing - Sleeve	360-2335
7K-0686	Trunnion - Rear	297-7266
7K-6497	Pin	252-6870
7N-0110	Core As - Oil Cooler	319-3435
7N-0165	Core As - Oil Cooler	295-5670
7N-1164	Mount As	295-5451
7N-2871	Line As - Fuel Injector	319-8172
7N-2872	Line As - Fuel Injector	319-8173
7N-2874	Line As - Fuel Injector	298-2779
7N-3515	Gear - Camshaft	314-8669
7N-5910	Impeller - Pump	314-8686
7N-9145	Gear - Flywheel	279-4994
7N-9146	Gear - Flywheel Starter	279-4995
7N-9312	Damper As - Camshaft	299-2005
7N-9805	Pin - Piston	295-6438
7S-3161	Lifter - Valve	279-4996
7S-4629	Pump Gp - Transfer	226-0158
7T-2036	Cap As - Filter	361-1721
7T-3370	Yoke As	302-2702
7T-5038	Housing As	297-7202
7T-9370	Gear - Sun	283-5207
7V-3842	Spider Gp - Brg	367-6069
7V-6715	Pin As	361-1701
7W-0450	Gear - Water Pump	279-4997
7W-0507	Gear - Oil Pump Drive	279-4998
7W-0508	Gear - Fuel Pump Drive	296-1351
7W-1902	Adapter - Fuel Nozzle	299-1955
7W-2164	Core As - Oil Cooler	299-1996
7W-5684	Pulley - Camshaft	298-2771
7W-5685	Pulley - Camshaft	298-2772
7W-5698	Pulley - Camshaft	295-5679
8D-2628	Nut	299-2027
8F-9365	Pin	319-3463
8H-2810	Case As - Filter	314-8512
8K-6285	Shaft - Axle	299-2057
8M-0874	Plunger As - Valve	311-9439
8N-0875	Valve - Exhaust	247-6893 (Valve), 241-3381 (Valve Kit)

(Continued)

Sales Model 966E (Continued)

Original Part Number	Part Name	Classic Part Number
8N-1187	Head Gp - Cylinder	242-3435
8N-1214	Mount As	325-6125
8N-1721	Rod As - Conn	269-5291
8N-1965	Tube - Disposal	325-6235
8N-2510	Shaft	325-6208
8N-2641	Sleeve	325-6210
8N-3251	Shaft As - Rocker Arm	314-8711
8N-3325	Arm Gp - Rocker	314-8623
8N-3327	Arm Gp - Rocker	314-8624
8N-5305	Spacer	363-7464
8N-5929	Cover - Water Pump	296-1349
8N-6796	Head Gp - Cylinder	269-5290
8N-7315	Tube As - Outlet	325-6232
8N-8225	Bearing - Main	314-8652
8N-9733	Line As - Fuel Injector	319-8174
8P-0953	Turbine - Converter	297-7269
8P-0957	Impeller - Converter	297-7209
8P-1121	Ring - Clamp	299-2049
8P-1892	Piston - Clutch	283-5208
8P-1916	Gear - Planet	283-5209
8P-1918	Gear - Planet	283-5210
8P-1919	Gear - Planet	300-2579
8P-2042	Shaft - Planet	283-5211
8P-8677	Hub - Impeller	297-7205
8P-9507	Piston - Clutch	283-5212
8R-0931	Housing - Pinion	302-4300
8R-3252	Shaft - Planet	297-7259
8R-3943	Collet	308-9840
8S-0248	Breather As	325-6033
8S-0493	Shaft As - Pump	325-6198
8S-3970	Chamber As	242-3438
8V-1613	Lever	299-2017
8V-1624	Lever	299-2019
8V-3134	Pinion - Bevel	260-0788
8V-3135	Gear - Differential Bevel	260-0783
8V-3136	Gear - Differential Bevel	253-1442
8V-7659	Pin As	361-1702
8V-7884	Housing - Support	302-2681
8V-7885	Housing - Support	297-7193
9C-1484	Pin As	319-3446
9C-4080	Yoke - Brake	302-2703
9C-5852	Hub As	297-7208
9C-6015	Pinion - Diff Bevel	297-7225
9C-6017	Gear - Diff Bevel	297-7187
9C-6027	Carrier - Planet	297-7166
9C-8218	Shaft - Bevel Pinion	302-2697
9C-8219	Gear - Bevel	297-7186
9C-9191	Trunnion	302-2701
9C-9748	Gear - Differential Bevel	302-2671
9C-9773	Gear - Differential Bevel	302-2672
9G-0280	Piston - Clutch	283-5213
9G-0284	Housing - Clutch	283-5214
9G-0285	Piston - Clutch	283-5215
9G-0289	Shaft - Planet	283-5216
9G-0290	Hub - Clutch	283-5217
9G-2413	Shaft - Output	297-7255
9G-7411	Gear - Oil Pump Drive	297-7182
9G-7412	Gear As - Oil Pump	297-7183
9K-8757	Rod End - Bearing	311-9361
9L-6371	Rod	363-7459
9N-5404	Piston Gp - Basic	250-6558 (Liner Kit)
9N-5769	Cover - Housing	325-6050
9N-6611	Pulley	325-6177
9P-3731	Carrier - Planet	301-4767
9P-7757	Gear - Sun	283-5218
9P-8283	Plate - Clutch	296-1364
9P-8521	Gear - Ring	296-1353
9P-8623	Shaft - Planet	314-8719
9P-8624	Shaft - Planet	295-5446
9P-8626	Gear - Sun	283-5219
9P-8866	Gear - Transfer	299-2012
9P-9031	Gear - Sun	283-5220
9P-9517	Stator - Converter	297-7262
9P-9610	Pump Gp	283-5221
9P-9790	Shaft - Output	302-2696
9S-2354	Manifold - Exhaust	261-0888
9S-2355	Manifold - Exhaust	261-0891
9S-8679	Chamber As	325-6042
9U-2787	Gear - Planet	367-6093
9U-3124	Gear - Planet	288-8806
9U-3125	Gear - Sun	288-8807
9V-2410	Housing - Bearing	302-2679
9V-2411	Housing - Bearing	302-2680
9V-3853	Pin	319-3469
9V-6523	Cap	297-7162
9V-6524	Cap	297-7163
9W-3605	Carrier - Ring	314-8662
9W-8270	Gear - Ring	308-9859
9W-8384	Hub - Turbine	297-7207
9W-8433	Shaft As - Output	302-4249
9W-8437	Gear - Sun	283-5222
9W-9069	Shaft - Input	302-2715
9Y-2988	Breather As	361-1716

Sales Model 980

Original Part Number	Part Name	Classic Part Number
121-7746	Precleaner As	360-2311
1M-7250	Bowl - Pre-cleaner	360-2296
7J-9344	Bearing - Sleeve	360-2334
1T-0662	Turbine - Conv	235-1819
129-2339	Spider	308-9936
1A-2846	Cap As - Filler	311-9368
1S-1888	Bracket - Lamp	297-7147
1S-4701	Pulley - Alt	264-5866
1S-8753	Plate - Cou-pling	308-9910
1S-8754	Joint Gp - Univ	308-9873
1T-0665	Ring - Clamp	308-9918
1T-1091	Hub - Turbine	308-9869
1V-4838	Link As - Spring	308-9874
1V-5410	Bearing	308-9806
1V-6978	Bolt - Shoul-der	308-9803
2D-9130	Washer - Thrust	308-9943
2F-5721	Bearing - Ball	311-9354
2J-5649	Pin - Cylinder	256-4782
2K-3592	Boss	314-8501
2K-4177	Pin - Lock	308-9893
2K-4442	Bearing - Sleeve	308-9812
2K-4507	Bearing - Sleeve	325-6021
2K-4512	Bearing - Sleeve	308-9813
2K-4513	Bearing - Sleeve	308-9814
2S-2781	Plunger - Relief	311-9435
2V-4374	Joint Gp - Slip	308-9872
3D-5315	Pinion - Diff Bevel	308-9856
3F-4971	Pin	295-5693
3K-0963	Pin - Lock	308-9895
3K-5461	Wheel - Steering	308-9945
3L-1425	Bearing - Ball	311-9356
3S-1262	Retainer	308-9915
3S-8034	Shaft - Planet	308-9926
3S-9466	Bearing - Sleeve	314-8509
4J-1612	Pin	308-9896
4J-3015	Shaft	325-6204
4J-6899	Bearing - Sleeve	308-9815
4K-0299	Bearing - Sleeve	308-9816
4K-0300	Bearing - Sleeve	308-9817
4K-1102	Bearing - Sleeve	325-6010
4K-3004	Bearing - Trunnion Support	314-8632
4K-3128	Bearing - Sleeve	314-8633
4K-8416	Shaft	308-9927
5D-0470	Valve Gp	314-8549
5F-6393	Shaft	308-9928
5F-7404	Nut - Bearing Lock	308-9878
5G-3612	Cap Gp	295-6419
5J-3492	Bearing - Sleeve	308-9879
5J-4542	Bearing - Sleeve	308-9818
5K-3490	Spacer	308-9933
5K-3491	Spacer	308-9934
5K-3497	Pin	308-9897
5K-3499	Pin - Lower	308-9898
5K-3502	Cap - Lower	308-9835
5K-3967	Yoke As	308-9946
5K-3968	Cage - Bear-ing	308-9804
5K-4079	Cage - Bear-ing	308-9805
5K-4180	Gear - Planet	308-9854
5K-4268	Retainer - Bearing	308-9916
5K-4305	Support As	308-9937
5K-4426	Bushing	308-9831
5K-4787	Bearing - Sleeve	308-9819
5K-4801	Pin	308-9899
5K-4802	Pin	308-9900
5K-4819	Pin	308-9901
5K-7995	Bearing - Sleeve	308-9820
5M-7900	Bolt - Hex Head	311-9349
5P-7807	Bearing - Ball	314-8502
5S-1211	Cover - Valve	314-8665
5S-4557	Bearing	311-9360
5S-9080	Pulley - Alt Drive	264-5883
6H-3957	Bearing - Ball	311-9358
6K-2034	Shaft	297-7249
6K-2036	Rack	299-2045
6K-6001	Pin	308-9902
6P-6739	Shaft - Planet	308-9929
6W-7290	Shaft - Planet	308-9930
7B-0503	Ballstud	308-9801
7G-2513	Gear - Planet	215-1734
7J-9707	Bearing - Sleeve	308-9821
7J-9708	Bearing - Sleeve	299-1964
7J-9731	Bearing - Sleeve	308-9822
7J-9732	Bearing - Sleeve	308-9823
7J-9814	Bearing - Sleeve	308-9824
7K-0078	Bearing - Sleeve	308-9825
7K-0373	Pin As	308-9885
7K-0374	Pin As	308-9886
7K-1818	Cover	308-9844
7K-6260	Shaft - Sector	308-9931
7K-7102	Pin	308-9903
7K-9528	Bearing - Sleeve	308-9828
7K-9604	Bearing - Sleeve	308-9829
7K-9981	Pin As	308-9887
7K-9988	Pin	308-9904
7K-9989	Pin	308-9905
7K-9990	Pin	308-9906
7K-9992	Pin	308-9907
7N-9146	Gear - Fly-wheel Starter	279-4995
7S-7809	Cap As - Radiator	295-6417
8F-9365	Pin	319-3463
8K-0042	Gear - Differ-ential Bevel	308-9850
8M-2549	Rod As - Con-nector	314-8537
9K-0198	Gear - Sun	308-9865
9V-7860	Support As - Front	308-9938

(Continued)

Sales Model 980 (Continued)

Original Part Number	Part Name	Classic Part Number
7T-2036	Cap As - Filter	361-1721

Sales Model 980B

Original Part Number	Part Name	Classic Part Number
111-8015	Gasket As - Head	279-4977
121-7746	Precleaner As	360-2311
129-2339	Spider	308-9936
131-3815	Seal Gp - Basic	325-6193
172-5185	Shaft - Water Pump	325-6201
172-5188	Shaft - Water Pump	325-6202
172-5189	Impeller - Pump	295-5687
172-5190	Impeller - Pump	325-6111
172-6712	Impeller - Pump	325-6112
172-7767	Pump Gp - Water	296-1365
196-0028	Gear As - Idler	364-5259
1M-7250	Bowl - Pre-cleaner	360-2296
1N-3576	Block Gp - Cylinder	279-4978
1N-3958	Elbow	325-6087
1P-4303	Head As - Cylinder	242-3434
1P-9945	Bracket As - Fan	296-1344
1P-9946	Shaft - Fan	325-6194
1P-9952	Impeller - Pump	314-8685
1S-1888	Bracket - Lamp	297-7147
1S-4701	Pulley - Alt	264-5866
1S-8753	Plate - Cou-pling	308-9910
1S-8754	Joint Gp - Univ	308-9873
1T-0662	Turbine - Conv	235-1819
1T-0665	Ring - Clamp	308-9918
1T-1091	Hub - Turbine	308-9869
1V-4838	Link As - Spring	308-9874
1V-5410	Bearing	308-9806
1V-6978	Bolt - Shoul-der	308-9803
1W-4402	Gear - Cam-shaft	279-4981
1W-4405	Gear - Crank-shaft	279-4982
2D-9130	Washer - Thrust	308-9943
2F-5721	Bearing - Ball	311-9354
2J-5649	Pin - Cylinder	256-4782
2K-3592	Boss	314-8501
2K-4177	Pin - Lock	308-9893
2K-4442	Bearing - Sleeve	308-9812
2K-4507	Bearing - Sleeve	325-6021
2K-4512	Bearing - Sleeve	308-9813
2P-1170	Shaft As - Gear	296-1367
2P-1738	Plate As - Oil Pan	325-6164
2P-1739	Tube As - Pump	325-6229
2P-1757	Hub - Fan Pulley	296-1357
2P-1781	Spacer - Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2519	Tube As - Inlet	325-6230
2P-2719	Pipe	363-7454
2P-6128	Pulley	264-5872
2P-6245	Shaft As - Pump	325-6197
2S-4015	Plunger As - Valve	311-9438
2V-3687	Gear - Diff Bevel	308-9849
2V-4374	Joint Gp - Slip	308-9872
2W-1086	Cover As - Cylinder Head	325-6049
2W-2621	Valve - Inlet	247-6892 (Valve), 241-3381 (Valve Kit)
2W-7255	Shaft - Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear - Water Pump	325-6088
3D-5315	Pinion - Diff Bevel	308-9856
3F-4971	Pin	295-5693
3K-0963	Pin - Lock	308-9895
3K-5461	Wheel - Steering	308-9945
3L-1425	Bearing - Ball	311-9356
3S-1262	Retainer	308-9915
3S-8034	Shaft - Planet	308-9926
3V-7427	Housing As	297-7197
4J-1612	Pin	308-9896
4J-3015	Shaft	325-6204
4J-6899	Bearing - Sleeve	308-9815
4K-0299	Bearing - Sleeve	308-9816
4K-0300	Bearing - Sleeve	308-9817
4K-1102	Bearing - Sleeve	325-6010
4K-3004	Bearing - Trunnion Support	314-8632
4K-3128	Bearing - Sleeve	314-8633
4K-8416	Shaft	308-9927
4N-2954	Sleeve - Cam-shaft	299-2059
4N-3281	Line As - Fuel Injector	247-3362
4N-3282	Line As - Fuel Injector	247-3363
4N-3283	Line As - Fuel Injector	247-3364
4N-4577	Muffler As	308-9877
4N-7693	Crankshaft As	242-3439
4N-8814	Line As - Fuel Injector	247-3366
4N-9587	Shield - Heat	297-7260
4P-3546	Valve As - Relief	325-6236
4S-8472	Hood As	296-1355
4V-3044	Plate - Lock	308-9911

(Continued)

Sales Model 980B (Continued)

Original Part Number	Part Name	Classic Part Number
4W-0452	Seal As - Camshaft	325-6191
5D-0470	Valve Gp	314-8549
5F-6393	Shaft	308-9928
5F-7404	Nut - Bearing Lock	308-9878
5G-3612	Cap Gp	295-6419
5J-3492	Bearing - Sleeve	308-9879
5J-4542	Bearing - Sleeve	308-9818
5K-3490	Spacer	308-9933
5K-3491	Spacer	308-9934
5K-3497	Pin	308-9897
5K-3499	Pin - Lower	308-9898
5K-3502	Cap - Lower	308-9835
5K-3967	Yoke As	308-9946
5K-3968	Cage - Bearing	308-9804
5K-4079	Cage - Bearing	308-9805
5K-4180	Gear - Planet	308-9854
5K-4268	Retainer - Bearing	308-9916
5K-4305	Support As	308-9937
5K-4426	Bushing	308-9831
5K-4787	Bearing - Sleeve	308-9819
5K-4801	Pin	308-9899
5K-4802	Pin	308-9900
5K-4819	Pin	308-9901
5K-7995	Bearing - Sleeve	308-9820
5M-7900	Bolt - Hex Head	311-9349
5P-7807	Bearing - Ball	314-8502
5S-1211	Cover - Valve	314-8665
5S-4557	Bearing	311-9360
5S-6795	Chamber As	242-3437
5S-9062	Spacer	363-7463
5S-9080	Pulley - Alt Drive	264-5883
6H-3957	Bearing - Ball	311-9358
6I-1346	Pump Gp - Oil	295-5674
6K-0053	Housing	297-7191
6K-2034	Shaft	297-7249
6K-2036	Rack	299-2045
6K-6001	Pin	308-9902
6N-1036	Gear - Oil Pump	279-4991
6N-1965	Line As - Fuel Injector	250-7535
6N-1966	Line As - Fuel Injector	250-7536
6N-2789	Pulley	264-5886
6N-8413	Housing - Pump	325-6110
6P-6739	Shaft - Planet	308-9929
6W-7290	Shaft - Planet	308-9930
7B-0503	Ballstud	308-9801
7C-4297	Seal As - Camshaft	325-6192
7G-2513	Gear - Planet	215-1734
7J-9344	Bearing - Sleeve	360-2334
7J-9707	Bearing - Sleeve	308-9821
7J-9708	Bearing - Sleeve	299-1964
7J-9731	Bearing - Sleeve	308-9822
7J-9732	Bearing - Sleeve	308-9823
7J-9814	Bearing - Sleeve	308-9824
7K-0078	Bearing - Sleeve	308-9825
7K-0373	Pin As	308-9885
7K-0374	Pin As	308-9886
7K-1818	Cover	308-9844
7K-6260	Shaft - Sector	308-9931
7K-7102	Pin	308-9903
7K-9528	Bearing - Sleeve	308-9828
7K-9604	Bearing - Sleeve	308-9829
7K-9981	Pin As	308-9887
7K-9988	Pin	308-9904
7K-9989	Pin	308-9905
7K-9990	Pin	308-9906
7K-9992	Pin	308-9907
7M-2167	Ring - Governor Control	308-9919
7N-0110	Core As - Oil Cooler	319-3435
7N-1164	Mount As	295-5451
7N-2871	Line As - Fuel Injector	319-8172
7N-2872	Line As - Fuel Injector	319-8173
7N-2874	Line As - Fuel Injector	298-2779
7N-2875	Line As - Fuel Injector	298-2780
7N-2876	Line As - Fuel Injector	298-2781
7N-2949	Pulley	264-5887
7N-2957	Cover - Rad Cap	361-1722
7N-3515	Gear - Camshaft	314-8669
7N-3536	Gear - Fuel	279-4993
7N-5511	Gear As - Idler	233-2180
7N-5910	Impeller - Pump	314-8686
7N-9145	Gear - Flywheel	279-4994
7N-9312	Damper As - Camshaft	299-2005
7N-9805	Pin - Piston	295-6438
7S-3161	Lifter - Valve	279-4996
7S-6723	Bracket - Alternator	299-1978
7S-7809	Cap As - Radiator	295-6417
7S-8443	Muffler	247-2675
7T-2036	Cap As - Filter	361-1721
7W-0450	Gear - Water Pump	279-4997
7W-0507	Gear - Oil Pump Drive	279-4998
7W-0508	Gear - Fuel Pump Drive	296-1351
7W-5687	Hub - Camshaft	314-8684
8F-9365	Pin	319-3463
8H-9806	Gear - Shaft Drive	325-6091
8K-0042	Gear - Differential Bevel	308-9850
8N-0002	Trunnion As	314-8728
8N-0875	Valve - Exhaust	247-6893 (Valve), 241-3381 (Valve Kit)
8N-1187	Head Gp - Cylinder	242-3435
8N-1721	Rod As - Conn	269-5291
8N-3251	Shaft As - Rocker Arm	314-8711
8N-3325	Arm Gp - Rocker	314-8623

(Continued)

Sales Model 980B (Continued)

Original Part Number	Part Name	Classic Part Number
8N-3327	Arm Gp - Rocker	314-8624
8N-5305	Spacer	363-7464
8N-5929	Cover - Water Pump	296-1349
8N-7315	Tube As - Outlet	325-6232
8N-8225	Bearing - Main	314-8652
8N-9733	Line As - Fuel Injector	319-8174

Original Part Number	Part Name	Classic Part Number
8S-0248	Breather As	325-6033
8S-0493	Shaft As - Pump	325-6198
8S-3970	Chamber As	242-3438
8S-7716	Manifold - Exhaust	295-0415
8S-7717	Manifold - Exhaust	261-0894
8S-7718	Manifold - Exhaust	295-0416
9H-2256	Pump Gp	311-9443

Original Part Number	Part Name	Classic Part Number
9K-0198	Gear - Sun	308-9865
9M-4789	Shaft - Gov Control	297-7256
9N-5251	Piston Gp - Basic	250-6557 (Liner Kit)
9N-5769	Cover - Housing	325-6050
9S-6129	Pulley - Alternator Drive	264-5891
9S-8679	Chamber As	325-6042
9V-7860	Support As - Front	308-9938

Sales Model 980C

Original Part Number	Part Name	Classic Part Number
0T-0259	Nut - Bearing Sleeve	311-9431
100-7860	Valve - Inlet	270-4360 (Valve), 270-4362 (Valve Kit)
104-4253	Line As - Fuel Injector	279-4988
104-4254	Line As - Fuel Injector	279-4989
111-8015	Gasket As - Head	279-4977
112-3818	Shaft - Input	302-2698
112-5585	Shaft - Planet	308-9932
112-8041	Carrier - Planet	295-5681
121-7583	Gear - Planet	364-5257
122-9405	Bracket As	325-6005
129-2339	Spider	308-9936
129-3068	Rebuild Kit, W/P (Str Brgs)	363-7455
131-3815	Seal Gp - Basic	325-6193
148-7455	Valve - Exhaust	270-4361
167-8123	Damper As	299-2006
172-5185	Shaft - Water Pump	325-6201
172-5188	Shaft - Water Pump	325-6202
172-5189	Impeller - Pump	295-5687
172-5190	Impeller - Pump	325-6111
172-6712	Impeller - Pump	325-6112

Original Part Number	Part Name	Classic Part Number
172-7767	Pump Gp - Water	296-1365
177-9024	Adapter - Damper	299-1956
180-3767	Adapter - Damper	299-1957
196-0028	Gear As - Idler	364-5259
1A-2846	Cap As - Filler	311-9368
1F-2254	Bushing - Stem	314-8510
1F-4419	Gasket - Cover	311-9393
1N-3576	Block Gp - Cylinder	279-4978
1P-9946	Shaft - Fan	325-6194
1S-1888	Bracket - Lamp	297-7147
1S-4701	Pulley - Alt	264-5866
1V-6342	Gear As	308-9847
1V-8240	Bearing - Sleeve	308-9807
1V-8241	Bearing - Sleeve	308-9808
1V-8242	Bearing - Sleeve	308-9809
1V-8439	Pin As	308-9881
1V-8604	Gear - Ring	308-9853
1V-8606	Gear - Sun	308-9860
1V-8849	Collar	308-9838
1V-8850	Pin	308-9891
1V-8851	Cap	308-9833
1V-8852	Cap	308-9834
1V-8947	Pin As	308-9882
1V-8949	Pin As	308-9883
1V-8953	Pin	308-9892

Original Part Number	Part Name	Classic Part Number
1V-8954	Pin As	361-1696
1V-9143	Bearing - Sleeve	308-9810
1V-9148	Bearing - Sleeve	308-9811
1W-1669	Piston	325-6158
1W-1695	Pump Gp	279-4980
1W-1698	Housing - Transfer Pump	296-1356
1W-4402	Gear - Camshaft	279-4981
1W-4405	Gear - Crankshaft	279-4982
1W-5912	Tappet As - Guide	325-6223
244-1090	Alarm - Back up	360-2345
2D-5658	Bearing - Ball	301-4628
2D-9130	Washer - Thrust	308-9943
2F-5721	Bearing - Ball	311-9354
2K-3592	Boss	314-8501
2N-7942	Spacer	363-7462
2P-1170	Shaft As - Gear	296-1367
2P-1738	Plate As - Oil Pan	325-6164
2P-1739	Tube As - Pump	325-6229
2P-1757	Hub - Fan Pulley	296-1357
2P-1781	Spacer - Oil Pump	325-6214
2P-2519	Tube As - Inlet	325-6230

(Continued)

Sales Model 980C (Continued)

Original Part Number	Part Name	Classic Part Number
2P-5680	Turbine - Converter	308-9942
2P-5693	Housing - Rotating	308-9866
2P-6245	Shaft As - Pump	325-6197
2V-3687	Gear - Diff Bevel	308-9849
2V-4374	Joint Gp - Slip	308-9872
2V-4700	Pin	308-9894
2V-7170	Yoke	308-9948
2V-7198	Pilot As - Recoil Spring	302-2709
2V-7393	Retainer	308-9914
2W-1086	Cover As - Cylinder Head	325-6049
2W-2621	Valve - Inlet	247-6892 (Valve), 241-3381 (Valve Kit)
2W-6757	Trunnion As	295-5678
2W-7255	Shaft - Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear - Water Pump	325-6088
2W-8494	Pulley - Alt	295-5692
3D-5315	Pinion - Diff Bevel	308-9856
3F-7445	Bearing - Sleeve	314-8508
3G-2665	Cover	308-9842
3K-2230	Gear - Planet	219-9658
3L-1425	Bearing - Ball	311-9356
3P-2685	Piston - Clutch	308-9908
3P-2768	Piston - Clutch	308-9909
3P-3059	Gear - Sun	308-9861
3P-3060	Gear - Sun	308-9862
3P-3096	Gear - Sun	308-9863
3P-3242	Shaft - Planet	308-9923
3P-3245	Shaft - Planet	308-9924
3P-3246	Shaft - Planet	308-9925
3P-4850	Gear As - Oil Pump	308-9848
3P-8283	Spacer	325-6215
3S-1262	Retainer	308-9915
3T-3203	Gear - Transfer	302-2675
3V-6648	Pin As	308-9884
4E-3456	Lever As	367-6081
4E-5213	Cover As	299-2000
4E-5882	Shaft - Axle	308-9921
4K-4780	Strip As - Wear	299-2063
4N-2954	Sleeve - Camshaft	299-2059
4N-3714	Chamber, Precom	363-7450
4N-6302	Belt Set - Vee	314-8495
4N-7693	Crankshaft As	242-3439
4P-3546	Valve As - Relief	325-6236
4P-9381	Line As - Fuel Injector	279-4984
4P-9382	Line As - Fuel Injector	279-4985
4P-9385	Line As - Fuel Injector	279-4986
4P-9386	Line As - Fuel Injector	279-4987
4P-9961	Line As - Fuel Injector	325-6115
4S-8472	Hood As	296-1355
4V-2518	Shaft	297-7243
4V-3044	Plate - Lock	308-9911
4V-3680	Bellcrank	308-9802
4V-6156	Saddle As	299-2052
4V-7099	Pin As	361-1698
4V-7105	Pin As	361-1699
4V-8674	Bearing - Bushing	307-1529
4W-0452	Seal As - Camshaft	325-6191
4W-2042	Spacer	325-6217
5D-0470	Valve Gp	314-8549
5F-7404	Nut - Bearing Lock	308-9878
5K-0609	Cover	308-9843
5K-3490	Spacer	308-9933
5K-3491	Spacer	308-9934
5K-3499	Pin - Lower	308-9898
5K-3502	Cap - Lower	308-9835
5K-3967	Yoke As	308-9946
5K-3968	Cage - Bearing	308-9804
5K-4079	Cage - Bearing	308-9805
5K-4268	Retainer - Bearing	308-9916
5K-4305	Support As	308-9937
5K-4426	Bushing	308-9831
5M-7900	Bolt - Hex Head	311-9349
5P-7807	Bearing - Ball	314-8502
5P-8194	Ring - Retaining	308-9920
5S-1211	Cover - Valve	314-8665
5S-4557	Bearing	311-9360
5S-6795	Chamber As	242-3437
5S-9062	Spacer	363-7463
5S-9080	Pulley - Alt Drive	264-5883
5V-8782	Lever As	299-2014
6H-3957	Bearing - Ball	311-9358
6I-1346	Pump Gp - Oil	295-5674
6L-8968	Coupling - Exhaust	311-9381
6N-1036	Gear - Oil Pump	279-4991
6N-1572	Mount As	308-9876
6N-8413	Housing - Pump	325-6110
6N-9743	Support - Muffler	308-9940
6P-6556	Carrier As	308-9836
6P-6739	Shaft - Planet	308-9929
6P-7358	Pump Gp	308-9913
6P-7704	Carrier - Ring	314-8658
6W-0240	Bearing - Brace	297-7143
6W-4281	Yoke - Flange	308-9949
6W-4284	Cage - Bearing	308-9832
6W-7290	Shaft - Planet	308-9930
6W-7331	Cover As	308-9845
6Y-2054	Plate As	302-2695
6Y-4819	Carrier - Planet	296-1348
6Y-4840	Plate As	297-7233
7C-0942	Adapter As	302-2636
7C-3039	Core, Oil Cooler	363-7451
7C-4297	Seal As - Camshaft	325-6192
7G-2476	Gear - Planet	223-4816
7G-2516	Gear - Planet	283-5203
7G-2830	Ring - Seal	295-6441
7G-3457	Gear - Planet	308-9857
7G-5618	Manifold As	283-5204
7G-7218	Carrier - Planet	283-5205

(Continued)

Sales Model 980C (Continued)

Original Part Number	Part Name	Classic Part Number
7G-7724	Piston - Clutch	283-5206
7H-0602	Dog - Clutch	314-8515
7M-4603	Body - Fuel Valve	311-9348
7M-4926	Retainer - Pin	314-8538
7N-0110	Core As - Oil Cooler	319-3435
7N-2957	Cover - Rad Cap	361-1722
7N-5910	Impeller - Pump	314-8686
7N-9146	Gear - Fly-wheel Starter	279-4995
7N-9674	Muffler As	360-7892
7N-9805	Pin - Piston	295-6438
7S-3161	Lifter - Valve	279-4996
7S-7809	Cap As - Radiator	295-6417
7T-2036	Cap As - Filter	361-1721
7T-9370	Gear - Sun	283-5207
7V-6790	Shaft - Bevel Pinion	308-9922
7W-0450	Gear - Water Pump	279-4997
7W-0507	Gear - Oil Pump Drive	279-4998
7W-0508	Gear - Fuel Pump Drive	296-1351
7W-1902	Adapter - Fuel Nozzle	299-1955
7W-2164	Core As - Oil Cooler	299-1996
8B-5972	Bearing - Ball	314-8503
8F-5104	Screen As - Oil Pan	314-8539
8H-1993	Valve - Inlet	256-4765 (Valve Kit)
8H-1994	Valve - Ex-haust	256-4765 (Valve Kit)
8H-2810	Case As - Filter	314-8512
8K-0042	Gear - Differ-ential Bevel	308-9850
8M-0874	Plunger As - Valve	311-9439
8M-6676	Cylinder - Adjustable	226-4960
8N-0875	Valve - Ex-haust	247-6893 (Valve), 241-3381 (Valve Kit)
8N-1187	Head Gp - Cylinder	242-3435
8N-1214	Mount As	325-6125
8N-1721	Rod As - Conn	269-5291
8N-2510	Shaft	325-6208
8N-2641	Sleeve	325-6210
8N-3251	Shaft As - Rocker Arm	314-8711
8N-3325	Arm Gp - Rocker	314-8623
8N-3327	Arm Gp - Rocker	314-8624
8N-5305	Spacer	363-7464
8N-5779	Coupling - Exhaust	325-6047
8N-5929	Cover - Water Pump	296-1349
8N-6796	Head Gp - Cylinder	269-5290
8N-7315	Tube As - Outlet	325-6232
8N-8225	Bearing - Main	314-8652
8P-0514	Yoke As	308-9947
8P-0769	Hub - Turbine	308-9870
8P-1892	Piston - Clutch	283-5208
8P-1916	Gear - Planet	283-5209
8P-1918	Gear - Planet	283-5210
8P-1919	Gear - Planet	300-2579
8P-2042	Shaft - Planet	283-5211
8P-9507	Piston - Clutch	283-5212
8R-3921	Collet	308-9839
8R-3943	Collet	308-9840
8R-3946	Collet	308-9841
8R-4821	Carrier - Planet	308-9837
8R-7425	Retainer	308-9917
8R-9798	Plate - Lock	308-9912
8S-0248	Breather As	325-6033
8S-0493	Shaft As - Pump	325-6198
8S-3970	Chamber As	242-3438
8V-1613	Lever	299-2017
8V-1624	Lever	299-2019
8V-6382	Hub As	308-9868
8V-6384	Spacer As	308-9935
9C-0624	Pin As	361-1709
9C-0625	Pin As	308-9888
9C-8074	Gear - Planet	308-9858
9C-8075	Gear - Sun	308-9864
9C-8277	Gear - Bevel	308-9851
9G-0280	Piston - Clutch	283-5213
9G-0284	Housing - Clutch	283-5214
9G-0285	Piston - Clutch	283-5215
9G-0289	Shaft - Planet	283-5216
9G-0290	Hub - Clutch	283-5217
9H-7670	Piston	226-4961
9J-5875	Bearing - Sleeve	308-9830
9K-8428	Pin As	241-2533
9K-8757	Rod End - Bearing	311-9361
9N-5769	Cover - Hous-ing	325-6050
9N-6611	Pulley	325-6177
9P-3731	Carrier - Planet	301-4767
9P-7757	Gear - Sun	283-5218
9P-8283	Plate - Clutch	296-1364
9P-8521	Gear - Ring	296-1353
9P-8623	Shaft - Planet	314-8719
9P-8624	Shaft - Planet	295-5446
9P-8626	Gear - Sun	283-5219
9P-9031	Gear - Sun	283-5220
9S-8493	Bolt - Con-necting Rod	311-9351
9S-8679	Chamber As	325-6042
9V-7860	Support As - Front	308-9938
9W-3605	Carrier - Ring	314-8662
9W-4702	Stator - Con-verter	308-9939
9W-6433	Impeller - Converter	308-9871
9W-6435	Flange - Drive	308-9846
9W-8270	Gear - Ring	308-9859
9W-8433	Shaft As - Output	302-4249
9W-8437	Gear - Sun	283-5222
9W-9069	Shaft - Input	302-2715
9Y-2988	Breather As	361-1716

Cornerstone Brochure

Media Number	Description	Languages Available
PEDP9129	Cat® Classic™ Parts - Another Option for Older Cat Machines	English
PFDP9129	Cat Classic Parts - Another Option for Older Cat Machines	French
PPDP9129	Cat Classic Parts - Another Option for Older Cat Machines	Portuguese
PSDP9129	Cat Classic Parts - Another Option for Older Cat Machines	Spanish

Datasheets

Media Number	Description	Languages Available
PEHJ0160	Cat Classic Parts for Track-Type Tractors	English
PEHP9565	Cat Classic Parts	English
PEHJ0178	Cat Classic Parts for Wheel Loaders	English
PEHJ0176	Cat Classic Parts for Hydraulic Excavators	English
PEHJ0132	Cat Classic Parts for 3300 DI Engines	English
PEHJ0144	Cat Classic Parts for Motor Graders	English
PEHJ0188	Cat Classic Parts for Commercial Engines	English
PFHJ0188	Cat Classic Parts for Commercial Engines	French
PPHJ0188	Cat Classic Parts for Commercial Engines	Portuguese
PSHJ0188	Cat Classic Parts for Commercial Engines	Spanish

Tri-folds

Media Number	Description	Languages Available
PECJ0011	D300/3300 PC Engine Quick Reference Card	English
PECJ0034	Customer Quick Reference Guide	English
PECJ0015	3300 DI Engine Quick Reference Guide	English
PECJ0037	Commercial Engines Quick Reference Guide	English
PFCJ0037	Commercial Engines Quick Reference Guide	French
PPCJ0037	Commercial Engines Quick Reference Guide	Portuguese
PSCJ0037	Commercial Engines Quick Reference Guide	Spanish

Counter Cards

Media Number	Description	Languages Available
PEKJ0008	Cat Classic Parts 3300 DI Engine Parts	English
PEKJ0013	Cat Classic Parts for High-Hour Commercial Engines	English
PFKJ0013	Cat Classic Parts for High-Hour Commercial Engines	French
PPKJ0013	Cat Classic Parts for High-Hour Commercial Engines	Portuguese
PSKJ0013	Cat Classic Parts for High-Hour Commercial Engines	Spanish

Posters/Banners

Media Number	Description	Languages Available
PEPJ0086	Cat Classic 3300 DI Engine Parts	English
PEPJ0094	Dealer Services Campaign - Cat Classic Parts	English
PEPJ0141	It's Time for Cat Classic Parts	English
PEPJ0142	Power Up Cost Down	English

CDs

Media Number	Description	Languages Available
PEWJ0124	Cat Classic Parts 3300 DI Engine Parts Promo Kit	English
PERJ0074	Cat Classic Parts for Commercial Engines Promo Kit	English

Sales Aid - DEALER USE ONLY

Media Number	Description	Languages Available
PEWJ0050	What Are Cat Classic Parts?	English
PEWJ0143	Cat Classic Parts Cutaway Engine	English

DLMS Course - DEALER USE ONLY

Course Number	Description	Languages Available
20269	Parts Pro - Cat® Classic™ Parts	English

Part Numbers Beginning with 0

Original Part Number	Part Name	Classic Part Number
054-2213	Spider and Bearing As	347-0464
054-6549	Pinion - Planetary	347-0478
055-1260	Housing Bk - Outer	347-0479
055-1986	Seal - Lip type	347-0465
086-0523	Pin	314-8696
087-5499	Bearing - Sleeve	314-8640
087-5533	Bearing - Sleeve	314-8628
087-5802	Link - Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
087-5847	Bearing - Sleeve	314-8629
094-1509	Shaft - Planet	360-2273
095-2927	Valve - Fill	360-2292
095-9291	Valve - Fill	360-2293
096-7911	Bearing - Sleeve	314-8653
096-7912	Bearing - Sleeve	314-8654
096-7913	Bearing - Sleeve	314-8655
099-0718	Bearing - Sleeve	360-2313
099-0721	Bearing - Sleeve	314-8641
0T-0259	Nut - Bearing Sleeve	311-9431

Part Numbers Beginning with 1

Original Part Number	Part Name	Classic Part Number
100-3431	Stop	314-8723
100-7860	Valve - Inlet	270-4360 (Valve), 270-4362 (Valve Kit)
102-1561	Lifter As - Valve	311-9402
102-4560	Bearing - Sleeve	347-0469
102-8112	Cylinder - Adjustable	360-2276
104-4253	Line As - Fuel Injector	279-4988
104-4254	Line As - Fuel Injector	279-4989
105-3196	Motor Gp - Gerotor	282-6547
106-7131	Shaft	288-8714
107-2139	Pin As	360-2352
108-0980	Pin As	314-8692
109-5562	Shaft	275-5272
109-9463	Muffler As	360-7864
110-4652	Housing	302-2683
110-7058	Carrier - Planet	301-4630
110-7059	Carrier - Planet	301-4636
110-7209	Carrier As	301-5237
111-0416	Guard As (rh)	325-6096
111-0419	Guard As (lh)	325-6097
111-0431	Guard As	325-6098
111-8015	Gasket As - Head	279-4977
112-1773	Piston	347-0462
112-3249	Muffler As	247-2661
112-3818	Shaft - Input	302-2698
112-5495	Joint Gp - Univ	297-4858
112-5585	Shaft - Planet	308-9932
112-8041	Carrier - Planet	295-5681
112-9629	Pin	347-0470
114-9036	Shaft - Input	297-4859
115-0637	Pump Gp	226-0160
115-4204	Pulley As - Idler	301-5219
115-6427	Spring	301-4776
115-6429	Cylinder	301-4679
117-1024	Link As.	188-5595
117-1616	Segment Gp - Sprocket	260-5851 (sprocket group)
118-1611	Roller Gp - SF	175-8024
118-1612	Roller Gp - DF	175-8025
118-1614	Roller Gp - SF	175-8035
118-1615	Roller Gp - DF	175-8036
118-1617	Roller Gp - SF	188-5272
118-1618	Roller Gp - DF	188-5271
118-1619	Roller Gp - Track	188-5257
118-1620	Roller Gp - DF	188-5258
118-1623	Roller Gp - Track	188-5596
118-1625	Roller Gp - Track	188-5597
118-9906	Muffler As	360-7865
119-2863	Pin	314-8698
119-7042	Shaft	347-0480
119-7047	Seal	347-0481
121-7583	Gear - Planet	364-5257
121-7746	Precleaner As	360-2311
122-1881	Plate - Clutch	347-0475
122-5076	Rod	301-4569
122-5077	Cylinder	301-4673
122-5178	Piston As	301-5252
122-9405	Bracket As	325-6005
124-3240	Pin	282-6548
125-2950	Gear As	301-4762
126-5061	Shoe -Track	335-5478
126-5062	Shoe -Track	286-9827
126-7130	Shaft As	275-5300
127-3365	Joint Gp - Slip	367-6067
127-5537	Core As	325-6045
127-5969	Gear - Sun	301-4761
127-5970	Gear - Planet	301-3398
127-8592	Muffler As	347-0463
128-0307	Plate	325-6165
128-9863	Bearing - Sleeve	314-8630
128-9882	Bearing - Sleeve	314-8642
128-9883	Bearing - Sleeve	360-2314
128-9884	Bearing - Sleeve	360-2315
129-2339	Spider	308-9936
129-2381	Gear - Planet	275-5274
129-3068	Rebuild Kit, W/P (Str Brgs)	363-7455
129-7768	Bearing - Sleeve	360-2316

(Continued)

Part Numbers Beginning with 1 (Continued)

Original Part Number	Part Name	Classic Part Number
130-1637	Shaft	347-0471
130-6856	Precleaner As	361-1717
130-6879	Seal	347-0482
130-9293	Rod	314-8708
131-3736	Socket Gp - Basic	325-6211
131-3737	Socket As	282-6626
131-3738	Socket As	282-6627
131-3815	Seal Gp - Basic	325-6193
131-7736	Support As - Engine	325-6222
137-2819	Bearing - Sleeve	360-2317
137-2820	Bearing - Sleeve	360-2318
137-2919	Bearing - Sleeve	360-2319
137-3060	Bearing - Sleeve	360-2320
141-6137	Socket Gp	325-6212
141-6138	Socket Gp	325-6213
145-3030	Cylinder	360-2260
147-3309	Spindle	282-6628
147-3400	Spindle	282-6549
148-4634	Shaft - Planet	360-2274
148-7455	Valve - Exhaust	270-4361
153-3580	Shaft	299-2055
154-3662	Link As	257-8020
154-3667	Link As	260-1509
154-3676	Link As	257-8021
155-2819	Ejector As - Exhaust	325-6078
160-1014	Pin As	347-0473
160-1400	Yoke	319-3479
160-6305	Cap - Bearing	295-5686
160-6308	Cap - Bearing	325-6036
163-4143	Roller Gp - SF	286-9823
164-1047	Idler Gp	275-3581
165-4262	Body As - Piston	270-4351
165-7211	Strip	325-6219
167-2329	Seal - U-cup	347-0466
167-8123	Damper As	299-2006
170-0560	Rebuild Kit	363-7458
172-5185	Shaft - Water Pump	325-6201
172-5188	Shaft - Water Pump	325-6202
172-5189	Impeller - Pump	295-5687
172-5190	Impeller - Pump	325-6111
172-6712	Impeller - Pump	325-6112
172-7767	Pump Gp - Water	296-1365
175-4070	Bushing - Sleeve	347-0484
176-9273	Piston	297-4860
177-9024	Adapter - Damper	299-1956
179-6152	Bearing	361-1704
180-3767	Adapter - Damper	299-1957
185-4037	Idler Gp	275-3581
185-6151	Segment, Segment Gp	260-1510, 260-1511 (sprocket group)
186-4118	Gear - Planet	347-0483
186-4440	Shaft - Planet	364-5261
190-7396	Segment Gp	275-3576 (sprocket group), 275-4087 segment
190-8609	Valve - Fill	360-2288
194-1608	Link As	308-6230
194-1609	Link As	308-6229
196-0028	Gear As - Idler	364-5259
1A-2846	Cap As - Filler	311-9368
1D-3996	Fork - Knuckle	228-9428
1F-2254	Bushing - Stem	314-8510
1F-4419	Gasket - Cover	311-9393
1H-4106	Pin As - Drawbar	325-6126
1H-8037	Yoke - Fitting	228-9415
1H-8262	Shaft	226-8016
1H-8382	Gear - Oil Pump Drive	226-6103
1H-8937	Drumbrake	226-7993
1H-8938	Lever	226-8028
1J-1738	Pin	319-3448
1J-6744	Bearing	361-1705
1J-6746	Pin	256-4817
1J-6747	Pin	367-6078
1J-6749	Screw - Adjustable	256-4824
1K-7974	Gear - Transmission Shaft	226-7984
1M-0176	Flange - Drum	223-4810
1M-0598	Gear - Transmission	213-8636
1M-1408	Nut (5/8-18)	200-9150
1M-1618	Collar As - Shift	226-8029
1M-1663	Collar As - Retain	226-8030
1M-1698	Gear - Sliding	215-1659
1M-1809	Shaft - Tr Sprocket	231-3314
1M-1930	Cage - Pinion Bearing	217-7727
1M-1947	Support As	226-6096
1M-2607	Cage - Bearing	239-7970
1M-2626	Cage - Carrier Bearing	216-7458
1M-2635	Housing - Clutch	216-3549
1M-2637	Housing - Clutch	216-3550
1M-3925	Gear - Shaft Idler	216-7459
1M-4153	Carrier - Planet	213-1114
1M-4155	Gear - Ring	214-0519
1M-4156	Gear - Ring	214-0520
1M-4167	Shaft - Planet	219-9700
1M-4171	Cage - Bearing	216-7460
1M-4344	Cage As	216-7466
1M-4486	Piston - Clutch	215-1660
1M-5151	Pinion - Bevel	215-1661
1M-5165	Pinion - Final Drive	231-8766
1M-5270	Pipe - Extension	367-6065
1M-6128	Manifold - Exhaust	261-0906
1M-6603	Gear - Transfer	217-7720
1M-6604	Gear - Transfer	217-7715
1M-7250	Bowl - Precleaner	360-2296
1M-8647	Housing As	215-1662

(Continued)

Part Numbers Beginning with 1 (Continued)

Original Part Number	Part Name	Classic Part Number
1M-9029	Guard	226-0219
1M-9177	Flywheel	226-6112
1M-9444	Retainer - Spring	299-2046
1N-2936	Muffler As	298-2782
1N-2946	Extension - Exh	367-6064
1N-3576	Block Gp - Cylinder	279-4978
1N-3958	Elbow	325-6087
1N-4304	Head Gp - Cylinder	269-8761
1N-5943	Manifold - Upper	311-9429
1N-7478	Manifold - Front	311-9428
1P-0005	Pump Gp - Fuel Transfer	256-4756
1P-0009	Rod As - Conn	311-9450
1P-0320	Retainer - Bearing	226-5987
1P-0579	Housing As	219-9678
1P-0963	Guard As - Roller	226-0179
1P-0965	Gear - Bevel	213-8215
1P-1006	Strip - Guard	226-0245
1P-1216	Manifold - Exhaust	261-0902
1P-1605	Gear - Forward	215-1663
1P-1608	Gear - Forward	302-2707
1P-1636	Lever As	226-8013
1P-1721	Gear - Balance	298-2769
1P-1722	Gear - Balance	298-2770
1P-1758	Bushing - Stem	311-9350
1P-1897	Gear - Final Drive	215-1670
1P-1931	Shaft - Steer	227-4772
1P-2187	Pump Gp	299-2044
1P-3759	Rod Gp - Recoil	302-2713
1P-4145	Valve Gp - Press	247-4436
1P-4231	Pump Gp - Gear	226-0156
1P-4303	Head As - Cylinder	242-3434
1P-5262	Cage - Bearing	226-5989
1P-5480	Cover As - End	299-1998
1P-6160	Gear - Pump Driven	231-8760
1P-6265	Gear - Bevel	221-9177
1P-6273	Rod Gp - Recoil	226-4847
1P-6752	Pump Gp	226-0161
1P-7044	Cage	226-7975
1P-7590	Support As	213-4400
1P-8005	Gasket - Chamber	314-8527
1P-8554	Coupling - Exhaust	325-6052
1P-8717	Roller Gp - Carrier	188-5600
1P-8835	Shaft As	215-1672
1P-9024	Spring - Equalizer	231-3311
1P-9663	Carrier - Bearing	217-7731
1P-9807	Shoe -Track	188-5333
1P-9808	Shoe -Track	175-8802
1P-9809	Shoe -Track	175-8882
1P-9810	Shoe -Track	188-5334
1P-9945	Bracket As - Fan	296-1344
1P-9946	Shaft - Fan	325-6194
1P-9952	Impeller - Pump	314-8685
1P-9989	Pipe	363-7453
1Q-4983	Shoe - Track	289-5117
1S-0876	Bolt - Spring	226-0224
1S-1532	Flange - Shaft	215-1673
1S-1801	Shaft As - Transmission	215-1674
1S-1859	Bolt - Track	188-5633
1S-1860	Nut (3/4-16)	188-5856
1S-1888	Bracket - Lamp	297-7147
1S-1967	Chamber As	247-3291
1S-1970	Chamber As	247-3292
1S-2268	Piston	226-2726
1S-2269	Sleeve	226-2720
1S-4701	Pulley - Alt	264-5866
1S-5315	Cap As - Brace Bearing	226-4848
1S-5331	Cylinder - Adjustable	226-0214
1S-5738	Insert - Seat Exhaust	311-9396
1S-6422	Pilot As - Spring	226-4849
1S-7114	Bolt	314-8500
1S-8186	Idler As.	188-5268
1S-8734	Bracket - Roller	226-0212
1S-8753	Plate - Coupling	308-9910
1S-8754	Joint Gp - Univ	308-9873
1S-8764	Ring - Flywheel Clutch Adjustable	226-8014
1T-0020	Wheel - Turbine	297-4862
1T-0224	Carrier - Ring	239-7928
1T-0228	Housing - Rotating	216-7467
1T-0231	Retainer - Bearing	319-3471
1T-0237	Flange As - Output	239-7929
1T-0256	Gear - Pump Drive	239-7930
1T-0300	Converter As	235-1803 (Repair Kit)
1T-0421	Flange As - Output	295-5442
1T-0436	Gear - Pump Drive	247-3367
1T-0437	Housing - Rotating	295-5685
1T-0438	Retainer - Bearing	295-0410
1T-0443	Carrier As - Guide	247-3368
1T-0447	Carrier - Ring	295-0409
1T-0521	Retainer - Bearing	325-6180
1T-0553	Gear As - Pump Drive	226-5983
1T-0595	Carrier - Wheel	239-7939
1T-0611	Converter As	235-1804 (Repair Kit)
1T-0662	Turbine - Conv	235-1819
1T-0665	Ring - Clamp	308-9918
1T-0670	Converter As	235-1805 (Repair Kit)

(Continued)

Part Numbers Beginning with 1 (Continued)

Original Part Number	Part Name	Classic Part Number
1T-0699	Impeller - Converter	235-1808
1T-0724	Impeller - Converter	216-7469
1T-0727	Hub - Impeller	229-8236
1T-0851	Impeller - Converter	253-1418
1T-0930	Torque Converter	235-0913 (Repair Kit)
1T-0947	Flange As - Input	229-8224
1T-0949	Housing - Rotating	217-7732
1T-0972	Carrier As	216-7470
1T-0987	Hub - Impeller	247-4118
1T-1089	Hub - Turbine	216-7471
1T-1091	Hub - Turbine	308-9869
1T-1255	Torque Converter	235-1806 (Repair Kit)
1T-1285	Gear As - Drive	217-7734
1T-1331	Stator - Converter	229-8237
1T-1350	Torque Converter	235-0912 (Repair Kit)
1T-1386	Yoke - Univ Joint	325-6239
1T-1389	Carrier - Bearing	247-4124
1T-1428	Retainer - Bearing	300-2587
1T-1691	Impeller - Converter	297-4863
1T-1790	Carrier As	296-1347
1T-1880	Carrier - Ring	295-0408
1T-1987	Housing - Rotating	297-4864
1T-1993	Wheel - Turbine	235-0920
1T-2050	Carrier As - Stat	325-6040
1T-2052	Stator As	295-5683
1U-0105	Brace As	295-5684
1U-0159	Pin	325-6134
1U-0612	Pin	325-6135
1U-0725	Retainer	314-8707
1U-0872	Pin	325-6136
1U-0873	Pin	325-6137
1U-0899	Pin	296-1363

Original Part Number	Part Name	Classic Part Number
1U-0928	Screw - Adjusting	325-6187
1U-0990	Pin	325-6138
1U-1204	Trunnion	325-6224
1U-1267	Brace As	296-1343
1U-2738	Piston As	367-6074
1U-4103	Trunnion	295-5680
1V-0557	Shoe - Track	288-6678
1V-0940	Holder - Bearing Cage	216-7472
1V-1080	Housing - Bearing Spt	260-0775
1V-1409	Carrier - Planet	253-1423
1V-1554	Spindle	219-2972
1V-1687	Wheel	226-5990
1V-2281	Carrier - Planet	226-5984
1V-2992	Gear - Diff Bevel	224-1301
1V-3242	Cage - Release Bearing	216-7475
1V-3335	Carrier - Planet	253-1424
1V-3676	Case - Drive Gear	216-7799
1V-3677	Case - Final Drive Gear	216-7802
1V-3995	Pin	319-3449
1V-4718	Spindle	223-4817
1V-4838	Link As - Spring	308-9874
1V-5410	Bearing	308-9806
1V-5724	Diff Gp	260-0776
1V-5744	Pin	241-2554
1V-6342	Gear As	308-9847
1V-6978	Bolt - Shoulder	308-9803
1V-7556	Support	216-7804
1V-8240	Bearing - Sleeve	308-9807
1V-8241	Bearing - Sleeve	308-9808
1V-8242	Bearing - Sleeve	308-9809
1V-8439	Pin As	308-9881
1V-8604	Gear - Ring	308-9853
1V-8606	Gear - Sun	308-9860
1V-8655	Lever As	226-5991
1V-8849	Collar	308-9838
1V-8850	Pin	308-9891

Original Part Number	Part Name	Classic Part Number
1V-8851	Cap	308-9833
1V-8852	Cap	308-9834
1V-8947	Pin As	308-9882
1V-8949	Pin As	308-9883
1V-8953	Pin	308-9892
1V-8954	Pin As	361-1696
1V-9143	Bearing - Sleeve	308-9810
1V-9148	Bearing - Sleeve	308-9811
1V-9208	Link As - Rear	299-2020
1W-0777	Muffler As	247-2662
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1695	Pump Gp	279-4980
1W-1698	Housing - Transfer Pump	296-1356
1W-1766	Muffler As	298-2783
1W-2491	Muffler As	360-7871
1W-2572	Muffler As	247-2663
1W-2870	Shaft As - Balance	314-8715
1W-2871	Shaft As - Balance	314-8716
1W-3062	Retainer As	311-9445
1W-4369	Pulley - Alt	296-1340
1W-4402	Gear - Camshaft	279-4981
1W-4405	Gear - Crankshaft	279-4982
1W-4407	Hub - Fan Pulley	296-1358
1W-4623	Muffler As	360-9622
1W-4737	Gear - Camshaft	295-5688
1W-4738	Bearing - Sleeve	325-6020
1W-4740	Gear As - Drive	295-5689
1W-4746	Retainer - Gear	295-5690
1W-5105	Ring Gp - Piston	311-9446
1W-5912	Tappet As - Guide	325-6223
1W-6541	Plunger As	325-6173
1W-7940	Spider As - Fan	295-5443
1W-9191	Line As - Fuel Injector	311-9403

(Continued)

Part Numbers Beginning with 1 (Continued)

Original Part Number	Part Name	Classic Part Number
1W-9192	Line As - Fuel Injector	311-9404
1W-9193	Line As - Fuel Injector	311-9405
1W-9194	Line As - Fuel Injector	311-9406
1W-9195	Line As - Fuel Injector	311-9407
1W-9196	Line As - Fuel Injector	311-9408
1W-9197	Line As - Fuel Injector	311-9409
1W-9198	Line As - Fuel Injector	311-9410
1W-9201	Line As - Fuel Injector	311-9411
1W-9202	Line As - Fuel Injector	311-9412
1W-9203	Line As - Fuel Injector	311-9413
1W-9204	Line As - Fuel Injector	311-9414
1W-9205	Line As - Fuel Injector	311-9415
1W-9206	Line As - Fuel Injector	311-9416
1W-9207	Line As - Fuel Injector	311-9417
1W-9208	Line As - Fuel Injector	311-9418
1W-9209	Line As - Fuel Injector	311-9419
1W-9210	Line As - Fuel Injector	311-9420
1W-9211	Line As - Fuel Injector	311-9421
1W-9212	Line As - Fuel Injector	311-9422
1W-9229	Muffler As	302-4282

Part Numbers Beginning with 2

Original Part Number	Part Name	Classic Part Number
208-5026	Pin	325-6133
223-3095	Gauge As	360-2295
227-0620	Gauge As	360-2295
227-6228	Cage	360-2343
227-6789	Bearing - Sleeve	360-2322
228-5621	Bearing - Sleeve	360-2323
229-2949	Rod As - Track	347-0486
229-2950	Rod As - Track	347-0487
236-6271	Bearing - Sleeve	360-2324
236-7724	Retainer	299-2048
236-9861	Link As	175-8555
236-9864	Link As	188-5527
236-9866	Link As.	188-5588
237-2252	Bearing - Sleeve	347-0474
238-9951	Link As	290-6589
239-9956	Brake Disc	347-0485
240-2913	Bearing - Sleeve	360-2325
244-1090	Alarm - Back up	360-2345
246-5228	Rim	289-2207
248-2041	Rim	289-2211
248-7143	Idler Gp	286-9830
250-2402	Pin As	360-2351
253-4393	Muffler - Converter	301-7975
253-4426	Muffler - Converter	301-7974
258-2308	Bearing - Sleeve	325-6019
260-7799	Pinion - Circle Drv	367-6094
281-8338	Roller - DF	275-3580
281-8339	Roller - SF	275-3579
2B-3708	Chamber As	247-3293
2B-8824	Drum	216-7817
2D-1345	Drum - Brake	228-9430
2D-1659	Rack - Shift	228-9431
2D-3188	Yoke	365-8822
2D-3467	Hub - Final Drive Gear	228-9396
2D-3609	Shaft - Final Drive Pinion	228-8919
2D-4010	Adjuster - Bearing	228-8916
2D-4205	Block - Pivot	228-9432
2D-4209	Pin - Pivot	228-9434
2D-4211	Arm - Steering	228-9435
2D-4215	Knuckle - Rh	228-9436
2D-4216	Knuckle - Lh	228-9437
2D-5658	Bearing - Ball	301-4628
2D-5795	Sleeve - Thrust	243-0360
2D-5799	Pinion - Reverse	243-0342
2D-5961	Pin - Axle Pivot	228-9438
2D-6381	Pinion	228-8915
2D-6382	Gear - Worm	228-9558
2D-7694	Shaft - Pivot	256-4774
2D-7933	Cover - Circle Rev	243-0340
2D-8212	Plate As - Press	229-1582
2D-9130	Washer - Thrust	308-9943
2F-0025	Tube	325-6233
2F-5721	Bearing - Ball	311-9354
2F-5894	Drum - Brake	228-9439
2F-5969	Collar - Coupling	228-9440
2F-5970	Collar - Coupling	228-9441
2F-6046	Pinion - Reduction	228-9442
2F-6050	Gear - Reduction	229-1584
2F-6051	Gear	229-1585
2F-6053	Gear - Reduction	228-9443
2F-6057	Gear - Reduction	228-9444
2F-7576	Shaft - Sprocket	226-6071
2F-7577	Shaft	226-6072
2F-8001	Shaft - Worm	228-9445
2F-9047	Block - Pivot	228-9446
2F-9074	Link - Tie Bar	228-9447
2G-2858	Cap - Pivot	243-0345
2G-4187	Shell - Bearing	245-5794

(Continued)

Part Numbers Beginning with 2 (Continued)

Original Part Number	Part Name	Classic Part Number
2G-5876	Housing - Drive	302-2684
2G-6157	Pin	282-6550
2G-6336	Hub - Brake	282-6551
2G-6375	Shaft - Drive	275-5282
2G-6377	Sprocket	275-5286
2G-7829	Housing As - Drive	297-7196
2G-8238	Yoke As	282-6631
2G-8239	Yoke As	282-6632
2G-8609	Pin	319-3450
2G-8612	Pin	282-6552
2G-8613	Pin	282-6553
2G-8616	Pin	282-6554
2G-8617	Pin	282-6555
2G-8618	Pin	299-2031
2G-8620	Pin	282-6556
2G-8621	Pin	282-6557
2G-8622	Pin	299-2032
2G-8625	Pin	282-6558
2G-8628	Pin	282-6559
2G-8629	Pin	282-6560
2G-8633	Pin	282-6561
2G-8736	Bearing - Sleeve	299-1959
2G-8769	Pin	282-6562
2G-8872	Shaft - Bevel	275-5271
2G-9098	Cap	300-2573
2H-4338	Plate - Pressure	226-8010
2H-4450	Washer - Thrust	325-6237
2H-4482	Collar	229-8218
2H-5046	Link - Flycam	299-2024
2H-6776	Plate - Pressure	226-8011
2H-6777	Plate - Flywheel	226-8012
2J-1506	Pin	319-3451
2J-2622	Bracket	256-4826
2J-3271	Pin	319-3452
2J-5394	Collar	256-4779
2J-5462	Trunnion	297-7264
2J-5468	Pin - Pivot	256-4781
2J-5531	Collar	256-4780
2J-5596	Pin - Pivot	297-7211
2J-5649	Pin - Cylinder	256-4782
2J-5662	Shaft - Pivot	256-4775
2J-8489	Bearing - Sleeve	295-5691
2K-0535	Nut	299-2026
2K-0714	Plate - Thrust	299-2040
2K-3592	Boss	314-8501
2K-3632	Yoke As	297-4866
2K-4177	Pin - Lock	308-9893
2K-4442	Bearing - Sleeve	308-9812
2K-4502	Bearing - Sleeve	299-1986
2K-4507	Bearing - Sleeve	325-6021
2K-4512	Bearing - Sleeve	308-9813
2K-4513	Bearing - Sleeve	308-9814
2K-5073	Bushing	299-1989
2K-5977	Yoke	226-5992
2K-6000	Shaft - Planet	221-9106
2K-6001	Shaft - Planet	221-9107
2K-6413	Pin	360-2270
2K-7418	Pin	241-2572
2K-8753	Gear - Diff	253-1432
2K-8754	Gear - Diff Bevel	253-1433
2L-4731	Adapter - Housing	311-9343
2M-0125	Cylinder - Adjustable	226-0215
2M-0365	Stop - Spring Rh	226-0230
2M-0366	Stop - Spring Lh	226-0231
2M-0369	Pilot - Spring Recoil	226-0226
2M-0398	Sleeve - Bolt	226-0235
2M-1086	Plate As - Press	226-8023
2M-1129	Cap - Support	239-7974
2M-2150	Nut - Spanner	239-7965
2M-2290	Bracket - Ring	299-1979
2M-2415	Guard-idler - Rh	226-4931
2M-2416	Guard-idler - Lh	226-4933
2M-2417	Guard-spring - Rh	226-4934
2M-2418	Guard-spring - Lh	226-4935
2M-3339	Piston - Clutch	221-7944
2M-4668	Retainer - Guard	297-4867
2M-5588	Gear - Final Drive	239-7936
2M-5589	Pinion - Final Drive	239-7942
2M-6920	Hub - Steering	239-7968
2M-6960	Cage - Gear Bearing	239-7971
2M-6984	Drum	239-7946
2M-8297	Pinion - Final Drive	218-4429
2M-8304	Shaft - Sprocket	221-1038
2M-8762	Drum - Steering	239-7944
2N-3220	Gear - Oil Pump Drive	311-9392
2N-3227	Bracket - Lft Guide	311-9367
2N-7194	Cap - Main Bearing	311-9369
2N-7224	Cap As - Main Bearing	311-9370
2N-7942	Spacer	363-7462
2N-8519	Guide - Spring	314-8525
2N-9297	Retainer - Spring	314-8535
2P-0483	Chamber As	256-4760
2P-0484	Chamber As	247-3296
2P-1005	Bearing - Sleeve	296-1342
2P-1126	Pulley - Camshaft	264-5868
2P-1129	Pulley - Tightener	264-5869
2P-1170	Shaft As - Gear	296-1367
2P-1438	Pipe - Exhaust Ext	325-6157
2P-1502	Gear - Shaft	214-0956
2P-1503	Gear - First	213-8637
2P-1554	Gear - Ring	239-7931
2P-1604	Piston - Steering	219-9694
2P-1605	Pilot - Piston	219-9695
2P-1606	Piston - Steering	239-7948
2P-1607	Pilot - Piston	239-7975
2P-1738	Plate As - Oil Pan	325-6164

(Continued)

Part Numbers Beginning with 2 (Continued)

Original Part Number	Part Name	Classic Part Number
2P-1739	Tube As - Pump	325-6229
2P-1757	Hub - Fan Pulley	296-1357
2P-1781	Spacer - Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2519	Tube As - Inlet	325-6230
2P-2719	Pipe	363-7454
2P-2744	Muffler As	247-2664
2P-2784	Ejector As - Exh	367-6063
2P-2922	Gear - Transfer	219-9679
2P-2923	Gear - Transfer	219-9680
2P-3422	Gear - First Reduction	213-8451
2P-3423	Pinion - Sec Reduction	216-3553
2P-3424	Gear - First Reduction	215-1675
2P-3425	Pinion - Sec Reduction	217-7697
2P-3586	Piston - Clutch	260-0777
2P-3598	Shaft - Output	215-1676
2P-3669	Pinion - Bevel	215-1677
2P-3992	Gear - Bevel	219-9666
2P-4370	Plate - Clutch	325-6166
2P-4404	Housing As	226-8027
2P-4409	Gear - Ring	226-7981
2P-4435	Plate	275-5295
2P-4443	Coupling - Flywheel	301-0233
2P-4510	Piston - Clutch	275-5293
2P-4611	Pipe - Exhaust	365-8821
2P-4701	Shaft As - Gear	297-7257
2P-5081	Muffler As	360-7872
2P-5608	Pipe - Extension	367-6066
2P-5609	Muffler As	247-2665
2P-5680	Turbine - Converter	308-9942
2P-5693	Housing - Rotating	308-9866
2P-6128	Pulley	264-5872
2P-6159	Pulley - Fan Drive	264-5873
2P-6245	Shaft As - Pump	325-6197
2P-6255	Muffler As	247-2666
2P-7622	Bolt - Spring	226-4850
2P-7828	Pan - Oil	314-8691
2P-7830	Pump Gp	314-8533
2P-7984	Yoke As - Idler	226-0220
2P-9037	Drum - Steering Clutch	219-9696
2P-9038	Drum - Steering	216-7821
2P-9039	Hub - Steering	219-9697
2P-9632	Damper As	299-2004
2P-9660	Gear - Final Drive	226-5995
2P-9667	Cage - Shaft Bearing	226-7971
2P-9669	Shoe -Track Master	188-5604
2P-9670	Bolt Master	188-5637
2P-9672	Cage - Pinion Bearing	226-7972
2R-0179	Pin As	325-6127
2S-1273	Chamber As	319-3434
2S-1477	Holder As - Cage	226-7985
2S-2140	Nut (7/8-14)	188-5857
2S-2781	Plunger - Relief	311-9435
2S-3188	Plate	299-2041
2S-3443	Drum - Steer	219-9689 (Drum), 230-7113 (Steering Clutch Kit)
2S-3803	Gear	226-6106
2S-3804	Gear - Sliding	226-6107
2S-3913	Cage - Gear Bearing	217-7722
2S-3946	Gear - Final Drive	215-1678
2S-3966	Ring - Seal	297-7237
2S-4015	Plunger As - Valve	311-9438
2S-4357	Pinion - Final Drive	217-7706
2S-4365	Retainer As	216-3554
2S-6263	Guard Gp - Spring	226-0192
2S-6264	Guard Gp - Spring	226-0193
2S-6265	Rod Gp - Recoil	226-0197
2S-6344	Gear - Final Drive	297-7173
2S-6346	Shoe -Track	188-5311
2S-6347	Shoe -Track	188-5613
2S-6357	Shoe -Track	281-6373
2S-6364	Shoe -Track	188-5615
2S-6739	Pulley - Tightener	298-2794
2S-7062	Shaft - Sprocket	219-9673
2S-7063	Nut	300-2584
2S-7064	Cap - Shaft Bearing	299-1991
2S-7099	Hub - Gear	219-2962
2S-7264	Pump As - Fuel Injector	311-9442
2S-7527	Flange - Drum	213-8163
2S-7596	Retainer	215-1679
2S-7603	Drum	213-6951
2S-7873	Pump Gp	226-0162
2S-7917	Gear - Pump Drive	247-4119
2S-7920	Pump Gp - Scavenge	217-2594
2S-8277	Guard Gp - Spring	226-4936
2S-8278	Guard Gp - Spring	226-4937
2S-8356	Rod Gp - Track Adjustable	226-0199
2S-8892	Pulley - Fan Drive	264-5874
2S-8961	Pulley - Tightener	264-5875
2V-0705	Pin As	241-2524
2V-0707	Bearing - Sleeve	360-2328
2V-0812	Pinion - Final Drive	231-0250
2V-0813	Gear - Sec Cluster	231-0232
2V-0814	Gear - Output	231-0233
2V-0816	Pinion - Swing Drive	231-0017
2V-0817	Gear - Cluster	231-0234
2V-0961	Driver	231-0255
2V-1074	Shaft - Planet	364-5262

(Continued)

Part Numbers Beginning with 2 (Continued)

Original Part Number	Part Name	Classic Part Number
2V-1722	Pin As	241-2525
2V-3687	Gear - Diff Bevel	308-9849
2V-4332	Collar	299-1993
2V-4374	Joint Gp - Slip	308-9872
2V-4700	Pin	308-9894
2V-5551	Pinion - Final Drive	216-7822
2V-5552	Gear & Pinion - Final Drive	216-7823
2V-5697	Cover As	299-1999
2V-5709	Shaft - Axle	299-2056
2V-5714	Gear - Ring	288-8716
2V-5715	Bushing	299-1987
2V-5722	Carrier - Planet	297-7164
2V-5881	Gear - Bevel Ring	253-1434
2V-6220	Shaft - Planet	221-9073
2V-6221	Shaft - Planet	221-9108
2V-6551	Pin	297-7212
2V-7083	Yoke	224-1302
2V-7170	Yoke	308-9948
2V-7198	Pilot As - Recoil Spring	302-2709
2V-7393	Retainer	308-9914
2W-0994	Body As - Preclnr	367-6084
2W-1086	Cover As - Cylinder Head	325-6049
2W-2621	Valve - Inlet	247-6892 (Valve), 241-3381 (Valve Kit)
2W-3211	Valve - Exhaust	311-9471
2W-3428	Muffler As	298-2784
2W-5540	Core, Radiator (Folded)	363-7452
2W-6030	Tube	314-8729
2W-6757	Trunnion As	295-5678
2W-7255	Shaft - Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear - Water Pump	325-6088
2W-8494	Pulley - Alt	295-5692
2W-9094	Adapter - Exhaust	299-2534
2W-9978	Core As - Oil Cooler	279-4983
2Y-4213	Pulley	314-8703

Part Numbers Beginning with 3

Original Part Number	Part Name	Classic Part Number
307-1303	Muffler As	361-6574
312-0782	Worm - Circle Drive	282-6623
323-8756	Link As	257-1992
323-8757	Link As	257-1990
323-8758	Link As	257-1994
323-8759	Link As	257-1991
3B-1464	Cap - Bearing	226-0206
3B-5067	Shaft - Shift Worm	228-8907
3B-6217	Muffler As	247-2671
3B-6218	Muffler As	247-2672
3B-6695	Gear - Worm	228-9448
3B-9970	Worm	228-8908
3D-0409	Arm - Pitman	228-9397
3D-2136	Sprocket	228-9398
3D-2149	Pinion	228-9450
3D-2236	Sprocket As	228-9399
3D-4442	Shaft - Rev Worm	243-0354
3D-4443	Shaft - Rev Worm	243-0351
3D-4498	Shaft - Lower	243-0348
3D-4718	Bearing - Sleeve	245-5795
3D-5315	Pinion - Diff Bevel	308-9856
3D-5457	Cage - Bearing	228-9400
3D-6672	Gear	229-1586
3D-9194	Gear	245-5796
3D-9502	Bolt - Draft	243-0332
3D-9786	Ballstud	228-9559
3D-9932	Cage - Bearing	228-9401
3F-0017	Gear - Coupling	229-1587
3F-0018	Gear - Coupling	229-1588
3F-0019	Collar - Coupling	229-1589
3F-1537	Nut - Spanner	226-6098
3F-1956	Cap - Frame Sup	226-7987
3F-1972	Retainer As	226-7988
3F-4971	Pin	295-5693
3F-6149	Pin	299-2033
3F-6185	Pin	295-5694
3F-6334	End-tie Rod - Rh	228-9451
3F-6338	End-tie Rod - Lh	228-9452
3F-6446	Pivot - Push Pole	256-4827
3F-6523	Pin - Clevis	256-4818
3F-6561	Arm As - Brace	256-4828
3F-6611	Socket - Joint	256-4829
3F-6612	Cap - Ball Joint	297-7155
3F-7445	Bearing - Sleeve	314-8508
3G-0034	Trunnion	361-1712
3G-0910	Cap - Bearing	325-6037
3G-1525	Bearing - Sleeve	325-6006
3G-2665	Cover	308-9842
3G-4929	Pin	325-6139
3G-6313	Bearing	325-6007
3G-6565	Bearing - Sleeve	325-6008
3G-8900	Pin	325-6140
3G-8917	Pin	325-6141
3G-8932	Pin	325-6143
3H-3378	Gear As - Pump	298-2795
3H-7161	Pin	256-4819
3H-7162	Collar	256-4830
3H-7164	Pin - Pivot	256-4820
3J-2452	Cap - Ball Joint	297-7156
3J-2682	Bracket	296-1345
3J-3493	Ballstud	256-4832
3J-4284	Cap - Bearing	314-8656
3J-4352	Arm As - Brace	297-7137
3J-5190	Cap - Bearing	256-4837

(Continued)

Part Numbers Beginning with 3 (Continued)

Original Part Number	Part Name	Classic Part Number
3J-5432	Pin - Pivot	361-1711
3J-6043	Trunnion	319-3477
3J-6167	Bearing - Sleeve	299-1960
3J-6182	Pin As	325-6128
3J-6204	Pin As	325-6129
3J-6442	Bearing - Sleeve	299-1961
3J-6497	Screw - Adjusting	256-4825
3J-6502	Pin	319-3453
3J-6559	Cap - Bearing	296-1346
3J-6560	Screw - Adjustable	297-7240
3J-6561	Screw - Adjustable	297-7241
3J-6570	Support - Bearing	299-2069
3J-6573	Screw - Adjusting	302-2714
3J-6575	Trunnion	297-7265
3J-6576	Bearing	256-4833
3J-6577	Pin - Brace	367-6077
3J-9133	Bearing - Sleeve	361-1691
3J-9710	Bearing - Sleeve	256-4793
3K-0963	Pin - Lock	308-9895
3K-2230	Gear - Planet	219-9658
3K-2498	Shaft - Planet	216-7824
3K-3124	Muffler - Trap	247-2673
3K-3774	Gear - Final Drive	217-7716
3K-3814	Gear & Pinion - Final Drive	216-7825
3K-5461	Wheel - Steering	308-9945
3K-7020	Gear - Planet	221-9074
3K-7021	Gear - Ring	221-9075
3K-7110	Gear - Planet	253-1435
3K-7111	Gear - Sun	253-1436
3K-7112	Gear - Ring	253-1437
3L-1425	Bearing - Ball	311-9356
3N-2078	Pump Gp - Fuel Transfer	311-9444
3N-3148	Tube As	311-9461
3N-3368	Pipe - Exhaust	311-9434
3N-6815	Shoe - Track	288-6681
3N-6841	Tube As - Inlet Rh	311-9464
3N-7326	Thrower - Camshaft Oil	311-9458
3N-7327	Thrower - Camshaft Oil	311-9459
3N-9160	Ring - Camshaft Seal	311-9447
3P-0114	Elbow - Exhaust	314-8516
3P-0165	Pulley - Fan Drive	298-2775
3P-0214	Gear - Transfer	219-9681
3P-0215	Gear - Transfer	219-9682
3P-0297	Shaft As	275-5297
3P-0307	Cage As - Bearing	300-2572
3P-0324	Coupling	301-0234
3P-0335	Platepress	297-7228
3P-0395	Cage - Carrier Bearing	217-7723
3P-0615	Shoe - Track Master	188-5601
3P-0616	Shoe - Track Master	175-8881
3P-0617	Shoe - Track Master	188-5246
3P-0618	Shoe - Track Master	188-5602
3P-0620	Shoe - Track Master	188-5606
3P-0628	Link As.	175-8759
3P-0651	Seal - o-Ring	314-8541
3P-0726	Shaft As	275-5298
3P-0785	Hub As - Clutch	302-2688
3P-0862	Carrier - Input	301-4764
3P-0894	Shaft As - Planet	302-3446
3P-1609	Carrier - Planet	302-4292
3P-1626	Hub As - Clutch	302-2687
3P-1651	Piston As	302-4296
3P-1757	Yoke As - Idler	226-2729
3P-1849	Ring - Sealing	360-2259
3P-2274	Bolt Master	200-9133
3P-2685	Piston - Clutch	308-9908
3P-2692	Cage - Bearing	302-2663
3P-2768	Piston - Clutch	308-9909
3P-2769	Support As	299-2064
3P-2811	Flange	239-7976
3P-2852	Clutch - Hub	301-4902
3P-2856	Plate - Clutch	302-2693
3P-2859	Drum As	301-4644
3P-3059	Gear - Sun	308-9861
3P-3060	Gear - Sun	308-9862
3P-3096	Gear - Sun	308-9863
3P-3208	Flange - Joint	301-4647
3P-3241	Plate - Pressure	325-6167
3P-3242	Shaft - Planet	308-9923
3P-3245	Shaft - Planet	308-9924
3P-3246	Shaft - Planet	308-9925
3P-3259	Cage - Bearing	217-7728
3P-3450	Yoke	229-8225
3P-3623	Lock - Adjustable Nut	226-7989
3P-3713	Gear As	275-5288
3P-3755	Guard As	226-2721
3P-3757	Guard As	226-2722
3P-3889	Shoe - Track Master	175-8021
3P-3890	Shoe - Track Master	175-8366
3P-3891	Shoe - Track Master	175-8368
3P-3892	Shoe - Track Master	175-8674
3P-3896	Shoe - Track Master	175-8023
3P-3935	Shaft	299-2053
3P-4002	Pump Gp - Gear	217-2595
3P-4089	Gear As - Ring	239-7952
3P-4094	Housing As	239-7954
3P-4096	Gear As - Ring	239-7953
3P-4142	Plate As	299-2039
3P-4157	Yoke As - Idler	226-0221
3P-4197	Guard As - Idler	226-0189
3P-4850	Gear As - Oil Pump	308-9848
3P-4855	Pump Gp	217-2596
3P-5349	Piston As	275-5292

(Continued)

Part Numbers Beginning with 3 (Continued)

Original Part Number	Part Name	Classic Part Number
3P-5359	Piston - Clutch	299-2037
3P-5672	Yoke	223-6313
3P-5736	Hub - Gear	219-2975
3P-5737	Shaft As - Clutch	275-5273
3P-5754	Hub - Gear	219-2976
3P-5755	Extension - Final Drive	226-7990
3P-5762	Link As	257-8022
3P-6269	Cage - Pinion Bearing	239-7972
3P-6293	Pump Gp	217-2597
3P-6318	Flange - Drum	213-8165
3P-6560	Stop - Recoil Spring	226-0232
3P-6561	Stop - Recoil Spring	226-0233
3P-6814	Pump Gp	226-0163
3P-6816	Pump Gp	226-0164
3P-6880	Housing As	302-2685
3P-7482	Cap - Drive Bearing	226-2731
3P-7623	Pump Gp	217-2598
3P-7640	Gear - Ctrshft	325-6093
3P-7641	Gear - Ctrshft	325-6094
3P-7642	Gear - Ctrshft	302-2668
3P-7643	Gear - Pinion Shft	302-2669
3P-7644	Gear - Pinion Shft	302-2706
3P-8283	Spacer	325-6215
3P-9394	Shaft - Planet	215-1680
3Q-5391	Shoe - Track	292-5634
3S-0311	Rod Gp	226-4953
3S-0777	Bearing - Roller Frame	229-8226
3S-1167	Gear - Planet	221-9101
3S-1261	Shaft - Center	239-7958
3S-1262	Retainer	308-9915
3S-1274	Shaft - Center	215-1681
3S-1691	Disc - Steering	302-2705
3S-2252	Manifold - Exhaust	261-0887
3S-2337	Shaft - Output	231-8765
3S-2420	Pilot As - Spring	226-2733
3S-2616	Pump Gp - Transmission	226-0165
3S-2710	Shaft - Planet	260-0779
3S-2712	Gear - Transfer	226-7977
3S-3917	Guard As - Sprocket	226-0188
3S-3918	Guard As - Sprocket	226-4950
3S-4386	Pump Gp - Steering	217-2599
3S-6907	Gear - Transfer	217-9774
3S-6908	Gear - Transfer	217-9775
3S-6989	Nut - Spanner	219-9701
3S-7153	Gear - Sliding	227-0024
3S-7306	Flange - Drum	216-7827
3S-7308	Cage - Pinion Bearing	219-9702
3S-7504	Gear - Idler	226-6084
3S-7517	Pulley - Belt Adjustable	264-5876
3S-7519	Pulley - Damper As	264-5877
3S-7987	Shaft - Planet	226-6074
3S-7996	Gear - Ring	226-6087
3S-8034	Shaft - Planet	308-9926
3S-8634	Hub - Gear	219-2977
3S-8735	Guard As	226-2723
3S-8736	Guard As	226-9992
3S-8800	Gear - Driven	325-6090
3S-9199	Hub - Sprocket	224-1310
3S-9466	Bearing - Sleeve	314-8509
3S-9919	Shaft As	239-7959
3S-9975	Piston - Clutch	260-0778
3T-0996	Bearing - Sleeve	295-5695
3T-0997	Bearing - Sleeve	307-1524
3T-1162	Sleeve - Wear	325-6209
3T-1446	Pump Gp	325-6178
3T-1554	Guard As	295-5696
3T-1898	Drum	219-9674
3T-1899	Drum	219-9690 (Drum), 230-7114 (Steering Clutch Kit)
3T-1900	Drum	226-7991
3T-1921	Drum - Inner	229-8227 (Drum), 230-7116 (Steering Clutch Kit)
3T-2145	Carrier As	325-6041
3T-2481	Strip	295-5448
3T-2849	Strip	295-5697
3T-3203	Gear - Transfer	302-2675
3T-3206	Roller Gp - Carrier	188-5590
3T-3447	Gear As - Sun	302-2676
3T-3690	Shoe -Track	175-8553
3T-4008	Gear - Planet	295-5444
3T-4011	Shaft As - Planet	295-5698
3T-4223	Gear - Transfer	319-3438
3T-4224	Gear - Transfer	297-7175
3T-4299	Joint Gp - Univ	325-6114
3T-4308	Bearing - Sleeve	296-1341
3T-4482	Guide - Front Idler	226-0248
3T-4516	Trunnion As	325-6226
3T-4568	Shaft - Planet	314-8712
3T-4824	Gear - Planet	295-5699
3T-5021	Carrier - Planet	295-5700
3T-5200	Carrier - Planet	295-5701
3T-5294	Spacer	325-6216
3T-5297	Pin	325-6145
3T-5672	Gear As - Oil Pump	295-5447
3T-5674	Gear As - Oil Pump	295-5449
3T-5929	Gear	288-8718
3T-6247	Shaft	314-8713
3T-6795	Piston - Clutch	281-1693
3T-7192	Guard As	325-6100
3T-7195	Guard As	325-6101
3T-7399	Piston	325-6159
3T-7701	Cylinder As	325-6058
3T-7710	Guide	325-6102
3T-7711	Guide	325-6103
3T-9152	Rim - Sprocket	322-6377

(Continued)

Part Numbers Beginning with 3 (Continued)

Original Part Number	Part Name	Classic Part Number
3T-9153	Rim - Sprocket	322-6303
3T-9496	Plate - Retainer	299-2042
3V-1025	Shaft - Pinion	226-6109
3V-1133	Strip	226-0203
3V-2042	Hub - Gear	217-7735
3V-2281	Link As	299-2023
3V-2337	Pin As	319-3440
3V-2771	Retainer	216-7830
3V-4527	Sprocket - Track	289-2209
3V-4622	Bracket - Carriage Roller	297-7148
3V-4874	Pin	241-2544
3V-5148	Pinion - Swing Gr	231-0251

Original Part Number	Part Name	Classic Part Number
3V-5257	Bracket - Carriage Roller	297-7149
3V-5317	Gear	231-0010
3V-5378	Gear - Output	231-0235
3V-5604	Pinion - Final Drive	216-7832
3V-5605	Gear - Final Drive & Pinion	216-7833
3V-5778	Shaft - Sprocket	216-7834
3V-5916	Plate As - Press	226-8025
3V-5918	Gear - Final Drive	217-7717
3V-5920	Hub - Gear	222-1762
3V-6648	Pin As	308-9884
3V-7365	Hub - Gear	219-2965
3V-7427	Housing As	297-7197

Original Part Number	Part Name	Classic Part Number
3V-8777	Gear - Spiral	297-7176
3V-8927	Pin	241-2545
3V-9025	Link As	289-4946
3V-9281	Bearing	314-8631
3V-9285	Pin	241-2546
3V-9439	Retainer As	231-0257
3W-0630	Pin	307-1525
3W-0640	Piston	325-6160
3W-0643	Cylinder	325-6061
3W-3284	Strip	296-1368
3W-3285	Strip	296-1369
3W-3628	Guard As	295-5677
3W-6551	Shaft	295-5702
3W-6555	Shaft	295-5703
3W-8239	Sleeve - Wear	360-2342
3Y-9984	Manifold - Exhaust	325-6123
3Y-9985	Manifold - Exhaust	325-6124

Part Numbers Beginning with 4

Original Part Number	Part Name	Classic Part Number
4B-1455	Cap As - Filter	361-1719
4B-5806	Shaft - Upper	243-0347
4B-7064	Shaft - Worm	245-5803
4D-0913	Arm - Steering	228-9402
4D-0926	Pin	247-4439
4D-0929	Rod End - Tie	228-9403
4D-0930	Rod End - Tie	228-9404
4D-1626	Shaft - Lift Arm	245-5805
4D-2184	Shaft - Low Pinion	229-1592
4D-2185	Shaft - Rev Idler	229-1593
4D-2198	Cage - Bearing	229-1594
4D-2218	Gear - Coupling	229-1595
4D-2219	Gear - Reverse	229-1597
4D-2220	Pinion - Transmission & Bevel	228-8920
4D-2227	Pinion	228-9453
4D-2229	Cage - Bearing	229-1598
4D-2268	Cover - Shaft	228-9454

Original Part Number	Part Name	Classic Part Number
4D-3462	Pin - Pivot	247-4440
4D-3898	Gear - Bevel	228-8921
4D-3966	Gear - Reduction	228-8924
4D-4863	Pinion	229-1599
4D-5997	Pinion	245-5809
4D-6664	Coupling - Shaft	243-0338
4D-6665	Shaft - Circle Rev	243-0349
4D-6698	Bearing - Tandem Housing	228-9405
4D-6926	Segment - Control	228-9455
4D-7213	Coupling	228-9406
4D-7282	Shaft - Axle	228-9408
4D-9934	Trunnion	229-1601
4E-0183	Pin	301-7976
4E-0403	Gear - Planet	260-0781
4E-1035	Pin	241-2553
4E-1065	Pin As	241-2538
4E-1285	Link As	299-2021
4E-3196	Pin As	361-1697
4E-3456	Lever As	367-6081
4E-5213	Cover As	299-2000

Original Part Number	Part Name	Classic Part Number
4E-5882	Shaft - Axle	308-9921
4E-8500	Idler Gp -Track	288-3691
4E-8534	Retainer - Seal	300-2588
4E-8535	Retainer - Seal	300-2589
4E-9426	Collar	231-0000
4F-1121	Bracket	299-1981
4F-1252	Pin	295-5704
4F-4974	Clamp	311-9373
4H-2029	Gear - Reverse	229-1602
4H-4021	Plate As - Loading	229-8219
4H-7969	Bearing - Worm	245-5811
4H-9040	Nut	226-7996
4I-0453	Bearing - Sleeve	360-2331
4I-0704	Bearing Sleeve	360-2332
4I-3954	Tube As	301-4779
4I-3955	Tube As	301-4802
4I-3956	Tube As	301-4780
4I-3957	Tube As	301-4801

(Continued)

Part Numbers Beginning with 4 (Continued)

Original Part Number	Part Name	Classic Part Number
4I-4665	Bearing - Sleeve	364-5267
4I-4805	Pin	365-8828
4I-4806	Pin	364-5268
4I-5015	Pin	365-8829
4I-8881	Tube As	301-4777
4J-0121	Cap - Bearing	360-2344
4J-1612	Pin	308-9896
4J-1614	Pin - Pivot	297-7214
4J-1616	Bracket	299-1982
4J-1641	Trunnion	314-8725
4J-1999	Ballstud	314-8625
4J-2414	Trunnion	296-1370
4J-2585	Pin	299-2034
4J-2590	Bearing	299-1958
4J-2847	Trunnion As	297-7267
4J-3015	Shaft	325-6204
4J-3583	Screw - Adjusting	297-7242
4J-3589	Cap - Ball Joint	297-7157
4J-3590	Bearing	297-7139
4J-3591	Bracket - Rh	299-1983
4J-6167	Bearing - Sleeve	325-6009
4J-6374	Bearing - Sleeve	295-6407
4J-6899	Bearing - Sleeve	308-9815
4K-0255	Retainer As	226-6102
4K-0299	Bearing - Sleeve	308-9816
4K-0300	Bearing - Sleeve	308-9817
4K-1102	Bearing - Sleeve	325-6010
4K-1328	Drum - Steering	216-7840 (Drum), 230-7112 (Steering Clutch Kit)
4K-3004	Bearing - Trunnion Support	314-8632
4K-3128	Bearing - Sleeve	314-8633
4K-4460	Pin	241-2609
4K-4632	Gear - Bevel	216-7842
4K-4780	Strip As - Wear	299-2063
4K-5074	Pinion	215-1683
4K-5086	Yoke	215-1684
4K-5109	Gear - Reverse	219-9659
4K-6212	Shaft - Bevel Pinion	223-4806
4K-6558	Pin - Lower	302-2710
4K-6702	Pin	241-2573
4K-6736	Drum - Brake	223-6320
4K-6737	Gear - Ring	221-9097
4K-6760	Cap - Lower	300-2574
4K-6761	Cap - Upper	300-2575
4K-6810	Retainer - Seal	300-2586
4K-7251	Cover	299-2003
4K-7269	Support	299-2067
4K-7386	Plate - Guide	226-4851
4K-7420	Retainer	297-7234
4K-8225	Pin - Cylinder	297-7215
4K-8416	Shaft	308-9927
4K-8561	Pin	299-2036
4K-8734	Bearing - Sleeve	299-1962
4K-9559	Hub - Gear	219-2978
4K-9598	Retainer	297-7235
4L-3307	Elbow - Manifold Inlet	311-9387
4L-3756	Bearing - Thrust	311-9366
4L-4653	Plate - Thrust	311-9440
4L-7820	Rod Assembly	311-9449
4M-0433	Shaft - Steer	239-7960
4M-0503	Gear As - Oil Pump	297-7184
4M-1001	Pump Gp - Final Drive Oil	226-0166
4M-7099	Gear - Ring	214-0521
4M-7100	Gear - Ring	214-0522
4M-7102	Gear - Ring	214-0523
4M-8845	Shaft - Planet	215-1685
4M-8967	Gear - Sun	219-9661
4M-9214	Shaft - Pump Drive	314-8543
4M-9215	Gear - Pump Idler	311-9391
4M-9216	Gear - Pump Drive	311-9390
4N-2954	Sleeve - Camshaft	299-2059
4N-3281	Line As - Fuel Injector	247-3362
4N-3282	Line As - Fuel Injector	247-3363
4N-3283	Line As - Fuel Injector	247-3364
4N-3284	Line As - Fuel Injector	247-3365
4N-3664	Guide - Valve	314-8524
4N-3714	Chamber, Precom	363-7450
4N-4356	Pulley - Camshaft	264-5878
4N-4539	Sleeve	314-8720
4N-4577	Muffler As	308-9877
4N-4782	Pulley	325-6176
4N-4864	Pump Gp - Fuel Transfer	242-3442
4N-4880	Pump Gp - Fuel Transfer	256-4758
4N-5184	Muffler As	360-7874
4N-5191	Muffler As	298-2785
4N-5390	Pulley - Alt Drive	264-5879
4N-5503	Adapter - Exhaust	299-1954
4N-6302	Belt Set - Vee	314-8495
4N-6638	Muffler As	360-7875
4N-7000	Head As - Cylinder	325-6105
4N-7526	Seal As - Pump	311-9454
4N-7692	Crankshaft As	242-3440
4N-7693	Crankshaft As	242-3439
4N-7977	Shaft As - Balance	314-8709
4N-7978	Shaft As - Balance	314-8710
4N-7982	Pulley	264-5880
4N-8591	Coupling - Exhaust	325-6053
4N-8809	Chamber As	247-3297
4N-8814	Line As - Fuel Injector	247-3366
4N-8942	Muffler As	298-2786
4N-9180	Seal As - Pump	311-9455
4N-9587	Shield - Heat	297-7260
4P-0660	Muffler As	298-2787
4P-1463	Muffler As	360-7876
4P-3546	Valve As - Relief	325-6236
4P-4010	Muffler As	298-2788

(Continued)

Part Numbers Beginning with 4 (Continued)

Original Part Number	Part Name	Classic Part Number
4P-9381	Line As - Fuel Injector	279-4984
4P-9382	Line As - Fuel Injector	279-4985
4P-9385	Line As - Fuel Injector	279-4986
4P-9386	Line As - Fuel Injector	279-4987
4P-9961	Line As - Fuel Injector	325-6115
4P-9962	Line As - Fuel Injector	325-6116
4P-9963	Line As - Fuel Injector	298-2777
4P-9964	Line As - Fuel Injector	298-2778
4S-5049	Guard As - Rh	226-0183
4S-5050	Guard As - Lh	226-0184
4S-5833	Spacer	239-7961
4S-5943	Piston - Clutch	221-9112
4S-5944	Gear - Sun	221-9078
4S-5945	Gear - Sun	221-9079
4S-5946	Shaft - Center	229-8238
4S-5947	Gear - Ring	221-9080
4S-5948	Gear - Ring	221-9082
4S-5979	Carrier As	216-7843
4S-5981	Gear - Ring	221-9084
4S-6189	Pinion - Reverse	226-6077
4S-6190	Pinion - Forward	226-6078
4S-6256	Nut - Bearing Adjustable	235-8008
4S-6559	Tube	325-6234
4S-6707	Piston - Clutch	215-1686
4S-7793	Thrower - Crankshaft Oil	367-6085
4S-8005	Pinion - Final Drive	226-6076
4S-8472	Hood As	296-1355
4S-8530	Shaft - Planet	221-9111
4S-8534	Shaft As - Planet	221-9116
4S-8660	Pump Gp - Transmission	226-0167
4S-8670	Shaft - Planet	300-2590
4S-8687	Piston - Clutch	226-8008
4S-8707	Shaft & Sun Gear	226-6089
4S-8708	Housing - Clutch	216-3557
4S-8713	Gear - Ring	226-6090
4S-8716	Gear - Transfer	226-7978
4S-8718	Cage - Carrier Bearing	217-7724
4S-8906	Insert	311-9397
4S-8908	Insert	311-9399
4S-8909	Insert - Valve Seat	311-9400
4S-9062	Cap - Final Drive Bearing	226-0204
4T-0202	Pin As	325-6130
4T-0732	Bracket	314-8627
4T-0998	Lever	314-8687
4T-1504	Trunnion	314-8727
4T-5172	Seal As	325-6189
4T-5405	Trunnion As	319-3476
4T-5495	Ballstud	314-8626
4T-6151	Trunnion	295-5671
4T-8088	Screw	325-6188
4T-9444	Pin	325-6146
4V-0015	Plate - Lock	282-6563
4V-0381	Bearing - Sleeve	299-1963
4V-2518	Shaft	297-7243
4V-2744	Gear	224-1303
4V-3044	Plate - Lock	308-9911
4V-3396	Hub - Gear	222-1763
4V-3397	Hub - Gear	219-2979
4V-3603	Pin As	319-3441
4V-3680	Bellcrank	308-9802
4V-5100	Support - Trunnion	299-2068
4V-5213	Spindle	299-2060
4V-5388	Shaft - Bevel Pinion	297-7244
4V-5393	Gear - Bevel	297-7189
4V-5394	Gear - Diff Bevel	297-7177
4V-5454	Link	299-2025
4V-5608	Pin As	241-2529
4V-6040	Drum	297-7168
4V-6156	Saddle As	299-2052
4V-6421	Pin As	319-3442
4V-6430	Bracket As	299-1974
4V-7082	Joint Gp - Slip	367-6068
4V-7099	Pin As	361-1698
4V-7105	Pin As	361-1699
4V-7344	Pin	241-2574
4V-7543	Retainer	281-1699
4V-8519	Bearing - Sleeve	307-1526
4V-8520	Bearing - Sleeve	307-1527
4V-8534	Shaft - Planet	281-1700
4V-8538	Gear - Ring	288-8720
4V-8673	Bearing - Sleeve	307-1528
4V-8674	Bearing - Bushing	307-1529
4V-8687	Boss	299-1971
4V-8690	Boss	299-1972
4V-9236	Plate - Pressure	231-0260
4V-9577	Shaft - Planet	231-0001
4W-0452	Seal As - Camshaft	325-6191
4W-2042	Spacer	325-6217
4W-2446	Damper As	279-4990
4W-2606	Seal Gp - Camshaft	311-9452
4W-2607	Seal Gp - Camshaft	311-9453
4W-5053	Muffler As	360-7881
4W-5549	Core As - Oil Cooler	311-9376
4W-5550	Core As - Oil Cooler	311-9377
4W-5551	Core As - Oil Cooler	311-9378
4W-9771	Gear - Crankshaft	302-2674
4W-9989	Gear As - Idler	302-2677
4Y-2817	Ejector As	295-6423

Part Numbers Beginning with 5

Original Part Number	Part Name	Classic Part Number
5A-3187	Bolt Master	257-7773
5A-4003	Shaft - Sprocket	229-8228
5A-5196	Hub - Gear	221-1066
5A-5740	Gear - Sliding	229-8229
5A-6897	Guard - Idler Rh	226-4951
5A-6898	Guard - Idler Lh	226-4952
5A-7840	Shaft - Track Sprocket	215-1687
5A-7841	Hub - Gear	219-2966
5A-8374	Roller Gp - Carrier	200-9185
5A-9551	Gear - Final Drive	226-7979
5B-0577	Collar	299-1992
5C-0451	Gear Gp - Bearing	235-5053
5C-0949	Link As	290-3452
5C-1834	Gear	231-0002
5C-3712	Gear	231-0003
5C-3714	Gear	231-0222
5C-3715	Gear	231-0223
5C-3716	Gear	231-0224
5C-3717	Gear	231-0225
5C-3784	Pin As	241-2512
5C-5038	Pin As	241-2506
5C-5153	Cartridge	231-0011
5C-5236	Gear	231-0226
5C-5829	Pin As	241-2510
5C-5837	Retainer - Pin	299-2047
5C-5937	Gear	231-0004
5C-6690	Pin As	241-2508
5C-8172	Pin As	241-2515
5C-8582	Shaft - Planet	231-0241
5C-8583	Gear - Ring	231-0005
5C-8584	Gear - Planet	231-0006
5C-8586	Gear	231-0007
5C-8587	Cover	231-0243
5C-8966	Gear	231-0227
5C-9207	Drum	301-4623
5D-0034	Plate - Retainer	228-9456
5D-0395	Bracket - Rail Rh	243-0335
5D-0396	Bracket - Rail Lh	243-0334
5D-0470	Valve Gp	314-8549
5D-0927	Shaft - Reduction	229-1605
5D-3283	Coupling - Shaft	243-0339
5D-3961	Block - Brake	245-5813
5D-4010	Rack	228-8909
5D-5039	Ballstud	228-8910
5D-6201	Shoe - Yoke	243-0356
5D-6375	Shaft - Final Drive Pinion	228-9409
5D-7339	Coupling	245-5816
5D-7461	Pin	247-4441
5D-7462	Pin	247-4442
5D-9548	Hub - Final Drive Gear	228-9412
5D-9906	Shaft - Axle	228-9413
5D-9972	Shaft	229-1607
5F-0689	Pin	256-4821
5F-0706	Pin	256-4822
5F-0707	Collar	256-4831
5F-0736	Pin - Pivot	256-4823
5F-1401	Pin - Pivot	297-7216
5F-2256	Cage - Bearing	226-7973
5F-6393	Shaft	308-9928
5F-7404	Nut - Bearing Lock	308-9878
5F-7993	Pin	319-3454
5G-3612	Cap Gp	295-6419
5G-9075	Strip	295-0412
5G-9076	Strip	295-0413
5H-0049	Hub - Flywheel	229-1608
5H-0051	Plate - Flywheel	229-1610
5H-0057	Ring - Bearing Thrust	229-1613
5H-1719	Pump Gp - Final Drive Oil	226-0168
5H-5500	Collar - Flywheel	302-2704
5H-5553	Screw -Tappet Adjustable	311-9451
5I-7619	Pulley	301-4772
5I-7694	Impeller	301-4763
5I-7959	Pulley As	301-5256
5I-8628	Plate - Valve	301-4771
5J-0698	Pin	319-3456
5J-1204	Pin As	325-6131
5J-1825	Pin	367-6080
5J-2602	Plate As - Trunnion	256-4838
5J-3492	Bearing - Sleeve	308-9879
5J-4321	Trunnion	302-2700
5J-4542	Bearing - Sleeve	308-9818
5J-4798	Bearing As	256-4840
5J-4924	Shaft - Pivot	256-4777
5J-4929	Bearing	256-4796
5J-5643	Connector	325-6043
5J-6417	Bearing	256-4798
5J-6418	Bearing - Sleeve	256-4799
5J-6419	Bearing - Sleeve	256-4800
5J-6421	Bearing	256-4801
5J-7980	Pin	256-4783
5J-7981	Pin	256-4784
5J-7983	Pin	256-4785
5J-8052	Trunnion	256-4843
5K-0609	Cover	308-9843
5K-0871	Pin - Lower	282-6630
5K-0989	Cap - Upper	297-7158
5K-0990	Pin	299-2035
5K-0991	Cap - Lower	319-3433
5K-1068	Retainer - Seal	260-0786
5K-2570	Spacer	226-5996
5K-2888	Hub - Gear	219-2967
5K-2893	Shaft - Sprocket	221-7953
5K-3490	Spacer	308-9933
5K-3491	Spacer	308-9934
5K-3497	Pin	308-9897
5K-3499	Pin - Lower	308-9898
5K-3502	Cap - Lower	308-9835
5K-3967	Yoke As	308-9946
5K-3968	Cage - Bearing	308-9804
5K-4079	Cage - Bearing	308-9805
5K-4180	Gear - Planet	308-9854
5K-4268	Retainer - Bearing	308-9916
5K-4305	Support As	308-9937
5K-4426	Bushing	308-9831
5K-4787	Bearing - Sleeve	308-9819
5K-4801	Pin	308-9899
5K-4802	Pin	308-9900
5K-4819	Pin	308-9901

(Continued)

Part Numbers Beginning with 5 (Continued)

Original Part Number	Part Name	Classic Part Number
5K-5927	Boss	299-1973
5K-5933	Cover As	247-4125
5K-6090	Flange	216-7844
5K-6142	Cage - Final Drive Gear Bearing	223-4811
5K-6377	Pin	241-2610
5K-6382	Pin	241-2611
5K-6383	Pin	241-2612
5K-7027	Pin	241-2575
5K-7995	Bearing - Sleeve	308-9820
5K-8265	Pin	241-2590
5K-8330	Holder - Tooth	299-2013
5K-8606	Cage - Gear Bearing	223-6310
5K-8628	Cage	216-7845
5K-9367	Pin	241-2613
5L-2648	Bearing - Sleeve	311-9362
5L-2660	Bearing - Sleeve	311-9363
5L-2894	Bearing - Sleeve	311-9364
5L-3980	V - Belt Set	314-8498
5L-5656	Belt Set - Vee	314-8499
5L-8856	Coupling - Exhaust	311-9379
5L-9370	Elbow - Manifold Inlet	311-9388
5L-9371	Connector - Inlet	311-9375
5L-9738	Coupling - Exhaust	311-9380
5M-0549	Gear - Transmission	215-1689
5M-1127	Countershaft	216-3558
5M-1133	Gear - Idler	214-0524
5M-1137	Gear As - Ctrshft	214-0960
5M-1139	Gear As - Ctrshft	214-0961
5M-1141	Gear As - Ctrshft	214-0962
5M-1143	Gear As	214-0963
5M-1145	Gear As - Forward	214-0964
5M-1147	Gear As - Reverse	214-0965
5M-1988	Piston - Steer	219-9691
5M-1990	Pilot - Piston	229-8233
5M-1998	Drum Steering	213-6952
5M-2026	Hubdriving	216-4471
5M-2971	Guard As - Front Idler	226-0190
5M-3470	Gear - Transmission	224-1305
5M-3474	Shaft - Output	215-1690
5M-3499	Shaft - Planet	319-3475
5M-3906	Gear - Ring	214-0526
5M-3907	Carrier - Planet	210-8475
5M-3941	Shaft - Planet	215-1691
5M-3942	Shaft - Planet	215-1692
5M-3947	Shaft - Planet	223-6318
5M-3996	Gear - Ring	214-0527
5M-3998	Gear - Ring	214-0528
5M-3999	Shaft - Transmission	215-1693
5M-4427	Gear - Sun	214-0529
5M-5037	Hub - Gear	219-2980
5M-5073	Joint Gp - Univ	325-6113
5M-5244	Hub - Gear	219-2982
5M-5822	Gear - Pump Drive	247-4120
5M-6120	Gear - Sun	213-8740
5M-6198	Shaft - Planet	297-7245
5M-6199	Shaft As - Planet	215-1694
5M-6208	Gear - Ring	247-4121
5M-6210	Shaft - Planet	219-9683
5M-6211	Shaft - Planet	219-9684
5M-6636	Support - Frame	235-8007
5M-6651	Hub - Gear	211-2135
5M-6670	Shaft - Sprocket	216-7847
5M-6673	Guard - F Idler Rh	226-2735
5M-6674	Guard - F Idler Lh	226-2736
5M-6690	Hub - Steering	215-1695
5M-7290	Cage - Bearing	216-7848
5M-7306	Cylinder	226-2737
5M-7336	Retainer - Washer	325-6181
5M-7340	Cage - Bearing	325-6034
5M-7342	Flange - Shaft	215-1696
5M-7344	Gear - Bevel	213-8741
5M-7345	Gear - Bevel	214-0957
5M-7346	Gear - Bevel	214-0958
5M-7348	Gear - Bevel	215-1699
5M-7349	Gear - Bevel	213-8742
5M-7352	Gear - Bevel	217-7713
5M-7353	Gear - Bevel	217-7714
5M-7355	Gear - Reverse	216-3581
5M-7740	Gear - Bevel	213-8216
5M-7841	Gear - Ring	214-0525
5M-7864	Pump Gp - Scavenge	226-0169
5M-7869	Gear - Ring	214-0530
5M-7875	Carrier - Front	213-4495
5M-7882	Joint Gp - Univ	297-7210
5M-7900	Bolt - Hex Head	311-9349
5M-7923	Shaft - Output	215-1697
5M-7953	Carrier As	239-7977
5M-7955	Shaft As - Planet	364-5273
5M-7990	Gear - Sun	239-7938
5M-8007	Gear - Ring	239-7932
5N-2691	Elbow - Air Transfer	311-9383
5N-2692	Elbow - Air Transfer	311-9384
5N-2902	Seal - Oil	314-8540
5N-3009	Tube As - Inlet Lh	311-9465
5N-3012	Tube As - Inlet	311-9466
5N-3050	Elbow - Outlet	311-9389
5N-4378	Shaft As - Pump	311-9456
5N-8501	Head As - Cylinder	256-4762
5N-8657	Manifold - Exhaust	261-0886
5N-8879	Manifold - Exhaust	261-0898
5N-9055	Manifold - Exhaust	261-0890
5P-7807	Bearing - Ball	314-8502
5P-8194	Ring - Retaining	308-9920
5S-0073	Plate - Steering	302-2692
5S-0135	Cage - Pinion Bearing	222-1766

(Continued)

Part Numbers Beginning with 5 (Continued)

Original Part Number	Part Name	Classic Part Number
5S-0160	Strip - Guard	226-2738
5S-0161	Strip - Guard	226-2739
5S-0162	Guard As - Guiding	226-2740
5S-0163	Guard As - Guiding	226-2741
5S-0192	Pinion - Final Drive	215-1698
5S-0464	Gear - First Reduction	216-7852
5S-0465	Pinion - Reduction	216-7853
5S-0726	Hub As - Sprocket	227-4769
5S-0821	Shoe -Track	175-8020
5S-0822	Shoe -Track	175-8365
5S-0823	Shoe -Track	175-8367
5S-0884	Gear - Ring	226-7982
5S-0885	Plate - Front	229-8234
5S-0894	Shaft - Center	226-6075
5S-1211	Cover - Valve	314-8665
5S-1757	Insert - Seat	311-9401
5S-1822	Chamber As	248-5406
5S-1833	Chamber As	247-3298
5S-4023	Gear	229-8230
5S-4359	Pump Gp - Transmission	226-0157
5S-4470	Gear - Transfer	224-1304
5S-4493	Carrier - Planet	223-6321
5S-4557	Bearing	311-9360
5S-4863	Holder As - Cage	215-1732
5S-5746	Retainer - Guard	319-3472
5S-6513	Guard As - Roller	226-4938
5S-6531	Holder As - Cage	214-2078
5S-6795	Chamber As	242-3437
5S-6796	Drum - Inner	213-6953 (Drum), 230-7115 (Steering Clutch Kit)
5S-6910	Shoe -Track	188-5603
5S-6911	Shoe -Track	188-5605
5S-6972	Gear - Sun	221-9087
5S-6978	Shaft - Planet	221-9103
5S-7009	Plate As - End	226-4957
5S-7010	Shaft - Planet	221-9104
5S-7013	Gear - Ring	221-9088
5S-7023	Carrier - Planet	226-5986
5S-7609	Pulley - Alt Drive	264-5881
5S-7888	Retainer - Bearing	226-5988
5S-7894	Flange As	216-7854
5S-7944	Shaft - Planet	297-7246
5S-7945	Shaft As - Planet	275-5299
5S-8038	Pulley - Crankshaft	264-5882
5S-8767	Gear - First	226-6085
5S-9062	Spacer	363-7463
5S-9080	Pulley - Alt Drive	264-5883
5T-0906	Cover	282-6625
5T-1362	Bearing - Spider	325-6011
5T-2925	Strip - Wear	282-6564
5T-2926	Shoe - Circle Guide	302-2699
5T-3475	Shaft	297-7247
5T-5222	Shoe - Circle Guide	297-7261
5T-6298	Lever	299-2018
5T-8500	Shoe - Circle Drive	243-0359
5T-8501	Shoe - Circle Drive	243-0358
5V-1271	Diff Gp	299-2008
5V-1480	Gear - Sun	288-8721
5V-1508	Pin As	361-1703
5V-1509	Pin As	319-3443
5V-1510	Pin As	252-6876
5V-1882	Pin As	361-1700
5V-4075	Gear - Planet	288-8722
5V-4969	Sprocket - Track	289-2205
5V-5279	Bearing - Sleeve	299-1966
5V-5661	Bearing - Sleeve	299-1965
5V-5866	Pin As	361-1707
5V-5917	Pinion - Diff Bevel	297-7224
5V-7207	Pinion - Final Drive	231-0252
5V-7214	Pin As	241-2522
5V-7222	Gear - Final Drive	231-0237
5V-8782	Lever As	299-2014

Part Numbers Beginning with 6

Original Part Number	Part Name	Classic Part Number
6A-4701	Gear	231-0231
6A-7129	Bearing - Sleeve	301-3130
6A-7534	Retainer	231-0244
6A-7539	Sprocket - Track	322-6304
6B-3158	Shoe - Yoke Lh	243-0357
6B-6911	Worm - Rh	245-5819
6B-6912	Worm - Lh	245-5820
6B-6941	Bearing - Worm	245-5812
6B-7178	Fork - Band Adjustable	299-2009
6C-0739	Carrier As	231-0012
6C-1573	Rod	297-7238
6C-3495	Sprocket - Track	322-6302
6C-3740	Shaft As	231-0013
6C-5062	Pinion	231-0016
6C-6374	Tube As	301-4778
6D-0217	Bearing - Sleeve	325-6022
6D-0687	Gear - Bevel	228-8922
6D-0708	Pinion	228-8923
6D-1599	Block - Link Pivot	228-9414
6D-1644	Shaft - Rod Pivot	228-9562
6D-1777	Gear - Planet	245-5799
6D-1778	Gear - Planet	245-5800
6D-1779	Gear - Planet	245-5801
6D-2362	Worm	243-0361
6D-4909	Cap - Pivot	297-7159
6D-6114	Cap	245-5822
6D-6201	Ballstud	228-9103

(Continued)

Part Numbers Beginning with 6 (Continued)

Original Part Number	Part Name	Classic Part Number
6D-6943	Housing - Axle	228-9416
6D-8671	Bolt - Draft	243-0333
6D-9164	Shaft - Pinion	243-0353
6D-9193	Hub - Final Drive Gear	228-9417
6D-9294	Shaft	228-9418
6E-1108	Bearing - Sleeve	325-6023
6E-1500	Piston	346-5677
6E-3535	Bearing - Sleeve	360-2333
6E-6153	Plate - Port	346-5678
6E-6163	Shaft	346-5679
6F-2904	Bearing	295-5673
6F-3183	Cap - Bearing	325-6038
6F-5201	Gear - Worm	245-5797
6F-6992	Cap - Ball-socket	297-7160
6F-7523	Cap - Bearing	325-6039
6G-1100	Shaft - Drive	297-7248
6G-1633	Chain Gp	282-6565
6G-1664	Adapter	297-7135
6G-1908	Housing As - Drive	297-7198
6G-1919	Cap - Pivot	243-0337
6G-2947	Shaft	243-0346
6G-4525	Strip - Wear	282-6624
6G-4680	Adapter	302-2633
6G-6241	Gear - Worm	299-2010
6G-8425	Valve Gp - Control	367-6086
6H-3217	Shaft As - Rocker	311-9457
6H-3957	Bearing - Ball	311-9358
6I-0341	Line As - Fuel Injector	325-6117
6I-0342	Line As - Fuel Injector	325-6118
6I-0343	Line As - Fuel Injector	325-6119
6I-0344	Line As - Fuel Injector	325-6120
6I-0345	Line As - Fuel Injector	325-6121
6I-0346	Line As - Fuel Injector	325-6122
6I-1346	Pump Gp - Oil	295-5674
6I-8132	Pinion	226-6080
6I-8736	Guard As	295-6434
6I-9034	Guard As	295-6435
6I-9454	Shoe -Track	286-9826
6J-0774	Trunnion	256-4844
6J-0800	Bearing	297-7140
6J-2326	Pin	319-3458
6J-5342	Retainer	325-6182
6J-5354	Bearing	297-7142
6J-6229	Pin	299-2030
6J-7563	Pin	319-3459
6J-8805	Bearing As	256-4841
6J-9258	Trunnion As	256-4846
6J-9474	Pin As	319-3444
6J-9793	Bearing	256-4835
6K-0053	Housing	297-7191
6K-1983	Pin	241-2614
6K-2034	Shaft	297-7249
6K-2036	Rack	299-2045
6K-2085	Shaft - Bevel Pinion	221-9102
6K-2703	Pin - Lower	252-6853
6K-2704	Pin - Upper	252-6873
6K-2707	Plate - Lock	319-3470
6K-3447	Pin	241-2576
6K-3674	Shaft - Bevel Pinion	253-1427
6K-3937	Pin	241-2557
6K-4180	Pin - Upper	252-6854
6K-4189	Spacer	367-6075
6K-4190	Cap - Lower	297-7161
6K-4191	Cap - Upper	300-2576
6K-4192	Pin - Lower	252-6855
6K-4193	Plate - Lock	282-6566
6K-4498	Bracket As - Lh	299-1976
6K-4600	Yoke	226-5993
6K-4617	Shaft - Sprocket	221-7951
6K-5448	Pin	252-6856
6K-5472	Pin	252-6857
6K-5513	Pin	241-2558
6K-5619	Shaft	253-1429
6K-5621	Retainer - Oil Seal	253-1443
6K-5625	Gear - Bevel Ring	253-1438
6K-6001	Pin	308-9902
6K-6046	Pin	241-2602
6K-6047	Pin	241-2603
6K-6051	Pin	252-6858
6K-6053	Pin	241-2604
6K-6054	Pin	241-2605
6K-6175	Pin	241-2606
6K-6185	Pin - Cylinder	252-6859
6K-6349	Pin	252-6860
6K-7161	Pin	241-2559
6K-7162	Pin	241-2560
6K-7164	Pin	241-2561
6K-7165	Pin	241-2562
6K-7166	Pin - Arm Pivot	241-2563
6K-7167	Pin	241-2569
6K-7284	Pin	241-2591
6K-7285	Pin	252-6861
6K-7286	Pin	241-2592
6K-7287	Pin	241-2564
6K-7288	Pin	252-6862
6K-8307	Pin	241-2593
6K-8308	Pin	241-2594
6K-8309	Pin	241-2595
6K-8311	Pin	241-2599
6K-8314	Pin	252-6863
6K-8316	Pin	252-6865
6K-8542	Pin	252-6867
6K-8544	Pin	252-6874
6K-8546	Pin	252-6868
6K-8897	Bracket As	299-1977
6K-9841	Cam & Lever As	226-5997
6L-3902	Line As - Fuel	311-9423
6L-3910	Line As - Fuel	311-9424
6L-4714	Panel - Air Cleaner Filter	314-8532
6L-6481	Elbow - Air Inlet	311-9385
6L-6482	Elbow - Air Outlet	311-9386
6L-6491	Pipe - Cross-over	311-9433
6L-7816	Seal - o-Ring	314-8542
6L-8585	Gear - Gov Drive	314-8526
6L-8968	Coupling - Exhaust	311-9381
6L-9210	Idler Gp (Complete Idler Group)	175-8038 (Idler As.), 200-9236
6L-9211	Idler Gp	200-9237
6L-9212	Idler Gp	200-9238
6N-0714	Pulley - Alt	264-5884
6N-0762	Pulley - Fan	264-5885
6N-1036	Gear - Oil Pump	279-4991

(Continued)

Part Numbers Beginning with 6 (Continued)

Original Part Number	Part Name	Classic Part Number
6N-1553	Coupling - Exhaust	295-6422
6N-1572	Mount As	308-9876
6N-1878	Muffler As	360-7883
6N-1965	Line As - Fuel Injector	250-7535
6N-1966	Line As - Fuel Injector	250-7536
6N-2789	Pulley	264-5886
6N-3256	Mount As	314-8688
6N-3964	Muffler As	360-7884
6N-5437	Muffler As	247-2674
6N-6969	Chamber As	247-3299
6N-7295	Manifold - Exhaust	261-0903
6N-8413	Housing - Pump	325-6110
6N-8847	Guide - Valve	314-8523
6N-9743	Support - Muffler	308-9940
6P-0169	Hub - Fly-wheel Clutch	297-7204
6P-0549	Guard - Final Drive Wear	223-4812
6P-1382	Pin	241-2615
6P-1383	Pin	241-2616
6P-2233	Gear - Planet	281-1690
6P-2776	Gear - Final Drive	217-7718
6P-3593	Support	229-8231
6P-3596	Hub	222-1764
6P-3597	Retainer	222-1770
6P-4948	Cap - Final Drive Bearing	226-0205
6P-5172	Guard Gp - Recoil	226-0196
6P-5173	Guard Gp - Recoil	229-8617
6P-5343	Rod Gp - Track Adjust-able	226-0200
6P-5404	Plate & Brake	325-6168
6P-6556	Carrier As	308-9836
6P-6653	Plate - Guide	226-0208
6P-6739	Shaft - Planet	308-9929
6P-7358	Pump Gp	308-9913
6P-7625	Guard As - Track Roller	226-0185
6P-7626	Guard As - Track Roller	226-0186
6P-7627	Guard As - Track Roller	226-0187
6P-7704	Carrier - Ring	314-8658
6P-7742	Shaft - Planet	281-1695
6P-7743	Shaft - Planet	281-1696
6P-8003	Gear - Planet	281-1689
6P-8005	Gear - Planet	281-1691
6P-8884	Guard As - Idler	226-2742
6P-8904	Guard Gp - Track Adjust-able	226-2744
6S-3457	Pin	325-6147
6S-3609	Roller - Car-rier	275-3578
6S-3759	Pin As	241-2543
6T-0064	Shaft - Planet	295-6442
6T-0234	Retainer	325-6183
6T-0240	Retainer	325-6184
6T-0241	Piston	325-6161
6T-0243	Plate - Thrust	325-6169
6T-0248	Ring - Seal	295-6440
6T-0443	Pinion - Shaft & Bevel	226-7999
6T-0511	Link As	290-3449
6T-0830	Housing As	297-7199
6T-0952	Pad As	367-6087
6T-0956	Pad As	367-6088
6T-0960	Pad As	367-6089
6T-1702	Support As	299-2065
6T-1705	Shaft - Pump Drive	283-5201
6T-1706	Gear - Pump Drive	283-5202
6T-1724	Bar As - Equalizer	283-5223
6T-1933	Collar - Idler End	226-2746
6T-1980	Collar - Idler End	226-0210
6T-3009	Piston - Clutch	297-7226
6T-3080	Plate& Brake	325-6170
6T-4481	Shaft - Planet	221-7946
6T-6053	Pinion - Shaft & Gear	226-6079
6T-6782	Segment Gp - Sprocket	188-5641 (sprocket)
6T-6987	Piston - Clutch	297-7227
6T-7882	Gear - Planet	296-1352
6T-8250	Retainer	319-3473
6W-0240	Bearing - Brace	297-7143
6W-1629	Shaft - Bevel Pinion	297-7250
6W-2398	Retainer	231-0014
6W-2451	Sprocket - Track	322-6376
6W-3674	Gear	231-0228
6W-4281	Yoke - Flange	308-9949
6W-4284	Cage - Bear-ing	308-9832
6W-7290	Shaft - Planet	308-9930
6W-7331	Cover As	308-9845
6Y-0305	Cage As - Bearing	297-7150
6Y-0580	Carrier - Planet	301-4768
6Y-0710	Gear	226-6104
6Y-0926	Gear - Planet	295-6427
6Y-0984	Gear - Ring	295-6428
6Y-1381	Shoe -Track	275-3564
6Y-1382	Shoe - Track	275-3565
6Y-1385	Shoe - Track	275-3570
6Y-1386	Shoe - Track	275-3571
6Y-1711	Link As	261-8008
6Y-1713	Link As	257-1993
6Y-2054	Plate As	302-2695
6Y-2192	Shoe - Track	288-6668
6Y-3896	Pin As	325-6132
6Y-4027	Pin	325-6148
6Y-4819	Carrier - Planet	296-1348
6Y-4840	Plate As	297-7233
6Y-5344	Shoe -Track	275-3566
6Y-5345	Shoe -Track	275-3567
6Y-5812	Bearing - Sleeve	325-6012
6Y-6126	Plate - Wear	325-6174
6Y-6127	Plate - Wear	325-6175
6Y-6134	Bearing - Sleeve	325-6013
6Y-6234	Bearing - Sleeve	325-6014
6Y-6236	Bearing - Sleeve	325-6024
6Y-6289	Shoe -Track	188-5270
6Y-6290	Shoe -Track Master	175-8728
6Y-6291	Shoe -Track	175-8031
6Y-6292	Shoe -Track Master	175-8032

(Continued)

Part Numbers Beginning with 6 (Continued)

Original Part Number	Part Name	Classic Part Number
6Y-6293	Shoe -Track	175-8369
6Y-6294	Shoe -Track Master	175-8370
6Y-6295	Shoe -Track	175-8371
6Y-6296	Shoe -Track Master	175-8372
6Y-6394	Shoe -Track Master	188-5591
6Y-6395	Shoe -Track	188-5396
6Y-6397	Shoe -Track Master	188-5594
6Y-6398	Shoe -Track	188-5593
6Y-6405	Shoe - Track	290-9938
6Y-6407	Shoe - Track	288-6679
6Y-6411	Shoe -Track	188-5397
6Y-6412	Shoe -Track Master	188-5592
6Y-6751	Pin	325-6149
6Y-6752	Pin	325-6150
6Y-6775	Pin	325-6151
6Y-6931	Shaft As	325-6206
6Y-7471	Pin - Pivot	325-6152
6Y-7474	Pin - Pivot	325-6153
6Y-7877	Housing As	297-7200
6Y-8184	Link As	289-4948
6Y-8248	Pin	325-6154
6Y-9468	Retainer As	325-6185
6Y-9930	Mount As	360-2353

Part Numbers Beginning with 7

Original Part Number	Part Name	Classic Part Number
7B-0503	Ballstud	308-9801
7B-2420	Ferrule - Director	314-8517
7B-5036	Shaft - Bracket	297-7251
7B-5088	Drum - Steering	223-4813
7C-0942	Adapter As	302-2636
7C-3039	Core, Oil Cooler	363-7451
7C-3567	Mount As	314-8689
7C-4297	Seal As - Camshaft	325-6192
7C-5851	Muffler As	298-2790
7C-5920	Insert - Seat	314-8528
7C-5921	Insert - Seat	314-8529
7C-5922	Insert - Seat	314-8530
7C-6398	Muffler As	360-7885
7D-2199	Sleeve As	228-9563
7D-2267	Link As	228-9564
7D-2637	Gear - Worm	231-8761
7D-3815	Gear - Final Drive	228-9419
7D-4519	Shaft	245-5807
7D-4523	Coupling	245-5817
7D-4688	Shaft As - Steering	228-9565
7D-5446	Shaft As - Control Drive	229-1616
7D-5813	Gear - Worm	228-8911
7D-5847	Pinion	228-8912
7D-5859	Adapter	297-7136
7D-5861	Adapter	243-0364
7D-6436	Pinion - Reverse	243-0344
7D-6516	Pinion - Reverse	243-0343
7D-6524	Shaft - Axle	228-8917
7D-6568	Cover As	228-9457
7D-6588	Worm	243-0362
7D-6841	Joint As - Univ	228-9566
7D-7075	Worm	243-0363
7D-7078	Shaft - Rev Worm	243-0355
7D-7289	Hub As Brake	229-1617
7D-7385	Shaft	228-9420
7D-7386	Shaft	228-9567
7D-7427	Sprocket	228-9458
7D-7442	Hub - Final Drive Gear	228-8918
7D-7854	Support - Rack	228-8913
7D-7889	Gear - Ring	275-5276
7E-0853	Muffler As	360-7887
7E-5663	Muffler As	247-2667
7F-6269	Gear - Worm	245-5798
7F-9263	Cap - Pivot	243-0336
7F-9541	Pin As - Drawbar	296-1361
7F-9547	Pin As - Drawbar	295-0414
7G-1013	Pump Gp	226-0170
7G-2037	Joint Gp - Univ	226-8017
7G-2038	Tube - Univ Joint	297-7268
7G-2474	Gear - Planet	300-2577
7G-2475	Gear - Planet	223-4815
7G-2476	Gear - Planet	223-4816
7G-2477	Gear - Planet	221-9090
7G-2480	Gear - Planet	226-6091
7G-2481	Gear - Planet	226-6092
7G-2485	Gear - Planet	226-7983
7G-2487	Gear - Planet	221-9092
7G-2492	Gear - Planet	239-7933
7G-2500	Gear - Planet	296-1350
7G-2511	Gear - Planet	260-0782
7G-2513	Gear - Planet	215-1734
7G-2516	Gear - Planet	283-5203
7G-2517	Gear - Planet	213-8747
7G-2520	Gear - Planet	221-9094
7G-2521	Gear - Planet	213-8749
7G-2522	Gear - Planet	216-7855
7G-2824	Piston	295-6439
7G-2828	Plate - Clutch	325-6171
7G-2830	Ring - Seal	295-6441
7G-3450	Gear - Planet	275-5289
7G-3451	Gear - Planet	297-7188
7G-3452	Gear - Planet	275-5290
7G-3454	Gear - Planet	300-2578
7G-3455	Gear - Planet	300-2582
7G-3456	Gear - Planet	300-2583
7G-3457	Gear - Planet	308-9857
7G-3461	Gear - Planet	275-5291
7G-3707	Piston - Clutch	302-2691
7G-3708	Piston - Clutch	300-2585
7G-3815	Pump Gp	226-0171
7G-4281	Housing As - Support	297-7201
7G-4302	Housing - Clutch	302-2708
7G-4306	Plate - Center	297-7229
7G-4758	Gear - Planet	288-8723
7G-5301	Pump Gp	217-2600
7G-5323	Pinion - Final Drive	231-8767

(Continued)

Part Numbers Beginning with 7 (Continued)

Original Part Number	Part Name	Classic Part Number
7G-5444	Carrier - Planet	297-7165
7G-5572	Gear - Sun	300-2580
7G-5589	Gear - Ring	281-1692
7G-5593	Gear - Sun	300-2581
7G-5614	Shaft - Planet	281-1697
7G-5618	Manifold As	283-5204
7G-5776	Shaft - Planet	325-6195
7G-5780	Shaft - Planet	325-6196
7G-5783	Gear - Planet	288-8724
7G-5784	Gear - Planet	288-8725
7G-6042	Cage As	216-7856
7G-6044	Cage As	216-7857
7G-6060	Plate - Center	302-2694
7G-6062	Gear - Ring	302-2678
7G-6489	Spring - Recoil	314-8722
7G-6576	Cage As	216-7859
7G-6681	Cage As	216-7860
7G-7013	Coupling - Pump Drive	295-5450
7G-7218	Carrier - Planet	283-5205
7G-7681	Shaft As	307-1530
7G-7724	Piston - Clutch	283-5206
7G-8389	Guard	226-0202
7G-8459	Hub - Gear	221-1070
7G-8513	Guard As	361-1714
7G-8517	Guard As	361-1715
7G-9555	Bearing - Spider	314-8721
7G-9721	Gear As - Oil Pump	297-7178
7G-9722	Gear - Pump Drive	297-7179
7H-0602	Dog - Clutch	314-8515
7H-1318	Coupling - Steering	226-8002
7H-2424	Sleeve - Spring	226-4852
7H-2742	Nut	229-8220
7H-3598	Bolt - Track	188-5636
7H-3599	Bolt - Track	188-5639
7H-4710	Bushing - Sleeve	299-1990
7H-7630	Spacer	239-7962
7I-6843	Pin	301-4766
7J-0086	Bearing As	256-4842
7J-1185	Bearing As	297-7146
7J-1309	Bearing - Aligning	360-2275
7J-1333	Bearing - Sleeve	295-6408
7J-1334	Bearing - Sleeve	325-6015
7J-3390	Pin - Hitch	256-4786
7J-4827	Yoke	299-2070
7J-5131	Trunnion	296-1371
7J-6461	Crown	325-6054
7J-6883	Shaft	256-4778
7J-6886	Pin	256-4787
7J-7488	Bearing	256-4836
7J-9344	Bearing - Sleeve	360-2334
7J-9366	Bearing - Sleeve	299-1985
7J-9682	Bearing - Sleeve	360-2335
7J-9707	Bearing - Sleeve	308-9821
7J-9708	Bearing - Sleeve	299-1964
7J-9731	Bearing - Sleeve	308-9822
7J-9732	Bearing - Sleeve	308-9823
7J-9814	Bearing - Sleeve	308-9824
7J-9842	Bearing - Sleeve	299-1968
7J-9884	Bearing - Sleeve	325-6016
7K-0078	Bearing - Sleeve	308-9825
7K-0252	Gear - Ring	231-0008
7K-0373	Pin As	308-9885
7K-0374	Pin As	308-9886
7K-0449	Yoke As	297-7271
7K-0450	Yoke As	297-7272
7K-0686	Trunnion - Rear	297-7266
7K-1311	Hub As - Sprocket	224-1313
7K-1818	Cover	308-9844
7K-3582	Nut - Adjusting	226-6099
7K-4458	Gear - Final Drive	226-6093
7K-4512	Pinion - Final Drive	226-6081
7K-4770	Pinion	226-6082
7K-4771	Gear	229-8221
7K-5213	Pin	252-6869
7K-6260	Shaft - Sector	308-9931
7K-6497	Pin	252-6870
7K-7102	Pin	308-9903
7K-7176	Pin	241-2570
7K-7195	Bearing - Sleeve	325-6025
7K-7200	Pin	241-2600
7K-7237	Gear - Planet	231-0009
7K-7613	Joint Gp - Slip	302-2689
7K-8237	Drum	226-6100
7K-8238	Flange	213-8166
7K-9343	Pin	241-2571
7K-9344	Pin	241-2607
7K-9345	Pin	241-2608
7K-9346	Pin	252-6871
7K-9347	Pin	252-6875
7K-9348	Pin	252-6872
7K-9360	Pin	319-3461
7K-9361	Pin	241-2565
7K-9366	Pin	241-2617
7K-9370	Pin	241-2618
7K-9371	Pin	241-2619
7K-9372	Pin	241-2577
7K-9373	Pin	241-2620
7K-9375	Pin	241-2621
7K-9488	Pin	241-2578
7K-9499	Pin	241-2579
7K-9502	Pin	241-2580
7K-9503	Pin	241-2581
7K-9504	Pin	241-2582
7K-9505	Pin	241-2583
7K-9506	Pin	241-2584
7K-9513	Pin	241-2596
7K-9514	Pin	241-2597
7K-9515	Pin	241-2589
7K-9528	Bearing - Sleeve	308-9828
7K-9530	Bearing - Sleeve	299-1967
7K-9591	Bearing - Sleeve	365-8826
7K-9593	Bearing - Sleeve	360-2337
7K-9601	Bearing - Sleeve	360-2338
7K-9602	Bearing - Sleeve	360-2339

(Continued)

Part Numbers Beginning with 7 (Continued)

Original Part Number	Part Name	Classic Part Number
7K-9604	Bearing - Sleeve	308-9829
7K-9638	Bearing - Sleeve	365-8827
7K-9639	Bearing - Sleeve	314-8643
7K-9642	Bearing - Sleeve	360-2340
7K-9644	Bearing - Sleeve	360-2341
7K-9981	Pin As	308-9887
7K-9988	Pin	308-9904
7K-9989	Pin	308-9905
7K-9990	Pin	308-9906
7K-9992	Pin	308-9907
7L-0104	Impeller - Pump	311-9395
7M-0457	Guard - Frame	226-0217
7M-0665	Bar As - Equalizer	231-3312
7M-0699	Cap - Brace Bearing	247-4123
7M-0820	Gear - Sliding	226-6086
7M-0859	Fork As - Shift	297-7172
7M-1184	Housing As	219-9704
7M-1185	Housing As	219-9705
7M-1186	Housing As	219-9706
7M-1195	Housing - Clutch	219-9707
7M-1249	Piston - Clutch	215-1748
7M-1776	Plate - Idler Guide	226-0222
7M-1840	Gear As - Ctrshft	214-0966
7M-1842	Gear As-ctr - Shft	214-0967
7M-1851	Bolt - Spring	226-0223
7M-1856	Pilot - Recoil Spring	226-0225
7M-1859	Pilot As - Spring	226-0207
7M-1861	Stop - Spring Rh	226-0228
7M-1862	Stop - Spring Lh	226-0229
7M-1889	Guard As	213-9108
7M-1890	Guard As - Final Drive Wear	213-9109
7M-2167	Ring - Governor Control	308-9919
7M-2531	Rod - Tie	297-7239
7M-4204	Manifold - Exhaust	261-0901
7M-4358	Manifold - Exhaust	261-0907
7M-4603	Body - Fuel Valve	311-9348
7M-4926	Retainer - Pin	314-8538
7M-5002	Drum - Steering	226-7992
7M-5050	Collar - Front Idler	226-4958
7M-5289	Hub - Steering	217-7736
7M-5756	Gear - Ring	214-0531
7M-6621	Pump Gp - Oil	226-0172
7M-7358	Valve - Inlet	298-2774
7M-7431	Service Gp - Valve	314-8550
7M-7817	Valve - Inlet	311-9474
7M-8395	Piston - Clutch	223-6322
7M-8397	Housing As	239-7956
7M-8453	Piston - Clutch	215-1755
7M-9398	Plate - Guide	297-7230
7N-0061	Muffler As	360-7889
7N-0110	Core As - Oil Cooler	319-3435
7N-0128	Core As - Oil Cooler	299-1994
7N-0165	Core As - Oil Cooler	295-5670
7N-1164	Mount As	295-5451
7N-2871	Line As - Fuel Injector	319-8172
7N-2872	Line As - Fuel Injector	319-8173
7N-2874	Line As - Fuel Injector	298-2779
7N-2875	Line As - Fuel Injector	298-2780
7N-2876	Line As - Fuel Injector	298-2781
7N-2949	Pulley	264-5887
7N-2957	Cover - Rad Cap	361-1722
7N-3350	Gear As - Pump Drive	319-3437
7N-3486	Manifold - Exhaust	261-0899
7N-3515	Gear - Camshaft	314-8669
7N-3536	Gear - Fuel	279-4993
7N-4515	Body As - Piston	311-9346
7N-5503	Gear - Camshaft Rr	233-2182
7N-5511	Gear As - Idler	233-2180
7N-5810	Gear As - Idler	233-2179
7N-5815	Gear - Camshaft Rr	233-2181
7N-5819	Gear - Hyd Pump Drive	215-1758
7N-5825	Gear - Drive	215-1759
7N-5910	Impeller - Pump	314-8686
7N-6677	Core As - Oil Cooler	299-1995
7N-8117	Muffler As	247-2668
7N-9145	Gear - Flywheel	279-4994
7N-9146	Gear - Flywheel Starter	279-4995
7N-9312	Damper As - Camshaft	299-2005
7N-9674	Muffler As	360-7892
7N-9805	Pin - Piston	295-6438
7N-9810	Pin - Piston	311-9432
7P-2372	Joint As	367-6072
7P-6596	Bearing - Sleeve	295-6409
7P-8370	Bearing	295-6410
7S-0706	Shoe -Track	175-8673
7S-1579	Nut - Spanner	239-7964
7S-2980	Plate - Reaction	226-5998
7S-3033	Hub - Clutch	226-5985
7S-3161	Lifter - Valve	279-4996
7S-4494	Piston - Clutch	226-5999
7S-4629	Pump Gp - Transfer	226-0158
7S-5787	Chamber As	247-3300
7S-6104	Gear - Sun	239-7934
7S-6531	Guard As - Rh	226-4939
7S-6532	Guard As - Lh	226-4940
7S-6537	Guard As - Rh Basic	226-4941

(Continued)

Part Numbers Beginning with 7 (Continued)

Original Part Number	Part Name	Classic Part Number
7S-6538	Guard As - Lh Basic	226-4942
7S-6723	Bracket - Alternator	299-1978
7S-6875	Pump Gp - Transmission	217-2601
7S-6902	Gear - Sun	229-1619
7S-6964	Gear - Ring	214-0532
7S-7070	Head As - Cylinder	325-6107
7S-7400	Pump Gp	226-0173
7S-7602	Pump Gp	226-0174
7S-7625	Support As	226-6095
7S-7809	Cap As - Radiator	295-6417
7S-7973	Guard - Final Drive Wear	213-9110
7S-7975	Guard - Final Drive Wear	239-7966
7S-8213	Guard As - Final Drive Wear	226-4943
7S-8214	Guard As - Final Drive Wear	226-4944
7S-8443	Muffler	247-2675
7S-8572	Gear - Ring	221-9095
7S-8631	Shaft As	275-5296
7S-8660	Pump Gp - Transmission	226-0175
7S-9093	Shoe -Track	188-5617
7S-9094	Shoe -Track	188-5313
7S-9096	Shoe -Track	281-6370
7S-9101	Shoe -Track	281-6372
7S-9567	Shoe -Track	175-8022
7S-9749	Pulley - Gen Drive	264-5888
7T-0119	Support As	299-2066
7T-0203	Guide	226-4959
7T-0204	Bearing - Brace	247-4126
7T-0205	Bearing - Brace	247-4127
7T-0206	Bearing - Brace	297-7144
7T-1285	Gear - Planet	297-7190
7T-1310	Rim -Track Sprocket	290-0861
7T-2036	Cap As - Filter	361-1721
7T-2092	Washer - Thrust	325-6238
7T-3173	Piston	346-5680
7T-3194	Yoke	346-5681
7T-3343	Plate - Clutch	297-7231
7T-3370	Yoke As	302-2702
7T-3952	Gear - Transfer	295-6429
7T-4562	Idler As	175-8263
7T-5038	Housing As	297-7202
7T-6427	Pin	319-3462
7T-8136	Shaft - Planet	314-8714
7T-9272	Gear - Sun	296-1354
7T-9370	Gear - Sun	283-5207
7T-9586	Bearing	314-8645
7T-9647	Piston - Clutch	275-5294
7T-9931	Countershaft	215-1760
7T-9963	Case As - Transfer Gear	219-9665
7V-3842	Spider Gp - Brg	367-6069
7V-5249	Shaft - Steering	215-1761
7V-5979	Gear	231-0238
7V-5981	Driver	231-0256
7V-6715	Pin As	361-1701
7V-6790	Shaft - Bevel Pinion	308-9922
7V-6898	Pin As	241-2539
7V-7017	Pinion Swing	231-0018
7V-7973	Gear Final Drive	231-0239
7V-7974	Pinion Final Drive	231-0253
7V-7976	Pinion - Swing Drive	231-0254
7W-0450	Gear - Water Pump	279-4997
7W-0507	Gear - Oil Pump Drive	279-4998
7W-0508	Gear - Fuel Pump Drive	296-1351
7W-1902	Adapter - Fuel Nozzle	299-1955
7W-2164	Core As - Oil Cooler	299-1996
7W-3042	Tube As - Drain	325-6231
7W-5194	Muffler As	346-5682
7W-5684	Pulley - Camshaft	298-2771
7W-5685	Pulley - Camshaft	298-2772
7W-5687	Hub - Camshaft	314-8684
7W-5698	Pulley - Camshaft	295-5679
7Y-0212	Gear - Ring	301-4681
7Y-0213	Gear - Planet	301-4760
7Y-0221	Gear - Planet	301-4758
7Y-0223	Shaft - Planet	301-4625
7Y-0224	Gear - Planet	301-4759
7Y-0225	Shaft - Planet	301-4571
7Y-0228	Carrier As	301-5239
7Y-0238	Gear - Sun	301-4689
7Y-0241	Carrier	301-4635
7Y-0242	Carrier	301-4637
7Y-0249	Gear - Sun	301-4694
7Y-0680	Piston	360-2262
7Y-1258	Piston	367-6091
7Y-1427	Gear - Sun	288-8727
7Y-1428	Gear - Planet	288-8728
7Y-1430	Gear - Sun	314-8671
7Y-1431	Gear - Planet	288-8729
7Y-1432	Carrier	314-8659
7Y-1461	Coupling	301-4649
7Y-1513	Pipe As - Exhaust	301-5249
7Y-1517	Pipe As - Tail	301-5246
7Y-1643	Gear - Sun	314-8670
7Y-1644	Gear - Planet	301-3406
7Y-1646	Shaft - Planet	301-4624
7Y-1687	Piston As	360-2266
7Y-1751	Carrier - Planet	314-8660
7Y-1752	Carrier - Planet	314-8661
7Y-1775	Shaft - Pinion	314-8718
7Y-1780	Cylinder	360-2261
7Y-2348	Pin	314-8697
7Y-2349	Pin	301-4556
7Y-2357	Pin	301-4564
7Y-2391	Link As	301-5240
7Y-2392	Link - Rh	301-4765
7Y-2395	Bearing - Sleeve	314-8646
7Y-2396	Bearing - Sleeve	314-8634
7Y-3427	Bearing - Sleeve	314-8635
7Y-3428	Bearing - Sleeve	314-8647
7Y-3549	Pin	360-2349

(Continued)

Part Numbers Beginning with 7 (Continued)

Original Part Number	Part Name	Classic Part Number
7Y-3550	Pin	360-2350
7Y-3552	Bearing - Sleeve	364-5266
7Y-3553	Bearing - Sleeve	301-0433

Original Part Number	Part Name	Classic Part Number
7Y-4666	Bearing - Sleeve	314-8636
7Y-5128	Bearing - Sleeve	314-8648

Original Part Number	Part Name	Classic Part Number
7Y-5131	Bearing - Sleeve	301-4626
7Y-6608	Bearing	314-8649
7Y-6626	Bearing	314-8650
7Y-6627	Pin As	314-8693

Part Numbers Beginning with 8

Original Part Number	Part Name	Classic Part Number
8B-5972	Bearing - Ball	314-8503
8D-0527	Gear	229-1621
8D-0682	Shaft	245-5806
8D-0926	Rod As - Tie Lh	228-9422
8D-0994	Rod As - Tie Rh	228-9459
8D-0995	Rod As - Tie Lh	228-9460
8D-1648	Disc	367-6070
8D-1769	Plate - Driving	229-1622
8D-1784	Pin	282-6567
8D-1833	Pin	364-5269
8D-2351	Pin	297-7217
8D-2429	Pin As	319-3445
8D-2452	Gear - Sun	297-7180
8D-2459	Gear - Planet	297-7181
8D-2469	Shaft - Drive	275-5280
8D-2519	Shaft - Planet	300-2591
8D-2532	Carrier - Planet	301-4773
8D-2628	Nut	299-2027
8D-3591	Carrier - Planet	301-4769
8D-3665	Pin	297-7218
8D-3744	Shaft - Drive	275-5283
8D-3877	Gear - Sun	275-5278
8D-4402	Yoke	365-8823
8D-4673	Pin - Cylinder	302-2711
8D-4766	Pin - Cylinder	365-8832
8D-5344	Gear - Worm	243-0341
8D-5346	Shaft - Drive Pinion	243-0350
8D-5347	Shaft - Drive Pinion	243-0352
8D-7096	Pin - Axle Leaning	297-7219
8D-7174	Cover As	299-1997
8D-7427	Shaft - Drive Pinion	282-6568
8D-8633	Shaft - Drive	275-5281

Original Part Number	Part Name	Classic Part Number
8D-8634	Gear - Planet	275-5275
8D-8638	Gear - Sun	275-5279
8D-8639	Gear - Ring	275-5277
8D-8805	Cover	299-2002
8D-8829	Bearing - Sleeve	361-1692
8D-9479	Gear - Diff Bevel	302-2670
8D-9482	Gear - Diff Bevel	302-2673
8D-9804	Housing - Drive	302-2682
8D-9815	Pin - Cylinder	297-7220
8E-3332	Shoe - Track	175-8184
8E-4275	Link As	288-3694
8E-4365	Segment Gp - Sprocket	188-5635 (sprocket group), 188-5589 (segment)
8E-4426	Shoe -Track	288-6671
8E-4427	Shoe -Track	288-6670
8E-4428	Shoe -Track	288-6669
8E-4429	Shoe - Track	288-6677
8E-4430	Shoe - Track	288-6676
8E-4434	Shoe -Track	188-5263
8E-4435	Shoe -Track Master	188-5264
8E-4436	Shoe -Track	188-5261
8E-4437	Shoe -Track Master	188-5262
8E-4499	Shoe -Track	188-5383
8E-4500	Shoe -Track Master	188-5387
8E-4501	Shoe -Track	188-5381
8E-4502	Shoe -Track Master	188-5385
8E-4576	Roller Gp - SF	288-3690
8E-4579	Roller Gp - SF	175-8216

Original Part Number	Part Name	Classic Part Number
8E-4675	Segment Gp - Sprocket	188-5599 (sprocket), 188-5638 (sprocket group)
8E-4713	Link As	288-3705
8E-4714	Link As	288-3693
8E-5450	Seal - Ebar	325-6190
8E-5600	Roller Gp - Carrier	286-9824
8E-5993	Gear As - Idler	215-1903
8E-6135	Idler Gp -Track	288-3691
8E-6221	Pin	325-6155
8E-6754	Connector As	325-6044
8E-6755	Bearing - Sleeve	325-6026
8E-6756	Bearing - Sleeve	325-6027
8E-7455	Gear - Planet	221-7947
8E-7456	Gear - Planet	221-7948
8E-7494	Roller Gp - SF	175-8185
8E-7857	Link As	290-0819
8E-7868	Shoe - Track	290-9940
8E-8643	Link As	288-5754
8E-8644	Link As	288-5755
8E-9214	Pin	325-6156
8E-9795	Connector As	256-4851
8E-9805	Sprocket	286-9821
8F-5104	Screen As - Oil Pan	314-8539
8F-7422	Gear - Worm	228-9461
8F-8858	Button Valve	314-8511
8F-9365	Pin	319-3463
8G-1682	Pin	241-2585
8G-3102	Piston	325-6162
8G-4187	Pin As	295-5676
8G-4189	Bearing - Aligning	295-6411
8G-4190	Seal - Ebar	296-1366

(Continued)

Part Numbers Beginning with 8 (Continued)

Original Part Number	Part Name	Classic Part Number
8G-8311	Bearing - Sleeve	295-6412
8H-1174	Drum - Steering	226-6101 (Drum), 231-1937 (Steering Clutch Kit)
8H-1383	Rod - Tie	299-2051
8H-1993	Valve - Inlet	256-4765 (Valve Kit)
8H-1994	Valve - Exhaust	256-4765 (Valve Kit)
8H-2300	Pinion - Final Drive	226-6083
8H-2434	Drum - Steering	216-7862
8H-2810	Case As - Filter	314-8512
8H-7810	Gear	213-8753
8H-7813	Collar	215-1780
8H-7980	Piston	226-0249
8H-9379	Nut - Brake Band Adjustable	299-2029
8H-9806	Gear - Shaft Drive	325-6091
8J-1300	Pin As	256-4788
8J-2022	Piston As - Pump	367-6073
8J-2652	Shaft	299-2054
8J-2653	Lever As	299-2015
8J-2654	Lever As	299-2016
8J-2880	Cap - Bearing	295-6420
8J-3431	Pin	256-4789
8J-5654	Bearing - Sleeve	325-6028
8J-7596	Bearing - Sleeve	361-1693
8K-0042	Gear - Differential Bevel	308-9850
8K-0323	Link As	290-3450
8K-0393	Pin	241-2548
8K-0442	Gear	231-0240
8K-0455	Pin	241-2547
8K-0518	Pin	241-2549
8K-0533	Bearing - Sleeve	314-8637
8K-0576	Cage - Bearing	231-0261
8K-0578	Spacer	231-0248
8K-0579	Retainer	231-0245
8K-0665	Cage - Bearing	231-0262
8K-1107	Rack - Disconnect	231-0264
8K-1317	Shaft	231-0019
8K-1749	Shaft - Sprocket	231-0242
8K-1754	Spacer	231-0247
8K-1755	Retainer - Cap	231-0246
8K-1756	Cage - Bearing	231-0263
8K-1940	Retainer As	231-0258
8K-1944	Case As - Swing Drive	231-0265
8K-1945	Shaft As - Output	231-0266
8K-1946	Retainer As	231-0259
8K-2518	Joint As	231-0267
8K-2682	Adapter	231-0268
8K-2743	Sprocket - Track	289-2206
8K-2779	Cage - Bearing	231-0483
8K-2860	Flange - Coupling	297-7171
8K-2956	Pin	241-2550
8K-3712	Pin As	241-2541
8K-4127	Gear Gp - Bearing & Basic	235-5055
8K-4296	Pin	241-2555
8K-4699	Link As	290-3451
8K-4753	Link As	290-0837
8K-4764	Pin	241-2556
8K-5283	Plate	299-2043
8K-5334	Pin	241-2598
8K-5587	Rod Gp - Recoil	226-4954
8K-5757	Bearing - Sleeve	367-6076
8K-5758	Pin	241-2566
8K-5991	Gear - Diff Bevel	253-1439
8K-5999	Gear - Sun	253-1440
8K-6015	Gear - Bevel Ring	221-9076
8K-6282	Gear - Sun	281-1698
8K-6283	Gear - Sun	221-9077
8K-6285	Shaft - Axle	299-2057
8K-6320	Shaft - Axle	253-1430
8K-6321	Gear - Sun	253-1441
8K-6357	Pin	241-2586
8K-6358	Pin	241-2587
8K-6359	Pin	241-2588
8K-9661	Gear - Bevel	213-8218
8L-3972	Baffle	311-9345
8L-4529	Pulley - Alternator	264-5889
8M-0493	Cage - Outer Bearing	216-7866
8M-0874	Plunger As - Valve	311-9439
8M-2549	Rod As - Connector	314-8537
8M-3224	Muffler	247-2676
8M-4014	Insert - Seat Exhaust	311-9398
8M-6191	Sleeve - Bolt	226-0234
8M-6219	Spring - Equalizer	293-7606
8M-6615	Leaf - Spring	293-7607
8M-6616	Leaf - Spring	293-7608
8M-6676	Cylinder - Adjustable	226-4960
8M-7166	Housing - Screen	297-7192
8M-7207	Guard As - Rh	226-0236
8M-7208	Guard As - Frame	226-0237
8M-8161	Flange - Shaft	215-1781
8M-8619	Cage - Bearing	217-7725
8M-8623	Gear - Sun	213-8755
8M-8628	Flange - Joint	217-9776
8M-8642	Housing - Clutch	219-9669
8M-8644	Housing - Clutch	215-1782
8M-8646	Plate As - Center	216-3583
8M-8649	Piston - Clutch	217-9777
8M-8650	Piston - Clutch	217-9778
8M-8652	Shaft	297-7252
8M-8677	Carrier - Planet	213-4449
8N-0002	Trunnion As	314-8728
8N-0597	Pulley	264-5890
8N-0875	Valve - Exhaust	247-6893 (Valve), 241-3381 (Valve Kit)

(Continued)

Part Numbers Beginning with 8 (Continued)

Original Part Number	Part Name	Classic Part Number
8N-1187	Head Gp - Cylinder	242-3435
8N-1188	Head Gp - Cylinder	242-3436
8N-1214	Mount As	325-6125
8N-1721	Rod As - Conn	269-5291
8N-1965	Tube - Disposal	325-6235
8N-1984	Rod As - Conn	242-3441
8N-2275	Bearing - Sleeve	311-9365
8N-2510	Shaft	325-6208
8N-2641	Sleeve	325-6210
8N-3180	Body As - Piston	250-6563
8N-3181	Piston Gp - Basic	250-6555 (Liner Kit)
8N-3182	Body As - Piston	250-6564 (Piston As), 250-6556 (Liner Kits)
8N-3183	Piston Gp - Basic	250-6556 (Liner Kit)
8N-3251	Shaft As - Rocker Arm	314-8711
8N-3311	Shaft As - Rocker Arm	325-6199
8N-3312	Shaft As - Rocker Arm	325-6200
8N-3325	Arm Gp - Rocker	314-8623
8N-3327	Arm Gp - Rocker	314-8624
8N-3723	Valve - Exhaust	311-9472
8N-5305	Spacer	363-7464
8N-5388	Muffler As	360-7895
8N-5779	Coupling - Exhaust	325-6047
8N-5929	Cover - Water Pump	296-1349
8N-6004	Head As - Cylinder	247-3369
8N-6796	Head Gp - Cylinder	269-5290
8N-7315	Tube As - Outlet	325-6232
8N-7769	Bearing - Conn Rod	314-8505
8N-7770	Bearing - Conn Rod	314-8506
8N-7771	Bearing - Conn Rod	314-8507
8N-7780	Shield - Oil	314-8544
8N-8225	Bearing - Main	314-8652
8N-9174	Liner - Cylinder	314-8531
8N-9402	Coupling	325-6048
8N-9489	Chamber As	247-3301
8N-9733	Line As - Fuel Injector	319-8174
8P-0025	Gear - Idler	217-7721
8P-0187	Nut - Adjusting	219-9676
8P-0203	Drum	226-8004
8P-0514	Yoke As	308-9947
8P-0605	Gear - First Reduction	213-8453
8P-0606	Pinion - Sec Reduction	215-1783
8P-0622	Hub - Sprocket	288-8731
8P-0769	Hub - Turbine	308-9870
8P-0953	Turbine - Converter	297-7269
8P-0957	Impeller - Converter	297-7209
8P-1121	Ring - Clamp	299-2049
8P-1182	Shaft	227-4771
8P-1183	Gear - Bevel	226-7980
8P-1324	Cage - Gr Shft Bearing	229-8239
8P-1325	Hub - Steering	226-8005
8P-1326	Pilot - Piston	226-6097
8P-1327	Pinion - Final Drive	226-8000
8P-1328	Flange - Drive Drum	226-8006
8P-1353	Piston - Steering	226-8007
8P-1656	Plate - Clutch	367-6071
8P-1774	Pinion - Final Drive	226-8001
8P-1851	Hub As - Sprocket	224-1314
8P-1853	Nut - Adjusting	226-7997
8P-1855	Hub As - Sprocket	227-4770
8P-1865	Bar As - Equalizer	231-3313
8P-1892	Piston - Clutch	283-5208
8P-1916	Gear - Planet	283-5209
8P-1918	Gear - Planet	283-5210
8P-1919	Gear - Planet	300-2579
8P-2042	Shaft - Planet	283-5211
8P-2430	Shaft As	297-7258
8P-3252	Pin	319-3464
8P-4111	Guard As	226-4945
8P-4112	Guard As	226-4946
8P-4537	Pinion - Reduction	216-7867
8P-4538	Gear - First Reduction	216-7868
8P-4539	Pinion - Final Drive	217-7711
8P-4734	Housing As	239-7955
8P-4735	Piston - Clutch	239-7949
8P-5117	Rod Gp - Track Adjustable	226-2747
8P-5197	Bearing As	295-6413
8P-5849	Plate As	223-6323
8P-6256	Roller Gp - Carrier	188-5612
8P-6274	Guard As - Lh	226-4949
8P-6275	Guard As - Rh	226-0191
8P-6495	Drum	213-6954 (Drum), 227-9302 (Steering Clutch Kit)
8P-6803	Shaft As	215-1842
8P-6949	Plate - Retainer	260-0787
8P-7396	Hub - Planet Gear	239-7967
8P-7595	Washer - Thrust	239-7940
8P-7639	Gear - Planet	239-7935
8P-7790	Valve Gp - Press	247-4437
8P-8221	Plate - Guide	226-2748
8P-8570	Pilot As - Piston	226-6097
8P-8677	Hub - Impeller	297-7205
8P-9507	Piston - Clutch	283-5212
8P-9657	Pin	241-2622
8P-9658	Pin	241-2623

(Continued)

Part Numbers Beginning with 8 (Continued)

Original Part Number	Part Name	Classic Part Number
8R-0931	Housing - Pinion	302-4300
8R-3252	Shaft - Planet	297-7259
8R-3787	Shaft	299-2058
8R-3921	Collet	308-9839
8R-3943	Collet	308-9840
8R-3946	Collet	308-9841
8R-4821	Carrier - Planet	308-9837
8R-7336	Bearing	301-3394
8R-7425	Retainer	308-9917
8R-9798	Plate - Lock	308-9912
8S-0248	Breather As	325-6033
8S-0386	Shoe -Track Master	188-5312
8S-0387	Shoe -Track Master	188-5614
8S-0388	Shoe -Track Master	188-5616
8S-0390	Shoe -Track Master	281-6371
8S-0391	Shoe -Track Master	188-5618
8S-0392	Shoe -Track Master	188-5314
8S-0394	Shoe -Track Master	315-6693
8S-0395	Bolt Master	188-5640
8S-0493	Shaft As - Pump	325-6198
8S-0556	Coupling	221-9114
8S-0569	Gear - Transfer	213-8754
8S-0573	Gear - Transfer	215-1844
8S-0905	Muffler As	302-2690
8S-0915	Shoe -Track Master	281-6374
8S-1061	Pilot As - Spring	226-0227
8S-1194	Shaft - Sprocket	217-7733
8S-1198	Hub - Gear	219-2969
8S-1831	Guard As - Sprocket	226-4947
8S-1832	Guard As - Sprocket	226-4948
8S-2123	Cage - Final Drive Bearing	217-7726
8S-2126	Spacer - Hub Bearing	222-1767
8S-2140	Trunnion - Gear	226-8020
8S-2560	Idler Gp, Idler As.	200-9235 (Complete Idler Group), 175-8255 (Idler As.)
8S-2809	Muffler	247-2677
8S-3487	Gear As - Ring	221-7949
8S-3491	Housing As	221-7950
8S-3617	Chamber As	247-3302
8S-3970	Chamber As	242-3438
8S-5438	Muffler As	360-7896
8S-5722	Plate - Pressure	226-8009
8S-7716	Manifold - Exhaust	295-0415
8S-7717	Manifold - Exhaust	261-0894
8S-7718	Manifold - Exhaust	295-0416
8S-7818	Bracket	226-0211
8S-9070	Carrier - Front	213-4464
8S-9071	Cage - Bearing	216-7869
8S-9184	Gear As	260-0785
8V-1613	Lever	299-2017
8V-1624	Lever	299-2019
8V-2631	Pin As	241-2526
8V-2632	Pin As	241-2523
8V-2634	Pin As	241-2518
8V-2639	Pin As	241-2542
8V-3134	Pinion - Bevel	260-0788
8V-3135	Gear - Differential Bevel	260-0783
8V-3136	Gear - Differential Bevel	253-1442
8V-5439	Pin As	241-2531
8V-6382	Hub As	308-9868
8V-6384	Spacer As	308-9935
8V-7175	Pin	241-2567
8V-7176	Pin	241-2568
8V-7659	Pin As	361-1702
8V-7884	Housing - Support	302-2681
8V-7885	Housing - Support	297-7193
8W-1751	Bracket As	288-8732
8W-1752	Bracket - Rail	288-8733
8W-1753	Bracket - Rail	288-8734
8W-2307	Shaft - Planet	275-5284
8W-2308	Shaft - Planet	275-5285
8W-4066	Bracket - Rail	288-8735
8W-4067	Bracket - Rail	288-8736
8W-4167	Bearing - Sleeve	361-1694
8W-5092	Pinion - Circle Drive	282-6569
8W-5293	Pin	282-6570
8W-6497	Pin	319-3465
8W-8286	Sprocket	299-2061
8W-8288	Sprocket	299-2062
8W-8289	Sprocket	282-6629
8W-8317	Sprocket	275-5287
8W-8628	Spindle - Front Axle	282-6571
8Y-1198	Strip	325-6220
8Y-1199	Strip	325-6221
8Y-1624	Guard As	295-6432
8Y-1625	Guard As	295-6433

Part Numbers Beginning with 9

Original Part Number	Part Name	Classic Part Number
9C-0624	Pin As	361-1709
9C-0625	Pin As	308-9888
9C-1484	Pin As	319-3446
9C-1528	Gear - Planet	223-4802
9C-1618	Gear	231-0229
9C-2646	Sprocket - Track	289-9674
9C-3187	Pin As	314-8694
9C-4080	Yoke - Brake	302-2703
9C-4211	Pin As	241-2519
9C-4737	Pin As	241-2520
9C-4811	Hub As	224-1300
9C-4912	Pin As	241-2517
9C-5060	Link As - Bearing	299-2022

(Continued)

Part Numbers Beginning with 9 (Continued)

Original Part Number	Part Name	Classic Part Number
9C-5852	Hub As	297-7208
9C-6015	Pinion - Diff Bevel	297-7225
9C-6017	Gear - Diff Bevel	297-7187
9C-6027	Carrier - Planet	297-7166
9C-6187	Pin As	241-2521
9C-6244	Gear	231-0230
9C-6544	Drum - Brake	297-7169
9C-8074	Gear - Planet	308-9858
9C-8075	Gear - Sun	308-9864
9C-8204	Shaft - Bevel Pinion	319-3474
9C-8205	Gear - Bevel	319-8175
9C-8218	Shaft - Bevel Pinion	302-2697
9C-8219	Gear - Bevel	297-7186
9C-8277	Gear - Bevel	308-9851
9C-9191	Trunnion	302-2701
9C-9748	Gear - Differential Bevel	302-2671
9C-9773	Gear - Differential Bevel	302-2672
9D-0120	Gear - Planet	288-8737
9D-0127	Gear - Sun	288-8738
9D-1177	Shaft - Drive Pinion	297-7253
9D-1487	Housing - Drive	297-7194
9D-2716	Spindle - Wheel	228-9463
9D-2731	Spindle - Wheel	228-9423
9D-4441	Housing	297-7195
9D-5741	Worm - Circle Drive	297-7270
9D-5746	Gear - Worm	299-2011
9D-5921	Shaft - Drive Pinion	297-7254
9D-6638	Strip - Wear	297-7263
9D-7924	Mounting	360-2356
9D-9665	Bracket - Cylinder Mtg	299-1980
9F-5224	Gear - Final Drive	226-6094
9F-7101	Bushing - Collar	299-1988
9G-0280	Piston - Clutch	283-5213
9G-0284	Housing - Clutch	283-5214
9G-0285	Piston - Clutch	283-5215
9G-0289	Shaft - Planet	283-5216
9G-0290	Hub - Clutch	283-5217
9G-0383	Hub - Gear	221-1064
9G-1231	Plate	297-7232
9G-1491	Carrier - Planet	281-1685
9G-1499	Gear - Oil Pump	295-6424
9G-2413	Shaft - Output	297-7255
9G-3526	Gear - Pump Drive	231-8763
9G-6476	Rod Gp - Idler Recoil	226-0198
9G-7411	Gear - Oil Pump Drive	297-7182
9G-7412	Gear As - Oil Pump	297-7183
9G-7993	Cage - Gr Bearing Rh	239-7973
9G-8117	Housing As	302-2686
9G-8246	Rod Gp - Idler Recoil	226-4955
9G-8302	Guide	226-4853
9G-8303	Collar - Idler End	226-0242
9G-8638	Gear - Planet	295-6425
9G-9174	Gear - Sun	295-6430
9G-9178	Spindle	295-6443
9G-9180	Hub - Sprocket	295-6436
9G-9183	Shaft	295-0417
9G-9349	Retainer	295-0411
9G-9543	Gear - Oil Pump	295-6426
9G-9764	Yoke As	319-3478
9H-1918	Gear - Bevel	219-9698
9H-1980	Pinion - Bevel	219-9699
9H-2256	Pump Gp	311-9443
9H-4104	Pilot - Spring	226-4962
9H-5233	Piston - Clutch	219-9708
9H-5433	Spacer	239-7963
9H-6980	Shaft - Pinion	226-6110
9H-7670	Piston	226-4961
9J-0123	Trunnion	325-6227
9J-0940	Pin	319-3467
9J-1105	Pin As	256-4790
9J-2332	Bearing - Pivot	299-1969
9J-2365	Retainer	325-6186
9J-3346	Plate As - Trunnion	256-4839
9J-5273	Trunnion As	256-4848
9J-5875	Bearing - Sleeve	308-9830
9J-7964	Bearing - Spherical	325-6017
9J-8323	Trunnion	361-1713
9J-8427	Bracket	299-1984
9J-9147	Nut	299-2028
9J-9427	Bearing - Sleeve	361-1695
9J-9543	Pin As	256-4791
9J-9598	Pin	296-1362
9K-0092	Pinion	231-0484
9K-0198	Gear - Sun	308-9865
9K-0424	Shaft - Pinion	215-1874
9K-0447	Shaft - Bevel Pinion	216-7870
9K-1193	Gear - Sun	221-9099
9K-1759	Carrier - Planet	221-9113
9K-1773	Gear - Ring	221-9100
9K-3413	Gear - Bevel Ring	223-4807
9K-3565	Shoe - Track	290-9941
9K-3568	Shoe - Track	290-9942
9K-6841	Cage As	216-7871
9K-6842	Cage As	216-7872
9K-8425	Bearing - Sleeve	314-8638
9K-8427	Pin As	241-2527
9K-8428	Pin As	241-2533
9K-8430	Pin As	241-2540
9K-8435	Pin	241-2552
9K-8757	Rod End - Bearing	311-9361
9K-9156	Retainer As	297-7236
9K-9158	Bearing - Sleeve	299-1970
9K-9271	Holder As - Cage	217-7730
9K-9273	Nut - Adjusting	226-7998
9L-6371	Rod	363-7459
9M-0701	Piston - Steer	219-9692
9M-0702	Pilot - Piston	229-8232
9M-1328	Bearing - Aligning	325-6018
9M-1500	Shaft - Planet	219-9685

(Continued)

Part Numbers Beginning with 9 (Continued)

Original Part Number	Part Name	Classic Part Number
9M-1502	Cage - Bearing	219-9686
9M-1995	Gear - Sun	213-8756
9M-1996	Shaft - Planet	215-1875
9M-2013	Housing As	216-3585
9M-2028	Gear - Sun	214-0959
9M-2038	Gear - Transfer Driven	215-1876
9M-2039	Gear - Transfer Driving	219-9672
9M-2045	Pinion - Bevel	215-1878
9M-2049	Gear - Ring	214-0533
9M-3025	Cover As	299-2001
9M-4163	Valve - Exhaust	298-2773
9M-4789	Shaft - Gov Control	297-7256
9M-4955	Pump Gp - Fuel Transfer	242-3443
9M-5045	Guard As - Wear	213-9111
9M-8117	Shaft - Flywheel Clutch	226-6073
9M-8119	Retainer - Inlet	226-8022
9M-8281	Gear As - Oil Pump	325-6089
9M-8284	Pump Gp - Transmission	226-0159
9N-4460	Housing As	297-7203
9N-4622	Pin	319-3468
9N-5251	Piston Gp - Basic	250-6557 (Liner Kit)
9N-5404	Piston Gp - Basic	250-6558 (Liner Kit)
9N-5769	Cover - Housing	325-6050
9N-6611	Pulley	325-6177
9P-0418	Cage	223-6311
9P-0620	Cage - Pinion Bearing	221-1052
9P-1779	Bearing - Sleeve	325-6029
9P-3242	Plate - Clutch	325-6172
9P-3436	Holder As - Cage	216-7875
9P-3663	Carrier - Planet	213-6939
9P-3731	Carrier - Planet	301-4767
9P-4859	Cage As - Bearing	297-7151
9P-5363	Piston - Clutch	219-9687
9P-5379	Housing - Clutch	215-1904
9P-6592	Gear - Planet	215-1915
9P-6594	Gear - Planet	215-1921
9P-6888	Shaft - Output	221-9105
9P-7757	Gear - Sun	283-5218
9P-8283	Plate - Clutch	296-1364
9P-8452	Hub - Output	297-7206
9P-8455	Cage As - Bearing	297-7152
9P-8521	Gear - Ring	296-1353
9P-8623	Shaft - Planet	314-8719
9P-8624	Shaft - Planet	295-5446
9P-8626	Gear - Sun	283-5219
9P-8866	Gear - Transfer	299-2012
9P-9000	Shaft - Steering	217-7738
9P-9031	Gear - Sun	283-5220
9P-9360	Gear - First Reduction	213-8454
9P-9361	Gear - Final Drive	223-4809
9P-9362	Pinion - Final Drive	215-1944
9P-9363	Pinion - Reduction	219-9677
9P-9517	Stator - Converter	297-7262
9P-9575	Cage - Bevel Gr Bearing	216-7876
9P-9610	Pump Gp	283-5221
9P-9742	Cage As - Bearing	297-7153
9P-9790	Shaft - Output	302-2696
9R-0080	Coupling	346-5683
9R-0097	Pin	346-5684
9R-0237	Pin As	346-5685
9R-0424	Pin	346-5686
9R-2410	Retainer As	346-5688
9R-2421	Shaft	346-5689
9R-2424	Gear - Planet Sun	346-5690
9R-2476	Disc - Bk Rear	346-5691
9R-2477	Disc As	346-5692
9R-2491	Spider	346-5693
9R-2846	Pin	346-5694
9R-2956	Pin	346-5695
9R-3161	Shaft - Sun Gear	346-5696
9R-3933	Pin	346-5697
9R-6158	Pin	346-5698
9R-6159	Pin	346-5699
9R-6160	Pin	346-5700
9R-6163	Pin	346-5701
9R-6475	Pad As	346-5702
9R-6545	Pin	346-5703
9R-7092	Bar	364-5272
9R-7158	Pin As	346-5704
9R-7696	Pin	346-5705
9R-7894	Pin As	346-5706
9R-7895	Pin As	346-5707
9R-8202	Pin	346-5708
9R-8206	Pin	346-5709
9R-8523	Pin	346-5710
9R-8579	Pin	346-5711
9R-8639	Cylinder	346-5712
9R-8662	Pin	346-5713
9R-8663	Pin	365-8831
9R-8707	Pin	346-5714
9R-8709	Pin	346-5715
9R-8715	Spider and Bearing As	346-5716
9R-8718	Yoke As	364-5258
9R-9049	Pin	346-5717
9R-9190	Rod Gp - Tie	346-5718
9R-9400	Case As	346-5719
9R-9402	Seal - Rax	347-0476
9R-9403	Pinion	347-0477
9R-9631	Pin	347-0467
9R-9812	Pin	347-0468
9S-1026	Cage - Gear Bearing	216-7873
9S-1043	Guard As - Guiding	226-0240
9S-1044	Guard As - Guiding	226-0241
9S-1045	Strip - Guard	226-0246
9S-1046	Strip - Guard	226-0247
9S-1838	Bolt Master	188-5634
9S-2354	Manifold - Exhaust	261-0888
9S-2355	Manifold - Exhaust	261-0891
9S-2356	Manifold - Exhaust	261-0905
9S-3321	Cage - Pinion Bearing	226-7974

(Continued)

Part Numbers Beginning with 9 (Continued)

Original Part Number	Part Name	Classic Part Number
9S-3955	Cage - Gear Bearing	216-7874
9S-4732	Guard Gp - Spring	226-0195
9S-5265	Shaft As	215-1945
9S-5277	Gear - Transfer	213-8758
9S-6129	Pulley - Alternator Drive	264-5891
9S-6590	Pump Gp - Oil	226-0176
9S-6743	Chamber As	247-3303
9S-6788	Pump Gp - Oil	217-2602
9S-6875	Pinion - Final Drive	217-7705
9S-6948	Shaft - Center	213-9966
9S-7079	Muffler As	247-2669
9S-7221	Idler As.	188-5610
9S-8245	Strip - Track	226-0243
9S-8246	Strip - Track	226-0244
9S-8251	Guard As - Roller	226-0180
9S-8252	Guard As - Roller	226-0181
9S-8253	Guard As - Roller	226-0182
9S-8257	Guard As - Guiding	226-0238
9S-8258	Guard As - Guiding	226-0239
9S-8353	Strip - Track	226-4854
9S-8354	Strip - Track	226-4855
9S-8358	Guard As - Guiding	226-4856
9S-8359	Guard As - Guiding	226-4857
9S-8493	Bolt - Connecting Rod	311-9351
9S-8679	Chamber As	325-6042
9S-8789	Plate - Clutch	302-2712
9S-8802	Gear - Ring	214-0952
9S-9385	Gear As - Oil Pump	297-7185
9T-0064	Bearing	361-1706
9T-0066	Trunnion	325-6228
9T-2373	Head	347-0461
9T-4761	Head	325-6108
9T-4762	Head	325-6109
9T-6526	Joint As - Univ	365-8824
9T-8424	Bearing - Sleeve	325-6030
9U-0654	Coupling	297-7167
9U-2400	Housing As	231-0249
9U-2787	Gear - Planet	367-6093
9U-3124	Gear - Planet	288-8806
9U-3125	Gear - Sun	288-8807
9U-8481	Pin As	295-5675
9V-2410	Housing - Bearing	302-2679
9V-2411	Housing - Bearing	302-2680
9V-3853	Pin	319-3469
9V-4333	Gear - Oil Pump Input	226-6105
9V-6523	Cap	297-7162
9V-6524	Cap	297-7163
9V-6775	Drum	226-7994
9V-7860	Support As - Front	308-9938
9W-0099	Bearing - Sleeve	314-8639
9W-0318	Spacer	325-6218
9W-0517	Carrier - Planet	281-1686
9W-0550	Shaft - Transmission Upper	226-6000
9W-0552	Shaft - Pinion	226-6001
9W-0876	Bearing - Sleeve	325-6031
9W-1677	Bearing	297-7145
9W-2344	Coupling - Pump Drive	314-8666
9W-2579	Plate	314-8701
9W-3361	Nut - Track	200-9127
9W-3605	Carrier - Ring	314-8662
9W-3619	Bolt - Track	286-9828
9W-4702	Stator - Converter	308-9939
9W-4897	Bracket As	295-6414
9W-4949	Carrier - Planet	281-1687
9W-4950	Gear - Sun	281-1688
9W-6358	Drum - Steering	226-7995
9W-6433	Impeller - Converter	308-9871
9W-6435	Flange - Drive	308-9846
9W-6483	Shoe - Track	288-6672, 288-6673
9W-7481	Gear - Planet	295-6431
9W-7839	Carrier - Planet	295-6421
9W-8270	Gear - Ring	308-9859
9W-8384	Hub - Turbine	297-7207
9W-8433	Shaft As - Output	302-4249
9W-8437	Gear - Sun	283-5222
9W-8937	Link As	188-5310
9W-9069	Shaft - Input	302-2715
9W-9351	Shoe -Track	286-9825
9W-9930	Mount As	295-6437
9Y-2988	Breather As	361-1716
9Y-2992	Bearing - Sleeve	325-6032
9Y-9431	Precleaner As	361-1718

PECJ0051-03
www.cat.com

© 2011 Caterpillar • All Rights Reserved • Printed in USA

CAT, CATERPILLAR, their respective logos, “Caterpillar Yellow” and the “Power Edge” trade dress, as well as corporate and product identity used herein, are trademarks of Caterpillar and may not be used without permission.