

**FRENIC**  
5000P11

# FRENIC 5000G11S FRENIC 5000P11S

**FUJI INVERTERS**

Now with dynamic torque vector control:  
Optimum control for all situations.



# I



deal combination of power and multiple-function.  
Dynamic torque-vector control promises  
optimum motor control under any operating conditions.

## 1. Dynamic torque-vector control



Dynamic torque-vector control system performs high-speed calculation to determine the required motor power for the load status. Our key technology is optimal control of voltage and current vectors for maximum output torque.


- A high starting torque of 200% at 0.5Hz.\*  
\* 180% for 30kW or larger models.
- Achieves smooth acceleration/deceleration in the shortest time for the load condition.
- Using a high-speed CPU quickly responds to an abrupt load change, detects the regenerated power to control the deceleration time. This automatic deceleration function greatly reduces the inverter tripping.
- Feedback control with PG  
Enables the inverter to execute "vector control with PG" by adding an optional PG feedback card to obtain higher performance.
  - Speed control range : 1:1200
  - Speed control accuracy :  $\pm 0.02\%$
  - Speed control response : 40Hz



## 2. Reduced motor wow at low speed



- Motor wow at low speed (1Hz) reduced to less than 1/2 of that achieved by conventional inverters, with the dynamic torque-vector control system, in combination with the Fuji's unique digital AVR.






# G11S/P11S

## 3. New on-line tuning system



- On-line tuning to continuously check for variation of motor characteristics during running for high-precision speed control.
- This tuning function also available for a second motor, which allows high-precision driving of the second motor by changeover operation between two motors.



## 4. Environment-friendly features



- Provided with low-noise control power supply systems which minimize noise interference on peripheral devices such as sensors.
- Equipped with terminals for connecting DC REACTOR that can suppress harmonics.
- Complied with EMC Directive (Emission) when connected to optional EMC-compliance filter.




## 5. Advanced, convenient functions




- 16-step speed with timer control, rotating motor pick-up control for conveyance machinery
- Automatic energy-saving operation, PID control, cooling fan on/off control, line/inverter changeover operation for fans and pumps
- Rotating motor pick-up control:  
Restarts motor without any shocks, by detecting motor speed where motor is coasting after momentary power failure occurs.
- Automatic energy-saving operation function:  
Minimizes inverter and motor loss at light load.

Rotating motor pick-up control characteristics (Sample:3.7kW)



Energy saving effect



## 6. Global products, communication



- Conforms to major world safety standards: UL, cUL, TÜV (up to 22kW), EN (CE marking)
- Equipped with RS-485 interface as standard.
- Connection to field bus: PROFIBUS-DP, Interbus-S, DeviceNet, Modbus Plus (Option)
- Universal DI/DO : Monitors digital I/O signal status and transmits to a host controller, helping to simplify factory automation.



### Safety Precautions

1. Use the contents of this catalog only for selecting product types and models. When using a product, read the Instruction Manual beforehand to use the product correctly.
2. Products introduced in this catalog have not been designed or manufactured for such applications in a system or equipment that will affect human bodies or lives. Customers, who want to use the products introduced in this catalog for special systems or devices such as for atomic-energy control, aerospace use, medical use, and traffic control, are requested to consult the Fuji's Sales Division. Customers are requested to prepare safety measures when they apply the products introduced in this catalog to such systems or facilities that will affect human lives or cause severe damage to property if the products become faulty.

## 7. Intelligent Keypad panel



- Copy function: Easily copies function codes and data to other inverters.
- Six languages (English, French, German, Italian, Spanish, and Japanese) are available as standard.
- Jogging (inching) operation from the Keypad or external signal
- Remote operation using optional extension cable (CBIII-10R-□□□□)



## 8. Protective functions, Maintenance



### Protection

- Motors with various characteristics can be used by setting thermal time constant for the electronic thermal overload protection.
- Input phase loss protective function protects the inverter from damage caused by disconnection of power supply lines.
- Motor is protected with a PTC thermistor.
- Input terminals for auxiliary control power supply (1.5kW or larger models) : Alarm signal output will be held even if main circuit power supply has shut down.

### Excellent maintainability

The items below can be monitored on the Keypad panel and making it easy to analyze the cause of trip and to take preventive measures.

- Input/output terminals check
- Life expectancy of main-circuit capacitors
- Inverter on-load factor
- Accumulated operation time
- Inverter operating condition (output current, heat sink temperature, input power, etc.)
- Detailed data on trip cause


## 9. Extensive product line



- Two series are available: G11S series ranging from 0.2 to 630kW for general industrial machines and P11S series ranging from 5.5 to 710kW for fans and pumps.
- Totally-enclosed casing (IP40) (up to 22kW as standard).
- Optional IP20 enclosure available for 30kW or larger models.
- Water-proof models (IP65 for 7.5kW or smaller, IP54 for 11 to 22kW) as a separate series (available soon).

## 10. Other useful functions

- Side-by-side mounting (up to 22kW) saves space when inverters are installed in a panel.
- The uniform height (260mm) of products (up to 7.5kW) makes it easy to design panels.
- User-definable control terminals: Digital input (9 points), transistor output (4points), and relay contact output (1point).
- Active drive feature: Performs prolonged acceleration at reduced torque, monitoring the load status to prevent tripping.
- Stall prevention function is provided as standard. Active or inactive can be also selected.



\* The above graph shows an example of torque characteristics when combining FRENIC5000G11S (up to 22kW at dynamic torque-vector control) with Fuji standard three-phase motor (8-type series, 4 poles). Continuous operation torque is for limits of allowable load torque for using the motor within the allowable temperature range and is not for motor output torque. The motor output torque is shown by the short-time operation torque.




Easy to apply to customer systems. A consistent design concept in all models from 0.2kW to 710kW.

FRENIC5000G11S series for general industrial machines			FRENIC5000P11S series for fans and pumps (variable torque loads)	
Nominal applied motors [kW]				
	400V series	200V series	400V series	200V series
0.2		FRN0.2G11S-2JE		
0.4	FRN0.4G11S-4JE	FRN0.4G11S-2JE		
0.75	FRN0.75G11S-4JE	FRN0.75G11S-2JE		
1.5	FRN1.5G11S-4JE	FRN1.5G11S-2JE		
2.2	FRN2.2G11S-4JE	FRN2.2G11S-2JE		
3.7	FRN3.7G11S-4JE	FRN3.7G11S-2JE		
5.5	FRN5.5G11S-4JE	FRN5.5G11S-2JE	FRN5.5P11S-4JE	FRN5.5P11S-2JE
7.5	FRN7.5G11S-4JE	FRN7.5G11S-2JE	FRN7.5P11S-4JE	FRN7.5P11S-2JE
11	FRN11G11S-4JE	FRN11G11S-2JE	FRN11P11S-4JE	FRN11P11S-2JE
15	FRN15G11S-4JE	FRN15G11S-2JE	FRN15P11S-4JE	FRN15P11S-2JE
18.5	FRN18.5G11S-4JE	FRN18.5G11S-2JE	FRN18.5P11S-4JE	FRN18.5P11S-2JE
22	FRN22G11S-4JE	FRN22G11S-2JE	FRN22P11S-4JE	FRN22P11S-2JE
30	FRN30G11S-4JE	FRN30G11S-2JE	FRN30P11S-4JE	FRN30P11S-2JE
37	FRN37G11S-4JE	FRN37G11S-2JE	FRN37P11S-4JE	FRN37P11S-2JE
45	FRN45G11S-4JE	FRN45G11S-2JE	FRN45P11S-4JE	FRN45P11S-2JE
55	FRN55G11S-4JE	FRN55G11S-2JE	FRN55P11S-4JE	FRN55P11S-2JE
75	FRN75G11S-4JE	FRN75G11S-2JE	FRN75P11S-4JE	FRN75P11S-2JE
90	FRN90G11S-4JE	FRN90G11S-2JE	FRN90P11S-4JE	FRN90P11S-2JE
110	FRN110G11S-4JE		FRN110P11S-4JE	FRN110P11S-2JE
132	FRN132G11S-4JE		FRN132P11S-4JE	
160	FRN160G11S-4JE		FRN160P11S-4JE	
200	FRN200G11S-4JE		FRN200P11S-4JE	
220	FRN220G11S-4JE		FRN220P11S-4JE	
280	FRN280G11S-4JE		FRN280P11S-4JE	
315	FRN315G11S-4JE		FRN315P11S-4JE	
355	FRN355G11S-4JE		FRN355P11S-4JE	
400	FRN400G11S-4JE		FRN400P11S-4JE	
450			FRN450P11S-4JE	
500	FRN500G11S-4JE		FRN500P11S-4JE	
630	FRN630G11S-4JE		FRN630P11S-4JE	
710			FRN710P11S-4JE	

## FRENIC 5000G11S all industrial plants

### Fans

- Air-conditioning system (for factory, building, office, hospital, clean room, shop, and cattle barn)
- Dryer
- Boiler fan
- Fans for controlling furnace temperature
- Roof fans controlled as a group
- Refrigerator
- Compressor
- Built-in blower in a film-manufacturing machine
- Cooling-tower fans
- Ventilating fans
- Air-conditioning equipment



## How to read the model number

Code	Series name	Code	Application range	Code	Protective structure	Code	Version
FRN	FRENIC 5000 series	G	General industrial machines	S	Standard	JE	JE
		P	Fans and pumps				
<b>FRN 0.4 G 11 S - 4 JE</b>							
Code	Nominal applied motors [kW]	Code	Developed inverter series	Code	Input power source		
0.2	0.2kW	11	11 series	4	Three-phase 400V		
0.4	0.4kW			2	Three-phase 200V		
0.75	0.75kW						
1.5	1.5kW						
to	to						
710	710kW						

### Food processing machines

- Food mixing machine
- Food slicer
- Grain milling machine (bread, cake, noodles)
- Tea making machine
- Rice cleaning machine



# G11S/P11S can be used for almost all plant and equipment areas.

## Machine tools


- Grinding machine
- Sanding machine
- Milling machine
- Lathe
- Drilling machine
- Turntable
- Work positioning machine
- PC board drilling machine
- Winding machine
- Press

## Conveyance machinery

- Crane (traveling, traversing, hoisting)
- Automated warehouse
- Conveyor (belt, chain, screw, roller)
- Lift
- Car parking facility
- Elevator, escalator
- Automatic door
- Shutter equipment
- Speed-change gear

## Chemical machinery/wood working machines

- Fluid mixing machine
- Extruder
- Vibrator
- Centrifugal separator
- Coating machine
- Take-up roller
- Routing machine
- Sanding machine
- Planing machine



## Electric pumps

- Tankless water supply system
- Submersible motor pump
- Vacuum pump
- Fountain pump
- Cooling water pump
- Circulating hot water pump
- Well pump
- Agricultural storage pump
- Water treatment system
- Constant-flow pump
- Sludge pump

## Packaging machinery

- Individual packaging/inner-packaging machine
- Packing machine
- Outer-packaging machine

## Paper making/ textile machinery

- Spinning machine
- Knitting machine
- Textile printing machine
- Industrial sewing machine
- Synthetic fiber manufacturing plant

## Other machinery

- Automated feed/medicine mixer
- Commercial-use washing machine
- Offset printing press
- Book-binding machine
- Car-washing machine
- Shredder
- Dishwasher
- Test equipment
- Crusher

## FRENIC5000G11S 400V series, for general industrial machines

Type	FRN					G11S-4JE		0.4	0.75	1.5	2.2	3.7	5.5	7.5	11	15	18.5	22	30	37	45	55	75	90	110	132	160	200	220	280	315	355	400	500	630			
Nominal applied motor								kW		0.4	0.75	1.5	2.2	3.7	5.5	7.5	11	15	18.5	22	30	37	45	55	75	90	110	132	160	200	220	280	315	355	400	500	630	
Output ratings	Rated capacity *1)		kVA		1.1	1.9	2.8	4.1	6.8	9.9	13	18	22	29	34	45	57	69	85	114	134	160	192	231	287	316	396	445	495	563	731	891						
	Rated voltage *2)		V		3-phase 380, 400, 415V/50Hz												380, 400, 440, 460V/60Hz																					
	Rated current *3)		A		1.5	2.5	3.7	5.5	9	13	18	24	30	39	45	60	75	91	112	150	176	210	253	304	377	415	520	585	650	740	960	1170						
	Overload capability		150% of rated current for 1min. 200% of rated current for 0.5s												150% of rated current for 1min. 180% of rated current for 0.5s																							
	Rated frequency		Hz		50, 60Hz																																	
Input ratings	Phases, Voltage, Frequency		3-phase 380 to 480V 50/60Hz												3-phase 380 to 440V/50Hz 380 to 480V/60Hz *4)																							
	Voltage / frequency variations		Voltage : +10 to −15% ( Voltage unbalance *6) : 2% or less ) Frequency :+5 to −5%																																			
	Momentary voltage dip capability *7)		When the input voltage is 310V or more, the inverter can be operated continuously. When the input voltage drops below 310V from rated voltage, the inverter can be operated for 15ms. The smooth recovery method is selectable.																																			
	Rated current *8) (with DCR)		0.82	1.5	2.9	4.2	7.1	10.0	13.5	19.8	26.8	33.2	39.3	54	67	81	100	134	160	196	232	282	352	385	491	552	624	704	880	1104								
	A (without DCR)		1.8	3.5	6.2	9.2	14.9	21.5	27.9	39.1	50.3	59.9	69.3	86	104	124	150	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-					
Required power supply capacity *9)		kVA		0.6	1.1	2.1	3.0	5.0	7.0	9.4	14	19	24	28	38	47	57	70	93	111	136	161	196	244	267	341	383	433	488	610	765							
Control	Starting torque		200% (with Dynamic torque-vector control selected)												180% (with Dynamic torque-vector control selected)																							
Braking	Standard	Braking torque	150%			100%			20% *10)			10 to 15% *10)																										
		Time s	5			5			No limit																													
		Duty cycle %	5	3	5	3	2	3	2	No limit																												
		Braking torque (Using options)	150%												100%																							
	DC injection braking		Starting frequency: 0.1 to 60.0Hz												Braking time: 0.0 to 30.0s			Braking level: 0 to 100% of rated current																				
Enclosure (IEC 60529)			IP 40												IP 00 ( IP 20 : Option )																							
Cooling method			Natural cooling			Fan cooling																																
Standards			-UL/cUL						-Low Voltage Directive						-EMC Directive						TÜV (up to 22kW)																	
			-IEC 61800-2 (Ratings, specifications for low voltage adjustable frequency a.c. power drive systems)																																			
			-IEC 61800-3 (EMC product standard including specific test methods)																																			
Mass		kg		2.2	2.5	3.8	3.8	3.8	6.5	6.5	10	10	10.5	10.5	29	34	39	40	48	70	70	100	100	140	140	250	250	360	360	525	525							

## FRENIC5000G11S 200V series, for general industrial machines

Type	FRN	G11S-2JE	0.2	0.4	0.75	1.5	2.2	3.7	5.5	7.5	11	15	18.5	22	30	37	45	55	75	90		
Nominal applied motor			kW		0.2	0.4	0.75	1.5	2.2	3.7	5.5	7.5	11	15	18.5	22	30	37	45	55	75	90
Output ratings	Rated capacity *1)		kVA		0.57	1.1	1.9	3.0	4.1	6.4	9.5	12	17	22	28	33	43	55	68	81	107	131
	Rated voltage *2)		V		3-phase    200V/50Hz    200, 220V, 230V/60Hz																	
	Rated current *3)		A		1.5	3.0	5.0	8.0	11	17	25	33	46	59	74	87	115	145	180	215	283	346
	Overload capability		150% of rated current for 1min. 200% of rated current for 0.5s														150% of rated current for 1min. 180% of rated current for 0.5s					
	Rated frequency		Hz		50, 60Hz																	
Input ratings	Phases, Voltage, Frequency		3-phase    200 to 230V    50/60Hz														3-phase    200 to 220V/50Hz (220 to 230V/50Hz) *5) 200 to 230V/60Hz					
	Voltage / frequency variations		Voltage : +10 to −15% ( Voltage unbalance *6 ) : 2% or less )    Frequency :+5 to −5%																			
	Momentary voltage dip capability *7)		When the input voltage is 165V or more, the inverter can be operated continuously. When the input voltage drops below 165V from rated voltage, the inverter can be operated for 15ms . The smooth recovery method is selectable.																			
	Rated current *8)	(with DCR)	0.94	1.6	3.1	5.7	8.3	14.0	19.7	26.9	39.0	54.0	66.2	78.8	109	135	163	199	272	327		
	A	(without DCR)	1.8	3.4	6.4	11.1	16.1	25.5	40.8	52.6	76.9	98.5	117	136	168	204	243	291	-	-		
	Required power supply capacity *9)	kVA	0.4	0.6	1.1	2.0	2.9	4.9	6.9	9.4	14	19	23	28	38	47	57	69	95	114		
Control	Starting torque		200% (with Dynamic torque-vector control selected)														180% (with Dynamic torque-vector control selected)					
Braking	Standard	Braking torque	150%				100%				20%    *10)				10 to 15%    *10)							
		Time	s		10		5		5				No limit									
		Duty cycle	%		10		5		3		5		3		2		No limit					
	Braking torque (Using options)		150%														100%					
	DC injection braking		Starting frequency: 0.1 to 60.0Hz    Braking time: 0.0 to 30.0s    Braking level: 0 to 100% of rated current																			
Enclosure (IEC 60529)			IP 40										IP 00 ( IP 20 : Option )									
Cooling method			Natural cooling				Fan cooling															
Standards			-UL/cUL    -Low Voltage Directive    -EMC Directive    TÜV (up to 22kW) -IEC 61800-2 (Ratings, specifications for low voltage adjustable frequency a.c. power drive systems) -IEC 61800-3 (EMC product standard including specific test methods)																			
Mass	kg		2.2	2.2	2.2	2.5	3.8	3.8	3.8	6.1	6.1	10	10	10.5	10.5	29	36	44	46	70	115	

NOTES:

\*1) Inverter output capacity (kVA) at 440V in 400V series, 220V in 200V series. \*2) Output voltage is proportional to the power supply voltage and cannot exceed the power supply voltage. \*3) Current derating may be required in case of low impedance loads such as high frequency motor. \*4) When the input voltage is 380V/50Hz or 380 to 415V/60Hz, the tap of the auxiliary transformer must be changed. \*5) Order individually. \*6) Refer to the IEC 61800-3(5.2.3). \*7) Tested at standard load condition (85% load). \*8) This value is under FUJI original calculation method. (Refer to the Technical Information.) \*9) When power-factor correcting DC reactor is used. \*10) With a nominal applied motor, this value is average torque when the motor decelerates and stops from 60Hz. (It may change according to motor loss.)



# FRENIC5000P11S 400V series, for fans and pumps

Type	FRN				P11S-4JE	5.5	7.5	11	15	18.5	22	30	37	45	55	75	90	110	132	160	200	220	280	315	355	400	450	500	630	710		
Nominal applied motor						kW		5.5	7.5	11	15	18.5	22	30	37	45	55	75	90	110	132	160	200	220	280	315	355	400	450	500	630	710
Output ratings	Rated capacity *1)		kVA		9.5	12.5	17.5	22.8	28.1	33.5	45	57	69	85	114	134	160	192	231	287	316	396	445	495	563	640	731	891	1044			
	Rated voltage *2)		V		3-phase 380, 400, 415V/50Hz										380, 400, 440, 460V/60Hz																	
	Rated current *3)		A		12.5	16.5	23	30	37	44	60	75	91	112	150	176	210	253	304	377	415	520	585	650	740	840	960	1170	1370			
	Overload capability				110% of rated current for 1min																											
	Rated frequency		Hz		50, 60Hz																											
Input ratings	Phases, Voltage, Frequency		3-phase 380 to 480V 50/60Hz										3-phase 380 to 440V/50Hz										380 to 480V/60Hz *4)									
	Voltage / frequency variations		Voltage : +10 to −15% ( Voltage unbalance *6) : 2% or less ) Frequency :+5 to −5%																													
	Momentary voltage dip capability *7)		When the input voltage is 310V or more, the inverter can be operated continuously. When the input voltage drops below 310V from rated voltage, the inverter can be operated for 15ms. The smooth recovery method is selectable.																													
	Rated current *8) (with DCR)		10.0	13.5	19.8	26.8	33.2	39.3	54	67	81	100	134	160	196	232	282	352	385	491	552	624	704	792	880	1104	1248					
	A (without DCR)		21.5	27.9	39.1	50.3	59.9	69.3	86	104	124	150	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-		
	Required power supply capacity *9)		kVA		7.0	9.4	14	19	24	28	38	47	57	70	93	111	136	161	196	244	267	341	383	433	488	549	610	765	865			
Control	Starting torque		50%																													
Braking	Standard	Braking torque *10)		20%										10 to 15%																		
		Time												No limit																		
		Duty cycle												No limit																		
		Braking torque (Using options)		100%										70%																		
		DC injection braking		Starting frequency: 0.1 to 60.0Hz										Braking time: 0.0 to 30.0s										Braking level: 0 to 80% of rated current								
Enclosure (IEC 60529)			IP 40										IP 00 ( IP 20 : Option )																			
Cooling method			Fan cooling																													
Standards			-UL/cUL -Low Voltage Directive -EMC Directive TÜV (up to 22kW) -IEC 61800-2 (Ratings, specifications for low voltage adjustable frequency a.c. power drive systems) -IEC 61800-3 (EMC product standard including specific test methods)																													
Mass			kg		6.1	6.1	6.1	10	10	10.5	29	29	34	39	40	48	70	70	100	100	140	140	250	250	250	360	360	525	525			










# FRENIC5000P11S 200V series, for fans and pumps

Type	FRN			P11S-2JE	5.5	7.5	11	15	18.5	22	30	37	45	55	75	90	110						
Nominal applied motor					kW	5.5	7.5	11	15	18.5	22	30	37	45	55	75	90	110					
Output ratings	Rated capacity *1)				kVA	8.3	11	16	20	25	29	43	55	68	81	107	131	158					
	Rated voltage *2)				V	3-phase 200V/50Hz 200, 220V, 230V/60Hz																	
	Rated current *3)				A	22	29	42	55	67	78	115	145	180	215	283	346	415					
	Overload capability				110% of rated current for 1min																		
	Rated frequency				Hz	50, 60Hz																	
Input ratings	Phases, Voltage, Frequency				3-phase 200 to 230V 50/60Hz										3-phase 200 to 220V/50Hz (220 to 230V/50Hz) *5) 200 to 230V/60Hz								
	Voltage / frequency variations				Voltage : +10 to -15% ( Voltage unbalance *6) : 2% or less ) Frequency :+5 to -5%																		
	Momentary voltage dip capability *7)				When the input voltage is 165V or more, the inverter can be operated continuously. When the input voltage drops below 165V from rated voltage, the inverter can be operated for 15ms . The smooth recovery method is selectable.																		
	Rated current *8)		(with DCR)		19.7	26.9	39.0	54.0	66.2	78.8	109	135	163	199	272	327	400						
	A (without DCR)				40.8	52.6	76.9	98.5	117	136	168	204	243	291	-	-	-						
Required power supply capacity *9)					kVA	6.9	9.4	14	19	23	28	38	47	57	69	95	114	139					
Control	Starting torque				50%																		
Braking	Standard	Braking torque *10)				20%										10 to 15%							
		Time				No limit																	
		Duty cycle				No limit																	
		Braking torque (Using options)				100%										70%							
	DC injection braking				Starting frequency: 0.1 to 60.0Hz Braking time: 0.0 to 30.0s Braking level: 0 to 80% of rated current																		
Enclosure (IEC 60529)					IP 40										IP 00 ( IP 20 : Option )								
Cooling method					Fan cooling																		
Standards					-UL/cUL -Low Voltage Directive -EMC Directive TÜV (up to 22kW) -IEC 61800-2 (Ratings, specifications for low voltage adjustable frequency a.c. power drive systems) -IEC 61800-3 (EMC product standard including specific test methods)																		
Mass					kg	5.7	5.7	5.7	10	10	10.5	29	29	36	44	46	70	115					

## NOTES:

\*1) Inverter output capacity (kVA) at 440V in 400V series, 220V in 200V series. \*2) Output voltage is proportional to the power supply voltage and cannot exceed the power supply voltage. \*3) Current derating may be required in case of low impedance loads such as high frequency motor. \*4) When the input voltage is 380V/50Hz or 380 to 415V/60Hz, the tap of the auxiliary transformer must be changed. \*5) Order individually. \*6) Refer to the IEC 61800-3( 5.2.3 ). \*7) Tested at standard load condition (85% load). \*8) This value is under FUJI original calculation method. (Refer to the Technical Information.) \*9) When power-factor correcting DC reactor (DCR) is used. \*10) With a nominal applied motor, this value is average torque when the motor decelerates and stops from 60Hz. (It may change according to motor loss.)

# Common Specifications

Item		Explanation	
		G11S	P11S
Output frequency	Setting	Maximum frequency	50 to 400Hz
		Base frequency	25 to 400Hz
		Starting frequency	0.1 to 60Hz, Holding time: 0.0 to 10.0s
		Carrier frequency *1)	0.75 to 15kHz (55kW or smaller) 0.75 to 10kHz (75kW or larger)
	Accuracy (Stability)	• Analog setting : $\pm 0.2\%$ of Maximum frequency (at $25\pm 10^{\circ}\text{C}$ ) • Digital setting : $\pm 0.01\%$ of Maximum frequency (at $-10$ to $+50^{\circ}\text{C}$ )	
	Setting resolution	• Analog setting : $\bullet 1/1000$ of Maximum frequency ex.) 0.06Hz at 60Hz, 0.12Hz at 120Hz, (0.4Hz at 400Hz: G11S) $\bullet 1/3000$ for 30kW and above • Digital setting : 0.01Hz at Maximum frequency of up to 99.99Hz (0.1Hz at Maximum frequency of 100Hz and above) • LINK setting : $\bullet 1/20000$ of Maximum frequency ex.) 0.003Hz at 60Hz, 0.006Hz at 120Hz, (0.02Hz at 400Hz: G11S) $\bullet 0.01\text{Hz}$ (Fixed)	
Control	Control method	• V/f control (Sinusoidal PWM control) • Dynamic torque-vector control (Sinusoidal PWM control) • Vector control with PG (*) (G11S only)	
	Voltage / freq. (V/f) characteristic	Adjustable at base and maximum frequency, with AVR control : 320 to 480V (400V series), 80 to 240V (200V series)	
	Torque boost	Selectable by load characteristics: Constant torque load (Auto/manual), Variable torque load (Manual)	
	Operation method	• KEYPAD operation :  or  key,  key • Digital input signal operation : FWD or REV command, Coast-to-stop command, etc. • LINK operation : RS-485 (Standard) T-Link (FUJI private link), PROFIBUS-DP, Interbus-S, DeviceNet, Modbus Plus, JPCN1 (Option)	
	Frequency setting (Frequency command)	• KEYPAD operation:  or  key • External potentiometer (*) : 1 to 5k $\Omega$ (1/2W) • Analog input : 0 to +10V DC (0 to +5V DC), 4 to 20mA DC (Reversible) 0 to $\pm 10\text{V}$ DC (0 to $\pm 5\text{V}$ DC) .....Reversible operation by polarized signal can be selected. (Inverse) +10 to 0V DC, 20 to 4mA DC.....Inverse mode operation can be selected. • UP/DOWN control : Output frequency increases when UP signal is ON, and decreases when DOWN signal is ON. • Multistep frequency : Up to 16 different frequencies can be selected by digital input signal. • Pulse train input (*) : 0 to 100kp/s • Digital signal (parallel) (*) : 16-bit binary • LINK operation : RS485 (Standard) T-Link (FUJI private link), RPOFIBUS-DP, Interbus-S, DeviceNet, Modbus Plus, JPCN1 (Option) • Programmed PATTERN operation: Max. 7 stages	
	Jogging operation	 or  key, FWD or REV digital input signal	
	Running status signal	Transistor output (4 points) : RUN, FAR, FDT, OL, LU, TL, etc. Relay output (2 points) : • Same as transistor output • Alarm output (for any fault) Analog output (1 point) : Output frequency, Output current, Output torque, etc. Pulse output (1 point) : Output frequency, Output current, Output torque, etc.	
	Acceleration / Deceleration time	0.01 to 3600s : • Independently adjustable acceleration and deceleration • 4 different times are selectable. Mode select : Linear, S-curve (weak), S-curve (strong), Non-linear	
	Active drive	When the acceleration time reaches 60s, the motor output torque is automatically reduced to rated torque. Then the motor operation mode is changed to torque limiting operation. The acceleration time is automatically extended up to 3 times.	
	Frequency limiter	High and Low limiter can be preset.	
	Bias frequency	Bias frequency can be preset.	
	Gain for frequency setting	Gain for frequency setting can be preset. (0.0 to 200.0%) ex.) Analog input 0 to +5V DC with 200% gain results in maximum frequency at 5V DC.	
	Jump frequency control	Jump frequency (3 points) and its common jump hysteresis width (0 to 30Hz) can be preset.	
	Rotating motor pick up (Flying start)	A rotating motor (including inverse rotating mode) can be smoothly picked up without stopping the motor (speed search method).	
	Auto-restart after momentary power failure	Automatic restart is available without stopping motor after a momentary power failure (speed search method). When "Smooth recovery" mode is selected, the motor speed drop is held minimum. (The inverter searches the motor speed, and smoothly returns to setting frequency. Even if the motor circuit is temporarily opened, the inverter operates without a hitch.)	
	Line / Inverter changeover operation	Controls the switching operation between line power and inverter. The inverter has sequence function inside.	
	Slip compensation	The inverter output frequency is controlled according to the load torque to keep motor speed constant. When the value is set at "0.00" and "Torque-vector" is set at "active", the compensation value automatically selects the Fuji standard motor. Slip compensation can be preset for the second motor.	
	Droop operation	The motor speed droops in proportion to output torque ( $-9.9$ to $0.0\text{Hz}$ ).....G11S only.	
	Torque limiting	• When the motor torque reaches a preset limiting level, this function automatically adjusts the output frequency to prevent the inverter from tripping due to an overcurrent. • Torque limiting 1 and 2 can be individually set, and are selectable with a digital input signal.	
	Torque control	Output torque (or load factor) can be controlled with an analog input signal.....G11S only.	
	PID control	This function can control flowrate, pressure, etc. (with an analog feedback signal.) • Function • KEYPAD operation (  or  key ) : Setting freq. / Max. freq. X 100 (%) • PATTERN operation : Setting freq./Max. freq. X 100 (%) signal • Voltage input (Terminal 12) : 0 to +10V DC • DI option input (*) : • BCD, setting freq./Max. freq. X 100 (%) • Current input (Terminal C1) : 4 to 20mA DC • Binary, full scale/100 (%) • Reversible operation with polarity (Terminal 12) : 0 to $\pm 10\text{V}$ DC • Multistep frequency setting : Setting freq./Max. freq. X 100 (%) • Reversible operation with polarity (Terminal 12 + V1) : 0 to $\pm 10\text{V}$ DC • RS-485 : Setting freq./Max. freq. X 100 (%) • Inverse mode operation (Terminal 12) : +10 to 0V DC • Inverse mode operation (Terminal C1) : 20 to 4mA DC • Feedback signal • Terminal 12 (0 to +10V DC or +10 to 0V DC) • Terminal C1 (4 to 20mA DC or 20 to 4mA DC)	
	Automatic deceleration	Torque limiter 1 (Braking) is set at "F41: 0" (Same as Torque limiter 2 (Braking)). • In deceleration : The deceleration time is automatically extended up to 3 times the setting time for tripless operation even if braking resistor not used. • In constant speed operation : Based on regenerative energy, the frequency is increased and tripless operation is active.	
	Second motor's setting	This function is used for two motors switching operation. • The second motor's V/f characteristics (base and maximum frequency) can be preset. • The second motor's circuit parameter can be preset. Torque-vector control can be applied to both motors.	
	Energy saving operation	This function minimizes inverter and motor losses at light load.	
	Fan stop operation	This function is used for silent operation or extending the fan's lifetime.	
	Universal DI	Transmits to main controller of LINK operation.	
	Universal DO	Outputs command signal from main controller of LINK operation.	
	Universal AO	Outputs analog signal from main controller of LINK operation.	
	Zero speed control (*)	The stopped motor holds its rotor angle.....G11S only.	
	Positioning control (*)	The SY option card can be used for positioning control by differential counter method.	
	Synchronized operation (*)	This function controls the synchronize operation between 2 axes with PGs.	

Note: (\*) Option

\*1) Inverter may automatically reduce carrier frequency, in accordance with ambient temperature or output current for protecting inverter.



Item		Explanation	
Indication	Operation mode (Running)	LED monitor	LCD monitor (Japanese, English, German, French, Spanish, Italian)
		<ul style="list-style-type: none"> <li>Output frequency 1 (Before slip compensation) (Hz)</li> <li>Output frequency 2 (After slip compensation) (Hz)</li> <li>Setting frequency (Hz)</li> <li>Output current (A)</li> <li>Output voltage (V)</li> <li>Motor synchronous speed (r/min)</li> <li>Line speed (m/min)</li> <li>Load shaft speed (r/min)</li> <li>Torque calculation value (%)</li> <li>Input power (kW)</li> <li>PID reference value</li> <li>PID reference value (remote)</li> <li>PID feedback value</li> <li>Trip history :Cause of trip by code (Even when main power supply is off, trip history data of the last 4 trips are retained.)</li> </ul>	<div>Operation monitor &amp; Alarm monitor</div> <p><b>Operation monitor</b></p> <ul style="list-style-type: none"> <li>Displays operation guidance</li> <li>Bargraph: Output frequency (%), Output current (A), Output torque (%)</li> </ul> <p><b>Alarm monitor</b></p> <ul style="list-style-type: none"> <li>The alarm data is displayed when the inverter trips.</li> </ul> <div>Function setting &amp; monitor</div> <p><b>Function setting</b></p> <p>Displays function codes and its data or data code, and changes the data value.</p>
		Stopping	Selected setting value or output value
	Trip mode	Displays the cause of trip by codes as follows.	<ul style="list-style-type: none"> <li>OC1 (Overcurrent during acceleration)</li> <li>OC2 (Overcurrent during deceleration)</li> <li>OC3 (Overcurrent during running at constant speed)</li> <li>EF (Ground fault)</li> <li>Lin (Input phase loss)</li> <li>FUS (Fuse blown)</li> <li>OU1 (Overvoltage during acceleration)</li> <li>OU2 (Overvoltage during deceleration)</li> <li>OU3 (Overvoltage running at constant speed)</li> <li>LU (Undervoltage)</li> <li>OH1 (Overheating at heat sink)</li> <li>OH2 (External thermal relay tripped)</li> <li>OH3 (Overtemperature at inside air)</li> <li>dBH (Overheating at DB circuit)</li> <li>OL1 (Motor 1 overload)</li> <li>OL2 (Motor 2 overload)</li> <li>OLU (Inverter unit overload)</li> <li>OS (Overspeed)</li> <li>PG (PG error)</li> <li>Er1 (Memory error)</li> <li>Er2 (KEYPAD panel communication error)</li> <li>Er3 (CPU error)</li> <li>Er4 (Option error)</li> <li>Er5 (Option error)</li> <li>Er6 (Operation procedure error)</li> <li>Er7 (Output phase loss error, impedance imbalance)</li> <li>Er7. (Charging circuit alarm, 30kW or larger)</li> <li>Er8 (RS-485 error)</li> </ul>
Charge lamp		When the DC link circuit voltage is higher than 50V, the charge lamp is ON.	
Protection	Overload	Protects the inverter by electronic thermal overload function and by detection of inverter temperature.	
	Overvoltage	Detects DC link circuit overvoltage, and stops the inverter. (400V series: 800V DC, 200V series: 400V DC)	
	Undervoltage	Detects DC link circuit undervoltage, and stops the inverter. (400V series: 400V DC, 200V series: 200V DC)	
	Input phase loss	Phase loss protection for power line input.	
	Overheating	Protects the inverter by detection of inverter temperature.	
	Short-circuit	Short-circuit protection for inverter output circuit	
	Ground fault	<ul style="list-style-type: none"> <li>Ground fault protection for inverter output circuit (3-phase current detection method)</li> <li>Zero-phase current detection method (30kW or larger)</li> </ul>	
	Motor overload	<ul style="list-style-type: none"> <li>The inverter trips, and then protects the motor.</li> <li>Electronic thermal overload protection can be set for standard motor or inverter motor</li> <li>Thermal time constant (0.5 to 75.0 minutes) can be preset for a special motor.</li> <li>The second motor's electronic thermal overload protection can be preset for 2-motor changeover operation.</li> </ul>	
	DB resistor overheating	<ul style="list-style-type: none"> <li>Prevents DB resistor overheating by internal electronic thermal overload relay (7.5kW or smaller).</li> <li>Prevents DB resistor overheating by external thermal overload relay attached to DB resistor (11kW or larger).</li> </ul> (The inverter stops electricity discharge operation to protect the DB resistor.)	
	Stall prevention	<ul style="list-style-type: none"> <li>Controls the output frequency to prevent <b>OC</b> (overcurrent) trip when the output current exceeds the limit value during acceleration.</li> <li>Lowens the output frequency to hold almost constant torque when the output current exceeds the limit value during operation at constant speed.</li> <li>Controls the output frequency to prevent <b>OU</b> (overvoltage) trip when the DC link circuit voltage exceeds the limit value during deceleration.</li> </ul>	
	Output phase loss	When the inverter executes auto-tuning, detects each phase impedance imbalance.	
	Motor protection by PTC thermistor	When the motor temperature exceeds allowable value, the inverter trips automatically.	
	Auto reset	When the inverter is tripped, it resets automatically and restarts.	
Condition (Installation and operation)	Installation location*	Free from corrosive gases, flammable gases, oil mist, dusts, and direct sunlight. Indoor use only.	
	Altitude	1000m or less. Applicable to 3000m with power derating (-10%/1000m)	
	Ambient temperature	-10 to +50 °C. For inverters of 22kW or smaller, remove the ventilation covers when operating it at a temperature of 40 °C or above.	
	Ambient humidity	5 to 95%RH (non-condensing)	
	Vibration	3mm at from 2 to less than 9Hz, 9.8m/s <sup>2</sup> at from 9 to less than 20Hz, 2m/s <sup>2</sup> at from 20 to less than 55Hz (2m/s <sup>2</sup> at from 9 to less than 55Hz :G11S 90kW, P11S 110kW or more) 1m/s <sup>2</sup> at from 55 to less than 200Hz,	
Storage condition		-Temperature : -25 to +65 °C, -Humidity : 5 to 95%RH (non-condensing)	

Operation monitor &amp; Alarm monitor

**Operation monitor**

- Displays operation guidance
- Bargraph: Output frequency (%), Output current (A), Output torque (%)

**Alarm monitor**

- The alarm data is displayed when the inverter trips.

Function setting &amp; monitor

**Function setting**

Displays function codes and its data or data code, and changes the data value.

**Operation condition**

- Output frequency (Hz)
- Output current (A)
- Output voltage (V)
- Torque calculation value (%)
- Setting frequency (Hz)
- Operation condition (FWD / REV, IL, VL / LU, TL)
- Motor synchronous speed (r/min)
- Load shaft speed (r/min)
- Line speed (m/min)
- PID reference value
- PID feedback value
- Driving torque limiter setting value (%)
- Braking torque limiter setting value (%)

**Tester function****(I/O check)**

- Digital I/O : ■ (ON), □ (OFF)
- Analog I/O: (V), (mA), (H), (p/s)

**Maintenance data**

- Operation time (h)
- DC link circuit voltage (V)
- Temperature at inside air (°C)
- Temperature at heat sink (°C)
- Maximum current (A)
- Main circuit capacitor life(%)
- Control PC board life (h)
- Cooling fan operation time (h)
- Communication error times (KEYPAD, RS485, Option)
- ROM version (Inverter, KEYPAD, Option)

**Load factor calculation**

- Measurement time (s)
- Maximum current (A)
- Average current (A)
- Average braking power (%)

**Alarm data**

- Output frequency (Hz)
- Output current (A)
- Output voltage (V)
- Torque calculation value (%)
- Setting frequency (Hz)
- Operation condition (FWD / REV, IL, VL / LU, TL)
- Operation time (h)
- DC link circuit voltage (V)
- Temperature at inside air (°C)
- Heat sink temperature (°C)
- Communication error times (KEYPAD, RS-485, Option)
- Digital input terminal condition (Remote, Communication)
- Transistor output terminal condition
- Trip history code
- Multiple alarm exist

# Terminal Functions

## Terminal Functions

	Symbol	Terminal name	Function	Remarks
Main circuit	L1/R, L2/S, L3/T	Power input	Connect a 3-phase power supply.	
	U, V, W	Inverter output	Connect a 3-phase induction motor.	
	P1, P(+)	For DC REACTOR	Connect the DC REACTOR for power-factor correcting or harmonic current reducing.	DC REACTOR: 55kW or smaller : Option 75kW or larger : Standard
	P(+), N(-)	For BRAKING UNIT	<ul style="list-style-type: none"> <li>• Connect the BRAKING UNIT (Option).</li> <li>• Used for DC bus connection system.</li> </ul>	BRAKING UNIT (Option): G11S: 11kW or larger, P11S: 15kW or larger
	P(+), DB	For EXTERNAL BRAKING RESISTOR	Connect the EXTERNAL BRAKING RESISTOR (Option)	G11S : 7.5kW or smaller, P11S : 11kW or smaller
	⚡ G	Grounding	Ground terminal for inverter chassis (housing).	
Analog input	R0, T0	Auxiliary control power supply	Connect the same AC power supply as that of the main circuit to back up the control circuit power supply.	0.75kW or smaller: Not correspond
	13	Potentiometer power supply	+10V DC power supply for frequency setting POT ( POT: 1 to 5k $\Omega$ )	• Allowable maximum output current : 10mA
	12	Voltage input	<ul style="list-style-type: none"> <li>• 0 to +10V DC/0 to 100% ( 0 to +5V DC/0 to 100% )</li> <li>• Reversible operation can be selected by function setting. 0 to <math>\pm 10V</math> DC / 0 to <math>\pm 100\%</math> ( 0 to <math>\pm 5V</math> DC/0 to <math>\pm 100\%</math> )</li> <li>• Inverse mode operation can be selected by function setting or digital input signal. +10 to 0V DC/0 to 100%</li> </ul>	<ul style="list-style-type: none"> <li>• Input impedance: 22k<math>\Omega</math></li> <li>• Allowable maximum input voltage: <math>\pm 15V</math> DC</li> <li>• If input voltage is 10 to 15V DC, the inverter estimates it to 10V DC.</li> </ul>
		(Torque control) (PID control) (PG feedback)	Used for torque control reference signal. Used for PID control reference signal or feedback signal. Used for reference signal of PG feedback control (option)	
	C1	Current input	<ul style="list-style-type: none"> <li>• 4 to 20mA DC/0 to 100%</li> <li>• Inverse mode operation can be selected by function setting or digital input signal. 20 to 4mA DC/0 to 100%</li> </ul>	<ul style="list-style-type: none"> <li>• Input impedance: 250k<math>\Omega</math></li> <li>• Allowable maximum input current: 30mA DC</li> <li>• If input current is 20 to 30mA DC, the inverter estimates it to 20mA DC.</li> </ul>
		(PID control)	Used for PID control reference signal or feedback signal.	
Digital input	11	Common	Common for analog signal	Isolated from terminals CME and CM.
	FWD	Forward operation command	FWD - CM: ON ..... The motor runs in the forward direction. FWD - CM: OFF ..... The motor decelerates and stops.	When FWD and REV are simultaneously ON, the motor decelerates and stops.
	REV	Reverse operation command	REV - CM: ON ..... The motor runs in the reverse direction. REV - CM: OFF ..... The motor decelerates and stops.	
	X1 X2 X3 X4 X5 X6 X7 X8 X9	Digital input 1 Digital input 2 Digital input 3 Digital input 4 Digital input 5 Digital input 6 Digital input 7 Digital input 8 Digital input 9	These terminals can be preset as follows.	<ul style="list-style-type: none"> <li>• ON state maximum input voltage: 2V (maximum source current : 5mA)</li> <li>• OFF state maximum terminal voltage: 22 to 27V (allowable maximum leakage current: 0.5mA)</li> </ul>
	(SS1) (SS2) (SS4) (SS8)	Multistep freq. selection	(SS1) : 2 (0, 1) different frequencies are selectable. (SS1, SS2) : 4 (0 to 3) different frequencies are selectable. (SS1, SS2, SS4) : 8 (0 to 7) different frequencies are selectable. (SS1, SS2, SS4, SS8) : 16 (0 to 15) different frequencies are selectable.	Frequency 0 is set by F01 (or C30). (All signals of SS1 to SS8 are OFF)
	(RT1) (RT2)	ACC / DEC time selection	(RT1) : 2 (0, 1) different ACC / DEC times are selectable. (RT1, RT2) : 4 (0 to 3) different ACC / DEC times are selectable.	Time 0 is set by F07/F08. (All signals of RT1 to RT2 are OFF)
	(HLD)	3-wire operation stop command	Used for 3-wire operation. (HLD) - CM: ON ..... The inverter self-holds FWD or REV signal. (HLD) - CM: OFF ..... The inverter releases self-holding.	Assigned to terminal X7 at factory setting.
	(BX)	Coast-to-stop command	(BX) - CM: ON ..... Motor will coast-to-stop. (No alarm signal will be output.)	<ul style="list-style-type: none"> <li>• The motor restarts from 0Hz by turning off BX with the operation command (FWD or REV) ON.</li> <li>• Assigned to terminal X8 at factory setting.</li> <li>• During normal operating, this signal is ignored.</li> <li>• Assigned to X9 at factory setting.</li> </ul>
	(RST)	Alarm reset	(RST) - CM: ON ..... Faults are reset. (This signal should be held for more than 0.1s.)	This alarm signal is held internally.
	(THR)	Trip command (External fault)	(THR) - CM: OFF ..... "OH2 trip" occurs and motor will coast-to-stop.	
	(JOG)	Jogging operation	(JOG) - CM: ON ..... JOG frequency is effective.	This signal is effective only while the inverter is stopping.
	(Hz2/Hz1)	Freq. set 2 / Freq. set 1	(Hz2/Hz1) - CM: ON ..... Freq. set 2 is effective.	If this signal is changed while the inverter is running, the signal is effective only after the inverter stops.
	(M2/M1)	Motor 2 / Motor 1	(M2/M1) - CM: ON ..... The motor circuit parameter and V/f characteristics are changed to the second motor's ones.	If this signal is changed while the inverter is running, the signal is effective only after the inverter stops.
	(DCBRK)	DC brake command	(DCBRK) - CM: ON ..... The DC injection brake is effective. (In the inverter deceleration mode)	If the operation command(FWD/REV) is input while DC braking is effective, the operation command (FWD/REV) has priority.
	(TL2/TL1)	Torque limiter 2 / Torque limiter 1	(TL2/TL1) - CM: ON ..... Torque limiter 2 is effective.	
	(SW50) (SW60)	Switching operation between line and inverter	(SW50(SW60)) - CM: ON ..... The motor is changed from inverter operation to line operation. (SW50(SW60)) - CM: OFF ..... The motor is changed from line operation to inverter operation.	Main circuit changeover signals are output through Y1 to Y5 terminal.
	(UP)	UP command	(UP) - CM: ON ..... The output frequency increases.	When UP and DOWN commands are simultaneously ON, DOWN signal is effective.
	(DOWN)	DOWN command	(DOWN) - CM: ON ..... The output frequency decreases. • The output frequency change rate is determined by ACC / DEC time. • Restarting frequency can be selected from 0Hz or setting value at the time of stop.	
	(WE-KP)	Write enable for KEYPAD	(WE-KP) - CM: ON ..... The data is changed by KEYPAD.	
	(Hz/PID)	PID control cancel	(Hz/PID) - CM: ON ..... The PID control is canceled, and frequency setting by KEYPAD (  or  ) is effective.	
	(IVS)	Inverse mode changeover	(IVS) - CM: ON ..... Inverse mode is effective in analog signal input.	If this signal is changed while the inverter is running, the signal is effective only after the inverter stops.
	(IL)	Interlock signal for 52-2	Connect to auxiliary contact (1NC) of 52-2.	
	(Hz/TRQ)	TRQ control cancel	(Hz/TRQ) - CM: ON ..... The torque control is canceled, and ordinary operation is effective.	
	(LE)	Link enable (RS-485, Bus)	(LE) - CM: ON ..... The link operation is effective. Used to switch operation between ordinary operation and link operation to communication.	RS-485: Standard, Bus: Option
	(U-DI) (STM)	Universal DI Pick up start mode	This signal is transmitted to main controller of LINK operation. (STM) - CM: ON ..... The "Pick up" start mode is effective.	
	(PG/Hz) (SYC)	SY-PG enabled Synchronization command	(PG/Hz) - CM: ON ..... Synchronized operation or PG-feedback operation is effective. (SYC) - CM: ON ..... The motor is controlled for synchronized operation between 2 axes with PGs.	Option Option
	(ZERO)	Zero speed command	(ZERO) - CM: ON ..... The motor decelerates and holds its rotor angle.	This function can be selected at PG feedback control. Option
	(STOP1) (STOP2)	Forced stop command Forced stop command with Deceleration time4	(STOP1) - CM: ON ..... The motor decelerates and stops. (STOP2) - CM: ON ..... The motor decelerates and stops with Deceleration time4.	
	(EXITE)	Pre-exciting command	(EXITE) - CM: ON ..... The magnetic flux can be established preliminary before starting at PG vector mode.	
	PLC	PLC terminal	Connect PLC power supply to avoid malfunction of the inverter that has SINK type digital input, when PLC power supply is off.	
	CM	Common	Common for digital signal	Isolated from terminals CME and 11.




# Terminal Functions

	Symbol	Terminal name	Function	Remarks
Analog output	FMA	Analog monitor	Output voltage (0 to 10V DC) is proportional to selected function's value as follows. The proportional coefficient and bias value can be preset. • Output frequency 1 (Before slip compensation) (0 to max. frequency) • Output frequency 2 (After slip compensation) (0 to max. frequency) • Output current (0 to 200%) • Output voltage (0 to 200%) • Output torque (0 to 200%) • Load factor (0 to 200%) • Input power (0 to 200%) • PID feedback value (0 to 100%) • PG feedback value (0 to max. speed) • DC link circuit voltage (400V series : 0 to 1000V) (200V series : 0 to 500V) (0 to 100%)	Allowable maximum output current: 2mA
	(11)	(Common)	• Universal AO (0 to 100%)	
Pulse output	FMP	Pulse rate monitor	• Pulse rate mode : Pulse rate is proportional to selected function's value* (50% duty pulse) • Average voltage mode : Average voltage is proportional to selected function's value* (2670P/S pulse width control)	Allowable maximum output current : 2mA
	(CM)	(Common)	* Kinds of function to be output is same as those of analog output (FMA).	
Transistor output	Y1 Y2 Y3 Y4	Transistor output 1 Transistor output 2 Transistor output 3 Transistor output 4	Output the selected signals from the following items.	• ON state maximum output voltage : 2V (Allowable maximum sink current : 50mA) • OFF state maximum leakage current : 0.1mA (Allowable maximum voltage : 27V)
	(RUN)	Inverter running	Outputs ON signal when the output frequency is higher than starting frequency.	
	(FAR)	Frequency equivalence signal	Outputs ON signal when the difference between output frequency and setting frequency is smaller than FAR hysteresis width.	
	(FDT1)	Frequency level detection	Outputs ON signal by comparison of output frequency and preset value (level and hysteresis).	
	(LU)	Undervoltage detection signal	Outputs ON signal when the inverter stops by undervoltage while the operation command is ON.	
	(B/D)	Torque polarity	Outputs ON signal in braking or stopping mode, and OFF signal in driving mode.	
	(TL)	Torque limiting	Outputs ON signal when the inverter is in torque-limiting mode.	
	(IPF)	Auto-restarting	Outputs ON signal during auto restart operation mode.(including "restart time")	
	(OL1)	Overload early warning	• Outputs ON signal when the electronic thermal value is higher than preset alarm level. • Outputs ON signal when the output current value is higher than preset alarm level.	
	(KP)	KEYPAD operation mode	Outputs ON signal when the inverter is in KEYPAD operation mode.	
	(STP)	Inverter stopping	Outputs ON signal when the inverter is stopping mode or in DC braking mode.	
	(RDY)	Ready output	Outputs ON signal when the inverter is ready for operation.	
	(SW88)	Line/Inv changeover (for 88)	Outputs 88's ON signal for Line/Inverter changeover operation.	
	(SW52-2)	Line/Inv changeover (for 52-2)	Outputs 52-2's ON signal for Line/Inverter changeover operation.	
	(SW52-1)	Line/Inv changeover (for 52-1)	Outputs 52-1's ON signal for Line/Inverter changeover operation.	
	(SWM2)	Motor2/Motor1	Outputs the motor changeover switch ON signal from motor 1 to motor 2.	
	(AX)	Auxiliary terminal (for 52-1)	Used for auxiliary circuit of 52-1. (Same function as AX1, AX2 terminal by FRENIC5000G9S series. (30kW or larger))	Refer to wiring diagram example.
	(TU)	Time-up signal	Outputs time up signal (100ms ON pulse) at every stage end of PATTERN operation.	
	(TO)	Cycle completion signal	Outputs one cycle completion signal (100ms ON pulse) at PATTERN operation.	
	(STG1) (STG2) (STG4)	Stage No indication 1 Stage No indication 2 Stage No indication 4	Outputs PATTERN operation's stage No. by signals STG1, STG2 and STG4.	
	(AL1) (AL2) (AL4) (AL8)	Alarm indication 1 Alarm indication 2 Alarm indication 4 Alarm indication 8	Outputs trip alarm No. by signals AL1, AL2, AL4, and AL8.	
	(FAN)	Fan operation signal	Outputs the inverter cooling fan operation status signal.	
	(TRY)	Auto-resetting	Outputs ON signal at auto resetting mode. (Including "Reset interval")	
	(U-DO)	Universal DO	Outputs command signal from main controller of LINK operation.	
	(OH)	Overheat early warning	Outputs ON signal when the heat sink temperature is higher than (trip level - 10°C), and outputs OFF signal when the temperature is lower than (trip level - 15°C).	
	(SY)	Synchronization completion signal	Synchronization completion signal for synchronized operation.	Option
	(LIFE)	Lifetime alarm	Outputs ON signal when the calculated lifetime is longer than preset alarm level.	
	(FDT2)	2nd Freq. level detection	2nd-outputs ON signal by comparison of output frequency and preset value (FDT2 level).	
	(OL2)	2nd OL level early warning	2nd-outputs ON signal when the output current value is larger than preset alarm level (OL2 level).	
	(C1OFF)	Terminal C1 off signal	Outputs ON signal when the C1 current is smaller than 2mA.	
	(DNZS)	Speed existance signal	Outputs ON signal at detection of motor speed when using OPC-G11S-PG/PG2/SY.	
	CME	Common (transistor output)	Common for transistor output signal.	Isolated from terminals CM and 11.
Relay output	30A, 30B, 30C	Alarm relay output	Outputs a contact signal when a protective function is activated.	• Contact rating : 250V AC, 0.3A, cosφ=0.3 48V DC, 0.5A, non-inductive
	Y5A, Y5C	Relay output	Changeable exciting mode active or non-exciting mode active by function "F36". Functions can be selected the same as Y1 to Y4. Changeable exciting mode active or non-exciting mode active by function "E25".	
LINK	DXA, DXB, SD	RS-485 I/O terminal	Connect the RS-485 link signal.	

# Basic Wiring Diagram



## Keypad panel Operation

The following diagram is for reference only. For detailed wiring diagrams, refer to the relevant instruction manual.




## Terminal Arrangement

### • Main circuit terminals




### • Control circuit terminals





# External signal input Operation

The following diagram is for reference only. For detailed wiring diagrams, refer to the relevant instruction manual.



## NOTE:

Common terminals [11], (CM), and <CME> for control circuits are isolated from one another.

\*Option

- \*1) Use the inverter whose rated input voltage matches the power supply voltage.
- \*2) An optional device. Use it when necessary.
- \*3) Use this peripheral device when necessary.
- \*4) 55kW or smaller:  
Terminals [P1] and [P(+)] are connected with a jumper wire before shipping. When connecting an optional DC reactor (DCR) \*9), remove the jumper wire that connects the terminals [P1] and [P(+)].  
75kW or larger:  
Terminals [P1] and [P(+)] are not connected at shipment from factory. Be sure to connect the DC reactor (DCR) \*9) standard provided to these terminals.
- \*5) For G11S models from 0.2 to 7.5kW, a built-in braking resistor (DBR) is connected to the inverter before shipping. (DBR is not

mounted on G11S models 11kW or larger, and P11S models.)  
When connecting an optional external braking resistor (DB), remove the DBR connection cables from [P(+)] and [DB] terminals. The end of the removed cables (indicated with an X) must be insulated.

- \*6) When connecting an optional external braking resistor (DB), be sure to also use an optional braking unit \*8). Connect the optional braking unit to the [P(+)] and [N(-)] terminals. Auxiliary terminals [1] and [2] have polarity. Be sure to connect cables to these terminals correctly. (See the diagram)
- \*7) Terminals [R0] and [T0] are provided for G11S models 1.5kW or larger, and P11S models. These terminals are not provided for G11S models 0.75kW or smaller. Even if these terminals are not powered, the inverter can be operated.

# Keypad Panel Functions and Operations

## Keypad panel

### LED monitor

In operation mode:  
Displays the setting frequency, output current, voltage, motor speed, or line speed.  
In trip mode:  
Displays code indicating the cause of trip.

### LCD monitor

In operation mode :  
Displays various items of information such as operation condition and function data. Operation guidance, which can be scrolled, is displayed at the bottom.  
In program mode :  
Displays functions and data.

### Up/Down keys

In operation mode :  
Increases or decreases the frequency or speed.  
In program mode :  
Increases or decreases function code number and data set value.

### Unit indication

Displays the unit for the information shown on the LED monitor.

### Program key

Switches the display to a menu screen or to the initial screen for operation mode or alarm mode.

### FWD/REV keys

In operation mode :  
Starts the inverter with forward or reverse operation command.  
Pressing the FWD or REV key lights the RUN lamp.  
Invalid when the function code F02 (Operation method) is set at 1 (External signal operation).

### Shift key (Column shift)

In program mode :  
Moves the cursor horizontally at data change. Pressing this key with the UP or DOWN key, the screen changes to the next function block.

### Stop key

In operation mode :  
Stops the inverter.  
Invalid when the function code F02 (Operation method) is set at 1 (External signal operation).

### Reset key

In program mode :  
Cancels the current input data and shifts the screen.  
In trip mode :  
Releases the trip-stop state.






### Function/Data Select key

In operation mode :  
Changes the displayed values of LED monitor.  
In program mode :  
Selects the function code or stores the data.





# Keypad panel operation


Perform the wiring shown in the Basic wiring diagram on page 14. Turn on inverter power, and use the  or  key to set an output frequency. Press the  key, then press the  or  key.

The inverter starts running using the factory setting function data.


Press the  key to stop the inverter.

## Procedure for selecting function codes and data codes







The following is a sample procedure for selecting a function code and changing the function data.

- ① Press the  key to switch the operation monitor screen to the program menu screen.





<b>RUN</b>	<b>FWD</b>
PRG → PRG	MENU
F/D → LED	SHIFT

- ② Select "1. DATA SET", and press the  key.


→ 1. DATA SET
2. DATA CHECK
3. OPR MNTR
4. I / O CHECK

- ③ Press the  or  key to select a target function code. To quickly scroll the function select screen, press  key and the  or  key at the same time. At the target function, press  key.


<b>F00</b>	<b>DATA PRTC</b>
<b>F01</b>	<b>FREQ CMD 1</b>
<b>F02</b>	<b>OPR METHOD</b>
<b>F03</b>	<b>MAX Hz-1</b>

- ④ Use the , , and  keys to change the function data to the target value. (Use the  key to move the cursor when you want to enter a numerical value.)

<b>F01</b>	<b>FREQ CMD 1</b>
	<b>0</b>
<b>0~11</b>	




- ⑤ Press the  key to store the updated function data in memory. The screen shifts for the selection of the next function.

<b>F02</b>	<b>OPR METHOD</b>
<b>F03</b>	<b>MAX Hz-1</b>
<b>F04</b>	<b>BASE Hz-1</b>
<b>F05</b>	<b>RATED V-1</b>


- ⑥ Pressing the  key switches the screen to the operation monitor screen.

<b>RUN</b>	<b>FWD</b>
PRG → PRG	MENU
F/D → LED	SHIFT

### 1) Setting a frequency

When the operation monitor screen is displayed, a frequency can be set by using the  or  key in both the operation and stop modes. When the target frequency is displayed, press the  key to enter the frequency in memory.

### 2) Switching a unit indication

During both operation and stop modes, each time the  key is pressed, the value displayed on the LED monitor changes, and the unit indication on the LCD monitor shifts from Hz to A, V, r/min, m/min, kW, and % in this order in accordance with the displayed value.

# Function settings

The functions in the yellow boxes can be set while the inverter is running. Other functions must be set while the inverter is stopped.

## Fundamental Functions

	Function		Setting range	Min. unit	Factory setting	
	Code	Name			-22kW	30kW-
Basic Functions	F00	Data protection	F00 DATA PRTC	0 : Data change enable 1 : Data protection	-	0
	F01	Frequency command 1	F01 FREQ CMD 1	0 : KEYPAD operation ( or key) 1 : Voltage input (terminals 12) (0 to +10V DC, 0 to +5V DC) 2 : Current input (terminal C1) (4 to 20mA DC) 3 : Voltage and current input (terminals 12 and C1) 4 : Reversible operation with polarity (terminal 12)(0 to ±10V DC) 5 : Reversible operation with polarity (terminals 12 and V1) (0 to ±10V DC) 6 : Inverse mode operation (terminals 12) (+10 to 0V DC) 7 : Inverse mode operation (terminal C1) (20 to 4mA DC) 8 : UP/DOWN control 1 (initial freq. = 0Hz) 9 : UP/DOWN control 2 (initial freq. = last value) 10 : PATTERN operation 11 : DI option or Pulse train input	-	0
	F02	Operation method	F02 OPR METHOD	0 : KEYPAD operation ( or key) 1 : FWD or REV command signal operation	-	0
	F03	Maximum frequency 1	F03 MAX Hz-1	G11S : 50 to 400Hz P11S : 50 to 120Hz	1Hz	60
	F04	Base frequency 1	F04 BASE Hz-1	G11S : 25 to 400Hz P11S : 25 to 120Hz	1Hz	60
	F05	Rated voltage 1 (at Base frequency 1)	F05 RATED V-1	0(Free), 320 to 480V (400V class) 0(Free), 80 to 240V (200V class)	1V	380 220
	F06	Maximum voltage 1 (at Maximum frequency 1)	F06 MAX V-1	320 to 480V (400V class) 80 to 240V (200V class)	1V	380 220
	F07	Acceleration time 1	F07 ACC TIME1	0.01 to 3600s	0.01s	6.00   20.00
	F08	Deceleration time 1	F08 DEC TIME1	0.01 to 3600s	0.01s	6.00   20.00
	F09	Torque boost 1	F09 TRQ BOOST1	0.0 : Automatic (for constant torque load) 0.1 to 1.9 : Manual (for variable torque load) 2.0 to 20.0 : Manual (for constant torque load)	0.1	G11S : 0.0 P11S : 0.1
	F10	Electronic thermal overload protection for motor 1 (Select)	F10 ELCTRN OL1	0 : Inactive 1 : Active (for 4-pole standard motor) 2 : Active (for 4-pole inverter motor)	-	1
	F11	(Level)	F11 OL LEVEL1	Approx. 20 to 135% of rated current	0.01A	*1)
	F12	(Thermal time constant)	F12 TIME CNST 1	0.5 to 75.0 min	0.1min	5.0   10.0
	F13	Electronic thermal overload protection (for braking resistor)	F13 DBR OL	G11S : [7.5kW or smaller] 0 : Inactive 1 : Active (built-in braking resistor) 2 : Active (DB***-2C / 4C external braking resistor) [11kW or larger] 0 : Inactive P11S : [11kW or smaller] 0,1 : Inactive 2 : Active (DB***-2C / 4C external braking resistor) [15kW or larger] 0 : Inactive	-	1 0 0 0
	F14	Restart mode after momentary power failure (operation selection)	F14 RESTART	0 : Inactive (Trip and alarm when power failure occurs.) 1 : Inactive (Trip, and alarm when power recovers.) 2 : Inactive (Deceleration stop, and alarm.) 3 : Active (Smooth recovery by continuous operation mode) 4 : Active (Momentarily stops and restarts at output frequency of before power failure) 5 : Active (Momentarily stops and restarts at starting frequency)	-	1
	F15	Frequency limiter (High)	F15 H LIMITER	G11S : 0 to 400Hz P11S : 0 to 120Hz	1Hz	70
	F16	Frequency limiter (Low)	F16 L LIMITER	G11S : 0 to 400Hz P11S : 0 to 120Hz	1Hz	0
	F17	Gain (for frequency setting signal)	F17 FREQ GAIN	0.0 to 200.0%	0.1%	100.0
	F18	Bias frequency	F18 FREQ BIAS	G11S : -400.0 to 400.0Hz P11S : -120.0 to 120.0Hz	0.1Hz	0.0
	F20	DC brake (Starting freq.)	F20 DC BRK Hz	0.0 to 60.0Hz	0.1Hz	0.0
	F21	DC brake (Braking level)	F21 DC BRK LVL	G11S : 0 to 100%	1%	0
	F22	DC brake (Braking time)	F22 DC BRK t	0.0 (DC brake inactive), 0.1 to 30.0s	0.1s	0.0
	F23	Starting frequency (Freq.)	F23 START Hz	0.1 to 60.0Hz	0.1Hz	0.5
	F24	(Holding time)	F24 HOLDING t	0.0 to 10.0s	0.1s	0.0
	F25	Stop frequency	F25 STOP Hz	0.1 to 60.0Hz	0.1Hz	0.2
	F26	Motor sound (Carrier freq.)	F26 MTR SOUND	0.75 to 15kHz (G11S : 55kW or smaller, P11S : 22kW or smaller) 0.75 to 10kHz (G11S : 75 to 400kW, P11S : 30 to 75kW) 0.75 to 6kHz (G11S : 500, 630kW, P11S : 90 to 630kW) 0.75 to 4kHz (P11S : 710kW)	1kHz	2
	F27	(Sound tone)	F27 MTR TONE	0 : level 0 1 : level 1 2 : level 2 3 : level 3	-	0
	F30	FMA (Voltage adjust)	F30 FMA V-ADJ	0 to 200%	1%	100
	F31	(Function)	F31 FMA FUNC	0 : Output frequency 1 (Before slip compensation) 1 : Output frequency 2 (After slip compensation) 2 : Output current 3 : Output voltage 4 : Output torque 5 : Load factor 6 : Input power 7 : PID feedback value 8 : PG feedback value 9 : DC link circuit voltage 10 : Universal AO	-	0
	F33	FMP (Pulse rate)	F33 FMP PULSES	300 to 6000 p/s (at full scale)	1p/s	1440
	F34	(Voltage adjust)	F34 FMP V-ADJ	0% : (Pluse rate output: 50% duty) 1 to 200% : (Voltage adjust: 2670p/s, duty adjust)	1%	0
	F35	(Function)	F35 FMP FUNC	0 : Output frequency 1 (Before slip compensation) 1 : Output frequency 2 (After slip compensation) 2 : Output current 3 : Output voltage 4 : Output torque 5 : Load factor 6 : Input power 7 : PID feedback value 8 : PG feedback value 9 : DC link circuit voltage 10 : Universal AO	-	0
	F36	30RY operation mode	F36 30RY MODE	0 : The relay (30) excites on trip mode. 1 : The relay (30) excites on normal mode.	-	0
	F40	Torque limit 1 (Driving)	F40 DRV TRQ 1	G11S : 20 to 200, 999% (999: No limit) *2) P11S : 20 to 150, 999% (999: No limit)	1%	999
	F41	(Braking)	F41 BRK TRQ 1	G11S : 0 (Automatic deceleration control), 20 to 200, 999% (999: No limit) *2) P11S : 0 (Automatic deceleration control), 20 to 150, 999% (999: No limit)	1%	999
	F42	Torque vector control 1	F42 TRQVECTOR1	0 : Inactive 1 : Active	-	0

The functions in the yellow boxes can be set while the inverter is running. Other functions must be set while the inverter is stopped.

# Extension Terminal Functions

	Function		Setting range	Min. unit	Factory setting	
	Code	Name			-22kW	30kW-
X1-X9 Terminal	E01	X1 terminal function	E01 X1 FUNC	Selects from the following items.		
	E02	X2 terminal function	E02 X2 FUNC			
	E03	X3 terminal function	E03 X3 FUNC			
	E04	X4 terminal function	E04 X4 FUNC			
	E05	X5 terminal function	E05 X5 FUNC			
	E06	X6 terminal function	E06 X6 FUNC			
	E07	X7 terminal function	E07 X7 FUNC			
	E08	X8 terminal function	E08 X8 FUNC			
	E09	X9 terminal function	E09 X9 FUNC			
			0 : Multistep freq. selection (1 to 4 bit)	[SS1]		
			1 : [SS2]			
			2 : [SS4]			
			3 : [SS8]			
			4 : ACC / DEC time selection (1 to 2 bit)	[RT1]		
			5 : [RT2]			
			6 : 3-wire operation stop command	[HLD]		
			7 : Coast-to-stop command	[BX]		
			8 : Alarm reset	[RST]		
			9 : Trip command (External fault)	[THR]		
			10 : Jogging operation	[JOG]		
			11 : Freq. set. 2 / Freq. set. 1	[Hz2/Hz1]		
			12 : Motor 2 / Motor 1	[M2/M1]		
			13 : DC brake command	[DCBRK]		
			14 : Torque limiter 2 / Torque limiter 1	[TL2/TL1]		
			15 : Switching operation between line and inverter (50Hz)	[SW50]		
			16 : Switching operation between line and inverter (60Hz)	[SW60]		
			17 : UP command	[UP]		
			18 : DOWN command	[DOWN]		
			19 : Write enable for KEYPAD	[WE-KP]		
			20 : PID control cancel	[Hz/PID]		
			21 : Inverse mode changeover (terminals 12 and C1)	[IVS]		
			22 : Interlock signal for 52-2	[IL]		
			23 : TRQ control cancel	[Hz/TRQ]		
			24 : Link enable (Bus,RS485)	[LE]		
			25 : Universal DI	[U-DI]		
			26 : Pick up start mode	[STM]		
			27 : SY-PG enable	[PG/Hz]		
			28 : Synchronization command	[SYC]		
			29 : Zero speed command	[ZERO]		
			30 : Forced stop command	[STOP1]		
			31 : Forced stop command with Deceleration time 4	[STOP2]		
			32 : Pre-exciting command	[EXITE]		
			33 : Line speed control Cancellation	[Hz/LSC]		
			34 : Line speed frequency memory	[LSC-HLD]		
			35 : Frequency setting 1 / Frequency setting 2	[Hz1/Hz2]		
ACC 2,3,4 DEC 2,3,4	E10	Acceleration time 2	E10 ACC TIME2	0.01 to 3600s	0.01s	6.00 20.00
	E11	Deceleration time 2	E11 DEC TIME2		0.01s	6.00 20.00
	E12	Acceleration time 3	E12 ACC TIME3		0.01s	6.00 20.00
	E13	Deceleration time 3	E13 DEC TIME3		0.01s	6.00 20.00
	E14	Acceleration time 4	E14 ACC TIME4		0.01s	6.00 20.00
	E15	Deceleration time 4	E15 DEC TIME4		0.01s	6.00 20.00
	E16	Torque limit 2 (Driving)	E16 DRV TRQ 2	G11S : 20 to 200%, 999% (999: No limit) *2) P11S : 20 to 150%, 999% (999: No limit)	1%	999
	E17	(Braking)	E17 BRK TRQ 2	G11S : 0 (Automatic deceleration control), 20 to 200%, 999% (999: No limit) *2) P11S : 0 (Automatic deceleration control), 20 to 150%, 999% (999: No limit)	1%	999
Y1-Y5C Terminal	E20	Y1 terminal function	E20 Y1 FUNC	Selects from the following items.		
	E21	Y2 terminal function	E21 Y2 FUNC			
	E22	Y3 terminal function	E22 Y3 FUNC			
	E23	Y4 terminal function	E23 Y4 FUNC			
	E24	Y5A,Y5C terminal function	E24 Y5 FUNC			
			0 : Inverter running	[RUN]		
			1 : Frequency equivalence signal	[FAR]		
			2 : Frequency level detection	[FDT1]		
			3 : Undervoltage detection signal	[LU]		
			4 : Torque polarity	[B/D]		
			5 : Torque limiting	[TL]		
			6 : Auto-restarting	[IPF]		
			7 : Overload early warning	[OL1]		
			8 : KEYPAD operation mode	[KP]		
			9 : Inverter stopping	[STP]		
			10 : Ready output	[RDY]		
			11 : Line/Inv changeover (for 88)	[SW88]	For Line / Inverter changeover operation	
			12 : Line/Inv changeover (for 52-2)	[SW52-2]		
			13 : Line/Inv changeover (for 52-1)	[SW52-1]		
			14 : Motor 2 / Motor 1	[SWM2]		
			15 : Auxiliary terminal (for 52-1)	[AX]		
			16 : Time-up signal	[TU]		
			17 : Cycle completion signal	[TO]		
			18 : Stage No. indication 1	[STG1]	For PATTERN operation	
			19 : Stage No. indication 2	[STG2]		
			20 : Stage No. indication 4	[STG4]		
			21 : Alarm indication 1	[AL1]	For Alarm signal output	
			22 : Alarm indication 2	[AL2]		
			23 : Alarm indication 4	[AL4]		
			24 : Alarm indication 8	[AL8]		
			25 : Fan operation signal	[FAN]		
			26 : Auto-resetting	[TRY]		
			27 : Universal DO	[U-DO]		
			28 : Overheat early warning	[OH]		
			29 : Synchronization completion signal	[SY]		
			30 : Life expectancy detection signal	[LIFE]		
			31 : 2nd Freq. level detection	[FDT2]		
			32 : 2nd OL level early warning	[OL2]		
			33 : Terminal C1 off signal	[C1OFF]		
			34 : Speed existence signal	[DNZS]		
			35 : Speed agreement signal	[DSAG]		
			36 : PG error signal	[PG-ABN]		
			37 : Torque limiting (Signal with delay)	[TL2]		
	E25	Y5 RY operation mode	E25 Y5RY MODE	0 : Inactive (Y5 Ry excites at "ON signal" mode.) 1 : Active (Y5 Ry excites at "OFF signal" mode.)		
	E30	FAR function signal (Hysteresis)	E30 FAR HYSTR	0.0 to 10.0 Hz	0.1Hz	2.5
	E31	FDT1 function signal (Level)	E31 FDT1 LEVEL	G11S : 0 to 400 Hz	1Hz	60
	E32	(Hysteresis)	E32 FDT HYSTR	0.0 to 30.0 Hz	0.1Hz	1.0
	E33	OL1 function signal (Mode select)	E33 OL1 WARNING	0 : Thermal calculation 1 : Output current	-	0
	E34	(Level)	E34 OL1 LEVEL	G11S : Approx. 5 to 200% of rated current P11S : Approx. 5 to 150% of rated current	0.01A	*1
	E35	(Timer)	E35 OL TIMER	0.1 to 60.0s	0.1s	10.0
	E36	FDT2 function (Level)	E36 FDT2 LEVEL	G11S : 0 to 400 Hz	1Hz	60
	E37	OL2 function (Level)	E37 OL2 LEVEL	G11S : Approx. 5 to 200% of rated current P11S : Approx. 5 to 150% of rated current	0.01A	*1



# Function settings

The functions in the yellow boxes can be set while the inverter is running. Other functions must be set while the inverter is stopped.

## Extension Terminal Functions (cont'd)

	Function		Setting range		Min. unit	Factory setting	
	Code	Name	LCD monitor			-22kW	30kW-
LED & LCD Monitor	E40	Display coefficient A	E40 COEF A	-999.00 to 999.00	0.01	0.01	
	E41	Display coefficient B	E41 COEF B	-999.00 to 999.00	0.01	0.00	
	E42	LED Display filter	E42 DISPLAY FL	0.0 to 5.0s	0.1s	0.5	
	E43	LED Monitor (Function)	E43 LED MNTR	0 : Output frequency 1 (Before slip compensation) (Hz) 1 : Output frequency 2 (After slip compensation) (Hz) 2 : Setting frequency (Hz) 3 : Output current (A) 4 : Output voltage (V) 5 : Motor synchronous speed (r/min) 6 : Line speed (m/min) 7 : Load shaft speed (r/min) 8 : Torque calculation value (%) 9 : Input power 10 : PID reference value 11 : PID reference value (remote) 12 : PID feedback value	-	0	
	E44	(Display at STOP mode)	E44 LED MNTR2	0 : Setting value 1 : Output value	-	0	
	E45	LCD Monitor (Function)	E45 LCD MNTR	0 : Displays operation guidance 1 : Bar graph (Output freq., Output current, and Output torque)	-	0	
	E46	Language	E46 LANGUAGE	0 : Japanese 1 : English 2 : German 3 : French 4 : Spanish 5 : Italian	-	1	
	E47	LCD Monitor (Contrast)	E47 CONTRAST	0 (Soft) to 10 (Hard)	-	5	

The functions in the yellow boxes can be set while the inverter is running. Other functions must be set while the inverter is stopped.

## Control Functions of Frequency

	Function		Setting range		Min. unit	Factory setting	
	Code	Name	LCD monitor			-22kW	30kW-
Jump Hz Control	C01	Jump (Jump freq. 1)	C01 JUMP Hz 1	G11S : 0 to 400Hz	1Hz	0	
	C02	frequency (Jump freq. 2)	C02 JUMP Hz 2	P11S : 0 to 120Hz	1Hz	0	
	C03	(Jump freq. 3)	C03 JUMP Hz 3		1Hz	0	
	C04	(Hysteresis)	C04 JUMP HYSTR	0 to 30Hz	1Hz	3	
Multi-Hz Control	C05	Multistep (Freq. 1)	C05 MULTI Hz-1	G11S : 0.00 to 400.00Hz	0.01Hz	0.00	
	C06	frequency (Freq. 2)	C06 MULTI Hz-2	P11S : 0.00 to 120.00Hz	0.01Hz	0.00	
	C07	setting (Freq. 3)	C07 MULTI Hz-3		0.01Hz	0.00	
	C08	(Freq. 4)	C08 MULTI Hz-4		0.01Hz	0.00	
	C09	(Freq. 5)	C09 MULTI Hz-5		0.01Hz	0.00	
	C10	(Freq. 6)	C10 MULTI Hz-6		0.01Hz	0.00	
	C11	(Freq. 7)	C11 MULTI Hz-7		0.01Hz	0.00	
	C12	(Freq. 8)	C12 MULTI Hz-8		0.01Hz	0.00	
	C13	(Freq. 9)	C13 MULTI Hz-9		0.01Hz	0.00	
	C14	(Freq. 10)	C14 MULTI Hz10		0.01Hz	0.00	
	C15	(Freq. 11)	C15 MULTI Hz11		0.01Hz	0.00	
	C16	(Freq. 12)	C16 MULTI Hz12		0.01Hz	0.00	
	C17	(Freq. 13)	C17 MULTI Hz13		0.01Hz	0.00	
	C18	(Freq. 14)	C18 MULTI Hz14		0.01Hz	0.00	
	C19	(Freq. 15)	C19 MULTI Hz15		0.01Hz	0.00	
	C20	JOG frequency	C20 JOG Hz	G11S : 0.00 to 400.00Hz	0.01Hz	5.00	
PATTERN Operation	C21	PATTERN (Mode select) operation	C21 PATTERN	0 : Active (Mono-cycle operation, and then stops.) 1 : Active (Continuous cyclic operation while operation command is effective.) 2 : Active (Mono-cycle operation, and after continues at the latest setting frequency.)	-	0	
	C22	(Stage 1)	C22 STAGE 1	• Operation time: 0.00 to 6000s	0.01s	0.00	F1
	C23	(Stage 2)	C23 STAGE 2	• F1 to F4 and R1 to R4	0.01s	0.00	F1
	C24	(Stage 3)	C24 STAGE 3		0.01s	0.00	F1
	C25	(Stage 4)	C25 STAGE 4		0.01s	0.00	F1
	C26	(Stage 5)	C26 STAGE 5		0.01s	0.00	F1
	C27	(Stage 6)	C27 STAGE 6		0.01s	0.00	F1
	C28	(Stage 7)	C28 STAGE 7		0.01s	0.00	F1
		*Setting for operation time, FWD/REV rotation and ACC/DEC time select.					
	C30	Frequency command 2	C30 FREQ CMD 2	0 : KEYPAD operation ( or key) 1 : Voltage input (terminal 12) (0 to +10V DC, 0 to +5V DC) 2 : Current input (terminal C1) (4 to 20mA DC) 3 : Voltage and current input (terminals 12 and C1) 4 : Reversible operation with polarity (terminal 12) (0 to ±10V DC) 5 : Reversible operation with polarity (terminal 12 and V1) (0 to ±10V DC) 6 : Inverse mode operation (terminal 12) (+10 to 0V DC) 7 : Inverse mode operation (terminal C1) (20 to 4mA DC) 8 : UP/DOWN control 1 (initial freq. = 0Hz) 9 : UP/DOWN control 2 (initial freq. = last value) 10 : PATTERN operation 11 : DI option or Pulse train input	-	2	
	C31	Offset (Terminal 12)	C31 OFFSET 12	-5.0 to +5.0%	0.1%	0.0	
	C32	(Terminal C1)	C32 OFFSET C1	-5.0 to +5.0%	0.1%	0.0	
	C33	Analog setting signal filter	C33 REF FILTER	0.00 to 5.00s	0.01s	0.05	

**M** The functions in the yellow boxes can be set while the inverter is running. Other functions must be set while the inverter is stopped.

## Motor Parameters

	Function		Setting range	Min. unit	Factory setting	
	Code	Name			-22kW	30kW-
Motor 1	P01	Number of motor 1 poles	P01 M1 POLES	2 to 14	2	4
	P02	Motor 1 (Capacity)	P02 M1-CAP	22kW or smaller : 0.01 to 45.00 kW 30kW or larger : 0.01 to 800.00 kW	0.01kW	*1)
	P03	(Rated current)	P03 M1-Ir	0.00 to 2000 A	0.01A	*1)
	P04	(Tuning)	P04 M1 TUN1	0 : Inactive 1 : Active (One time tuning of %R1 and %X ( on motor stopping mode )) 2 : Active (One time tuning of %R1, %X and lo ( on motor running mode ))	-	0
	P05	(On-line Tuning)	P05 M1 TUN2	0 : Inactive 1 : Active (Real time tuning of %R2)	-	0
	P06	(No-load current)	P06 M1-lo	0.00 to 2000 A	0.01A	*1)
	P07	(%R1 setting)	P07 M1-%R1	0.00 to 50.00 %	0.01%	*1)
	P08	(%X setting)	P08 M1-%X	0.00 to 50.00 %	0.01%	*1)
	P09	(Slip compensation control 1)	P09 SLIP COMP1	0.00 to +15.00	0.01Hz	0.00

## High Performance Functions

	Function		Setting range	Min. unit	Factory setting	
	Code	Name			-22kW	30kW-
High Performance Functions	H03	Data initializing (Data reset)	H03 DATA INIT	0 : Manual set value 1 : Return to factory set value	-	0
	H04	Auto-reset (Times)	H04 AUTO-RESET	0 (Inactive), 1 to 10 times	1	0
	H05	(Reset interval)	H05 RESET INT	2 to 20s	1s	5
	H06	Fan stop operation	H06 FAN STOP	0 : Inactive 1 : Active (Fan stops at low temperature mode)	-	0
	H07	ACC/DEC pattern (Mode select)	H07 ACC PTN	0 : Inactive (linear acceleration and deceleration) 1 : S-shape acceleration and deceleration (mild) 2 : S-shape acceleration and deceleration (variable) 3 : Curvilinear acceleration and deceleration	-	0
	H08	Rev. phase sequence lock	H08 REV LOCK	0 : Inactive 1 : Active	-	0
	H09	Start mode (Rotating motor pick up)	H09 START MODE	0 : Inactive 1 : Active (Only Auto-restart after momentary power failure mode ) 2 : Active (All start modes)	-	0
	H10	Energy-saving operation	H10 ENERGY SAV	0 : Inactive 1 : Active (Only when torque boost "F09" is set at manual setting mode.)	-	G11S : 0 P11S : 1
	H11	DEC mode	H11 DEC MODE	0 : Normal (according to "H07" mode) 1 : Coast-to-stop	-	0
	H12	Instantaneous overcurrent limiting	H12 INST CL	0 : Inactive 1 : Active	-	1
	H13	Auto-restart (Restart time)	H13 RESTART t	0.1 to 10.0s	0.1s	0.5
	H14	(Freq. fall rate)	H14 FALL RATE	0.00 to 100.00Hz/s	0.01Hz/s	10.00
	H15	(Holding DC voltage)	H15 HOLD V	400 to 600V (400V class) 200 to 300V (200V class)	1V	470V 235V
	H16	(OPR command selfhold time)	H16 SELFHOLD t	0.0 to 30.0s, 999s (999s : The operation command is held while DC link circuit voltage is larger than 50V.)	0.1s	999
	H18	Torque control	H18 TRQ CTRL	G11S 0 : Inactive (Frequency control) 1 : Active (Torque control by terminal 12 (Driving)) (0 to +10V/0 to 200%) 2 : Active (Torque control by terminal 12 (Driving & Braking)) (0 to ±10V/0 to ±200%) P11S 0 : Inactive (Fixed)	-	0
	H19	Active drive	H19 AUT RED	0 : Inactive 1 : Active	-	0
PID Control	H20	PID control (Mode select)	H20 PID MODE	0 : Inactive 1 : Active (PID output 0 to 100% / Frequency 0 to max.) 2 : Active (Inverse operation mode : PID output 0 to 100% / Frequency max. to 0)	-	0
	H21	(Feedback signal)	H21 FB SIGNAL	0 : Terminal 12 (0 to +10V) 1 : Terminal C1 (4 to 20mA) 2 : Terminal 12 (+10 to 0V) 3 : Terminal C1 (20 to 4mA)	-	1
	H22	(P-gain)	H22 P-GAIN	0.01 to 10.00	0.01	0.10
	H23	(I-gain)	H23 I-GAIN	0.0 : Inactive 0.1 to 3600.0s	0.1s	0.0
	H24	(D-gain)	H24 D-GAIN	0.00 : Inactive 0.01 to 10.0s	0.01s	0.00
Y1-Y5C Terminal	H25	(Feedback filter)	H25 FB FILTER	0.0 to 60.0s	0.1s	0.5
	H26	PTC thermistor (Mode select)	H26 PTC MODE	0 : Inactive 1 : Active	-	0
	H27	(level)	H27 PTC LEVEL	0.00 to 5.00V	0.01V	1.60
Serial Link	H28	Droop operation	H28 DROOP	G11S : -9.9 to 0.0Hz P11S : 0.0 (Fixed)	0.1Hz	0.0
	H30	Serial link (Function select)	H30 LINK FUNC	(Code) (Monitor) (Frequency command) (Operation command) 0 : X - - x : Valid 1 : X X - - : Invalid 2 : X - X 3 : X X X	-	0
	H31	RS-485 (Address)	H31 485ADDRESS	1 to 31	1	1
	H32	(Mode select on no response error)	H32 MODE ON ER	0 : Trip and alarm (Er8) 1 : Operation for H33 timer, and alarm (Er8) 2 : Operation for H33 timer, and retry to communicate. * If the retry fails, then the inverter trips("Er 8"). 3 : Continuous operation	-	0
	H33	(Timer)	H33 TIMER	0 to 60.0s	0.1s	2.0
	H34	(Baud rate)	H34 BAUD RATE	0 : 19200 bit/s 1 : 9600 2 : 4800 3 : 2400 4 : 1200	-	1
	H35	(Data length)	H35 LENGTH	0 : 8 bit 1 : 7 bit	-	0
	H36	(Parity check)	H36 PARITY	0 : No checking 1 : Even parity 2 : Odd parity	-	0
	H37	(Stop bits)	H37 STOP BITS	0 : 2 bit 1 : 1 bit	-	0
	H38	(No response error detection time)	H38 NO RES t	0 (No detection), 1 to 60s	1s	0
	H39	(Response interval)	H39 INTERVAL	0.00 to 1.00s	0.01s	0.01

# Function Settings

The functions in the yellow boxes can be set while the inverter is running. Other functions must be set while the inverter is stopped.

## Alternative Motor Parameters

	Function		Setting range	Min. unit	Factory setting	
	Code	Name			~22kW	30kW~
Motor 2	<b>P01</b>	Maximum frequency 2	A01 MAX Hz-2	G11S : 50 to 400Hz P11S : 50 to 120Hz	1Hz	60
	<b>P02</b>	Base frequency 2	A02 BASE Hz-2	G11S : 25 to 400Hz P11S : 25 to 120Hz	1Hz	60
	<b>P03</b>	Rated voltage 2 (at Base frequency 2)	A03 RATED V-2	0 (Free), 320 to 480V (400V class) 0 (Free), 80 to 240V (200V class)	1V	380 220
	<b>P04</b>	Maximum voltage 2 (at Maximum frequency 2)	A04 MAX V-2	320 to 480V (400V class) 80 to 240V (200V class)	1V	380 220
	<b>P05</b>	Torque boost 2	A05 TRQ BOOST2	0.0 : Automatic (for constant torque load) 0.1 to 1.9 : Manual (for variable torque load) 2.0 to 20.0 : Manual (for constant torque load)	-	G11S : 0.0 P11S : 0.1
	<b>P06</b>	Electronic thermal overload protection for motor 2 (Select)	A06 ELCTRN OL2	0 : Inactive 1 : Active (for 4-pole standard motor) 2 : Active (for 4-pole inverter motor)	-	1
	<b>P07</b>	OL LEVEL2 (Level)	A07 OL LEVEL2	Approx. 20 to 135% of rated current	0.01A	*1)
	<b>P08</b>	(Thermal time constant)	A08 TIME CNST2	0.5 to 75.0 min	0.1min	5.0 10.0
	<b>P09</b>	Torque vector control 2	A09 TRQVECTOR2	0 : Inactive 1 : Active	-	0
	<b>P10</b>	Number of motor 2 poles	A10 M2 POLES	2 to 14	2	4
	<b>P11</b>	Motor 2 (Capacity)	A11 M2-CAP	22kW or smaller : 0.01 to 45.00 kW 30kW or larger : 0.01 to 800.00 kW	0.01kW	*1)
	<b>P12</b>	(Rated current)	A12 M2-Ir	0.00 to 2000 A	0.01A	*1)
	<b>P13</b>	(Tuning)	A13 M2 TUN1	0 : Inactive 1 : Active (One time tuning of %R1 and %X ( on motor stopping mode )) 2 : Active (One time tuning of %R1, %X and lo ( on motor running mode ))	-	0
	<b>P14</b>	(On-line Tuning)	A14 M2 TUN2	0 : Inactive 1 : Active (Real time tuning of %R1 and %X)	-	0
	<b>P15</b>	(No-load current)	A15 M2-Io	0.00 to 2000 A	0.01A	*1)
	<b>P16</b>	(%R1 setting)	A16 M2-%R1	0.00 to 50.00 %	0.01%	*1)
	<b>P17</b>	(%X setting)	A17 M2-%X	0.00 to 50.00 %	0.01%	*1)
	<b>P18</b>	Slip compensation control 2	A18 SLIP COMP2	0.00 to +15.00 Hz	0.01Hz	0.00

NOTES :

\*1) Typical value of standard Fuji 4P motor.

\*2) Percent shall be set according to FUNCTION CODE : P02 or A11, Motor capacity.

Torque referenced here may not be obtainable when DATA CODE : 0 is selected for FUNCTION CODE : P02 or A11.

The functions in the yellow boxes can be set while the inverter is running. Other functions must be set while the inverter is stopped.

## User Functions

	Function		Setting range	Min. unit	Factory setting	
	Code	Name			~22kW	30kW~
	<b>U01</b>	Maximum compensation frequency during braking torque limit	U01 USER 01	0 to 65535	1	75
	<b>U02</b>	1st S-shape level at acceleration	U02 USER 02	1 to 50%	1	10
	<b>U03</b>	2nd S-shape level at acceleration	U03 USER 03	1 to 50%	1	10
	<b>U04</b>	1st S-shape level at deceleration	U04 USER 04	1 to 50%	1	10
	<b>U05</b>	2nd S-shape level at deceleration	U05 USER 05	1 to 50%	1	10
	<b>U08</b>	Main DC link (Initial value)	U08 USER 08	0 to 65535	1	XXXX
	<b>U09</b>	capacitor (Measured value)	U09 USER 09	0 to 65535	1	0
	<b>U10</b>	PC board capacitor powered on time	U10 USER 10	0 to 65535h	1	0
	<b>U11</b>	Cooling fan operating time	U11 USER 11	0 to 65535h	1	0
	<b>U13</b>	Magnetize current vibration damping gain	U13 USER 13	0 to 32767	1	819 410
	<b>U15</b>	Slip compensation filter time constant	U15 USER 15	0 to 32767	1	556 546
	<b>U23</b>	Integral gain of continuous operation at power failure	U23 USER 23	0 to 65535	1	1738 1000
	<b>U24</b>	Proportional gain of continuous operation at power failure	U24 USER 24	0 to 65535	1	1024 1000
	<b>U48</b>	Input phase loss protection	U48 USER 48	0, 1, 2	-	-55kW 75kW- 0 1
	<b>U49</b>	RS-485 protocol selection	U49 USER 49	0, 1	-	0
	<b>U56</b>	Speed agreement (Detection width)	U56 USER 56	0 to 50%	1	10
	<b>U57</b>	/PG error (Delection timer)	U57 USER 57	0.0 to 10.0s	0.1	0.5
	<b>U58</b>	PG error selection	U58 USER 58	0, 1	-	1
	<b>U59</b>	Braking-resistor function select	U59 USER 59	00 to A8 (HEX)	1	00
	<b>U60</b>	Regeneration avoidance at deceleration	U60 USER 60	0, 1	-	0
	<b>U61</b>	Voltage detect offset and gain adjustment	U61 USER 61	-22kW : 0 (Fixed.) 30kW~ : 0, 1, 2	-	0




Function	Description		LED monitor
<b>Overcurrent protection (Short-circuit) (Ground fault)</b>	<ul style="list-style-type: none"> <li>Stops running to protect inverter from an overcurrent resulting from overload.</li> <li>Stops running to protect inverter from an overcurrent due to a short-circuit in the output circuit.</li> <li>Stops running to protect inverter from an overcurrent due to a ground fault in the output circuit.</li> <li>Stops running to protect inverter from an overcurrent resulting from ground fault in the output circuit by detecting zero-phase current.</li> </ul>	• 30kW or larger model only	During acceleration <b>OC 1</b>
			During deceleration <b>OC 2</b>
			While running at constant speed <b>OC 3</b>
			Ground fault <b>EF</b>
<b>Overvoltage protection</b>	• The inverter stops when it detects an overvoltage in the DC link circuit.	<ul style="list-style-type: none"> <li>400V series : 800V DC or more</li> <li>200V series : 400V DC or more</li> <li>Protection is not assured if excess AC line voltage is applied inadvertently.</li> </ul>	During acceleration <b>OU 1</b>
			During deceleration <b>OU 2</b>
			While running at constant speed <b>OU 3</b>
<b>Incoming surge protection</b>	<ul style="list-style-type: none"> <li>Protects the inverter against surge voltage between the main circuit power line and ground.</li> <li>Protects the inverter against surge voltage in the main circuit power line.</li> </ul>	• The inverter may be tripped by some other protective function.	
<b>Undervoltage protection</b>	• Stops the inverter when the DC link circuit voltage drops below undervoltage level.	<ul style="list-style-type: none"> <li>400V series : 360V DC (22kW or smaller), 375V DC (30kW or larger)</li> <li>200V series : 180V DC (22kW or smaller), 186V DC (30kW or larger)</li> </ul>	<b>LU</b>
<b>Input phase loss protection</b>	• The inverter is protected from being damaged when open-phase fault occurs.		<b>Lin</b>
<b>Overheat protection</b>	<ul style="list-style-type: none"> <li>Stops the inverter when it detects excess heat sink temperature in case of cooling fan failure or overload. This is also caused by short-circuit of terminals 13 and 11.</li> <li>Stops the inverter when it detects an abnormal rise in temperature in the inverter unit caused by insufficient ventilation in cubicles or an abnormal ambient temperature.</li> <li>This is also caused by short-circuit of terminals 13 and 11 (overcurrent of 20mA at terminal 13).</li> </ul>	• G11S : 7.5kW or smaller model only	<b>OH 1</b>
	<ul style="list-style-type: none"> <li>When the built-in braking resistor overheats, the inverter stops discharging and running.</li> <li>Function data appropriate for the resistor type (built-in/external) must be set.</li> </ul>		<b>OH 3</b>
			<b>dbH</b>
<b>Electronic thermal overload protection (Motor protection)</b>	<ul style="list-style-type: none"> <li>This function stops the inverter by detecting an inverter overload.</li> <li>This function stops the inverter by detecting an overload in a standard motor or inverter motor.</li> </ul>		<b>OLU</b>
			Motor 1 overload <b>OL 1</b>
			Motor 2 overload <b>OL 2</b>
<b>Fuse blown</b>	• When a blown fuse is detected, the inverter stops running.	• 30kW or larger model only	<b>FUS</b>
<b>Stall prevention (Momentary overcurrent limitation)</b>	• When an output current exceeds the limit during acceleration, this function lowers output frequency to prevent the occurrence of an OC1 trip.	• The stall prevention function can be disabled.	
<b>Output phase loss error</b>	• If an unbalance of output circuits is detected during auto-tuning, this function issues an alarm (and stops the inverter).		<b>Er 7</b>
<b>Active drive</b>	• During running in which acceleration is 60s or longer, this function increases the acceleration time to prevent the occurrence of an OLU trip.	• The acceleration time can be prolonged up to three times the preset time.	
<b>External alarm input</b>	<ul style="list-style-type: none"> <li>The inverter stops on receiving external alarm signals.</li> <li>This function is activated when the motor temperature rises where PTC thermistor is used for motor protection (H26: 1).</li> </ul>	• Use THR terminal function (digital input).	<b>OH 2</b>
<b>Overspeed protection</b>	• Stops the inverter when the output frequency exceeds the rated maximum frequency by 20%.		<b>OS</b>
<b>PG error</b>	• If disconnection occurs in pulse generator circuits, the inverter issues an alarm.		<b>PG</b>
<b>Alarm output (for any fault)</b>	• The inverter outputs a relay contact signal when the inverter issued an alarm and stopped.	<ul style="list-style-type: none"> <li>Output terminals: 30A, 30B, and 30C</li> <li>Use the RST terminal function for signal input.</li> <li>Even if main power input is turned off, alarm history and trip-cause data are retained.</li> </ul>	
<b>Alarm reset command</b>	• An alarm-stop state of the inverter can be cleared with the RESET key or by a digital input signal (RST).		
<b>Alarm history memory</b>	• Store up to four instances of previous alarm data.		
<b>Storage of data on cause of trip</b>	• The inverter can store and display details of the latest alarm history data.		
<b>Memory error</b>	• The inverter checks memory data after power-on and when the data is written. If a memory error is detected, the inverter stops.		<b>Er 1</b>
<b>KEYPAD panel communication error</b>	• If an error is detected in communication between the inverter and KEYPAD when the keypad panel is being used, the inverter stops.	• When operated by external signals, the inverter continues running. The alarm output (for any fault) is not output. Only Er2 is displayed.	<b>Er 2</b>
<b>CPU error</b>	• If the inverter detects a CPU error caused by noise or some other factor, the inverter stops.		<b>Er 3</b>
<b>Option communication error</b>	• If a checksum error or disconnection is detected during communication, the inverter issues an alarm.		<b>Er 4</b>
<b>Option error</b>	• If a linkage error or other option error is detected, the inverter issues an alarm.		<b>Er 5</b>
<b>Operation procedure error</b>	• Er6 is indicated only when the inverter is forcibly stopped by [STOP 1] or [STOP 2] operation in E01 to E09 (Set value: 30 or 31).		<b>Er 6</b>
<b>Output wiring error</b>	• This error is detected when the wiring on the inverter output is disconnected unwired on auto-tuning.		<b>Er 7</b>
<b>Charging circuit alarm</b>	• This alarm is activated when the power supply is not applied to the main terminal L1/R or L3/T or charging-circuit relay is faulty.	• 30kW or larger model only	<b>Er 7</b>
<b>RS-485 communication error</b>	• If an RS-485 communication error is detected, the inverter issues an alarm.		<b>Er 8</b>

## NOTES :

1)Retaining alarm signal when auxiliary controll power supply is not used :


If the inverter power supply is cut off while an internal alarm signal is being output, the alarm signal cannot be retained.

2)To issue the RESET command, press the  key on the KEYPAD panel or connect terminals RST and CM and disconnect them afterwards.

3)Fault history data is stored for the past four trips.

**Fig. 1**


**FRN0.4G11S-4JE, FRN0.75G11S-4JE  
FRN0.2G11S-2JE to FRN0.75G11S-2JE**



Type	D	D4	D5
FRN0.4G11S-4JE FRN0.2G11S-2JE FRN0.4G11S-2JE	130	36.5	80
FRN0.75G11S-4JE FRN0.75G11S-2JE	145	51.5	95


**Fig. 2**

FRN1.5G11S-4JE to FRN3.7G11S-4JE  
FRN1.5G11S-2JE to FRN3.7G11S-2JE




**Fig. 3**

FRN5.5G11S-4JE,FRN7.5G11S-4JE  
FRN5.5G11S-2JE,FRN7.5G11S-2JE  
FRN5.5P11S-4JE to FRN11P11S-4JE  
FRN5.5P11S-2JE to FRN11P11S-2JE




**Fig. 4**

FRN11G11S-4JE to FRN22G11S-4JE  
FRN11G11S-2JE to FRN22G11S-2JE  
FRN15P11S-4JE to FRN22P11S-4JE  
FRN15P11S-2JE to FRN22P11S-2JE




**Fig. 5**

FRN30G11S-4JE to FRN220G11S-4JE    FRN30G11S-2JE to FRN90G11S-2JE    FRN30P11S-4JE to FRN280P11S-4JE    FRN30P11S-2JE to FRN110P11S-2JE



**Fig. 6**

FRN280G11S-4JE to FRN630G11S-4JE    FRN315P11S-4JE to FRN710P11S-4JE




Power supply voltage	Nominal applied motor (kW)	Type		Fig	Dimensions (mm)																	Mtg Bolt																																																				
		G11S series	P11S series		W	W1	W2	W3	W4	W5	H	H1	H2	H3	H4	H5	H6	H7	D	D1	D2		C																																																			
400V	30	FRN30G11S-4JE	FRN30P11S-4JE	5	340	240	326	—	—	550	530	500	512	—	12	25	9	255	145	10	M8																																																					
	37	—	FRN37P11S-4JE		—	675	655											625				637	270	4	—																																																	
	45	—	FRN45P11S-4JE																							—	740	720	690	702	—	—																																										
	55	FRN55G11S-4JE	FRN55P11S-4JE																														—	740	710	675	685	—	—																																			
	75	—	FRN75P11S-4JE																																					—	—	—	—	—	—	—																												
	90	FRN75G11S-4JE	FRN90P11S-4JE																																												—	—	—	—	—	—	—																					
	110	FRN110G11S-4JE	FRN110P11S-4JE																																																			—	—	—	—	—	—	—														
	132	—	FRN132P11S-4JE																																																										—	—	—	—	—	—	—							
	160	FRN160G11S-4JE	FRN160P11S-4JE																																																																	—	—	—	—	—	—	—
	200	—	FRN200P11S-4JE																																																																							
	220	FRN220G11S-4JE	FRN220P11S-4JE	—				—	—	—	—	—	—																																																													
	280	—	FRN280P11S-4JE		—	—	—							—	—	—	—																																																									
	315	FRN280G11S-4JE	FRN315P11S-4JE															—	—	—	—	—	—	—																																																		
	355	FRN315G11S-4JE	FRN315P11S-4JE																						—	—	—	—	—	—	—																																											
	400	—	FRN355P11S-4JE																													—	—	—	—	—	—	—																																				
	450	FRN355G11S-4JE	FRN400P11S-4JE																																				—	—	—	—	—	—	—																													
	500	—	FRN400G11S-4JE																																											—	—	—	—	—	—	—																						
	630	FRN450P11S-4JE	FRN500P11S-4JE																																																		—	—	—	—	—	—	—															
	710	FRN500G11S-4JE	FRN630P11S-4JE																																																									—	—	—	—	—	—	—								
		—	FRN710P11S-4JE																																																																—	—	—	—	—	—	—	
			—	—				—	—	—	—	—																																																														
					—	—	—						—	—	—	—																																																										
																	—	—	—	—	—	—	—																																																			
																								—	—	—	—	—	—	—																																												
																															—	—	—	—	—	—	—																																					
																																						—	—	—	—	—	—	—																														
																																													—	—	—	—	—	—	—																							
																																																				—	—	—	—	—	—	—																
																																																											—	—	—	—	—	—	—									
																																																																		—	—	—	—	—	—	—		
			—	—				—	—	—	—	—																																																														
					—	—	—						—	—	—	—																																																										
																	—	—	—	—	—	—	—																																																			
																								—	—	—	—	—	—	—																																												
																															—	—	—	—	—	—	—																																					
																																						—	—	—	—	—	—	—																														
																																													—	—	—	—	—	—	—																							
																																																				—	—	—	—	—	—	—																
																																																											—	—	—	—	—	—	—									
																																																																		—	—	—	—	—	—	—		
			—	—				—	—	—	—	—																																																														
					—	—	—						—	—	—	—																																																										
																	—	—	—	—	—	—	—																																																			
																								—	—	—	—	—	—	—																																												
																															—	—	—	—	—	—	—																																					
																																						—	—	—	—	—	—	—																														
																																													—	—	—	—	—	—	—																							
																																																				—	—	—	—	—	—	—																
																																																											—	—	—	—	—	—	—									
																																																																		—	—	—	—	—	—	—		
			—	—				—	—	—	—	—																																																														
					—	—	—						—	—	—	—																																																										
																	—	—	—	—	—	—	—																																																			
																								—	—	—	—	—	—	—																																												
																															—	—	—	—	—	—	—																																					
																																						—	—	—	—	—	—	—																														
																																													—	—	—	—	—	—	—																							
																																																				—	—	—	—	—	—	—																
																																																											—	—	—	—	—	—	—									
																																																																		—	—	—	—	—	—	—		
			—	—				—	—	—	—	—																																																														
					—	—	—						—	—	—	—																																																										
																	—	—	—	—	—	—	—																																																			
																								—	—	—	—	—	—	—																																												
																															—																																											

NOTE :

For 75kW or larger models, DC reactor is provided as standard (separately installed). For the outline dimensions, see page 27.

**Fig. 7**

**KEYPAD panel**  
(Common for all models)





## Reactor, Filter, and Other Accessories

Name (Type)	Function	Mounting position
<b>Arrester</b> (CN23232) (CN2324E)	Suppresses induced lightning surges from power source , thus protecting all equipment connected the power source.	
<b>Radio noise reducing zero-phase reactor</b> (ACL-40B) (ACL-74B)	Reduces radio frequency noise. If the wiring between motor and inverter is shorter than 20m, use the ferrite ring in the power supply side. If longer than 20m, use it in the output side.	
<b>Power filter</b> (FHF-TA/□□/250) (FHF-TA/□□/500) (FHF-TB/□□/250) (FHF-TB/□□/500)	Prevents the noise generated from the inverter.  Supresses radiation noise and induction noise generated from the output side wiring.	
<b>EMC compliant filter</b> (EFL-□□□SP-2) (EFL-□□□G11-4) (RF3□□□-F11)	This is a special filter which complies with the European EMC (Emission) Directive. This filter should be used together with a ferrite core. <i>Note: Other prerequisites must be fulfilled to ensure compliance with EMC Directives. Refer to this filters operation manual for details.</i>	
<b>Output circuit filter</b> (OFL-□□□-□) (OFL-□□□-4A)	Connected to the output circuit of inverters under low-noise operation with carrier frequency from 8 to 15kHz, 6kHz or higher for 30kW or larger inverters (OFL-□□□-□), 0.75 to 15kHz, 0.75 to 10kHz for 75kW or larger inverters (OFL-□□□-4A). This filter has the following functions: ① Suppressing fluctuation of motor terminal voltage. Protects the motor insulation from being damaged by surge voltage. (400V series) ② Suppressing leakage current from output side wiring. (OFL-□□□-□ only) Reduces the leakage current caused when several motors are operated in parallel or connected with long wiring. * Total wiring length should be less than 400m. ③ Suppressing radial noise or inductive noise from output side wiring. Effective noise suppression device for long wiring applications such as plant. <i>Note: When connecting OFL-□□□-□, be sure to set the carrier frequency F26 at 8kHz or over.</i>	
<b>DC REACTOR(DCR)</b> (DCR4-□□□) (DCR2-□□□)	[Use the DCR to normalize the power supply in the following cases.] ① The power transformer capacity is 500kVA or over and exceeds the inverter rated capacity by 10 times. ② The inverter and a thyristor converter are connected with the same transformer. * Check if the thyristor converter uses a commutation reactor. If not, AC reactor must be connected to the power supply side. ③ Overvoltage trip occurs due to open/close of the phase-advancing capacitor for the power supply lines. ④ The voltage unbalance exceeds 2%.  $\text{Voltage unbalance (\%)} = \frac{\text{Max. voltage [V]} - \text{Min. Voltage [V]}}{\text{Three-phase average voltage [V]}} \times 67$  <p>[For improving input power-factor, reducing harmonics]  • Used to reduce input harmonic current (correcting power-factor)  • For the resultant effects, refer to the appended guidelines.</p>	
<b>Surge absorber</b> (Surge suppressor) (S2-A-0) (S1-B-0)	S2-A-0: for magnetic contactor S1-B-0: for mini control relay, or timer	
<b>Frequency meter</b> (TRM-45) (FM-60)	Analog frequency meter TRM-45: 45mm square FM-60 : 60mm square	
<b>Frequency setting device</b> (RJ-13) (WA3W-1kΩ)	Frequency setting potentiometer (mounted externally)	

# DC reactor

Fig. A




Fig. B




Fig. C





Fig. D



\*Provided with as standard (separately installed) for inverters of 75kW or larger capacity.

Power supply voltage	Nominal applied motor (kW)	Inverter type	Reactor type	Fig	Dimensions, mm										Mass (kg)
					A	B	C	D	E	F	G	H	Terminal screw		
Three-phase 400V	0.4	FRN0.4G11S-4JE	DCR4-0.4	A	66	56	72	90	15	-	5.2×8	94	M4	1.0	
	0.75	FRN0.75G11S-4JE	DCR4-0.75	A	66	56	72	90	20	-	5.2×8	94	M4	1.4	
	1.5	FRN1.5G11S-4JE	DCR4-1.5	A	66	56	72	90	20	-	5.2×8	94	M4	1.6	
	2.2	FRN2.2G11S-4JE	DCR4-2.2	A	86	71	80	100	15	-	6×9	110	M4	2.0	
	3.7	FRN3.7G11S-4JE	DCR4-3.7	A	86	71	80	100	20	-	6×9	110	M4	2.6	
	5.5	FRN5.5G11S/P11S-4JE	DCR4-5.5	A	86	71	80	100	20	-	6×9	110	M4	2.6	
	7.5	FRN7.5G11S/P11S-4JE	DCR4-7.5	A	111	95	80	100	24	-	7×11	130	M5	4.2	
	11	FRN11G11S/P11S-4JE	DCR4-11	A	111	95	80	100	24	-	7×11	130	M5	4.3	
	15	FRN15G11S/P11S-4JE	DCR4-15	A	146	124	96	120	15	-	7×11	171	M5	5.9	
	18.5	FRN18.5G11S/P11S-4JE	DCR4-18.5	A	146	124	96	120	25	-	7×11	171	M6	7.2	
	22	FRN22G11S/P11S-4JE	DCR4-22A	A	146	124	96	120	25	-	7×11	171	M6	7.2	
	30	FRN30G11S/P11S-4JE	DCR4-30B	B	152	90	115	157	100	78	8	130	M8	13	
	37	FRN37G11S/P11S-4JE	DCR4-37B	B	171	110	110	150	100	75	8	150	M8	15	
	45	FRN45G11S/P11S-4JE	DCR4-45B	B	171	110	125	165	110	82	8	150	M8	18	
	55	FRN55G11S/P11S-4JE	DCR4-55B	B	171	110	130	170	110	85	8	150	M8	20	
	75	FRN75G11S/P11S-4JE	DCR4-75B	C	190	160	115	151	100	75	10	240	M10	20	
	90	FRN90G11S/P11S-4JE	DCR4-90B	C	190	160	125	161	120	80	10	250	ø12	23	
	110	FRN110G11S/P11S-4JE	DCR4-110B	C	190	160	125	161	120	80	10	250	ø12	25	
	132	FRN132G11S/P11S-4JE	DCR4-132B	C	200	170	135	171	120	85	10	260	ø12	28	
	160	FRN160G11S/P11S-4JE	DCR4-160B	C	210	180	135	171	120	85	12	290	ø12	32	
200	FRN200G11S/P11S-4JE	DCR4-200B	C	210	180	135	171	140	90	12	295	ø12	35		
220	FRN220G11S/P11S-4JE	DCR4-220B	C	220	190	135	171	140	90	12	300	ø15	40		
280	FRN280G11S/P11S-4JE	DCR4-280B	C	220	190	145	181	150	95	12	320	ø15	45		
315	FRN315G11S/P11S-4JE	DCR4-315B	D	220	190	145	181	150	95	12	320	ø15	52		
355	FRN355G11S/P11S-4JE	DCR4-355B	D	220	190	145	181	160	95	12	320	ø15	55		
400	FRN400G11S/P11S-4JE	DCR4-400B	D	240	210	145	181	170	95	12	340	ø15	60		
450	FRN450P11S-4JE	DCR4-450B	D	260	225	145	181	170	95	12	340	ø15	67		
500	FRN500G11S/P11S-4JE	DCR4-500B	D	260	225	145	181	185	100	12	340	ø15	70		
630	FRN630G11S/P11S-4JE	DCR4-630B	D	300	245	170	211	195	110	12	390	ø15	80		
710	FRN710P11S-4JE	DCR4-710B	D	310	255	170	211	205	115	12	405	ø15	88		
Three-phase 200V	0.2	FRN0.2G11S-2JE	DCR2-0.2	A	66	56	72	90	5	-	5.2×8	94	M4	0.8	
	0.4	FRN0.4G11S-2JE	DCR2-0.4	A	66	56	72	90	15	-	5.2×8	94	M4	1.0	
	0.75	FRN0.75G11S-2JE	DCR2-0.75	A	66	56	72	90	20	-	5.2×8	94	M4	1.4	
	1.5	FRN1.5G11S-2JE	DCR2-1.5	A	66	56	72	90	20	-	5.2×8	94	M4	1.6	
	2.2	FRN2.2G11S-2JE	DCR2-2.2	A	86	71	80	100	10	-	6×11	110	M4	1.8	
	3.7	FRN3.7G11S-2JE	DCR2-3.7	A	86	71	80	100	20	-	6×11	110	M4	2.6	
	5.5	FRN5.5G11S/P11S-2JE	DCR2-5.5	A	111	95	80	100	20	-	7×11	130	M5	3.6	
	7.5	FRN7.5G11S/P11S-2JE	DCR2-7.5	A	111	95	80	100	23	-	7×11	130	M5	3.8	
	11	FRN11G11S/P11S-2JE	DCR2-11	A	111	95	80	100	24	-	7×11	137	M6	4.3	
	15	FRN15G11S/P11S-2JE	DCR2-15	A	146	124	96	120	15	-	7×11	171	M6	5.9	
	18.5	FRN18.5G11S/P11S-2JE	DCR2-18.5	A	146	124	96	120	25	-	7×11	180	M8	7.4	
	22	FRN22G11S/P11S-2JE	DCR2-22A	A	146	124	96	120	25	-	7×11	180	M8	7.5	
	30	FRN30G11S/P11S-2JE	DCR2-30B	B	152	90	116	156	115	78	8	130	M10	12	
	37	FRN37G11S/P11S-2JE	DCR2-37B	B	171	110	110	151	115	75	8	150	M10	14	
	45	FRN45G11S/P11S-2JE	DCR2-45B	B	171	110	125	166	120	86	8	150	M10	16	
	55	FRN55G11S/P11S-2JE	DCR2-55B	C	190	160	90	131	100	65	8	210	M12	16	
	75	FRN75G11S/P11S-2JE	DCR2-75B	C	200	170	100	141	110	70	10	210	M12	18	
	90	FRN90G11S/P11S-2JE	DCR2-90B	C	180	150	110	151	140	75	10	240	ø15	20	
	110	FRN110P11S-2JE	DCR2-110B	C	190	160	120	161	150	80	10	270	ø15	25	


The reactors in the blue boxes are provided as standard (separately installed).

# Braking unit, Braking resistor

Power supply voltage	Inverter				Option				G11S	Continuous braking (100% torque conversion value)				Repetitive braking (100s or less cycle)				P11S	Continuous braking (100% torque conversion value)				Repetitive braking (100s or less cycle)			
	G11S		P11S		Braking unit		Braking resistor			Max. braking torque (%)	Braking time (s)	Discharging capability (kWs)	Duty cycle (%)	Average loss (kW)	Max. braking torque (%)	Braking time (s)	Discharging capability (kWs)		Duty cycle (%)	Average loss (kW)						
	Motor (kW)	Inverter type	Motor (kW)	Inverter type																	Type	Q'ty	Type	Q'ty		
Three-phase 400V	0.4	FRN0.4G11S-4JE	—	—	—	—	DB0.75-4	1	150%	45	9	22	0.044	—	—	—	—	—	—							
	0.75	FRN0.75G11S-4JE						1		45	17	18	0.068													
	1.5	FRN1.5G11S-4JE						1		45	34	10	0.075													
	2.2	FRN2.2G11S-4JE						1		30	33	7	0.077													
	3.7	FRN3.7G11S-4JE	5.5	FRN5.5P11S-4JE	—	—	DB3.7-4	1		20	37	5	0.093	100%	15	37	3.5	0.093								
	5.5	FRN5.5G11S-4JE	7.5	FRN7.5P11S-4JE	—	—	DB5.5-4	1		20	55	5	0.138		15	55	3.5	0.138								
	7.5	FRN7.5G11S-4JE	11	FRN11P11S-4JE	—	—	DB7.5-4	1		10	38	5	0.188		7	38	3.5	0.188								
	11	FRN11G11S-4JE	15	FRN15P11S-4JE	BU22-4C	1	DB11-4	1		10	55	5	0.275		7	55	3.5	0.275								
	15	FRN15G11S-4JE	18.5	FRN18.5P11S-4JE		1	DB15-4	1		10	75	5	0.375		8	75	4	0.375								
	18.5	FRN18.5G11S-4JE	22	FRN22P11S-4JE		1	DB18.5-4	1		10	93	5	0.463		8	93	4	0.463								
	22	FRN22G11S-4JE	30	FRN30P11S-4JE		1	DB22-4	1		8	88	5	0.55		6	88	3	0.55								
	30	FRN30G11S-4JE	37	FRN37P11S-4JE	BU37-4C	1	DB30-4C	1		10	150	10	1.5		75%	8	150	8	1.5							
	37	FRN37G11S-4JE	45	FRN45P11S-4JE		1	DB37-4C	1		10	185	10	1.85	8		185	8	1.85								
	45	FRN45G11S-4JE	55	FRN55P11S-4JE	BU55-4C	1	DB45-4C	1		10	225	10	2.25	8		225	8	2.25								
	55	FRN55G11S-4JE	75	FRN75P11S-4JE		1	DB55-4C	1		10	275	10	2.75	7		275	7	2.75								
	75	FRN75G11S-4JE	90	FRN90P11S-4JE	BU90-4C	1	DB75-4C	1		10	375	10	3.75	8		375	8	3.75								
	90	FRN90G11S-4JE	110	FRN110P11S-4JE		1	DB110-4C	1		10	450	10	4.5	8		450	8	4.5								
	110	FRN110G11S-4JE	132	FRN132P11S-4JE	BU132-4C	1	DB110-4C	1		10	550	10	5.5	8		550	8	5.5								
	132	FRN132G11S-4JE	160	FRN160P11S-4JE		1	DB132-4C	1		10	665	10	6.65	8		665	8	6.65								
	160	FRN160G11S-4JE	200	FRN200P11S-4JE	BU220-4C	1	DB160-4C	1		10	800	10	8.0	8		800	8	8.0								
	200	FRN200G11S-4JE	220	FRN220P11S-4JE		1	DB200-4C	1		10	1000	10	10.0	9		1000	9	10.0								
	220	FRN220G11S-4JE	280	FRN280P11S-4JE		1	DB220-4C	1		10	1100	10	11.0	8		1100	8	11.0								
	280	FRN280G11S-4JE	315	FRN315P11S-4JE		2	DB160-4C	2		11	1600	11	16.0	10		1600	10	16.0								
	315	FRN315G11S-4JE	355	FRN355P11S-4JE		2	DB160-4C	2		10	1600	10	16.0	9		1600	9	16.0								
	355	FRN355G11S-4JE	400	FRN400P11S-4JE		2	DB200-4C	2		11	2000	11	20.0	10		2000	10	20.0								
	400	FRN400G11S-4JE	450	FRN450P11S-4JE		2	DB200-4C	2		10	2000	10	20.0	9		2000	9	20.0								
	—	—	500	FRN500P11S-4JE		2	DB200-4C	2		—	—	—	—	8		2000	8	20.0								
	500	FRN500G11S-4JE	630	FRN630P11S-4JE								Contact Fuji.														
	630	FRN630G11S-4JE	710	FRN710P11S-4JE																						
	Three-phase 200V	0.2	FRN0.2G11S-2JE	—	—	—	—	DB0.75-2		1	150%	90	9	37	0.037	—	—	—	—	—						
0.4		FRN0.4G11S-2JE	1						45	9		22	0.044													
0.75		FRN0.75G11S-2JE	1						45	17		18	0.068													
1.5		FRN1.5G11S-2JE	1						45	34		10	0.075													
2.2		FRN2.2G11S-2JE					DB2.2-2	1	30	33		7	0.077													
3.7		FRN3.7G11S-2JE	5.5	FRN5.5P11S-2JE	—	—	DB3.7-2	1	20	37		5	0.093	100%	15	37	3.5	0.093								
5.5		FRN5.5G11S-2JE	7.5	FRN7.5P11S-2JE				BU22-2C	1	DB5.5-2		1	20		55	5	0.138	15	55	3.5	0.138					
7.5		FRN7.5G11S-2JE	11	FRN11P11S-2JE					BU37-2C	1		DB7.5-2	1		10	37	5	0.188	7	37	3.5	0.188				
11		FRN11G11S-2JE	15	FRN15P11S-2JE						1		DB11-2	1		10	55	5	0.275	7	55	3.5	0.275				
15		FRN15G11S-2JE	18.5	FRN18.5P11S-2JE	1	DB15-2	1			10		75	5		0.375	8	75	4	0.375							
18.5		FRN18.5G11S-2JE	22	FRN22P11S-2JE	1	DB18.5-2	1	10		92		5	0.463		8	92	4	0.463								
22		FRN22G11S-2JE	30	FRN30P11S-2JE	1	DB22-2	1	8	88	5		0.55	6		88	3.5	0.55									
30		FRN30G11S-2JE	37	FRN37P11S-2JE	BU37-2C	1	DB30-2C	1	10	150		10	1.5		75%	8	150	8	1.5							
37		FRN37G11S-2JE	45	FRN45P11S-2JE		1	DB37-2C	1	10	185		10	1.85	8		185	8	1.85								
45		FRN45G11S-2JE	55	FRN55P11S-2JE	BU55-2C	1	DB45-2C	1	10	225		10	2.25	8		225	8	2.25								
55		FRN55G11S-2JE	75	FRN75P11S-2JE		1	DB55-2C	1	10	275		10	2.75	7		275	7	2.75								
75		FRN75G11S-2JE	90	FRN90P11S-2JE	BU90-2C	1	DB75-2C	1	10	375		10	3.75	8		375	8	3.75								
90		FRN90G11S-2JE	110	FRN110P11S-2JE		1	DB90-2C	1	10	450		10	4.5	8		450	8	4.5								

## NOTES:

- Each model of the P11S series uses options that are one-class smaller than the options for the G11S series of the same capacity.
- The braking time and duty cycle (%) are calculated as the rated-torque braking used for deceleration.



$$\bullet \text{ Duty cycle (\%)} = \frac{T_1}{T_0} \times 100 [\%]$$

## [Procedure for selecting options]

All three conditions listed below must be satisfied.

- The maximum braking torque does not exceed the value shown in the table.
- The energy discharged in the resistor for each braking (the area of the triangle shown in the above figure) does not exceed the discharging capability (kWs) in the table.
- The average loss (energy discharged in the resistor divided by a braking interval) does not exceed the average loss (kW) shown in the table.



Name (type)	Dimensions																																																																																																																																																																																											
Braking unit	Fig.A		Fig.B																																																																																																																																																																																									
	Fig.C																																																																																																																																																																																											
	<table><tr><th>Voltage</th><th>Type</th><th>Fig.</th><th colspan="6">Dimensions [mm]</th><th>Mass [kg]</th></tr><tr><th rowspan="5">400V series</th><td>BU3-220-4</td><td>A</td><td colspan="6">See Fig. A</td><td>1.1</td></tr><tr><td>BU37-4C</td><td rowspan="4">C</td><td>150</td><td>100</td><td rowspan="3">280</td><td rowspan="3">265</td><td rowspan="3">250</td><td rowspan="3">160</td><td>4</td></tr><tr><td>BU55-4C</td><td>230</td><td>130</td><td>5.5</td></tr><tr><td>BU90-4C</td><td rowspan="2">250</td><td colspan="5">150</td><td>9</td></tr><tr><td>BU132-4C</td><td>450</td><td>435</td><td>420</td><td>13</td></tr><tr><td>BU220-4C</td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td></tr><tr><th rowspan="5">200V series</th><td>BU3-185-2</td><td>A</td><td colspan="6">See Fig. A</td><td>1.1</td></tr><tr><td>BU3-220-2</td><td rowspan="4">B</td><td>150</td><td>100</td><td>240</td><td>225</td><td rowspan="2">210</td><td rowspan="3">160</td><td>1.2</td></tr><tr><td>BU37-2C</td><td>230</td><td>130</td><td>240</td><td>225</td><td>4</td></tr><tr><td>BU55-2C</td><td rowspan="2">250</td><td rowspan="2">150</td><td rowspan="2">370</td><td rowspan="2">355</td><td rowspan="2">340</td><td>6</td></tr><tr><td>BU90-2C</td><td>9</td></tr></table>										Voltage	Type	Fig.	Dimensions [mm]						Mass [kg]	400V series	BU3-220-4	A	See Fig. A						1.1	BU37-4C	C	150	100	280	265	250	160	4	BU55-4C	230	130	5.5	BU90-4C	250	150					9	BU132-4C	450	435	420	13	BU220-4C									200V series	BU3-185-2	A	See Fig. A						1.1	BU3-220-2	B	150	100	240	225	210	160	1.2	BU37-2C	230	130	240	225	4	BU55-2C	250	150	370	355	340	6	BU90-2C	9																																																																																									
Voltage	Type	Fig.	Dimensions [mm]						Mass [kg]																																																																																																																																																																																			
400V series	BU3-220-4	A	See Fig. A						1.1																																																																																																																																																																																			
	BU37-4C	C	150	100	280	265	250	160	4																																																																																																																																																																																			
	BU55-4C		230	130					5.5																																																																																																																																																																																			
	BU90-4C		250	150					9																																																																																																																																																																																			
	BU132-4C			450	435	420	13																																																																																																																																																																																					
BU220-4C																																																																																																																																																																																												
200V series	BU3-185-2	A	See Fig. A						1.1																																																																																																																																																																																			
	BU3-220-2	B	150	100	240	225	210	160	1.2																																																																																																																																																																																			
	BU37-2C		230	130	240	225			4																																																																																																																																																																																			
	BU55-2C		250	150	370	355	340		6																																																																																																																																																																																			
	BU90-2C							9																																																																																																																																																																																				
Braking resistor	Fig.A		Fig.B		Fig.C																																																																																																																																																																																							
	Fig.D																																																																																																																																																																																											
	Fig.E																																																																																																																																																																																											
	<p>* Note: The braking resistor type DB220-4C use two braking resistors.</p>																																																																																																																																																																																											
	<table><tr><th>Voltage</th><th>Type</th><th>Fig.</th><th>W</th><th>W1</th><th>H</th><th>H1</th><th>D</th><th>Mass [kg]</th></tr><tr><th rowspan="15">400V series</th><td>DB0.75-4</td><td rowspan="3">A</td><td>64</td><td>-</td><td>310</td><td>295</td><td>67</td><td>1.3</td></tr><tr><td>DB2.2-4</td><td rowspan="2">74</td><td rowspan="2">470</td><td rowspan="2">455</td><td rowspan="2">67</td><td rowspan="2">2.0</td></tr><tr><td>DB3.7-4</td></tr><tr><td>DB5.5-4</td><td rowspan="3">B</td><td>142</td><td>74</td><td>470</td><td>455</td><td>67</td><td>4.5</td></tr><tr><td>DB7.5-4</td><td rowspan="2">74</td><td rowspan="2">430</td><td rowspan="2">415</td><td rowspan="2">160</td><td rowspan="2">6.9</td></tr><tr><td>DB11-4</td></tr><tr><td>DB15-4</td><td rowspan="3">C</td><td>142</td><td>74</td><td>510</td><td>495</td><td>160</td><td>6.9</td></tr><tr><td>DB18.5-4</td><td rowspan="2">74</td><td rowspan="2">660</td><td rowspan="2">628</td><td rowspan="2">240</td><td rowspan="2">11</td></tr><tr><td>DB22-4</td></tr><tr><td>DB30-4C</td><td rowspan="3">D</td><td>420</td><td>388</td><td>750</td><td>718</td><td>140</td><td>19</td></tr><tr><td>DB37-4C</td><td rowspan="2">520</td><td rowspan="2">283</td><td rowspan="2">240</td><td rowspan="2">440</td><td rowspan="2">26</td></tr><tr><td>DB45-4C</td></tr><tr><td>DB55-4C</td><td rowspan="3">E</td><td>550</td><td>520</td><td rowspan="3">283</td><td rowspan="3">240</td><td rowspan="3">440</td><td>30</td></tr><tr><td>DB75-4C</td><td>650</td><td>620</td><td>41</td></tr><tr><td>DB110-4C</td><td>750</td><td>720</td><td>57</td></tr><tr><td>DB160-4C</td><td rowspan="3">A</td><td>600</td><td>570</td><td>283</td><td>240</td><td>440</td><td>74</td></tr><tr><td>DB200-4C</td><td rowspan="2">74</td><td rowspan="2">430</td><td rowspan="2">415</td><td rowspan="2">160</td><td rowspan="2">6.9</td></tr><tr><td>DB220-4C *</td></tr><tr><th rowspan="14">200V series</th><td>DB0.75-2</td><td rowspan="3">B</td><td>64</td><td>-</td><td>310</td><td>295</td><td>67</td><td>1.3</td></tr><tr><td>DB2.2-2</td><td rowspan="2">76</td><td rowspan="2">345</td><td rowspan="2">332</td><td rowspan="2">94</td><td rowspan="2">2.0</td></tr><tr><td>DB3.7-2</td></tr><tr><td>DB5.5-2</td><td rowspan="3">C</td><td>142</td><td>90</td><td>450</td><td>430</td><td>67.5</td><td>4.5</td></tr><tr><td>DB7.5-2</td><td rowspan="2">156</td><td rowspan="2">390</td><td rowspan="2">370</td><td rowspan="2">90</td><td rowspan="2">5.0</td></tr><tr><td>DB11-2</td></tr><tr><td>DB15-2</td><td rowspan="3">D</td><td>142</td><td>74</td><td>430</td><td>415</td><td>160</td><td>6.9</td></tr><tr><td>DB18.5-2</td><td rowspan="2">74</td><td rowspan="2">510</td><td rowspan="2">495</td><td rowspan="2">240</td><td rowspan="2">18</td></tr><tr><td>DB22-2</td></tr><tr><td>DB30-2C</td><td rowspan="3">E</td><td>400</td><td>368</td><td>750</td><td>718</td><td>140</td><td>10</td></tr><tr><td>DB37-2C</td><td rowspan="2">420</td><td rowspan="2">388</td><td rowspan="2">660</td><td rowspan="2">628</td><td rowspan="2">240</td><td rowspan="2">13</td></tr><tr><td>DB45-2C</td></tr><tr><td>DB55-2C</td><td rowspan="3">F</td><td>550</td><td>520</td><td>283</td><td>240</td><td>440</td><td>35</td></tr><tr><td>DB75-2C</td><td rowspan="2">74</td><td rowspan="2">430</td><td rowspan="2">415</td><td rowspan="2">160</td><td rowspan="2">6.9</td></tr><tr><td>DB110-2C</td></tr></table>										Voltage	Type	Fig.	W	W1	H	H1	D	Mass [kg]	400V series	DB0.75-4	A	64	-	310	295	67	1.3	DB2.2-4	74	470	455	67	2.0	DB3.7-4	DB5.5-4	B	142	74	470	455	67	4.5	DB7.5-4	74	430	415	160	6.9	DB11-4	DB15-4	C	142	74	510	495	160	6.9	DB18.5-4	74	660	628	240	11	DB22-4	DB30-4C	D	420	388	750	718	140	19	DB37-4C	520	283	240	440	26	DB45-4C	DB55-4C	E	550	520	283	240	440	30	DB75-4C	650	620	41	DB110-4C	750	720	57	DB160-4C	A	600	570	283	240	440	74	DB200-4C	74	430	415	160	6.9	DB220-4C *	200V series	DB0.75-2	B	64	-	310	295	67	1.3	DB2.2-2	76	345	332	94	2.0	DB3.7-2	DB5.5-2	C	142	90	450	430	67.5	4.5	DB7.5-2	156	390	370	90	5.0	DB11-2	DB15-2	D	142	74	430	415	160	6.9	DB18.5-2	74	510	495	240	18	DB22-2	DB30-2C	E	400	368	750	718	140	10	DB37-2C	420	388	660	628	240	13	DB45-2C	DB55-2C	F	550	520	283	240	440	35	DB75-2C	74	430	415	160	6.9	DB110-2C
Voltage	Type	Fig.	W	W1	H	H1	D	Mass [kg]																																																																																																																																																																																				
400V series	DB0.75-4	A	64	-	310	295	67	1.3																																																																																																																																																																																				
	DB2.2-4		74	470	455	67	2.0																																																																																																																																																																																					
	DB3.7-4																																																																																																																																																																																											
	DB5.5-4	B	142	74	470	455	67	4.5																																																																																																																																																																																				
	DB7.5-4		74	430	415	160	6.9																																																																																																																																																																																					
	DB11-4																																																																																																																																																																																											
	DB15-4	C	142	74	510	495	160	6.9																																																																																																																																																																																				
	DB18.5-4		74	660	628	240	11																																																																																																																																																																																					
	DB22-4																																																																																																																																																																																											
	DB30-4C	D	420	388	750	718	140	19																																																																																																																																																																																				
	DB37-4C		520	283	240	440	26																																																																																																																																																																																					
	DB45-4C																																																																																																																																																																																											
	DB55-4C	E	550	520	283	240	440	30																																																																																																																																																																																				
	DB75-4C		650	620				41																																																																																																																																																																																				
	DB110-4C		750	720				57																																																																																																																																																																																				
DB160-4C	A	600	570	283	240	440	74																																																																																																																																																																																					
DB200-4C		74	430	415	160	6.9																																																																																																																																																																																						
DB220-4C *																																																																																																																																																																																												
200V series	DB0.75-2	B	64	-	310	295	67	1.3																																																																																																																																																																																				
	DB2.2-2		76	345	332	94	2.0																																																																																																																																																																																					
	DB3.7-2																																																																																																																																																																																											
	DB5.5-2	C	142	90	450	430	67.5	4.5																																																																																																																																																																																				
	DB7.5-2		156	390	370	90	5.0																																																																																																																																																																																					
	DB11-2																																																																																																																																																																																											
	DB15-2	D	142	74	430	415	160	6.9																																																																																																																																																																																				
	DB18.5-2		74	510	495	240	18																																																																																																																																																																																					
	DB22-2																																																																																																																																																																																											
	DB30-2C	E	400	368	750	718	140	10																																																																																																																																																																																				
	DB37-2C		420	388	660	628	240	13																																																																																																																																																																																				
	DB45-2C																																																																																																																																																																																											
	DB55-2C	F	550	520	283	240	440	35																																																																																																																																																																																				
	DB75-2C		74	430	415	160	6.9																																																																																																																																																																																					
DB110-2C																																																																																																																																																																																												
Radio noise reducing zero-phase reactor (ACL-40B)(ACL-74B)	ACL-40B		ACL-74B																																																																																																																																																																																									
	ACL-40B		ACL-74B																																																																																																																																																																																									
	<p>Recommended wire size</p> <table><tr><th>Reactor type</th><th>Q'ty</th><th>No. of turns</th><th>Recommended wire size [mm²]</th></tr><tr><td rowspan="2">ACL-40B</td><td>1</td><td>4</td><td>2.0, 3.5, 5.5</td></tr><tr><td>2</td><td>2</td><td>8, 14</td></tr><tr><td rowspan="3">ACL-74B</td><td>1</td><td>4</td><td>8, 14</td></tr><tr><td>2</td><td>2</td><td>22, 38, 60, 5.5 × 2, 8 × 2, 14 × 2, 22 × 2</td></tr><tr><td>4</td><td>1</td><td>100, 150, 200, 250, 325, 38 × 2, 60 × 2, 100 × 2, 150 × 2</td></tr></table>										Reactor type	Q'ty	No. of turns	Recommended wire size [mm²]	ACL-40B	1	4	2.0, 3.5, 5.5	2	2	8, 14	ACL-74B	1	4	8, 14	2	2	22, 38, 60, 5.5 × 2, 8 × 2, 14 × 2, 22 × 2	4	1	100, 150, 200, 250, 325, 38 × 2, 60 × 2, 100 × 2, 150 × 2																																																																																																																																																													
Reactor type	Q'ty	No. of turns	Recommended wire size [mm²]																																																																																																																																																																																									
ACL-40B	1	4	2.0, 3.5, 5.5																																																																																																																																																																																									
	2	2	8, 14																																																																																																																																																																																									
ACL-74B	1	4	8, 14																																																																																																																																																																																									
	2	2	22, 38, 60, 5.5 × 2, 8 × 2, 14 × 2, 22 × 2																																																																																																																																																																																									
	4	1	100, 150, 200, 250, 325, 38 × 2, 60 × 2, 100 × 2, 150 × 2																																																																																																																																																																																									

# Option cards and other options

Name (type)	Function	Specifications		
Relay output card (OPC-G11S-RY)	<ul style="list-style-type: none"><li>Includes four relay output circuits.</li><li>Converts transistor output signals from inverter control output terminals Y1 to Y4 to relay (SPDT) output signals.</li></ul>			
Digital I/O interface card (OPC-G11S-DIO)	<ul style="list-style-type: none"><li>For setting frequency using a binary code.</li><li>For monitoring frequency, output current, and output voltage using a binary code.</li><li>For input and output of other individual signals.</li></ul>			
Analog I/O interface card (OPC-G11S-AIO)	<ul style="list-style-type: none"><li>For setting a torque limit value using an input analog signal.</li><li>For input of auxiliary signal to set frequency.</li><li>For analog monitoring of inverter output frequency, output current, and torque.</li></ul>			
T-link interface card (OPC-G11S-TL)	<ul style="list-style-type: none"><li>For setting a frequency.</li><li>For setting, reading, and storing function data for function codes.</li><li>For setting operation commands (FWD, REV, RST, etc.).</li><li>For monitoring the operation status.</li><li>For reading trip information.</li></ul>	• Used together with MICREX-F series PLC.		
Open bus card	It is an optional card conforming to various open buses. The following operation can be made from the personal computer and PLC. <ul style="list-style-type: none"><li>Setting of running frequency</li><li>Setting of operation command (FWD,REV,RST,etc.)</li><li>Setting/reading of data code of each function code</li><li>Monitoring running frequency and operation status</li></ul>	Correspondent bus	Option type	
		PROFIBUS-DP DeviceNet Modbus Plus Interbus-S CAN open	OPC-G11S-PDP OPC-G11S-DEV OPC-G11S-MBP OPC-G11S-IBS OPC-G11S-COP	
RS-232C communication adaptor (OPC-G11S-PC)	The RS-232C communication can be done by connecting it to the keypad panel on the main body of the inverter.			
Personal computer loader	<ul style="list-style-type: none"><li>The operation status monitoring and the parameter setting can be made through the inverter's RS-485 interface from the host personal computer.</li><li>The parameter can be read and written collectively or individually.</li><li>Comparison of two arbitrary parameters.</li><li>Monitor of output frequency, output current, and operation status of inverter.</li><li>Monitor of alarm history and operation information on alarm.</li></ul>	Communication <ul style="list-style-type: none"><li>Physical level : EIA-RS-485</li><li>The number of units connected : Maximum 31 inverters</li><li>Synchronous method : start-stop synchronization</li><li>Transmission method : half duplex</li></ul>		
PG feedback card (OPC-G11S-PG)	<ul style="list-style-type: none"><li>For performing PG vector control using feedback signals obtained from a PG.</li></ul>	Applicable Pulse Encoder specification: <ul style="list-style-type: none"><li>• 100 to 3000P/R • A, B, Z phase • 12V or 15V</li></ul>		
PG feedback card (OPC-G11S-PG2)	<ul style="list-style-type: none"><li>For performing PG vector control using feedback signals obtained from a PG.</li></ul>	Applicable Pulse Encoder specification: <ul style="list-style-type: none"><li>• 100 to 3000P/R • A, B, Z phase • 5V</li></ul>		
Synchronized operation card (OPC-G11S-SY)	<ul style="list-style-type: none"><li>Speed control by pulse train input can be made.</li></ul>	Applicable Pulse Encoder specification: <ul style="list-style-type: none"><li>• 20 to 3000P/R • A, B, Z phase • 12V or 15V</li></ul>		
Extension cable for keypad panel (CBIII-10R-□□)	Connects the keypad panel to an inverter unit. Three cable types are available: straight 2m, curled 1m, and curled 2m. The curled 1m cable can be extended up to 5m, and the curled 2m cable up to 10m. Note: Cables once extended to the maximum length do not return to their original length.	Type	Nominal length	Maximum length
		CBIII-10R-2S	2m	2m
		CBIII-10R-1C	1m	5m
		CBIII-10R-2C	2m	10m
IP20 enclosure adapter (P20G11-□□)	• Used to put 30kW or larger models to change its enclosure of IP00 into that of IP20.	Type	Applicable inverter type	
		P20G11-30	FRN30G11S-4JE-2JE FRN30P11S-4JE-2JE to FRN37P11S-4JE-2JE	
		P20G11-55	FRN37G11S-4JE to FRN55G11S-4JE FRN45P11S-4JE to FRN75P11S-4JE	
		P20G11-75-4	FRN75G11S-4JE FRN37G11S-2JE to FRN55G11S-2JE FRN90P11S-4JE FRN45P11S-2JE to FRN75P11S-2JE	
		P20G11-75-2	FRN75G11S-2JE, FRN90P11S-2JE	
		P20G11-110	FRN90G11S-4JE to FRN110G11S-4JE FRN110P11S-4JE to FRN132P11S-4JE	
		P20G11-160	FRN132G11S-4JE to FRN160G11S-4JE FRN160P11S-4JE to FRN200P11S-4JE	
		P20G11-220	FRN200G11S-4JE to FRN220G11S-4JE FRN90G11S-2JE FRN220P11S-4JE to FRN280P11S-4JE FRN110P11S-2JE	
		P20G11-315	FRN280G11S-4JE to FRN315G11S-4JE FRN315P11S-4JE to FRN400P11S-4JE	
		P20G11-400	FRN315G11S-4JE to FRN400G11S-4JE FRN450P11S-4JE to FRN500P11S-4JE	
Mounting adapter for external cooling (PBG11-□□)	<ul style="list-style-type: none"><li>Used to put the cooling fan section of the inverter outside the panel.</li><li>Only applicable to 22kW and below inverters. (30kW and above inverters can be modified to external cooling type by replacing the mounting bracket, as standard.)</li></ul>	Type	Applicable inverter type	
		PBG11-0.75	FRN0.4G11S-4JE to FRN0.75G11S-4JE FRN0.2G11S-2JE to FRN0.75G11S-2JE	
		PBG11-3.7	FRN1.5G11S-4JE to FRN3.7G11S-4JE FRN1.5G11S-2JE to FRN3.7G11S-2JE	
		PBG11-7.5	FRN5.5G11S-4JE, 2JE to FRN7.5G11S-4JE, 2JE FRN5.5P11S-4JE, 2JE to FRN11P11S-4JE, 2JE	
		PBG11-22	FRN11G11S-4JE, 2JE to FRN22G11S-4JE, 2JE FRN15P11-4JE, 2JE to FRN22P11S-4JE, 2JE	
Panel-mount adapter (MAG9-□□)	Used to put an FRN-G11S inverter to be mounted in panel holes that were used to mount an FVR-G7S inverter.	Type	Applicable inverter type	
		MAG9-3.7	FRN0.4G11S-4JE to FRN3.7G11S-4JE FRN0.4G11S-2JE to FRN3.7G11S-2JE	
		MAG9-7.5	FRN5.5G11S-4JE to FRN7.5G11S-4JE FRN5.5G11S-2JE to FRN7.5G11S-2JE	
		MAG9-22	FRN11G11S-4JE to FRN22G11S-4JE FRN11G11S-2JE to FRN22G11S-2JE	
Keypad panel for Chinese language	Used to display the LCD screen in Chinese language	Display language: Chinese, English, Japanese		

# Wiring equipment

Power supply voltage	Nominal applied motor (kW)	Inverter type		MCCB or ELCB Rated current (A)		Magnetic contactor (MC)			Recommended wire size (mm <sup>2</sup> )					
		G11S series	P11S series	With DCR	Without reactor	MC1 for input circuit		MC2 for output circuit	Input circuit [L1/R, L2/S, L3/T]		Output circuit [U.V.W]		DCR circuit [P1,P(+)]	DB circuit [P(+),DB,N(-)]
						With DCR	Without reactor		With DCR	Without reactor	G11S	P11S		
Three-phase 400V	0.4	FRN0.4G11S-4JE	—	5	5	SC-05	SC-05	SC-05	2.0	2.0	2.0	—	2.0	2.0
	0.75	FRN0.75G11S-4JE												
	1.5	FRN1.5G11S-4JE												
	2.2	FRN2.2G11S-4JE												
	3.7	FRN3.7G11S-4JE												
	5.5	FRN5.5G11S-4JE	FRN5.5P11S-4JE	15	30	SC-5-1	SC-N1	SC-4-0	3.5	5.5	3.5	3.5		
	7.5	FRN7.5G11S-4JE	FRN7.5P11S-4JE	20	40									
	11	FRN11G11S-4JE	FRN11P11S-4JE	30	50									
	15	FRN15G11S-4JE	FRN15P11S-4JE	40	60									
	18.5	FRN18.5G11S-4JE	FRN18.5P11S-4JE	75	100									
	22	FRN22G11S-4JE	FRN22P11S-4JE	50	100	SC-N1	SC-N2S	SC-N1	5.5	14	5.5	8.0	5.5	
	30	FRN30G11S-4JE	FRN30P11S-4JE	75	125									
	37	FRN37G11S-4JE	FRN37P11S-4JE	100	150									
	45	FRN45G11S-4JE	FRN45P11S-4JE	125	200									
	55	FRN55G11S-4JE	FRN55P11S-4JE	175	250									
	75	FRN75G11S-4JE	FRN75P11S-4JE	200	300	SC-N7	SC-N8	SC-N5	38	60	100	100	100	
	90	FRN90G11S-4JE	FRN90P11S-4JE	250	350									
	110	FRN110G11S-4JE	FRN110P11S-4JE	300	400									
	132	FRN132G11S-4JE	FRN132P11S-4JE	350	500									
	160	FRN160G11S-4JE	FRN160P11S-4JE	500	600									
	200	FRN200G11S-4JE	FRN200P11S-4JE	600	700	SC-N14	SC-N14	SC-N14	250	150×2	325	150×2	400	
	220	FRN220G11S-4JE	FRN220P11S-4JE	700	800									
	280	FRN280G11S-4JE	FRN280P11S-4JE	800	1000									
	315	FRN315G11S-4JE	FRN315P11S-4JE	1000	1200									
	355	FRN355G11S-4JE	FRN355P11S-4JE	1200	1500									
	400	FRN400G11S-4JE	FRN400P11S-4JE	1500	2000	SC-N16	SC-N16	SC-N16	200×2	250×2	250×2	250×2	250×2	
	450	—	FRN450P11S-4JE	2000	2500									
	500	FRN500G11S-4JE	FRN500P11S-4JE	2500	3000									
	630	FRN630G11S-4JE	FRN630P11S-4JE	3000	3500									
	710	—	FRN710P11S-4JE	3500	4000									
	Contact Fuji.													
Three-phase 200V	0.2	FRN0.2G11S-2JE	—	5	5	SC-05	SC-05	SC-05	2.0	2.0	2.0	—	2.0	2.0
	0.4	FRN0.4G11S-2JE												
	0.75	FRN0.75G11S-2JE												
	1.5	FRN1.5G11S-2JE												
	2.2	FRN2.2G11S-2JE												
	3.7	FRN3.7G11S-2JE												
	5.5	FRN5.5G11S-2JE	FRN5.5P11S-2JE	30	50	SC-5-1	SC-N1	SC-4-0	3.5	5.5	3.5	2.0		
	7.5	FRN7.5G11S-2JE	FRN7.5P11S-2JE	40	75									
	11	FRN11G11S-2JE	FRN11P11S-2JE	50	100									
	15	FRN15G11S-2JE	FRN15P11S-2JE	75	125									
	18.5	FRN18.5G11S-2JE	FRN18.5P11S-2JE	100	150									
	22	FRN22G11S-2JE	FRN22P11S-2JE	150	200	SC-N2S	SC-N5	SC-N2	14	38	14	14	22	
	30	FRN30G11S-2JE	FRN30P11S-2JE	200	250									
	37	FRN37G11S-2JE	FRN37P11S-2JE	250	300									
	45	FRN45G11S-2JE	FRN45P11S-2JE	300	350									
	55	FRN55G11S-2JE	FRN55P11S-2JE	350	400									
	75	FRN75G11S-2JE	FRN75P11S-2JE	400	500	SC-N11	SC-N12	SC-N3	22	60	38	38	38	
	90	FRN90G11S-2JE	FRN90P11S-2JE	500	600									
	110	FRN110G11S-2JE	FRN110P11S-2JE	600	700									
	132	FRN132G11S-2JE	FRN132P11S-2JE	700	800									
	160	FRN160G11S-2JE	FRN160P11S-2JE	800	1000									
	200	FRN200G11S-2JE	FRN200P11S-2JE	1000	1200	SC-N16	SC-N17	SC-N4	14	38	22	22	22	
	220	FRN220G11S-2JE	FRN220P11S-2JE	1200	1500									
	280	FRN280G11S-2JE	FRN280P11S-2JE	1500	2000									
	315	FRN315G11S-2JE	FRN315P11S-2JE	2000	2500									
	355	FRN355G11S-2JE	FRN355P11S-2JE	2500	3000									
	400	FRN400G11S-2JE	FRN400P11S-2JE	3000	3500	SC-N18	SC-N19	SC-N5	22	60	38	38	38	
	450	—	FRN450P11S-2JE	3500	4000									
	500	FRN500G11S-2JE	FRN500P11S-2JE	4000	5000									
	630	FRN630G11S-2JE	FRN630P11S-2JE	5000	6000									
	710	—	FRN710P11S-2JE	6000	7000									

## NOTES :

- For molded-case circuit breakers (MCCB) and earth-leakage circuit breakers (ELCB), the required frame type and series depend on the facility transformer capacity and other factors. When selecting optimal breakers, refer to the relevant technical data.
- Also select the rated sensitive current of ELCB utilizing the technical data.
- The recommended wire sizes are based on the condition that the temperature inside the panel does not exceeds 50°C.
- The above wires are 600V HIV insulated cables (75°C).
- Data in the above table may differ for different conditions (ambient temperature, power supply voltage, and other factors).

\*Contact Fuji Electric FA.



# An Extensive Lineup Keeps The Fuji Inverter Family Actively Ahead

Application	Series (Cat. No.)	Features
For general industrial machines	<b>Compact inverter</b> <b>FRENIC-Mini</b> (MEH441)	<ul style="list-style-type: none"> <li>● Easy to operate as frequency setting POT is provided as standard.</li> <li>● Equipped with supreme automatic torque boost, current limiting function and slip compensation function for traverse carriers.</li> <li>● Equipped with supreme automatic energy-saving operation function and PID control function for fans &amp; pumps.</li> </ul>
	<b>Inverter for fans &amp; pumps</b> <b>FRENIC-Eco</b> (MEH442)	<ul style="list-style-type: none"> <li>● Specially developed for variable torque loads such as fans &amp; pumps.</li> <li>● Equipped with a newly systemized automatic energy-saving, PID control, lifetime alarm and line/inverter operation changeover sequence functions, etc.</li> <li>● Perfect for air conditioners, fans &amp; pumps that were previously difficult to consider for use with an general-purpose inverter because of costs and functions.</li> </ul>
	<b>High-performance, compact inverter</b> <b>NEW</b> <b>FRENIC-Multi</b> (MEH652 for JE) (MEH653 for EN)	<ul style="list-style-type: none"> <li>● Designed for prolonged use (10 years) and complied with RoHS Directive to enhance its friendliness toward the environment. (Production lot of autumn 2005 or later)</li> <li>● Handles all applications due to an extended capacity range, ample variations in product types and excellent maintainability.</li> <li>● Provided with the functions of contact-stoppage operation, brake signal, torque limiting, and current limiting that are essential for traverse and transfer carriers.</li> </ul>
	<b>High-performance, multi-function inverter</b> <b>FRENIC 5000G11S</b> (MEH403 for JE) (MEH413 for EN)	<ul style="list-style-type: none"> <li>● Achieved starting torque of 200% at 0.5Hz, with our unique dynamic torque vector control system.</li> <li>● Fully replete with useful functions like auto tuning.</li> <li>● A wide variation from 0.2 to 630kW (compact and enclosed type for 22kW or smaller).</li> </ul>
	<b>Inverter for fans &amp; pumps</b> <b>FRENIC 5000P11S</b> (MEH403)	<ul style="list-style-type: none"> <li>● Appropriate for equipment such as fans &amp; pumps.</li> <li>● Provides effortless energy-saving operation because of its automatic energy-saving function.</li> <li>● Easy operation as interactive keypad is provided as standard.</li> </ul>
	<b>High-performance, vector control inverter</b> <b>FRENIC 5000VG7S</b> (MEH405)	<ul style="list-style-type: none"> <li>● A highly accurate inverter that quickly provides control responses and has stable torque characteristics.</li> <li>● Can be used in a wide range of general industry systems as its extensive functions and a variety of options.</li> <li>● Vector control operation of general-purpose motors thanks to the auto tuning function.</li> </ul>
For machine tools	<b>Spindle drive system for machine tools</b> <b>FRENIC 5000MS5</b> (MEH391)	<ul style="list-style-type: none"> <li>● The converter separation structure enabling the configuration of multiaxial systems.</li> <li>● Free combinations such as torque vector/high-performance vector control or dynamic braking/power regeneration.</li> <li>● Supports multiple processing of machine tools due to extensive option functions.</li> </ul>

Standard product    Made-to-order

	Input voltage class	Capacity range (applicable motor capacity [kW])																																	
		0.1	0.2	0.4	0.75	1.5	2.2	3.7	5.5	7.5	11	15	18.5	22	30	37	45	55	75	90	110	132	160	200	220	280	315	355	400	450	500	560	630	710	
	Three-phase 200V	0.1						3.7																											
	Three-phase 400V		0.4					3.7																											
	Single-phase 200V	0.1						2.2																											
	Single-phase 100V	0.1		0.75																															
	Three-phase 200V			0.75														55	75	110															
	Three-phase 400V			0.75														55	75														560		
	Single-phase 200V																																		
	Single-phase 100V																																		
	Three-phase 200V	0.1																		15															
	Three-phase 400V		0.4																	15															
	Single-phase 200V	0.1																		2.2															
	Single-phase 100V																																		
	Three-phase 200V		0.2															55	75	90															
	Three-phase 400V		0.4															55	75													500		630	
	Single-phase 200V																																		
	Single-phase 100V																																		
	Three-phase 200V								5.5									55	75	110															
	Three-phase 400V								5.5									55	75													500		710	
	Single-phase 200V																																		
	Single-phase 100V																																		
	Three-phase 200V			0.75														45	55	90															
	Three-phase 400V				3.7													45	55													500		630	
	Single-phase 200V																																		
	Single-phase 100V																																		
	Three-phase 200V				0.75													45																	

## To all our customers who purchase Fuji Electric FA Components & Systems' products:

Please take the following items into consideration when placing your order.

When requesting an estimate and placing your orders for the products included in these materials, please be aware that any items such as specifications which are not specifically mentioned in the contract, catalog, specifications or other materials will be as mentioned below.

In addition, the products included in these materials are limited in the use they are put to and the place where they can be used, etc., and may require periodic inspection. Please confirm these points with your sales representative or directly with this company.

Furthermore, regarding purchased products and delivered products, we request that you take adequate consideration of the necessity of rapid receiving inspections and of product management and maintenance even before receiving your products.

### 1. Free of Charge Warranty Period and Warranty Range

#### 1-1 Free of charge warranty period

- (1) The product warranty period is "1 year from the date of purchase" or 18 months from the manufacturing date imprinted on the name plate, whichever date is earlier.
- (2) However, in cases where the use environment, conditions of use, use frequency and times used, etc., have an effect on product life, this warranty period may not apply.
- (3) Furthermore, the warranty period for parts restored by Fuji Electric's Service Department is "6 months from the date that repairs are completed."

#### 1-2 Warranty range

- (1) In the event that breakdown occurs during the product's warranty period which is the responsibility of Fuji Electric, Fuji Electric will replace or repair the part of the product that has broken down free of charge at the place where the product was purchased or where it was delivered. However, if the following cases are applicable, the terms of this warranty may not apply.
  - 1) The breakdown was caused by inappropriate conditions, environment, handling or use methods, etc. which are not specified in the catalog, operation manual, specifications or other relevant documents.
  - 2) The breakdown was caused by the product other than the purchased or delivered Fuji's product.
  - 3) The breakdown was caused by the product other than Fuji's product, such as the customer's equipment or software design, etc.
  - 4) Concerning the Fuji's programmable products, the breakdown was caused by a program other than a program supplied by this company, or the results from using such a program.
  - 5) The breakdown was caused by modifications or repairs affected by a party other than Fuji Electric.
  - 6) The breakdown was caused by improper maintenance or replacement using consumables, etc. specified in the operation manual or catalog, etc.
  - 7) The breakdown was caused by a chemical or technical problem that was not foreseen when making practical application of the product at the time it was purchased or delivered.
  - 8) The product was not used in the manner the product was originally intended to be used.
  - 9) The breakdown was caused by a reason which is not this company's responsibility, such as lightning or other disaster.
- (2) Furthermore, the warranty specified herein shall be limited to the purchased or delivered product alone.
- (3) The upper limit for the warranty range shall be as specified in item (1) above and any damages (damage to or loss of machinery or equipment, or lost profits from the same, etc.) consequent to or resulting from breakdown of the purchased or delivered product shall be excluded from coverage by this warranty.

#### 1-3. Trouble diagnosis

As a rule, the customer is requested to carry out a preliminary trouble diagnosis. However, at the customer's request, this company or its service network can perform the trouble diagnosis on a chargeable basis. In this case, the customer is asked to assume the burden for charges levied in accordance with this company's fee schedule.

### 2. Exclusion of Liability for Loss of Opportunity, etc.

Regardless of whether a breakdown occurs during or after the free of charge warranty period, this company shall not be liable for any loss of opportunity, loss of profits, or damages arising from special circumstances, secondary damages, accident compensation to another company, or damages to products other than this company's products, whether foreseen or not by this company, which this company is not be responsible for causing.

### 3. Repair Period after Production Stop, Spare Parts Supply Period (Holding Period)

Concerning models (products) which have gone out of production, this company will perform repairs for a period of 7 years after production stop, counting from the month and year when the production stop occurs. In addition, we will continue to supply the spare parts required for repairs for a period of 7 years, counting from the month and year when the production stop occurs. However, if it is estimated that the life cycle of certain electronic and other parts is short and it will be difficult to procure or produce those parts, there may be cases where it is difficult to provide repairs or supply spare parts even within this 7-year period. For details, please confirm at our company's business office or our service office.

### 4. Transfer Rights

In the case of standard products which do not include settings or adjustments in an application program, the products shall be transported to and transferred to the customer and this company shall not be responsible for local adjustments or trial operation.

### 5. Service Contents

The cost of purchased and delivered products does not include the cost of dispatching engineers or service costs. Depending on the request, these can be discussed separately.

### 6. Applicable Scope of Service

The above contents shall be assumed to apply to transactions and use of this company's products within the nation of Japan. Please discuss transactions and use outside Japan separately with the local supplier where you purchased the products, or with this company.

**M**emo





## NOTES

### In running general-purpose motors

- **Driving a 400V general-purpose motor**

When driving a 400V general-purpose motor with an inverter, damage to the insulation of the motor may occur. Use an output circuit filter (OFL) if necessary after checking with the motor manufacturer. Fuji's motors do not require the use of output circuit filters because of their reinforced insulation.

- **Torque characteristics and temperature rise**

When the inverter is used to run a general-purpose motor, the temperature of the motor becomes higher than when it is operated using a commercial power supply. In the low-speed range, the cooling effect will be weakened, so decrease the output torque of the motor. If constant torque is required in the low-speed range, use a Fuji inverter motor or a motor equipped with an externally powered ventilating fan.

- **Vibration**

Use of an inverter does not increase vibration of a general-purpose motor, but when the motor is mounted to a machine, resonance may be caused by the natural frequencies, including that of the machine system.

\* The use of a rubber coupling or vibration dampening rubber is recommended.

\* It is also recommended to use the inverter jump frequency control to avoid resonance points.

Note that operation of a 2-pole motor at 60Hz or more may cause abnormal vibration.

- **Noise**

When an inverter is used with a general-purpose motor, the motor noise level is higher than that with a commercial power supply. To reduce noise, raise carrier frequency of the inverter. High-speed operation at 60Hz or more can also result in more noise.

### In running special motors

- **Explosion-proof motors**

When driving an explosion-proof motor with an inverter, use a combination of a motor and an inverter that has been approved in advance. Such approved products are available in our special product series. Contact Fuji Electric FA for details.

- **Submersible motors and pumps**

These motors have a larger rated current than general-purpose motors. Select an inverter whose rated output current is greater than that of the motor. These motors differ from general-purpose motors in thermal characteristics. Set a low value in the thermal time constant of the motor when setting the electronic thermal facility.

- **Brake motors**

For motors equipped with parallel-connected brakes, their braking power must be supplied from the inverter input side (the primary circuit). If the brake power is connected to the inverter power output side (the secondary circuit) by mistake, problems may occur. Do not use inverters for driving motors equipped with series-connected brakes.

- **Geared motors**

If the power transmission mechanism uses an oil-lubricated gearbox or speed changer/reducer, then continuous motor operation at low speed may cause poor lubrication. Avoid such operation.

- **Synchronous motors**

It is necessary to use software suitable for this motor type. Contact Fuji Electric FA for details.

- **Single-phase motors**

Single-phase motors are not suitable for inverter-driven variable speed operation. Use three-phase motors.

\* Even if a single-phase power supply is available, use a three-phase motor as the inverter provides three-phase output.

### Environmental conditions

- **Installation location**

Use the inverter in a location with an ambient temperature range of -10 to 50°C.

The inverter heat sinks and braking resistor surfaces become hot under certain operating conditions. Install the inverter on nonflammable material such as metal. Ensure that the installation location meets the environmental conditions specified in "Environment" in Common specifications on page 11. For inverters of 22kW or smaller, remove the ventilation covers when operating it at a temperature of 40°C or higher.

### Combination with peripheral devices

- **Installing a molded case circuit breaker (MCCB) or earth leakage circuit breaker (ELCB)**

Install a recommended molded case circuit breaker (MCCB) or an earth leakage circuit breaker (ELCB) (with the exception of those exclusively designed for protection from ground faults) in the primary circuit of the inverter to protect the wiring. Ensure that the circuit breaker capacity is equivalent to or lower than the recommended capacity.

- **Installing a magnetic contactor (MC) on the inverter power output side (the secondary circuit)**

If a magnetic contactor (MC) is mounted on the inverter power output side (the secondary circuit) for switching the motor to commercial power or for any other purpose, turn the MC on or off while both the inverter and the motor are fully stopped.

Remove the surge suppressor integrated with the MC. For switching operation from/to commercial power supply, use of newly developed "Line/inverter changeover operation" function using terminals such as SW88, SW52-2, SW52-1, SW50, is recommended.

- **Installing a magnetic contactor (MC) on the inverter input side (the primary circuit)**

Do not turn the magnetic contactor (MC) on the inverter input side (the primary circuit) on or off more than once an hour as an inverter fault may result. If frequent starts or stops are required during motor operation, use FWD/REV signals.

- **Protecting the motor**

When driving a motor with an inverter, the electronic thermal facility of the inverter can protect the motor. The operation level and the motor type (general-purpose motor, inverter motor) should be set. For high-speed motors or water-cooled motors, set a small value for the thermal time constant to protect the motor, in combination with the "cooling system OFF" signal.

When driving several motors with an inverter, connect a thermal relay to each motor and turn on the inverter's electronic thermal relay facility.

If you connect the motor thermal relay to the motor with a long cable, a high-frequency current may flow into the wiring stray capacitance. This may cause the relay to trip at a current lower than the set value for the thermal relay. If this happens, lower the carrier frequency or use the output circuit filter (OFL).

- **Discontinuance of power-factor correcting capacitor**

Do not mount power-factor correcting capacitors in the inverter primary circuit. (Use the DC REACTOR

to improve the inverter power-factor.) Do not use power-factor correcting capacitors in the inverter output circuit. An overcurrent trip will occur, disabling motor operation.

- **Discontinuance of surge killer**

Do not mount surge killers in the inverter secondary circuit.

- **Reducing noise**

Use of a filter and shielded wires are typical measures against noise to ensure that EMC Directives are met. Refer to Appendices, App. A "Advantageous Use of Inverters (Notes on electrical noise)" for details.

- **Measures against surge currents**

If an overvoltage trip occurs while the inverter is stopped or operated under a light load, it is assumed that the surge current is generated by open/close of the phase-advancing capacitor in the power system.

\* Connect a DC REACTOR to the inverter.

- **Megger test**

When checking the insulation resistance of the inverter, use a 500V megger and follow the instructions contained in the FRN-G11S/P11S Instruction Manual.

### Wiring

- **Control circuit wiring length**

When using remote control, limit the wiring length between the inverter and operator box to 20m or less and use twisted shielded cable.

- **Wiring length between inverter and motor**

If long wiring is used between the inverter and the motor, the inverter will overheat or trip as a result of overcurrent (high-frequency current flowing into the stray capacitance) in the wires connected to the phases. Ensure that the wiring is shorter than 50m for 3.7kW or less, and shorter than 100m for 5.5kW or more. If this length must be exceeded, lower the carrier frequency or mount an output circuit filter (OFL).

When wiring is longer than 50m, and Dynamic torque-vector control or vector with PG is selected, execute off-line auto-tuning.

- **Wiring size**

Select cables with a sufficient capacity by referring to the current value or recommended wire size.

- **Wiring type**

Do not use multicore cables.

- **Grounding**

Securely ground the inverter using the grounding terminal.

### Selecting inverter capacity

- **Driving general-purpose motor**

Select an inverter according to the applicable motor ratings listed in the standard specifications table for the inverter. When high starting torque is required or quick acceleration or deceleration is required, select an inverter with a capacity one size greater than the standard.

- **Driving special motors**

Select an inverter that meets the following condition:  
Inverter rated current > Motor rated current

### Transportation and storage

When transporting or storing inverters or inverters while mounted on machines, follow the procedures and select locations that meet the environmental conditions listed in the FRN-G11S/P11S Instruction Manual.

# Fuji Electric FA Components & Systems Co., Ltd.

Mitsui Sumitomo Bank Ningyo-cho Bldg.,  
5-7, Nihonbashi Odemma-cho, Chuo-ku, Tokyo 103-0011, Japan  
Phone: +81-3-5847-8011 Fax: +81-3-5847-8172



Printed on 100% recycled paper