



LP-Gas & Anhydrous Ammonia Equipment

A

Regulators and Accessories

B

Cylinder and Service Valves

C

Multivalve® Assemblies

D

Pressure Relief Valves and Relief Valve Manifolds

E

Globe and Angle Valves

F

Excess Flow, Check, Filler and Vapor Equalizing Valves

G

Internal Valves and Accessories

H

Adapters, Connectors and Fittings

J

Miscellaneous Equipment (Including Rotogages and ESVs)

Foreword

This catalog describes a complete line of equipment available from REGO® for use with LP-Gas and anhydrous ammonia (NH₃). The following points are important to know for proper use of the catalog:

1. Illustrations and drawings of individual products are representative of "product groups" and all products within a product group are similar in construction.
2. Materials used for construction of products in this catalog are suitable for rated service pressure at temperatures of -40° F. to +165° F., unless otherwise specified.
3. Products in this catalog are only intended for use in LP-Gas and/or anhydrous ammonia service as follows.
 - a. "A" or "AA" prefix — Products with this prefix are suitable for NH₃ service (i.e., contain no brass parts).
 - b. "AA" prefix on relief valves — These valves are NOT suitable for use with LP-Gas service. These are of partial aluminum materials and are listed by Underwriters Laboratories (UL) for NH₃ service only.
 - c. All other products are suitable for use with LP-Gas service.
 - d. "SS" prefix—Hydrostatic relief valve with this prefix are suitable for NH₃ service (i.e., they have stainless steel materials).
4. We manufacture valves and adapters designed to be used on LP-Gas and Anhydrous Ammonia systems, we do not design systems or consult in system design. For this type of information consult a professional system designer.

Caution

Do not use any product contained in this catalog with any service commodity other than LP-Gas or NH₃. If you have a need for use of another application, contact REGO®, 100 RegO Drive, Elon, NC 27244, (336) 449-7707 before proceeding.

Proper application, installation and maintenance of products in this catalog are essential. Users of these products should obtain further information if there are any doubts or questions.

Notice

Installation, usage, and maintenance of all REGO® products must be in compliance with all REGO® instructions as well as requirements and provisions of NFPA #54, NFPA#58, DOT, ANSI, and all applicable federal, state, provincial and local standards, codes, regulations, and laws.

Inspection and maintenance on a periodic basis is essential. Installation and maintenance should be performed only by qualified personnel.

Be sure all instructions are read and understood before installation, operation and service.

Warning

All REGO® products are mechanical devices that will eventually become inoperative due to wear, corrosion and aging of components made of materials such as rubber. The environment and conditions of use will determine the safe service life of these products. Periodic inspection and maintenance are essential to avoid serious injury and property damage.

Many REGO® products are manufactured for storage, transport, transfer and use of toxic flammable and dangerous liquids and gases. Such substances should be handled by experienced and trained personnel only, using accepted governmental and industrial safety procedures. Never vent LP-Gas near any possible source of ignition.

Filters

REGO® LP-Gas equipment is designed to operate in a system free from contamination. A variety of in-line filters are commercially available to the LP-Gas industry for installation in domestic systems.

The use of an in-line filter should be considered when other system components may be unclean and the system contaminated by rust, scale, dirt, debris or other foreign material.

Determining the Age of Products

All REGO® products are mechanical devices that will eventually become inoperative due to wear, contaminants, corrosion and aging of components made of material such as metal and rubber.

The environment and conditions of use will determine the safe service life of these products. Periodic inspection and maintenance are essential.

Because REGO® products have a long and proven record of quality and service, LP-Gas dealers may forget the hazards that can occur because products are used beyond their safe service life.

The life of a product is determined by the environment in which it “lives.” The LP-Gas dealer knows better than anyone what this environment is.

Since 1960, most REGO® products are identified with an alphabetical code indicating the month and the year they were manufactured.

Check the product for this code to determine age. If valves or regulators are repainted, take care to keep the date code clear for later identification and inspection.

1960 to 1985 — Two-Letter Date Code

First letter in date code is the month

A — January	G — July
B — February	H — August
C — March	I — September
D — April	J — October
E — May	K — November
F — June	L — December

Relief valves used on ASME tanks carry a numerical code indicating month and year such as 1-75 means January, 1975.

Second letter in date code is the year

R — 1960	A — 1969	J — 1978
S — 1961	B — 1970	K — 1979
T — 1962	C — 1971	L — 1980
U — 1963	D — 1972	M — 1981
V — 1964	E — 1973	N — 1982
W — 1965	F — 1974	O — 1983
X — 1966	G — 1975	P — 1984
Y — 1967	H — 1976	Q — 1985
Z — 1968	I — 1977	

EXAMPLE: DL = April of 1980

From 1985 to 1990 — Digit Date Code

First digit in date code is the month

1 — January	7 — July
2 — February	8 — August
3 — March	9 — September
4 — April	10 — October
5 — May	11 — November
6 — June	12 — December

Second 2 digits in date code are the year

86 — 1986	89 — 1989
87 — 1987	90 — 1990
88 — 1988	

EXAMPLE: 5-87 = May of 1987

After 1990 — Digit-Letter-Digit Date Code

First digit in date code is the month

1 — January	7 — July
2 — February	8 — August
3 — March	9 — September
4 — April	10 — October
5 — May	11 — November
6 — June	12 — December

Letter in date code is the week

A — 1 st week
B — 2 nd week
C — 3 rd week
D — 4 th week
E — 5 th week

Second 2 digits in date code are the year

91 — 1991	97 — 1997
92 — 1992	98 — 1998
93 — 1993	99 — 1999
94 — 1994	00 — 2000
95 — 1995	01 — 2001
96 — 1996	02 — 2002
03 — 2003	etcetera . . .

EXAMPLE: 6A92 = First week of June, 1992

Regulator Color Coding

REGO® Domestic first stage, second stage, single stage, and integral

twin stage LP-Gas regulators are easy to identify. In addition to the standard part number marking which indicates the proper application,

each regulator is color coded to help minimize misapplication in the field that can lead to accidents and costly service callbacks. The color coding system is standard on all 404, LV404, 2302, LV2302, 2403, 2503, LV4403, and LV5503 series domestic LPGas regulators manufactured after May of 1986.

Classic Gold — Indicates a single stage regulator that is designed to be used alone in single stage systems.

Brilliant Red — Denotes a first stage high pressure regulator, normally used in two-stage applications in conjunction with a select brown second stage regulator.

Select Brown — Signifies second stage low pressure regulators, designed for use in two-stage systems in conjunction with a brilliant red high pressure regulator — also signifies integral twin stage regulators designed to provide benefits of two-stage regulation in one compact unit.

Select Blue — Indicates a second stage 2 PSIG delivery pressure regulator and a line pressure regulator downstream to reduce 2 PSIG to appliance pressure

Green — High pressure pounds to pounds anhydrous ammonia regulator.

Section	Description
----------------	--------------------

A	Regulators and Accessories
----------	-----------------------------------

B	Cylinder and Service Valves
----------	------------------------------------

C	Multivalve® Assemblies
----------	-------------------------------

D	Pressure Relief Valves and Relief Valve Manifolds
----------	--

E	Globe and Angle Valves
----------	-------------------------------

F	Excess Flow, Check, Filler and Vapor Equalizing Valves
----------	---

G	Internal Valves and Accessories
----------	--

H	Adapters, Connectors and Fittings
----------	--

J	Miscellaneous Equipment (Including Rotogages and ESVs)
----------	---

Cross Reference by Part Number

100-HGD.....J20	1494-1.....H12	3127P.....D16	3200C.....G14	LV4403SR96.....A15
302.....A26	1519A2.....F10	3127U.....D16	3200L.....G14	LV4403TR96.....A15
302S.....A26	1519C2.....F9	3129G.....D15	A3209D050.....G8	LV4403-400.....A34
302V.....A26	A1519A2.....F10	3129G.....D16	A3209DT050.....G8	AA500Y8.....F14
302V9.....A26	1519A3.....F10	3129H.....D16	A3209D080.....G8	LV5503B4.....A18
302V9LS.....A26	1519A4.....F10	3129J.....D16	A3209DT080.....G8	LV5503G4.....A20
LV404B4.....A21	1519B4.....F10	3129K.....D15	A3211D110.....G9	LV5503B6.....A18
LV404B9.....A21	1519C4.....F9	3129K.....D16	A3211D080.....G9	LV5503Y6.....A19
LV404Y9.....A24	A1519A4.....F10	3129L.....D16	A3212R105.....G16	LV5503B8.....A18
LV404B34.....A22	A1519B4.....F10	3129P.....D16	A3212RT105.....G16	LV5503Y8.....A19
LV404B39.....A22	A1519A6.....F10	3129U.....D16	A3212R175.....G16	5547.....J19
LV404B46.....A21	AA1582MH.....A28	AA3130UA250.....D14	A3212RT175.....G16	5575.....J19
LV404B4V9.....A21	AA1582MK.....A28	AA3130UA265.....D14	A3212R250.....G16	5576.....J19
LV404B96.....A21	AA1582ML.....A28	3131G.....D14	A3212RT250.....G16	5726B23.....A23
LV404B9V9.....A21	AA1582MW.....A28	3132G.....D14	A3213R150.....G15	5726B23.....A25
LV404B34V9.....A22	1584VH.....A28	MV3132G.....D14	A3213RT150.....G15	5727B23.....A23
LV404B39V9.....A22	1584VL.....A28	T3132G.....D14	A3213R200.....G15	5727B23.....A25
LV404B46V9.....A21	1584VN.....A28	W3132G.....D14	A3213RT200.....G15	5754B4.....A23
LV404B96V9.....A21	AA1584VH.....A28	3133G.....D14	A3213R300.....G15	5754B4.....A25
597FA.....A27	AA1584VL.....A28	3135G.....D14	A3213RT300.....G15	5755B4.....A23
597FB.....A27	AA1584VW.....A28	AA3135UA250.....D14	A3213R400.....G15	5755B4.....A25
597FC.....A27	X1584VL.....A29	AA3135UA265.....D14	A3213RT400.....G15	5760A.....H12
597FD.....A27	X1584VN.....A29	3139-18.....A30	A3217AL160.....G10	5760B.....H12
612.....J19	1586VH.....A28	3139-26.....A30	A3217AR160.....G10	5760C.....H12
612JS12.....A31	1586VL.....A28	3139-38.....A30	A3217DAL160.....G10	5760D.....H12
612PS12.....A31	1586VN.....A28	3144-9P.....H8	A3217DAR160.....G10	5760S.....H12
612JS20.....A31	AA1586VH.....A28	3144-91.....H8	A3217AL210.....G10	5760Z.....H12
612PS20.....A31	AA1586VL.....A28	3146.....F26	A3217AR210.....G10	5761A.....H12
901C1.....B14	AA1586MW.....A28	3146S.....F26	A3217DAL210.....G10	5761B.....H12
901C3.....B15	X1586VL.....A29	A3146.....F26	A3217DAR210.....G10	5761C.....H12
901C5.....B15	X1586VN.....A29	A3149G.....D14	A3217AL260.....G10	5761D.....H12
901-400.....B18	1588VH.....A28	A3149L55.....D14	A3217AR260.....G10	5763D.....H9
903-400.....B18	1588VL.....A28	A3149L200.....D14	A3217DAL260.....G10	C5763N.....H7
907FP.....H8	1588VN.....A28	3165C.....J18	A3217DAR260.....G10	5764A.....H9
912FS12.....H8	X1588VL.....A29	3165CF.....J18	A3217AL410.....G10	5764B.....H9
912JS12.....H8	X1588VN.....A29	3165S.....J18	A3217AR410.....G10	5764C.....H9
912PS12.....H8	1708.....H8	3165CF12.0.....J18	A3217DAL410.....G10	5764D.....H9
912FA20.....H8	2070CO.....J6	3165SF12.0.....J18	A3217DAR410.....G10	5764E.....H9
912FS20.....H8	2071-L25.7.....J6	TSS3169.....J18	A3217AL510.....G10	A5764D.....H9
912JS20.....H8	2071-L39.7.....J6	TA3169F12.0.....J18	A3217AR510.....G10	A5764E.....H9
912PA20.....H8	A2137.....F13	3170.....F24	A3217DAL510.....G10	A5764W.....H9
912PS20.....H8	A2137A.....F13	3171.....H5	A3217DAR510.....G10	5765D.....H9
912FS30.....H8	2139.....F13	3171A.....H5	A3219RT.....G14	5765E.....H9
912PS30.....H8	2139A.....F13	3174C.....F23	A3219FA400L.....G12	5765F.....H9
912FS36.....H8	A2141A6.....J7	3174-9P.....H8	A3219FA600L.....G12	5765M.....H9
912JS36.....H8	A2141A6L.....J7	3174-91.....H8	3226A-3.....J19	5765PR.....H7
912PA36.....H8	A2141A8.....J7	3174-93.....H8	3272E.....F11	A5765C.....H9
912PS36.....H8	A2141A8L.....J7	3175.....H5	3272F.....F11	A5765D.....H9
912PA48.....H8	A2141A10.....J7	3175A.....H5	3272G.....F11	A5765E.....H9
912PS48.....H8	A2141A16.....J7	3175B.....H5	A3272G.....F11	A5765F.....H9
913JS05A.....H8	2302-31.....A32	3175P.....H8	A3276BC*.....F26	C5765N.....H7
913PS05A.....H8	2411.....J19	A3175.....H5	3282A.....F11	5766E.....H9
913PS12G.....H8	2434A.....A33	A3175A.....H5	3282B.....F11	5766F.....H9
913PS12H.....H8	2434-2.....J19	3176.....F26	3282C.....F11	5767F.....H9
913PS12S.....H8	2434A-2.....J19	A3176.....F26	A3282C.....F11	5767G.....H9
948.....J19	2503-19.....A32	3179B.....H7	3292A.....F11	5767H.....H9
948B.....J19	2503-22.....A32	3180C.....F24	3292B.....F11	5767M.....H9
970.....A31	A2697-20R.....F20	3181.....H5	A3292A.....F11	A5767F.....H9
970.....H11	A2697-20R.....F23	3181A.....H5	A3292B.....F11	C5767N.....H7
970AW.....A31	2723C.....F15	3183AC.....F24	A3292C.....F11	5768G.....H9
970AW.....H11	A2797-20R.....F20	A3184-8R.....F20	A3400L4.....F27	5768H.....H9
970AX.....A31	A2797-20R.....F23	3184-90.....H8	A3400L6.....F27	5768J.....H9
970AX.....H11	A2805C.....J17	A3184-90.....H8	LV3403TR.....A14	A5768H.....H9
970AXS.....A31	2884D.....F16	3185.....H5	LV3403TRV9.....A14	5769H.....H9
970AXS.....H11	2906A.....H12	A3185.....H5	A3500L4.....F14	5769H.....H10
970HT.....A31	2906D.....H12	A3186.....F26	A3500N4.....F14	5769HVB.....H10
970HT.....H11	2906E.....H12	3188A.....H11	A3500P4.....F14	5769J.....H9
970JR.....H11	2906F.....H12	3188B.....H11	A3500R6.....F14	5769K.....H9
970S.....A31	2906G.....H12	3188C.....H11	A3500T6.....F14	5769K.....H10
970S.....H11	2962.....A34	3191.....H5	A3500V6.....F14	5769M.....H9
N970P.....H7	3119A.....H6	3194C.....F23	3705RC.....H7	5769M.....H10
1212 KIT.....A33	3120.....H6	A3194-8R.....F20	LV4403B4.....A16	5769VSS.....H10
1224WA.....J20	3121.....H6	3194-9.....H8	LV4403SR4.....A15	A5769H.....H9
1286.....J19	3125L.....D16	3194-90.....H8	LV4403TR4.....A15	A5769K.....H9
1300.....H12	AA3126L030.....D14	A3194-90.....H8	LV4403Y4.....A19	C5769N.....H7
1314WA.....J20	AA3126L250.....D14	3195.....H5	LV4403SR9.....A15	5776.....H8
1316WA.....J20	AA3126L312.....D14	A3195.....H5	LV4403TR9.....A15	A5776.....H8
1328.....H12	3127G.....D15	3195-50.....J19	LV4403B46.....A16	5807.....A25
1331.....H12	3127G.....D16	A3196.....F26	LV4403B46R.....A16	5808.....A25
1332.....H12	3127H.....D16	3197C.....F22	LV4403Y46R.....A19	5820.....A25
1350E.....A32	3127J.....D16	A3198S.....F25	LV4403B66.....A16	5828.....A25
1350R.....A32	3127K.....D15	3199W.....A31	LV4403B66R.....A16	5832.....A25
1450E.....A32	3127K.....D16	3199W.....F16	LV4403B66RA.....A17	6010.....J11
1450R.....A32	3127L.....D16	3199W.....H11	LV4403B66RAB.....A17	AA6010.....J11

Cross Reference by Part Number

6016.....J10	7514AP.....E11	A7704P.....E13	A8564G.....D19
AA6016.....J10	7514FP.....E11	7705P.....E13	A8573AG.....D19
6016-60D.....J12	7514FP.....E11	A7705P.....E13	A8573G.....D19
6024.....J10	A7514AP.....E10	7706P.....E13	A8574AG.....D19
AA6024.....J10	A7514FP.....E10	A7706P.....E13	A8574G.....D19
LV6503B14.....A20	7517AP.....E11	A7707L.....E6	8593AR16.0.....C7
LV6503B16.....A20	7517FP.....E11	A7708L.....E6	8684G.....D13
6532A12.0.....C10	7517FP.....E11	7781AFPN-1.....J12	8685G.....D13
6532R12.0.....C10	A7517AP.....E10	A7793A.....E5	A9091R.....J5
6533A10.5.....C10	A7517AP.....E10	A7794.....J14	A9091-18L.....J4
6533R10.5.....C10	TA7517AP.....E10	A7796.....J14	A9091-18LX.....J4
6533A11.7.....C10	TA7517FP.....E10	A7797A.....E5	A9091-18N.....J4
6533R11.7.....C10	7518AP.....E11	A7883FK.....G18	A9091-M24.0.....J4
6542A12.0.....C10	7518FP.....E11	A7883FK.....G19	A9091-M36.0.....J4
6542R12.0.....C10	7518FP.....E11	A7884FK.....G18	A9091-M48.0.....J4
6543A11.1.....C10	A7518AP.....E10	A7884FK.....G19	A9091-M60.0.....J4
6543R11.1.....C10	A7518FP.....E10	TA7894P.....E15	A9091-M72.0.....J4
6543A11.7.....C10	7534B.....D13	7901T.....E8	A9092R.....J5
6543R11.7.....C10	7534G.....D13	7901TA.....E8	A9093RS.....J5
6555R10.6.....C9	A7537L4.....F12	7901TB.....E8	A9093TS.....J5
6555R11.6.....C9	A7537L4F.....F12	7901TB.....J13	A9094RS.....J5
6555R12.0.....C9	A7537N4.....F12	7901TC.....E8	A9094TS.....J5
6579.....F20	A7537N4F.....F12	SS8001G.....D16	A9095RS.....J5
6584C.....F23	A7537P4.....F12	SS8001J.....D16	A9095TS.....J5
6586D.....F27	A7537P4F.....F12	SS8001L.....D16	9101C1.....B14
A6586D.....F27	A7539R6.....F12	SS8001U.....D16	9101R1.....B14
6587EC.....F22	A7539R6F.....F12	SS8002G.....D16	9101H5.....B15
7034LP.....E11	A7539T6.....F12	SS8002J.....D16	9101P5.....B16
7034P.....E11	A7539T6F.....F12	SS8002L.....D16	9101P5H.....B16
TA7034LP.....E10	A7539V6.....F12	SS8002U.....D16	9101Y5H.....B15
TA7034P.....E10	A7539V6F.....F12	A8013D.....F15	9101H6.....B15
7053T.....E8	7550P.....E14	A8013DA.....F15	9101P6.....B16
7141FP.....H8	7550PX.....E14	A8013DB.....F15	9101P6H.....B16
7177.....J13	A7550P.....E14	A8016DBC.....E16	9101D11.1.....B14
7188.....J13	A7550PX.....E14	A8016DP.....E17	9101R11.1.....B14
7188HS.....J13	7551P.....E14	A8016-9P.....H8	9101D11.7.....B14
7188MS.....J13	A7551P.....E14	A8016-93.....H8	9101R11.7.....B14
7188-21.....J13	A7553A.....E8	A8017DH.....E18	PT9102R1.....B14
7193D.....J13	7554LAV.....E7	A8017DLP.....E18	PT9102R11.1.....B14
7193D-10.....J13	7554LV.....E7	A8017DP.....E18	PT9102R11.7.....B14
7193D-10.....J15	7554SAV.....E7	A8018DP.....E19	9103T9F.....B10
7193K-10B.....J16	7554SV.....E7	A8020D.....E18	9103D10.6.....B9
7193L-10A.....J16	7556R12.0.....C11	SS8021G.....D16	9103D11.6.....B9
7193T-10.....J15	PT7556R12.0.....C12	SS8021J.....D16	9104PPA.....B17
7193U-10.....J15	7560-55.....D18	SS8021L.....D16	9104PT.....B17
7194HD.....J13	7560-56.....D18	SS8021U.....D16	9106CO.....B11
7194MD.....J13	A7571LA.....H4	SS8022G.....D16	9107K8A.....B12
7194-1.....J13	A7571LB.....H4	SS8022J.....D16	10538P.....H7
7194H-3.....J13	7572C-14A.....F19	SS8022L.....D16	12472.....F11
7194M-3A.....J13	7572C-15A.....F19	SS8022P.....D16	12802.....J17
7505AP.....E11	7572-400.....F28	SS8022U.....D16	12982.....H11
A7505AP.....E10	7573D.....F24	A8060.....J19	12982G.....H11
TA7505AP.....E10	7573DC.....F24	A8150.....J19	15774-1.....H12
7506AP.....E11	7574.....F11	A8400.....J19	
A7506AP.....E10	7574L.....F11	A8434G.....D10	
TA7506AP.....E10	A7575L2.....H4	A8434N.....D10	
7507AP.....E11	A7575L3.....H4	A8436G.....D10	
A7507AP.....E10	A7575L4.....H4	A8436N.....D10	
TA7507AP.....E10	A7575L5.....H4	G8475RV.....C6	
7508AP.....E11	7576.....H13	G8475RW.....C6	
A7508AP.....E10	7577V.....H7	PG8475RV.....C12	
7509BP.....E11	7579.....F20	PG8475RV.....C12	
A7509BP.....E10	7579P.....F20	PG8475RW.....C12	
TA7509BP.....E10	7579S.....F22	PG8475RW.....C12	
7510BP.....E11	7580F-20.....F19	A8523.....F12	
A7510BP.....E10	7583G.....D13	A8525.....F12	
TA7510BP.....E10	7590U.....F18	8542G.....D17	
7511AP.....E11	7590U-10.....F19	AA8542UA250.....D17	
7511FP.....E11	7590U-20.....F18	AA8542UA265.....D17	
7511FP.....E11	7591U.....F18	8543G.....D11	
A7511AP.....E10	7605A-BT.....J12	8543T.....D11	
A7511FP.....E10	7605APN-8A.....J12	8544G.....D11	
TA7511AP.....E10	7605AP-15.....J12	8544K.....D11	
TA7511FP.....E10	7605AP-16.....J12	8544T.....D11	
7512AP.....E11	7605PN-50.....J12	8545AK.....D12	
A7512AP.....E10	TA7614FP.....E10	8555D10.6.....C9	
TA7512AP.....E10	7647DC.....F21	8555R10.6.....C9	
7513AP.....E11	7647H.....F21	8555D11.6.....C9	
7513FP.....E11	7647HF.....F21	8555DL11.6.....C8	
7513FP.....E11	7647SA.....F21	8555R11.6.....C9	
A7513AP.....E10	7647SC.....F21	8556.....B13	
A7513FP.....E10	7704LP.....E13	A8563AG.....D19	
TA7513AP.....E10	7704P.....E13	A8563G.....D19	
TA7513FP.....E10	A7704LP.....E13	A8564AG.....D19	

Limited Warranty and Limitation Of Liability

LIMITED 10 YEAR WARRANTY AND LIMITATION OF LIABILITY

LIMITED 10 YEAR WARRANTY

REGO® warrants to the original purchasers the products and repair kits manufactured by it to be free from defects in materials and workmanship under normal use and service for a period of 10 years from the date of manufacture. If within thirty days after buyer's discovery of what buyer believes is a defect, buyer notifies in writing and ships the product to REGO® at 100 Rego Drive, Elon, NC 27244, REGO®, at its option, and within forty-five days of receipt, will repair, replace F.O.B. point of manufacture, or refund the purchase price of that part or product found by REGO® to be defective. Failure of buyer to give such written notice and ship the product within thirty days shall be deemed an absolute and unconditional waiver of any and all claims of buyer arising out of such defect.

This warranty does not extend to any product or part that is not installed and used continuously after installation in accordance with REGO®'s printed instructions, all applicable state and local regulations, and all applicable national standards, such as those promulgated by NFPA, DOT and ANSI. This warranty does not extend to any product or part that has been damaged by accident, misuse, abuse, failure to maintain, or neglect, nor does it extend to any product or part which has been modified, altered, disassembled, or repaired in the field. This warranty does not cover any cosmetic issues, such as scratches, dents, marring, fading of colors or discoloration.

Except as expressly set forth above, and subject to the limitation of liability below, REGO® MAKES NO OTHER WARRANTY, EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, with respect to its products and parts, whether used alone or in combination with others. REGO® disclaims all warranties not stated herein.

LIMITATION OF LIABILITY

REGO®'s total liability for any and all losses and damages arising out of any cause whatsoever shall in no event exceed the purchase price of the products or parts in respect of which such cause arises, whether such cause be based on theories of contract, negligence, strict liability, tort or otherwise.

REGO® shall not be liable for incidental, consequential or punitive damages or other losses. REGO® shall not be liable for, and buyer assumes any liability for, all personal injury and property damage connected with the handling, transportation, possession, further manufacture, other use or resale of products, whether used alone or in combination with any other products or materials.

From time to time buyers might call to ask REGO® for technical advice based upon limited facts disclosed to REGO®. If REGO® furnishes technical advice to buyer, whether or not at buyer's request, with respect to application, further manufacture or other use of the products and parts, REGO® shall not be liable for such technical advice or any such advice provided to buyer by any third party and buyer assumes all risks of such advice and the results thereof.

NOTE: Some states do not allow the exclusion or limitation of incidental, consequential or punitive damages, so the above limitation or exclusion may not apply to you. The warranty gives you specific legal rights, and you may have other rights that vary from State to State. The portions of this limited warranty and limitation of liability shall be considered severable and all portions which are not disallowed by applicable law shall remain in full force and effect.

NOTICE TO USERS OF PRODUCTS

The Limited Warranty stated above is a factory warranty to the first purchasers of REGO® products. Since most users have purchased these products from REGO® distributors, the user must within thirty (30) days after the user's discovery of what user believes is a defect, notify in writing and return the product to the distributor from whom he purchased the product/part. The distributor may or may not at the distributor's option choose to submit the product/parts to REGO®, pursuant to this Limited Warranty. Failure by buyer to give such written notice within thirty (30) days shall be deemed an absolute and unconditional waiver of buyer's claim for such defects. Acceptance of any alleged defective product/parts by REGO®'s distributor for replacement or repairs under the terms of REGO®'s Limited Warranty in no way determines REGO®'s obligations under this Limited Warranty.

Because of a policy of continuous product improvement, REGO® reserves the right to change designs, materials or specifications without notice.



LP-Gas & Anhydrous Ammonia Equipment

Section A Regulators and Accessories

A

RegO® Regulator Color Coding

RegO® domestic first stage, second stage, single stage, and integral twin stage LP-Gas regulators are easy to identify. In addition to a standard part number marking, each regulator is color coded to indicate the proper application and to help minimize misapplication in the field that can lead to accidents and costly service callbacks. The color coding system is standard on all 404, LV404, 2302, LV2302, 2403, 2503, LV3403, LV4403, and LV5503 series domestic LP-Gas regulators manufactured after May of 1986.

- Brilliant Red** - First Stage High Pressure Regulators.
Normally used in two-stage applications in conjunction with a second stage low pressure regulator.
- Select Brown** - Regulators with Low Pressure delivery range. Select Brown color is found on both:
- Second Stage Low Pressure Regulators.
Normally used in two-stage applications in conjunction with a first stage high pressure regulator.
 - Integral Twin Stage Regulators. Designed to provide benefits of two-stage regulation in one compact unit.
- Select Blue** - Second Stage Regulators for 2 PSIG Systems. Designed to reduce first stage pressure down to 2 PSIG.
Normally used in conjunction with a first stage high pressure regulator.
- Classic Gold** - Single Stage Regulators. Designed to use alone in Single Stage Systems.
- Green** - High Pressure Anhydrous Ammonia Regulators.

Limited Warranty and Limitation of Liability

LIMITED 10 YEAR WARRANTY AND LIMITATION OF LIABILITY

LIMITED 10 YEAR WARRANTY

REGO® warrants to the original purchasers the products and repair kits manufactured by it to be free from defects in materials and workmanship under normal use and service for a period of 10 years from the date of manufacture. If within thirty days after buyer's discovery of what buyer believes is a defect, buyer notifies in writing and ships the product to REGO® at 100 Rego Drive, Elon, NC 27244, REGO®, at its option, and within forty-five days of receipt, will repair, replace F.O.B. point of manufacture, or refund the purchase price of that part or product found by REGO® to be defective. Failure of buyer to give such written notice and ship the product within thirty days shall be deemed an absolute and unconditional waiver of any and all claims of buyer arising out of such defect.

This warranty does not extend to any product or part that is not installed and used continuously after installation in accordance with REGO®'s printed instructions, all applicable state and local regulations, and all applicable national standards, such as those promulgated by NFPA, DOT and ANSI. This warranty does not extend to any product or part that has been damaged by accident, misuse, abuse, failure to maintain, or neglect, nor does it extend to any product or part which has been modified, altered, disassembled, or repaired in the field. This warranty does not cover any cosmetic issues, such as scratches, dents, marring, fading of colors or discoloration.

Except as expressly set forth above, and subject to the limitation of liability below, REGO® MAKES NO OTHER WARRANTY, EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, with respect to its products and parts, whether used alone or in combination with others. REGO® disclaims all warranties not stated herein.

LIMITATION OF LIABILITY

REGO®'s total liability for any and all losses and damages arising out of any cause whatsoever shall in no event exceed the purchase price of the products or parts in respect of which such cause arises, whether such cause be based on theories of contract, negligence, strict liability, tort or otherwise.

REGO® shall not be liable for incidental, consequential or punitive damages or other losses. REGO® shall not be liable for, and buyer assumes any liability for, all personal injury and property damage connected with the handling, transportation, possession, further manufacture, other use or resale of products, whether used alone or in combination with any other products or materials.

From time to time buyers might call to ask REGO® for technical advice based upon limited facts disclosed to REGO®. If REGO® furnishes technical advice to buyer, whether or not at buyer's request, with respect to application, further manufacture or other use of the products and parts, REGO® shall not be liable for such technical advice or any such advice provided to buyer by any third party and buyer assumes all risks of such advice and the results thereof.

NOTE: Some states do not allow the exclusion or limitation of incidental, consequential or punitive damages, so the above limitation or exclusion may not apply to you. The warranty gives you specific legal rights, and you may have other rights that vary from State to State. The portions of this limited warranty and limitation of liability shall be considered severable and all portions which are not disallowed by applicable law shall remain in full force and effect.

NOTICE TO USERS OF PRODUCTS

The Limited Warranty stated above is a factory warranty to the first purchasers of REGO® products. Since most users have purchased these products from REGO® distributors, the user must within thirty (30) days after the user's discovery of what user believes is a defect, notify in writing and return the product to the distributor from whom he purchased the product/part. The distributor may or may not at the distributor's option choose to submit the product/parts to REGO®, pursuant to this Limited Warranty. Failure by buyer to give such written notice within thirty (30) days shall be deemed an absolute and unconditional waiver of buyer's claim for such defects. Acceptance of any alleged defective product/parts by REGO®'s distributor for replacement or repairs under the terms of REGO®'s Limited Warranty in no way determines REGO®'s obligations under this Limited Warranty.

Because of a policy of continuous product improvement, REGO® reserves the right to change designs, materials or specifications without notice.

Foreword

This catalog describes a complete line of equipment available from REGO® for use with LP-Gas and anhydrous ammonia (NH₃). The following points are important to know for proper use of the catalog:

1. Illustrations and drawings of individual products are representative of “product groups” and all products within a product group are similar in construction.
2. Materials used for construction of products in this catalog are suitable for rated service pressure at temperatures of -40° F. to +165° F., unless otherwise specified.
3. Products in this catalog are only intended for use in LP-Gas and/or anhydrous ammonia service as follows.
 - a. “A” or “AA” prefix — Products with this prefix are suitable for NH₃ service (i.e., contain no brass parts).
 - b. “AA” prefix on relief valves — These valves are NOT suitable for use with LP-Gas service. These are of partial aluminum materials and are listed by Underwriters Laboratories (UL) for NH₃ service only.
 - c. All other products are suitable for use with LP-Gas service.
 - d. “SS” prefix—Hydrostatic relief valve with this prefix are suitable for NH₃ service (i.e., they have stainless steel materials).

Caution

Do not use any product contained in this catalog with any service commodity other than LP-Gas or NH₃. If you have a need for use of another application, contact REGO®, 100 RegO Drive, Elon, NC 27244, (336) 449-7707 before proceeding.

Proper application, installation and maintenance of products in this catalog are essential. Users of these products should obtain further information if there are any doubts or questions.

Warning

All REGO® products are mechanical devices that will eventually become inoperative due to wear, corrosion and aging of components made of materials such as rubber. The environment and conditions of use will determine the safe service life of these products. Periodic inspection and maintenance are essential to avoid serious injury and property damage.

Many REGO® products are manufactured for storage, transport, transfer and use of toxic flammable and dangerous liquids and gases. Such substances should be handled by experienced and trained personnel only, using accepted governmental and industrial safety procedures. Never vent LP-Gas near any possible source of ignition.

Notice

Installation, usage, and maintenance of all REGO® products must be in compliance with all REGO® instructions as well as requirements and provisions of NFPA #54, NFPA#58, DOT, ANSI, and all applicable federal, state, provincial and local standards, codes, regulations, and laws.

Inspection and maintenance on a periodic basis is essential. Installation and maintenance should be performed only by qualified personnel.

Be sure all instructions are read and understood before installation, operation and service.

Filters

REGO® LP-Gas equipment is designed to operate in a system free from contamination. A variety of in-line filters are commercially available to the LP-Gas industry for installation in domestic systems.

The use of an in-line filter should be considered when other system components may be unclean and the system contaminated by rust, scale, dirt, debris or other foreign material.

Contents

Page

Advantages of Two-Stage Regulation	A8
Brackets.....	A34
Compact First Stage Regulators	A14
Compact Regulators.....	A27
Compact Twin Stage Regulators	A21
Cross Reference by Part Number.....	A37
High Pressure Industrial / Commercial lbs.-to-lbs. Regulators	A28
High Pressure High Temp Industrial / Commercial lbs.-to-lbs Regulators	A30
High Pressure First Stage Regulators	A15
Inlet Fittings	A33
Large Capacity Second Stage Regulators	A20
Low Pressure Second Stage Regulators.....	A16
Low Pressure Single Stage Regulators.....	A28
Low Pressure Second Stage Tobacco Barn Regulator	A20
Manifolds	A34
Pigtails	A33
Safety Warning	A5
Pipe and Tubing Selection Guide	A10
RegO® Regulator Dependability	A4
RegO® Regulator Designs	A13
RegO® Regulator Selection	A4

Contents

Page

Regulator Outfits.....	A26
Second Stage Regulators for 2 PSI Systems.....	A19
Test Kits	A35
Twin Stage Automatic Changeover Regulators	A23
Two PSIG Delivery Pressure Twin-Stage Regulator	A24
Two-Stage LP-Gas Systems	A9
Vapor Relief Valves	A33
Warnings and Labels	A36

RegO® Regulator Dependability

When RegO® LP-Gas Regulators are properly installed, safe, precise, trouble-free service is the result.

Dependability is built into every regulator ... the result of rigid standards of quality control and close tolerance machining. And this has been true for more than 60 years.

RegO® Products are manufactured from the finest materials, and assembled and tested using procedures second to none.

All give you a product that provides accurate gas delivery under varying pressure ranges and load conditions.

RegO® LP-Gas Regulators are UL listed and comply with applicable code requirements.

RegO® Products offer a complete line of LP-Gas Regulators with capacities for almost every application.

RegO® Regulator Selection

In order to properly size the RegO® Regulator, find the total load of the installation. The total load is calculated by adding up the input ratings (BTU or CFH) of all appliances in the installation. Input ratings may be obtained from the nameplates on the appliances or from the manufacturers' literature.

Determine the type of regulation needed referring to the chart below.

Type of System	Maximum Load	Suggested Regulator
First Stage in a Two Stage System	1,500,000	LV3403TR
	2,500,000	LV4403SR Series LV4403TR Series
Second Stage in a Two Stage System	450,000	LV3403B Series
	935,000	LV4403B Series
	1,600,000	LV5503B4/B6
	2,300,000	LV5503B8
	9,800,000	LV6503B Series
Second Stage in a 2 PSIG System	1,000,000	LV4403Y4/Y46R
	2,200,000	LV5503Y6/Y8
Integral Twin Stage	450,000	LV404B34/39 Series
	525,000	LV404B4/B9 Series
	800,000	LV404Y9
Automatic Changeover	200,000	7525B34 Series
	450,000	7525B4 Series

* See catalog page for inlet and delivery specifications.

Now determine which regulator in the Series would be most suitable. Turn to the individual product pages and refer to the Performance Curves. Check the performance of the regulator with your actual load conditions at the minimum LP-Gas inlet pressure for the regulator. Use the pressure corresponding to your lowest winter temperatures shown in the chart below or refer to the delivery pressure of your first

Temperature		Approx. Pressure (PSIG)		Temperature		Approx. Pressure (PSIG)	
°F	°C	Propane	Butane	°F	°C	Propane	Butane
-40	-40	3.6		40	4	72	3.0
-30	-34	8		50	10	86	6.9
-20	-29	13.5		60	16	102	12
-10	-23	23.3		70	21	127	17
0	-18	28		80	27	140	23
10	-12	37		90	32	165	29
20	-7	47		100	38	196	36
30	-1	58		110	43	220	45

stage regulator.


Example for a First Stage Regulator

1. Assume a load of 500,000 BTU's per hour.
2. Assume a minimum delivery pressure of 9.5 PSIG.
3. Assume a minimum tank pressure of 15 PSIG.
4. For these conditions, refer to chart for the LV4403TR Series, First

Stage Regulator, shown below.

5. Find the line on the chart corresponding to the lowest anticipated winter tank pressure (note that each performance line corresponds to and is marked with a different inlet pressure in PSIG).
6. Draw a vertical line upward from the point of assumed load (500,000 BTU's per hour) to intersect with the line corresponding to the lowest tank pressure.
7. Read horizontally from the intersection of these lines to the delivery pressure at the left side of the chart. In this example the delivery pressure will be 9.7 PSIG. Since the delivery pressure will be 9.7 PSIG at the maximum load conditions and lowest anticipated tank pressure, the regulator will be sized properly for the demand.


LV4403TR Series First Stage Regulator



Example for a Second Stage Regulator

1. Assume load of 250,000 BTU's per hour.
2. Assume a minimum delivery pressure of 10" w.c.
3. Assume a minimum inlet pressure of 10 PSIG.
4. For these conditions, refer to chart for the LV4403B Series, Second Stage Regulator, shown below.
5. Find the line on the chart corresponding to the anticipated inlet pressure.
6. Draw a vertical line upward from the point of assumed load (250,000 BTU's per hour) to intersect with the line corresponding to the lowest inlet pressure.
7. Read horizontally from the intersection of these lines to the delivery pressure at the left side of the chart. In this example the delivery pressure will read 10.6" w.c. Since the delivery pressure will be 10.6" w.c. at the maximum load condition and lowest anticipated inlet pressure, the regulator is sized properly for the demand.

LV4403B Series Second Stage Regulator



Safety Warnings



Purpose

In its continuing quest for safety, REGO® publishes a series of bulletins explaining the hazards associated with the use, misuse, and aging of LP-Gas valves and regulators. It is hoped that these factual bulletins will make clear to LP-Gas dealer managers and service personnel, that the utmost care and attention must be used in the installation, inspection, and maintenance of these products, or problems could occur which would result in injuries and property damage.

The National Fire Protection Association Pamphlet #58 - 2004 Edition, "Liquefied Petroleum Gas Code" states in Section 1.5 that, "persons who transfer liquid LP-Gas, who are employed to transport LP-Gas, or whose primary duties fall within the scope of this code shall be trained in proper handling procedures. Refresher training shall be provided at least every three years. The training shall be documented." These "REGO® Safety Warnings" may be useful in training new employees and reminding older employees of hazards that can occur. It is recommended that all employees be furnished with a copy of NPGA Safety Pamphlet 306, "LP-Gas Regulator and Valve Inspection and Maintenance."

Nature of Warnings

It is recognized that warnings should be as brief as possible, but the factors involved in regulator failures are not simple. They need to be fully understood so that proper maintenance programs can be established. If there is a simple warning, it would be:

Inspect regulators regularly as outlined in this safety warning and replace as required per these recommendations. When all of these recommendations are followed, the recommended service life of an REGO® regulator (except single stage) manufactured after 1995 is 25 years. The recommended service life of all other REGO® regulators is 15 years.

LP-Gas Regulators

This bulletin applies most particularly to permanent LP-Gas installations of cylinders and tanks. The warnings also apply in most cases to portable installations of recreational vehicles, barbecue grills, etc. This bulletin is not intended to be an exhaustive treatment of the subject of regulators and certainly does not cover all safety practices that should be followed in the installation and maintenance of LP-Gas systems.

It should not be necessary to remind readers of this bulletin that regulators must be installed in strict conformance with NFPA Pamphlets 54 and 58, and all other applicable codes and regulations. Codes, regulations and manufacturer's recommendations have been developed by experts with many years of experience in the LP-Gas industry.

Failure to fully follow these codes, regulations and recommendations could result in hazardous installations.

Pamphlet 58 states "All regulators for outdoor installations, except regulators used for portable industrial applications, shall be designed, installed or protected so their operation will not be affected by the elements (freezing rain, sleet, snow, ice, mud or debris). This protection may be integral with the regulator."

Failed and/or Inoperative Regulators

Failed regulators can cause three kinds of hazards:

- High pressure LP-Gas in a system downstream of the regulator; and
- Leaks of LP-Gas to atmosphere from the regulator itself.
- Loss of pressure due to a "freeze-up" in the orifice.

High Pressure LP-Gas in a System

Anything that prevents a regulator from regulating properly could result in high pressure gas at the regulator outlet and thus in a system.

High pressure gas into piping and appliances could cause piping leaks and damage to appliance burner controls with the potential for fires and explosions.


The Causes of High Pressure Gas in a System are:

1. Regulator vents that are clogged or obstructed.

Vents must be clear and fully open at all times.

Many regulators are equipped with a pressure relief valve which discharges to atmosphere through the vent. Ice, snow drifts, dirt, bugs, paint, or other foreign material can clog the vents.

An obstructed vent may prevent the pressure relief valve from operating properly.



Regulators should be installed with the vent facing down or protected so their operation will not be affected by the elements. In cases where the regulator vent is equipped with a discharge tube, the outlet of this tube must be facing down. The vents and/or discharge tubes must be protected from the elements and must be equipped with a screen to prevent bugs from obstructing the opening.

Action Required: Regulators should be properly installed and regularly inspected when tanks or cylinders are filled. If vents are clogged or the screen is missing, they must be cleaned or replaced. If the vent screen is missing and there is evidence of foreign material around the vent, the regulator should be replaced.

2. Foreign material lodging between the regulator nozzle and seat disc:

When this occurs, the regulator can remain open, allowing high pressure gas into the system.

This material can come from system piping between the container shut-off valve and the regulator. Chips created during piping installation or dirty piping can create this hazard. Corrosion inside of copper pigtails and piping can cause problems. This can occur particularly when LP-Gas contains high sulphur or excessive moisture.

Action Required: Make sure regulator inlet piping is clean at the time of installation. Periodic checks should be made to assure piping remains clean without corrosion. Never use old pigtails on new LP-Gas installations. Old pigtails can also work harden and crack if they have been bent and twisted several times.

3. Wrong regulator installed for the application:

The proper regulator must be used for each system.

For example, installation of high pressure regulators not designed to reduce gas pressure to an appliance requirement of 11" w.c. will cause a hazard. Installing a regulator undersized for the load can cause improper combustion at the appliance burner with a potential for carbon monoxide poisoning.

Action Required: Make sure the regulator is correct for each application and test the system with a pressure gauge or a manometer.

4. Failure to external mechanical parts due to corrosion:


Adjusting springs and relief valve springs can rapidly corrode if exposed to salt air or industrial pollution. Even moisture condensation on these springs can cause them to rust and fail.

Failure of these springs will result in failure of the regulator to control the pressure.

With the vent of a regulator facing down, corrosion products from the springs could clog the regulator vent screen blocking the vent.

Action Required: Regulator inspection for corrosion should be made according to the guidelines listed below:

- For underground installations subject to submersion, the regulator should be inspected **every** time the container is filled.
- For known corrosive atmospheres of salt air or chemical pollution, the regulator should be inspected at least once a year.



- For other applications, the regulator should be inspected every 3 years.


A casual inspection for corrosion can be made by examining the surface and looking into the bonnet after the bonnet cap has been removed. This sometimes will alert the inspector to corrosive conditions. Certainly the regulator should be examined in more detail by a qualified and trained technician. For single stage, second stage and twin stage regulators remove the bonnet cap and examine the inside of the bonnet with a strong flashlight. For first stage regulators that have a bonnet cap, shut down the system, remove the bonnet cap and spring and examine the inside of the bonnet with a strong flashlight. After the inspection, the regulator must be adjusted to the proper pressure.

If any corrosion is evident, replace the regulator.

It is essential that the regulator bonnet cap be tightly in place at all times to prevent the entrance of water, bugs, dirt, etc. Foreign material can cause the regulator to function improperly with potentially hazardous results.

5. Liquid propane in the regulator:

This can occur on recreational vehicles, unless the regulator is installed substantially higher than the container shut-off valve. Here, sloshing propane could get into the regulator with the resulting high



pressure downstream of the regulator. It could also occur on stationary installations if the regulator is installed below the shut-off valve and the container is over-filled.

Action Required: Be careful of regulator installation and never overfill any LP-Gas container.

Leaks of LP-Gas to Atmosphere

While the occurrences of leaking regulators are rare, they can and do occur with a potential for fires and explosions.

These leaks can be caused by:



1. Corrosion of the relief valve spring or foreign material on the seat disc which causes the relief valve to open, will cause LP-Gas to escape through the regulator vent, as well as permitting high pressure into the system.

Action Required: Regulator inspection for corrosion should be made according to the guidelines listed below:

- For underground installations subject to submersion, the regulator should be inspected **every** time the container is filled.
- For known corrosive atmospheres of salt air or chemical pollution, the regulator should be inspected at least once a year.
- For other applications, the regulator should be inspected every 3 years.

A casual inspection for corrosion can be made by examining the surface and looking into the bonnet after the bonnet cap has been removed. This sometimes will alert the inspector to corrosive conditions. Certainly the regulator should be examined in more detail by a qualified and trained technician. For single stage, second stage and twin stage regulators remove the bonnet cap and examine the inside of the bonnet with a strong flashlight. For first stage regulators that have a bonnet cap, shut down the system, remove the bonnet cap and spring and examine the inside of the bonnet with a strong flashlight. After the inspection, the regulator must be adjusted to the proper pressure.


If any corrosion is evident, replace the regulator.

2. Bad piping connections at the regulator inlet and outlet. This can occur at the time of installation where connections are loose or the regulator may have been overstressed by excessive wrenching. It is important that proper wrenches, both on the piping and on the regulator inlet and outlet, be used when connecting the system piping, and that the regulator die cast body is not cracked by wrenching the pipe too deeply into the body.

Action Required: Always test for leaks at time of installation and inspect for leaks if there is reason to believe that pipe connections could cause a hazard.

Loss of Pressure

Freeze-up inside the regulator.



This will prevent the regulator from regulating properly.

Regulator freeze-ups occur because there is excessive moisture in the gas. Freeze-ups can also occur in pigtails that are kinked or bent where free flow of the LP-Gas is restricted. These freeze-ups can occur when the moisture, gas flow and temperature combine to create a hazardous condition. Freeze-ups can occur at temperatures above 32° F.


Action Required: All LP-Gas should be checked for moisture content prior to delivery to consumers and proper amounts of anhydrous methanol added if the gas cannot be returned to the supplier. Any container suspected of having excessive moisture should be treated with the proper amount of methanol.

Underground Installations

Special hazards can occur if regulators are not properly installed in underground systems. Water, dirt, mud and insects can get into the regulator if the bonnet cap is not tightly in place and the vent is not protected with a proper vent tube, opening above any potential water level.

Most problems occur because the waterproof dome on the buried storage tank does not extend above the ground level sufficiently to keep out water and mud.

Refer to NPGA No. 401.



Note: Water mark left in housing dome at level above regulator vent, or end of vent tube requires replacement of regulator. Then correct installation.

Customer Safety

Since regulators are often used by consumers without previous knowledge of the hazards of LP-Gas, and the LP-Gas dealers are the only ones who have direct contact with the consumers,

It is the dealer's responsibility to make sure that his customers are properly instructed in safety matters relating to their installation.

At the very minimum, it is desirable that these customers:

1. Know the odor of LP-Gas and what to do in case they smell gas. Use the NPGA "Scratch 'n Sniff" leaflet.
2. Are instructed to never tamper with the system.
3. Know that when protective hoods are used to enclose regulators and/or valves, that these hoods must be closed, but not locked.
4. Keep snow drifts from covering regulators.
5. Know the location of the cylinder or tank shut-off valve in emergencies.

General Warning


All REGO® Products are mechanical devices that will eventually become inoperative due to wear, contaminants, corrosion and aging of components made of materials such as metal and rubber. As a general recommendation, Regulators should be replaced in accordance with all of the recommendations outlined in this safety warning. The recommended service life of a regulator is one of many factors that must be considered in determining when to replace a regulator.

The environment and conditions of use will determine the safe service life of these products. Periodic inspection and maintenance are essential.

Because REGO® Products have a long and proven record of quality and service, LP-Gas dealers may forget the hazards that can occur because a regulator is used beyond its safe service life. Life of a regulator is determined by the environment in which it "lives." The LP-Gas dealer knows better than anyone what this environment is.

NOTE: There is a developing trend in state legislation and in proposed national legislation to make the owners of products responsible for replacing products before they reach the end of their safe useful life. LP-Gas dealers should be aware of legislation which could affect them.

Advantages of Two-Stage Regulation



The regulator is truly the heart of an LP-Gas installation. It must compensate for variations in tank pressure from as low as 8 PSIG to 220 PSIG – and still deliver a steady flow of LP-Gas at 11" w.c. to consuming appliances. The regulator must deliver this pressure

despite a variable load from intermittent use of the appliances. Though a single-stage system may perform adequately in many installations, the use of a two-stage system offers the ultimate in pinpoint regulation. Two-stage regulation can result in a more profitable LP-Gas operation for the dealer resulting from less maintenance and fewer installation callbacks – and there is no better time than now for installing RegO® Regulators in two-stage systems.

Uniform Appliance Pressure

The installation of a two-stage system – one high pressure regulator at the container to compensate for varied inlet pressures, and one low pressure regulator at the building to supply a constant delivery pressure to the appliances – helps ensure maximum efficiency and trouble-free operation year-round. It is important to note that while pressure at the appliances can vary up to 4" w.c. using single-stage systems, two-stage systems keep pressure variations within 1" w.c. New high-efficiency appliances require this closer pressure control for proper ignition and stable, efficient operation. In fact, one major manufacturer requires the use of two-stage systems with their appliances.

Reduced Freeze-ups/Service Calls

Regulator freeze-up occurs when moisture in the gas condenses and freezes on cold surfaces of the regulator nozzle. The nozzle becomes chilled when high pressure gas expands across it into the regulator

body. This chilling action is more severe in single-stage systems as gas expands from tank pressure to 11" w.c. through a single regulator nozzle.

Two-stage systems can greatly reduce the possibility of freeze-ups and resulting service calls as the expansion of gas from tank pressure to 11" w.c. is divided into two steps, with less chilling effect at each regulator. In addition, after the gas exits the first-stage regulator and enters the first-stage transmission line, it picks up heat from the line, further reducing the possibility of second-stage freeze-up.

Service calls for pilot outages and electronic ignition system failures are also reduced as a result of more uniform appliance pressure from two-stage systems.

Economy of Installation

In a single-stage system, transmission line piping between the container and the appliances must be large enough to accommodate the required volume of gas at 11" w.c. In contrast, the line between the first and second stage regulators in two-stage systems can be much smaller as it delivers gas at 10 PSIG to the second-stage regulator. Often the savings in piping cost will pay for the second regulator.

As an additional benefit, single-stage systems can be easily converted to two-stage systems using existing supply lines when they prove inadequate to meet added loads. This is the least expensive and best method of correcting the problem.

Allowance for Future Appliances

A high degree of flexibility is offered in new installations of two-stage systems. Appliances can be added later to the present load – provided the high pressure regulator can handle the increase – by the addition of a second low pressure regulator. Since appliances can be regulated independently, demands from other parts of the installation will not affect their individual performances.

Size The System Correctly


Prior to installing your two-stage system, be sure the system pipe and tubing is properly sized. Proper sizing will help ensure constant delivery pressure to the appliances during fluctuating loads at all times. Just as important, be sure the RegO® Regulators you choose are capable of handling the desired load. This is another advantage of two-stage systems – they are capable of handling much more BTU's/hr. than single-stage systems. The RegO® "LP-Gas Serviceman's Manual" provides complete information on pipe sizing and proper regulator selection.

Replace Pigtails

If you are replacing an old regulator, remember to replace the copper pigtail. The old pigtail may contain corrosion which can restrict flow. In addition, corrosion may flake off and wedge between the regulator orifice and seat disc – preventing proper lock-up.

Two-Stage LP-Gas Systems ...

Require First Stage Regulators with Built-in Relief Valves





Resulting in sudden pressure surge due to flashing into vapor here! First stage relief can prevent liquid from forming in first stage piping during periods with no gas demand!!

Ambient Temperature	Tank Pressure
70° F.	120 PSIG
80° F.	140 PSIG
90° F.	165 PSIG

Ground Temperature	Pressure at Which liquid will form
40° F.	72 PSIG
50° F.	86 PSIG
60° F.	102 PSIG

Pressure at which liquid can form at various temperatures.

Vapor Pressures of LP Gases



The Problem

Many modern LP-Gas appliances are equipped with pilotless ignition systems. Water heaters and older appliances use pilot lights, but it has become a common practice for energy conscious homeowners to shut-off the pilot when leaving home for extended periods of time. In each instance, there is **no gas demand at all** for extended periods.

The Consequences

If the first stage regulator fails to lock-up tight, usually as a result of a worn seat disc or foreign material lodged between nozzle and seat disc, pressure will build-up in the first stage piping – possibly to a level that approaches tank pressure. Combining this with warm ambient temperatures and cool ground, **propane liquid may form** in the first stage piping.

When gas demand resumes, this liquid may pass through the second stage regulator into the appliances and furnace. NOTE – the second

stage regulator will not relieve the pressure in first stage piping. The rapid vaporization of the liquid may cause a rapid pressure surge that could seriously damage critical components of the appliance and furnace controls.

A fire or explosion could occur as a consequence.

The Solution


Rego® LV4403 Series First Stage Regulators with Built-In Relief Valves reduce the possibility of this serious hazard in two stage applications. The built-in relief valve is designed to vent as needed and reduce the possibility of first stage piping pressure from becoming high enough to form liquid.

Pipe and Tubing Selection Guide

Use the following simple method to assure the selection of the correct sizes of piping and tubing for LP-Gas vapor systems. Piping between first and second stage regulators is considered, as well as low pressure (inches water column) piping between second stage, single stage, or integral twin stage regulators and appliances. The information supplied below is from NFPA 54 (National Fuel Gas Code) Appendix C section C 4.1. The pipe sizing tables are from NFPA 58 (Liquefied Petroleum Gas Code) Chapter 15. For More detailed information on LP-Gas vapor pipe sizing refer to NFPA 54 or NFPA 58. The illustrations are for demonstrative purposes, they are not intended for actual system design.

Instructions:

- Determine the total gas demand for the system by adding up the BTU/hr input from the appliance nameplates and adding demand as appropriate for future appliances.
- For second stage or integral twin stage piping:
 - Measure length of piping required from outlet of regulator to the appliance *furthest away*. No other length is necessary to do the sizing.
 - Make a simple sketch of the piping, as shown.
 - Determine the capacity to be handled by each section of piping. For example, the capacity of the line between a and b must handle the total demand of appliances A, B, and C; the capacity of the line from c to d must handle only appliance B, etc.
 - Using Table 3 select proper size of tubing or pipe for each section of piping, using values in BTU/hr for the length determined from step #2-A. If exact length is not on chart, use next longer length. Do not use any other length for this purpose! Simply select the size that shows at least as much capacity as needed for each piping section.
- For piping between first and second stage regulators
 - For a simple system with only one second stage regulator, merely measure length of piping required between outlet of first stage regulator and inlet of second stage regulator. Select piping or tubing required from Table 1.
 - For systems with multiple second stage regulators, measure length of piping required to reach the second stage regulator that is furthest away. Make a simple sketch, and size each leg of piping using Table 1, 2, or 3 using values shown in column corresponding to the length as measured above, same as when handling second stage piping.




Example 1

Determine the sizes of piping or tubing required for the twin-stage LP-Gas installation shown.


Total piping length = 84 feet (use Table 3 @90 feet)

From a to b, demand = 38,000 + 35,000 + 30,000
= 103,000 BTU/hr; use 3/4" pipe
From b to c, demand = 38,000 + 35,000
= 73,000 BTU/hr; use 1/2" pipe or 3/4" tubing
From c to d, demand = 35,000 BTU/hr; use 1/2" pipe or 5/8" tubing
From c to e, demand = 38,000 BTU/hr; use 1/2" pipe or 5/8" tubing
From b to f, demand = 30,000 BTU/hr; use 1/2" pipe or 1/2" tubing



Example 2.

Determine the sizes of piping or tubing required for the two-stage LP-Gas installation shown.



Total first stage piping length = 26 feet; first stage regulator setting is 10psig (use Table 1 or 2 @ 30 feet)

From aa to a, demand = 338,000 BTU/hr; use 1/2" pipe, 1/2" tubing, or 1/2" T plastic pipe.

Total second stage piping length = 58 feet (use Table 3 @ 60 feet)

From a to b, demand = 338,000 BTU/hr; use 1" pipe
From b to c, demand = 138,000 BTU/hr; use 3/4" pipe or 7/8" tubing
From c to d, demand = 100,000 BTU/hr; use 1/2" pipe or 3/4" tubing
From d to e, demand = 35,000 BTU/hr; use 1/2" pipe or 1/2" tubing
From b to f, demand = 200,000 BTU/hr; use 3/4" pipe or 7/8" tubing
From c to g, demand = 38,000 BTU/hr; use 1/2" pipe or 1/2" tubing
From d to h, demand = 65,000 BTU/hr; use 1/2" pipe or 5/8" tubing

Pipe and Tubing Selection Guide

Example 3

Determine the sizes of piping or tubing required for the 2 PSI LP-Gas installation shown.

Total first stage piping length = 26 feet; first stage regulator setting is 10psig (use Table 1 or 2 @ 30 feet)

Total 2 PSI Piping Length = 19 ft. (use Table 4 @ 20 ft. or Table 6 @ 20 ft.)

From aa to a, demand= 338,000 BTU

use 3/8" CSST or 1/2" copper tubing or 1/2" pipe

From Regulator a to each appliance:

From a to b, demand= 65,000 BTU; length = 25 ft. (Table 5),

use 1/2" CSST

From a to c, demand= 200,000 BTU; length = 30 ft. (Table 5)

use 3/4" CSST

From a to d, demand= 38,000 BTU; length = 21 ft.* (Table 5)

use 3/8" CSST *use 25 ft. column

From a to e, demand= 35,000 BTU; length = 40 ft. (Table 5)

use 1/2" CSST




Table 1 – First Stage Pipe Sizing (Between First and Second Stage Regulators) 10 PSIG Inlet with a 1 PSIG Pressure Drop Maximum capacity of pipe or tubing, in thousands of BTU/hr or LP-Gas

Size of Pipe or Copper Tubing, Inches		Length of Pipe or Tubing, Feet																			
		10	20	30	40	50	60	70	80	90	100	125	150	175	200	225	250	275	300	350	400
Copper Tubing (O.D.)	3/8"	558	383	309	265	235	213	196	182	171	161	142	130	118	111	104	90	89	89	82	76
	1/2"	1387	870	700	599	531	481	443	412	386	365	323	293	269	251	235	222	211	201	185	172
	5/8"	2360	1622	1303	1115	988	896	824	767	719	679	601	546	502	467	438	414	393	375	345	321
	3/4"	3993	2475	2205	1887	1672	1515	1394	1297	1217	1149	1018	923	843	790	740	700	664	634	584	543
	1"	5339	3339	2295	1843	1577	1398	1267	1165	1084	1017	961	852	772	710	660	619	585	556	530	488
	1 1/4"	6982	4799	3854	3298	2923	2649	2437	2267	2127	2009	1780	1613	1484	1381	1296	1224	1162	1109	1020	949
	1 1/2"	13153	9040	7259	6213	5507	4989	4590	4270	4007	3785	3354	3039	2796	2601	2441	2305	2190	2089	1922	1788
	2"	27004	18560	14904	12756	11306	10244	9424	8767	8226	7770	6887	6240	5741	5340	5011	4733	4495	4289	3945	3670
	2 1/2"	40461	27809	22331	19113	16939	15348	14120	13136	12325	11642	10318	9349	8601	8002	7508	7092	6735	6426	5911	5499
	3"	77924	53556	43008	36809	32623	29559	27194	25299	23737	22422	19871	18005	16564	15410	14459	13658	12971	12375	11385	10591

* Total length of piping from outlet of first stage regulator to inlet of second stage regulator (or to inlet of second stage regulator furthest away).

Notes: 1) To allow 2 PSIG pressure drop, multiply total gas demand by .707, and use capacities from table. 2) For different first stage pressures, multiply total gas demand by the following factors, and use capacities from table. Ex: 1,000,000 BTU load at 5 PSI: 1,000,000 (1.12) = 1,200,000 BTU then use chart bases on 1,200,000 BTU

First Stage Pressure PSIG Multiply By

20 .844
15 .912
5 1.120

Data Calculated per NFPA #54 & 58

Table 2 – First Stage Plastic Tubing Sizing 10 PSIG Inlet with a 1 PSIG Pressure Drop

Maximum capacity of plastic tubing in thousands of BTU/hr of LP-Gas

Size of Plastic Tubing		Length of Tubing, Feet*																			
		10	20	30	40	50	60	70	80	90	100	125	150	175	200	225	250	275	300	350	400
1/2 CTS	7.00	1387	954	762	653	578	524	482	448	421	397	352	319	294	273	256	242	230	219	202	188
3/4	9.33	3901	2681	2143	1835	1626	1473	1355	1261	1183	1117	990	897	826	778	721	681	646	617	567	528
1 CTS	11.00	7811	5369	4292	3673	3256	2950	2714	2525	2369	2238	1983	1797	1653	1539	1443	1363	1294	1235	1136	1057
1 1/4	11.00	9510	6536	5225	4472	3864	3591	3304	3074	2884	2724	2414	2188	2013	1872	1757	1659	1576	1503	1383	1287
1 1/2	11.00	14094	9687	7744	6628	5874	5322	4896	4555	4274	4037	3578	3242	2983	2775	2603	2459	2336	2228	2050	1907
2	11.00	24416	16781	13416	11482	10106	9220	8433	7891	7404	6994	6199	5616	5167	4807	4510	4260	4046	3860	3551	3304
2 1/2	11.00	-	-	20260	17340	15368	13924	12810	11918	11182	10562	9361	8482	7803	7259	6811	6434	6111	5830	5363	4989
3	11.00	66251	45534	36402	31155	27612	25019	23017	21413	20091	18978	16820	15240	14020	13043	12238	11560	10979	10474	9636	8965

* Total length of piping from outlet of first stage regulator to inlet of second stage regulator or to inlet of second stage regulator furthest away.

First Stage Pressure PSIG Multiply By

20 .844
15 .912
5 1.120

Data Calculated per NFPA #54 & 58

Pipe and Tubing Selection Guide

Table 3 – Second Stage or Integral Twin Stage Pipe Sizing 11 Inches Water Column Inlet with a 1/2 Inch Water Column Drop Maximum capacity of pipe or tubing in thousands of BTU/hr of LP-Gas

Size of Pipe or Copper Tubing, Inches		Length of Pipe or Tubing, Feet																			
		10	20	30	40	50	60	70	80	90	100	125	150	175	200	225	250	275	300	350	400
Copper Tubing (O.D.)	3/8"	49	34	27	23	20	19	-	16	-	14	12	11	-	10	-	9	-	8	7	7
	1/2"	110	76	61	52	46	42	38	36	33	32	28	26	-	22	-	19	-	18	16	15
	5/8"	206	141	114	97	86	78	71	67	62	59	52	48	-	41	-	36	-	33	30	28
	3/4"	348	239	192	164	146	132	120	113	105	100	89	80	-	69	-	61	-	55	51	47
	7/8"	536	368	296	253	224	203	185	174	161	154	137	124	-	106	-	94	-	85	78	73
Pipe Size	1/2"	291	200	161	137	122	110	102	94	87	84	74	67	62	58	54	51	48	46	43	40
	3/4"	608	418	336	287	255	231	212	198	185	175	155	141	129	120	113	107	101	97	89	83
	1"	1146	788	632	541	480	435	400	372	349	330	292	265	244	227	213	201	191	182	167	156
	1 1/4"	2353	1617	1299	1111	985	892	821	764	717	677	600	544	500	465	437	412	392	374	344	320
	1 1/2"	3525	2423	1946	1665	1476	1337	1230	1144	1074	1014	899	815	749	697	654	618	587	560	515	479
	2"	6789	4666	3747	3207	2842	2575	2369	2204	2068	1954	1731	1569	1443	1343	1260	1190	1130	1078	992	923

* Total length of piping from outlet of regulator to appliance furthest away.

Data Calculated per NFPA #54 & 58

Table 4-Maximum Capacity of CSST In Thousands of BTU per hour of undiluted LP-Gases Pressure of 2 psi and a pressure drop of 1 psi (Based on a 1.52 Specific Gravity Gas)*

Size	EHD** Flow Designation	Length of Pipe or Tubing, Feet													
		10	20	30	40	50	75	80	110	150	200	250	300	400	500
3/8"	13	426	262	238	203	181	147	140	124	101	86	77	69	60	53
	15	558	347	316	271	243	196	189	169	137	118	105	96	82	72
1/2"	18	927	591	540	469	420	344	333	298	245	213	191	173	151	135
	19	1106	701	640	554	496	406	393	350	287	248	222	203	175	158
3/4"	23	1735	1120	1027	896	806	663	643	578	477	415	373	343	298	268
	25	2168	1384	1266	1100	986	809	768	703	575	501	448	411	355	319
1"	30	4097	2560	2331	2012	1794	1457	1410	1256	1021	880	785	716	616	550
	31	4720	2954	2692	2323	2072	1685	1629	1454	1182	1019	910	829	716	638

Table does not include effect of pressure drop across the line regulator. If regulator loss exceeds 1/2 psi (based on 13 in. water column outlet pressure), **DO NOT USE THIS TABLE.** Consult with regulator manufacturer for pressure drops and capacity factors. Pressure drops across a regulator may vary with flow rate.

CAUTION: Capacities shown in table may exceed maximum capacity for a selected regulator. Consult with regulator or tubing manufacturer for guidance.

*Table includes losses for four 90-degree bends and two end fittings. Tubing runs with larger number of bends and/or fittings shall be increased by an equivalent length of tubing according to the following equation: $L = 1.3n$ where L is additional length (ft) of tubing and n is the number of additional fittings and/or bends.

**EHD — Equivalent Hydraulic Diameter — A measure of the relative hydraulic efficiency between different tubing sizes. The greater the value of EHD, the greater the gas capacity of the tubing.

Table 5-Maximum Capacity of CSST In Thousands of BTU per hour of undiluted LP-Gases Pressure of 11 Inch Water Column and a Pressure Drop of 0.5 Inch Water Column (Based on a 1.52 Specific Gravity Gas)*

Size	EHD** Flow Designation	Length of Pipe or Tubing, Feet																
		5	10	15	20	25	30	40	50	60	70	80	90	100	150	200	250	300
3/8"	13	72	50	39	34	30	28	23	20	19	17	15	15	14	11	9	8	8
	15	99	69	55	49	42	39	33	30	26	25	23	22	20	15	14	12	11
1/2"	18	181	129	104	91	82	74	64	58	53	49	45	44	41	31	28	25	23
	19	211	150	121	106	94	87	74	66	60	57	52	50	47	36	33	30	26
3/4"	23	355	254	208	183	164	151	131	118	107	99	94	90	85	66	60	53	50
	25	426	303	248	216	192	177	153	137	126	117	109	102	98	75	69	61	57
1"	30	744	521	422	365	325	297	256	227	207	191	178	169	159	123	112	99	90
	31	863	605	490	425	379	344	297	265	241	222	208	197	186	143	129	117	107

*Table includes losses for four 90-degree bends and two end fittings. Tubing runs with larger number of bends and/or fittings shall be increased by an equivalent length of tubing according to the following equation: $L = 1.3n$ where L is additional length (ft) of tubing and n is the number of additional fittings and/or bends.

**EHD — Equivalent Hydraulic Diameter — A measure of the relative hydraulic efficiency between different tubing sizes. The greater the value of EHD, the greater the gas capacity of the tubing.

Table 6 – Copper Tube Sizing or Schedule 40 Pipe Sizing* In Thousands of BTU per hour of undiluted LP-Gases 2 PSIG inlet with a 1PSIG pressure drop (Between 2 PSIG service regulator & line pressure regulator).

Size of Pipe or Copper Tubing, Inches		Length of Pipe or Tubing, Feet																			
		10	20	30	40	50	60	70	80	90	100	150	200	250	300	350	400	450	500	600	700
Copper Tubing (O.D.)	3/8"	451	310	249	213	189	171	157	146	137	130	104	89	79	72	66	61	58	54	49	45
	1/2"	1020	701	563	482	427	387	356	331	311	294	236	202	179	162	149	139	130	123	111	102
	5/8"	1900	1306	1049	898	795	721	663	617	579	547	439	376	333	302	278	258	242	229	207	191
	3/4"	3215	2210	1774	1519	1346	1219	1122	1044	979	925	743	636	563	511	470	437	410	387	351	323
	1/2"	2687	1847	1483	1269	1125	1019	938	872	819	773	621	531	471	427	393	365	343	324	293	270
Pipe Size	3/4"	5619	3862	3101	2654	2352	2131	1961	1824	1712	1617	1298	1111	985	892	821	764	717	677	613	564
	1"	10585	7275	5842	5000	4431	4015	3694	3436	3224	3046	2446	2093	1855	1681	1546	1439	1350	1275	1155	1063
	1 1/4"	21731	14936	11994	10265	9098	8243	7584	7055	6620	6253	5021	4298	3809	3451	3175	2954	2771	2618	2372	2182
	1 1/2"	32560	22378	17971	15381	13632	12351	11363	10571	9918	9369	7524	6439	5707	5171	4757	4426	4152	3922	3554	3270
	2"	62708	43099	34610	29621	26253	23787	21884	20359	19102	18043	14490	12401	10991	9959	9162	8523	7997	7554	6844	6297

RegO® Regulator Designs

Typical of the LV4403 Low Pressure Regulators and LV4403 High Pressure Regulators.

RegO® LP-Gas Regulators have been designed to give outstanding performance and dependability with a minimum of maintenance.

Nozzle Orifice

Replaceable and precision machined to prevent scoring of the seat disc.

Seat Disc

Replaceable, resilient construction gives sure closing at lock up pressure. Straight line seat disc to nozzle operation provides even seat disc wear and positive lock up.

Pivot Pin

Fully enclosed in regulator body.

Control Linkage


Provides quick response to diaphragm movement; moves directly perpendicular to nozzle orifice to meter gas flow, give positive closure and reduce seat disc wear.

Built-In Pressure Tap

Provides a convenient way to check downstream pressure on both high and low pressure models.

Body & Bonnet

Painted, heavy-duty zinc resists corrosion and gives long-life protection, even under "salty air" conditions.



Molded Diaphragm Assembly

Molded synthetic rubber with a tough, flexible fabric gives a super sensitive response in a temperature range of -40° to +165°F. Molded diaphragm seals in a groove between the body and bonnet.

Diaphragm Plate

Rigid diaphragm plate transmits pressure variations to control linkage.

Relief Valve

It is built in and tamper resistant. Large bonnet vent allows high capacity relief on second stage regulators.

Bonnet Cap

Bonnet cap incorporates travel stop to help control downstream pressure in the unlikely event of a regulator malfunction.

Large Bonnet Vent

Large vent is equipped with protective screen and threaded for 1/4" F. NPT vent piping. Large vent helps prevent ice from building up and blocking the vent during inclement weather. The regulator should be installed with vent down and the vent protected against blockage.

Typical of the 1580 Industrial High Pressure Regulators

The pounds-to-pounds, industrial regulator gives higher delivery pressure as tank pressure decreases, thus permitting full use of the gas in the tank. Most units are field adjustable to meet changing conditions.

Connections


Machined and threaded into the body forging; also includes 1/4" NPT pressure gauge ports.

Seat Disc

Synthetic rubber assembly attached directly to the diaphragm assembly to ensure proper movement and regulation.

Back Cap Spring

Provides added upward force to help provide a positive lock-up.



Adjusting Assembly

Large handle with lock-nut release allows easy resetting of delivery pressure.

Integral O-Ring

Minimizes tendency to vibrate or hum under extreme loads.

Sensitivity

In those cases where there is a choice of delivery pressure ranges, the **lowest** spring range which will fulfill your requirements is recommended because the sensitivity of a regulator decreases as the range of the adjusting spring increases.

Relief Valves

Most high pressure regulators are not equipped with integral relief valves. For certain applications where it is desirable to protect equipment downstream of the regulator, relief valves must be installed in the line.

Compact First Stage Regulators LV3403TR

Application



Ideal for use as a first stage regulator on any domestic size ASME or DOT container in propane gas installations requiring up to 1,500,000 BTU's per hour. The regulator is factory set to reduce container pressure to an intermediate pressure of approximately 10 PSIG.

Features

- Compact design can be connected to a service valve using either a POL adapter or a RegO product pigtail.
- Large threaded $\frac{3}{8}$ " F.NPT bonnet vent can easily be piped-away underground installations without the need of glue kits or extra adapters.
- Non Adjustable
- Large flow orifice resists freeze ups due to water concentration in LPG vapor.
- Design provides for good flow regulation at both high and low container pressures.
- Built in relief valve and travel stop comply with NFPA 58 over pressure requirements.
- Incorporates $\frac{1}{8}$ " F.NPT downstream pressure tap for an easy inline check of the regulator's delivery pressure.
- Molded diaphragm provides an o-ring type seal between the body and bonnet.
- Body and bonnet are assembled in the USA using the unique, patented RegUlok seal system.
- Fully painted in brilliant red for complete corrosion protection.
- Mounting bracket available as an accessory: part number 2302-31.

Materials

Body Zinc
Bonnet Zinc
Spring Steel
Seat Disc Resilient Rubber
Diaphragm Integrated Fabric and Synthetic Rubber



Ordering Information

Part Number	Inlet Connection	Outlet Connection	Orifice Size	Factory Delivery Pressure	Bonnet Vent Position	Vapor Capacity BTU/hr Propane*
LV3403TR	$\frac{1}{4}$ " F.NPT	$\frac{1}{2}$ " F.NPT	$\frac{1}{4}$ "	10 PSIG	Over Outlet	1,500,000
LV3403TRV9					9:00	

* Maximum flow based on inlet pressure 20 PSIG higher than the regulator setting and delivery pressure 20% lower than the regulator setting and delivery pressure 20% lower than the setting.

High Pressure First Stage Regulators LV4403SR and TR Series

Application


Provides accurate first stage regulation in two-stage bulk tank systems. Reduce tank pressure to an intermediate pressure of 5 to 10 PSIG. Also used to supply high pressure burners for applications like industrial furnaces or boilers. Also incorporated in multiple cylinder installations.

Features


- Incorporate integral relief valves for added system protection.
- Large vent helps prevent blockage and has ¼" F.NPT thread for vent piping.
- Bonnet vent positioned over outlet to avoid icing and contamination by foreign material.
- Unique bonnet vent profile designed to minimize vent freeze over when properly installed.
- Replaceable valve orifice and valve seat disc.
- Straight-line valve closure reduces wear on seat disc.
- Large molded diaphragm is extra sensitive to pressure changes.
- Built in pressure tap has plugged 1/8" F.NPT outlet.
- Plug can be removed with a 3/16" hex allen wrench.
- Extra long lever arm provides uniform delivery pressure.
- Brilliant red finish.

Materials


Body Die Cast Zinc
Bonnet Die Cast Zinc
Nozzle Orifice Brass
Spring Steel
Valve Seat Disc Resilient Rubber
Diaphragm Integrated Fabric and Synthetic Rubber



LV4403SR



LV4403TR



Ordering Information

Part Number	Inlet Connection	Outlet Connection	Orifice Size	Factory Delivery Pressure	Adjustment Range* (PSIG)	Integral Relief Included	Vapor Capacity BTU/hr Propane**
LV4403SR4	½" F. NPT	½" F. NPT	¼"	5	1-5	Yes	2,500,000
LV4403TR4				10	5-10		
LV4403SR9	F. POL	¾" F.NPT		5	1-5		
LV4403TR9				10	5-10		
LV4403SR96				5	1-5		
LV4403TR96				10	5-10		

* When used for final stage pressure control, must either incorporate integral relief valve or separate relief valve should be specified in accordance with NFPA Pamphlet 58.

** Maximum flow based on inlet pressure 20 PSIG higher than the regulator setting and delivery pressure 20% lower than the setting.

Low Pressure Second Stage Regulators LV4403B Series

Application


Designed to reduce first stage pressure of 5 to 20 PSIG down to burner pressure, normally 11" w.c. Ideal for medium commercial installations, multiple cylinder installations and normal domestic loads.

Features

- Large vent helps prevent blockage and has 1/2" F.NPT for vent piping.
- With 15 PSIG inlet pressure, regulator is designed to not pass more than 2 PSIG with the seat disc removed.
- Incorporates integral relief valves.
- Replaceable valve orifice and valve seat disc.
- Straight line valve closure reduces wear on seat disc.
- Unique bonnet vent profile minimizes vent freeze over when properly installed.
- Large molded diaphragm is extra sensitive to pressure changes.
- Built in pressure tap has plugged 1/8" F.NPT outlet. Plug can be removed with a 3/16" hex allen wrench.
- Select brown finish.

Backmount Design

Mounts directly to house line piping. Eliminates need for union joints, elbows, and mounting brackets. Quick and easy to install.




Materials

Body	Die Cast Zinc
Bonnet	Die Cast Zinc
Nozzle Orifice	Brass
Spring	Steel
Valve Seat Disc	Resilient Rubber
Diaphragm	Integrated Fabric and Synthetic Rubber



LV4403B Series



Ordering Information

Part Number	Inlet Connection	Outlet Connection	Orifice Size	Factory Delivery Pressure	Adjustment Range	Bonnet Vent Position	Vapor Capacity BTU/hr. Propane**
LV4403B4	1/2" F. NPT	1/2"	#28 Drill	11" w.c. at 10 PSIG Inlet	9" to 13" w.c.	Over Inlet	935,000
LV4403B46		1/2"					
LV4403B46R*		3/4" F. NPT					
LV4403B66	3/4" F. NPT	3/4" F. NPT	#28 Drill	11" w.c. at 10 PSIG Inlet	9" to 13" w.c.	Over Inlet	935,000
LV4403B66R*							

* Backmount design

** Maximum flow based on 10 PSIG inlet and 9" w.c. delivery pressure.

Low Pressure Second Stage Regulators LV4403B66RA Series

Application


Designed to reduce first stage pressure of 5 to 20 PSIG down to burner pressure, normally 11" w.c. Ideal for medium commercial installations, vapor meter installations and normal domestic loads.

Features

- 90 degree right angle inlet to outer connection for meter or standard installations.
- Large vent helps to prevent blockage and has 3/4" F. NPT for vent piping.
- With 15 PSIG inlet pressure, regulator is designed to not pass more than 2 PSIG with the seat disc removed.
- Replaceable valve orifice and valve seat.
- Straight line valve closure reduces wear on seat disc
- Unique bonnet vent profile minimizes vent freeze over when properly installed.
- Large molded diaphragm is extra sensitive to pressure changes.
- Built in pressure tap has plugged 1/8" F. NPT outlet. Plug can be removed with a 3/16" hex allen wrench.
- Select Brown Finish


Right Angle Design

Can mount directly to vapor meter. It is also suitable for mounting directly to the house piping. It will retrofit into existing installations that are currently using a 90 degree, right angle regulator.



Materials

Body Die Cast Zinc
Bonnet Die Cast Zinc
Nozzle Orifice Brass
Spring Steel
Valve Seat Disc Resilient Rubber
Diaphragm Integrated Fabric and Synthetic Rubber



Ordering Information

Part Number	Inlet Connection	Outlet Connection	Orifice Size	Factory Delivery Pressure	Adjustment Range	Bonnet Vent Position	Vapor Capacity BTU/hr. Propane*
LV4403B66RA	3/4" F. NPT	3/4" F. NPT	3/16"	11" w.c. at 10 PSIG Inlet	9" to 13" w.c.	Over Inlet	1,000,000
LV4403B66RAB**							

* Maximum flow is based on 10 PSIG inlet and 9" w.c. delivery pressure.**

** Mounting Bracket Included.

Low Pressure Second Stage Regulators LV5503B Series

Application

Designed to reduce first stage pressure of 5 to 20 PSIG down to burner pressure, normally 11" w.c. Ideal for larger commercial and industrial applications, multiple cylinder installations and large domestic systems.


Features

- Incorporates integral relief valve.
- With 15 PSIG inlet pressure, regulator is designed to not pass more than 2 PSIG with the seat disc removed.
- Replaceable valve orifice and valve seat disc.
- Straight line valve closure saves wear on seat disc and orifice.
- Built in pressure tap has plugged 1/8" F.NPT outlet. Plug can be removed with a 3/16" hex allen wrench.
- Large bonnet vent profile minimizes vent freeze over when properly installed.
- Extra long lever arm for uniform delivery pressure.
- Large diaphragm is extra sensitive to pressure changes.


Materials

Body (LV5503B Series) Die Cast Aluminum
Bonnet (LV5503B Series) Die Cast Aluminum
Nozzle Orifice Brass
Spring Steel
Valve Seat Disc Resilient Rubber
Diaphragm Integrated Fabric and Synthetic Rubber


LV5503B Series



LV5503B8



LV5503B4, LV5503B6



Ordering Information

Part Number	Inlet Connection	Outlet Connection	Orifice Size	Factory Delivery Pressure	Adjustment Range	Bonnet Vent Position	Vapor Capacity BTU/hr. Propane
LV5503B4	½" F. NPT	¾" F. NPT	¼"	11" w.c. at 10 PSIG Inlet	9" - 13" w.c.	Over Inlet	1,600,000
LV5503B6	¾" F. NPT						1" F. NPT
LV5503B8							

Maximum flow is based on 10 PSIG inlet and 9" w.c. delivery pressure.

Second Stage Regulators for 2 PSI Systems LV4403Y and LV5503Y Series

Application

Designed to reduce first stage pressure of 10 PSIG down to 2 PSIG. A line pressure regulator is required downstream to reduce the 2 PSIG to a nominal 11" W.C.

Features


- Large vent helps prevent blockage and has 3/4" F.NPT for vent piping.
- With 15 PSIG inlet pressure, regulator is designed to not pass more than 5 PSIG with the seat disc removed.
- Incorporates an integral relief valve.
- Replaceable valve orifice and valve seat disc.
- Straight line valve closure reduces wear on seat disc.
- Unique bonnet vent profile minimizes vent freeze over when properly installed.
- Large molded diaphragm is extra sensitive to pressure changes.
- Built in pressure tap has plugged 1/8" F.NPT outlet. Plug can be removed with a 3/16" hex allen wrench.
- Select blue finish.

*Backmount Design

Mounts directly to house line piping. Eliminates need for union joints, elbows, and mounting brackets. Quick and easy to install.

Materials




Body (LV4403Y Series)	Die Cast Zinc
Body (LV5503Y Series)	Die Cast Aluminum
Bonnet (LV4403Y Series)	Die Cast Zinc
Bonnet (LV5503Y Series)	Die Cast Aluminum
Nozzle Orifice	Brass
Spring	Steel
Valve Seat Disc	Resilient Rubber
Diaphragm	Integrated Fabric and Synthetic Rubber



LV4403Y Series

LV5503Y Series

LV4403Y4, LV4403Y46R



Ordering Information

Part Number	Inlet Connection	Outlet Connection	Orifice Size	Adjustment Range	Bonnet Vent Position	Vapor Capacity BTU/hr. Propane***
LV4403Y4	1/2" F. NPT	1/2" F. NPT	1/4"	2 PSIG @ 10 PSIG Inlet	Over Inlet	1,000,000
LV4403Y46R*	1/2" F. NPT	3/4" F. NPT	1/4"	2 PSIG @ 10 PSIG Inlet	Over Inlet	1,000,000
LV5503Y6	3/4" F. NPT	3/4" F. NPT	1/4"	2 PSIG @ 10 PSIG Inlet	Over Inlet	2,200,000
LV5503Y8	3/4" F. NPT	1" F. NPT	9/32"	2 PSIG @ 10 PSIG Inlet	Over Inlet	2,200,000

Maximum flow is based on 10 PSIG inlet pressure and 1.5 PSIG delivery pressure.


Low Pressure Second Stage Tobacco Barn Regulator LV5503G4 Series

Application

Especially developed for drying barns in the tobacco industry. The LV5503G4 regulator will supply a steady and constant flow of fuel to as many as 12 to 20 burners throughout the barn.

Features


- Similar to construction of the LV5503B Series. Provides the same stability, low lock-up, and sensitive performance.
- Equipped with integral relief valve.
- Built in pressure tap has plugged 1/8" F.NPT outlet. Plug can be removed with a 3/16" hex allen wrench.
- Distinctive yellow finish.



Materials

Body	Die Cast Aluminum
Bonnet	Die Cast Aluminum
Nozzle Orifice	Brass
Spring	Steel
Valve Seat Disc	Resilient Rubber
Diaphragm	Integrated Fabric and Synthetic Rubber

LV5503G4 Series




Ordering Information

Part Number	Inlet Connection	Outlet Connection	Orifice Size	Factory Delivery Pressure	Adjustment Range	Bonnet Vent Position	Vapor Capacity BTU/hr. Propane*
LV5503G4	1/2" F. NPT	3/4" F. NPT	1/4"	15" w.c. at 15 PSIG Inlet	8" - 18" w.c.	Above Inlet	1,750,000

Maximum flow is based on 15 PSIG inlet pressure and 13" w.c. delivery pressure.

Large Capacity Second Stage Regulators LV6503B Series



Application

These regulators are designed to reduce gas pressure from the first stage regulator down to appliance pressure, normally 11" w.c. They are for use in LP-Gas applications.

Features

- Tee style inlet and outlet connections – made from ductile iron.
- Incorporate integral large 2" F.NPT relief vents.
- Built in pressure taps for both inlet and outlet pressure.
- Full capacity relief at 10 psig inlet will keep the down stream pressure at less than 2 PSIG per NFPA 58.

Materials

Inlet Body	Ductile Iron
Body	Cast Aluminum
Bonnet	Cast Aluminum

Ordering Information

Part Number	Inlet Connection	Outlet Connection	Orifice Size	Factory Delivery Pressure	Adjustment Range	Bonnet Vent Position	Vapor Capacity BTU/hr. Propane
LV6503B14	1 1/2" F. NPT	1 1/2" F. NPT	5/8"	11" w.c. at 10 PSIG Inlet	8 1/2" - 14" w.c.	Over Inlet	8,000,000
LV6503B16	2" F. NPT	2" F. NPT					9,750,000

* Maximum flow is based on 10 PSIG inlet and 20% droop.

Compact Twin Stage Regulators LV404B4 and LV404B9 Series

Application

This compact two-stage regulator is designed to reduce container pressure down to 11" w.c. delivery pressure. It is ideal for "on-site" cylinder applications, mobile homes and average domestic service including small ASME and 100 to 420 pound DOT cylinders.

Features

- Incorporates integral relief valve.
- With 15 PSIG inlet pressure, regulator is designed to not pass more than 2 PSIG with the seat disc removed.
- Large vent helps prevent blockage and has 3/4" F. NPT for vent piping.
- Compact size allows for easy installation — especially under container hoods and within collars.
- Vent on the first stage is consistently in the down position.
- Built in pressure taps on both first and second stage regulators have plugged 1/8" F.NPT outlets. Plugs can be removed with a 3/16" hex allen wrench.
- Select brown finish.




Materials

Body (First Stage)..... Zinc or Brass
Body (Second Stage) Die Cast Zinc
Nozzle Orifice Brass
Spring Steel
Valve Seat Disc Resilient Rubber
Diaphragm Integrated Fabric and Synthetic Rubber

LV404B4

LV404B4V9

LV404B9



Ordering Information

Part Number	Inlet Connection	Outlet Connection	Orifice Size	Factory Delivery Pressure	Adjustment Range 2nd Stage	Bonnet Vent Position 1st Stage	Bonnet Vent Position 2nd Stage	Capacity BTU/hr. Propane*	Accessories
									1st Stage Vent Pipe-Away
LV404B4	¼" F. NPT	½" F. NPT	.219	11" w.c. at 100 PSIG Inlet	9" - 13" w.c.	Down	Over Outlet	525,000	404PE
LV404B4V9						9 o'clock	9 o'clock		
LV404B46		¾" F. NPT				Down	Over Outlet		
LV404B46V9						9 o'clock	9 o'clock		
LV404B9	F. POL	½" F. NPT				Down	Over Outlet		
LV404B9V9						9 o'clock	9 o'clock		
LV404B96		¾" F. NPT				Down	Over Outlet		
LV404B96V9						9 o'clock	9 o'clock		

Maximum flow is based on 25 PSIG inlet pressure and 9" w.c. delivery pressure.

New Compact Twin Stage Regulators for LP-Gas LV404B34 & LV404B39 Series

Application

The compact twin-stage regulator is designed to reduce container pressure down to 11" w.c. delivery pressure. It is ideal for "on site" container applications such as homes, mobile homes and cottages for average domestic service; including small ASME tanks and 100-420 pound DOT cylinders.

Features

- Large vent helps prevent vent blockage, the second stage regulator bonnet is tapped for 3/8" F.NPT for vent piping, the high pressure regulator is tapped with 1/8" F.NPT for vent piping.
- With 15 PSIG inlet pressure, the regulator is designed to not pass more than 2 PSIG downstream with the seat disc removed.
- Incorporates an integral relief valve on second stage.
- Unique bonnet vent profile minimizes vent freeze over when properly installed.
- Compact design saves space allows for easy installation – especially under container hoods with collars.
- Built in pressure taps 1/8" F.NPT on both high pressure regulator inlet and downstream side of the second stage regulator.
- Plugs can be removed with a 3/16" hex Allen wrench.
- Select brown finish.

Materials



Body First Stage (LV404B39) Brass
Body First Stage (LV404B34) Die Cast Zinc
Bonnet Second Stage Die Cast Zinc
Diaphragms Integrated Fabric and Synthetic Rubber
Springs Steel and Stainless Steel
Valve Discs Resilient Synthetic Rubber



LV404B39



LV404B34



Ordering Information

Part Number	Inlet Connection	Outlet Connection	Orifice Size	Factory Delivery Pressure	Adjustment Range 2nd Stage	Bonnet Vent Position 1st stage **	Bonnet Vent Position 2nd stage**	Vapor Capacity BTU/hr *	
LV404B34	¼" F.NPT	½" F.NPT	.100	11" w.c. @ 100 Psig Inlet	9" to 13"w..c.	Rear	Outlet	450,000	
LV404B39	F.POL					Left	9:00		
LV404B34V9	¼" F.NPT								
LV404B39V9	F.POL								

* Maximum flow based on 10 PSIG Inlet 9" w.c. delivery pressure

** Other vent positions available upon request

A22

Twin Stage Automatic Changeover Regulators 7525B Series


Application

These combination automatic changeover, two stage regulators are especially suitable for homes, mobile homes, cottages, construction and other portable two cylinder installations. Empty containers may be replaced without interrupting customer's gas service.

Features

- Automatic changeover switches from "service" to "reserve" cylinder automatically without interrupting service.
- The Second Stage Incorporates wide bonnet drip lip vent to guard against freeze-up when properly installed.
- With 15 PSIG inlet pressure the second stage, regulator is designed to not pass more than 2 PSIG with the seat disc removed.
- Allows "reserve" cylinder to supplement the flow of gas from the "service" cylinder during extreme load or severe cold conditions.
- Incorporates molded diaphragm in second stage regulators.
- Integral indicator gauge.
- Change over knob and indicator are integral to the first stage.
- Select brown finish on first stage.

7525B4




Materials

Body (First Stage)	Die Cast Zinc
Body (Second Stage)	Die Cast Zinc
Bonnet First Stage	Die Cast Zinc
Bonnet, Second Stage	Die Cast Zinc
First Stage Nozzle Orifice	Brass
Springs	Steel
Valve Seat Discs	Resilient Rubber
Diaphragms	Integrated Fabric and Synthetic Rubber



7525B34

New Photo Needed



Ordering Information

Kit Number	Automatic Changeover Regulator Included	Inlet	Outlet	Pigtails Included-2	Bracket Included	Capacity BTU/hr. Propane
5726B34	7525B34	1/4" Inverted Flare	1/2" F. NPT	912FA20	2302-31	400,000
5727B34	7525B34			912FS20		
5754B4	7525B4			912FA20	2503-22	450,000
5755B4	7525B4			912FS20		

Maximum flow is based on 25 PSIG inlet pressure and 9" w.c. delivery pressure.

Two PSIG Delivery Pressure Twin-Stage Regulator LV404Y9

Application

SPECIAL 2 PSIG DELIVERY pressure twin stage regulator is designed to reduce container pressure down to 2 PSIG. A line pressure regulator is required downstream to reduce the 2 PSIG to a nominal 11" W.C.

Features




- Incorporates integral relief valve in the 2 PSIG stage portion of the regulator.
- Designed to pass not more than 5 PSIG with the seat disc removed.
- Large vent helps prevent blockage and has a 3/4" F.NPT for vent piping.
- Compact size for easy installation.
- Built in pressure taps for both the 10 PSIG regulator and 2 PSIG regulator, Plugs can be removed with a 3/16" hex Allen wrench.
- Select Blue Finish to designate 2 PSIG delivery pressure for 2-pound systems.

Materials

Body (First Stage)..... Brass
Body (2 PSIG Stage) Die Cast Zinc
Bonnet, Second Stage Die Cast Zinc
Diaphragms Integrated Fabric and Synthetic Rubber
Springs Steel and Stainless Steel
Valve Discs Resilient Rubber



LV404Y9



Ordering Information

Part Number	Inlet Connection	Outlet Connection	Orifice Size	Factory Delivery Pressure (PSIG)	Adjustment Range (PSIG)	Bonnet Vent Position 1st Stage	2 PSIG Bonnet Vent Position	Capacity BTU/HR*
LV404Y9	F.POL (CGA 510)	1/2" F.NPT	.219	2	1.8 to 2.5	Down	Outlet	800,000

Maximum flow is based on 25 PSIG inlet pressure and 1.5 PSIG delivery pressure.

Two Stage Regulator Outfits 5807, 5808, 5820 Series

Application

These outfits contain the equipment required to provide two-stage regulation.

Features

- Includes a new pigtail. This helps ensure that a new pigtail is installed along with the regulator.
- Features, designs, and performance characteristics of the individual components may be found under the appropriate section of this catalog.

Ordering Information

Kit Number	1st Stage Regulator Included		2nd Stage Regulator Included		Bracket Included	Pigtail Included	Capacity BTU/hr. Propane
	Part Number	Inlet x Outlet Female	Part Number	Inlet x Outlet F. NPT			
5807	LV4403TR9	POL x ½" NPT	LV4403B4	½" x ½"	2503-22	913PS12	935,000
5808			LV4403B46R	½" x ¾"	Not Required		
5820	LV4403TR96	POL x ¾" NPT	LV4403B66R	¾" x ¾"			

LV4403TR9

LV4403B Series



913PS12



2503-22



Twin Stage Regulator Outfits 5828 and 5832

Application

This outfit contains the equipment required to provide twin-stage regulation.

Features

- Includes a new pigtail. This helps ensure that a new pigtail is installed along with the regulator.
- Features, designs, and performance characteristics of the individual components may be found under the appropriate section of this catalog.

Ordering Information

Kit Number	Twin Stage Regulator Included	Inlet F. NPT	Outlet F. NPT	Pigtails Included	Capacity BTU / hr. Propane
5828	LV404B4	1/4"	1/2"	912JS12	525,000
5832	LV404B34V9				400,000

LV404B4

LV404B34V9



2503-22

912JS12



Automatic Changeover Regulator Outfits 5726B23, 5727B23, 5754B4, 5755B4

Application

This outfit contains the equipment required to provide twin-stage regulation.

Features

- Includes 2 new pigtails. This helps ensure that a new pigtail is installed along with the regulator.
- Features, designs, and performance characteristics of the individual components may be found under the appropriate section of this catalog.

Ordering Information

Kit Number	Automatic Changeover Regulator Included	Inlet	Outlet	Pigtails Included-2	Bracket Included	Capacity BTU/hr. Propane
5726B34	7525B34	1/4" Inverted Flare	1/2" F. NPT	912FA20	2302-31	400,000
5727B34	7525B34			912FS20		
5754B4	7525B4			912FA20	2503-22	450,000
5755B4	7525B4			912FS20		

7525B4



912FA20



Compact Regulators 302 Series

Application

These compact regulators are designed for smaller outdoor grills and fish cookers. It is intended for use on small portable appliances that use 100,000 BTU's/hr. or less. It may not be used on fixed pipe systems per NFPA 58, 1995 edition.

Features



- All metal, die cast construction.
- Molded diaphragms assure close control of burner pressure.
- Durable valve levers.
- Variety of model configurations and sizes available.
- All POL inlet connections are soft nose.

Materials

Body Die Cast Zinc
Bonnet Die Cast Zinc
Springs Steel
Valve Seat Discs Resilient Rubber
Diaphragms Molded Synthetic Rubber



302



302V



Ordering Information

Part Number	Type	Inlet Connection	Outlet Connection	Orifice Size	Factory Delivery Pressure	Adjustment Range	Bonnet Vent Position	Vapor Capacity BTU/hr. Propane*
302	Single Stage	1/4" F. NPT	3/8" F. NPT	No. 50 Drill	11" w.c. at 100 PSIG inlet	9-13" w.c.	Small Vent Above Inlet	125,000
302S		Soft M. POL w/60 DMS orifice						
302V		1/4" F. NPT					Drip Lip Above Inlet	
302V9		1/4" F. NPT					Drip Lip at 9 o'clock	
302V9LS		Soft POL w/o orifice						

Maximum flow is based on 25 PSIG inlet pressure and 9" w.c. delivery pressure.


High Pressure Industrial / Commercial Pounds-to-Pounds Regulators 597F Series

Application

Designed to reduce propane gas container pressure down to between 3 and 100 PSIG. Ideal for liquid or vapor service, they can be used in a variety of applications including salamander heaters, weed burning torches, fish cookers, tar pot heaters, and other industrial type services.



Features

- Provides high capacity performance at a reasonable price.
- Suitable for both liquid and vapor service.
- Compact design provides for easy installation.
- Negative or indirect acting design provides for excellent performance when needed most – in cold weather, when tank pressures are lowest and system demands are highest.
- Consistent delivery pressure, especially in cold weather, helps assure maximum performance from the second stage regulator.
- Can be readily fitted with a pressure gauge in the 1/4" F.NPT port.
- Molded diaphragm provides an o-ring like seal between the body and the bonnet.
- Fully painted in brilliant red for complete corrosion protection.
- Available in four adjustable ranges for maximum performance.
- Bonnet and body are assembled in the USA using the unique, patented RegULok™ Seal System.



Materials

Body	Zinc
Bonnet	Zinc
Springs	Steel
Valve Seat Discs	Resilient Rubber
Diaphragms	Integrated Fabric and Synthetic Rubber
Adjusting Screw	Brass



Ordering Information

Part Number	Adjustment Method	Inlet Connection	Outlet Connection	Recommended Delivery Pressure Range (PSIG)	Capacity Determined at Set Pressure of PSIG*	Capacity BTU/hr. Propane**
597FA	Tee Handle	1/4" NPT	1/4" NPT	1-15	10	1,750,000
597FB				10-30	20	3,000,000
597FC				20-45	30	3,500,000
597FD				40-100	40	4,500,000

* Set pressure established at 100 PSIG inlet and a flow of 250,000 BTU/hr.

** Capacity determined at actual delivery pressure 20% less than set pressure with inlet pressure 20 PSIG higher than the set pressure.

High Pressure Industrial / Commercial Pounds-to-Pounds Regulators 1580M Series and AA1580M Series



Application


Designed to reduce LP-Gas and anhydrous ammonia container pressures to between 3 and 125 PSIG. Precision-built with a multi-million BTU capacity, the 1580M series is perfect for such big, tough jobs as crop dryers, asphalt batch mixing plants, road building "tar wagons", heat treating and other large industrial and commercial loads. It's also ideal as a first stage regulator in large multiple operations. The AA1580M series is ideal for use in anhydrous ammonia applications such as blue print machines and heat treating.

Features

- Large nozzle and straight through flow provides high capacity and resistance to freeze-up.
- O-ring on retainer assembly provides a dampening effect to reduce vibration.
- Suitable for both liquid and vapor service.
- Can be readily fitted with pressure gauge in 1/4" F. NPT port.

Materials

Body Forged Aluminum
Bonnet Die Cast Aluminum
Spring Steel
Valve Seat Discs Resilient Rubber
Diaphragms Integrated Fabric and Synthetic Rubber






Ordering Information

Part Number	Service	Adjustment Method	Inlet & Outlet Connections	Recommended Delivery Pressure Range (PSIG)	A Width	B Height (max.)	Capacity Determined at Set Pressure of PSIG	Capacity**
AA1582MW	NH ₃	Tee Handle	¼" F. NPT	3-25	2 ⅜"	4⅝"	20	2,100 CFH NH ₃
AA1582MK		Hex Head		20-50			30	2,400 CFH NH ₃
AA1582ML				45-125			60	2,600 CFH NH ₃
AA1582MH								
1584VN	LP-Gas	Tee Handle	½" F. NPT	3-30	2 ⅝"	4⅞"	20	7,000,000 BTU/hr. LPG
1584VL				25-50			30	7,500,000 BTU/hr. LPG
1584VH				45-125			60	8,000,000 BTU/hr. LPG
AA1584VW	NH ₃			3-25			20	4,500 CFH NH ₃
AA1584VL				20-50			30	4,800 CFH NH ₃
AA1584VH				45-125			60	5,100 CFH NH ₃
1586VN	LP-Gas		¾" F. NPT	3-30	3 ½"	7"	20	11,000,000 BTU/hr. LPG
1586VL				25-50			30	12,000,000 BTU/hr. LPG
1586VH				45-125			60	14,000,000 BTU/hr. LPG
AA1586MW	NH ₃			3-25			20	7,000 CFH NH ₃
AA1586VL				20-50			30	7,700 CFH NH ₃
AA1586VH				45-125			60	8,900 CFH NH ₃
1588VN	LP-Gas		1" F. NPT	3-30			20	11,000,000 BTU/hr. LPG
1588VL				25-50			30	12,000,000 BTU/hr. LPG
1588VH				45-125			60	14,000,000 BTU/hr. LPG

* Set pressure is established with 100 PSIG inlet pressure and a flow of 500,000 BTU/hr. propane for 1580M Series, 90 CFH/hr. NH₃ for AA1582M Series and 180 CFH/hr. NH₃ for AA1584M and AA1586M Series.

** Capacities determined at actual delivery pressure 20% less than set pressure with inlet pressure 20 PSIG higher than set pressure.

NOTE: Care must be taken to prevent re-liquefaction of propane at normal temperatures by heat tracing or other effective means. Use of a relief valve upstream or downstream of these regulators is recommended in accordance with NFPA 58.



High Pressure / High Temperature Industrial / Commercial Pounds-to-Pounds Regulators X1584M, X1586M Series

Application

Designed to reduce LP-Gas container pressures to between 3 and 50 PSIG. Ideal for crop drying, heat treating, asphalt batch mixing and other large industrial and commercial load application utilizing high temperature LP-Gas or high temperature atmosphere under conditions up to 300°F. Also ideal as a first stage regulator in large multiple operations.

Features

- Special diaphragm and seat materials are suitable for up to 300°F. temperatures.
- Large nozzle and straight through flow provides high capacity and resistance to freeze ups.
- Suitable for both liquid and vapor service.
- Can be fitted with high pressure gauge in 1/4" F. NPT port. REGO® recommends that these gauges use silver braze rather than soft solder construction.

Materials

Body Forged Aluminum
Bonnet Die Cast Aluminum
Spring Stainless Steel
Diaphragms Integrated Fabric and Synthetic Rubber
Seat Discs High Temperature Resilient Composition
Backup Seal High Temperature Resilient Composition


Ordering Information

Part Number	Service	Adjustment Method	Inlet & Outlet Connections	Recommended Delivery Pressure Range (PSIG)	Capacity Determined at Set Pressure of PSIG*	Capacity BTU/hr. Propane**
X1584VN	LP-Gas	Tee Handle	1/2" F. NPT	3-30	20	7,000,000
X1584VL				25-50	30	7,500,000
X1586VN			3/4" F. NPT	3-30	20	11,000,000
X1586VL				25-50	30	12,000,000
X1588VN			1" F. NPT	3-30	20	11,000,000
X1588VL				25-50	30	12,000,000

* Set pressure is established with 100 PSIG inlet pressure and a flow of 500,000 BTU/hr. propane.

** Capacities determined at actual delivery pressure 20% less than set pressure with inlet pressure 20 PSIG higher than set pressure.

NOTE: Care must be taken to prevent re-liquefaction of propane at normal temperatures by heat tracing or other effective means. Use of a relief valve upstream or downstream of these regulators is recommended in accordance with NFPA 58.



Vapor Relief Valves 3139 Series

Application

Designed for use as a relief valve on first stage regulators that comply with the NFPA 58 2.5.7.5 exception: "first stage regulators with a rated capacity of more than 500,000 BTU/hr. shall be permitted to have a separate relief valve.

Features

- Pop-action design keeps product loss to a minimum.
- Suitable for use downstream of 1580 series regulators on vapor systems to comply with NFPA 58.
- May be installed on either the regulator pressure gauge port or on a fitting downstream from the regulator outlet.
- Constructed of non-corrosive brass.



3139-18



3139-26



3139-38



Part Number	Set Pressure	Regulator Settings	Connection Size	Height	Width	Flow Capacity at 120% of Set Pressure (SCFH Propane)
3139-18	18 PSIG	10 PSIG	1/4" M. NPT	2 27/32"	1 1/16"	1357*
3139-26	26 PSIG	15 PSIG				1725**
3139-38	38-PSIG	20 PSIG				2304***

* Flow recorded at 21.6 PSI inlet pressure for this valve.


** Flow recorded at 31.2 PSI inlet pressure for this valve.

*** Flow recorded at 45.6 PSI inlet pressure for this valve.

Copper Pigtails 912 and 913 Series

Straight Pigtails Ordering Information

Connections	Approximate Length	Part Number		
		1/4" Tube		3/8" Tube
		7/8" Hex Short Nipple	1 1/4" Hex Long Nipple	7/8" Hex Short Nipple
M.POL x M.POL	5"	-	1/2"	913JS05
	12"	912PS12	-	913PS12
	20"	912PS20	912PA20	913PS20
	30"	912PS30	-	913PS30
	36"	912PS36	912PA36	913PS36
	48"	912PS48	912PA48	913PS48
1/4" Inverted Flare x M.POL	12"	912FS12	-	-
	20"	912FS20	912FA20	-
	30"	912FS30	-	-
	36"	912FS36	-	-
1/4" M.NPT x M.POL	5"	-	-	913JS05
	12"	912JS12	-	-
	20"	912JS20	-	-
	36"	912JS36	-	-
1/2" M.NPT x M.POL	12"	-	-	913LS12
1/2" M.NPT x 3/8" M.NPT	12"	-	-	913KL12



Application

Pigtails are available in a variety of connections, sizes and styles. Care should always be taken in selecting the proper pigtail for a particular application.

Note: REGO® recommends a new pigtail be installed with every new and replaced regulator.

Features

- Heavy duty construction.
- Individually soldered connections to the copper tubing.
- Each pigtail is individually tested prior to shipment.

Materials

Tubing..... Copper
Connection Brass



Bent Pigtails Ordering Information

Connections	Approximate Length	Part Number	Type/Degree of Bend
		3/8" Tube	
		7/8" Hex Short Nipple	
1/4" M. NPT x M. POL	5"	913JS05A	90°
M. POL x M. POL	12"	913PS05A	
		913PS12G	270° Right Hand
		913PS12H	270° Left Hand
		913PS12S	360°

A

Inlet Fittings



These inlet fittings are available for assembly into either first stage of single stage regulators. All have 1/4" M. NPT connections and are machined from brass.

Part Number	Description
970	Hard nose POL with wrench nut.
970AX	Hard nose POL with wrench nut and excess flow.
970AXS	Soft nose POL with wrench nut and excess flow.
3199W	Heavy duty hard nose POL with wrench nut and excess flow.
970AW	Soft nose POL with Handwheel.
970HT	Soft nose POL with Handwheel and 60 DMS orifice.
970S	Soft nose POL with wrench nut and 60 DMS orifice.



3199W

Part Number	Length	1/8" Hex Male - POL Short Nipple	7/8" Hex Male - POL Short Nipple	1/4" Male NPT
612JS12	12"	X		X
612JS20	20"	X		X
612PS12	12"	X	X	
612PS20	20"	X	X	



Brackets

RegO® Brackets are especially designed for use in installing RegO® Regulators in applications requiring the use of a bracket.

Part Number	Material	For Use With Regulator Model:
2302-31	Cadmium Plated Steel	LV2302, LV3403, LV404B3
2503-22		LV404B4 LV404B9 Series, LV5503 Series
2503-19	Aluminum	LV4403 Series



2503-19



2503-22



2302-31

Manifolds

Tee Check Manifolds

1350R and 1450R

Application

For use in systems that require uninterrupted gas service during cylinder exchange. Especially for summer cottages, mobile homes and single appliance loads.

- Floating disc check minimizes discharge of gas to the atmosphere when empty cylinder is being replaced.

Features

- Floating disc check minimizes discharge of gas to the atmosphere when empty cylinder is being replaced.


Materials

Body Forged Brass
Seat Discs Resilient Rubber


Part Number	Inlet Connections	Outlet Connection
1350R	F. POL	M. POL
1450R	1/4" Inverted Flare	1/4" M. NPT



1350R



1450R



Multiple Cylinder Manifolds

1350E and 1450E

Application

Use with suitable pigtails to connect multiple cylinders together. Ideal for loads that require more than one cylinder to be in service at a time.

Features

- Provides a three-way tee function without an internal disc check.


Materials

Body Forged Brass


Part Number	Inlet Connections	Outlet Connection
1350E	F. POL	M. POL
1450E	1/4" Inverted Flare	1/4" M. NPT



1350E



1450R



Test Kits

Low Pressure Test Set

2434A Series

This kit provides the equipment necessary for checking regulator delivery pressure (low pressure) at the appliances. The basic set contains a 2424A-2 low pressure gauge and a 3 foot — $\frac{3}{16}$ " O.D. flexible synthetic rubber tube. Adapters are also available.

Part Number	Contents	Adapters
2434A	Test Kit	1328
		1331
		1332



2434A



1328 Adapter

Water Manometer Kit

1212 Kit

Application

The water manometer kit is especially suited for use with low pressure LP-Gas systems. It is ideal for pressure checks downstream of the low pressure regulator and at the appliances.

Features

- Flexible tube rolls up for convenient storage with accessories in compact carry case.
- Magnetic clips allow easy attachment to metal surfaces.
- Flexible spring steel scale is calibrated in inches of water column for reading to 16" w.c.
- Molded nylon tubing connectors incorporate a rapid shut-off design in an unbreakable molded top.
- Rapid pressure safety trap prevents loss of fluid due to pressure surges on both columns.
- Scale is center mounted between columns to eliminate parallax error and has a full two-inch sliding zero adjustment.

Contents

- 1—Flexible water manometer which reads up to 16" w.c. of pressure.
- 1—Heavy duty, compact carrying case.
- 1— $\frac{3}{4}$ oz. bottle of Fluorescein Green color concentrate.
- 2— $\frac{1}{8}$ " pipe thread barbed tubing adapters.
- 1—3 foot, $\frac{3}{16}$ " rubber tube.
- 1—Rubber tubing adapter and $\frac{7}{16}$ " spud.



Part Number	Description
1212 KIT	Flexible Tube Water Manometer Kit

Accessories


High Pressure Gauge Adapter

2962



Designed for testing high pressure lines. Adapter has 0 to 300 PSIG gauge. A bleeder valve allows you to bleed down to correct pressure during pressure tests.

Part Number	Inlet Connection	Outlet Connection	Pressure Gauge Range (PSIG)
2962	Soft Nose M. POL	F. POL	0 - 300



2962

Adhesive Warning Labels

These adhesive warning labels are intended for application as close as possible to the LP-Gas regulator once the regulator has been installed.

Part Number	Description
LV4403-400	Adhesive Warning Label

DANGER

WARNING

**LP-GAS IS EXTREMELY
FLAMMABLE AND EXPLOSIVE**

AVOID SERIOUS INJURY AND PROPERTY DAMAGE. IF YOU SEE, SMELL, OR HEAR ESCAPING GAS... EVACUATE AREA IMMEDIATELY! CALL YOUR LOCAL FIRE DEPARTMENT! DO NOT ATTEMPT TO REPAIR. DO NOT STORE IN BUILDING OR ENCLOSED AREA. DO NOT USE ON HOT AIR BALLOONS OR AIRCRAFT.

Insist that your LP-Gas dealer regularly inspect and maintain this installation and properly instruct you in safety matters.

Make sure ice, snow drifts, dirt, bugs and other foreign material do not obstruct vent passage-ways and openings. The vent opening must have a screen installed. If screen is missing, call your gas dealer for immediate examination and replacement.

DO NOT REMOVE, DEFACE OR OBLITERATE THIS LABEL.
DO NOT FILL CONTAINER UNLESS THIS LABEL IS READABLE.

ADDITIONAL SAFETY INFORMATION IS AVAILABLE FROM

REGO

Printed in U.S.A. 04-0994-1189
Part Number LV4403-400

100 RegO Drive PO Box 247 Elon College, NC 27244 USA Phone (336) 449-7707 Fax (336) 449-6594 www.regoproducts.com

Warning Notice

The following warning information, Part Number LV4403-500, is included with each shipment of regulators to the first purchaser of the product from the factory.

This information is intended to be forwarded throughout the product distribution chain. Additional copies are available from REGO® and Authorized Product Distributors.

DANGER READ THIS FIRST WARNING

LP-GAS IS EXTREMELY FLAMMABLE AND EXPLOSIVE

AVOID SERIOUS INJURY AND PROPERTY DAMAGE. IF YOU SEE, SMELL OR HEAR ESCAPING GAS... EVACUATE AREA IMMEDIATELY! CALL YOUR LOCAL FIRE DEPARTMENT! DO NOT ATTEMPT TO REPAIR. DO NOT STORE IN BUILDING OR ENCLOSED AREA. DO NOT USE ON HOT AIR BALLOONS OR AIRCRAFT.

Make sure you are thoroughly trained before you attempt any regulator installation or maintenance. Improper conditions or procedures can cause accidents resulting in property damage and personal injury.

Become thoroughly familiar with NPGA Safety Pamphlet 306 "LP-Gas Regulator and Valve Inspections & Maintenance" and ECIL "Safety Warning LP-Gas Regulators" found in the regulator section of the L-500 & L-102 Catalogs. Follow its recommendations.

Know and understand NFPA Pamphlet 58 "Liquefied Petroleum Gas Code", which is the law in many states. This publication is available from NFPA, Batterymarch Park, Quincy, MA 02269. Following its requirements is essential in the safe use of LP-Gas. Section 4.4 states: persons who transfer liquid LP-Gas, who are employed to transport LP-Gas, or whose primary duties fall within the scope of this code shall be trained in proper handling procedures. Refresher training shall be provided at least every three years and shall be documented.

Pamphlet 58 also states that "All regulators for outdoor installations, except regulators used for portable industrial applications, shall be designed, installed or protected so their operation will not be affected by the elements (freezing rain, sleet, snow, ice, mud or debris). This protection may be integral with the regulator."

Vents must be clear and fully open at all times. An obstructed vent will prevent the regulator from functioning properly and may result in property damage and personal injury.

Regulators should be installed with the vent facing down or otherwise covered for protection.

Twin-Stage Regulators should be installed completely under cover and/or with screened vent pipe away adapters that position both vents in a down position without obstructing flow through the vents.

Make sure piping is clean and free from foreign material (such as dirt, corrosion, chips, pipe joint compound, etc.) Always replace the pigtail when replacing a regulator. Thread sealant used on piping must be compatible with LP-Gas.

Make sure the use and location of the regulator(s) as a component(s) of the LP-Gas system to be installed is proper. (Avoid misusing LP-Gas equipment.) See the following ECIL publications: L-500 & L-102 Catalogs and the LP-Gas Serviceman's manual.

For underground installations, make sure that water, mud, dirt, and insects cannot get into the regulator, and that the regulator is easily accessible for regulator maintenance. Follow NPGA Bulletin 401. See ECIL "Safety Warning LP-Gas Regulators" found in the regulator section of the L-500 & L-102 Catalogs.

Check regulator and installation for leaks following NFPA #54 and NPGA Bulletin 403 "Pressure Testing and Leak Checking LP-Gas Piping Systems".

In selecting a label for posting at the installation site, consider ECIL "part number 2403-400 along with your own, NPGAs and others.

Remember to instruct the owner/user/customer in safety matters concerning LP-Gas and this equipment. See ECIL "Safety Warning LP-Gas Regulators" found in the regulator section of the L-500 & L-102 Catalogs.

Engineered Controls International, Inc., ECIL "requests that this information be forwarded to your customers. Additional copies are available from ECIL " and your authorized ECIL " Product Distributor.

REGO

Printed in USA 07-0809-0390 Part number LV4403-500

100 RegO Drive PO Box 247 Elon, NC 27244 USA Phone (336) 449-7707 Fax (336) 449-6594 www.re goproducts.com

Cross Reference by Part Number

302.....	A26	AA1582MH.....	A28	LV4403SR4.....	A15
302S.....	A26	AA1582MK.....	A28	LV4403TR4.....	A15
302V.....	A26	AA1582ML.....	A28	LV4403Y4.....	A19
302V9.....	A26	AA1582MW.....	A28	LV4403SR9.....	A15
302V9LS.....	A26	1584VH.....	A28	LV4403TR9.....	A15
LV404B4.....	A21	1584VL.....	A28	LV4403B46.....	A16
LV404B9.....	A21	1584VN.....	A28	LV4403B46R.....	A16
LV404Y9.....	A24	AA1584VH.....	A28	LV4403Y46R.....	A19
LV404B34.....	A22	AA1584VL.....	A28	LV4403B66.....	A16
LV404B39.....	A22	AA1584VW.....	A28	LV4403B66R.....	A16
LV404B46.....	A21	X1584VL.....	A29	LV4403B66RA.....	A17
LV404B4V9.....	A21	X1584VN.....	A29	LV4403B66RAB.....	A17
LV404B96.....	A21	1586VH.....	A28	LV4403SR96.....	A15
LV404B9V9.....	A21	1586VL.....	A28	LV4403TR96.....	A15
LV404B34V9.....	A22	1586VN.....	A28	LV4403-400.....	A34
LV404B39V9.....	A22	AA1586VH.....	A28	LV5503B4.....	A18
LV404B46V9.....	A21	AA1586VL.....	A28	LV5503G4.....	A20
LV404B96V9.....	A21	AA1586MW.....	A28	LV5503B6.....	A18
597FA.....	A27	X1586VL.....	A29	LV5503Y6.....	A19
597FB.....	A27	X1586VN.....	A29	LV5503B8.....	A18
597FC.....	A27	1588VH.....	A28	LV5503Y8.....	A19
597FD.....	A27	1588VL.....	A28	5726B23.....	A23
612.....	J19	1588VN.....	A28	5726B23.....	A25
612JS12.....	A31	X1588VL.....	A29	5727B23.....	A23
612PS12.....	A31	X1588VN.....	A29	5727B23.....	A25
612JS20.....	A31	2302-31.....	A32	5754B4.....	A23
612PS20.....	A31	2434A.....	A33	5754B4.....	A25
970AW.....	A31	2503-19.....	A32	5755B4.....	A23
970AX.....	A31	2503-22.....	A32	5755B4.....	A25
970AXS.....	A31	2962.....	A34	5807.....	A25
970HT.....	A31	3139-18.....	A30	5808.....	A25
970S.....	A31	3139-26.....	A30	5820.....	A25
1212 KIT.....	A33	3139-38.....	A30	5828.....	A25
1350E.....	A32	3199W.....	A31	5832.....	A25
1350R.....	A32	LV3403TR.....	A14	LV6503B14.....	A20
1450E.....	A32	LV3403TRV9.....	A14	LV6503B16.....	A20
1450R.....	A32	LV4403B4.....	A16		



LP-Gas & Anhydrous Ammonia Equipment

B

Section B Cylinder and Service Valves

Limited Warranty and Limitation of Liability

LIMITED 10 YEAR WARRANTY AND LIMITATION OF LIABILITY

LIMITED 10 YEAR WARRANTY

REGO® warrants to the original purchasers the products and repair kits manufactured by it to be free from defects in materials and workmanship under normal use and service for a period of 10 years from the date of manufacture. If within thirty days after buyer's discovery of what buyer believes is a defect, buyer notifies in writing and ships the product to REGO® at 100 Rego Drive, Elon, NC 27244, REGO®, at its option, and within forty-five days of receipt, will repair, replace F.O.B. point of manufacture, or refund the purchase price of that part or product found by REGO® to be defective. Failure of buyer to give such written notice and ship the product within thirty days shall be deemed an absolute and unconditional waiver of any and all claims of buyer arising out of such defect.

This warranty does not extend to any product or part that is not installed and used continuously after installation in accordance with REGO®'s printed instructions, all applicable state and local regulations, and all applicable national standards, such as those promulgated by NFPA, DOT and ANSI. This warranty does not extend to any product or part that has been damaged by accident, misuse, abuse, failure to maintain, or neglect, nor does it extend to any product or part which has been modified, altered, disassembled, or repaired in the field. This warranty does not cover any cosmetic issues, such as scratches, dents, marring, fading of colors or discoloration.

Except as expressly set forth above, and subject to the limitation of liability below, REGO® MAKES NO OTHER WARRANTY, EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, with respect to its products and parts, whether used alone or in combination with others. REGO® disclaims all warranties not stated herein.

LIMITATION OF LIABILITY

REGO®'s total liability for any and all losses and damages arising out of any cause whatsoever shall in no event exceed the purchase price of the products or parts in respect of which such cause arises, whether such cause be based on theories of contract, negligence, strict liability, tort or otherwise.

REGO® shall not be liable for incidental, consequential or punitive damages or other losses. REGO® shall not be liable for, and buyer assumes any liability for, all personal injury and property damage connected with the handling, transportation, possession, further manufacture, other use or resale of products, whether used alone or in combination with any other products or materials.

From time to time buyers might call to ask REGO® for technical advice based upon limited facts disclosed to REGO®. If REGO® furnishes technical advice to buyer, whether or not at buyer's request, with respect to application, further manufacture or other use of the products and parts, REGO® shall not be liable for such technical advice or any such advice provided to buyer by any third party and buyer assumes all risks of such advice and the results thereof.

NOTE: Some states do not allow the exclusion or limitation of incidental, consequential or punitive damages, so the above limitation or exclusion may not apply to you. The warranty gives you specific legal rights, and you may have other rights that vary from State to State. The portions of this limited warranty and limitation of liability shall be considered severable and all portions which are not disallowed by applicable law shall remain in full force and effect.

NOTICE TO USERS OF PRODUCTS

The Limited Warranty stated above is a factory warranty to the first purchasers of REGO® products. Since most users have purchased these products from REGO® distributors, the user must within thirty (30) days after the user's discovery of what user believes is a defect, notify in writing and return the product to the distributor from whom he purchased the product/part. The distributor may or may not at the distributor's option choose to submit the product/parts to REGO®, pursuant to this Limited Warranty. Failure by buyer to give such written notice within thirty (30) days shall be deemed an absolute and unconditional waiver of buyer's claim for such defects. Acceptance of any alleged defective product/parts by REGO®'s distributor for replacement or repairs under the terms of REGO®'s Limited Warranty in no way determines REGO®'s obligations under this Limited Warranty.

Because of a policy of continuous product improvement, REGO® reserves the right to change designs, materials or specifications without notice.

Foreword

This catalog describes a complete line of equipment available from REGO® for use with LP-Gas and anhydrous ammonia (NH₃). The following points are important to know for proper use of the catalog:

1. Illustrations and drawings of individual products are representative of “product groups” and all products within a product group are similar in construction.
2. Materials used for construction of products in this catalog are suitable for rated service pressure at temperatures of -40° F. to +165° F., unless otherwise specified.
3. Products in this catalog are only intended for use in LP-Gas and/or anhydrous ammonia service as follows.
 - a. “A” or “AA” prefix — Products with this prefix are suitable for NH₃ service (i.e., contain no brass parts).
 - b. “AA” prefix on relief valves — These valves are NOT suitable for use with LP-Gas service. These are of partial aluminum materials and are listed by Underwriters Laboratories (UL) for NH₃ service only.
 - c. All other products are suitable for use with LP-Gas service.
 - d. “SS” prefix—Hydrostatic relief valve with this prefix are suitable for NH₃ service (i.e., they have stainless steel materials).

Caution

Do not use any product contained in this catalog with any service commodity other than LP-Gas or NH₃. If you have a need for use of another application, contact REGO®, 100 RegO Drive, Elon, NC 27244, (336) 449-7707 before proceeding.

Proper application, installation and maintenance of products in this catalog are essential. Users of these products should obtain further information if there are any doubts or questions.

Warning

All REGO® products are mechanical devices that will eventually become inoperative due to wear, corrosion and aging of components made of materials such as rubber. The environment and conditions of use will determine the safe service life of these products. Periodic inspection and maintenance are essential to avoid serious injury and property damage.

Many REGO® products are manufactured for storage, transport, transfer and use of toxic flammable and dangerous liquids and gases. Such substances should be handled by experienced and trained personnel only, using accepted governmental and industrial safety procedures. Never vent LP-Gas near any possible source of ignition.

Notice

Installation, usage, and maintenance of all REGO® products must be in compliance with all REGO® instructions as well as requirements and provisions of NFPA #54, NFPA#58, DOT, ANSI, and all applicable federal, state, provincial and local standards, codes, regulations, and laws.

Inspection and maintenance on a periodic basis is essential. Installation and maintenance should be performed only by qualified personnel.

Be sure all instructions are read and understood before installation, operation and service.

Filters

REGO® LP-Gas equipment is designed to operate in a system free from contamination. A variety of in-line filters are commercially available to the LP-Gas industry for installation in domestic systems.

The use of an in-line filter should be considered when other system components may be unclean and the system contaminated by rust, scale, dirt, debris or other foreign material.

Contents

Page

Cross Reference by Part Number	B20
Cylinder Valves	B9
Design Features of RegO® Cylinder Valves	B8
Safety Warnings	B4
Service Valves	B15
Warnings and Labels	B18

LP-Gas Cylinder and Service Valves

Safety Warnings



Purpose

In its continuing quest for safety, REGO® publishes a series of bulletins explaining the hazards associated with the use, misuse, and aging of LP-Gas valves and regulators. It is hoped that these factual bulletins will make clear to LP-Gas dealer managers and service personnel, that the utmost care and attention must be used in the installation, inspection, and maintenance of these products, or problems could occur which would result in injuries and property damage.


The National Fire Protection Association Pamphlet #58 - 2004 Edition, "Liquefied Petroleum Gas Code" states in Section 1.5 that, "persons who transfer liquid LP-Gas, who are employed to transport LP-Gas, or whose primary duties fall within the scope of this code shall be trained in proper handling procedures. Refresher training shall be provided at least every three years. The training shall be documented." These "REGO® Safety Warnings" may be useful in training new employees and reminding older employees of hazards that can occur. It is recommended that all employees be furnished with a copy of NPGA Safety Pamphlet 306, "LP-Gas Regulator and Valve Inspection and Maintenance."

Nature of Warnings

It is recognized that warnings should be as brief as possible, but the factors involved in cylinder valve failure are many because of the multiple functions the valve serves. If there is any simple warning, it would be:

Check cylinder valves for leaking components every time cylinders are filled.

The bulletin is not intended to be an exhaustive treatment of the subject of cylinder valves and certainly does not cover all safety practices that should be followed in installation, operation and maintenance of LP-Gas systems which include cylinder valves.



LP-Gas Cylinder Valves

These valves are mounted in DOT cylinders, and are intended to provide one or more of the following functions:

1. Vapor service shut-off
2. Liquid service shut-off (with excess flow valve)
3. Liquid filling
4. Pressure relief
5. Fixed liquid level gauge

These functions, although simple, are extremely critical in the safe operation of an LP-Gas cylinder system.

Abuse of these valves, failure to follow a good installation and maintenance program and attempting to use cylinder valves beyond their normal service life can result in extremely hazardous conditions.

Important Factors:

1. Installation: It should not be necessary to remind the readers that cylinder valves must be installed and used in strict conformance with NFPA Pamphlet 58, and all other applicable codes and regulations. Codes, regulations and manufacturers' recommendations have been developed by experts with many years of experience in the LP-Gas industry in the interest of safety for users of LP-Gas and all personnel servicing LP-Gas systems. Failure to fully follow these codes, regulations and recommendations could result in hazardous installations.

2. The bonnet and stem seal assembly of a cylinder valve are extremely critical, since any malfunction could cause external leakage and spillage. Check bonnet to see that it is in proper position. If there is any doubt about tightness of threaded connection between bonnet and body, valve must be repaired in accordance with manufacturers' repair instructions before cylinder is filled. Handwheel must be in good condition, stem threads must not be worn or damaged and bonnet must be properly assembled. This area should be examined each time the cylinder is filled. A leakage test should be conducted while the shut-off valve is in the open position during filling.

3. The cylinder outlet connection is usually a female POL. Threads must be free of dents, gouges and any indication of excessive wear. Seating surface inside this connection must be smooth and free of nicks and scratches to assure a gas tight seal when connected to a male POL cylinder adapter. Cylinder adapter must spin on freely all the way, without indication of drag, roughness or excessive looseness, and must then be tightened with a wrench. Connection must be checked for leakage.

4. The pressure relief valve is of critical importance: Its proper operation is vital in avoiding excessive pressures during emergencies, such as overfilling or exposure to excessive heat. No repair of this device is allowable. Relief valve should be visually inspected and checked for leaks each time the cylinder is returned for filling. All flow passages must be clean and free of foreign material.

LP-Gas Cylinder and Service Valves

Entire assembly must be free of dents, distortion or other indications of damage. If relief valve appears to be contaminated or damaged, the cylinder valve must be replaced. (Caution: Eye protection must be used when examining relief valves under pressure.)

5. The liquid service shut-off valve, with excess flow valve provided on some cylinder valves, is also of critical importance. The excess flow valve must be periodically tested for proper performance, in addition to the inspection of the shut-off valve.


6. The fixed liquid level gauge on a cylinder valve is, when present, essential to prevent overfilling the cylinder. The gauging valve must operate freely, venting vapor when loosened, and sealing gas-tight easily when tightened with the fingers. Gauge valves meant for use with a socket key or screwdriver must also seal easily without excessive torque. The fixed liquid level gauge diptube must be of the proper length, and be in proper position. Periodic test should be conducted by weighing the cylinder after filling, to determine that it does not contain more than the allowable amount of LP-Gas. This check should be done periodically, and any time there is suspicion that the gauge diptube may be damaged or broken.

Do Not Overfill Cylinders

Do not fill a cylinder without first repairing or replacing the cylinder valve, as required, if any defect is noted.

While not required by codes, it is recommended that a plug or suitable protection be inserted in the POL outlet of the cylinder valve at all times except during filling and while connected for use. This will guard against discharge of gas should the handwheel be inadvertently opened while the cylinder is in storage or transit. This is highly advisable for small cylinders that could be transported inside an automobile or trunk. It is important that proper wrenches and adapters be used when filling, servicing and installing cylinder valves in order to avoid damage to the valve or associated piping.

Since cylinders are often used by consumers without previous knowledge of the hazards of LP-Gases and the LP-Gas dealers are the only ones who have direct contact with the consumers, **it is the dealers' responsibility to make sure that his customers are properly instructed in safety matters relating to their installation.**



At the very minimum, it is desirable that these customers:

1. Know the odor of LP-Gas and what to do in case they smell gas. Use of the NPGA "Scratch 'n Sniff" leaflet could be productive.
2. Are instructed never to tamper with the system.
3. Know that when protective hoods are used to enclose regulators and/or valves, that these hoods must be closed, but not locked.
4. Know the location of the cylinder shut-off valve in emergencies.

General Warning

All REGO® Products are mechanical devices that will eventually become inoperative due to wear, contaminants, corrosion and aging of components made of materials such as metal and rubber.


The environment and conditions of use will determine the safe service life of these products. Periodic inspection and maintenance are essential. Because REGO® Products have a long and proven record of quality and service, LP-Gas dealers may forget the hazards that can occur because a cylinder valve is used beyond its safe service life. Life of a cylinder valve is determined by the environment in which it "lives". The LP-Gas dealers know better than anyone what this environment is. NOTE: There is a developing trend in state legislation and in proposed national legislation to make the owners of products responsible for replacing products before they reach the end of their safe useful life. LP-Gas dealers should be aware of legislation which could affect them.

Thread Specifications

Cylinder Valve Threads

Because of the many thread forms available on equipment used in the LP-Gas industry today, the maze of letters, numbers and symbols which make up various thread specifications becomes confusing. To help eliminate some of this confusion, a brief explanation of some of the more widely used thread specifications is shown below.

Inlet Connections



NGT and NPT Threads

The NGT (National Gas Taper) thread is the commonly used valve-to-cylinder connection. The male thread on the valve has about two more threads at the large end than the NPT in order to provide additional fresh threads if further tightening is necessary. Additionally, the standard $\frac{3}{4}$ " NGT valve inlet provides the greater tightness at the bottom of the valve by making the valve threads slightly straighter than the standard taper of $\frac{3}{4}$ " per foot in NPT connections. In all other respects NPT and NGT threads are similar.


Outlet Connections

CGA Outlets

The CGA (Compressed Gas Association) outlets are standard for use with various compressed gases. The relation of one of these outlets to another is fixed so as to minimize undesirable connections. They have been so designed to prevent the interchange of connections which may result in a hazard.



3/8"-18 NPT Thread Connection

This connection also is used for vapor or liquid withdrawal. It has a $\frac{3}{8}$ " diameter thread, and 18 threads per inch, National Pipe Taper Outlet form.




CGA 555

CGA 555 is the standard cylinder valve outlet connection for liquid withdrawal of butane and/or propane. Thread specification is $.903$ " – 14 NGO – LH – EXT, which means $.903$ " diameter thread, 14 threads per inch, National Gas Outlet form, left-hand external thread.



CGA 182, or SAE Flare

This connection assures a leak-tight joining of copper tubing to brass parts without need for brazing or silver soldering. The common size used on LP-Gas valves and fittings is $\frac{3}{8}$ " SAE (Society of Automotive Engineers) flare. Although this connection is referred to as a $\frac{3}{8}$ ", because $\frac{3}{8}$ " OD tubing is used, the thread actually measures $\frac{5}{8}$ ". The specifications are $.625 - 18 \text{ UNF} - 2A - \text{RH} - \text{EXT}$, which means $.625$ " diameter thread, 18 threads per inch, Unified Fine Series Class 2 Tolerances, right-hand, external thread.



CGA 510 or POL

Most widely used in this industry, POL is the common name for the standard CGA 510 connection. Thread specification is $.885$ " – 14 NGO – LH – INT, meaning $.885$ " diameter thread, 14 threads per inch, National Gas Outlet form, left-hand internal thread. REGO® POL outlet connections for LP-Gases conform to this standard.

LP-Gas Cylinder and Service Valves

General Information

The wide acceptance of REGO® Cylinder Valves is based on their reliable performance as well as their reputation for engineering and manufacturing excellence.

Together with thorough testing, these efforts result in years of trouble-free service. REGO® Cylinder Valves are listed by Underwriters' Laboratories and approved by the Bureau of Explosives for pressure relief valve operation, wherever applicable. See section on relief valves for important information.

Reliability

REGO® Cylinder Valves are built with attention to each detail: Beginning with comprehensive inspection of forgings and machined parts, and ending with intense quality testing on each individual valve prior to shipment.

Every valve must pass a stringent and comprehensive underwater leakage test. Additionally, valves with pressure reliefs are tested for proper pressure and operation, including reseating to ensure proper opening and closing at required pressures. Those equipped with excess flow checks are tested for compliance with published closing specifications, and tested to ensure minimum leakage after closing.

Heavy-Duty Valve Stem Seals

RegO® Cylinder Valves utilize seat discs and stem seals which resist deterioration and provide the kind of reliable service required for LP-Gas utilization. Diaphragm or O-Ring stem seals are available. Valves with diaphragm stem seals are recognized for their heavy-duty body design and are suitable for use in cylinders up to 200 lbs. propane capacity.

O-Ring type stem seals are the most widely accepted in the industry. The simple, economical and long life design features a tapered and confined nylon seat disc which provides positive, hand-tight closings, and a faster filling cylinder valve.

Pressure Relief

RegO® Valves have full-capacity "pop action" pressure reliefs with start to discharge settings at 375 PSIG.

A Valve for Every Need

RegO® Cylinder Valves are available for all LP-Gas services; a wide choice for domestic, commercial, industrial, RV, motor fuel, and lift truck applications.

Valves are available with a combination of such options as pressure reliefs, liquid level gauges, and liquid withdrawal tubes. Also available for special applications are plumbers' pot valves, tamperresistant valves for field service, and dual valves for simultaneous liquid and vapor service.

Instructions for the Proper Use and Applications of RegO® Cylinder Valves

1. Containers and pipe line should be cleaned thoroughly before valves are installed. Large particles of solid foreign matter can cut the seating surface of any resilient seat disc, causing the valve to leak. Care must be exercised in inserting valves into lines or containers to avoid damaging or exerting pressure against pressure relief valves and outlet connections. Use a minimum amount of a suitable luting compound on the cylinder valve threads only. Excess amounts of luting compound can foul the operating parts of the valves.

2. Do not use excessive force in opening or closing the valves. The seat disc and diaphragm materials permit the valves to be opened and closed easily by hand. Never use a wrench on wheel handle valves.

3. When the design of the piping installation allows liquid to be locked between two valves, a hydrostatic relief valve must be installed in the line between the two valves. The pressures which can develop due to temperature increase in a liquid full line are tremendous and can cause rupture of the line or damage to the valves.

4. The valves are designed to withstand normal atmospheric temperatures. They should not, however, be subjected to abnormally high temperatures.

B

Design Features of RegO® Cylinder Valves

Valve Stems On 901, 9101, 9102 and 9103 Valves

Are machined with a double lead thread for quick opening and closing as well as high lift.

Back Seat On 901, 9101, 9102 and 9103 Valves

Is metal-to-metal seating to provide added protection against leakage while the valve is open. Back seat the valve while in operation.

Forged Brass Body

Pressure Relief

Provides quick discharge of excess pressure. Relief seat disc is special resilient composition rubber.

Tapered Seat Openings On 9101, 9102 and 9103 Valves


Permit increased flow rates resulting in faster charging.

O-Rings

For positive leak-proof seals under temperature and pressure variations.

Seat Disc

Is a tapered nylon in a fully confined seat to ensure easy, leak-free, positive shutoffs. Seat disc also provides a separate swivel action to minimize scoring by impurities.



Heavy-Duty Cylinder Valves for Vapor Withdrawal 9103 Series

Application


This heavy duty cylinder valve is designed for vapor withdrawal of DOT cylinders up to 100 lbs. propane capacity. It is used in domestic hookups, and industrial commercial installations.

Features

- Equipped with a fast filling throat and high lift, o-ring stem seal design.
- Utilizes a nylon tapered seat design for positive closing.
- Available with a fixed liquid level gauge.
- Self-tapping screw secures handwheel to stem and reduces possibility of handwheel vibrating loose while in transit.

Materials

Body	Forged Brass
Handwheel.....	Aluminum
Stem	Brass
O-Rings	Resilient Rubber
Seat Disc	Nylon
Relief Spring	Stainless Steel



Ordering Information

Part Number	Container Connection	Service Connection	Fixed Liquid Level Vent Valve	Dip Tube Length w/ Deflector	Pressure Relief Valve Setting	For Use in Cylinders w/Propane Capacity Up To:	Approximate Filling Rate Liquid Flow, GPM				Accessories
							Pressure Drop Across Valves				POL Plug
							10 PSIG	25 PSIG	50 PSIG	100 PSIG	
9103D10.6	3/4" M NGT	F. POL (CGA 510)	Yes	10.6"	375 PSIG	100 lbs.	12.7	20.3	29.0	41.3	N970P
9103D11.6				11.6"							

Tamper-Resistant Cylinder Valve with Outlet Check for Vapor Withdrawal 9103T9F

Application

This valve is designed for vapor withdrawal from and protection of DOT cylinders up to 100 lbs. propane capacity. Ideal for cylinders used in the field by construction crews, utility repair men and plumbers.


Features

- Minimizes the risk of unauthorized persons withdrawing propane from cylinders not in service. It is necessary to install a male POL connection to open the outlet check to withdraw vapor from the valve.
- Ball type excess flow located in the valve inlet protects against excessive discharge if the cylinder is tipped or the hose ruptures. Closing flow is 200 SCFH at 100 PSIG.
- Removable POL outlet and check mechanism make field replacement of worn connections an easy process without removing the valve from the cylinder.
- Outlet seal plug on a heavy duty chain prevents dirt from entering POL when not in use.
- Nylon tapered seat design provides positive closure.



Materials

Body	Forged Brass
Handwheel.....	Aluminum Die Cast
Stem	Brass
O-Rings	Resilient Rubber
Seat Disc	Nylon
Relief Spring.....	Stainless Steel
Plug	Brass



Ordering Information

Part Number	Container Connection	Service Connection	Fixed Liquid Level Vent Valve Style	Pressure Relief Valve Setting	For Use in Cylinders w/ Propane Capacity Up To:	Approximate Filling Rate Liquid Flow, GPM			
						Pressure Drop Across Valves			
						10 PSIG	25 PSIG	50 PSIG	100 PSIG
9103T9F	3/4" M. NGT	F. POL (CGA 510)	None	375 PSIG	100 lbs.	5.0	7.6	10.7	14.9

NOTE: These valves incorporate an excess flow valve.
Refer to L-500/Section F, for complete information regarding selection, operation and testing of excess flow valves.

Cylinder Valve for RV and Small ASME System Vapor Withdrawal 9106CO

Application


Designed especially for vapor withdrawal service in small ASME containers with surface area up to 23.8 square feet. UL flow capacity is 645 SCFM/air.

Features

- One-piece relief valve is shielded from tampering and damage.
- Relief is forged as part of the body for extra strength.
- 312 PSIG Relief Valve setting.

Materials

Body Forged Brass
Handwheel..... Aluminum Die Cast
Stem Brass
Seat Disc Nylon
Relief Spring Stainless Steel



Ordering Information

Part Number	Container Connection	Service Connection	Fixed Liquid Level Vent Valve Style	Pressure Relief Valve Setting	For Use In Cylinders w/ Propane Capacity Up To	Flow Capacity SCFM/Air
9106CO	3/4" M. NGT	F. POL (CGA 510)	none	312 PSIG	ASME Tanks*	645

* Surface area up to 23.8 square feet.

Cylinder Valve for Liquid Withdrawal 9107K8A

Application


Equipped with excess flow valves and liquid withdrawal tubes, they are designed for liquid withdrawal of DOT cylinders up to 100 lbs. propane capacity. They are most often used with heavy BTU loads found in industrial uses.

Features

- O-ring stem seal design.
- Nylon tapered seat disc for positive closure.
- Self-tapping screw secures handwheel to stem and reduces possibility of handwheel vibrating loose while in transit.
- Features ball check excess flow valve.
- Furnished with 3/8" O.D. stainless steel withdrawal tube with "T" dimension of 44".

Materials

Body Forged Brass
Handwheel..... Aluminum Die Cast
Seat Disc Nylon
O-Rings Resilient Rubber
Relief Spring Stainless Steel
Stem Brass



Ordering Information

Part Number	Container Connection	Service Connection	Fixed Liquid Level Vent Valve Style	Dip Tube Length w/ Deflector	Liquid Withdrawal Tube Length
9107K8A	3/4" M. NGT	CGA 555	Knurled	11.6"	44"

Pressure Relief Valve Setting	For Use in Cylinders w/ Propane Capacity Up To:	Approximate Filling Rate Liquid Flow, GPM				Closing Flow (LP-Gas) *		
		Pressure Drop Across Valves				Vapor		Liquid
		10 PSIG	25 PSIG	50 PSIG	100 PSIG	25 PSIG Inlet	100 PSIG Inlet	
375 PSIG	100 lbs.	3.3	5.4	7.7	11.1	525 SCFH	1,000 SCFH	1.7 GPM

*Closing flows based on 3/8" O.D. withdrawal tube 44" long or less attached.

IMPORTANT: 1/4" O.D. pigtails or POL connections for 1/4" O.D. pigtails should not be used with these valves.

NOTES: To ensure proper functioning and maximum protection from excess flow valves, the cylinder valve should be fully opened and backseated when in use. These valves incorporate an excess flow valve. Refer to L-500 / Section F, for complete information regarding selection, operation and testing of excess flow valves.

“Dual” Cylinder Valve for Simultaneous Liquid and Vapor Withdrawal 8556

Application


This dual cylinder valve was designed especially for industrial uses. It increases the cylinder's flexibility by permitting DOT cylinders up to 100 lbs. propane capacity to be used interchangeably or simultaneously for either liquid or vapor withdrawal.

Features

- Two separate flow channels in the body permit vapor and/or liquid withdrawal alternately, or simultaneously.
- Outlet connections have two different fittings.
- Handwheels are equipped with appropriate “liquid” or “vapor” identification labels.
- Furnished with a 3/8" O.D. stainless steel liquid withdrawal tube with a “T” dimension of 44”.

Materials

Body Forged Brass
Handwheel..... Aluminum Die Cast
Stem Brass
Seat Disc Nylon
O-Rings Resilient Rubber
Relief Spring Stainless Steel



Ordering Information

Part Number	Container Connection	Service Connection		Fixed Liquid Level Vent Valve Style	Liquid Withdrawal Tube Length
		Vapor	Liquid		
8556	¾" M. NGT	F. POL (CGA 510)	CGA 555	None	44"

Pressure Relief Valve Setting	For Use in Cylinders w/ Propane Capacity Up To:	Approximate Filling Rate Liquid Flow, GPM				Liquid Closing Flow* (LP-Gas)
		Pressure Drop Across Valves				
		10 PSIG	25 PSIG	50 PSIG	100 PSIG	
375 PSIG	100 lbs.	6.6	10.0	14.5	21.0	2.3 GPM

* To ensure proper functioning and maximum protection from integral excess flow valves, the cylinder valve should be fully opened and backseated when in use.

NOTE: These valves incorporate an excess flow valve. Refer to L-500/Section F, for complete information regarding selection, operation and testing of excess flow valves.

Service Valves for ASME and DOT Containers or Fuel Line Applications 901C1, 9101C, 9101D, 9101R and PT9102 Series

Application

Designed for vapor withdrawal service on ASME and DOT containers or in fuel line applications. Since none of these valves have an integral pressure relief valve, they may only be used as an accessory valve on containers that have an independent pressure relief valve sufficient for that container's capacity.




Features


- O-Ring stem seal design provides positive seal.
- Metal-to-metal back seat provides added protection against leakage while the valve is open.
- Valves with fixed liquid level gauges permit operator to quickly determine when the maximum permitted filling level of the container is reached.
- 9101R Series with MultiBonnet allows quick and easy repair of bonnet.

Materials

Body Forged Brass
Handwheel..... Aluminum Die Cast
Stem Brass
O-Rings Resilient Synthetic Rubber
Seat Disc Nylon



901C1




9101R1



PT9102



9101D



Ordering Information

Part Number	Bonnet Style	Container Connection	Service Connection	Fixed Liquid Level Vent Valve	Approximate Filling Rate Liquid Flow, GPM					
					Pressure Drop Across Valve					
					10 PSIG	25 PSIG	50 PSIG	100 PSIG		
901C1	Standard	¾" M. NGT	F. POL CGA 510	No	5.3	8.2	10.8	14.2		
9101C1					8.8	12.4	15.8	21.7		
9101D11.1				Yes	8.6	12.7	16.3	22.3		
9101D11.7										
9101R1	MultiBonnet					No	7.6	11.7	15.2	20.6
9101R11.1						Yes				
9101R11.7						No				
PT9102R1						Yes				
PT9102R11.1										
PT9102R11.7										

Note: Since these valves have no integral pressure relief valve, they can be used on any container with an independent relief device sufficient for that tank's capacity.

Service Valves for ASME Motor Fuel Containers 901C, 9101H, and 9101Y Series

Application

Designed specifically for vapor or liquid withdrawal service on ASME motor fuel containers. Since none of these valves have an integral pressure relief valve, they may only be used as an accessory valve on containers that have an independent pressure relief valve sufficient for that container's capacity.

The integral excess flow valve found in all these service valves helps prevent excessive product loss in the event of fuel line rupture.

When installed for liquid withdrawal, the 9101H6 has provisions for attachment of a liquid withdrawal tube. All other valves must be installed in containers that have provisions for a separate liquid withdrawal.

To insure proper functioning and maximum protection from integral excess flow valves, these service valves should be fully opened and backseated when in use.

Features

- Incorporates integral excess flow valve and shut-off valve in one unit.
- Double lead thread provides faster opening and closing.
- O-Ring stem seal design provides positive seal.
- Tapered and confined seat disc provides positive shut off.
- Metal-to-metal back seat provides added protection against leakage while the valve is open.
- 9101H6 equipped with a 1/4" NPT internal thread for the addition of a liquid withdrawal tube.
- 9101Y Series features a 60° angled outlet connection to facilitate easier and simpler fuel line make-up.

Materials

Body Forged Brass
Handwheel..... Aluminum Die Cast
Stem Brass
O-Rings Resilient Synthetic Rubber
Seat Disc Nylon

Ordering Information

Part Number	Container Connection	Service Connection	Liquid Withdrawal Connection	Closing Flow (LP Gas)		
				Vapor		Liquid GPM
				25 PSIG Inlet (SCFH)	100 PSIG Inlet (SCFH)	
901C3	3/4" M. NGT	F. POL CGA 510	None	350***	605***	1.5***
901C5				550***	1050***	2.6***
9101H5*				765**	1300**	3.6**
9101H6*		3/8" SAE Flare	1/4" NPT	550****	1050****	2.6****
9101Y5H*		60° Angle 3/8" SAE Flare	None	765**	1300**	3.6**

* Heavy-duty models

** Based on 3/8" O.D. pigtail, 20" long or less, connected to valve outlet. For greater lengths, the pigtail must have a larger O.D.

*** Same as (**). In addition, 1/4" O.D. pigtails or POL connections for 1/4" O.D. should not be used with this valve.

**** Based on 3/8" O.D. pigtail; 20" long or less, connected to valve outlet. Also based on 1/4" pipe size dip tube, 42" long or less, attached to special inlet connection. For longer pigtail lengths, the diameter of the pigtail must be increased.

NOTE: These valves incorporate an excess flow valve. Refer to L-500/Section F, for complete information regarding selection, operation and testing of excess flow valves.



901C5







9101H5



9101H6



9101Y5H



Service Valves for DOT Fork Lift Containers 9101P5 and 9101P6 Series

Application

Designed specifically for vapor or liquid withdrawal service on DOT fork lift containers. Valves with 1.5 GPM closing flow are for use in small and medium size lift truck applications, while those with 2.6 GPM closing flow are for large lift trucks. Since none of these valves have an integral pressure relief valve, they may only be used as an accessory valve on containers that have an independent pressure relief valve sufficient for that cylinders capacity.

The integral excess flow valve found in all these service valves helps prevent excessive product loss in the event of fuel line rupture.

When installed for liquid withdrawal, the 9101P6 Series has provisions for attachment of a liquid withdrawal tube. The 9101P5 Series must be installed in containers that have provisions for a separate liquid withdrawal.


To insure proper functioning and maximum protection for integral excess flow valves, these service valves should be fully opened and backseated when in use.

Features


- Incorporates integral excess check valve and shut-off valve in one unit.
- Special 1.5 GPM closing flow on select valves provided especially for lift trucks and equipment with smaller engines.
- Double lead stem thread provides faster opening and closing.
- O-Ring stem seal design provides positive seal.
- Tapered and confined seat disc provides positive shut-off.
- Metal-to-metal back seat provides added protection against leakage while the valve is open.
- 9101P6 Series equipped with a 1/4" NPT internal thread for the addition of a liquid withdrawal tube.

Materials

Body Forged Brass
Handwheel..... Aluminum Die Cast
Stem Brass
O-Rings Resilient Synthetic Rubber
Seat Disc Nylon



9101P5
9101P5H



9101P6
9101P6H



Ordering Information

Part Number	Container Connection	Service Connection	Liquid Withdrawal Connection	Closing Flow (LP-Gas)			Approximate Filling Rate Liquid Flow, GPM				Accessories		
				Vapor		Liquid (GPM)	Pressure Drop Across Valve				ACME Check Connectors		
				25 PSIG Inlet (SCFH)	100 PSIG Inlet (SCFH)		10 PSIG	25 PSIG	50 PSIG	100 PSIG	Male	Female	Cap
9101P5	¼" M. NGT	¾" M. NPT	None	430	900	1.5	5.0	7.6	10.7	14.9	7141M	7141F	7141M-40 or 7141FP
9101P5H				550	1050	2.6							
9101P6			¼" NPT	430	900	1.5	4.5	7.2	10.3	14.8			
9101P6H				550	1050	2.6							

Note: These valves incorporate an excess flow valve. Refer to L-500/Section F, for complete information regarding selection, operation and testing of excess flow valves.

Cylinder Valve for Propylene Service 9104PT and 9104PPA

Application

Designed for vapor withdrawal from and protection of DOT cylinders up to 100 lbs. propylene capacity with pressure ratings such as 4B-260, 4BA-260, and 4BW-260 cylinders.


Features

- Nylon tapered seat designed for positive closing.
- Relief is forged as part of the body for extra strength.
- Available with Fixed Liquid Level Gauge.
- 435 PSIG Relief Valve Setting.
- Meets TB27 requirements.
- $\frac{3}{32}$ " Markings.



Materials

Body	Forged Brass
Handwheel.....	Aluminum
Stem	Brass
Seat Disc	Viton
Relief Spring	Stainless Steel
Relief Valve Setting	435 PSIG TB27



9104PT

9104PPA



Ordering Information

Part Number	Container Connection	Service Connection	Fixed Liquid Level Vent Valve Style	Dip Tube w/ Deflector
9104PPA	$\frac{3}{4}$ " M.NPT	F.POL - (CGA 510)	N/A	N/A
9101P5H			Knurled	Yes

Note: Valve can be ordered with other dip tube lengths. Specify required length when ordering.

Adhesive Warning Labels

901-400 and 903-400

These adhesive warning labels are intended for application as close as possible to the cylinder valve and/or service valve.

The basic information contained on the label is intended for the benefit of the user of the valves and is not intended to be an “all-inclusive” product warning.

These labels are printed on a heavy duty material with pressure sensitive adhesive backing. The ultra-violet ink stands up well when exposed to the environment.

Part Number	
901-400	Adhesive Label Primarily for Fork Lift Cylinders
903-400	Adhesive Label Primarily for Small DOT Cylinders

DANGER LP GAS IS EXTREMELY FLAMMABLE AND EXPLOSIVE WARNING

AVOID SERIOUS INJURY AND PROPERTY DAMAGE. IF YOU SEE, SMELL, OR HEAR ESCAPING GAS, EVACUATE AREA IMMEDIATELY. CALL YOUR LOCAL FIRE DEPARTMENT! DO NOT ATTEMPT TO REPAIR. DO NOT STORE IN BUILDING OR ENCLOSED AREA. DO NOT USE ON HOT AIR BALLOONS OR AIRCRAFT.

This container is filled with highly flammable LP-Gas under pressure. A serious fire or explosion can result from leaks and misuse or misbranding of the cylinder and its valve. Do not move, hold or fill the container by any means. Do not expose to fire or temperatures above 120°F (49°C). Do not overfill. Do not expose to fire or temperatures above 120°F (49°C). Do not overfill.

This container incorporates a pressure relief valve. The pressure relief valve can equalize the pressure in the cylinder if the container is exposed to temperatures higher than the temperatures at the time it was filled. The pressure relief valve is equipped with a protective cover. The protective cover must remain in place at all times except when inspecting the valve. CAUTION: Unsealing or tampering with the pressure relief valve may cause the valve to fail and cause a leak or rupture or otherwise cause damage to the container.

Each time the container is filled, the pressure relief valve must be checked to ensure that it is completely undamaged and that it has no physical damage. If there is any doubt about the condition of the valve, the container must be removed from service and the pressure relief valve must be replaced.

Only trained personnel should be permitted to fill this container. Before the container is filled for the first time, it must be purged of air. The total liquid volume of LP-Gas must never exceed the amount designated by applicable filling density regulations for the gas. Make sure the protective cap is in place on the ACME threaded filler valve or affixes. Never insert a candle or other tool into the filler valve. Do not damage the label or grade and date or uncontrolled tank.

DO NOT REMOVE, DEFACE OR OBLITERATE THIS LABEL—DO NOT FILL THIS CONTAINER UNLESS THIS LABEL IS READABLE.

ADDITIONAL SAFETY INFORMATION IS AVAILABLE FROM: **REGO** Printed in U.S.A. 04-0894-1189 Part No. 901-400 100 RegO Drive PO Box 247 Elon College, NC 27244 USA Phone (336) 449-7707 Fax (336) 449-6594 www.regoproducts.com

DANGER!

AVOID SERIOUS INJURY AND PROPERTY DAMAGE. IF YOU SEE, SMELL, OR HEAR ESCAPING GAS, IMMEDIATELY GET AWAY FROM THIS CYLINDER. CALL YOUR LOCAL FIRE DEPARTMENT! DO NOT ATTEMPT TO REPAIR. DO NOT USE OR STORE IN BUILDING OR ENCLOSED AREA OR OUTDOOR USE ONLY.

This cylinder contains highly flammable LP-Gas under pressure. A serious fire or explosion can result from leaks and misuse or misbranding of the cylinder and its valve. Do not carry, hold or lift the cylinder by its valve. Do not expose to fire or temperatures above 120°F (49°C). The cylinder valve incorporates a Shut-Off Valve and Pressure Relief Valve. The Pressure Relief Valve can equalize the pressure in the cylinder if the cylinder is exposed to temperatures higher than the temperatures at the time it was filled. The Pressure Relief Valve is equipped with a protective cover. The protective cover must remain in place at all times except when inspecting the valve. CAUTION: Unsealing or tampering with the pressure relief valve may cause the valve to fail and cause a leak or rupture or otherwise cause damage to the cylinder.

Each time the cylinder is filled, the pressure relief valve must be checked to ensure that it is completely undamaged and that it has no physical damage. If there is any doubt about the condition of the valve, the cylinder must be removed from service and the pressure relief valve must be replaced.

Only trained LP-Gas Dealer personnel should be permitted to fill this cylinder and to repair or replace its valve. Each time the cylinder is filled, the entire cylinder valve must be checked for leaks (with a leak detection solution, leaks cause bubbles to grow). The shut-off valve and fused liquid level gauge (if incorporated) must be checked for proper operation. The Pressure Relief Valve must be checked to ensure that it is completely undamaged and that it has no physical damage.

DO NOT REMOVE, DEFACE OR OBLITERATE THIS LABEL—DO NOT FILL THIS CYLINDER UNLESS THIS LABEL IS READABLE.

ADDITIONAL SAFETY INFORMATION IS AVAILABLE FROM: **REGO** Printed in U.S.A. 04-0894-1189 Part No. 901-400 100 RegO Drive PO Box 247 Elon College, NC 27244 USA Phone (336) 449-7707 Fax (336) 449-6594 www.regoproducts.com

LP-GAS IS EXTREMELY FLAMMABLE AND EXPLOSIVE KEEP CYLINDER OUT OF THE REACH OF CHILDREN

AVOID SERIOUS INJURY AND PROPERTY DAMAGE. IF YOU SEE, SMELL, OR HEAR ESCAPING GAS, IMMEDIATELY GET AWAY FROM THIS CYLINDER. CALL YOUR LOCAL FIRE DEPARTMENT! DO NOT ATTEMPT TO REPAIR. DO NOT USE OR STORE IN BUILDING OR ENCLOSED AREA OR OUTDOOR USE ONLY.

CAUTION: Eye protection must be worn when examining the valve. This valve cannot be repaired. If it is obstructed, the entire cylinder valve must be replaced. The Shut-Off Valve may require periodic repair or replacement. Before the cylinder is filled for the first time, it must be purged of air. Total liquid volume must never exceed the amount designated by DOT for this cylinder. If the cylinder has a fused liquid level gauge, filling should stop the moment a white LP-Gas cloud is emitted from its bleed hole. Keep the vent valve closed tightly at all other times. Keep the cylinder firmly secured in an upright position at all times. Do not lay on its side during transport, storage or use. In other than an upright position, liquid LP-Gas may flow or leak. This liquid can cause skin burns, frostbite and other serious injuries in addition to those caused by fire or explosion.

When not in use: Close the Shut-Off Valve. Insert a protective plug (P.O.L. plug) into the cylinder valve outlet. (CAUTION: countercheck the thread). The P.O.L. plug must be inserted whenever the cylinder is stored, manually moved, or transported by vehicle.

DO NOT REMOVE, DEFACE OR OBLITERATE THIS LABEL—DO NOT FILL THIS CYLINDER UNLESS THIS LABEL IS READABLE.

ADDITIONAL SAFETY INFORMATION IS AVAILABLE FROM: **REGO** Printed in U.S.A. 04-0894-1189 Part No. 901-400 100 RegO Drive PO Box 247 Elon College, NC 27244 USA Phone (336) 449-7707 Fax (336) 449-6594 www.regoproducts.com

WARNING!

AVOID SERIOUS INJURY AND PROPERTY DAMAGE. IF YOU SEE, SMELL, OR HEAR ESCAPING GAS, IMMEDIATELY GET AWAY FROM THIS CYLINDER. CALL YOUR LOCAL FIRE DEPARTMENT! DO NOT ATTEMPT TO REPAIR. DO NOT USE OR STORE IN BUILDING OR ENCLOSED AREA OR OUTDOOR USE ONLY.

When making connections to an appliance: 1. Do not use the cylinder without first reading the instructions accompanying the appliance with which this cylinder is intended to be used. 2. Before connecting the Cylinder Valve outlet connection to an appliance, make sure the connection does not contain dirt or debris. These may cause the connection to leak or may impair the functioning of the regulator, creating a hazardous condition. 3. When connecting the Cylinder Valve outlet to an appliance (CAUTION: countercheck the thread), make sure the connection is tight. Check for leaks with a high quality leak detection solution (leaks cause bubbles to grow). If the connection leaks after tightening, close cylinder valve, disconnect from the appliance, insert the P.O.L. plug and immediately return the cylinder, with the Cylinder Valve attached, to your LP-Gas Dealer for examination.

This cylinder must be used only in compliance with all applicable laws and regulations, including National Fire Protection Association Publication No. 58, which is the law in many states. A copy of this Publication may be obtained by writing NFPA, Batterymarch Park, Quincy, MA 02269.

DO NOT REMOVE, DEFACE OR OBLITERATE THIS LABEL—DO NOT FILL THIS CYLINDER UNLESS THIS LABEL IS READABLE.

ADDITIONAL SAFETY INFORMATION IS AVAILABLE FROM: **REGO** Printed in U.S.A. 04-0894-1189 Part No. 901-400 100 RegO Drive PO Box 247 Elon College, NC 27244 USA Phone (336) 449-7707 Fax (336) 449-6594 www.regoproducts.com

Warning Notice

The following warning information, Part Number 903-500, is included with each shipment of cylinder valves and service valves to the first purchaser of the product from the factory.

This information is intended to be forwarded throughout the product distribution chain. Additional copies are available from REGO® and Authorized Product Distributors.

DANGER READ THIS FIRST WARNING

LP-GAS IS EXTREMELY FLAMMABLE AND EXPLOSIVE

AVOID SERIOUS INJURY AND PROPERTY DAMAGE. IF YOU SEE, SMELL, OR HEAR ESCAPING GAS, EVACUATE AREA IMMEDIATELY! CALL YOUR LOCAL FIRE DEPARTMENT! DO NOT ATTEMPT TO REPAIR. DO NOT STORE IN BUILDING OR ENCLOSED AREA. DO NOT USE ON HOT AIR BALLOONS OR AIRCRAFT.

Make sure you are thoroughly trained before you attempt any valve installation, maintenance or repair. Improper conditions or procedures can cause accidents resulting in property damage and personal injury.

Become thoroughly familiar with NFPA Safety Pamphlet 306 "LP-Gas Regulator and Valve Inspections & Maintenance" and ECIL "Safety Warnings: LP-Gas Cylinder Valves", "LP-Gas Excess Flow Valves", and "LP-Gas Filler and Hose End Filling Valves" found in the cylinder valve, excess flow valve, and filler valve sections of the L-500 & L-102 Catalogs. Follow their recommendations.

Know and understand NFPA Pamphlet 58 "Liquefied Petroleum Gas Code", which is the law in many states. This publication is available from NFPA, Batterymarch Park, Quincy, MA 02269. Following its requirements is essential in the safe use of LP-Gas. Section 4.4 states: persons who transfer liquid LP-Gas, who are employed to transport LP-Gas, or whose primary duties fall within the scope of this code shall be trained in proper handling procedures. Refresher training shall be provided at least every three years and shall be documented.

Make sure this valve is the proper one for this installation. Avoid misusing LP-Gas equipment.

Apply thread joint compound compatible with LP-Gas on valve external threads only. Make sure compound never comes into contact with other parts of the valve.

Install valves by applying force to wrenching flats only.

Tighten pipe threads approximately 1 to 1½ turns beyond the hand-tight insertion point using a wrench which avoids damage to other valve parts.

Check for damage and proper operation after valve installation. Check that the valve is clean and free of foreign material.

Check container-valve connection with a non-corrosive leak detection solution before filling with LP-Gas.

Purge container before filling with LP-Gas (refer to the ECIL "LP-Gas Serviceman's Manual for recommended procedure).

Test excess flow check valve for proper operation before placing into service. See NFPA Bulletin 113 for recommended procedure.

Check outlet connection carefully for leaks with a non-corrosive leak detection solution when placing into service.

REGO Products Filler Valves: To prevent damage to the internal checks when it is necessary to utilize an unloading adapter, use ONLY REGO Products 3115A, 3120 and 3121 Unloading Adapters with REGO Products Filler Valves. Carefully follow the instructions supplied with these unloading adapters.

If container is not being placed into service at the present time, insert plug or cap onto the outlet connection.

In selecting a label for posting at the installation site, consider ECIL "part number 901-400 or 903-400 along with your own, NFPA's and others.

Remember to instruct the owner/user/customer in safety matters concerning LP-Gas and this equipment. See ECIL "Safety Warnings: LP-Gas Cylinder Valves", "LP-Gas Excess Flow Valves", and "LP-Gas Filler and Hose End Filling Valves" found in the cylinder valve, excess flow valve, and filler valve sections of the L-500 & L-102 Catalogs.

Engineered Controls International, Inc., ECIL "requests that this information be forwarded to your customers. Additional copies are available from ECIL " and your authorized ECIL " Product Distributor.

REGO Printed in USA 08-0809-0686 Part number 903-500 100 RegO Drive PO Box 247 Elon, NC 27244 USA Phone (336) 449-7707 Fax (336) 449-6594 www.regoproducts.com

Cross Reference by Part Number

901C1B14
901C3B15
901C5B15
901-400B18
903-400B18
9101C1B14
9101R1B14
9101H5B15
9101P5B16
9101P5HB16
9101Y5HB15
9101H6B15
9101P6B16

9101P6HB16
9101D11.1B14
9101R11.1B14
9101D11.7B14
9101R11.7B14
PT9102R1B14
PT9102R11.1B14
PT9102R11.7B14
9103T9FB10
9103D10.6B9
9103D11.6B9
9104PPAB17
9104PTB17
9106COB11
9107K8AB12



LP-Gas & Anhydrous Ammonia Equipment

C

Section C

Multivalve® Assemblies

Limited Warranty and Limitation of Liability

LIMITED 10 YEAR WARRANTY AND LIMITATION OF LIABILITY

LIMITED 10 YEAR WARRANTY

REGO® warrants to the original purchasers the products and repair kits manufactured by it to be free from defects in materials and workmanship under normal use and service for a period of 10 years from the date of manufacture. If within thirty days after buyer's discovery of what buyer believes is a defect, buyer notifies in writing and ships the product to REGO® at 100 Rego Drive, Elon, NC 27244, REGO®, at its option, and within forty-five days of receipt, will repair, replace F.O.B. point of manufacture, or refund the purchase price of that part or product found by REGO® to be defective. Failure of buyer to give such written notice and ship the product within thirty days shall be deemed an absolute and unconditional waiver of any and all claims of buyer arising out of such defect.

This warranty does not extend to any product or part that is not installed and used continuously after installation in accordance with REGO®'s printed instructions, all applicable state and local regulations, and all applicable national standards, such as those promulgated by NFPA, DOT and ANSI. This warranty does not extend to any product or part that has been damaged by accident, misuse, abuse, failure to maintain, or neglect, nor does it extend to any product or part which has been modified, altered, disassembled, or repaired in the field. This warranty does not cover any cosmetic issues, such as scratches, dents, marring, fading of colors or discoloration.

Except as expressly set forth above, and subject to the limitation of liability below, REGO® MAKES NO OTHER WARRANTY, EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, with respect to its products and parts, whether used alone or in combination with others. REGO® disclaims all warranties not stated herein.

LIMITATION OF LIABILITY

REGO®'s total liability for any and all losses and damages arising out of any cause whatsoever shall in no event exceed the purchase price of the products or parts in respect of which such cause arises, whether such cause be based on theories of contract, negligence, strict liability, tort or otherwise.

REGO® shall not be liable for incidental, consequential or punitive damages or other losses. REGO® shall not be liable for, and buyer assumes any liability for, all personal injury and property damage connected with the handling, transportation, possession, further manufacture, other use or resale of products, whether used alone or in combination with any other products or materials.

From time to time buyers might call to ask REGO® for technical advice based upon limited facts disclosed to REGO®. If REGO® furnishes technical advice to buyer, whether or not at buyer's request, with respect to application, further manufacture or other use of the products and parts, REGO® shall not be liable for such technical advice or any such advice provided to buyer by any third party and buyer assumes all risks of such advice and the results thereof.

NOTE: Some states do not allow the exclusion or limitation of incidental, consequential or punitive damages, so the above limitation or exclusion may not apply to you. The warranty gives you specific legal rights, and you may have other rights that vary from State to State. The portions of this limited warranty and limitation of liability shall be considered severable and all portions which are not disallowed by applicable law shall remain in full force and effect.

NOTICE TO USERS OF PRODUCTS

The Limited Warranty stated above is a factory warranty to the first purchasers of REGO® products. Since most users have purchased these products from REGO® distributors, the user must within thirty (30) days after the user's discovery of what user believes is a defect, notify in writing and return the product to the distributor from whom he purchased the product/part. The distributor may or may not at the distributor's option choose to submit the product/parts to REGO®, pursuant to this Limited Warranty. Failure by buyer to give such written notice within thirty (30) days shall be deemed an absolute and unconditional waiver of buyer's claim for such defects. Acceptance of any alleged defective product/parts by REGO®'s distributor for replacement or repairs under the terms of REGO®'s Limited Warranty in no way determines REGO®'s obligations under this Limited Warranty.

Because of a policy of continuous product improvement, REGO® reserves the right to change designs, materials or specifications without notice.

Foreword

This catalog describes a complete line of equipment available from REGO® for use with LP-Gas and anhydrous ammonia (NH₃). The following points are important to know for proper use of the catalog:

1. Illustrations and drawings of individual products are representative of “product groups” and all products within a product group are similar in construction.
2. Materials used for construction of products in this catalog are suitable for rated service pressure at temperatures of -40° F. to +165° F., unless otherwise specified.
3. Products in this catalog are only intended for use in LP-Gas and/or anhydrous ammonia service as follows.
 - a. “A” or “AA” prefix — Products with this prefix are suitable for NH₃ service (i.e., contain no brass parts).
 - b. “AA” prefix on relief valves — These valves are NOT suitable for use with LP-Gas service. These are of partial aluminum materials and are listed by Underwriters Laboratories (UL) for NH₃ service only.
 - c. All other products are suitable for use with LP-Gas service.
 - d. “SS” prefix—Hydrostatic relief valve with this prefix are suitable for NH₃ service (i.e., they have stainless steel materials).

Caution

Do not use any product contained in this catalog with any service commodity other than LP-Gas or NH₃. If you have a need for use of another application, contact REGO®, 100 RegO Drive, Elon, NC 27244, (336) 449-7707 before proceeding.

Proper application, installation and maintenance of products in this catalog are essential. Users of these products should obtain further information if there are any doubts or questions.

Warning

All REGO® products are mechanical devices that will eventually become inoperative due to wear, corrosion and aging of components made of materials such as rubber. The environment and conditions of use will determine the safe service life of these products. Periodic inspection and maintenance are essential to avoid serious injury and property damage.

Many REGO® products are manufactured for storage, transport, transfer and use of toxic flammable and dangerous liquids and gases. Such substances should be handled by experienced and trained personnel only, using accepted governmental and industrial safety procedures. Never vent LP-Gas near any possible source of ignition.

Notice

Installation, usage, and maintenance of all REGO® products must be in compliance with all REGO® instructions as well as requirements and provisions of NFPA #54, NFPA#58, DOT, ANSI, and all applicable federal, state, provincial and local standards, codes, regulations, and laws.

Inspection and maintenance on a periodic basis is essential. Installation and maintenance should be performed only by qualified personnel.

Be sure all instructions are read and understood before installation, operation and service.

Filters

REGO® LP-Gas equipment is designed to operate in a system free from contamination. A variety of in-line filters are commercially available to the LP-Gas industry for installation in domestic systems.

The use of an in-line filter should be considered when other system components may be unclean and the system contaminated by rust, scale, dirt, debris or other foreign material.

Contents

Page

Cross Reference by Part Number	C13
Multivalve® Assemblies	C4
Warnings	C12

RegO Multivalve® Assemblies

General Information

RegO Multivalves® were pioneered in the 1930's. By combining several valve functions in one unit, Multivalves® made possible new and more practical tank designs (fewer openings and smaller, less cumbersome protective hoods). They received immediate acceptance.

The Multivalve® design has kept pace with changing industry needs over the years. They are as popular as ever; still keeping fabricating costs down and reducing operating expenses for the LP-Gas dealer.

RegO Multivalves® Reduce the Cost of Fabrication by

- Combining several valve functions in one less expensive body.
- Reducing the number of threaded openings in ASME containers.
- Diminishing the size and cost of protective hoods.
- Providing generous sized wrenching bosses for quick, easy installation.

RegO Multivalves® Reduce LPG Dealer Expenses by

- Permitting on-site filling of 100 lb. to 420 lb. DOT cylinders, thus eliminating cylinder return and interrupted customer service.
- Providing well-placed hose connections for easy filling.
- Allowing ample space for secure attachment and easy removal of the regulator.
- Providing substantial savings of bonnet repairs on valves with the MultiBonnet®.

RegO Multivalves® Satisfy Customer Demands for Tough, Safe Equipment with These Features

Heavy-Duty Valve Stem Seals —

- Tapered nylon disc in a fully confined seat resist deterioration and provide hand-tight closings over a long service life.

Comprehensive Testing —

- Every Multivalve® must pass a stringent underwater leakage test prior to shipment.
- Multivalves® with pressure relief valves are individually tested and adjusted to assure proper pressure settings.
- Those equipped with excess flow checks are tested for compliance with published closing specifications and for leakage after closing.

Pressure Relief Valves and Other Devices —

- Multivalves® equipped with integral pressure relief devices employ full-capacity, "pop-action" reliefs with set pressures of 250 psig for ASME use and 375 psig for DOT cylinders.

Double Back-Check Filler Valves —

- Multivalves® with filling connections have double backcheck safety. If the upper check ceases to function, the lower stand-by check will continue to protect the filling connection from excessive leakage.


Ease of Maintenance —

- Standardization of parts makes it possible for one repair kit to maintain the bonnet assemblies of RegO® cylinder valves, service valves, motor fuel valves, and Multivalves®.

RegO Multivalves® fit every LP-Gas need.

- Wide selection of Multivalves® for domestic, commercial, and industrial needs are available.
- Multivalves® may be ordered with pressure relief, liquid level tube, filler valve, vapor equalizing valve, internal pipe connections, liquid filling and withdrawal connections, and 1/4" NPT tapped opening for pressure gauge with or without steel plug.


Design Features of RegO Multivalves®



RegO Multibonnet® Assemblies

Design Features of the MultiBonnet®

- Handwheel**
Aluminum die cast handwheel.
- Non-Rising Stem**
Designed to allow easy backseating and long service life.
- Upper Packing Assembly**
Contains both internal and external o-rings. Provides leak resistant performance.
- Internal O-ring**
- Lower Bonnet and Stem Assembly**
Machined brass construction offers durability to bonnet design.
- External O-ring**
- Nameplate**
Provides easy identification of the RegO MultiBonnet®.
- Teflon Backseat**
Provides for upper packing isolation when valve is fully open.
- Machined Double Lead Threads**
Provides for quick opening and closing of the valve.
- Shut-off Seat Disc**
Tapered nylon disc is retained in a fully confined seat that helps ensure positive shut-offs.



Application

The MultiBonnet® is designed to allow quick and easy repair of bonnet packings in certain Multivalves® and service valves on active propane systems. It allows you to repair valve bonnet stem o-ring leaks in minutes, without interrupting gas service to your customers.

- Eliminates the need to evacuate tanks or cylinders to repair the MultiBonnet® packing.
- Two section design allows repair of MultiBonnet® assemblies on active propane systems without interruption in gas service or shutting off appliances downstream. This helps to prevent time consuming relighting of pilots, special appointments, and call backs.
- Cost of replacing the MultiBonnet® packing is only 1/3 as much as replacing a complete bonnet assembly—not including time cost savings, which can be substantial.

- Available on certain new Multivalves® and service valves as well as repair assemblies for many existing RegO® valves.
- UL listed as a component of valve assembly.

Here's How The MultiBonnet® Works

- When the valve is fully open, only the lower stem will rise and backseat against the teflon washer which isolates the upper packing.
- This allows you to remove the upper packing nut, which contains the o-rings, and replace it while the valve is fully open and gas service not interrupted.

ASME Multivalves® for Vapor Withdrawal G8475R Series

Application

These Multivalves® are designed for use in single opening ASME containers equipped with a 2½" M. NPT riser. They can be used with underground ASME containers up to 639 sq. ft. surface area, and above ground ASME containers up to 192 sq. ft. surface area. A separate opening is required for liquid withdrawal. The MultiBonnet® is standard on this valve.

Features

- The most complete Multivalve® assembly in the LP-Gas industry.
- Combines double back check filler valve, vapor equalizing valve with excess flow, pressure relief valve with protective cap and chain, service line shut-off valve, fixed liquid level gauge, "junior" size float gauge flange opening and plugged pressure gauge opening in one unit.
- **Designed for installation of a 1/8" FNPT pressure gauge or pressure gauge connection. The pressure test port will communicate to the downstream side of the service valve.**
- Double back check filler valve has filling capacities matched to the high capacity pumps and meters on modern delivery trucks.
- Vapor equalizing valve with excess flow has increased capacity matched to the filler valve.
- Internal threads accommodate 2½" M. NPT riser pipe connection and a ¾" F. NPT connection for a customer furnished liquid baffle tube.
- MultiBonnet® allows quick and easy repair of bonnet.


Materials

Body Forged Brass
Handwheel..... Aluminum Die Cast
Valve Stems..... Brass
O-Rings Resilient Rubber
Seat Disc (shut-off valve) Nylon
Seat Disc (other)..... Resilient Rubber
Relief Spring..... Stainless Steel




Ordering Information

Part Number	Container Connection	Service Connection	Filling Connection	Relief Valve Height	Vapor Equalizing Connection		Float Guage Flange Opening	Fixed Liquid Level Vent Valve	Dip Tube Length	Pressure Relief Valve				For use in conainers w/ surface are up to:
					Size	UL Listed Closing Flow				Setting	Part Number	Flow Capacity		
UL	ASME													
G8475RV	2½" F. NPT	F. POL (CGA 510)	1¾" M. ACME	6¾"	1¼" M. ACME	4200 CFH @ 100 PSIG	Fits "JUNIOR" size	Yes	30"*	250 PSIG	M3131G	2020 SCFM, air	1939 SCFM, air	83 sq. ft. above ground
G8475RW				8½"							MV3132G	3995 SCFM, air	n/a	192 sq. ft. above ground 639 sq. ft under ground



G8475R

With the service valve closed the pressure port will be isolated from the container. This will allow a high pressure leak test to be conducted without disconnecting the pigtail from the service valve.



Part Number	Approximate Filling Rate Liquid Flow, GPM			
	Pressure Drop Across Valve			
	10 PSIG	25 PSIG	50 PSIG	100 PSIG
G8475RV	42	72	98	125
G8475RW				

ASME Multivalves® for Vapor Withdrawal 8593AR

Application

These Multivalves® provide vapor withdrawal and filling of ASME containers. A separate pressure relief valve is required in addition to this valve. The MultiBonnet® is standard on this valve.

Features


- Combines double back check filler valve, service valve, vapor equalizing valve with excess flow, fixed liquid level gauge and plugged pressure gauge opening in one unit.
- Includes plugged, 1/4" F. NPT gauge boss.
- "Y" shape configuration allows for ease of operation with all valves and gauges easily accessible at all times.
- Large 21/16" hex wrenching boss on center column provides ease of installation in tank coupling.
- MultiBonnet® allows quick and easy repair of bonnet.

Materials


Body Forged Brass
Handwheel..... Aluminum Die Cast
Valve Stem Brass
O-Ring Resilient Rubber
Seat Disc (shut-off valve) Nylon
Seat Discs (other)..... Resilient Rubber



8593AR



1/4" Steel Plug
Installed



Liquid Filling Rates

Part Number	Approximate Filling Rate Liquid Flow, GPM			
	Pressure Drop Across Valve			
	10 PSIG	25 PSIG	50 PSIG	100 PSIG
8593AR16.0	42	72	98	125

Ordering Information

Part Number	Container Connection	Service Connection	Filling Connection	Vapor Equalizing Connection		Fixed Liquid Level Vent Valve Style	Dip Tube Length	For Use In Containers w/ Surface Area Up To:
				Connection Size	UL Listed Closing Flow			
8593AR16.0	1 1/2" M. NPT	F. POL (CGA 510)	1 1/4" M. ACME	1 1/4" M. ACME	4200 CFH at 100 PSIG	Knurled	16"*	**

*Dip tube not installed, may be cut by customer to desired length.

**Since these Multivalves® have no integral pressure relief valves, they can be used on any ASME container with an independent relief device sufficient for that tank's capacity.

DOT Multivalve® for Liquid Withdrawal 8555DL

Application

These Multivalves® permit liquid withdrawal from DOT cylinders with up to 100 lbs. propane capacity. They eliminate unnecessary cylinder handling when servicing high volume loads and allow on-site filling into the vapor space without interrupting gas service.

Features


- Incorporates service valve, high capacity filler valve with integral back-check, fixed liquid level gauge, liquid withdrawal with excess flow check and pressure relief valve in one single unit.
- CGA 555 service connection minimizes accidental connection to vapor service systems.
- Furnished with 44" long, ½" O.D. brass liquid withdrawal tube.
- Liquid withdrawal tube incorporates a ball check excess flow valve that opens by allowing vapor, not liquid, to equalize pressure.
- 11⁄8" wrenching flats.

Materials

Body	Forged Brass
Handwheel.....	Aluminum Die Cast
Valve Stems.....	Brass
O-Rings	Resilient Rubber
Seat Disc (shut-off valve)	Nylon
Seat Disc (others).....	Resilient Rubber
Relief Spring.....	Stainless Steel



8555DL



Liquid Filling Rates

Part Number	Approximate Filling Rate Liquid Flow, GPM			
	Pressure Drop Across Valve			
	10 PSIG	25 PSIG	50 PSIG	100 PSIG
8555DL11.6	8	23	34	42

Ordering Information

Part Number	Container Connection	Service Connection	Filling Connection	Fixed Liquid Level Vent Valve Style	Dip Tube Length w/ Deflector	Liquid Withdrawal Tube Length	Pressure Relief Valve Setting	For Use In Cylinders w/Propane Capacity Up To:	Liquid Closing Flow (LP-Gas)***
8555DL11.6	¾" M. NGT	CGA 555*	1¾" M. ACME	Knurled	11.6"	44"	375 PSIG	100 lbs. **	1.7 GPM

* Use adapter 12982 to connect to pipe threads.

** Per CGA Pamphlet S-1.1.

*** To ensure proper functioning and maximum protection from integral excess flow valves, the cylinder valve should be fully opened and backseated when in use.

DOT Multivalves® for Vapor Withdrawal 6555R, 8555D and 8555R Series

Application

These Multivalves® permit vapor withdrawal. They allow for container filling without interrupting gas service.

The 6555R Series is designed for ASME containers with up to 25 ft² surface area or 60 gallons water capacity.

The 8555D and 8555R Series are designed for DOT cylinders with up to 200 lbs. propane capacity.

Features

- Incorporates service valve, high capacity filler valve with integral back-check, fixed liquid level gauge and pressure relief valve in one single unit.
- Filler Valve is high capacity with integral back check.
- Heavy duty O-ring stem seal provides positive leak proof seal.
- Tapered nylon shut-off seat disc in fully confined seat ensures easy, leak-free, positive shut-off.
- 1½" wrenching flats.
- The MultiBonnet® option allows quick and easy repair of bonnet.

Materials

Body	Forged Brass
Handwheel.....	Aluminum Die Cast
Valve Stems.....	Brass
O-Rings	Resilient Rubber
Seat Disc (shut-off valve)	Nylon
Seat Disc (others).....	Resilient Rubber
Relief Spring.....	Stainless Steel




Liquid Filling Rates

Part Number	Approximate Filling Rate Liquid Flow, GPM			
	Pressure Drop Across Valve			
	10 PSIG	25 PSIG	50 PSIG	100 PSIG
8555D Series	8	23	34	42
8555R Series				

Ordering Information

Part Number	Bonnet Style	Application	For Use In Containers with Size Up To:	Dip Tube Length w/Deflector	Container Connection	Service Connection	Filling Connection	Fixed Liquid Level Vent Valve	Pressure Relief Valve		
									Setting	Flow Capacity*	
										UL Listing	ASME
6555R10.6	MultiBonnet®	ASME Containers	25 ft² surface area or 60 gallons water capacity	10.6"	¾" M. NGT	F. POL (CGA 510)	1¼" M. ACME	Yes	250 PSIG	793 SCFM, air	700 SCFM, air
6555R11.6	MultiBonnet®			11.6"							
6555R12.0	MultiBonnet®			12.0"							
8555D10.6	Standard	DOT Cylinders	200 lbs. Propane **	10.6"	¾" M. NGT	F. POL (CGA 510)	1¼" M. ACME	Yes	375 PSIG	n/a	n/a
8555R10.6	MultiBonnet®			10.6"							
8555D11.6	Standard			11.6"							
8555R11.6	MultiBonnet®										

*Per CGA Pamphlet S-1.1.



DOT and ASME Multivalves® for Vapor Withdrawal 6532, 6533, 6542 and 6543 Series

Application


These Multivalves® permit vapor withdrawal from ASME containers up to 50 sq. ft. surface area and DOT containers up to 420 lbs. propane capacity. They allow on-site cylinder filling without interrupting gas service.

Features 6542 and 6543

- Incorporates high capacity filler valve with double back checks, service valve, fixed liquid level gauge, pressure relief valve and built-in baffle tube into one compact unit.
- Higher filling capacity is combined with back check protection by placing the secondary back check at the bottom of the baffle tube, creating a larger flow area through the body.
- Pre-drilled hole in 1¼" wrenching flat accepts a drive screw for attaching relief cap and chain.

Features 6532 and 6533

- Similar but smaller than the 6542 and 6543, these are generally used for replacement on existing containers with ¾" NGT openings.
- Secondary back check placed in the body of the valve to help minimize reverse flow in the event the upper back check shears off or requires replacement.
- The MultiBonnet® option allows quick and easy repair of bonnet.



Materials

Body Forged Brass
Handwheel..... Aluminum Die Cast
Valve Stems..... Brass
O-Rings Resilient Rubber
Seat Disc (shut-off valve) Nylon
Seat Disc (others)..... Resilient Rubber
Relief Spring Stainless Steel

Liquid Filling Rates

Part Number	Approximate Filling Rate -- Liquid Flow, GPM			
	Pressure Drop Across Valve			
	10 PSIG	25 PSIG	50 PSIG	100 PSIG
6532A12.0/6532R12.0	11	16	23	28
6542A12.0/6542R12.0	23	32	46	57
6533A10.5/6533R10.5	11	16	23	28
6533A11.7/6533R11.7				
6543A11.1/6543R11.1	23	32	46	57
6543A11.7/6543R11.7				

Ordering Information

Part Number	Bonnet Style	Application	Container Connection	Service Connection	Filling Connection	Fixed Liquid Level Vent Valve Style	Dip Tube Length with Deflector	Pressure Relief Valve Setting	For Use In Cylinders w/Propane Capacity Up To:**	For Use In Containers w/Surface Area Up To:***	
6532A12.0	Standard	ASME*	¾" M. NGT	F. POL (CGA 510)	1¾" M. ACME	Knurled	12.0"	250 PSIG	-	43 sq. ft.	
6532R12.0	MultiBonnet®		1" M. NGT							53 sq ft.	
6542A12.0	Standard						DOT	¾" M. NGT	10.5"	375 PSIG	420 lbs. Propane
6542R12.0	MultiBonnet®		1" M. NGT								
6533A10.5	Standard	1" M. NGT						11.1"			
6533R10.5	MultiBonnet®								11.7"		
6533A11.7	Standard							11.7"			
6533R11.7	MultiBonnet®										
6543A11.1	Standard										
6543R11.1	MultiBonnet®										
6543A11.7	Standard										
6543R11.7	MultiBonnet®										

* UL rated flow capacities are: 6532A12.0-1180 SCFM/air, 6542A12.0-1530 SCFM/air.

** Per CGA Pamphlet S-1.1.

*** From NFPA, Appendix D.

ASME Multivalves® for Vapor Withdrawal 7556R

Application



These compact Multivalves® are especially suited for vapor withdrawal of ASME containers where compact groupings of components are necessary. Separate filler valves and pressure relief valves are required.

Features

- Combines service valve, vapor equalizing valve with excess flow, fixed liquid level gauge and plugged pressure gauge opening in one unit.
- Rugged, 1" wrenching boss on center column minimizes possible damage during installation.
- Low profile design extends only 3" above the container boss, allowing use of smaller domes.
- "Y" shape configuration allows for ease of operation with all valves and gauges easily accessible at all times.
- Designed for installation of a 1/8" M.NPT pressure gauge or pressure gauge connection. The pressure test port will communicate to the downstream side of the service valve.
- MultiBonnet® allows quick and easy repair of bonnet.

Materials


Body	Forged Brass
Handwheel.....	Aluminum Die Cast
Valve Stems.....	Brass
O-Rings	Resilient Rubber
Seat Disc (shut-off valve)	Nylon
Seat Disc (others).....	Resilient Rubber



7556R

New Style 7556R Series with 1/8" FNPT pressure test port.

1/8" F-NPT Pressure Test Port is isolated from the container when the service valve is closed.



With the service valve closed the pressure test port will be isolated from the container. This will allow a high-pressure leak test to be conducted without disconnecting the pigtail from the service valve.



Ordering Information

Part Number	Container Connection	Service Connection	Vapor Equalization Connection		Fixed Liquid Level Vent Valve	Dip Tube Length	For Use In Containers w/ Surface Area Up To:
			Connection Size	UL Listed Closing Flow			
7556R12.0	3/4" M. NGT	F. POL (CGA 510)	1 1/4" M. ACME	4200 CFH @ 100 PSIG	Yes	12"***	*

* Since these Multivalves® have no integral pressure relief valves, they can be used on any ASME container with an independent relief device sufficient for that tank's capacity.

** Other tube lengths available.

Valves with Presto-Tap PG8475, PT7556 Series Valves

PG8475 Series Multivalves

Designed for use in single opening ASME containers equipped with a 2 1/2" M. NPT riser. They can be used with underground ASME containers up to 639 sq. ft. surface area, and above ground ASME containers up to 192 sq. ft. surface area. A separate opening is required for liquid withdrawal.

Part Number	Approximate Filling Rate Liquid Flow, GPM			
	Pressure Drop Across Valve			
	10 PSIG	25 PSIG	50 PSIG	100 PSIG
PG8475RV	42	72	98	125
PG8475RW				



Part Number	Container Connection	Service Connection	Filling Connection	Vapor Equalizing Connection		Float Guage Flange Opening	Fixed Liquid Level Vent Valve	Dip Tube Length	Pressure Relief Valve				For use in conatiners w/ surface are up to:
				Size	UL Listed Closing Flow				Setting	Part Number	Flow Capacity		
											UL	ASME	
PG8475RV	2½" F. NPT	F. POL (CGA 510)	1¼" M. ACME	1¼" M. ACME	4200 CFH @ 100 PSIG	Fits "JUNIOR" size	Yes	30"	250 PSIG	M3131G	2020 SCFM, air	1939 SCFM, air	83 sq. ft. above ground
PG8475RW										MV313269	3995 SCFM, air	n/a	276 sq. ft. under ground
													192 sq. ft. above ground

* Dip tube not installed, may be cut by customer to desired length.

PT7556 R Multivalve®

Especially suited for vapor withdrawal of ASME containers where compact groups of components are necessary. Separate filler valves and pressure relief valves are required



Part Number	Container Connection	Service Connection	Vapor Equalization Connection		Fixed Liquid Level Vent Valve	Dip Tube Length	For Use In Containers w/Surface Area Up To:
			Connection Size	UL Listed Closing Flow			
PT7556R12.0	3/4" M. NGT	F. POL (CGA 510)	1 1/4" M. ACME	4200 CFH @ 100 PSIG	Yes	12"	*

* Since these MultiValves® have no integral pressure relief valves, they can be used on any ASME container with an independent relief device sufficient for the tanks capacity.

** Other dip tube lengths available.

Warning Notice

The following warning information, Part Number 903-500, is included with each shipment of Multivalve® Assemblies to the first purchaser of the product from the factory.

This information is intended to be forwarded throughout the product distribution chain. Additional copies are available from REGO® and Authorized Product Distributors.

DANGER	READ THIS FIRST	WARNING
LP-GAS IS EXTREMELY FLAMMABLE AND EXPLOSIVE		
AVOID SERIOUS INJURY AND PROPERTY DAMAGE. IF YOU SEE, SMELL OR HEAR ESCAPING GAS... EVACUATE AREA IMMEDIATELY! CALL YOUR LOCAL FIRE DEPARTMENT! DO NOT ATTEMPT TO REPAIR. DO NOT STORE IN BUILDING OR ENCLOSED AREA. DO NOT USE ON HOT AIR BALLOONS OR AIRCRAFT.		
Make sure you are thoroughly trained before you attempt any valve installation, maintenance or repair. Improper conditions or procedures can cause accidents resulting in property damage and personal injury.		
Become thoroughly familiar with NPGA Safety Pamphlet 306 "LP-Gas Regulator and Valve Inspections & Maintenance" and ECII "Safety Warnings: LP-Gas Cylinder Valves", "LP-Gas Excess Flow Valves", and "LP-Gas Filler and Hose End Filling Valves" found in the cylinder valve, excess flow valve, and filler valve sections of the L-500 & L-102 Catalogs. Follow their recommendations.		
Know and understand NFPA Pamphlet 58 "Liquefied Petroleum Gas Code", which is the law in many states. This publication is available from NFPA, Batterymarch Park, Quincy, MA 02269. Following its requirements is essential in the safe use of LP-Gas. Section 4.4 states: persons who transfer liquid LP-Gas, who are employed to transport LP-Gas, or whose primary duties fall within the scope of this code shall be trained in proper handling procedures. Refresher training shall be provided at least every three years and shall be documented.		
Make sure this valve is the proper one for this installation. Avoid misusing LP-Gas equipment.		
Apply thread joint compound compatible with LP-Gas on valve external threads only. Make sure compound never comes into contact with other parts of the valve.		
Install valves by applying force to wrenching flats only.		
Tighten pipe threads approximately 1 to 1½ turns beyond the hand-tight insertion point using a wrench which avoids damage to other valve parts.		
Check for damage and proper operation after valve installation. Check that the valve is clean and free of foreign material.		
Check container-valve connection with a non-corrosive leak detection solution before filling with LP-Gas.		
Purge container before filling with LP-Gas (refer to the ECII "LP-Gas Serviceman's Manual for recommended procedure).		
Test excess flow check valve for proper operation before placing into service. See NPGA Bulletin 113 for recommended procedure.		
Check outlet connection make-up for leaks with a non-corrosive leak detection solution when placing into service.		
RegO Products Filler Valves: To prevent damage to the internal checks when it is necessary to utilize an unloading adapter, use ONI Y RegO Products 3119A, 3120 and 3121 Unloading Adapters with RegO Products Filler Valves. Carefully follow the instructions supplied with these unloading adapters.		
If container is not being placed into service at the present time, insert plug or cap onto the outlet connection.		
In selecting a label for posting at the installation site, consider ECII "part number 901-400 or 903-400 along with your own, NPGAs and others.		
Remember to instruct the owner/user/customer in safety matters concerning LP-Gas and this equipment. See ECII "Safety Warnings: LP-Gas Cylinder Valves", "LP-Gas Excess Flow Valves", and "LP-Gas Filler and Hose End Filling Valves" found in the cylinder valve, excess flow valve, and filler valve sections of the L-500 & L-102 Catalogs.		
Engineered Controls International, Inc., ECII "requests that this information be forwarded to your customers. Additional copies are available from ECII " and your authorized ECII " Product Distributor.		
REGO		
Printed in USA 08-0809-0686 Part number 903-500		
100 RegO Drive PO Box 247 Elon, NC 27244 USA Phone (336) 449-7707 Fax (336) 449-6594 www.regoproducts.com		

Cross Reference by Part Number

6532A12.0.....	C10	7556R12.0.....	C11
6532R12.0.....	C10	PT7556R12.0.....	C12
6533A10.5.....	C10	G8475RV.....	C6
6533R10.5.....	C10	G8475RW.....	C6
6533A11.7.....	C10	PG8475RV.....	C12
6533R11.7.....	C10	PG8475RV.....	C12
6542A12.0.....	C10	PG8475RW.....	C12
6542R12.0.....	C10	PG8475RW.....	C12
6543A11.1.....	C10	8555D10.6.....	C9
6543R11.1.....	C10	8555R10.6.....	C9
6543A11.7.....	C10	8555D11.6.....	C9
6543R11.7.....	C10	8555DL11.6.....	C8
6555R10.6.....	C9	8555R11.6.....	C9
6555R11.6.....	C9	8593AR16.0.....	C7
6555R12.0.....	C9		



LP-Gas & Anhydrous Ammonia Equipment

D

Section D Pressure Relief Valves and Relief Valve Manifolds

Limited Warranty and Limitation of Liability

LIMITED 10 YEAR WARRANTY AND LIMITATION OF LIABILITY

LIMITED 10 YEAR WARRANTY

REGO® warrants to the original purchasers the products and repair kits manufactured by it to be free from defects in materials and workmanship under normal use and service for a period of 10 years from the date of manufacture. If within thirty days after buyer's discovery of what buyer believes is a defect, buyer notifies in writing and ships the product to REGO® at 100 Rego Drive, Elon, NC 27244, REGO®, at its option, and within forty-five days of receipt, will repair, replace F.O.B. point of manufacture, or refund the purchase price of that part or product found by REGO® to be defective. Failure of buyer to give such written notice and ship the product within thirty days shall be deemed an absolute and unconditional waiver of any and all claims of buyer arising out of such defect.

This warranty does not extend to any product or part that is not installed and used continuously after installation in accordance with REGO®'s printed instructions, all applicable state and local regulations, and all applicable national standards, such as those promulgated by NFPA, DOT and ANSI. This warranty does not extend to any product or part that has been damaged by accident, misuse, abuse, failure to maintain, or neglect, nor does it extend to any product or part which has been modified, altered, disassembled, or repaired in the field. This warranty does not cover any cosmetic issues, such as scratches, dents, marring, fading of colors or discoloration.

Except as expressly set forth above, and subject to the limitation of liability below, REGO® MAKES NO OTHER WARRANTY, EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, with respect to its products and parts, whether used alone or in combination with others. REGO® disclaims all warranties not stated herein.

LIMITATION OF LIABILITY

REGO®'s total liability for any and all losses and damages arising out of any cause whatsoever shall in no event exceed the purchase price of the products or parts in respect of which such cause arises, whether such cause be based on theories of contract, negligence, strict liability, tort or otherwise.

REGO® shall not be liable for incidental, consequential or punitive damages or other losses. REGO® shall not be liable for, and buyer assumes any liability for, all personal injury and property damage connected with the handling, transportation, possession, further manufacture, other use or resale of products, whether used alone or in combination with any other products or materials.

From time to time buyers might call to ask REGO® for technical advice based upon limited facts disclosed to REGO®. If REGO® furnishes technical advice to buyer, whether or not at buyer's request, with respect to application, further manufacture or other use of the products and parts, REGO® shall not be liable for such technical advice or any such advice provided to buyer by any third party and buyer assumes all risks of such advice and the results thereof.

NOTE: Some states do not allow the exclusion or limitation of incidental, consequential or punitive damages, so the above limitation or exclusion may not apply to you. The warranty gives you specific legal rights, and you may have other rights that vary from State to State. The portions of this limited warranty and limitation of liability shall be considered severable and all portions which are not disallowed by applicable law shall remain in full force and effect.

NOTICE TO USERS OF PRODUCTS

The Limited Warranty stated above is a factory warranty to the first purchasers of REGO® products. Since most users have purchased these products from REGO® distributors, the user must within thirty (30) days after the user's discovery of what user believes is a defect, notify in writing and return the product to the distributor from whom he purchased the product/part. The distributor may or may not at the distributor's option choose to submit the product/parts to REGO®, pursuant to this Limited Warranty. Failure by buyer to give such written notice within thirty (30) days shall be deemed an absolute and unconditional waiver of buyer's claim for such defects. Acceptance of any alleged defective product/parts by REGO®'s distributor for replacement or repairs under the terms of REGO®'s Limited Warranty in no way determines REGO®'s obligations under this Limited Warranty.

Because of a policy of continuous product improvement, REGO® reserves the right to change designs, materials or specifications without notice.

Foreword

This catalog describes a complete line of equipment available from REGO® for use with LP-Gas and anhydrous ammonia (NH₃). The following points are important to know for proper use of the catalog:

1. Illustrations and drawings of individual products are representative of “product groups” and all products within a product group are similar in construction.
2. Materials used for construction of products in this catalog are suitable for rated service pressure at temperatures of -40° F. to +165° F., unless otherwise specified.
3. Products in this catalog are only intended for use in LP-Gas and/or anhydrous ammonia service as follows.
 - a. “A” or “AA” prefix — Products with this prefix are suitable for NH₃ service (i.e., contain no brass parts).
 - b. “AA” prefix on relief valves — These valves are NOT suitable for use with LP-Gas service. These are of partial aluminum materials and are listed by Underwriters Laboratories (UL) for NH₃ service only.
 - c. All other products are suitable for use with LP-Gas service.
 - d. “SS” prefix—Hydrostatic relief valve with this prefix are suitable for NH₃ service (i.e., they have stainless steel materials).

Caution

Do not use any product contained in this catalog with any service commodity other than LP-Gas or NH₃. If you have a need for use of another application, contact REGO®, 100 RegO Drive, Elon, NC 27244, (336) 449-7707 before proceeding.

Proper application, installation and maintenance of products in this catalog are essential. Users of these products should obtain further information if there are any doubts or questions.

Warning

All REGO® products are mechanical devices that will eventually become inoperative due to wear, corrosion and aging of components made of materials such as rubber. The environment and conditions of use will determine the safe service life of these products. Periodic inspection and maintenance are essential to avoid serious injury and property damage.

Many REGO® products are manufactured for storage, transport, transfer and use of toxic flammable and dangerous liquids and gases. Such substances should be handled by experienced and trained personnel only, using accepted governmental and industrial safety procedures. Never vent LP-Gas near any possible source of ignition.

Notice

Installation, usage, and maintenance of all REGO® products must be in compliance with all REGO® instructions as well as requirements and provisions of NFPA #54, NFPA#58, DOT, ANSI, and all applicable federal, state, provincial and local standards, codes, regulations, and laws.

Inspection and maintenance on a periodic basis is essential. Installation and maintenance should be performed only by qualified personnel.

Be sure all instructions are read and understood before installation, operation and service.

Filters

REGO® LP-Gas equipment is designed to operate in a system free from contamination. A variety of in-line filters are commercially available to the LP-Gas industry for installation in domestic systems.

The use of an in-line filter should be considered when other system components may be unclean and the system contaminated by rust, scale, dirt, debris or other foreign material.

Contents

Page

Cross Reference by Part Number	D20
Duoport® Assemblies	D17
General Information	D6
Hydrostatic Relief Valves	D16
Multiport™ Assemblies	D18
“Pop-Action” Relief Valves	D10
Safety Warning	D4
Warnings	D20

Safety Warning — LP-Gas Pressure Relief Valves

Purpose

In its continuing quest for safety, REGO® is publishing safety warning bulletins explaining the hazards associated with the use, misuse and aging of REGO® Products. LP-Gas dealer managers and service personnel must realize that the failure to exercise the utmost care and attention in the installation, inspection and maintenance of these products can result in personal injury and property damage.

The National Fire Protection Association Pamphlet #58 - 2004 Edition, "Liquified Petroleum Gas Code" states in Section 1.5 that, "persons who transfer liquid LP-Gas, who are employed to transport LP-Gas, or whose primary duties fall within the scope of this code shall be trained in proper handling procedures. Refresher training shall be provided at least every three years. The training shall be documented. REGO® Warning Bulletins are useful in training new employees and reminding older employees of potential hazards.

This Warning Bulletin should be provided to all purchasers of REGO® and all personnel using or servicing these products. Additional copies are available from REGO® and your Authorized REGO® Distributor.

WARNING

What You Must Do:

- **Read This Entire Warning**
- **Install Properly**
- **Inspect Regularly**

Scope

This bulletin applies to pressure relief valves installed on stationary, portable and cargo containers and piping systems utilized with these containers. This bulletin is not intended to be an exhaustive treatment of this subject and does not cover all safety practices that should be followed in the installation and maintenance of LP-Gas systems. Each LP-Gas employee should be provided with a copy of NPGA Safety Pamphlet 306 "LP-Gas Regulator and Valve Inspection and Maintenance" as well as the NPGA "LP-Gas Training Guidebooks" relating to this subject.

Warnings should be as brief as possible. If there is a simple warning, it is:

Inspect pressure relief valves regularly. Replace unsafe or suspect valves immediately. Use common sense.

Inspect Regularly

A pressure relief valve discharges when some extraordinary circumstance causes an over pressure condition in the container. If a pressure relief valve is known to have discharged, the relief valve, as well as the entire system, should be immediately and thoroughly inspected to determine the reason for the discharge. In the case of discharge due to fire, the valve should be removed from service and replaced.

Relief valves should be inspected each time the container is filled but no less than once a year. If there is any doubt about the condition of the valve, it must be replaced.

Eye protection must be worn when performing inspection on relief valves under pressure. Never look directly into a relief valve under pressure or place any part of your body where the relief valve discharge could impact it. In some cases a flashlight and a small mirror are suggested to assist when making visual inspections.

To Properly Inspect A Pressure Relief Valve, Check For:

1. **A rain cap.** Check protective cap located in valve or at end of pipeaway for a secure fit. Protective caps help protect the relief valve against possible malfunction caused by rain, sleet, snow, ice, sand, dirt, pebbles, insects, other debris and contamination. **REPLACE DAMAGED OR MISSING CAPS AT ONCE AND KEEP A CAP IN PLACE AT ALL TIMES**
2. **Open weep holes.** Dirt, ice, paint and other foreign particles can prevent proper drainage from the valve body. **IF THE WEEP HOLES CANNOT BE CLEARED, REPLACE THE VALVE.**
3. **Deterioration and corrosion on relief valve spring.** Exposure to high concentrations of water, salt, industrial pollutants, chemicals and roadway contaminants could cause metal parts to fail. **IF THE COATING ON THE RELIEF VALVE SPRING IS CRACKED OR CHIPPED, REPLACE THE VALVE.**

Replace Pressure Relief Valves In 10 Years Or Less

The safe useful life of pressure relief valves can vary greatly depending on the environment in which they live.

Relief valves are required to function under widely varying conditions. Corrosion, aging of the resilient seat disc and friction all proceed at different rates depending upon the nature of the specific environment and application. Gas impurities, product misuse and improper installations can shorten the safe life of a relief valve.

Predicting the safe useful life of a relief valve obviously is not an exact science. The conditions to which the valve is subjected will vary widely and will determine its useful life. In matters of this kind, only basic guidelines can be suggested. For example, the Compressed Gas Association Pamphlet S-1.1 Pressure Relief Device Standards — Cylinders, section 9.1.1 requires all cylinders used in industrial motor fuel service to have the cylinder's pressure relief valves replaced by new or unused relief valves within twelve years of the date of manufacture of cylinder and within each ten years thereafter. The LP-Gas dealer must observe and determine the safe useful life of relief valves in his territory. The valve manufacturer can only make recommendations for the continuing safety of the industry.

4. **Physical damage.** Ice accumulations and improper installation could cause mechanical damage. **IF THERE ARE ANY INDICATIONS OF DAMAGE, REPLACE THE VALVE.**

5. **Tampering or readjustment.** Pressure relief valves are factory set to discharge at specified pressures. **IF THERE ARE ANY INDICATIONS OF TAMPERING OR READJUSTMENT, REPLACE THE VALVE.**

6. **Seat leakage.** Check for leaks in the seating area using a noncorrosive leak detection solution. **REPLACE THE VALVE IF THERE IS ANY INDICATION OF LEAKAGE.** Never force a relief valve closed and continue to leave it in service. This could result in damage to the valve and possible rupture of the container or piping on which the valve is installed.

7. **Corrosion and contamination. REPLACE THE VALVE IF THERE ARE ANY SIGNS OF CORROSION OR CONTAMINATION ON THE VALVE.**

8. **Moisture, foreign particles or contaminants in the valve.** Foreign material such as paint, tar or ice in relief valve parts can impair the proper functioning of the valves. Grease placed in the valve body may harden over time or collect contaminants, thereby impairing the proper operation of the relief valve. **DO NOT PLACE GREASE IN THE VALVE BODY, REPLACE THE VALVE IF THERE ARE ANY INDICATIONS OF MOISTURE OR FOREIGN MATTER IN THE VALVE.**

9. **Corrosion or leakage at container connection.** Check container to valve connection with a non-corrosive leak detection solution. **REPLACE THE VALVE IF THERE IS ANY INDICATION OF CORROSION OR LEAKAGE AT THE CONNECTION BETWEEN THE VALVE AND CONTAINER.**

CAUTION: Never plug the outlet of a pressure relief valve. Any device used to stop the flow of a properly operating pressure relief valve that is venting an overfilled or overpressurized container - raises serious safety concerns!

WARNING: Under normal conditions, the useful safe service life of a pressure relief valve is 10 years from the original date of manufacture. However, the safe useful life of the valve may be shortened and replacement required in less than 10 years depending on the environment in which the valve lives. Inspection and maintenance of pressure relief valves is very important. Failure to properly inspect and maintain pressure relief valves could result in personal injuries or property damage.

For Additional Information Read:

1. CGA Pamphlet S-1.1 Pressure Relief Standards - Cylinders, Section 9.1.1.
2. REGO® Catalog L-500.
3. REGO® Warning # 8545-500.
4. NPGA Safety Pamphlet 306 "LP-Gas Regulator and Valve Inspection and Maintenance" and "LP-Gas Training Guidebooks".
5. NFPA # 58, "Storage and Handling of Liquefied Petroleum Gases".
6. NFPA # 59, "LP-Gases at Utility Gas Plants".
7. ANSI K61.1 Safety Requirements for Storage and Handling of Anhydrous Ammonia.

RegO® Pressure Relief Valves

Requirements for Pressure Relief Valves

Every container used for storing or hauling LP-Gas and anhydrous ammonia must be protected by a pressure relief valve. These valves must guard against the development of hazardous conditions which might be created by any of the following:

- Hydrostatic pressures due to overfilling or the trapping of liquid between two points.
- High pressures resulting from exposure of the container to excessive external heat.
- High pressures due to the use of incorrect fuel.
- High pressures due to improper purging of the container.

Consult NFPA Pamphlet #58 for LP-Gas and ANSI #K61.1 for anhydrous ammonia, and/or any applicable regulations governing the application and use of pressure relief valves.

Operation of Pressure Relief Valves

Pressure relief valves are set and sealed by the manufacturer to function at a specific "start-to-discharge" pressure in accordance with regulations. This set pressure, marked on the relief valve, depends on the design requirement of the container to be protected by the relief valve. If the container pressure reaches the start-to-discharge pressure, the relief valve will open a slight amount as the seat disc begins to move slightly away from the seat. If the pressure continues to rise despite the initial discharge through the relief valve, the seat disc will move to a full open position with a sudden "pop". This sharp popping sound is from which the term "pop-action" is derived.

Whether the relief valve opens a slight amount or pops wide open, it will start to close if the pressure in the container diminishes. After the pressure has decreased sufficiently, the relief valve spring will force the seat disc against the seat tightly enough to prevent any further escape of product. The pressure at which the valve closes tightly is referred to as the "re-seal" or "blow-down" pressure. Generally, the re-seal pressure will be lower than the start-to-discharge pressure. The re-seal pressure can be, and in most cases is, adversely affected by the presence of dirt, rust, scale or other foreign particles lodging between the seat and disc. They interfere with the proper mating of the seat and disc and the pressure in the container will usually have to decrease to a lower pressure before the spring force embeds foreign particles into the resilient seat disc material and seals leak-tight. The degree by which the presence of dirt decreases the re-seal pressure, is, of course, dependent on the size of the interfering particles.

Once particles have been trapped between the disc and seat, the start-to-discharge pressure is also affected. For example, the pressure relief valve will start-to-discharge at some pressure lower than its original start-to-discharge pressure. Again, the pressure at which the valve will start to discharge is dependent on the size of the foreign particles.

In the case of a pressure relief valve that has opened very slightly due to a pressure beyond its start-to-discharge setting, the chances of foreign material lodging between the seat and disc is negligible although the possibility is always present. If the relief valve continues to leak at pressures below its start-to-discharge setting it must be replaced.

Relief valves which have "popped" wide open must also be checked for foreign material lodged between the seat and disc, as well as for proper reseating of the seat and disc. Continued leakage at pressures below the start-to-discharge setting indicate the relief valve must be replaced.

The pressure at which a pressure relief valve will start to discharge should never be judged by the reading of the pressure gauge normally furnished on the container.

The reasons for this are two-fold:

- If the relief valve is called upon to open, the resulting discharge produces an increased vaporization of the product in the container with the result that the liquid cools to a certain extent and the vapor pressure drops. A reading taken at this time would obviously not indicate what the pressure was when the relief valve opened.
- The pressure gauges usually on most containers provide somewhat approximate readings and are not intended to provide an indication of pressure sufficiently accurate to judge the setting of the relief valve.

Repair and Testing

RegO® Pressure Relief Valves are tested and listed by Underwriters Laboratories, Inc., in accordance with NFPA Pamphlet #58. Construction and performance of RegO® Pressure Relief Valves are constantly checked at the factory by U.L. inspectors. Therefore, testing of RegO® Pressure Relief Valves in the field is not necessary.

Any pressure relief valve which shows evidence of leakage, other improper operation or is suspect as to its performance must be replaced immediately using approved procedures.

Pipe-Away Adapters

Pipe-away adapters are available for most RegO® Pressure Relief Valves, where it is required or desirable to pipe the discharge above or away from the container. Each adapter is designed to sever if excessive stress is applied to the vent piping – thus leaving the relief valve fully operative.

Weep hole deflectors are available on larger relief valves. These deflectors provide protection against flame impinging on adjacent containers which could occur from ignition of LP-Gas escaping through the relief valve drain hole when the valve is discharging.

Selection of RegO® Pressure Relief Valves For ASME Containers

The rate of discharge required for a given container is determined by the calculation of the surface area of the container as shown in "Chart A" for LP-Gas and "Chart B" for anhydrous ammonia. See page D9.

Setting - The set pressure of a pressure relief valve depends upon the design pressure of the container. Refer to NFPA Pamphlet #58 for more information.

Selection of RegO® Pressure Relief Valves for DOT Containers

To determine the proper relief valve required for a given DOT container, refer to the information shown with each pressure relief valve in the catalog. This information will give the maximum size (pounds water capacity) DOT container for which the relief valve has been approved.

Setting - The standard relief valve setting for use on DOT cylinders is 375 PSIG.

RegO® Pressure Relief Valves

Ordering RegO® Pressure Relief Valves


When ordering RegO® Pressure Relief Valves, be sure you are certain that it will sufficiently protect the container as specified in the forewording information, NFPA Pamphlet #58 and any other applicable standards or specifications.

All adapters, protective caps and deflectors must be ordered separately, unless specified otherwise.

Part Number Explanation

Products carrying an "A" or "AA" prefix contain no brass parts and are suitable for NH3. Hydrostatic relief valves carrying an "SS" prefix are of stainless steel construction and are suitable for use with NH3. The products are also suitable for use with LP-Gas service except relief valves carrying an "AA" prefix. These are of partial aluminum construction and are listed by U.L. for NH3 service only.

Safety Information - Relief Valves Don't Last Forever



RegO® Relief Valve for lift truck containers

The internal spring is protected from external contamination but the other external parts must be protected with a cap. Circular rubber seat disc ring seats on brass shoulder approximately 3/64" wide.

This article was prepared by the engineers of RegO® products, after technical consultation with valve manufacturers and other industry sources. Its purpose is to alert and remind the LP-Gas industry of the importance of proper maintenance of pressure relief valves. It applies most particularly to separate relief valves with emphasis on lift truck and motor fuel containers where the hazards of contamination are greatest.

Since the beginning of our industry, manufacturers of equipment and distributors of LP-Gas have worked diligently to provide a safe environment for employees and consumers. The history of the industry testifies to the success of their efforts.

But the industry is now entering its sixth decade and equipment installed years ago is failing because of age. Every year, additional equipment will fail unless it is replaced. Pressure relief valves are no exception. The valve manufacturers and LP-Gas dealers are naturally concerned about this situation.

Causes of Relief Valve Failure

A relief valve is designed to have a safe useful life of many years, but that life will vary greatly depending on the environment in which it "lives." To attempt to estimate the safe useful life of a relief valve and the effect of environment on its performance, a brief discussion of the materials used and the nature of its performance should be helpful.

Relief valve bodies are generally made of brass or steel. Springs are made from various spring wires which are plated or painted, or made of stainless steel. Valve seat discs are made of synthetic rubber compounds which will remain serviceable in an atmosphere of LP-Gas. Relief valve stems, guides, etc. are generally made from brass or stainless steel.

Relief valves, over the years, may not function properly in several ways:

- They may leak at pressures below the set pressure.
- They may open and fail to properly reseal.
- They may open at higher than the set pressure.

These failures to function properly are due primarily to four "environmental" conditions:

1. Corrosion of metal parts (particularly springs) which result in the component parts failing to perform.
2. Deterioration of the synthetic rubber seat disc material.
3. Clogging or "cementing" of the movable relief valve components so that their movement is restricted.
4. Debris on the valve seat after the relief valve opens, effectively preventing the valve from reseating.

Corrosion is caused by water, corrosive atmospheres of salt and industrial pollutants, chemicals, and roadway contaminants. High concentrations can attack the metal parts vigorously. No suitable metals are totally resistant to such corrosion.

Synthetic rubber and seat disc materials can also be attacked by impurities in the gas and corrosive atmospheres, particularly those with sulphur dioxide. There are no suitable rubber materials which resist all contaminants.

"Cementing" of relief valve parts has been caused by normal industrial atmospheres containing particles of dirt, iron oxide, metal chips, etc. combined with water, oil, or grease. Ice collecting in recessed valves could cause relief valves to fail to open. Paint and tar in relief valves also cause failure to function properly.

Safety Information - Relief Valves Don't Last Forever

Debris on valve seats which prevents reseating can occur whenever the valve collects material in the relief valve opening which is not blown out when the relief valve opens.

Inspection of Relief Valves

Unfortunately many of the above problems may not be easily observed because of the compact nature of some relief valve designs.

A casual visual inspection of a relief valve may not necessarily disclose a potential hazard. On the other hand, a visual inspection will often disclose leakage, corrosion, damage, plugging and contamination.

If additional light is required, a flashlight should be used.

If there is any doubt about the condition of the valve, or if there is a suspicion that the valve has not been protected by a cap for some time, it should be replaced before refilling the container.

Eye protection must be used when examining relief valves under pressure.

Smaller Relief Valves

The industry's requirement for a small full-flow safety relief valve challenged design engineers some years ago:

- The valve must be leakproof before operating and must reseat leakproof each time after each operation. The only known satisfactory seat disc materials to accomplish this have been special synthetic rubber compounds.
- Valve discharge settings are relatively high and require high spring loads to keep the valve closed.
- Because of the small interior diameter of the valve, the round metal seating area is small.

All of these parameters may result in the development of a significant indentation in the rubber seat disc after some years. The seat disc may have a tendency to cling to the metal seat. This may result in the relief valve not opening at the set pressure as the seat disc ages.

Tests have been conducted on small LP-Gas relief valves of all the U.S. valve manufacturers. Valves over 10 years old were removed from service and tested to determine at what pressure the valves discharged. In many of the valves, the pressure required to open the valve exceeded the set pressure.

Because of the critical importance of proper functioning of relief valves, common sense and basic safety practice dictate that small relief valves should be replaced in about 10 years.

Some larger relief valves on bulk storage tanks can be replaced with rebuilt valves obtained from the manufacturers. Small relief valves cannot be rebuilt economically, thus, new valves are required. Most LP-Gas dealers find it impractical and costly to test relief valves and field repairing of relief valves is not sanctioned by the manufacturers, Underwriter's Laboratories, or ASME.

Use of Protective Caps

Many of the problems that cause inoperative relief valves could be prevented if proper protective caps were kept in place at all times.

Collection of debris would be prevented. Contamination caused by corrosive atmospheres would be reduced. Water collection in the valves would be eliminated. Relief valves protected with caps from the time of installation in the container would obviously have a much longer safe useful life, but they still should be replaced at some time because of the gradual deterioration of the rubber seat disc due to age alone.

NFPA 58 requires that protective caps must be kept in place as a protective cover on some relief valves. This is a mandatory requirement on several types of relief valves. The fact that use of caps may make inspection more time consuming should not be viewed as a reason for either not using the caps, or not making required periodic inspections.

In the event a relief valve has been used without the required cap, the relief valve should be thoroughly inspected and the required cap placed on the relief valve. If damage is noted to the relief valve, it should be replaced and the replacement valve should be capped. Relief valves with pipe-away adapters or deflectors used on lift truck containers have been found choked with debris. Inspection of relief valves with deflectors can only be accomplished by removing the deflector.

Similarly, larger relief valves with vent stacks have been found choked with debris and water. Valves have failed because springs rusted through. The weep hole was plugged. It was obvious that the relief valves had not been inspected in many years. These conditions must be alleviated by periodic inspections and replacement of relief valves as needed.

Summary Recommendations

Predicting the safe useful life of a relief valve is obviously not an exact science. The conditions to which the valve is subjected will vary widely and will largely control its life. In matters of this kind, only basic guidelines can be suggested. The LP-Gas dealer must observe and determine the safe useful life of relief valves in his territory. The valve manufacturers can only make recommendations for the continuing safety of the industry:

1. Make sure proper protective caps are in place at all times. Do not release a container for service or fill a container unless it has a protective cap in place.
2. Replace relief valves periodically, at least every 10 years. Every relief valve has the month and year of manufacture stamped on the valve. This is most particularly true of small separate relief valves.
3. Carefully inspect valves each time before the container is filled. Replace valves showing any signs of contamination, corrosion, damage, plugging, leakage, or any other problem. Eye protection must be used when examining relief valves under pressure.

Chart A — Minimum Required Rate of Discharge for LP-Gas Pressure Relief Valves Used on ASME Containers

From NFPA Pamphlet #58, Appendix D (1986).

Minimum required rate of discharge in cubic feet per minute of air at 120% of the maximum permitted start-to-discharge pressure for pressure relief valves to be used on containers other than those constructed in accordance with Interstate Commerce Commission specification.

Surface Area Sq. Ft.	Flow Rate SCFM Air	Surface Area Sq. Ft.	Flow Rate SCFM Air	Surface Area Sq. Ft.	Flow Rate SCFM Air	Surface Area Sq. Ft.	Flow Rate SCFM Air	Surface Area Sq. Ft.	Flow Rate SCFM Air	Surface Area Sq. Ft.	Flow Rate SCFM Air	Surface Area Sq. Ft.	Flow Rate SCFM Air
20 or less	626	85	2050	150	3260	230	4630	360	6690	850	13540	1500	21570
25	751	90	2150	155	3350	240	4800	370	6840	900	14190	1550	22160
30	872	95	2240	160	3440	250	4960	380	7000	950	14830	1600	22740
35	990	100	2340	165	3530	260	5130	390	7150	1000	15470	1650	23320
40	1100	105	2440	170	3620	270	5290	400	7300	1050	16100	1700	23900
45	1220	110	2530	175	3700	280	5450	450	8040	1100	16720	1750	24470
50	1330	115	2630	180	3790	290	5610	500	8760	1150	17350	1800	25050
55	1430	120	2720	185	3880	300	5760	550	9470	1200	17960	1850	25620
60	1540	125	2810	190	3960	310	5920	600	10170	1250	18570	1900	26180
65	1640	130	2900	195	4050	320	6080	650	10860	1300	19180	1950	26750
70	1750	135	2990	200	4130	330	6230	700	11550	1350	19780	2000	27310
75	1850	140	3080	210	4300	340	6390	750	12220	1400	20380		
80	1950	145	3170	220	4470	350	6540	800	12880	1450	20980		

Surface area = Total outside surface area of container in square feet.

When the surface area is not stamped on the name plate or when the marking is not legible, the area can be calculated by using one of the following formulas:

1. Cylindrical container with hemispherical heads. Area (in sq. ft.) = overall length (ft.) x outside diameter (ft.) x 3.1416.
2. Cylindrical container with semi-ellipsoidal heads. Area (in sq. ft.) = overall length (ft.) + .3 outside diameter (ft.) x outside diameter (ft.) x 3.1416.
3. Spherical container. Area (in sq. ft.) = outside diameter (ft.) squared x 3.1416.

Flow Rate SCFM Air = Required flow capacity in cubic feet per minute of air at standard conditions, 60°F. and atmospheric pressure (14.7 psia).

The rate of discharge may be interpolated for intermediate values of surface area. For containers with total outside surface area greater than 2000 square feet, the required flow rate can be calculated using the formula, Flow Rate—SCFM Air = 53.632 A^{0.82}. Where A = total outside surface area of the container in square feet.

D

Chart B — Minimum Required Rate of Discharge for Anhydrous Ammonia Pressure Relief Valves Used on ASME Containers

From ANSI K61.1-1981, Appendix A (1981).

Minimum required rate of discharge in cubic feet per minute of air at 120% of the maximum permitted start-to-discharge pressure for pressure relief valves to be used on containers other than those constructed in accordance with United States Department of Transportation cylinder specifications.

Surface Area Sq. Ft.	Flow Rate SCFM Air	Surface Area Sq. Ft.	Flow Rate SCFM Air	Surface Area Sq. Ft.	Flow Rate SCFM Air	Surface Area Sq. Ft.	Flow Rate SCFM Air	Surface Area Sq. Ft.	Flow Rate SCFM Air	Surface Area Sq. Ft.	Flow Rate SCFM Air	Surface Area Sq. Ft.	Flow Rate SCFM Air
20	258	95	925	170	1500	290	2320	600	4200	1350	8160	2100	11720
25	310	100	965	175	1530	300	2380	650	4480	1400	8410	2150	11950
30	360	105	1010	180	1570	310	2450	700	4760	1450	8650	2200	12180
35	408	110	1050	185	1600	320	2510	750	5040	1500	8900	2250	12400
40	455	115	1090	190	1640	330	2570	800	5300	1550	9140	2300	12630
45	501	120	1120	195	1670	340	2640	850	5590	1600	9380	2350	12850
50	547	125	1160	200	1710	350	2700	900	5850	1650	9620	2400	13080
55	591	130	1200	210	1780	360	2760	950	6120	1700	9860	2450	13300
60	635	135	1240	220	1850	370	2830	1000	6380	1750	10090	2500	13520
65	678	140	1280	230	1920	380	2890	1050	6640	1800	10330		
70	720	145	1310	240	1980	390	2950	1100	6900	1850	10560		
75	762	150	1350	250	2050	400	3010	1150	7160	1900	10800		
80	804	155	1390	260	2120	450	3320	1200	7410	1950	11030		
85	845	160	1420	270	2180	500	3620	1250	7660	2000	11260		
90	885	165	1460	280	2250	550	3910	1300	7910	2050	11490		

Surface area = Total outside surface area of container in square feet.

When the surface area is not stamped on the name plate or when the marking is not legible, the area can be calculated by using one of the following formulas:

1. Cylindrical container with hemispherical heads. Area (in sq. ft.) = overall length (ft.) x outside diameter (ft.) x 3.146.
2. Cylindrical container with other than hemispherical heads. Area (in sq. ft.) = overall length (ft.) + .3 outside diameter (ft.) x outside diameter (ft.) x 3.1416.
3. Spherical container. Area (in sq. ft.) = outside diameter (ft.) squared x 3.1416.

Flow Rate SCFM Air = Required flow capacity in cubic feet per minute of air at standard conditions, 60°F. and atmospheric pressure (14.7 psia).

The rate of discharge may be interpolated for intermediate values of surface area. For containers with total outside surface area greater than 2,500 square feet, the required flow rate can be calculated using the formula, Flow Rate—SCFM Air = 22.11 A^{0.82} where A = outside surface area of the container in square feet.

Conversion Factor

$$\begin{aligned} \text{ft}^2 \times 0.092903 &= \text{m}^2 \\ \text{SCFM} \times 0.028317 &= \text{m}^3/\text{min} \\ \text{ft} \times 0.3048 &= \text{m} \end{aligned}$$

D9

“Pop-Action” Pressure Relief Valves

General Information

The “Pop-Action” design permits the RegO® Pressure Relief Valve to open slightly to relieve moderately excessive pressure in the container. When pressure increases beyond a predetermined point, the valve is designed to “pop” open to its full discharge capacity, reducing excess pressure quickly. This is a distinct advantage over ordinary valves which open gradually over their entire range, allowing excessive pressure to develop before the relief valve is fully open. All RegO® internal, semiinternal, and external relief valves incorporate this “Pop-Action” design.

Relief Valves in this catalog are only intended for use in LP-Gas or anhydrous ammonia service. Do not use any other service commodity. If you have an application other than conventional LP-Gas or anhydrous ammonia service, contact REGO® before proceeding.


Fully Internal “Pop-Action” Pressure Relief Valves for Transports and Delivery Trucks A8434 and A8436 Series

Application

Designed specifically for use as a primary relief valve in ASME transports and delivery trucks with 2” and 3” NPT couplings.

Features

- Low profile design assures maximum protection against sheering or distortion.
- All functioning parts are located below the level of the container connection to reduce the possibility of damage or tampering.
- Longer spring size designed to minimize stress cracking in service.
- Use of two different materials for stem and guide minimizes the possibility of stem seizure which may occur when similar materials are used.
- Internal octagonal wrenching broach assures easy installation and removal.
- ASME approved for use with LP-Gas and anhydrous ammonia.



A8434-SERIES

Materials

Body	Stainless Steel
Spring	Stainless Steel
Stem	Stainless Steel
Stem Bushing	17 - 4PH Stainless Steel
Seat Disc	Resilient Synthetic Rubber



Ordering Information

Part Number	Start To Discharge Setting PSIG	A Container Connection	B Overall Height (Approx.)	C Height Above Coupling (Approx.)	UL (At 120% of Set Pressure)	ASME (At 120% of Set Pressure)	Suitable for Tanks with Surface Area Up To:*	Protective Cap (Included)
A8434N	265	2" M. NPT	9 1/16"	1/2"	3700	3659	175 Sq. Ft.	A8434-11B
A8434G	250					3456		
A8436N	265	3" M. NPT	17 7/8"	3/4"	10210	9839	602 Sq. Ft.	A8436-11B
A8436G	250					9598		

* Per NFPA Pamphlet #58, Appendix D. Area shown is for UL or ASME flow rating—whichever is larger.

Fully Internal "Pop-Action" Pressure Relief Valves for Motor Fuel Containers 8543 and 8544 Series

Application

8543 Series relief valves are designed for use as a primary relief valve in larger ASME motor fuel containers such as on buses, trucks and construction equipment.

8544 Series relief valves are designed for use as a primary relief valve in smaller ASME and DOT motor fuel containers such as on tractors, lift trucks, cars and taxicabs.

Features

- Assure minimum product loss due to "pop-action" design.
- Recessed design minimizes possibility of damage and tampering.
- All are threaded to accept RegO® Pipeaway Adapters that permit the addition of a discharge hose or piping.
- ASME rated for use with LP-Gas (except 8544K which meets DOT requirements).
- Specify RegO® Relief Valves on all your original equipment motor fuel container purchases for reliable performance.

Materials

Body Brass
 Spring (8543)..... Stainless Steel
 Spring (8544)..... Coated Steel
 Seat Disc Resilient Rubber




7543-10



7544-11A



8544



Ordering Information

Part Number	Container Type	Start To Discharge Setting PSIG	A Container Connection M. NPT	B Overall Height (Approx.)	C Height Above Coupling (Approx.)	D Hex Wrenching Section	Flow Capacity SCFM/Air****		Protective Cap (Included)	Accessories Pipeaway Adapter
							UL (At 120% of Set Pressure)	ASME (At 120% of Set Pressure)		
8544G	ASME	250	1"	5 7/16"	7/8"	1 5/16"	1020	936	7544-41G	7544-11A*
8543G			1 1/4"			1 11/16"	1465	1400	7543-40C	7543-10**
8544T			1"			1 5/16"	1282	1158	7544-41	7544-11A
8543T		312	1 1/4"			1 11/16"	1990	1731	7543-40C	7543-10**
8544K	DOT/ASME	375	1"			1 5/16"	1545***	-	7544-41	7544-11A

* 1" M. NPT outlet connection.

** 1 1/4" M. NPT outlet connection.

*** Rating also applies to DOT requirements.

**** Flow rates shown are for bare relief valves. Adapters and pipeaway will reduce flow as discussed in forewording information.

Fully Internal "Pop-Action" Pressure Relief Valve for DOT Fork Lift Cylinders 8545AK

Application

Designed specifically for use as a primary relief valve on forklift cylinders, the 8545AK reduces the possibility of improper functioning of the relief mechanism due to foreign material build up. All guides, springs, stem and adjusting components are located inside the cylinder - removed from the direct exposure of foreign materials and debris from the atmosphere.

NFPA Pamphlet #58 requires that:

"All containers used in industrial truck (including forklift truck cylinders) service shall have the container pressure relief valve replaced by a new or unused valve within 12 years of the date of manufacture of the container and each 10 years thereafter."

Features

- Positive stop in the upper body protects against improper insertion of a pipeway adapter that might interfere with proper operation of the relief valve.
- Internal stem guide eliminates the need for a close fit between the body and poppet, which lessens the chance of clogging due to foreign material.
- Single piece cold-headed stem provides more accurate positioning of working parts for more consistent operation and precise adjustment.
- Two different deflector adapters and a protective cap are available as accessories to provide complete protection.
- "Pop-action" design keeps product loss at a minimum.
- Request RegO® Relief Valves on all your original equipment forklift cylinders for reliable performance.

Materials


Body	Brass
Stem	Stainless Steel
Spring	Stainless Steel
Poppet	Brass
Guide	Brass
Seat Disc	Resilient Rubber



7545-12 90° Adapter



7545-14 45° Adapter



Ordering Information

Part Number	Container Type	Start To Discharge Setting PSIG	Container Connection M. NPT	Flow Capacity SCFM/Air**	Accessories (Order Separately)		
				(REGO® Rated at 480 PSIG)	Protective Cap	Deflectors***	
8545AK	Dot	375	3/4"	400*	7545-40	7545-14	7545-12

* Classified by U.L. in accordance with Compressed Gas Association Pamphlet S-1.1 Pressure Device Standards for Cylinders. Meets requirements for use on DOT containers with 262 pounds or less weight of water or 109 pounds or less of LP-Gas.

** Flow rates are shown for bare relief valves. Adapters and pipeways will reduce flow as discussed in forewording information.

*** Order protective cap #8545-41 or 7545-40.


Semi-Internal "Pop-Action" Pressure Relief Valves for ASME Containers 7583, 8684 and 8685 Series

Application

Designed for use as a primary relief valve on ASME containers such as 250, 500 and 1,000 gallon tanks. Underwriters' Laboratories lists containers systems on which these types of valves are mounted outside the hood without additional protection, if mounted near the hood and fitted with a protective cap.

Features

- Constructed of non-corrosive materials.
- "Pop-action" design keeps product loss at a minimum.
- ASME rated for use with LP-Gas.
- Request Rego® Relief Valves on all your original equipment ASME containers for reliable performance.



Materials

Body Brass
 Spring Steel
 Stem Stainless Steel
 Seat Disc Resilient Rubber

Ordering Information

Part Number	Start To Discharge Setting PSIG	A Container Connection M. NPT	B Overall Height (Approx.)	C Height Above Coupling (Approx.)	D Wrench Hex Section	Flow Capacity SCFM/Air		Suitable for Tanks w/Surface Area Up To:*	Protective Cap (Included)
						UL (At 120% of Set Pressure)	ASME (At 120% of Set Pressure)		
7583G	250	3/4"	8 3/8"	1 1/8"	1 3/4"	1980	1806	80 Sq. Ft.	7583-40X
8684G		1"	9 5/8"	1 1/8"	1 7/8"	2620	2565	113 Sq. Ft.	8684-40
8685G		1 1/4"	11 1/8"	1 1/8"	2 3/8"	4385	4035	212 Sq. Ft.	7585-40X


* Per NFPA Pamphlet #58, Appendix D. Area shown is for UL or ASME flow rating—whichever is larger.

Application

Designed especially for use as a primary relief valve on large stationary storage containers, these low profile relief valves are generally mounted in half couplings. However, they are designed so that the inlet ports clear the bottom of a full 2" coupling. This assures that the relief valve should always be capable of maximum flow under emergency conditions.

Features

- High capacity, low turbulence design has a maximum guiding area providing for dependable shut-off after opening.
- Built-in spring stop limits the rise of the seat in full open position and prevents the spring from going "solid".
- External 3" NPT threaded body allows easy attachment of vent stacks. Optional pipeaway adapter has break-off groove to prevent damage to the relief valve should piping be stressed by damaging winds.
- "Pop-Action" design keeps product loss at a minimum.
- No guiding projections around the seat disc retainer to bind and hinder opening of valve if body is damaged.



Materials

Body Brass
 Spring Steel
 Stem Stainless Steel
 Seat Disc Resilient Rubber

Ordering Information

Part Number	Start To Discharge Setting PSIG	Container Connection M. NPT	Flow Capacity SCFM/Air*		Suitable for Tanks w/ Surface Area Up To:**	Accessories	
			UL (At 120% of Set Pressure)	ASME (At 120% of Set Pressure)		Protective Cap	Pipeaway Adapter
7534B	125	2"	6,025	-	319 Sq. Ft.	7534-40	7534-20***
7534G	250		11,675	10,422	708 Sq. Ft.		

* Flow rates shown are for bare relief valves. Adapters and pipeaways will reduce flow as discussed in the forewording information.

** Per NFPA Pamphlet #58, Appendix D. Area shown is for UL or ASME—whichever is larger.

*** 3" F. NPT outlet connection.


External "Pop-Action" Pressure Relief Valves for ASME Containers and Bulk Plant Installations AA3126, AA3130, 3131, 3132, 3133, 3135, AA3135, and A3149 Series

Application

Designed for use as a primary relief valve on ASME above ground and underground containers, bulk plant installations and skid tanks. The 3131 Series may also be used as a primary or secondary relief valve on DOT cylinders, or as a hydrostatic relief valve. All working components of these relief valves are outside the container connection, so the valves must be protected from physical damage.

Features

- "Pop-action" design keeps product loss at a minimum.
- Relief valve designed to automatically reseal firmly after discharge.
- Resilient seat disc provides "bubble-tight" seal.
- 3149 relief valves incorporate integral pipeaway adapter with break off groove that protects the valve from piping stress damage.
- Optional pipeaway adapters have grooves that will break off to protect the relief valve from damage should excess stress be applied to the piping.
- 3149 relief valves include weep hole deflectors, installed to guard against flame impingement on adjacent containers.
- Most are ASME rated for use with LP-Gas and anhydrous ammonia.



Materials

Description	3131, 3132, 3133, 3135	AA3126 AA3130	AA3135	A3149
Body	Brass	Aluminum Rod*		Upper Cold Rolled Steel Lower Ductile Iron
Liner		None		Stainless Steel
Spring Guide	Brass	Aluminum		Stainless Steel
Spring	Corrosion Resistant Steel	Stainless Steel		Stainless Steel or Coated Steel
Seat Disc		Resilient Synthetic Rubber		



Ordering Information

Part Number	Start To Discharge Setting PSIG	A Container Connection M. NPT	B Overall Height (Approx.)	C Wrench Hex Section	Flow Capacity SCFM/Air (a)		Suitable for Tanks w/Surface Area Up To: (e)	Accessories					
					UL (At 120% of Set Pressure)	ASME (At 120% of Set Pressure)		Protective Cap	Part Number	Outlet Size	Weep Hole Deflector		
AA3126L030	30	½"	2⅝"	⅞"	(b)	-	-	7545-40	AA3126-10	½" M. NPT	-		
A3149L55	55	2½"	10½"	4⅞"	2608(c)	-	113 Sq. Ft.	3149-40	(h)		Included (j)		
A3149L200	200				8770 (c)	-	500 Sq. Ft.						
AA3126L250	250	½"	2⅝"	⅞"	277 (c)	-	23 Sq. Ft. (f)	7545-40	AA3126-10	½" M. NPT	-		
3131G		¾"	3 ⅞"	1¼"	2060	1939	85 Sq. Ft.	3131-40 (g)	-				
AA3130UA250					2045	1838	249 Sq. Ft. (f)	AA3130-40P	AA3131-10	1" F. NPT			
W3132G		1"	6 ⅜"	2⅝"	3340	-	154 Sq. Ft.	3132-54 (g)	3132-10	1¼" F. NPT	3133-11		
3132G		1¼"			4130	-	200 Sq. Ft.		-				
T3132G					3790	-	180 Sq. Ft.		3132-10	1¼" F. NPT			
MV3132G					3995	-	190 Sq. Ft.		-				
3135G					5 2⅜"	-	300 Sq. Ft.	3135-54 (g)	3135-10	2" F. NPT			
AA3135UA250					6 1⅜"	6341	1010 Sq. Ft. (f)	AA3135-0PR	AA3135-10				
3133G		1½"	5 1⅝"	3⅜"	6080	-	320 Sq. Ft.	3133-40 (g)	3133-10				
A3149G		2½"	10½"	4⅞"	10390	9153	613 Sq. Ft.	3149-40	(h)		Included (j)		
AA3130UA265	265	¾"	3 ⅞"	1¼"	2125	1912	261 Sq. Ft. (f)	AA3130-40P	AA3131-10	1" F. NPT		-	
AA3135UA265		1¼"	6 1⅜"	2 1⅞"	6615	6703	1045 Sq. Ft. (f)	AA3135-40PR	AA3135-10	2" F. NPT	3133-11		
AA3126L312	312	½"	2⅝"	⅞"	330 (c)	-	27 Sq. Ft. (f)	7545-40	AA3126-10	½" M. NPT	-		

(a) Flow rates shown are for bare relief valves. Adapters and pipeaways will reduce flow as discussed in forewording information.

(b) Not UL or ASME rated. .059 square inch effective area.

(c) Not UL or ASME rated. REGO® rated at 120% of set pressure.

(f) Per ANSI K61.1-1972, Appendix A.

(g) Cap supplied with chain.

(h) Outlet 3/2-8N (F) thread, will accept 3" M. NPT pipe thread.

(j) Weep hole deflector is Part No. A3134-11B.

(e) Per NFPA Pamphlet #58, Appendix D. Area shown is for UL or ASME flow rating—whichever is larger.

External “Pop-Action” Supplementary Pressure Relief Valves for Small ASME Containers and DOT Cylinders 3127 and 3129 Series

Application

Designed for use as a supplementary relief valve on small ASME above ground and underground containers. They may also be used as a primary or secondary relief device on DOT cylinders, or as hydrostatic relief valves.

All working components of these relief valves are outside the container connection, so the valves must be protected from physical damage.

Features

- “Pop-action” design keeps product loss at a minimum.
- Relief valve designed to automatically reseal firmly after discharge.
- Resilient seat disc provides a “bubble-tight” seal.

Materials



Body Brass
Spring Stainless Steel
Seat Disc Resilient Rubber



3129-10 Pipe Away Adapter



3127 Series



Ordering Information

Part Number	Container Type	Start To Discharge Setting PSIG	A Container Connection M. NPT	B Overall Height (Approx.)	C Wrench Hex Section	Flow Capacity SCFM/ Air		Suitable for Tanks w/Surface Area Up To:*	Accessories		
						UL (At 120% of Set Pressure)	REGO® Rated at 480 PSIG***		Protective Cap	Pipeaway Adapter	
										Part Number	Outlet Size
3127G	ASME	250	¼"	1 31⁄32"	7⁄8"	295	-	-	7545-40	-	
3129G			½"	2 19⁄32"	1 1⁄8"	465		3129-10		½" F. NPT	
3127K	DOT	375	¼"	1 31⁄32"	7⁄8"	-	450	100 lbs./Propane		-	
3129K			½"	2 19⁄32"	1 1⁄8"	-	780	200 lbs./Propane		3129-10	½" F. NPT

* Flow rates shown are for bare relief valves. Adapters and pipeaways will reduce flow as discussed in forewording information.

** Not UL or ASME rated. REGO® rated at 480 PSIG.

*** Meets DOT requirements.

External Hydrostatic Relief Valves 3125, 3127, 3129, SS8001, SS8002, SS8021 and SS8022 Series

Application

Designed especially for the protection of piping and shut-off valves where there is a possibility of trapping liquid LP-Gas or anhydrous ammonia. They may be installed in pipelines and hoses located between shut-off valves or in the side boss of RegO® shut-off valves.

Features

- Relief valve designed to automatically reseal firmly after discharge.
- Resilient seat disc provides a "bubble-tight" seal.
- Available in both brass and stainless steel.
- Available in configurations that permit direct attachment of vent piping when required.

Materials

Body (3125, 3127, 3129) Brass
 Body (SS8001, SS8002, SS8021, SS8022) Stainless Steel
 Spring Stainless Steel
 Seat Disc Resilient Rubber


Ordering Information

Part Number	Start To Discharge Setting PSIG	Valve Body Material	A Container Connection M. NPT	B Height (Approx.)	C Wrench Hex Section	Accessories	
						Protective Cap	Pipeaway Adapter or Threads
SS8001G	250	Stainless Steel	1/4"	1 3/8"	7/8"	-	-
SS8002G			1/2"				1/4" NPSM Thrds
SS8021G			1/4"				3/8" NPT Thrds
SS8022G			1/2"				-
3127G	275	Brass	1/4"	2 1/8"	1 1/8"	7545-40	3129-10*
3129G			1/2"				-
3127H			1/4"				3129-10*
3129H			1/2"				-
3127P	300	Brass	1/4"	2 1/8"	1 1/8"	7545-40	3129-10*
3129P			1/2"				-
SS8022P			1/2"				3/8" NPT Thrds
3127J			1/4"				-
3129J	350	Brass	1/4"	2 1/8"	1 1/8"	7545-40	3129-10*
SS8001J			1/2"				-
SS8002J			1/4"				1/4" NPSM Thrds
SS8021J			1/2"				3/8" NPT Thrds
SS8022J	375	Brass	1/4"	2 1/8"	1 1/8"	7545-40	-
3127K			1/2"				3129-10*
3129K			1/4"				Included
3125L			1/2"				7545-40
3127L	400	Brass	1/4"	2 1/8"	1 1/8"	3129-40P	3129-10*
3129L			1/2"				-
SS8001L			1/4"				1/4" NPSM Thrds
SS8002L			1/2"				3/8" NPT Thrds
SS8021L	450	Brass	1/4"	2 1/8"	1 1/8"	7545-40	-
SS8022L			1/2"				3129-10*
3127U			1/4"				-
3129U			1/2"				1/4" NPSM Thrds
SS8001U	450	Stainless Steel	1/4"	1"	7/8"	-	3/8" NPT Thrds
SS8002U			1/2"				-
SS8021U			1/4"				1/4" NPSM Thrds
SS8022U			1/2"				3/8" NPT Thrds


* 1/2" F. NPT outlet connection.



3125 Series (.161 Orifice)
 3127 Series (.274 Orifice)
 3129 Series (.386)



SS8022G



SS8001, SS8002
 Series
 (.156 Orifice)

DuoPort® Pressure Relief Valve Manifolds for Small Storage Containers 8542 Series

Application

Designed especially for use as a primary relief device on smaller stationary storage containers, with 2" NPT threaded couplings. These manifolds allow servicing or replacement of either of the two relief valves without evacuating the container or loss of service. The operating lever selectively closes off the entrance port to the relief valve being removed while the remaining valve provides protection for the container and its contents. The rating of each manifold is based on actual flow through the manifold and a single pressure relief valve, taking friction loss into account. It is not merely the rating of the relief valve alone.

Features

- Allows for relief valve removal and replacement on a periodic basis without shutting down and evacuating the container.
- Unique seat ring assemblies provide a smooth tubular section to preclude turbulence and assure more efficient flow capacity.
- Operating lever is only locked in the mid-position or in a position to seal either relief valve. Placement of the clapper disc in an intermediate position could restrict flow through one of the relief valves, causing it to chatter and destroy the resilient seat disc.
- A rubber plug with chain is provided to protect manifold outlet threads where the relief valve has been removed.
- "Pop-action" design insures maximum protection with only minimal product loss at moderately excessive pressures.
- Resilient relief valve seat disc provides "bubble-tight" seal.
- Relief valves are ASME rated for use with LP-Gas and anhydrous ammonia.

Manifold Materials

Body Ductile Iron
Clapper Disc Stainless Steel
Bleeder Valve Stainless Steel
Seat Disc Teflon
Packing Polyethylene

Relief Valve Materials

Body Forged Aluminum*
Spring Guide Aluminum
Spring Coated Steel
Seat Disc Resilient Synthetic Rubber


*A special coating is applied to the inlet threads to minimize the possibility of electrolytic action.

Ordering Information

Part Number	Start to Discharge Setting PSIG	Application		Container Connection M. NPT	Relief Valve Included				Flow Capacity SCFM/Air** (at 120% of set pressure)	
					Quantity	Part Number	Inlet Connection M. NPT	Accessory	UL Rating (at 120% of set Pressure)	ASME Rating (at 120% of set Pressure)
		LP-Gas	NH3					Pipeaway Adaptors		
8542G	250	Yes	No	2"	2	3135MG	1¼"	3135-10*	5250 (1)	NA
AA8542UA250		No	Yes			AA3135MUA250		AA3135-10*	6430 (1)	6341 (1)
AA8542UA265	265					AA3135MUA265			6615 (1)	6703 (1)

* 2" F. NPT outlet connection.

** Flow rating based on number of relief valves indicated in parenthesis (). Flow rates shown are for bare relief valves. Adapters and pipeaways will reduce flow rates as discussed in forewording information.



Multiport™ Pressure Relief Valve Manifold Assemblies for Large Storage Containers A8560, A8570 and AA8570 Series

Application

Designed especially for use as a primary relief device on large stationary pressurized storage containers with flanged openings. These manifolds incorporate an additional relief valve, not included in the flow rating, allowing for servicing or replacement of any one of the relief valves without evacuating the container. The handwheel on the manifold selectively closes off the entrance port to the relief valve being removed while the remaining relief valves provide protection for the container and its contents. All manifold flow ratings are based on flow through the relief valves after one has been removed for service or replacement.

Features

- Allows for relief valve removal and replacement on a periodic basis without shutting down and evacuating the container.
- "Pop-action" design of relief valves insures maximum protection with only minimal product loss at moderately excessive pressures.
- A rubber plug with chain is provided to protect manifold outlet threads where the relief valve has been removed.
- May be mounted directly to a welding neck flange or manhole cover plate. Requires no inlet piping.
- Relief valves designed to automatically reseal firmly after discharge.
- Resilient relief valve seat disc provides "bubble-tight" seal.
- Relief valves are ASME rated for use with LP-Gas and anhydrous ammonia.



Materials

Body Ductile Iron
Resilient Parts Teflon
Clapper Disc Stainless Steel
Bleeder Valve Stainless Steel


Bolt Stud and Nut Assemblies

Part Number	Consists of	For Use With:	For Connection To:	Number Required
7560-55	1-Bolt Stud and Nut	All RegO Multiports™	Modified 3" - 300# and 4"-ASA 300# Welding Neck Flange	8
7560-56			Manhole Cover Plate	


Relief Valve Materials

Description	A8563, A8564, A8573, A8574
Body	Upper Cold Rolled Steel Lower Ductile Iron
Liner	Stainless Steel
Spring Guide	Stainless Steel
Spring	Coated Steel
Seat Disc	Resilient Synthetic Rubber

*A special coating is applied to the inlet threads to minimize possibility of electrolytic action.



Typical RegO Multiport™ Pressure Relief Valve Manifold



Flange Dimensions

Manifold Series	Flange Size	Flange Drilling	Port Diameter	Flange Gasket
A8560	Modified 3" 300# (4" Port Dia)	(8) 7/8" Bolt Holes on a 6 3/4" Bolt Circle Diameter Flat Faced.	4"	3" 7564-48
A8570 AA8570	4" ASA 300#	(8) 7/8" Bolt Holes on a 7 7/8" Bolt Circle Diameter 1/16" Raised Faced.	4"	4" 7565-48



Ordering Information

Part Number	Start To Discharge Setting PSIG	Application		Container Flange Connection	Relief Valve				Flow Capacity SCFM/Air** At 120% of Set Pressure	
		LP-Gas	NH ₃		Quantity	Part Number	Inlet Connection M. NPT	Accessories	UL Rating	ASME Rating
								Pipeaway Adapters		
A8563G	250	Yes	Yes	3"-300#*	3	A3149MG	2½"	****	18,500 (2)	Not Applicable
A8564G					4				27,750 (3)	
A8573G					3				18,500 (2)	
A8574G					4				27,750 (3)	
A8563AG				3"-300#*	3	A3149G			Not Applicable	18,300 (2)
A8564AG					4					27,400 (3)
A8573AG					3					18,300 (2)
A8574AG					4					27,400 (3)

* For use with modified 300# ANSI flange with 4" port.

*** 2" F. NPT outlet connection.

** Flow rating based on number of relief valves indicated in parenthesis (). Flow rates shown are for bare relief valves. Adapters and pipeaways will reduce flow rates as discussed in forewording information.

**** Outlet 3 1/2-8N (F) thread, will accept 3" M. NPT pipe thread.

REGO® Warning Notice

The following warning information, Part Number 8545-500, is included with each shipment of pressure relief valves and relief valve manifolds to the first purchaser of the product from the factory.

This information is intended to be forwarded throughout the product distribution chain. Additional copies are available from REGO® and Authorized Product Distributors.

DANGER
LP-GAS IS EXTREMELY FLAMMABLE AND EXPLOSIVE

READ THIS FIRST

WARNING

AVOID SERIOUS INJURY AND PROPERTY DAMAGE. IF YOU SEE, SMELL OR HEAR ESCAPING GAS, ... EVACUATE AREA IMMEDIATELY! CALL YOUR LOCAL FIRE DEPARTMENT! DO NOT ATTEMPT TO REPAIR. DO NOT STORE IN BUILDING OR ENCLOSED AREA. DO NOT USE ON HOT AIR BALLOONS OR AIRCRAFT. Make sure you are thoroughly trained before you attempt any pressure relief installation or maintenance. Improper conditions or procedures can cause accidents resulting in property damage and personal injury.

Become thoroughly familiar with NPGA Safety Pamphlet 306 "LP-Gas Regulator and Valve Inspections & Maintenance" and ECIL "Safety Warning "Pressure Relief Valves" found in the relief valve section of the L-500 & L-102 Catalogs. Follow its recommendations.

Know and understand NFPA Pamphlet 58 "Liquefied Petroleum Gas Code", which is the law in many states. This publication is available from NFPA, Batterymarch Park, Quincy, MA 02269. Following its requirements is essential in the safe use of LP-Gas. Section 4.4 states: persons who transfer liquid LP-Gas, who are employed to transport LP-Gas, or whose primary duties fall within the scope of this code shall be trained in proper handling procedures. Refresher training shall be provided at least every three years and shall be documented.

Make sure this valve is the proper one for this installation. Avoid misusing LP-Gas equipment. Flow rates in the charts are for bare relief valves found in the relief valve section of the L500 & L102 Catalogs. The addition of defectors, pipeway adapters and piping will restrict the flow. To properly protect any container the total system flow must be sufficient to relieve pressure at the pressure setting of the relief valve in accordance with all applicable codes.

Use only ECIL "RegO" adapters on ECIL "RegO" relief valves. Adapters not designed specifically for piping away ECIL "RegO" relief valves, such as those with 90° turns or reduced internal diameters, will decrease flow dramatically. These should never be used as they can cause the relief valve to chatter and eventually destroy itself.

Apply thread joint compound compatible with LP-Gas on valve external threads only. Make sure compound never comes into contact with other parts of the valve.

Install valves by applying force to wrenching flats only.

Tighten pipe threads approximately 1 to 1 1/2 turns beyond the hand-tight insertion point using a wrench which avoids damage to other valve parts.

Check for damage after valve installation. Check that the pressure relief valve is clean and free of foreign material. Make sure protective cap is properly in place.

Check that there are no leaks with a non-corrosive leak detection solution before filling with LP-Gas.

Purge container before filling with LP-Gas (refer to the ECIL "LP-Gas Serviceman's Manual for recommended procedures).

In selecting a label for posting at the installation site, consider ECIL "part number 901-400 along with your own, NPGAs and others.

Remember to instruct the owner/user/customer in safety matters concerning LP-Gas and this equipment. See ECIL "Safety Warning "Pressure Relief Valves" found in the relief valve section of the L-500 & L-102 Catalogs.

Engineered Controls International, Inc., ECIL "requests that this information be forwarded to your customers. Additional copies are available from ECIL " and your authorized ECIL " Product Distributor.

REGO
100 Ite gO Drive PO Box 247 Elon, NC 27244 USA Phone (336) 449-7707 Fax (336) 449-6594 www.rego-products.com
Printed in USA 06-0809-0686
Part number 8545-500

Cross Reference by Part Number

3125LD16	3129UD16	SS8001JD16	AA8542UA250D17
AA3126L030D14	AA3130UA250D14	SS8001LD16	AA8542UA265D17
AA3126L250D14	AA3130UA265D14	SS8001UD16	8543GD11
AA3126L312D14	3131GD14	SS8002GD16	8543TD11
3127GD15	3132GD14	SS8002JD16	8544GD11
3127GD16	MV3132GD14	SS8002LD16	8544KD11
3127HD16	T3132GD14	SS8002UD16	8544TD11
3127JD16	W3132GD14	SS8021GD16	8545AKD12
3127KD15	3133GD14	SS8021JD16	A8563AGD19
3127KD16	3135GD14	SS8021LD16	A8563GD19
3127LD16	AA3135UA250D14	SS8021UD16	A8564AGD19
3127PD16	AA3135UA265D14	SS8022GD16	A8564GD19
3127UD16	A3149GD14	SS8022JD16	A8573AGD19
3129GD15	A3149L55D14	SS8022LD16	A8573GD19
3129GD16	A3149L200D14	SS8022PD16	A8574AGD19
3129HD16	7534BD13	SS8022UD16	A8574GD19
3129JD16	7534GD13	A8434GD10	8684GD13
3129KD15	7560-55D18	A8434ND10	8685GD13
3129KD16	7560-56D18	A8436GD10	
3129LD16	7583GD13	A8436ND10	
3129PD16	SS8001GD16	8542GD17	



LP-Gas & Anhydrous Ammonia Equipment

Section E

Globe and Angle Valves

E

Limited Warranty and Limitation of Liability

LIMITED 10 YEAR WARRANTY AND LIMITATION OF LIABILITY

LIMITED 10 YEAR WARRANTY

REGO® warrants to the original purchasers the products and repair kits manufactured by it to be free from defects in materials and workmanship under normal use and service for a period of 10 years from the date of manufacture. If within thirty days after buyer's discovery of what buyer believes is a defect, buyer notifies in writing and ships the product to REGO® at 100 Rego Drive, Elon, NC 27244, REGO®, at its option, and within forty-five days of receipt, will repair, replace F.O.B. point of manufacture, or refund the purchase price of that part or product found by REGO® to be defective. Failure of buyer to give such written notice and ship the product within thirty days shall be deemed an absolute and unconditional waiver of any and all claims of buyer arising out of such defect.

This warranty does not extend to any product or part that is not installed and used continuously after installation in accordance with REGO®'s printed instructions, all applicable state and local regulations, and all applicable national standards, such as those promulgated by NFPA, DOT and ANSI. This warranty does not extend to any product or part that has been damaged by accident, misuse, abuse, failure to maintain, or neglect, nor does it extend to any product or part which has been modified, altered, disassembled, or repaired in the field. This warranty does not cover any cosmetic issues, such as scratches, dents, marring, fading of colors or discoloration.

Except as expressly set forth above, and subject to the limitation of liability below, REGO® MAKES NO OTHER WARRANTY, EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, with respect to its products and parts, whether used alone or in combination with others. REGO® disclaims all warranties not stated herein.

LIMITATION OF LIABILITY

REGO®'s total liability for any and all losses and damages arising out of any cause whatsoever shall in no event exceed the purchase price of the products or parts in respect of which such cause arises, whether such cause be based on theories of contract, negligence, strict liability, tort or otherwise.

REGO® shall not be liable for incidental, consequential or punitive damages or other losses. REGO® shall not be liable for, and buyer assumes any liability for, all personal injury and property damage connected with the handling, transportation, possession, further manufacture, other use or resale of products, whether used alone or in combination with any other products or materials.

From time to time buyers might call to ask REGO® for technical advice based upon limited facts disclosed to REGO®. If REGO® furnishes technical advice to buyer, whether or not at buyer's request, with respect to application, further manufacture or other use of the products and parts, REGO® shall not be liable for such technical advice or any such advice provided to buyer by any third party and buyer assumes all risks of such advice and the results thereof.

NOTE: Some states do not allow the exclusion or limitation of incidental, consequential or punitive damages, so the above limitation or exclusion may not apply to you. The warranty gives you specific legal rights, and you may have other rights that vary from State to State. The portions of this limited warranty and limitation of liability shall be considered severable and all portions which are not disallowed by applicable law shall remain in full force and effect.

NOTICE TO USERS OF PRODUCTS

The Limited Warranty stated above is a factory warranty to the first purchasers of REGO® products. Since most users have purchased these products from REGO® distributors, the user must within thirty (30) days after the user's discovery of what user believes is a defect, notify in writing and return the product to the distributor from whom he purchased the product/part. The distributor may or may not at the distributor's option choose to submit the product/parts to REGO®, pursuant to this Limited Warranty. Failure by buyer to give such written notice within thirty (30) days shall be deemed an absolute and unconditional waiver of buyer's claim for such defects. Acceptance of any alleged defective product/parts by REGO®'s distributor for replacement or repairs under the terms of REGO®'s Limited Warranty in no way determines REGO®'s obligations under this Limited Warranty.

Because of a policy of continuous product improvement, REGO® reserves the right to change designs, materials or specifications without notice.

Foreword

This catalog describes a complete line of equipment available from REGO® for use with LP-Gas and anhydrous ammonia (NH₃). The following points are important to know for proper use of the catalog:

1. Illustrations and drawings of individual products are representative of “product groups” and all products within a product group are similar in construction.
2. Materials used for construction of products in this catalog are suitable for rated service pressure at temperatures of -40° F. to +165° F., unless otherwise specified.
3. Products in this catalog are only intended for use in LP-Gas and/or anhydrous ammonia service as follows.
 - a. “A” or “AA” prefix — Products with this prefix are suitable for NH₃ service (i.e., contain no brass parts).
 - b. “AA” prefix on relief valves — These valves are NOT suitable for use with LP-Gas service. These are of partial aluminum materials and are listed by Underwriters Laboratories (UL) for NH₃ service only.
 - c. All other products are suitable for use with LP-Gas service.
 - d. “SS” prefix—Hydrostatic relief valve with this prefix are suitable for NH₃ service (i.e., they have stainless steel materials).

Caution

Do not use any product contained in this catalog with any service commodity other than LP-Gas or NH₃. If you have a need for use of another application, contact REGO®, 100 RegO Drive, Elon, NC 27244, (336) 449-7707 before proceeding.

Proper application, installation and maintenance of products in this catalog are essential. Users of these products should obtain further information if there are any doubts or questions.

Warning

All REGO® products are mechanical devices that will eventually become inoperative due to wear, corrosion and aging of components made of materials such as rubber. The environment and conditions of use will determine the safe service life of these products. Periodic inspection and maintenance are essential to avoid serious injury and property damage.

Many REGO® products are manufactured for storage, transport, transfer and use of toxic flammable and dangerous liquids and gases. Such substances should be handled by experienced and trained personnel only, using accepted governmental and industrial safety procedures. Never vent LP-Gas near any possible source of ignition.

Notice

Installation, usage, and maintenance of all REGO® products must be in compliance with all REGO® instructions as well as requirements and provisions of NFPA #54, NFPA#58, DOT, ANSI, and all applicable federal, state, provincial and local standards, codes, regulations, and laws.

Inspection and maintenance on a periodic basis is essential. Installation and maintenance should be performed only by qualified personnel.

Be sure all instructions are read and understood before installation, operation and service.

Filters

REGO® LP-Gas equipment is designed to operate in a system free from contamination. A variety of in-line filters are commercially available to the LP-Gas industry for installation in domestic systems.

The use of an in-line filter should be considered when other system components may be unclean and the system contaminated by rust, scale, dirt, debris or other foreign material.

Contents	Page
Cross Reference by Part Number	E20
Flange Seal Valves.....	E12
Hose-End Filling Valve Safety Warning	E4
Multipurpose Valves	E16
Quick-Acting Horse End Valves.....	E6
Quick-Acting Minimum Loss Valves	E5
Quick-Acting Valves.....	E7
Tank Car Valve	E15
Vapor Head Manifold	E14
“V”-Ring Seal Valves	E9
Warnings	E20

LP-Gas Hose-End Filling Valves (With ACME Connectors)

Safety Warnings



Purpose

In its continuing quest for safety, REGO® publishes a series of bulletins explaining the hazards associated with the use, misuse, and aging of LP-Gas valves and regulators. It is hoped that these factual bulletins will make clear to LP-Gas dealer managers and service personnel, that the utmost care and attention must be used in the installation, inspection, and maintenance of these products, or problems could occur which would result in injuries and property damage.

The National Fire Protection Association Pamphlet #58 - 2004 Edition, "Liquefied Petroleum Gas Code" states that, "persons who transfer liquid LP-Gas, who are employed to transport LP-Gas, or whose primary duties fall within the scope of this code shall be trained in proper handling procedures. Refresher training shall be provided at least every three years. The training shall be documented." These "REGO® Safety Warnings" may be useful in training new employees and reminding older employees of hazards that can occur. It is recommended that all employees be furnished with a copy of NPGA Safety Pamphlet 306-88, "LP-Gas Regulator and Valve Inspection and Maintenance."

Nature of Warnings

It is recognized that warnings should be as brief as possible, but factors involved in filler valve and filling valves failure are not simple. They need to be fully understood so that proper procedures and maintenance can be used to prevent accidents. If there is a simple warning, it would be:

**Loosen filling valve from filler valve very slowly.
If there is a leak, know procedure to follow.**

This bulletin is not intended to be an exhaustive treatment of the subject of filler valves and certainly does not cover all safety practices that should be followed in the installation, operation and maintenance of LPG systems, which include filler and filling valves.

Hose-End Filling Valves With ACME Connectors

Hose-end valves must never be dragged over the ground or dropped or banged into the truck when the hose is reeled in.

They could open accidentally or they could be damaged. Dragging will cause abnormal wear and eventual valve failure. Foreign material will lodge in the connector which can cause failure of the filler valve.

To prevent hazardous conditions, operators should follow this procedure on every filling application:

- Always wear gloves and eye protection.
- Check for foreign material in hose-end valve and the filler valve, and if present, remove with extreme care. If material cannot be safely removed, do not proceed with filling and replace valve.
- Make sure the ACME connector spins on easily by hand.
- If leak is noticed when filling is started, stop the operation and correct the leaking condition.
- After filling, bleed the gas trapped between the filler valve and hose-end valve by using the vent on the hose-end valve or by slightly loosening coupling nut to vent the gas before disconnecting.

If gas does not stop venting, then filler valve or hose-end valve is leaking. Do not disconnect filling connector. This is a hazardous situation and your company procedure for handling this problem must be carefully followed.

Make sure your company has such a procedure. Inspection of Filling Valves with Handwheel

- Valves should be inspected at least once a month to be sure the valve handle is tight and not damaged, that the stem is not bent and that there is no "play" in the threads in the bonnet. "Play" will normally not be noticed if the valve is under pressure.
- The ACME threads should be examined for wear, dents or nicks and the seating area should be clean and smooth.



Loosen slowly.
If gas continues
to vent, retighten
ACME connector
and follow company
emergency
procedures.

Inspection of Quick Acting Filling Valves

- Valves should be inspected daily to make sure locking mechanism functions properly.
- The ACME threads should be examined for wear, dents or nicks and the seating area should be clean and smooth.
- The retaining ring on the filler connection should be examined to make sure it is properly holding the female ACME rotating nut or handle so as to keep the surface that seats on the filler valve gasket protected.
- If any problems are evident, valves should be immediately replaced or repaired.

Larger Filler and Filling Valves

For 2¼" and 3¼" valves with ACME connections, use only the special wrenches designed for the purpose.

Do not use pipe wrenches or hammers to tighten the connections. All of the previous warnings about the smaller valves also apply here.

General Warning

All REGO® products are mechanical devices that will eventually become inoperative due to wear, contaminants, corrosion and aging components made of materials such as rubber and metal. The environment and conditions of use will determine the safe service life of these products. Periodic inspection and maintenance are essential. Because REGO® products have a long and proven record of quality and service, LP-Gas dealers may forget the hazards that can occur because a filler valve or a filling valve is used beyond its safe service life. Life of these valves is determined by the environment in which they "live." The LP-Gas dealer knows better than anyone what this environment is. Note: There is a developing trend in state legislation and in proposed national legislation to make the owner of products responsible for replacing products before they reach the end of their safe useful life. LP-Gas dealers should be aware of the legislation which could affect them.

Quick-Acting Minimum Loss Hose-End Valves for Bobtail Delivery Trucks and Dispensing Stations A7793A and A7797A

Application

Designed to vastly reduce the amount of product vented when disconnecting bobtail delivery trucks, dispensing systems and anhydrous ammonia nurse tanks.

These valves provide instant, full-on flow at the flip of a handle. Shut-off is instant and the handle locks for added protection. This "top of the line" hose-end valve is a fully contained unit that does not require additional filling adapters or connectors.


Features

- Minimizes product venting loss, when disconnecting, instantly by housing the seat disc at the bottom of the built-in ACME filling connector.
- Vents less than 2cc of liquid when disconnected.
- "V"-ring spring-loaded pressure seal design provides for dependable, leak-free operation. No packing to retighten or replace.
- Operator friendly. Contoured handle rotates a full 360° and large, easy to grip filling connector make the valve easy to handle.
- Self locking handle is operator opened and closed to prevent against accidental opening of the valve.



Materials

Body	Ductile Iron
"V"-Ring	Teflon
Stem	Stainless Steel
Seat Disc	Synthetic Elastomer
ACME Connector.....	Aluminum w/Steel Insert
Seal Housing	Stainless Steel
Lever.....	Stainless Steel
Bonnet	Cadmium Plated Steel



Ordering Information

Part Number	Inlet Connection (F. NPT)	Outlet Connection (F. ACME)	Locking Handle	Flow at 1 PSIG (Cv) Pressure Drop* (GPM/Propane)
A7793A	3/4"	1 3/4"	Yes	16.0
A7797A	1"	1 3/4"	Yes	16.0

* To obtain approximate flow at other than 1 PSIG pressure drop, multiply flow in table by square root of pressure drop. Example: A7797 @ 9 PSIG = 16.0 x 9 = 48.0 GPM/propane. For NH₃ flow, multiply propane flow by .90.

Quick-Acting Hose-End Valves for Bobtail Delivery Trucks and Dispensing Stations A7707L and A7708L


Application

Designed especially for safe operator handling of LP-Gas in bobtail delivery truck, dispensing systems and anhydrous ammonia nurse tank service.


These valves provide instant, full-on flow at the flip of the handle and provide instant positive shut-off with a handle lock for added protection.

Features

- "V"-ring spring-loaded pressure stem seal provides for leak-proof operation. No packing to retighten or replace.
- Self locking handle is operator opened and closed to prevent against accidental opening of the valve.
- Large, contoured handle provides firm, comfortable grip.
- Full swivel handle rotates 360° so the valve can be operated from any angle.
- Built-in vent valve on the downstream side of the valve permits bleeding of trapped product to assure safe uncoupling.
- Can be used with a variety of RegO® filling adapter connectors.
- Swivel seat disc minimizes grinding on the body seat and assures longer service life.




A7707L



A7708L

Materials

Body	Ductile Iron
"V"-Ring	Teflon
Stem	Stainless Steel
Seat Disc	Synthetic Elastomer
Valve Lever	Stainless Steel
Seal Housing	Stainless Steel
Bonnet	Cadmium Plated Steel



Ordering Information

Part Number	Body Design	Inlet & Outlet Connection (F. NPT)	Locking Handle	Flow at 1 PSIG Pressure Drop (Cv) (GPM/Propane)**	Accessories		
					Filling Connectors**		
					Extended	Compact	
					Steel	Brass	Steel
A7707L	Globe	1"	Yes	18.0	A7575L4	3175A	A3175A
A7708L	Angle			22.0			

* To obtain approximate flow at other than 1 PSIG pressure drop, multiply flow in table by square root of pressure drop.
Example: A7708L @ 9 PSIG = 22.0 x $\sqrt{9}$ = 66.0 GPM/propane. For NH₃ flow, multiply propane flow by .90.

** See appropriate catalog section for additional information.

Quick-Acting Valves for Crop Driers and Charging Manifold Hoses

7554 Series

Application

7554S Series valves provide instant shut-off and fast opening control on LP-Gas crop driers. They are also ideal for charging manifold hoses, stationary fuel transfer hoses and other applications requiring quick, positive shut-off. They are not for use with delivery truck hoses because the handle could snag on the ground and open the valve as the hose is reeled back to the truck.

7554L Series valves feature a locking handle device to help prevent accidental opening of the valve. It is ideal for all the same applications as the 7554S Series and may be used on delivery trucks as it incorporates the locking handle design.



Both valve series must be installed so that flow through the valve is opposite to that of a conventional globe valve. This allows the inlet flow to assist in closing the valve and prevents the valve from being opened by high pump pressures.

Features

- Quick-acting design speeds transfer operations, permitting rapid, one-handed opening and closing.
- Resilient seat disc provides positive shut-off.
- Flange seal stem design provides for leak-proof operation. No packing to retighten or replace.
- 7554L Series incorporates locking handle to prevent accidental opening of the valve.
- Vent valve installed on the downstream side of the valve permits bleeding of trapped product to assure safe uncoupling.
- Swivel seat disc minimizes grinding on the body seat and assures longer service life.

Materials

Body	Ductile Iron
Bonnet	Brass
"V"-Ring	Teflon
Stem	Stainless Steel
Seat Disc	Synthetic Elastomer
ACME Connector.....	Aluminum w/Steel Insert
Seal Housing	Stainless Steel
Lever.....	Stainless Steel



Ordering Information

Part Number	Inlet & Outlet Connection (F. NPT)	Locking Handle	Flow At 1 PSIG (Cv) Pressure Drop* (GPM/Propane)
7554SAV	1/2"	No	7.3
7554LAV		Yes	
7554SV	3/4"	No	11.3
7554LV		Yes	

* To obtain approximate flow at other than 1 PSIG pressure drop, multiply flow in table by square root of pressure drop. Example: 7554LV @ 9 PSIG = 11.5 X $\sqrt{9}$ = 34.5 GPM/propane.

Quick-Acting Valves for Cylinder Charging Hoses 7053T, A7553A, and 7901T Series

Application

Designed primarily for use on cylinder charging hoses to provide fast, convenient shut-off and fast opening.




These valves must be installed so that flow through the valve is in the opposite direction to that of a conventional globe valve. This allows the inlet flow to assist in closing the valve, and even more important, helps prevent the valve from being forced open by high pump pressure.

Features

- Quick-acting design speeds transfer operations.
- Permits easy, one-handed opening and closing of the valve.
- O-ring stem seal design.
- Provides quick, positive shut-off.

Materials

Body (7053T, 7901)	Forged Brass
Body (A7553)	Ductile Iron
O-Ring	Resilient Synthetic Rubber
Bonnet Assembly (7053T, 7901)	Brass
Bonnet Assembly (A7553)	Steel
Seat Disc	Resilient Synthetic Rubber
Handle (7053T, 7901)	Brass
Handle (A7553)	Steel
Springs	Stainless Steel



Ordering Information

Part Number	Inlet Connection (F. NPT)	Outlet Connection (F. NPT)	Body Material	Flow At 1 PSIG (CV) Pressure Drop* (GPM/Propane)
7901T	1/4"	1/4"	Brass	1.95
A7553A			Ductile Iron	
7901TA	3/8"	3/8"	Brass	
7901TB	1/2"	1/4"		
7901TC		1/2"		
7053T				

* To obtain approximate flow at other than 1 PSIG pressure drop, multiply flow in table by square root of pressure drop. Example: 7901T @ 9 PSIG = $\sqrt{9} \times 1.95 = 5.85$ GPM/propane. For NH3 flow, multiply propane flow by .90.

"V"-Ring Seal Globe and Angle Valves

General Information


RegO® Globe and Angle Valves are designed and manufactured especially to meet the rigid requirements of the LP-Gas industry. The high quality construction and wide variety of sizes and styles also make them highly suited to many other industries such as anhydrous ammonia, chemical and petrochemical.

These ductile iron valves are available in both threaded and flanged connections. Threaded connections are available in ½" F. NPT to 3" F. NPT sizes. Flanged connections are available in 1½", 2" and 3" pipe sizes.

The ductile iron used in these valves has a 60,000 PSIG tensile strength which closely approaches that of steel castings. Its yield strength of 45,000 PSIG and elongation of 15% is also comparable to that of steel castings. These material features assure the ability of the valve body to withstand impact, wrenching stresses and thermal shock. This ductile iron conforms to ASTM specification A395.

RegO® globe and angle valves are designed for working pressures up to 400 PSIG WOG and for operating temperatures from -40° F. to +160° F.

"V"-Ring Stem Seal



The "V"-ring spring-loaded pressure seal used in these RegO® globe and angle valves is the most effective stem seal yet developed. It should not be confused with conventional valve stem packing where the seal is obtained by compressing the packing around the stem by means of a packing gland with resultant hard operation and frequent packing replacement.

The wax like surface of the teflon "V"-ring seal and consequent low friction assures leak-tight performance for an indefinite period where periodic retightening of the packing is not required and the seal provides extra long service life.

In the RegO® "V"-ring design, the seal is effected by the pressure expanding the "V"-shape of the seal, forcing it against the stem and bonnet surfaces to prevent leakage. The higher the pressure within the valve, the more effective the seal becomes. A spring loaded washer under the "V"-rings keeps them in an expanded position to assure an effective seal under low pressure conditions. A wiper ring, located above the seal, keeps the seal free from grit, and/or other foreign material that may hamper operation.

Installation and Operation Note

Containers and pipe lines should be thoroughly cleaned before globe and angle valves are installed. Large particles of solid foreign matter can permanently damage the seating surface in the valve body, causing the valve to leak. Use a minimum amount of a suitable pipe dope on the male connecting threads as excess amounts may fall off and be carried into the valve, causing damage to the seat or other operating parts.

It is totally unnecessary to use excess force in opening or closing RegO® valves. The type of seat disc material used and the general design of these valves permits them to be opened and closed easily. Proper valve operation insures unusually long life.

Wrenches must never be used to operate valves equipped with handwheels and designed for hand operation.

Downstream Accessory Boss

These RegO® valves incorporate a plugged ¼" F. NPT boss on the downstream side of the body for attaching either a hydrostatic relief valve or vent valve. Boss size on the 2" and 3" valves has been increased to allow a ¾" drilling for accommodation of a standard by-pass valve or jumper lines.


Hydrostatic Relief—When the design of the piping installation is such that liquid may be locked between two shut-off valves, a hydrostatic relief valve should be installed in the lines between the valves. The pressures which can develop due to temperature increase in a liquidfull line are tremendous and can easily damage the valves or piping unless a hydrostatic relief valve is installed.

Vent Valve—If the globe or angle valve is used as a shut-off valve on a loading hose, a vent valve should be installed in the downstream boss to allow liquid trapped beyond the shut-off valve to be vented before disconnecting the hose coupling.

Replace Gate Valves with Flanged Valves

Except for standard flange sizes, RegO® Flanged Globe and Angle Valves are smaller and lighter than contemporary valves, thus reducing price and shipping costs and making them far easier to install. RegO® face to face flange dimensions conform to gate valve dimensions, making replacement of most gate or plug valves with RegO® valves simple and easy.

General Features



"V"-Ring Seal Globe and Angle Valves for Bulk Storage Containers, Transports, Bobtails and Plant Piping A7500 Series and TA7500 Series

Application

Specifically designed to assure positive shut-off and long, maintenancefree service life in liquid or vapor service on bulk storage containers, transports, bobtails, cylinder filling plants and plant piping.

The high quality construction and wide variety of sizes make them highly suited for use with LP-Gas, anhydrous ammonia and in the chemical and petrochemical industries.

Features

"V"-ring spring-loaded pressure stem seal provides for leak-proof operation. No packing to retighten or replace.

- Circular bridge in the globe design and a dropped seat in the angle design achieve greater flow with less pressure drop.
- Swivel seat disc assembly minimizes the seat disc from grinding on the body seat. The seat disc stops rotating as soon as it touches the body seat. This feature provides for good seat alignment and assures long seat life.
- ¼" F. NPT plugged boss on the downstream side of the valve body allows attachment of a hydrostatic relief valve or vent valve.
- "V"-ring stem seal virtually eliminates hard to turn handles frequently encountered with packed type seals.
- Heavy duty rolled ACME stem threads provide quick action and long service life.

Materials

Body	Ductile Iron
Bonnet (7034, 7505-7508).....	Steel
Bonnet (7509-7518).....	Ductile Iron
Valve Stem	Stainless Steel
Wiper Ring.....	Synthetic Rubber
Seat Disc	See Ordering Chart
"V"-Rings	Teflon
Handwheel.....	Ductile Iron
Spring	Stainless Steel

Ordering Information

Part Number				Inlet and Outlet Connection	Port Diameter	Flow at 1 PSIG Pressure Drop (Cv) (GPM/Propane)***		Accessories			
Buna N Seat Discs		Teflon Seat Discs*				Globe	Angle	Hydrostatic Relief Valve	Vent Valve		
Globe	Angle	Globe	Angle								
-	-	TA7034P	TA7034LP	½" F. NPT	¾"	10.0	14.8	SS8001U	TSS3169		
A7505AP	A7506AP	TA7505AP	TA7506AP	¾" F. NPT		12.0	17.7				
A7507AP	A7508AP	TA7507AP	-	1" F. NPT	1"	17.8	22.0				
A7509BP	A7510BP	TA7509BP	TA7510BP	1¼" F. NPT	1¼"	36.5	54.0				
A7511AP	A7512AP	TA7511AP	TA7512AP	1½" F. NPT	1½"	43.0	55.5				
A7511FP	-	TA7511FP	-	1½" Flange**		46.0	-				
A7513AP	A7514AP	TA7513AP	-	2" F. NPT	2"	75.0	88.5				
A7513FP	A7514FP	TA7513FP	TA7614FP	2" Flange**		78.0	133.0				
A7517AP	A7518AP	TA7517AP	-	3" F. NPT	3⅝"	197.0	303.0				
A7517AP	A7518FP	TA7517FP	-	3" Flange**							

* Teflon seat discs on valves built to order.






** 300# ANSI R.F. Flange.

*** To obtain approximate flow at other than 1 PSIG pressure drop, multiply flow in chart by square root of pressure drop.
Example: 7514FP @ 9 PSIG = 133 x √9 = 399 GPM/propane. For NH₃ flow, multiple propane flow by .90.

E10










Globe and Angle Valve Dimensions

Drawing	Valve Number (A or TA Prefix)	Inlet & Outlet	Port Diameter	Dimensions						
				A	B	C	Flanges			G
							D	E	F	
	7034P	½" F. NPT	¾"	4¾"	-	3⅞"	-	-	-	-
	7505AP	¾" F. NPT				4⅝"				
	7507AP	1" F. NPT	1¾"							
	7034LP	½" F. NPT			-					
	7506AP	¾" F. NPT				2"				
	7508AP	1" F. NPT								
	7509BP	1¼" F. NPT	1¼"	6¾"	-	4⅞"	-	-	-	-
	7511AP	1½" F. NPT	1½"	6⅓⅙"		5⅝"				
	7513AP	2" F. NPT	2"	7⅞"		5⅞"				
	7517AP	3" F. NPT	3⅞"	13¼"		9"			9"	
	7510BP	1¼" F. NPT	1¼"	6¾"	2¼"	-	-	-	-	5¼"
	7512AP	1½" F. NPT	1½"	6⅓⅙"	2⅞"					
	7514AP	2" F. NPT	2"	7⅞"	2⅞"					
	7518AP	3" F. NPT	3⅞"	11¾"	4"					9"
	7511FP	1½" Flange	1½"	7⅞"	-	7½"	6⅞"	¾"	2⅞"	5¼"
	7513FP	2" Flange	2"	8⅞"		8½"	6½"	⅓⅙"	3⅝"	
	7517FP	3" Flange	3⅞"	13¼"		11⅞"	8¼"	1⅞"	5"	9"
	7514FP	2" Flange	2"	7½"	5¼"	-	6½"	⅓⅙"	3⅝"	5¼"
	7518FP	3" Flange	3⅞"	11¾"	6¼"		8¼"	1⅞"	5"	9"

NOTE: Regarding 7505AP through 7510BP — the thread used for assembling the bonnet to the body of the valve is a left hand thread. We advise our customers to be cognizant of this assembly design in attempting to remove the bonnets of these valves in order to avoid serious damage to the valves.

Flange Dimensions

	Valve Number (A or TA Prefix)	Size	Flange Drilling		D	E	F	H
								
	7511FP	1 1/2"		7/8" Bolt Holes on a 4 1/2" Bolt Circle Diameter	6 1/8"	13/16"	2 7/8"	3/4"
	7513FP	2"		3/4" Bolt Holes on a 5" Bolt Circle Diameter	6 1/2"	7/8"	3 5/8"	13/16"
	7514FP							
	7517FP	3"		7/8" Bolt Holes on a 6 5/8" Bolt Circle Diameter	8 1/4"	1 1/8"	5"	1 1/16"
	7518FP							

* Reducing screwed flanges are available for reducing 1 1/2" flange to 1 or 1 1/4" pipe thread and 3" flange to 2 1/2" pipe thread. Order from your local piping supplier.


Flange Seal Globe and Angle Valves

General Information

Globe and Angle Valves, incorporating the synthetic rubber flange seal design, operate on the same principle as the "V"-ring valves. Gas pressure in the valve is exerted against the synthetic rubber flange, forcing it tightly against the stem.

Leak-tight performance is assured and periodic adjustment is not required. The synthetic rubber construction provides smooth operating performance with long service life.

These valves all incorporate a plugged $\frac{1}{4}$ " NPT side boss on the downstream side of the valve that can be equipped with a hydrostatic relief valve or vent valve.



Please be familiar with the "Installation and Operation Note" and "Downstream Accessory Boss" section of the "V"-ring valve design general information before ordering these valves.

General Features

Rugged quick-acting ACME threads on stem. Threads are under flange ring . . . dust, sand and grit can't reach them.


Swivel seat cannot grind during valve opening or closing.

Synthetic Rubber Seat Disc

Nylon bearing surrounds stem to prevent galling.

Rubber flange ring stem seal effectively prevents gas escape. The higher the pressure, the tighter the seal.

Metal to metal back seat permits replacement of flange ring with valve in service.



Valve body made of shell molded ductile iron. Highly resistant to cracking or fracturing from wrenching, dropping or hammer blows. Bonnet and seal cap are steel on "A" prefix valves.

Flange Seal Globe and Angle Valves for Bulk Storage Containers, Filling Hoses and Plant Piping 7704, 7705 and 7706 Series


Application

Designed to assure positive shut-off and long maintenance-free service life in liquid or vapor service. Ideally suited for use on cylinder charging manifolds, truck filling hoses, bulk storage containers and plant piping.

The high quality construction and wide variety of sizes make them highly suited for use with LP-Gas, anhydrous ammonia and in the chemical and petrochemical industries.



A7704P




7704 P
A7704 P
7705 P
A7705 P

Features

- Available with either a brass bonnet and bronze stem for LP-Gas service or a steel bonnet and stainless steel stem for combined LP-Gas and anhydrous ammonia service.
- Flange seal stem provides for leak-proof operation. No packing to retighten or replace.
- Metal-to-metal back seat permits replacement of the flange ring with the valve in service.
- Plugged 1/4" NPT boss on downstream side of valve accommodates hydrostatic relief valve or vent valve.
- Swivel seat disc minimizes grinding on the body seat and assures longer service life.
- "Dropped seat" body design of the angle valve provides high flow capacity.



A7706 P



7704 LP
A7704 LP
7706 P
A7706 P

Materials

Body	Ductile Iron
Bonnet (7704, 05, 06).....	Brass
Bonnet (7704, 05, 06).....	Steel
Stem (7704, 05, 06).....	Bronze
Stem (7704, 05, 06).....	Stainless Steel
Flange Ring	Synthetic Rubber
Seat Disc	Synthetic Rubber



Ordering Information

Part Number		Inlet & Outlet Connection (F. NPT)	Flow at 1 PSIG Pressure Drop (Cv) (GPM/Propane)*		Accessories	
Globe	Angle		Globe	Angle	Hydrostatic Relief Valve	Vent Valve
7704P	7704LP	½"	7.3	12.3	SS8001J or SS8001L	TSS3169
A7704P	A7704LP					
7705P	7706P	¾"	11.5	17.7		
A7705P	A7706P					

* To obtain approximate flow at other than 1 PSIG pressure drop, multiply flow in table by square root of pressure drop. Example: A7704LP @ 9 PSIG = $12.3 \times \sqrt{9} = 36.9$ GPM/propane. For NH₃ flow, multiply propane flow by .90.

Flange Seal Liquid Transfer Angle Valves for Bulk Storage Containers

7550 and 7551 Series

Application

Designed especially for liquid transfer of LP-Gas from consumer bulk storage containers when used with a Chek-Lok® or equipped with an integral excess flow valve. May also be used for vapor LP-Gas service.

In NH₃ applicator tanks they may be used as a vapor bleeder valve or as a liquid withdrawal valve when installed in a coupling with a dip pipe.

These liquid transfer valves are equipped with an integral excess flow valve for liquid transfer directly from the tank fitting, or without an integral excess flow for LP-Gas transfer through a Check-Lok®.


When equipped with an integral excess flow valve (7550PX), the valve should be mounted in a forged steel 3000 lb. half coupling. When mounted in a 1 1/4" x 3/4" NPT reducing coupling, the 3/4" female thread in this coupling must be full length — equivalent to a forged steel 3000 lb. half coupling.

The excess flow valve will not function properly if these specifications are not met. Refer to the Warning Bulletin in the Excess Flow Valve Section of this catalog.



Features

- Flange seal stem design provides for leak-proof operation. No packing to retighten or replace.
- Large, unrestricted interior ports reduce pressure drop through the valve, increasing capacity and preventing cavitation.
- Resilient swivel seat disc assures longer seat life and easy, positive shut-off.
- Plugged 1/4" NPT outlet boss accommodates hydrostatic relief valve or vent valve.
- Specifically designed for liquid transfer of LP-Gas with the Chek-Lok®.



Materials

Body (7550, 51)	Brass
Body (A7550, 51)	Cadmium Plated Ductile Iron
Bonnet (7550, 51)	Brass
Body (A7550, 51)	Steel
Stem (7550, 51)	Bronze
Stem (A7550, 51)	Stainless Steel
Flange Ring	Synthetic Rubber
Seat Disc	Synthetic Rubber



Ordering Information

Part Number	Inlet Connection (F. NPT)	Outlet Connection (F. NPT)	Integral Excess Flow	Flow at 1 PSIG (Cv) Pressure Drop* (GPM/Propane)	Excess Flow Approximate Closing Flow** (GPM/Propane)	Accessories	
						Hydrostatic Relief Valve	Vent Valve
7550P	3/4"	3/4"	No	13.3	-	3127U	3165
A7550P			No	13.3	-	SS8001J	TSS3169
7550PX		3/4"	Yes	-	16.0	3127U	3165
A7550PX			Yes	-	16.0	SS8001J	TSS3169
7551P	1/2"	1/2"	No	8.9	-	3127U	3165
A7551P			No	8.9	-	SS8001J	TSS3169

* To obtain approximate flow at other than 1 PSIG pressure drop, multiply flow in table by square root of pressure drop. Example: 7550P @ 9 PSIG = 13.3 x/9 = 39.9 GPM/propane. For NH₃ flow, multiple propane flow by .90.

** For NH₃ flow, multiply propane flow by .90.

Tank Car Angle Valves for Railroad Tank Cars TA7894P

Application


Designed especially for transfer of LP-Gas and anhydrous ammonia in railroad tank car service.

The combined heavyweight ductile iron castings and precision machining provide ruggedness and superior performance in working pressures up to 400 PSIG.

Features

- "V"-ring spring-loaded pressure seal design provides dependable, leak-free operation. No packing to retighten or replace.
- Wiper o-ring eliminates entrance of dirt and grit into stem area that can prohibit smooth operation.
- Heavy duty ACME stem threads give quick action and are hardened for long service life.
- Swivel seat reduces scoring of seat disc and provides positive shut-off.
- Full diameter seat provides greater flow capacity and low pressure drop.
- Plugged 1/4" NPT boss on downstream side of valve accommodates vent valve or hydrostatic relief valve.
- Equipped with a malleable iron plug and chain installed in the valve outlet.

AAR Approval #E-049015



Materials

Body	Ductile Iron
"V"-Rings	Teflon
O-Ring	Synthetic Rubber
Stem	Stainless Steel
Bonnet	Ductile Iron
Seat Disc	Teflon
Handwheel.....	Cadmium Plated Ductile Iron



Ordering Information

Part Number	Inlet Connection	Outlet Connection (F.NPT)	Flow At 1 PSIG (Cv) Pressure Drop	Accessories	
				Hydrostatic Relief Valve	Vent Valve
TA7894P	Tank Car Flange	2"	112	SS8001U	TSS3169

* To obtain approximate flow at other than 1 PSIG pressure drop, multiply flow in table by square root of pressure drop. Example: TA7894P @ 9 PSIG = $112 \times \sqrt{9} = 336$ GPM/propane. For NH_3 flow, multiply propane flow by .90.

Multipurpose Valve for Filling of NH₃ Containers A8016DBC

Application

Designed specifically for use as a manual filler valve on anhydrous ammonia applicator tanks. This valve incorporates an integral back check valve.

Features

- Positive seating back check valve opens for maximum flow at minimum pressure drop when filling — regardless of the type of coupling in which the valve is installed.
- Back Check seat is fully contained in the tank coupling for maximum protection in the event of external damage to the valve.
- Resilient seat disc assembly is fully contained on three sides for bubble-tight shut-off and long service life.
- "V"-ring spring-loaded stem seal design requires no repacking or field adjustment.
- Specially machined break-away groove beneath ACME threads will shear-off with excessive pull on the hose and leave the valve body intact.
- Plugged 1/4" NPT boss accommodates vent valve or hydrostatic relief valve.




A8016DBC



Materials

Body	Ductile Iron
Bonnet	Steel
"V"-Rings	Teflon
Stem	Stainless Steel
Seat Disc	Resilient Synthetic Rubber
Back Check Valve.....	Stainless Steel, Steel and Synthetic Rubber
Springs	Stainless Steel



Ordering Information

Part Number	Inlet Connection	Filling Connection	Filling Capacity at 20 PSIG Pressure Drop GPM/NH ₃	Accessories	
				Hydrostatic Relief Valve	Vent Valve
A8016DBC	1 1/4"	1 3/4"	95	SS8001J	TSS3169

* Determined at 9.5 to 12 PSIG differential.

** Determined at 100 PSIG inlet.

Multipurpose Valve for Filling of NH₃ Containers A8016DP

Application

Designed specifically for use as a manual valve or vapor equalizing valve on anhydrous ammonia applicator and nurse tanks.

This valve incorporates an integral excess flow valve. When product is required, the valve must completely open and backseated to allow the excess flow valve to function properly as explained in the excess flow section of this catalog.

Features


- Positive-acting excess flow valve opens for maximum flow at minimum pressure drop when filling -- regardless of the type of coupling in which the valve is installed.
- Excess flow seat is fully contained in the tank coupling for maximum protection in the event of external damage to the valve.
- Resilient seat disc assembly is fully contained on three sides for bubble-tight shut-off and long service life.
- "V"-ring spring-loaded stem seal design requires no repacking or field adjustment.
- Specially machined break-away groove beneath ACME threads will shear-off with excessive pull on the hose and leave the valve body intact.
- Plugged 1/4" NPT boss accommodates vent valve or hydrostatic relief valve.



A8016DP

Materials

Body	Ductile Iron
Bonnet	Steel
"V"-Rings	Teflon
Stem	Stainless Steel
Seat Disc	Resilient Synthetic Rubber
Excess Flow Valve	Stainless Steel--Steel Body
Springs	Stainless Steel



Ordering Information

Part Number	Inlet Connection (M. NPT)	Filling Connection (M. ACME)	Filling Capacity At 20 PSIG Pressure Drop GPM/NH ₃	Approximate Excess Flow Closing Flows		Accessories	
				Liquid* GPM/NH ₃	Vapor** CFH/NH ₃	Hydrostatic Relief Valve	Vent Valve
A8016DP	1 1/4"	1 3/4"	95	44	24,000	SS8001J	TSS3169

* Determined at 9.5 to 12 PSIG differential.

** Determined at 100 PSIG inlet.

Multipurpose Valves for Liquid Withdrawal of LP-Gas and NH₃ Containers

A8017D & A8020D

Application

Designed especially for use as a high capacity liquid withdrawal valve on LP-Gas and anhydrous ammonia containers.

These valves incorporate an integral excess flow valve. When product is required, the valve must be completely open and backseated to allow the excess flow valve to function properly as explained in the excess flow valve section of this catalog.


The A8017DH is equipped with a soft seated automatic differential back pressure check valve in the seat disc assembly. This allows any pressure build up in the liquid transfer line in excess of 10-15 psig above the container pressure to flow back into the container. The transfer hose is protected against excessive liquid or vapor pressure entrapment, which adds materially to the useful life of flexible hose. In addition to increasing hose service life, the equalizing valve adds substantially to the operating safety of liquid transfer systems.

Features


- Positive-acting excess flow valve opens for maximum flow at minimum pressure drop when filling — regardless of the type of coupling in which the valve is installed.
- Excess flow seat is fully contained in the tank coupling for maximum protection in the event of external damage to the valve.
- Resilient seat disc assembly is fully contained on three sides for bubble-tight shut-off and long service life.
- "V"-ring spring loaded stem seal design requires no repacking or field adjustment.
- A8017DH has two plugged 1/4" NPT ports, one on the top and the other on the side, accommodate either a vent valve or hydrostatic relief valve.
- A8020D has a plugged 1/4" NPT port that accommodates vent valve, hydrostatic relief valve, or pressure gauge.
- A8017DH incorporates an automatic back check valve built into the shut-off valve, eliminating the need for a separate hydrostatic relief valve.

Materials

Body	Ductile Iron
Bonnet	Steel
Stem	Stainless Steel
Seat Disc	Resilient Synthetic Rubber
"V"-Rings	Teflon
Excess Flow Valve.....	Stainless Steel - Steel Body
Springs	Stainless Steel



A8017DP



A8020D



Ordering Information

Part Number	Inlet Connection (M. NPT)	Outlet Connection (F. NPT)	Approximate Excess Flow Liquid Closing Flow** (GPM/Propane)	Accessories	
				Hydrostatic Relief Valve	Vent Valve
A8017DH	1¼"	1"	49	Not Required	TSS3169
A8017DP			55	SS8001J	
A8017DLP		¾"	49		
A8020D	1¼"	1"	78	SS8001J	TSS3169

* Built-in back pressure check valve incorporated into shut-off valve.

** Determined at 11.5 to 13.5 PSIG differential for 3/4" outlet and 9 to 12 PSIG differential for 1" outlet. For NH₃ flow, multiply by .90.

Multipurpose Valve for Filling and Liquid Transfer of NH₃ Containers A8018DP

Application

Designed primarily for use as a combination filler and liquid withdrawal valve on three-opening applicator tanks or on nurse tanks.

This valve incorporates an integral excess flow valve. When product is required, the valve must be completely open and backseated to allow the excess flow valve to function properly as explained in the excess flow valve section of this catalog.

Features


- Functions as both a filler valve and liquid transfer valve, in one unit.
- Positive acting excess flow valve opens for maximum flow at minimum pressure drop when filling — regardless of the type of coupling in which the valve is installed.
- Excess flow seat is fully contained in the tank coupling for maximum protection in the event of external damage to the valve.
- Specially machined break-away groove beneath ACME thread of filler valve will shear-off with excessive pull on the hose and leave the valve body intact.
- Triple guide filler valve check provides for dependable shut-off performance when filling ceases.
- Resilient seat disc assembly is fully contained on three sides for bubble-tight shut-off and long service life.
- "V"-ring spring loaded stem seal design requires no repacking or field adjustment.
- Plugged 1/4" NPT boss accommodates vent valve or hydrostatic relief valve.

Materials

Body	Ductile Iron
Bonnet	Steel
Stem	Stainless Steel
Seat Discs	Synthetic Resilient Rubber
"V"-Rings	Teflon
Excess Flow Valve	Stainless Steel - Steel Body
Springs	Stainless Steel



A8018DP



Ordering Information

Part Number	Inlet Connection (M. NPT)	Outlet Connection (F. NPT)	Filling Connection (M.ACME)	Filling Capacity At 20 PSIG Pressure Drop GPM/NH ₃	Approximate Excess Flow Liquid Closing Flow GPM/NH ₃	Accessories	
						Hydrostatic Relief Valve	Vent Valve
A8018DP	1 1/4"	1"	1 1/4"	74	50	SS8001J	TSS3169

* Determined at 9 to 12 PSIG differential.

Warning Notice

The following warning information, Part Number 903-500, is included with each shipment of Quick-Acting and Tank Car Valves to the first purchaser of the product from the factory.

This information is intended to be forwarded throughout the product distribution chain. Additional copies are available from REGO® and Authorized Product Distributors.

DANGER

READ THIS FIRST

WARNING

LP-GAS IS EXTREMELY FLAMMABLE AND EXPLOSIVE

AVOID SERIOUS INJURY AND PROPERTY DAMAGE. IF YOU SEE, SMELL OR HEAR ESCAPING GAS... EVACUATE AREA IMMEDIATELY! CALL YOUR LOCAL FIRE DEPARTMENT! DO NOT ATTEMPT TO REPAIR. DO NOT STORE IN BUILDING OR ENCLOSED AREA. DO NOT USE ON HOT AIR BALLOONS OR AIRCRAFT.

Make sure you are thoroughly trained before you attempt any valve installation, maintenance or repair. Improper conditions or procedures can cause accidents resulting in property damage and personal injury.

Become thoroughly familiar with NFPA Safety Pamphlet 306 "LP-Gas Regulator and Valve Inspections & Maintenance" and ECII "Safety Warnings: LP-Gas Cylinder Valves", "LP-Gas Excess Flow Valves", and "LP-Gas Filler and Hose End Filling Valves" found in the cylinder valve, excess flow valve, and filler valve sections of the L-500 & L-102 Catalogs. Follow their recommendations.

Know and understand NFPA Pamphlet 58 "Liquefied Petroleum Gas Code", which is the law in many states. This publication is available from NFPA, Batterymarch Park, Quincy, MA 02269. Following its requirements is essential in the safe use of LP-Gas. Section 4.4 states: persons who transfer liquid LP-Gas, who are employed to transport LP-Gas, or whose primary duties fall within the scope of this code shall be trained in proper handling procedures. Refresher training shall be provided at least every three years and shall be documented.

Make sure this valve is the proper one for this installation. Avoid missing LP-Gas equipment.

Apply thread joint compound compatible with LP-Gas on valve external threads only. Make sure compound never comes into contact with other parts of the valve.

Install valves by applying force to wrenching flats only.

Tighten pipe threads approximately 1 to 1½ turns beyond the hand-tight insertion point using a wrench which avoids damage to other valve parts.

Check for damage and proper operation after valve installation. Check that the valve is clean and free of foreign material.

Check container-valve connection with a non-corrosive leak detection solution before filling with LP-Gas.

Purge container before filling with LP-Gas (refer to the ECII "LP-Gas Serviceman's Manual for recommended procedure).

Test excess flow check valve for proper operation before placing into service. See NFPA Bulletin 113 for recommended procedure.

Check outlet connection make-up for leaks with a non-corrosive leak detection solution when placing into service.

RegO Products Filler Valves: To prevent damage to the internal checks when it is necessary to utilize an unloading adapter, use ONLY RegO Products 3119A, 3120 and 3121 Unloading Adapters with RegO Products Filler Valves. Carefully follow the instructions supplied with these unloading adapters.

If container is not being placed into service at the present time, insert plug or cap onto the outlet connection.

In selecting a label for posting at the installation site, consider ECII "part number 901-400 or 903-400 along with your own, NPGAs and others.

Remember to instruct the owner/user/customer in safety matters concerning LP-Gas and this equipment. See ECII "Safety Warnings: LP-Gas Cylinder Valves", "LP-Gas Excess Flow Valves", and "LP-Gas Filler and Hose End Filling Valves" found in the cylinder valve, excess flow valve, and filler valve sections of the L-500 & L-102 Catalogs.

Engineered Controls International, Inc., ECII "requests that this information be forwarded to your customers. Additional copies are available from ECII " and your authorized ECII " Product Distributor.

REGO

Printed in USA 08-0809-0086
Part number 903-500

100 RegO Drive PO Box 247 Elon, NC 27244 USA Phone (336) 449-7707 Fax (336) 449-6594 www.regoproducts.com

Cross Reference by Part Number

7034LP.....E11	7511FP.....E11	A7517AP.....E10	A7704P.....E13
7034P.....E11	7511FP.....E11	A7517AP.....E10	7705P.....E13
TA7034LP.....E10	A7511AP.....E10	TA7517AP.....E10	A7705P.....E13
TA7034P.....E10	A7511FP.....E10	TA7517FP.....E10	7706P.....E13
7053T.....E8	TA7511AP.....E10	7518AP.....E11	A7706P.....E13
7141FP.....H8	TA7511FP.....E10	7518FP.....E11	A7707L.....E6
7505AP.....E11	7512AP.....E11	7518FP.....E11	A7708L.....E6
A7505AP.....E10	A7512AP.....E10	A7518AP.....E10	A7793A.....E5
TA7505AP.....E10	TA7512AP.....E10	A7518FP.....E10	A7797A.....E5
7506AP.....E11	7513AP.....E11	7550P.....E14	TA7894P.....E15
A7506AP.....E10	7513FP.....E11	7550PX.....E14	7901T.....E8
TA7506AP.....E10	7513FP.....E11	A7550P.....E14	7901TA.....E8
7507AP.....E11	A7513AP.....E10	A7550PX.....E14	7901TB.....E8
A7507AP.....E10	A7513FP.....E10	7551P.....E14	7901TC.....E8
TA7507AP.....E10	TA7513AP.....E10	A7551P.....E14	A8016DBC.....E16
7508AP.....E11	TA7513FP.....E10	A7553A.....E8	A8016DP.....E17
A7508AP.....E10	7514AP.....E11	7554LAV.....E7	A8017DH.....E18
7509BP.....E11	7514FP.....E11	7554LV.....E7	A8017DLP.....E18
A7509BP.....E10	7514FP.....E11	7554SAV.....E7	A8017DP.....E18
TA7509BP.....E10	A7514AP.....E10	7554SV.....E7	A8018DP.....E19
7510BP.....E11	A7514FP.....E10	TA7614FP.....E10	A8020D.....E18
A7510BP.....E10	7517AP.....E11	7704LP.....E13	
TA7510BP.....E10	7517FP.....E11	7704P.....E13	
7511AP.....E11	7517FP.....E11	A7704LP.....E13	



LP-Gas & Anhydrous Ammonia Equipment

Section F

Excess Flow, Check, Filler and Vapor Equalizing Valves

F

Limited Warranty and Limitation of Liability

LIMITED 10 YEAR WARRANTY AND LIMITATION OF LIABILITY

LIMITED 10 YEAR WARRANTY

REGO® warrants to the original purchasers the products and repair kits manufactured by it to be free from defects in materials and workmanship under normal use and service for a period of 10 years from the date of manufacture. If within thirty days after buyer's discovery of what buyer believes is a defect, buyer notifies in writing and ships the product to REGO® at 100 Rego Drive, Elon, NC 27244, REGO®, at its option, and within forty-five days of receipt, will repair, replace F.O.B. point of manufacture, or refund the purchase price of that part or product found by REGO® to be defective. Failure of buyer to give such written notice and ship the product within thirty days shall be deemed an absolute and unconditional waiver of any and all claims of buyer arising out of such defect.

This warranty does not extend to any product or part that is not installed and used continuously after installation in accordance with REGO®'s printed instructions, all applicable state and local regulations, and all applicable national standards, such as those promulgated by NFPA, DOT and ANSI. This warranty does not extend to any product or part that has been damaged by accident, misuse, abuse, failure to maintain, or neglect, nor does it extend to any product or part which has been modified, altered, disassembled, or repaired in the field. This warranty does not cover any cosmetic issues, such as scratches, dents, marring, fading of colors or discoloration.

Except as expressly set forth above, and subject to the limitation of liability below, REGO® MAKES NO OTHER WARRANTY, EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, with respect to its products and parts, whether used alone or in combination with others. REGO® disclaims all warranties not stated herein.

LIMITATION OF LIABILITY

REGO®'s total liability for any and all losses and damages arising out of any cause whatsoever shall in no event exceed the purchase price of the products or parts in respect of which such cause arises, whether such cause be based on theories of contract, negligence, strict liability, tort or otherwise.

REGO® shall not be liable for incidental, consequential or punitive damages or other losses. REGO® shall not be liable for, and buyer assumes any liability for, all personal injury and property damage connected with the handling, transportation, possession, further manufacture, other use or resale of products, whether used alone or in combination with any other products or materials.

From time to time buyers might call to ask REGO® for technical advice based upon limited facts disclosed to REGO®. If REGO® furnishes technical advice to buyer, whether or not at buyer's request, with respect to application, further manufacture or other use of the products and parts, REGO® shall not be liable for such technical advice or any such advice provided to buyer by any third party and buyer assumes all risks of such advice and the results thereof.

NOTE: Some states do not allow the exclusion or limitation of incidental, consequential or punitive damages, so the above limitation or exclusion may not apply to you. The warranty gives you specific legal rights, and you may have other rights that vary from State to State. The portions of this limited warranty and limitation of liability shall be considered severable and all portions which are not disallowed by applicable law shall remain in full force and effect.

NOTICE TO USERS OF PRODUCTS

The Limited Warranty stated above is a factory warranty to the first purchasers of REGO® products. Since most users have purchased these products from REGO® distributors, the user must within thirty (30) days after the user's discovery of what user believes is a defect, notify in writing and return the product to the distributor from whom he purchased the product/part. The distributor may or may not at the distributor's option choose to submit the product/parts to REGO®, pursuant to this Limited Warranty. Failure by buyer to give such written notice within thirty (30) days shall be deemed an absolute and unconditional waiver of buyer's claim for such defects. Acceptance of any alleged defective product/parts by REGO®'s distributor for replacement or repairs under the terms of REGO®'s Limited Warranty in no way determines REGO®'s obligations under this Limited Warranty.

Because of a policy of continuous product improvement, REGO® reserves the right to change designs, materials or specifications without notice.

Foreword

This catalog describes a complete line of equipment available from REGO® for use with LP-Gas and anhydrous ammonia (NH₃). The following points are important to know for proper use of the catalog:

1. Illustrations and drawings of individual products are representative of “product groups” and all products within a product group are similar in construction.
2. Materials used for construction of products in this catalog are suitable for rated service pressure at temperatures of -40° F. to +165° F., unless otherwise specified.
3. Products in this catalog are only intended for use in LP-Gas and/or anhydrous ammonia service as follows.
 - a. “A” or “AA” prefix — Products with this prefix are suitable for NH₃ service (i.e., contain no brass parts).
 - b. “AA” prefix on relief valves — These valves are NOT suitable for use with LP-Gas service. These are of partial aluminum materials and are listed by Underwriters Laboratories (UL) for NH₃ service only.
 - c. All other products are suitable for use with LP-Gas service.
 - d. “SS” prefix—Hydrostatic relief valve with this prefix are suitable for NH₃ service (i.e., they have stainless steel materials).

Caution

Do not use any product contained in this catalog with any service commodity other than LP-Gas or NH₃. If you have a need for use of another application, contact REGO®, 100 RegO Drive, Elon, NC 27244, (336) 449-7707 before proceeding.

Proper application, installation and maintenance of products in this catalog are essential. Users of these products should obtain further information if there are any doubts or questions.

Warning

All REGO® products are mechanical devices that will eventually become inoperative due to wear, corrosion and aging of components made of materials such as rubber. The environment and conditions of use will determine the safe service life of these products. Periodic inspection and maintenance are essential to avoid serious injury and property damage.

Many REGO® products are manufactured for storage, transport, transfer and use of toxic flammable and dangerous liquids and gases. Such substances should be handled by experienced and trained personnel only, using accepted governmental and industrial safety procedures. Never vent LP-Gas near any possible source of ignition.

Notice

Installation, usage, and maintenance of all REGO® products must be in compliance with all REGO® instructions as well as requirements and provisions of NFPA #54, NFPA#58, DOT, ANSI, and all applicable federal, state, provincial and local standards, codes, regulations, and laws.

Inspection and maintenance on a periodic basis is essential. Installation and maintenance should be performed only by qualified personnel.

Be sure all instructions are read and understood before installation, operation and service.

Filters

REGO® LP-Gas equipment is designed to operate in a system free from contamination. A variety of in-line filters are commercially available to the LP-Gas industry for installation in domestic systems.

The use of an in-line filter should be considered when other system components may be unclean and the system contaminated by rust, scale, dirt, debris or other foreign material.

Contents

Page

Back Pressure Check Valves	F25
Chek-Lok® Excess Flow Valves	F18
Chek-Lok® Operation	F17
Cross Reference by Part Number	F29
Double Check Filler Valves	F20
Excess Flow Valves	F8
Limitations of Excess Flows	F7
Safety Warning for Excess Flows	F4
Testing of Excess Flows	F7
Troubleshooting of Excess Flows	F6
Vapor Equalizing Valves	F23
Warnings and Labels	F28

LP-Gas Excess Flow Valves

Safety Warnings



Purpose

In its continuing quest for safety, REGO® publishes a series of bulletins explaining the hazards associated with the use, misuse, and aging of LP-Gas valves and regulators. It is hoped that these factual bulletins will make clear to LP-Gas dealer managers and service personnel, that the utmost care and attention must be used in the installation, inspection, and maintenance of these products, or problems could occur which would result in injuries and property damage.

The National Fire Protection Association Pamphlet #58 - 2004 Edition, "Liquefied Petroleum Gas Code" states that, "persons who transfer liquid LP-Gas, who are employed to transport LP-Gas, or whose primary duties fall within the scope of this code shall be trained in proper handling procedures. Refresher training shall be provided at least every three years. The training shall be documented." These "REGO® Safety Warnings" may be useful in training new employees and reminding older employees of hazards that can occur. It is recommended that all employees be furnished with a copy of NPGA Safety Pamphlet 306-88, "LP-Gas Regulator and Valve Inspection and Maintenance."

Nature of Warnings


It is recognized that warnings should be as brief as possible, but the factors involved in excess flow valve failures to perform are not simple. They need to be fully understood. If there is a simple warning, it would be:

Make sure that the excess flow valve really closes when the flow exceeds normal transfer flow.

This bulletin is not intended to be an exhaustive treatment of excess flow valves, and certainly does not cover all safety practices that should be followed in installation, operation and maintenance of LP-Gas systems which include excess flow valves.

Selection and Installation

The selection of a given closing rating of an excess flow valve involves an analysis of the complete piping system and is beyond the scope of this bulletin.



It is sufficient to say that an excess flow valve must be installed in the correct direction and will close only if the flow of liquid or vapor exceeds its designed closing rating. Many valves have been installed with closing ratings considerably higher than any flow that could be obtained by a downstream rupture in piping or hoses and thus give none of the protection for which they are intended.


REGO® provides excess flow valves with a number of closing ratings. REGO® obviously can take no responsibility for the proper selection or correct installation of any valve.

Excess flow valves do not provide complete shut-off because there is a bleed at the check to permit pressure equalization.

Causes of Failure to Close


Installers, LP-Gas plant managers and service personnel should be aware that the excess flow valves may not close if these conditions are present.

1. The piping system restrictions (due to pipe length, branches, reduction in pipe size or number of other valves) decrease the flow rate to less than the valve's closing flow.




LP-Gas Excess Flow Valves


2. The break or damage to the downstream line is not large enough to allow enough flow to close the valve.




3. A shut-off valve in the line is only partially open and will not allow enough flow to close the excess flow valve.



4. LP-Gas pressure upstream of the excess flow valve, particularly due to low temperature, is not high enough to produce a closing flow rate.



5. Foreign matter (such as welding slag, scale or sludge) is lodged in the valve and prevents closing.



Because of these limitations, it is good industry practice to NOT rely entirely on excess flow valves for protection. Installation of emergency shut-off valves with remote controls is recommended in addition to excess flow valves.

Testing

The National Propane Gas Association Safety Bulletin #113-78 states:

"In order to test an excess flow valve in a piping system, the flow through the valve must be made to exceed the valve's closing rating. This testing should only be attempted by trained personnel familiar with the process. If no one at the facility has experience in proper testing, outside expert help should be obtained. The exact procedure used may vary with the installation, advisability of gas discharge and availability of equipment.

In general, most testing makes use of the fact that excess flow valves are "surge sensitive" and will close quicker under a sudden flow surge than under steady flow. A sufficient surge can often be created by using a quick open/close valve to control sudden, momentary flow into a tank or piping section containing very low pressure. An audible click from the excess flow valve (and corresponding stoppage of flow) indicates its closure.

A test involving venting gas to the atmosphere is hazardous and may be impractical, or illegal.

Any test of any excess flow valve will not prove that the valve will close in an emergency situation, due to reasons cited before. This test will only check the valve's condition, and the flow rate sizing for those test conditions."

General Warning

All REGO® products are mechanical devices that will eventually become inoperative due to wear, contaminants, corrosion and aging of components made of materials such as metal and rubber.

The environment and conditions of use will determine the safe service life of these products. Periodic testing at least once a year when tank pressures are low and maintenance, as required, are essential.

Because REGO® products have a long and proven record of quality and service, LP-Gas dealers may forget the hazards that can occur because an excess flow valve is used beyond its safe service life. Life of an excess flow valve is determined by the environment in which it "lives". The LPGas dealer knows better than anyone what this environment is.

NOTE: There is a developing trend in state legislation and in proposed national legislation to make the owners of products responsible for replacing products before they reach the end of their safe useful life. LPGas dealers should be aware of legislation which could effect them.

Troubleshooting Excess Flow Valve Installations

Periodical Inspections for Excess Flow Valves

Excess flow valves should be tested and proven at the time of installation and at periodic intervals not to exceed one year. CAUTION: Testing an excess flow valve in the summer when tank pressures are high will not prove that the same valve will also function under low pressure conditions in the winter. Once a year testing should be conducted during the winter.

The test should include a simulated break in the line by the quick opening of a shut-off valve at the farthest point in the piping that the excess flow valve is intended to protect. If the excess flow valve closes under these conditions, it is reasonable to assume that it will close in the event of accidental breakage (clean break) of the piping at any point closer to the excess flow valve.

The National Propane Gas Association Safety Bulletin Number 113-78 states:

In order to test an excess flow valve in a piping system, the flow through the valve must be made to exceed the valve's closing rating. This testing should only be attempted by trained personnel familiar with the process. If no one at the facility has experience in proper testing, outside expert help should be obtained. The exact procedure used may vary with the installation, advisability of gas discharge and availability of equipment.

In general, most testing makes use of the fact that excess flow valves are "surge sensitive" and will close quicker under sudden flow surge than under steady flow. A sufficient surge can often be created by using a quick open/close valve to control sudden, momentary flow into a tank or piping section containing very low pressure. An audible click from the excess flow valve (and corresponding stoppage of flow) indicates its closure.


A test involving venting gas to the atmosphere is hazardous and may be impractical or illegal.

Any test of any excess flow valve will not prove that the valve will close in an emergency situation, due to reasons cited before. This test will only check the valve's condition and the flow rate sizing for those test conditions.

What prevents excess flow valves from closing when the line breaks?


For one or a combination of the following reasons, excess flow valves have been prevented from closing in emergencies:

1. Not a Clean Break




Hoses with a split or tear, and pipe lines not completely severed may be emitting LP-Gas in an amount insufficient to cause an "excess" flow. The amount of LP-Gas which can escape through such breaks may be even less than the flow during normal transfer service and under these conditions the excess flow valve could not be expected to close.

2. Line Restriction Too Great




An excess flow valve installed in a tank outlet will not close if the line beyond it is reduced or if the flow is otherwise restricted by too many fittings or too long a run because the line is incapable of passing the amount of LP-Gas necessary to create an "excess" flow. This condition should be corrected when testing a system by simulating a break at the farthest possible point and replacing any restrictive hose, pipe or fittings.

3. Improper Operating Practice




A restriction can also be imposed upon the excess flow valve by an improperly opened valve at the tank outlet. The shutoff valve should be either fully opened or fully closed. If "throttled," the valve could reduce the amount of LP-Gas passing through the excess flow valve in a sufficient amount to keep it from closing. Throttling operations should not be performed in the lines being protected by excess flow valves.

4. Improper Selection




The many types of excess flow valves available are designed for specific jobs. The excess flow valve selected should remain open during normal flow but close at "excess" flow. An inspection which simulates a line break prior to start-up operations will determine if the proper valve has been selected.

5. Tampering with Excess Flow Valves



Sometimes an operator, annoyed with frequent closures of an excess flow valve with too low a rating, has mutilated the valve and forgotten to replace it with a properly rated excess flow valve. A pre-test of the system would reveal this and allow the excess flow valve to be replaced.

6. Impurities in the Line



Dirt, weld slag, broken drill taps, and various other foreign objects have been found jammed between the valve disc and valve seat to prevent excess flow valves from closing. A pre-test of the system would also discover this.

The Limitations of Excess Check Valves for LP-Gas

Excess flow check valves have been of help in limiting gas loss in many incidents involving breakage of hoses and transfer piping. Thus, they do provide a useful safety function in LP-Gas systems. However, there have also been transfer system accidents where excess flow valves have been ineffective in controlling gas loss due to a variety of conditions and to the inherent limitations of these valves. This bulletin explains what protection excess flow valves can offer, points out conditions which can interfere with that protection, and offers suggestions for effective excess flow valve installation.

An excess flow valve is a protective device to help control the discharge of product in the event of complete breakage of pipe lines or hose rupture. However, an excess flow valve can only offer limited protection from gas discharge, because it will only close under those conditions which cause the flow through the valve to exceed its rated closing flow, and even when closed it necessarily allows some "bleed" past the valve.

An excess flow valve is not designed to close and thus may not provide protection, if any of the following conditions are present:

1. The piping system restrictions (due to pipe length, branches, reduction in pipe size, or number of other valves) decrease the flow rate to less than the valve's closing flow. (Valve should be selected by closing flow rating — not just by pipe size).
2. The break or damage to the downstream line is not large enough to allow enough flow to close the valve.
3. A shut-off valve in the line is only partially open and will not allow enough flow to close the excess flow valve.
4. LP-Gas pressure upstream of the excess flow valve, particularly due to low temperature, is not high enough to produce a closing flow rate.
5. Foreign matter (such as welding slag) is lodged in the valve and prevents its closing.
6. A buildup of process material (sludge), which may be found in LPGas, may occur over a period of time and cause the valve to stick open.
7. The piping break or damage occurs upstream of an in-line excess flow valve, so the escaping product is not passing through the valve.
8. The flow through the valve is in the wrong direction. (Excess flow valves only respond to flow in one direction.)
9. The excess flow valve has been damaged, or is otherwise not in operating condition.

Because of these limitations of excess flow valves, they should not be relied upon as the only means of controlling the escape of product in the event of piping damage. When possible, shut-off protection by quick closing valves, with shut-off controls accessible in spite of likely line damage, should be provided in addition to, or instead of excess flow valves.

Where excess flow valves are installed, they should be checked to see that:

1. They are installed in the correct direction — the arrow on the valve indicates the shut-off direction.
2. The flow rating on the valve is proper for the installation. The rating must be above the normal system flow, but not higher than necessary to prevent "nuisance" closing in normal conditions. If the manufacturer's catalog information is not sufficient, the valve suppliers can provide sizing assistance.
3. In-line excess flow valves are installed so likely piping damage will occur downstream of the valve and will not separate the valve from the upstream piping.

When the excess flow valves can be examined separate from the line (before the installation or if removed for system maintenance), they should be checked to see that the parts are in good condition and that the poppet can be pushed fully closed.

Testing of Excess Flow Valves

In order to test an excess flow valve in a piping system, the flow through the valve must be made to exceed the valve's closing rating.

This testing should only be attempted by trained personnel familiar with the process. If no one at the facility has experience in proper testing, outside expert help should be obtained. The exact procedure used may vary with the installation, advisability of gas discharge, and availability of equipment.

In general, most testing makes use of the fact that excess flow valves are "surge sensitive" and will close quicker under a sudden flow surge than under steady flow. A sufficient surge can often be created by using a quick-closing valve to control sudden, momentary flow into a tank or piping section containing very low pressure. An audible click from the excess flow valve (and corresponding stoppage of flow) indicates its closure.

A test involving venting gas to the atmosphere is hazardous and may be impractical, or illegal.

Any test of any excess flow valve will not prove that the valve will close in an emergency situation, due to reasons cited before. This test will only check the valve's condition, and the flow rate sizing for those test conditions.

For additional information on excess flow valves and other means of shut-off protection, contact REGO® and refer to NFPA 58.

Prepared by
NATIONAL PROPANE GAS ASSOCIATION

The purpose of this bulletin is to set forth general safety practices for the installation, operation, and maintenance of LP-Gas equipment. It is not intended to be an exhaustive treatment of the subject, and should not be interpreted as precluding other procedures which would enhance safe LP-Gas operations. The National Propane Gas Association assumes no liability for reliance on the contents of this bulletin.

Excess Flow Valves

General Information

RegO® Excess Flow Valves have been designed, developed, and manufactured for a wide variety of industry needs for more than three decades.

Throughout the years, those concerned with installing and operating bulk plant facilities have looked to RegO® products with confidence for reliable, long-lasting valves as required by the National Fire Protection Association (NFPA) Standards 58 and 59, as well as any state, provincial, and local regulations.

It is a responsibility we have not taken lightly. RegO® products continue to not only assess the most effective designs, but anticipate and meet the industry's changing requirements. Toward that goal, RegO® products include over fifty different types and sizes of excess flow valves (most of which are listed by Underwriters Laboratories) to meet the needs of the LP-Gas and anhydrous ammonia industries.

An Explanation and Warning

An excess flow valve is a spring-loaded check valve which will close only when the flow of fluid through the valve generates sufficient force to overcome the power of the spring holding it open. Each valve has a closing rating in gallons per minute and CFH/air.

The selection of a proper closing rating is critical. It requires a technical understanding of the flow characteristics of the piping system, including restrictions of the piping and other valves and fittings downstream of the excess flow valve.

System designers and operating people must understand why an excess flow valve, which remains open in normal operations, may fail to close when an accident occurs.

Warning: A downstream break in piping or hoses may not result in sufficient flow to close the valve.

How They Work

Excess flow valves permit the flow of liquid or vapor in either direction. This flow is controlled in only one direction (the direction of the arrow stamped on the valve). If the flow in that direction exceeds a predetermined rate (shown in this catalog for each valve), the valve automatically closes.

The valve disc is held in the open position by a spring. When the flow creates a pressure drop across the valve disc that overcomes the preset load on the spring, the valve disc moves to the closed position. It remains closed until the force on both sides of the valve disc are approximately equal (a small bleed hole in the disc of each valve permits equalization), then the spring automatically reopens the valve. When a line is completely broken, the pressure cannot equalize and the excess flow valve remains closed until the line is repaired. Because the bleed hole in each valve disc permits equalization of pressure, excess flow valves do not provide a 100 percent type shut-off.

Proper Installation

Since excess flow valves depend on flow in order to close, the line downstream of the excess flow valve should be large enough not to excessively restrict the flow. If the piping is too small, unusually long or restricted by too many elbows, tees and other fittings, consideration should be given to the use of larger size pipe fittings.

An excess flow valve in a pump suction line cannot be expected to close in the case of a clean break in the line beyond the pump, as the pump constitutes too great a restriction, even if running.

Good piping practices dictate the selection of an excess flow valve with a rated closing flow of approximately 50 percent greater than the anticipated normal flow. This is important because valves which have a rated closing flow very close to the normal flow may chatter or slug closed when surges in the line occur during normal operation, or due to the rapid opening of a control valve.

All installations must be in accordance with NFPA Standards 58 and 59, as well as state, provincial and local regulations.

Cotter pin prevents loss of spring retainer due to vibration in service.


Spring retainer.

Stainless steel spring for consistent closing flow, long service life.

Welded for strength.

Precision machining.

Generous flow channels for lowest pressure drop are particularly important in pump suction lines.



Excess Flow Valves for Liquid or Vapor Service

1519C Series

Application

Designed for top mounting in storage tank manhole covers for liquid or vapor applications. The tapped inlet allows for an optional 1" NPT dip pipe connection to withdraw liquid from the top of the tank.

The 1519C4 is designed for installation in long line or branch piping applications.

Features

- Precision machined
- Generous flow channels provide low pressure drop.
- Cotter pin prevents loss of spring retainer due to vibration in service.
- Stainless steel spring provides consistent closing flow and long service life.

Materials


1519C2

Body Brass
Valve Poppet w/Stem Brass
Spring Stainless Steel
Guide Brass




1519C4

Body Brass
Valve Disc Cadmium Plated Steel
Stem Stainless Steel
Spring Stainless Steel
Guide Ductile Iron




1519C2

Typical Installation




Manhole Cover


Performance



NOTE: Multiply flow rate by .94 to determine liquid butane flow.



1519C4



Typical Installation

Ordering Information

Part Number	A Inlet Connection NPT	B Outlet Connection F. NPT	C Wrench Hex Flats	D Effective Length (Approx.)	E Threaded End to Port	Filling Connection F. NPT	Approximate Closing Flows		
							Liquid (GPM Propane)	Vapor SCFH (Propane)	
								25 PSIG Inlet	100 PSIG Inlet
1519C2	1½" Male*	1"	2¼"	2½"	2½"	1"	25	5,000	8,800
1519C4	2" Female	2"	3"	4½"	-	2"	170	28,590	48,600

* 1" Female Dip Pipe Connection

** Based on horizontal installation of excess flow valve. Flows are slightly more when valves are installed with outlet up; slightly less when installed with outlet down.
NOTE: Multiply flow rate by .94 to determine liquid butane flow.

Excess Flow Valves for Liquid or Vapor Line Service

1519A Series, 1519B Series and A1519 Series

Application

Designed for top installation, in any position, in liquid or vapor service lines. They are intended for long lines or branch piping where tank mounted excess flow valves cannot suffice.

Features

- Precision machined.
- Generous flow channels provide low pressure drop.
- Cotter pin prevents loss of spring retainer due to vibration in service.
- Stainless steel spring provides consistent closing flow and long service life.

Materials

1519A Series and 1519B Series

Body Brass
Valve Poppet w/Stem Brass
Spring Stainless Steel
Guide Brass




1519A2, 1519A3, 1519A4, 1519B4,
A1519A2, A1519A4, A1519B4



A1519 Series

Body Cadmium Plated Steel
Valve Disc Cadmium Plated Steel
Stem Stainless Steel
Spring Stainless Steel
Guide Ductile Iron


Performance



NOTE: Multiply flow rate by .94 to determine liquid butane flow and by .90 to determine liquid anhydrous ammonia flow.



A1519A6



Typical Installation

Ordering Information

Part Number	Brass or Steel	A Inlet Connection NPT	B Outlet Connection F. NPT	C Wrench Hex Flats	D Effective Length (Approx)	Approximate Closing Flows*		
						Liquid (GPM Propane)	Vapor SCFH (Propane)	
							25 PSIG Inlet	100 PSIG Inlet
1519A2	Brass	1"	1"	1¾"	3⅝"	25	5,000	8,800
A1519A2	Steel							
1519A3	Brass	1½"	1½"	2¼"	4"	60	11,500	20,200
1519A4		2"	2"	3"	4⅞"	100	19,000	34,500
A1519A4	Steel							
1519B4	Brass	133	27,700	50,300				
A1519B4	Steel				3"	3"	4"	6⅞"
A1519A6		225	45,000	82,000				

* Based on horizontal installation of excess flow valve. Flows are slightly more when valves are installed with outlet up; slightly less when installed with outlet down.

NOTE: Multiply flow rate by .94 to determine liquid butane flow and by .90 to determine liquid anhydrous ammonia flow.

Excess Flow Valves for Liquid or Vapor 3272 Series, 3282 Series, 3292 Series, A3272 Series, A3282 Series, A3292 Series, 7574 and 12472

Application

Designed for liquid or vapor use for filling, withdrawal and vapor equalizing in container or line applications. They are intended for long lines or branch piping where tank-mounted excess flow valves are inadequate.

Features

- Precision machined.
- Generous flow channels provide low pressure drop.
- Stainless steel spring provides consistent closing flow and long service life.


Materials

Series 3272, 3282, 3292, 7574, 12472


Body Brass
Seat Disc Brass
Stem Brass
Spring Stainless Steel
Guide (12472 ONLY) Plastic

Series A3272, A3282, A3292


Body Cadmium Plated Steel
Seat Disc Cadmium Plated Steel
Stem Cadmium Plated Steel
Spring Stainless Steel



Typical Installation





Container Service



Pipe Line Service

Performance



Ordering Information

NOTE: Multiply flow rate by .94 to determine liquid butane flow and by .90 to determine liquid anhydrous ammonia flow.

Part Number	Brass or Steel	A Inlet Connection (M. NPT)	B Outlet Connection (F. NPT)	C Wrench Hex Flats	D Effective Length (Approx.)	Approximate Closing Flow*						
						Liquid (GPM Propane)	Vapor SCFH (Propane)					
							25 PSIG Inlet	100 PSIG Inlet				
12472	Brass	3/4"	3/4"	1 1/8"	1 1/8"	4	1,050	1,700				
3272E						10	2,100	3,700				
3272F						15	2,800	5,000				
3272G						20	3,700	6,900				
A3272G	Steel	1 1/4"	1 1/4"	2"	1 15/16"	30	5,850	10,000				
3282A	Brass					40	7,600	13,600				
3282B						50	9,000	16,300				
3282C	Steel					1 1/2"	1 1/2"	2 1/4"	1 3/4"	90	15,200	28,100
A3282C	70	14,000	25,000									
7574	Brass	2"	2"	2 7/8"	1 1/8"					75	14,200	24,800
7574L										100	18,100	32,700
3292A	Steel					122	22,100	37,600				
A3292A	Brass											
3292B	Steel											
A3292B												
A3292C												

* Based on horizontal installation of excess flow valve. Flows are slightly more when valves are installed with outlet up; slightly less when installed with outlet down.

Excess Flow Valves for Container Service

A7537 Series, A7539 Series, A8523 and A8525

Application

Designed for mounting in threaded full or half couplings in container installations. They may be used for filling, withdrawal or vapor equalizing applications. The exceptionally low pressure drop makes them ideal for pump suction lines. If a riser pipe to the vapor space is used with these valves, the minimum inside diameter of the riser pipe must be at least two times the valve thread size in order not to restrict flow to the side inlet ports.



Features

- Precision machined.
- Generous flow channels provide low pressure drop minimizing cavitation in pump suction lines.
- Cotter pin prevents loss of spring retainer due to vibration in service.
- Stainless steel spring provides consistent closing flow and long service life.
- Separate models for installation in either half or full couplings.

Materials

Body	Cadmium Plated Steel
Body (A7539 Series Only)	Ductile Iron
Seat Disc	Cadmium Plated Steel
Stem	Stainless Steel
Spring	Stainless Steel
Guide	Cadmium Plated Steel

Performance




NOTE: Multiply flow rate by .94 to determine liquid butane flow and by .90 to determine liquid anhydrous ammonia flow.


Ordering Information

Part Number	For Use With This Type Coupling	A Inlet Connection M. NPT	B Outlet Connection NPT	C Wrench Hex Flats	D Effective Length (Approx.)	Approximate Closing Flow*		
						Liquid (GPM Propane)	Vapor SCFH (Propane)	
							25 PSIG Inlet	100 PSIG Inlet
A8523	Half	3/4"	3/4" Male	1 1/8"	1 3/4"	15	5,170	8,800
A8525	Half	1 1/4"	1 1/4" Male	1 3/4"	2 1/8"	35	12,540	21,560
A7537L4	Half	2"	2" Male and 1 1/4" Female	2 5/8"	2 1/2"	75	13,000	25,600
A7537L4F	Full					125	25,000	42,500
A7537N4	Half					150	30,500	52,000
A7537N4F	Full					150	30,500	52,000
A7537P4	Half	3"	3" Male and 2" Female	3 3/4"	3 1/8"	150	32,100	55,500
A7537P4F	Full					200	39,400	68,300
A7539R6	Half					250	51,100	88,700
A7539R6F	Full							
A7539T6	Half							
A7539T6F	Full							
A7539V6	Half							
A7539V6F	Full							


* Based on horizontal installation of excess flow valve. Flows are slightly more when valves are installed with outlet up; slightly less when installed with outlet down.



Typical Installation



Half Coupling



Full Coupling



Excess Flow Valves for Vapor or Liquid A2137 Series and 2139 Series

Application

Designed especially for filling, withdrawing or vapor equalizing in half and full coupling installations. Ideal for container service where welded-in dip pipes are not provided. For vapor use, mount in the bottom opening with a threaded dip pipe. For liquid use, mount in the top opening with a threaded dip pipe. These may also be installed in pipe lines provided the connection is made to the male inlet thread and not the female dip pipe connection.

Features

- Precision machined.
- Cotter pin helps prevent loss of spring retainer due to vibration in service.
- Stainless steel spring provides consistent closing flow and long service life.
- Generous flow channels provide low pressure drop.


Materials

A2137 Series


Body Cadmium Plated Steel
Disc..... Cadmium Plated Steel
Stem Stainless Steel
Spring Stainless Steel
Guide..... Cadmium Plated Steel

2139 Series


Body Brass
Disc..... Brass
Stem Stainless Steel
Spring Stainless Steel
Guide..... Brass



Typical Installations



Performance



NOTE: Multiply flow rate by .94 to determine liquid butane flow and by .90 to determine liquid anhydrous ammonia flow.

Ordering Information

Part Number	A Inlet Connection NPT	B Outlet Connection F. NPT	C Wrench Hex Flats	D Effective Length (Approx.)	Approximate Closing Flows***		
					Liquid (GPM Propane)	Vapor SCFH (Propane)	
						25 PSIG Inlet	100 PSIG Inlet
A2137	2"	2" Male and 1 1/4" Female	2 7/16"	1 1/8"	50	10,000	17,000
A2137A					70	14,000	25,000
2139	3"	3" Male and 2" Female	3 1/2"	1 1/8"	125	26,500	46,000
2139A					160	32,700	57,200

* 1 1/4" F. NPT Dip Pipe Connection

** 2" F. NPT Dip Pipe Connection

*** Based on horizontal installation of excess flow valve. Flows are slightly more when valves are installed with outlet up; slightly less when installed with outlet down.

Excess Flow Valves for Flange Mounting in Container Service A3500 Series and A4500 Series

Application

Designed for mounting in flanged tank connections with internal threads in the bottom of a container. They may be used in filling, withdrawal or vapor equalizing application. They provide high flow capacity with low pressure drop to minimize pump inlet line cavitation.

If a riser pipe to the vapor space is used with these excess flow valves, the minimum inside diameter of the riser pipe must be at least two times the valve thread size in order not to restrict flow to the side inlet ports.

Flange mounted excess flow valves are readily accessible for servicing and completely enclosed and protected in event of fire. Because there is no direct connection between external piping and the valve, stresses imposed on piping will not affect the excess flow valve.

Features

- Precision machined.
- Generous flow channels provide low pressure drop minimizing cavitation in pump suction lines.
- Cotter pin prevents loss of spring retainer due to vibration in service.
- Stainless steel spring provides consistent closing flow and long service life.

Materials

Body	Cadmium Plated Steel
Seat Disc	Cadmium Plated Steel
Stem	Stainless Steel
Spring	Stainless Steel
Guide	Cadmium Plated Steel

Flanged Installation In Container

NOTE: The opening in the tank flange should be machined with a $\frac{1}{4}$ "-45° chamfer at the outer edge. The thread should be tapped one or two turns large as checked by a plug gauge. This and the undersize thread on the valve should permit the valve to be installed so that its outer face is at least flush with the outer edge of the flange.

The valve is screwed into this opening by fitting a $\frac{1}{4}$ " flat metal piece into the slot and turning until hand tight. A lubricant may be used, but a luting compound is not necessary since this joint does not have to be gas tight.

If any difficulty is experienced in "making up" the valve to fit flush, as indicated, the thread in the tank flange can be tapped.

Design and construction of tank and flange must be in accordance with the appropriate section of the ASME Pressure Vessel Code.


Ordering Information

Part Number	A Inlet Connection NPT	B For Installation	C Effective Thread (Approx.)	D Threaded End To Port	Approximate Closing Flows*		
					Liquid (GPM Propane)	Vapor SCFH (Propane)	
						25 PSIG Inlet	100 PSIG Inlet
A3500L4	2"	Slotted Body	¾"	1½⁄₁₆"	75	13,000	22,500
A3500N4					125	25,000	42,500
A3500P4					150	30,500	52,000
A3500R6	3"		1"	1⁄₁₆"	150	32,100	55,500
A3500T6					200	39,400	68,300
A3500V6					250	51,100	88,700
A4500Y8	4"		1¼"	1½"	500	89,000	154,000


NOTE: Multiply flow rate by .94 to determine liquid butane flow and by .90 to determine liquid anhydrous ammonia flow.

* Based on horizontal installation of excess flow valve. Flows are slightly more when valves are installed with outlet up; slightly less when installed with outlet down.


F14



Performance



Specifications for companion flanges, gaskets, bolts and nuts must meet the appropriate codes, such as ASA B16.5.



Key No.	Description	A3400L4, A3500L4, A3500N4, A3500P4	A3400L6, A3500R6, A3500T6, A3500V6	A4500Y8
A	Valve Size (NPT)	2"	3"	4"
B	Tank Opening	3 $\frac{1}{2}$ "	4 $\frac{1}{2}$ "	5 $\frac{1}{2}$ "
C	Thickness (min.)	1"	1 $\frac{1}{4}$ "	1 $\frac{3}{8}$ "
D	Outside Diameter	6 $\frac{1}{2}$ "	8 $\frac{1}{4}$ "	10"
E	Pipe Thread (NPT)	2"	3"	4"
F	Bolt Circle Dia.	5"	6 $\frac{1}{8}$ "	7 $\frac{1}{8}$ "
	Number of Bolt Holes	8	8	8
G	Bolt Hole Thread	$\frac{5}{8}$ " -11 NC - 2	$\frac{3}{4}$ " - 10 NC - 2	$\frac{3}{4}$ " - 10 NC - 2
H	Bolt Hole Thread (min. eff.)	$\frac{3}{4}$ "	1"	1 $\frac{1}{8}$ "

Excess Flow Valves for Liquid or Vapor Withdrawal 2723C and A8013D Series

Application

These valves are designed for bottom mounting in consumer storage tanks for liquid service. They may also be top mounted for vapor service. These valves are designed especially for use with RegO® globe and angle valves.

Features

- 2723C provides a 3/4" dip pipe inlet connection for top-mounted liquid or bottom-mounted vapor requirements.
- A8013D Series features a 2-position floating valve disc for faster, more efficient container filing.
- Precision machined.
- Stainless steel spring provides consistent closing flow and long service life.
- Generous flow channels provide low pressure drop.


Materials

A8013D Series


Body	Cadmium Plated Steel
Disc	Stainless Steel
Stem	Stainless Steel
Spring	Stainless Steel
Guide	Cadmium Plated Steel
Insert	Stainless Steel

2723C

Body	Brass
Valve Poppet	Brass
Retainer	Brass
Spring	Stainless Steel




A8013D



2723C

Performance



Ordering Information

Part Number	A. Inlet Connection M. NPT	B. Outlet Connection NPT	C. Wrench Hex Flats	D. Effective Length (Approx.)	E. Threaded End To Port	Approximate Closing Flow**		
						Liquid (GPM Propane)	Vapor SCFH (Propane)	
							25 PSIG Inlet	100 PSIG Inlet
A8013D	1 1/4"	3/4"	1 1/4"	9/16"	-	39	8,700	14,700
A8013DA		1"		2 1/2"		44		
A8013DB		1 1/4"		1 1/16"		55		
2723C	1 1/4"	3/4"	1 1/16"	1 1/4"	3 3/16"	20	3,900	6,900

* 3/4" F. NPT Dip Pipe Connection

** Based on horizontal installation of excess flow valve. Flows are slightly more when valves are installed with outlet up; slightly less when installed with outlet down.

NOTE: Multiply flow rate by .94 to determine liquid butane flow and by .90 to determine liquid anhydrous ammonia flow.

Excess Flow Valve for Pressure Gauges 2884D

Application


Designed for container use in pressure gauge installations to minimize excess gas discharge in the event the pressure gauge is sheared. A suitable shut-off valve should be installed between this valve and the pressure gauge to allow convenient gauge replacement.

Features

- Precision machined.
- Suitable for use with all 1/4" M.NPT pressure gauges.

Materials

Body	Brass
Valve	Brass
Spring	Stainless Steel
Pin	Stainless Steel



2884D



Ordering Information

Part Number	A. Inlet Connection M. NPT	B. Outlet Connection F. NPT	C. Wrench Hex Flats	D. Effective Length (Approx.)	E. Threaded End To Port	Approximate Closing Flow*		
						Liquid (GPM Propane)	Vapor SCFH (Propane)	
							25 PSIG Inlet	100 PSIG Inlet
2884D	3/4"	1/4"	1 1/16"	1 1/4"	1 1/16"	N/A	60	110

* Based on horizontal installation of excess flow valve. Flows are slightly more when valves are installed with outlet up; slightly less when installed with outlet down.

NOTE: Multiply flow rate by .94 to determine liquid butane flow.

Excess Flow Valve for DOT Cylinders 3199W

Application

Designed for use on portable systems with vapor or liquid including torches, heaters, lead melting burners, tar and asphalt burners, wallpaper steamers and other applications involving portable DOT cylinders. The POL inlet attaches directly to the cylinder valve and the outlet mounts to the regulator.

Features



- Integral ball check design.
- Machined groove designed to break-off and allow excess flow valve ball to close.

Materials

Body	Brass
Nut	Brass
Bell	Stainless Steel
Spring	Stainless Steel
Retainer Spring	Stainless Steel
Retainer	Brass



3199W



Typical Installation



NOTE:

No protection is afforded should break-off occur downstream of the groove. Also, restrictions introduced by the regulator may prevent closing of the valve due to limited flow capacity. The valve's purpose is to protect the cylinder valve outlet should the regulator be broken off of its connection (at the groove), in which case it will close. It must not be depended upon to protect against breaks downstream of the regulator.

Ordering Information

Part Number	A. Inlet Connection	B. Outlet Connection	C. Wrench Hex Flats	D. Effective Length (Approx.)	Approximate Closing Flow*		
					Liquid (GPM Propane)	Vapor SCFH (Propane)	
						25 PSIG Inlet	100 PSIG Inlet
3199W	Male POL	1/4"	7/8"	1 1/16"	.95	265	500

* Based on horizontal installation of excess flow valve. Flows are slightly more when valves are installed with outlet up; slightly less when installed with outlet down.

NOTE: Multiply flow rate by .94 to determine liquid butane flow.

F16

Chek-Lok® Excess Flow Valves

Designed to provide a convenient means of withdrawing liquid from stationary containers prior to moving the container.

NFPA Pamphlet 58 standards require: 1) containers with 125 gallons water capacity, or more, have a connection for liquid evacuation which is at least 3/4" NPT, and 2) containers designed for stationary use, have no more propane than 5% of their water capacity in liquid form during transportation. These rules apply to containers manufactured after July 1, 1961.

Chek-Lok® Operation

Instructions to Open Chek-Lok®

- 1 Loosen cap to vent any accumulated LP-Gas from the Chek-Lok. After venting stops, remove the cap. If venting does not stop, retighten the cap and use other approved means to withdraw liquid from the container.

NOTE: Use a suitable size wrench when removing the cap and adapter from the Chek-Lok. Do not allow the Chek-Lok to unthread from the tank during removal. When necessary, use a second wrench to secure the Chek-Lok in position.

- 2 Before beginning withdrawal, securely connect an REGO® 7550P angle valve or suitable shut-off valve to the adapter. Fully open the shut-off valve – the valve's handwheel must be fully opened before connecting adapter to tank.
- 3 Completely thread the adapter and shut-off valve assembly onto the Chek-Lok by turning adapter's coupling nut clockwise until it is tight. Immediately close the shut-off valve. Listen for an audible click to signal that the Chek-Lok has opened and is actuated for liquid withdrawal. The flow can now be controlled by the transfer valve.

- 4 Check the coupling nut and adapter assembly for leaks using a suitable leak detection solution.

If the Chek-Lok fails to open after following this procedure, the pressure downstream of the shut-off valve should be increased to equalize pressure in the Chek-Lok. It is simple to equalize pressures using vapor from either the vapor return valve or service valve, or from a hose end valve connected to the delivery truck.

Instructions to Close Chek-Lok®


- 1 To re-lock the Chek-Lok, container pressure must be in excess of 35 PSIG. Close shut-off valve and disconnect the hose or piping.
- 2 Open shut-off valve fully. Liquid discharging to the atmosphere should cause the excess flow valve of the Chek-Lok to close, provided tank pressure is 35 PSIG or more.

If, for any reason, the excess flow valve does not close, the shut-off valve must be closed immediately and must not be removed until the system can be evacuated and the unit repaired.


- 3 After the excess flow valve closes, remove the Adapter and Shut-Off Valve Assembly.
- 4 Clean face of Chek-Lok and install the Cap with a gasket. IMPORTANT: Only use the proper Chek-Lok Cap. Do not use a standard pipe cap.

The Chek-Lok® permits one transfer shut-off valve with an adapter to be used interchangeably on a number of tanks. With a Chek-Lok® on each tank and a high capacity RegO® 7550P Series transfer valve and adapter on all your service and delivery trucks – the need for individual transfer valves is eliminated. This provides a substantial savings without sacrificing safety.

Connecting the 7590U or 7591U Chek-Lok®



Connecting the 7572FC or 7580FC Chek-Lok®




In the absence of a 7550P transfer valve, a 3/4" A7505A Globe Valve or A7506AP Angle Valve may be used. Follow the above procedures using the 7572C-15A adapter instead of the 7572C-14A. Use a REGO® 7550P without an adapter in an emergency only.

CAUTION: Always wear approved protective gloves when working with the Chek-Lok®. Do not vent LP-Gas near possible source of ignition.

Chek-Lok® Mounting

Chek-Lok® Valves may be either top mounted with a dip tube or bottom mounted. For bottom mounting, it is preferable to position the coupling in the head or slightly off of the bottom. This helps prevent the accumulation of sludge, etc. around the valve which could affect the proper operation of the excess flow valve.



Chek-Lok® Excess Flow Valves 7590U and 7591U Series

Application

Chek-Lok® Excess Flow Valves are designed to provide a convenient means of withdrawing liquid from stationary containers prior to moving the container. The Chek-Lok® permits one transfer shut-off valve with an adapter to be used interchangeably on a number of tanks.


The 7590U and 7591U Chek-Loks® are also designed for use on permanent installations provided the excess flow valve is sized properly for the system and piping. NOTE: In some cases, it may be necessary to use an in-line excess flow valve to protect the downstream piping. This valve is not recommended for use as a liquid source for pumps.

Features

- Extra strength connection between body and adapter provides increased strength.
- Weep hole in cap provides indicator to verify Chek-Lok® is closed before cap removal.
- Heavy duty brass cap requires at least 3½" full turns for removal.
- O-ring seal on adapter provides a gas tight seal before the adapter opens the equalizing stem.
- Eliminates need for individual transfer valves at each container.
- UL listed.



7590U with Cap



Materials

Body	Brass
Stem	Brass
Spring	Stainless Steel
Seals	Sunthetic Rubber
Valve Poppet	Brass
Gasket	Nylon

Chek-Lok® Number	Inlet Connection	Outlet Connection	A. Body Wrench Hex Flats	B. Approximate Effective Length	C. Cap Wrench Hex Flats	Approximate Closing Flow, Liquid GPM (Propane)*
7590U	¾" M. NPT	1½" UNF	1½"	1¼"	1½"	20
7591U	1¼" M. NPT		1¾"	1½"		35

* Based on horizontal installation of excess flow valve. Flows are slightly more when valves are installed with outlet up, and slightly less when installed with outlet down.
Note: Multiply flow rate by .94 to determine liquid butane flow.

Chek-Lok® Liquid Evacuation Adapter for 7590U and 7591U Valves 7590U-20

Application

Designed specifically for use with RegO® 7590U and 7591U Chek-Lok® Excess Flow Valves. Adapter's operating handle opens and closes equalizing stem in the Chek-Lok® valve. Eliminates gas flow through Chek-Lok® valve when installing or removing adapter. Use of RegO® adapter ensures proper connections and opening of the check mechanism.

Features


- Built in nylon gasket provides a gas tight seal.
- Adapter can be installed without depressing the equalizing stem of the Chek-Lok®.
- Design eliminates the need to slug excess flow feature of Chek-Lok® when removing the adapter.
- Built in bleeder valve allows controlled discharge of liquid before removing the adapter.

Ordering Information

Adapter Number	Inlet Connection	Outlet Connection	A Wrench Hex Flats	B Approximate Length
7590U-20	1½" F. NPT	¾" F. NPT	1¼" F. NPT	4½" F. NPT



7590U-20



7580F-20 Liquid Evacuation Adapter for older design 7572FC and 7580FC Chek-Lok® Valves

Application


Designed specifically for use with RegO 7572FC and 7580FC Chek-Lok® Excess Flow Valves. The adapter's operating handle opens and closes the equalizing stem in these older style Check-Lok® valves. This adapter is designed to eliminate the need for gas to flow from the Chek-Lok® when the adapter is installed or removed. A shutoff valve, such as a full port ball valve must be installed at the outlet of the 7580F-20.

Features

- Built in nylon gasket provides a gas tight seal.
- Adapter can be installed without depressing the equalizing stem of the Chek-Lok®.
- Design eliminates the need to slug the excess flow feature of the Chek-Lok® when removing the adapter.
- Built in bleeder valve allows for controlled discharge of liquid before removing the adapter.


Ordering Information

Adapter Number	Inlet Connection	Outlet Connection	Approximate Length	Wrench Hex Flats
7580F-20	¾" M-NPT	¾" F. NPT	1¾"	3⅞"



Union Style Adapters for 7590U and 7591U Valves

The 7590U-10 adapter must be used to connect to the 7590U and 7591U Chek-Lok. This insures a proper connection to open the check mechanism. A built in nylon gasket provides a gas tight seal.



7590U-10

Ordering Information


Adapter Number	Inlet Connection	Outlet Connection	A. Wrench Hex Flats	B. Approximate Length
7590U-10	1½" UNF	¾" F. NPT	1¾"	1⅜"

Adapters for 7572FC and 7580FC Valves

These adapters must be used to connect to the 7572FC and 7580FC Chek Loks to open the check mechanism properly. A built in nylon gasket provides a gas tight seal.



7572C-14A
For Transfer
Valves




Ordering Information

Adapter Number	Inlet Connection	Outlet Connection	A. Wrench Hex Flats	B. Approximate Effective Length
7572C-14A	¾" M. NPT	¾" F. NPT	1⅝"	1"
7572C-15A	¾" M. NPT	¾" M. NPT	1⅝"	¼"



7572C-15A
For Globe and
Angle Valves



Double-Check Filler Valves

General Information


RegO® Double-Check Filler Valves incorporate a resilient upper check valve, normally designated as a filler valve, and a lower check valve, commonly called a back pressure check valve. Available in a range of sizes to cover virtually all LP-Gas storage containers, these valves are UL listed and meet NFPA standards, as well as other safety requirements.

Flow of liquid into the storage container opens both check valves. When flow stops, they both are designed to close automatically to permit the operator to disconnect the hose coupling. The automatic closing action also helps prevent the discharge of container contents in the event of hose failure. The lower back pressure check affords extra protection by restricting the discharge if the upper check fails to function properly due to accidents or other causes.

The double back check construction allows emergency inspection, repair, or replacement of the upper fill assembly without removing product from the container. When the upper filler valve body is removed, the lower back check valve provides a seal, permitting only some leakage, allowing a new upper filler valve body to be installed.

Spare Gasket Ordering Information

ACME	Part Number
1¼"	A2797-20R
1½"	A2697-20R
2¼"	A3184-8R
3¼"	A3194-8R



Double-Check Filler Valves for Large Motor Fuel and ASME Tanks 6579 Series and 7579 Series

Application

Designed to provide fast filling of large motor fuel and ASME domestic tanks. The 6579 Series incorporates a swing-away lower check which greatly reduces pressure drop across the valve. This lower pressure drop promotes faster filling rates and greater efficiency resulting in more profitable operations.

Features

- Double back check provides added system protection.
- Upper filler valve assembly can be easily replaced without evacuating the container.
- Both checks are spring actuated for quick, precise closure when flow into the valve stops or reverses.
- 6579 Series swing-away check promotes faster filling for more profitable operations.
- Specify RegO® Filler Valves on all your original tank purchases to insure quality and dependable performance.



Materials

Upper Body.....	Brass
Lower Body.....	Brass
Springs.....	Stainless Steel
Washer and Seat Disc.....	Synthetic Rubber
Cap.....	Plastic



Ordering Information

Part Number		A. ACME Hose Connection	B. Tank Connection M. NPT	C. Wrench Hex Flats	D. Effective Length (Approx.)	Propane Liquid Capacity at Various Differential Pressures (GPM)				
Cap Only	Cap, Chain and Ring					5 PSIG	10 PSIG	25 PSIG	50 PSIG	75 PSIG
7579	7579C	1¼"	1¼"	1½"		50	70	111	157	192
7579P	-		1¼"			37	52	82	116	142
6579**	6579C**		1¼"			78	110	174	246	301

* Incorporates ¾ F. NPT dip pipe connection

** Swing-away lower back check valve design for higher filling rate. NOTE: Multiply flow rate by .94 to determine liquid butane capacity.

Double Check Filler Valves for Forklift, Motor Fuel and RV Tanks 7647 Series

Application

Designed to provide fast filling of forklift, motor fuel, and recreational vehicle tanks.

Features


- Resilient seat disc in lower check designed to provide a gas tight seal without leakage.
- Double back check provides added system protection.
- 7647SA has 30° angle on hose connection. Makes connection and disconnection easier for certain engine fuel applications.
- Large 1½" wrench flats on 7647SC allow use of socket wrench for easy installation.
- Specify RegO® Filler Valves on all your original tank purchases to insure quality and dependable performance.

Materials



Upper Body..... Brass
Lower Body..... Brass
Springs..... Stainless Steel
Washer and Seat Discs..... Resilient Synthetic Rubber
Cap..... Plastic





7647DC



7647H




7647SC



7647SA



7647HF



Ordering Information

Part Number		A Hose Connection	B Tank Connection M. NPT	C Wrench Flats	D Effective Length (Approx.)	Propane Liquid Capacity at Various Differential Pressures (GPM)***				
Basic	w/Lanyard and Cap					10 PSIG	20 PSIG	30 PSIG	40 PSIG	50 PSIG
7647H	-	½" F. NPT	¾"	1½"	2⅞"	14	20	24	27	50
7647HF	-	½" SAE Flare			2⅝"					
-	7647DC	1¾" ACME & F. POL			3"					
-	7647SA**	1¾" ACME			3⅞"					
-	7647SC*			1¾"	2½"					

* Large 1½" hex wrench flats.

** 30° angle on 1¼" ACME hose connection.

*** Multiply flow rate by .94 to determine liquid butane capacity.

Double Check Filler Valves for Delivery Truck Tanks and Large Storage Containers 7579S, 6587EC and 3197C

Application

Designed to provide fast filling of bobtails, transports and large bulk storage tanks.


The 6587EC incorporates a swing-away lower check which greatly reduces pressure drop across the valve. This lower pressure drop promotes faster filling rates and greater efficiency resulting in more profitable operations.

Features


- Double back check provides added system protection.
- Upper filler valve assembly can be easily replaced without evacuating the container.
- Both checks are spring actuated for quick, precise closure when flow into the valve stops or reverses.
- 6587EC swing-away check promotes up to 65% faster filling rates for more profitable operations. Faster filling rates add longer pump life by reducing chances of cavitation.
- Specify RegO® Filler Valves on all your original tank purchases to insure quality and dependable performance.

Materials


Upper Body.....	Brass
Lower Body (7579S and 6587EC).....	Brass
Lower Body (3197C).....	Plated Steel
Springs	Stainless Steel
Washer and Seat Discs	Synthetic Rubber
Cap (6587EC and 3197C).....	Brass
Cap (7579S).....	Plastic



7579S



6587EC



3197C

Ordering Information

Part Number	A. ACME Hose Connection	B. Tank Connection M. NPT	C. Wrench Hex Flats	D. Effective Length (Approx.)	Propane Liquid Capacity at Various Differential Pressures (GPM)				
					5 PSIG	10 PSIG	25 PSIG	50 PSIG	75 PSIG
7579S	1 1/4"	1 1/2"	2"	2 1/16"	44	62	98	139	170
6587EC*	2 1/4"	2"	2 1/8"	4 3/8"	92	130	206	291	356
3197C	3 1/4"	3"	4"	6 1/2"	148	210	332	470	575

* Swing-away lower back check valve design for higher filling rates.
NOTE: Multiply flow rate by .94 to determine liquid butane capacity.

Single Check Filler Valves for Storage Tanks with Supplementary Back Check Valves 3174C, 3194C and 6584C

Application

Designed for use with RegO® Back Check Valves to provide fast filling of bulk storage tanks. Also may be used as a spare or replacement part.

These single check filler valves must never be installed directly into container couplings. They must be used with the appropriate back check valve to comply with NFPA Pamphlet #58.

Features

- Specifically for use with RegO® Back Check Valves.
- 6584C stem assembly reduces turbulence during filling and promotes higher filling rates.
- Specify RegO® Filler Valves on all your original tank purchases to insure quality and dependable performance.

Materials

Upper Body.....	Brass
Lower Body	Brass
Springs	Stainless Steel
Washer and Seat Discs	Synthetic Rubber
Cap (3194C, 6584C)	Brass
Cap (3174C).....	Plastic



3174C



3194C, 6584C

Ordering Information

Part Number	ACME Hose Connection	Outlet Connection M. NPT	Wrench Hex Flats	Propane Liquid Capacity at Various Differential Pressures (GPM)				For Use With Back Check Valve:
				5 PSIG	10 PSIG	25 PSIG	50 PSIG	
3174C	1 1/4"	1 1/4"	1 1/4"	23	33	52	74	3176
6584C*	2 1/4"	2"	2 3/8"	156	220	348	492	A3186
3194C	3 1/4"	3"	3 1/2"	147	208	329	465	A3196

* Stem Assembly designed for higher filling rates.

NOTE: Multiply flow rate by .94 to determine liquid butane capacity.

Vapor Equalizing Valves

General Information

RegO® Vapor Equalizing Valves consist of an upper back check valve and lower excess flow valve. In the closed position, the attachment of a vapor hose coupling with its projecting nozzle, opens the back check valve to permit flow in either direction. The lower excess flow valve is designed to close automatically when flow out of the container being filled exceeds the rated capacity. The valve closes automatically when the coupling is removed. Like the double-check filler valves, the vapor equalizing valves utilize a two-piece body construction. The lower excess flow valve will permit some leakage when the upper back check valve is removed for emergency repairs or replacement.

RegO® Vapor Equalizing Valves are designed for use in both ASME and DOT containers.



Seal cap made of tough, resilient molded plastic. Protects threads and internal working parts. Caps are designed to contain normal tank pressures, and must be kept on valves at all times.

Long-wearing gasket permits hand-tight connection of cap and hose coupling.

Seat disc of special synthetic composition is extra thick for longer life.

Valve guide is precision machined to assure positive seal.

Spare Gasket Ordering Information

ACME	Part Number
1 1/4"	A2797-20R
1 3/4"	A2697-20R

Double Check Vapor Equalizing Valves for ASME and DOT Containers 7573 Series and 3183AC

Application

Designed to facilitate loading operations by providing equalization of pressures in the supply and storage containers. The supplementary excess flow valve closes when the flow from the container being filled exceeds a predetermined rate.


The 7573 Series is designed for use in bulk delivery systems and motor fuel containers. The 3183AC is designed for use in delivery trucks and other large containers.

Features

- Double check provides added system protection.
- Upper back check valve can be easily replaced without evacuating the container
- Specify RegO® Vapor Equalizing Valves on all your original tank purchases to insure quality and dependable performance.

Ordering Information

Part Number		A.	B.	C.	D.	Approx. Closing Flow at 100 PSIG Inlet Pressure (SCFH/Propane)
Basic	W/ Chain & Cap	ACME Hose Connection	Tank Connection M. NPT	Wrench Hex Flats	Effective Length (Approx.)	
7573D	7573DC	1 1/4"	3/4"	1 1/4"	2 1/16"	4,100
-	3183AC	1 3/4"	1 1/4"	2"	3 1/16"	10,000



7573 Series

Materials

Body	Brass
Spring	Stainless Steel
Upper Check Seat Disc	Synthetic Rubber
Seals	Synthetic Rubber
Cap	Plastic

Single Check Vapor Equalizing Valves for ASME and DOT Containers with Supplementary Excess Flow Valves

Application

Designed for use with RegO® Excess Flow Valves to facilitate loading operations by providing equalization of pressures in the supply and storage containers. Also may be used as a spare or replacement part. These vapor equalizing valves must never be installed directly into container couplings. They must be used with the appropriate excess flow valve to comply with NFPA Pamphlet #58.

Features


- Specifically for use with RegO® Excess Flow Valves.
- Specify RegO® Vapor Equalizing Valves on all your original tank purchases to insure quality and dependable performance.

Materials

Body	Brass
Spring	Stainless Steel
Seat Disc	Synthetic Rubber
Seal	Synthetic Rubber
Cap	Plastic



3170



Ordering Information

Part Number		A.	B.	C.	D.	Approximate Closing Flow at 100 PSIG Inlet Pressure (SCFH/Propane Vapor)	For Use With Excess Flow Valve:
Basic	With Cap & Chain	Inlet Connection	Outlet Connection	Wrench Hex Flats	Effective Length (Approx.)		
3170	-	1 1/4"	3/4"	1 1/4"	1 1/16"	7,600	3272E
-	3180C	1 3/4"	1 1/4"	1 1/4"	1 11/16"	10,000	3282A

New 3" Soft Seat Back Check Valve A3198S

Application

Designed to provide protection in a container opening when desired flow is always into the container. May be used on in-line applications where flow must be limited to one direction. Note: The 3" M-NPT connections must be used for in-line service, the 2" outlet connection is for a standpipe when installed inside of a container.



Features


- Large flow area designed to keep the pressure drop low.
- Heavy-duty construction for long service life.
- Synthetic rubber seat disc for a positive seal.

Materials

Body	Cadmium Plated Steel
Disc.....	Cadmium Plated Steel
Stem.....	Stainless Steel
Spring	Stainless Steel
Seat Disc	Synthetic Rubber



A3198S



Ordering Information

Part Number	Inlet Connection	Outlet Connection	Wrench Hex Flats	Effective Length (Approx.)	Propane Liquid Capacity at Various Differential Pressures (GPM)		
					5 PSIG	10 PSIG	25 PSIG
A3198S	3" Male & 2" Female	3" Male & 2" Female	3½"	3 ⅞"	210	290	400

Back Pressure Check Valves

General Information

RegO® Back Pressure Check Valves are designed to allow flow in one direction only. The check, normally held in the closed position by a spring, precludes the possibility of flow out of the container. When flow starts into the container, the pressure overcomes the force of the spring to open the check. When the flow stops or reverses, the check closes.

Metal-to-metal seats will allow slight leakage after closure. These valves will restrict the escape of container contents in the event of accidental breakage of the piping or fittings.

Back Pressure Valves for Container or Line Applications 3146 Series, 3176 Series, A3186, A3187S, A3196, and A3276BC

Application

Designed to provide protection of a container opening when desired flow is always into the vessel. May be used in line applications where flow must be limited to one direction.


When used with the appropriate single check filler valve, the combination forms a double check filler valve suitable for use in filling of bulk storage tanks.

Features


- Generous flow channels for low pressure drop.
- Heavy-duty construction for long service life.
- Soft seat valves have synthetic rubber seat disc for positive seals.

Materials

Body (3146, 3146S, 3176)	Brass
Body (all others)	Cadmium Plated Steel
Disc (3146, 3146S, 3176)	Brass
Disc (all others)	Cadmium Plated Steel
Stem (3146, 3146S, 3176)	Brass
Stem (A3146, A3196, A3276BC)	Stainless Steel
Stem (A3176, A3186)	Cadmium Plated Steel
Spring	Stainless Steel
Seat Disc (3146S, A3276BC)	Synthetic Rubber



3146 Series, 3176 Series, A3186, A3196



A3276BC

Ordering Information

Part Number		A Inlet Connection F. NPT	B Outlet Connection M. NPT	C Wrench Hex Flats	D Effective Length (approx.)	Propane Liquid Capacity at various differential pressures (GPM)			
Brass	Steel					5 PSIG	10 PSIG	25 PSIG	50 PSIG
3146	A3146	3/4"	3/4"	1 3/8"	1 15/16"	11	16	25	36
3146S*									
3176	A3176	1 1/4"	1 1/4"	2"	1 3/8"	28	40	63	89
	A3276BC*				2 1/2"				
	A3186	2"	2"	2 7/8"	2 7/16"	124	175	276	391
	A3187S*	2" M & 1 1/4" F	2" M & 1 1/4" F	2 3/8"	4 3/8"	60	110	225	350
	A3196	3"	3"	4"	3 15/16"	297	420	664	939

*Soft seat version.

NOTE: Multiply flow rate by .94 to determine liquid butane capacity and by .90 to determine liquid anhydrous ammonia capacity.

Swing-Away Back Pressure Check Valves for Container or Line Applications 6586D and A6586D

Application

Designed to provide protection of a container opening when desired flow is always into the vessel. May also be used in the line applications where flow must be limited to one direction.

When used with the appropriate single check filler valve, the combination forms a double check filler valve suitable for use in filling of bulk storage tanks.

The swing-away check offers more efficient flow rates than conventional designs. It swivels open vertically to reduce pressure drop across the valve and improves flow rates.


Features

- Swing-away check design offers faster flow rates.
- Heavy-duty construction for long service life.



Materials

Body (6586D)	Brass
Body (A6586D)	Steel
Disc (6586D)	Brass
Disc (A6586D)	Stainless Steel
Stem Assembly	Stainless Steel
Spring	Stainless Steel
Screw	Stainless Steel



6586D

Ordering Information

Part Number		A. Inlet Connection F. NPT	B. Outlet Connection M. NPT	C. Wrench Hex Flats	D. Effective Length (Approx.)	Propane Liquid Capacity at Various Differential Pressures (GPM)			
Brass	Steel					5 PSIG	10 PSIG	25 PSIG	50 PSIG
6586D	A6586D	2"	2"	2 1/8"	2 7/16"	190	270	420	600

NOTE: Multiply flow rate by .94 to determine liquid butane capacity.

Back Pressure Check Valves for Flanged Installation A3400L4 and A3400L6

Application

Designed to provide high flow capacity and allow more efficient tank filling than conventional designs. The unobstructed throat area reduces flow turbulence through the valve, thereby reducing pressure drop. Large flow channels and spacious side ports assure ample capacity for the most demanding high capacity filling operations.

The valve is designed for installation in internally threaded flanges in container bottoms.

Features

- Speeds up filling operations in bulk tanks.
- All steel and stainless steel construction assures long service life.


Materials

Body	Cadmium Plated Steel
Stem	Stainless Steel
Spring	Stainless Steel
Disc	Cadmium Plated Steel
Guide	Stainless Steel
Roll Pin	Stainless Steel

Ordering Information

Part Number	A. Flange Connection M. NPT	B. Wrench Hex Flats	C. Overall Length	D. Threaded End To Port	Propane Liquid Capacity at Various Differential Pressures (GPM)			
					5 PSIG	10 PSIG	25 PSIG	50 PSIG
A3400L4	2"	Slotted	5 1/4"	1 5/16"	223	316	500	707
A3400L6	3"		5 5/8"	1 1/16"	424	600	949	1342


NOTE: For installation in flange tank connections with internal threads, see the "Flanged Installation in Container" section under "Excess Flow Valves." Multiply flow rate by .94 to determine liquid butane capacity and by .90 for liquid anhydrous ammonia capacity.



A3400L6



Typical high capacity filling installation for large storage containers



Warning Notice

The following warning information, Part Number 903-500, is included with each shipment of Excess Flow, Check, Filler and Vapor Equalizing Valves to the first purchaser of the product from the factory.

This information is intended to be forwarded throughout the product distribution chain. Additional copies are available from REGO® and Authorized Product Distributors.

These adhesive warning labels are intended for application as close as possible to the Chek-Lok® once the Chek-Lok® is installed.

The basic information contained on the label is intended for the benefit of the user of the Chek-Lok® and is not intended to be an "all-inclusive" product warning.

This label is printed on a heavy duty material with pressure sensitive adhesive backing. The ultra-violet ink stands up well when exposed to the environment.

Part Number	Description
7572-400	Adhesive Warning Label

DANGER

LP-GAS IS EXTREMELY FLAMMABLE AND EXPLOSIVE

AVOID SERIOUS INJURY AND PROPERTY DAMAGE. IF YOU SEE, SMELL OR HEAR ESCAPING GAS... EVACUATE AREA IMMEDIATELY! CALL YOUR LOCAL FIRE DEPARTMENT! DO NOT ATTEMPT TO REPAIR. DO NOT STORE IN BUILDING OR ENCLOSED AREA. DO NOT USE ON HOT AIR BALLOONS OR AIRCRAFT.

Make sure you are thoroughly trained before you attempt any valve installation, maintenance or repair. Improper conditions or procedures can cause accidents resulting in property damage and personal injury.

Become thoroughly familiar with NPGA Safety Pamphlet 306 "LP-Gas Regulator and Valve Inspections & Maintenance" and ECII "Safety Warnings "LP-Gas Cylinder Valves", "LP-Gas Excess Flow Valves", and "LP-Gas Filler and Hose End Filling Valves" found in the cylinder valve, excess flow valve, and filler valve sections of the L-500 & L-102 Catalogs. Follow their recommendations.

Know and understand NFPA Pamphlet 58 "Liquefied Petroleum Gas Code", which is the law in many states. This publication is available from NFPA, Batterymarch Park, Quincy, MA 02269. Following its requirements is essential in the safe use of LP-Gas. Section 4.4 states: persons who transfer liquid LP-Gas, who are employed to transport LP-Gas, or whose primary duties fall within the scope of this code shall be trained in proper handling procedures. Refresher training shall be provided at least every three years and shall be documented.

Make sure this valve is the proper one for this installation. Avoid misusing LP-Gas equipment.

Apply thread joint compound compatible with LP-Gas on valve external threads only. Make sure compound never comes into contact with other parts of the valve.

Install valves by applying force to wrenching flats only.

Tighten pipe threads approximately 1 to 1½ turns beyond the hand-tight insertion point using a wrench which avoids damage to other valve parts.

Check for damage and proper operation after valve installation. Check that the valve is clean and free of foreign material.

Check container-valve connection with a non-corrosive leak detection solution before filling with LP-Gas.

Purge container before filling with LP-Gas (refer to the ECII "LP-Gas Serviceman's Manual for recommended procedure).

Test excess flow check valve for proper operation before placing into service. See NPGA Bulletin 113 for recommended procedure.

Check outlet connection make-up for leaks with a non-corrosive leak detection solution when placing into service.

RegO Products Filler Valves: To prevent damage to the internal checks when it is necessary to utilize an unloading adapter, use ONLY RegO Products 3119A, 3120 and 3121 Unloading Adapters with RegO Products Filler Valves. Carefully follow the instructions supplied with these unloading adapters.

If container is not being placed into service at the present time, insert plug or cap onto the outlet connection.

In selecting a label for posting at the installation site, consider ECII "part number 901-400 or 903-400 along with your own, NPGAs and others.

Remember to instruct the owner/user/customer in safety matters concerning LP-Gas and this equipment. See ECII "Safety Warnings "LP-Gas Cylinder Valves", "LP-Gas Excess Flow Valves", and "LP-Gas Filler and Hose End Filling Valves" found in the cylinder valve, excess flow valve, and filler valve sections of the L-500 & L-102 Catalogs.

Engineered Controls International, Inc., ECII "requests that this information be forwarded to your customers. Additional copies are available from ECII " and your authorized ECII " Product Distributor.

WARNING

LP-GAS IS EXTREMELY FLAMMABLE AND EXPLOSIVE

AVOID SERIOUS INJURY AND PROPERTY DAMAGE. IF YOU SEE, SMELL, OR HEAR ESCAPING GAS... EVACUATE AREA IMMEDIATELY! CALL YOUR LOCAL FIRE DEPARTMENT! DO NOT ATTEMPT TO REPAIR. DO NOT STORE IN BUILDING OR ENCLOSED AREA. DO NOT USE ON HOT AIR BALLOONS OR AIRCRAFT.

CAUTION!
Use this CHECK-LOK® connection only for liquid evacuation before moving tank in accordance with NFPA Pamphlet 58, which is the law in many states. This publication is available from NFPA, Batterymarch Park, Quincy, MA 02269. Read and follow ECII " product instruction number 7572FA-301.

DO NOT REMOVE, DEFACE OR OBLITERATE THIS LABEL.
DO NOT FILL THIS CONTAINER UNLESS THIS LABEL IS READABLE.

ADDITIONAL SAFETY INFORMATION IS AVAILABLE FROM

100 RegO Drive PO Box 247 Elon, NC 27244 USA Phone (336) 449-7707 Fax (336) 449-6594 www.regoproducts.com

Printed in U.S.A. 03-0994-1189 Part No. 7572-400

DANGER

LP-GAS IS EXTREMELY FLAMMABLE AND EXPLOSIVE

AVOID SERIOUS INJURY AND PROPERTY DAMAGE. IF YOU SEE, SMELL, OR HEAR ESCAPING GAS... EVACUATE AREA IMMEDIATELY! CALL YOUR LOCAL FIRE DEPARTMENT! DO NOT ATTEMPT TO REPAIR. DO NOT STORE IN BUILDING OR ENCLOSED AREA. DO NOT USE ON HOT AIR BALLOONS OR AIRCRAFT.

CAUTION!
Use this CHECK-LOK® connection only for liquid evacuation before moving tank in accordance with NFPA Pamphlet 58, which is the law in many states. This publication is available from NFPA, Batterymarch Park, Quincy, MA 02269. Read and follow ECII " product instruction number 7572FA-301.

DO NOT REMOVE, DEFACE OR OBLITERATE THIS LABEL.
DO NOT FILL THIS CONTAINER UNLESS THIS LABEL IS READABLE.

ADDITIONAL SAFETY INFORMATION IS AVAILABLE FROM

WARNING

LP-GAS IS EXTREMELY FLAMMABLE AND EXPLOSIVE

AVOID SERIOUS INJURY AND PROPERTY DAMAGE. IF YOU SEE, SMELL, OR HEAR ESCAPING GAS... EVACUATE AREA IMMEDIATELY! CALL YOUR LOCAL FIRE DEPARTMENT! DO NOT ATTEMPT TO REPAIR. DO NOT STORE IN BUILDING OR ENCLOSED AREA. DO NOT USE ON HOT AIR BALLOONS OR AIRCRAFT.

CAUTION!
Use this CHECK-LOK® connection only for liquid evacuation before moving tank in accordance with NFPA Pamphlet 58, which is the law in many states. This publication is available from NFPA, Batterymarch Park, Quincy, MA 02269. Read and follow ECII " product instruction number 7572FA-301.

DO NOT REMOVE, DEFACE OR OBLITERATE THIS LABEL.
DO NOT FILL THIS CONTAINER UNLESS THIS LABEL IS READABLE.

ADDITIONAL SAFETY INFORMATION IS AVAILABLE FROM

100 RegO Drive PO Box 247 Elon, NC 27244 USA Phone (336) 449-7707 Fax (336) 449-6594 www.regoproducts.com

Printed in U.S.A. 03-0994-1189 Part No. 7572-400

DANGER

LP-GAS IS EXTREMELY FLAMMABLE AND EXPLOSIVE

AVOID SERIOUS INJURY AND PROPERTY DAMAGE. IF YOU SEE, SMELL OR HEAR ESCAPING GAS... EVACUATE AREA IMMEDIATELY! CALL YOUR LOCAL FIRE DEPARTMENT! DO NOT ATTEMPT TO REPAIR. DO NOT STORE IN BUILDING OR ENCLOSED AREA. DO NOT USE ON HOT AIR BALLOONS OR AIRCRAFT.

Make sure you are thoroughly trained before you attempt any valve installation, maintenance or repair. Improper conditions or procedures can cause accidents resulting in property damage and personal injury.

Become thoroughly familiar with NPGA Safety Pamphlet 306 "LP-Gas Regulator and Valve Inspections & Maintenance" and ECII "Safety Warnings "LP-Gas Cylinder Valves", "LP-Gas Excess Flow Valves", and "LP-Gas Filler and Hose End Filling Valves" found in the cylinder valve, excess flow valve, and filler valve sections of the L-500 & L-102 Catalogs. Follow their recommendations.

Know and understand NFPA Pamphlet 58 "Liquefied Petroleum Gas Code", which is the law in many states. This publication is available from NFPA, Batterymarch Park, Quincy, MA 02269. Following its requirements is essential in the safe use of LP-Gas. Section 4.4 states: persons who transfer liquid LP-Gas, who are employed to transport LP-Gas, or whose primary duties fall within the scope of this code shall be trained in proper handling procedures. Refresher training shall be provided at least every three years and shall be documented.

Make sure this valve is the proper one for this installation. Avoid misusing LP-Gas equipment.

Apply thread joint compound compatible with LP-Gas on valve external threads only. Make sure compound never comes into contact with other parts of the valve.

Install valves by applying force to wrenching flats only.

Tighten pipe threads approximately 1 to 1½ turns beyond the hand-tight insertion point using a wrench which avoids damage to other valve parts.

Check for damage and proper operation after valve installation. Check that the valve is clean and free of foreign material.

Check container-valve connection with a non-corrosive leak detection solution before filling with LP-Gas.

Purge container before filling with LP-Gas (refer to the ECII "LP-Gas Serviceman's Manual for recommended procedure).

Test excess flow check valve for proper operation before placing into service. See NPGA Bulletin 113 for recommended procedure.

Check outlet connection make-up for leaks with a non-corrosive leak detection solution when placing into service.

RegO Products Filler Valves: To prevent damage to the internal checks when it is necessary to utilize an unloading adapter, use ONLY RegO Products 3119A, 3120 and 3121 Unloading Adapters with RegO Products Filler Valves. Carefully follow the instructions supplied with these unloading adapters.

If container is not being placed into service at the present time, insert plug or cap onto the outlet connection.

In selecting a label for posting at the installation site, consider ECII "part number 901-400 or 903-400 along with your own, NPGAs and others.

Remember to instruct the owner/user/customer in safety matters concerning LP-Gas and this equipment. See ECII "Safety Warnings "LP-Gas Cylinder Valves", "LP-Gas Excess Flow Valves", and "LP-Gas Filler and Hose End Filling Valves" found in the cylinder valve, excess flow valve, and filler valve sections of the L-500 & L-102 Catalogs.

Engineered Controls International, Inc., ECII "requests that this information be forwarded to your customers. Additional copies are available from ECII " and your authorized ECII " Product Distributor.

WARNING

LP-GAS IS EXTREMELY FLAMMABLE AND EXPLOSIVE

AVOID SERIOUS INJURY AND PROPERTY DAMAGE. IF YOU SEE, SMELL, OR HEAR ESCAPING GAS... EVACUATE AREA IMMEDIATELY! CALL YOUR LOCAL FIRE DEPARTMENT! DO NOT ATTEMPT TO REPAIR. DO NOT STORE IN BUILDING OR ENCLOSED AREA. DO NOT USE ON HOT AIR BALLOONS OR AIRCRAFT.

CAUTION!
Use this CHECK-LOK® connection only for liquid evacuation before moving tank in accordance with NFPA Pamphlet 58, which is the law in many states. This publication is available from NFPA, Batterymarch Park, Quincy, MA 02269. Read and follow ECII " product instruction number 7572FA-301.

DO NOT REMOVE, DEFACE OR OBLITERATE THIS LABEL.
DO NOT FILL THIS CONTAINER UNLESS THIS LABEL IS READABLE.

ADDITIONAL SAFETY INFORMATION IS AVAILABLE FROM

100 RegO Drive PO Box 247 Elon, NC 27244 USA Phone (336) 449-7707 Fax (336) 449-6594 www.regoproducts.com

Printed in U.S.A. 08-0809-0686 Part number 903-500

Cross Reference by Part Number

1519A2.....	F10	A3292C.....	F11
1519C2.....	F9	A3400L4.....	F27
A1519A2.....	F10	A3400L6.....	F27
1519A3.....	F10	A3500L4.....	F14
1519A4.....	F10	A3500N4.....	F14
1519B4.....	F10	A3500P4.....	F14
1519C4.....	F9	A3500R6.....	F14
A1519A4.....	F10	A3500T6.....	F14
A1519B4.....	F10	A3500V6.....	F14
A1519A6.....	F10	A4500Y8.....	F14
A2137.....	F13	6579.....	F20
A2137A.....	F13	6584C.....	F23
2139.....	F13	6586D.....	F27
2139A.....	F13	A6586D.....	F27
A2697-20R.....	F20	6587EC.....	F22
A2697-20R.....	F23	A7537L4.....	F12
2723C.....	F15	A7537L4F.....	F12
A2797-20R.....	F20	A7537N4.....	F12
A2797-20R.....	F23	A7537N4F.....	F12
2884D.....	F16	A7537P4.....	F12
3146.....	F26	A7537P4F.....	F12
3146S.....	F26	A7539R6.....	F12
A3146.....	F26	A7539R6F.....	F12
3170.....	F24	A7539T6.....	F12
3174C.....	F23	A7539T6F.....	F12
3176.....	F26	A7539V6.....	F12
A3176.....	F26	A7539V6F.....	F12
3180C.....	F24	7572C-14A.....	F19
3183AC.....	F24	7572C-15A.....	F19
A3184-8R.....	F20	7572-400.....	F28
A3186.....	F26	7573D.....	F24
3194C.....	F23	7573DC.....	F24
A3194-8R.....	F20	7574.....	F11
A3196.....	F26	7574L.....	F11
3197C.....	F22	7579.....	F20
A3198S.....	F25	7579P.....	F20
3199W.....	F16	7579S.....	F22
3272E.....	F11	7580F-20.....	F19
3272F.....	F11	7590U.....	F18
3272G.....	F11	7590U-10.....	F19
A3272G.....	F11	7590U-20.....	F18
A3276BC*.....	F26	7591U.....	F18
3282A.....	F11	7647DC.....	F21
3282B.....	F11	7647H.....	F21
3282C.....	F11	7647HF.....	F21
A3282C.....	F11	7647SA.....	F21
3292A.....	F11	7647SC.....	F21
3292B.....	F11	A8013D.....	F15
A3292A.....	F11	A8013DA.....	F15
A3292B.....	F11	A8013DB.....	F15
		12472.....	F11

F



LP-Gas & Anhydrous Ammonia Equipment

Section G

Internal Valves and Accessories

G

Limited Warranty and Limitation of Liability

LIMITED 10 YEAR WARRANTY AND LIMITATION OF LIABILITY

LIMITED 10 YEAR WARRANTY

REGO® warrants to the original purchasers the products and repair kits manufactured by it to be free from defects in materials and workmanship under normal use and service for a period of 10 years from the date of manufacture. If within thirty days after buyer's discovery of what buyer believes is a defect, buyer notifies in writing and ships the product to REGO® at 100 Rego Drive, Elon, NC 27244, REGO®, at its option, and within forty-five days of receipt, will repair, replace F.O.B. point of manufacture, or refund the purchase price of that part or product found by REGO® to be defective. Failure of buyer to give such written notice and ship the product within thirty days shall be deemed an absolute and unconditional waiver of any and all claims of buyer arising out of such defect.

This warranty does not extend to any product or part that is not installed and used continuously after installation in accordance with REGO®'s printed instructions, all applicable state and local regulations, and all applicable national standards, such as those promulgated by NFPA, DOT and ANSI. This warranty does not extend to any product or part that has been damaged by accident, misuse, abuse, failure to maintain, or neglect, nor does it extend to any product or part which has been modified, altered, disassembled, or repaired in the field. This warranty does not cover any cosmetic issues, such as scratches, dents, marring, fading of colors or discoloration.

Except as expressly set forth above, and subject to the limitation of liability below, REGO® MAKES NO OTHER WARRANTY, EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, with respect to its products and parts, whether used alone or in combination with others. REGO® disclaims all warranties not stated herein.

LIMITATION OF LIABILITY

REGO®'s total liability for any and all losses and damages arising out of any cause whatsoever shall in no event exceed the purchase price of the products or parts in respect of which such cause arises, whether such cause be based on theories of contract, negligence, strict liability, tort or otherwise.

REGO® shall not be liable for incidental, consequential or punitive damages or other losses. REGO® shall not be liable for, and buyer assumes any liability for, all personal injury and property damage connected with the handling, transportation, possession, further manufacture, other use or resale of products, whether used alone or in combination with any other products or materials.

From time to time buyers might call to ask REGO® for technical advice based upon limited facts disclosed to REGO®. If REGO® furnishes technical advice to buyer, whether or not at buyer's request, with respect to application, further manufacture or other use of the products and parts, REGO® shall not be liable for such technical advice or any such advice provided to buyer by any third party and buyer assumes all risks of such advice and the results thereof.

NOTE: Some states do not allow the exclusion or limitation of incidental, consequential or punitive damages, so the above limitation or exclusion may not apply to you. The warranty gives you specific legal rights, and you may have other rights that vary from State to State. The portions of this limited warranty and limitation of liability shall be considered severable and all portions which are not disallowed by applicable law shall remain in full force and effect.

NOTICE TO USERS OF PRODUCTS

The Limited Warranty stated above is a factory warranty to the first purchasers of REGO® products. Since most users have purchased these products from REGO® distributors, the user must within thirty (30) days after the user's discovery of what user believes is a defect, notify in writing and return the product to the distributor from whom he purchased the product/part. The distributor may or may not at the distributor's option choose to submit the product/parts to REGO®, pursuant to this Limited Warranty. Failure by buyer to give such written notice within thirty (30) days shall be deemed an absolute and unconditional waiver of buyer's claim for such defects. Acceptance of any alleged defective product/parts by REGO®'s distributor for replacement or repairs under the terms of REGO®'s Limited Warranty in no way determines REGO®'s obligations under this Limited Warranty.

Because of a policy of continuous product improvement, REGO® reserves the right to change designs, materials or specifications without notice.

Foreword

This catalog describes a complete line of equipment available from REGO® for use with LP-Gas and anhydrous ammonia (NH₃). The following points are important to know for proper use of the catalog:

1. Illustrations and drawings of individual products are representative of “product groups” and all products within a product group are similar in construction.
2. Materials used for construction of products in this catalog are suitable for rated service pressure at temperatures of -40° F. to +165° F., unless otherwise specified.
3. Products in this catalog are only intended for use in LP-Gas and/or anhydrous ammonia service as follows.
 - a. “A” or “AA” prefix — Products with this prefix are suitable for NH₃ service (i.e., contain no brass parts).
 - b. “AA” prefix on relief valves — These valves are NOT suitable for use with LP-Gas service. These are of partial aluminum materials and are listed by Underwriters Laboratories (UL) for NH₃ service only.
 - c. All other products are suitable for use with LP-Gas service.
 - d. “SS” prefix—Hydrostatic relief valve with this prefix are suitable for NH₃ service (i.e., they have stainless steel materials).

Caution

Do not use any product contained in this catalog with any service commodity other than LP-Gas or NH₃. If you have a need for use of another application, contact REGO®, 100 RegO Drive, Elon, NC 27244, (336) 449-7707 before proceeding.

Proper application, installation and maintenance of products in this catalog are essential. Users of these products should obtain further information if there are any doubts or questions.

Warning

All REGO® products are mechanical devices that will eventually become inoperative due to wear, corrosion and aging of components made of materials such as rubber. The environment and conditions of use will determine the safe service life of these products. Periodic inspection and maintenance are essential to avoid serious injury and property damage.

Many REGO® products are manufactured for storage, transport, transfer and use of toxic flammable and dangerous liquids and gases. Such substances should be handled by experienced and trained personnel only, using accepted governmental and industrial safety procedures. Never vent LP-Gas near any possible source of ignition.

Notice

Installation, usage, and maintenance of all REGO® products must be in compliance with all REGO® instructions as well as requirements and provisions of NFPA #54, NFPA#58, DOT, ANSI, and all applicable federal, state, provincial and local standards, codes, regulations, and laws.

Inspection and maintenance on a periodic basis is essential. Installation and maintenance should be performed only by qualified personnel.

Be sure all instructions are read and understood before installation, operation and service.

Filters

REGO® LP-Gas equipment is designed to operate in a system free from contamination. A variety of in-line filters are commercially available to the LP-Gas industry for installation in domestic systems.

The use of an in-line filter should be considered when other system components may be unclean and the system contaminated by rust, scale, dirt, debris or other foreign material.

Contents

Page

Cross Reference by Part Number	G23
Flomatic® Service Guide.....	G19
Flomatic® Valves.....	G17
General Information-Flomatic®	G16
General Information-Manual Valves	G6
Manual Valves—1¼" Threaded	G8
Manual Valves—3" Threaded	G14
Manual Valves—2" Threaded	G15
Manual Valves—3" Flanged	G10
Manual Valves—4" Flanged	G11
Pump System Troubleshooting.....	G23
Remote Cable Controls	G13
Remote Thermal Release.....	G13
Safety Warning	G4

Warnings



Purpose

In its continuing quest for safety, REGO® publishes a series of bulletins explaining the hazards associated with the use, misuse, and aging of LP-Gas valves and regulators. It is hoped that these factual bulletins will make clear to LP-Gas dealer managers and service personnel, that the utmost care and attention must be used in the installation, inspection, and maintenance of these products, or problems could occur which would result in injuries and property damage.

The National Fire Protection Association Pamphlet #58, "Storage and Handling of Liquefied Petroleum Gases" states in section 1-6 that "In the interest of safety, all persons employed in handling LP-Gases shall be trained in proper handling and operating procedures". These "REGO® Safety Warnings" may be useful in training new employees and reminding older employees of hazards that can occur.

It is recommended that all employees be furnished with a copy of NPGA Safety Pamphlet 306-88 "LP-Gas Regulator and Valve Inspection and Maintenance, 111-81 Limitations of Excess Flow Check Valves for LP-Gas, and 113-78 Safety Considerations in Bobtail Deliveries."

Nature of Warnings

It is recognized that warnings should be as brief as possible, but the factors involved in internal valve and excess flow valve failures to perform are not simple. They need to be fully understood. If there is a simple

Make sure that the internal valve's excess flow feature really closes when the flow exceeds rated closing flow, and that the valve will shut-off.

This bulletin is not intended to be an exhaustive treatment of internal valves, and certainly does not cover all safety practices that should be followed in installation, operation and maintenance of LP-Gas systems, which include internal valves.

Internal valves must be closed on Cargo Vehicles when traveling on public roads and highways. The valve should only be open when pumping. Per MC 330 or 331, internal valves must also be equipped with remote closure system, when used on transports or bobtails.

There are two types of internal valves being used on storage tanks, transports and bobtails — spring loaded internal valves and differential pressure internal valves. They both provide positive shut-off when product is not being withdrawn and may include excess flow protection for the system during transfer operations.

Spring Loaded Internal Valves

Spring loaded internal valves are manually opened by levers, by means of fuse linked cable mechanisms or pneumatic or hydraulic actuators. They incorporate an excess flow feature that will close the valve when the flow through the valve exceeds its rate of flow. These valves should never be locked open by means of wires, chains, pegs or other devices.

Testing

Testing should be completed on a periodic basis.

1. To check operation of a spring loaded valve, activate the remote control to close the valve while unit is pumping. If the meter indicator flow continues, the valve should be repaired immediately.

2. Testing excess flow feature.

The National Propane Gas Association Safety Bulletin #113-78 states: "In order to test an excess flow valve in a piping system, the flow through the valve must be made to exceed the valve's closing rating."

This testing should only be attempted by trained personnel familiar with the process. If no one at the facility has experience in proper testing, outside expert help should be obtained.



The exact procedure used may vary with the installation, advisability of gas discharge and availability of equipment.

In general, most testing makes use of the fact that the excess flow valves are "surge sensitive" and will close quicker under a sudden flow surge than under steady flow. A sufficient surge can often be created by using a quick open/close valve to control sudden, momentary flow into a tank or piping section containing very low pressure. An audible click from the excess flow valve (and corresponding stoppage of flow) indicates its closure.

A test involving venting gas to the atmosphere is hazardous and may be impractical, or illegal.

Any test of any excess flow valve will not prove that the valve will close in an emergency situation, due to reasons cited before. This test will only check the valves condition, and the flow rate sizing for those test conditions.

3. Tight Shut-Off — A test should be made to insure the internal valve will give a gas tight seal when the valve is in the closed position. This will require removal of all product downstream from the internal valve, to insure the valve will give 100% seal when in the closed position. If the internal valve does not give 100% seal the valve should be repaired immediately.

Pressure Differential Internal Valves (Flomatics)

Pressure differential valves (Flomatics) open by pump pressure and close when the pump stops.

These valves must never be locked open by means of wires, chains, pegs or other devices.

Testing

Testing should be completed on a periodic basis.

1. To check operation of a differential pressure internal valve activate the remote control shut-off valve while the unit is pumping. If the meter indicates that flow continues the valve should be repaired immediately.

2. Since the differential pressure internal valve requires at least 18 psi to open and 8 psi over container pressure to keep open, a test may be performed to check for closure. With the PTO disengaged, connect delivery hose to a container with very low pressure. Then with hose end valve open, engage PTO. The internal valve should remain closed, no flow should be detected through the meter. If flow continues through the meter the valve should be repaired immediately.

3. Tight Shut-Off — A test should be made to insure the internal valve will give a gas tight seal when the valve is in the closed position. First insure the pump prime valve is closed by turning clockwise until it seats. Then with the valve closed (PTO disengaged) the product downstream from the internal valve will have to be safely removed. If the internal valve does not give 100% seal, the valve should be repaired immediately.

General Warning

All REGO® Products are mechanical devices that will eventually become inoperative due to wear, contaminants, corrosion and aging of components made of materials such as metal and rubber.

The environment and conditions of use will determine the safe service life of these products. Periodic testing at least once a year when tank pressures are low and maintenance, as required, are essential.

Because REGO® products have a long and proven record of quality and service, LP-Gas dealers may forget the hazards that can occur because an excess flow valve is used beyond its safe service life. Life of an excess flow valve is determined by the environment in which it "lives". The LP-Gas dealer knows better than anyone what this environment is.

NOTE: There is a developing trend in state legislation and in proposed national legislation to make the owners of products responsible for replacing products before they reach the end of their safe useful life. LP-Gas dealers should be aware of legislation which could effect them.



G

Manual Internal Valves

A3200 Series

General Information

Manual Internal Valves are designed for a variety of uses in LP-Gas and anhydrous ammonia service. In addition, accessories allow most of them to be actuated manually, by cable or with air.

Installation, usage and maintenance of this product must be in compliance with all REGO® instructions, as well as requirements and provisions of NFPA # 58, DOT, ANSI, and all applicable federal, state, provincial, and local standards, codes, regulations and laws.

How The Valves Work

Refer to the drawings. View "A" shows the valve held closed without leakage by tank pressure and the valve's closing spring. Actuation of the operating handle alone does not open the valve, it only allows pressure to equalize between the inlet and outlet of the valve by rapid bleeding of the product downstream. This equalized pressure then allows the valve to open via the internal spring.

The valve opens by moving the handle to mid-point, see view "B". This position allows the actuator to put the equalizing portion of the valve stem in the pilot opening, allowing more product to bleed downstream than if the handle was fully open.

In a few seconds, the tank and downstream pressure will be nearly equal. The excess flow spring will push the main poppet to the open position, see view "C", the handle should then be moved to the fully open position.

If at first, the handle is quickly moved to the fully opened position, the pilot valve allows a small amount of bleed downstream, but much less than during rapid bleed (view "B"). This results in a longer pressure equalizing time before the main valve can open.

NOTE: The main poppet will not open until outlet pressure approximates tank pressure!

Once the main poppet is open, flow greater than the excess flow rating, or a sufficient surge in flow, forces the main poppet closed against the excess flow spring, as seen in view "D". The pilot valve in this position is open and allows a small amount of bleed downstream, but much less than during rapid bleed (view "B").

When the operating handle is moved to the closed position, the valve closes and a leak-tight seal is re-established as seen in view "A".

NOTE: To provide excess flow protection, the flow rating of the pump, piping, valves, fittings, and hose on the inlet and outlet sides of the valve must be greater than the flow rating of the valve. Any restrictions that reduce the flow to less than the excess flow valve rating will result in the excess flow valve not operating when required.

Valve Operation and Precautions

1. Valve must be opened before starting pump, and before opening valve on pump outlet.
2. Leave pumping system "wet" to avoid drying of seals and to reduce time involved in opening valve. Drain piping only when required by codes or safe operating practices.
3. When piping is dry or at lower pressure than the tank, open valve half-way for a few seconds to allow line pressure to equalize before fully opening the valve handle. The main poppet may not open immediately if the handle is placed in the open position too quickly.
4. Flow surges may close the built-in excess flow valve and should be avoided. If the valve slams shut, immediately stop the pump, close the nearest downstream valve, and move handle to midpoint position to equalize pressure until valve reopens with a click, then restart pump and open downstream valve slowly.

These valves must remain in the closed position except during product transfer. A line break downstream of the pump may fail to actuate the excess flow valve as the pump may limit flow. If break occurs in the system, or the excess flow closes, immediately shut down the system.

Inspection and maintenance on a periodic basis is essential. Installation and maintenance must be performed only by qualified personnel.

Be sure all instructions are read and understood before installation and operation of these valves.

5. Always keep valve closed except during product transfer.

6. Completely open all valves during pumping. Partially closed or throttle type valves may prevent excess flow valve from closing when required, even in a properly designed piping system.

7. All personnel must be aware of remote closure locations and their operation in case of emergency. They must also be aware of the equalizing opening through which bleeding can occur after the excess flow valve closes. If this bleed is not stopped by closing a downstream valve, a hazard may occur.

8. Never, under any circumstances, permanently wire open the operating handle of the internal valve.

Cable Control System

The cable control system employed must meet the requirements and be in accordance with the provisions of NFPA #58, DOT, ANSI, and all applicable federal, state, provincial and local codes.

Troubleshooting

- 1. Internal Valve Will Not Open.** Causes may be excess leakage downstream, pump engaged too quickly, excessive wear of valve, or ice freezing of poppet.

When there is excessive volume downstream, a greater amount of time is required to equalize tank and downstream pressure.

To determine if the pilot seat is opening, install a pressure gauge downstream of valve outlet, open any hand valves between valve and pressure gauge, and open valve. Pilot seat is not opening if pressure does not build up to tank pressure. Perform this test with pump off. A broken internal part may cause pilot seat not to open.

If operating handle rotates past the full open position, there is internal malfunctioning, and the valve must be disassembled and repaired.

- 2. Premature Valve Closure.**

First, check to see that operating lever is properly connected and fully opens valve. Premature closure may also be a result of engaging pump too quickly, sudden line surges, an underrated excess flow spring or an obstructed inlet port.

- 3. Valve Will Not Close.**

Usually a result of faulty or sticking actuator. First, check the actuator to see that it works freely by disconnecting it from valve handle and cycling it several times. Also, operate valve handle manually. If it sticks in the open position, replace the packing and bushings. This should free the operating mechanism providing the valve has no internal damage.

- 4. Low Flow Capacity**

Downstream piping may be too small and/or long, screen or strainer may be plugged, possible restriction downstream, or a bypass valve stuck in the open position are causes of low flow. Also, the bypass valve may be set too low and prematurely opening. Check for high differential pressure across the bypass valve. If bypass valve is open, the differential across the valve should not exceed 5 to 6 psig.

Maintenance

Potential problems may be eliminated with preventive internal valve maintenance. Perform the following steps once a month:

1. Check to see that the operating lever moves freely and smoothly. There should be no leakage around the lower stem or seal housing. Leakage requires replacement of the seal housing packing. A sticking lever indicates trapped foreign material or mechanism wear.


2. Check both seat discs for tight closure. Close valve and exhaust downstream pressure. Be sure piping is warmed to an ambient temperature. Close the first downstream valve and note pressure buildup between the closed valves with a pressure gauge. If leakage occurs, replace both seat discs.

3. Inspect, clean and oil all operating controls. Check controls to see that they open fully, but do not overtravel the valve operating lever. See that they work freely to close the valve. Worn parts should be replaced.


4. Remove valve if the tank is to be steam cleaned. Heat may damage the valve's seals.

5. Valve is not designed for water service. After tank is hydrostatically tested, immediately remove all water and allow tank to thoroughly dry out before installing valve.


A3209D Series, 1¼" Straight
A3209DT Series, 1¼" Straight
A3211D Series 1½" Straight
A3212R Series, 2" Straight
A3212RT Series 2" Tee Body
A3213R Series, 3" Straight
A3213T Series 3" Tee Body



A3217A Series, 3" Flanged
A3217DA Series, 3" Double Flanged



A3219FA Series, 4" Flanged



1 1/4" Threaded Internal Valve for Small Capacity Pumping Systems and Bobtail Vapor Equalization A3209D & A3209DT Series


Application

Designed primarily for use with LP-Gas and anhydrous ammonia as a main valve on small capacity pumping systems, NH3 nurse tanks and in-line installations. It may also be installed in the vapor equalizing opening on bobtail delivery trucks. Installation is quick and easy, and it fits in both full and half couplings, as well as, in-line applications. The valve may be actuated manually by hand or cable.




Features

- Valve is compact, with one piece body construction.
- Spring loaded V-packing with heavy duty wiper ring on operating shaft for dependable leak-free construction.
- Nylon bearing supported operating shaft provides smooth, easy operation.
- Simple operating lever allows for easy connection of cable controls.
- Built in excess flow valve
- Return spring forces the valve to the closed position when the lever is released.
- All critical operating components are located in the valve body and inside the container coupling for maximum protection against damage.
- Midway stem position allows for quick pressure equalization.
- Equipped with 212° F, UL listed fuse link for thermal protection.





A3209DT



A3209D

Materials

Body Ductile Iron
Operating Lever..... Cadmium Plated Carbon Steel
Stem Stainless Steel
Springs Stainless Steel
Seat Disc Resilient Synthetic Rubber
Shaft Bearing..... Nylon



NOTE: Multiply flow rate by .94 to determine liquid butane flow and by .90 to determine liquid anhydrous ammonia flow.

Ordering Information

Part Number	Inlet Connection M. NPT	Outlet Connection F. NPT	Closing Flow		LP-Gas Vapor Capacity** (SCFH/Propane)		Accessories	
			LP-Gas	NH3	25 PSIG	100 PSIG	Thermal Latch	Pneumatic Actuators
A3209D050	1 1/4"	1 1/4"	50	45	13,300	22,900	A3209TL	A3209PA A3209PAF
A3209D080	1 1/4"	1 1/4"	80	72	15,700	26,700		
A3209DT050	1 1/4"	1 1/4"	50	45	13,300	22,900		
A3209DT080	1 1/4"	1 1/4"	80	72	15,700	26,700		

Product Update New Straight Through 1½" Internal Valve A3211D Series

Application

Designed primarily for use with LP-Gas and anhydrous ammonia as a main valve on pumping systems, and in-line installations. Installation is quick and easy, and it fits in both full and half couplings, as well as, in-line applications. The valve may be opened manually by hand or pneumatic actuator.



Features


- Valve is compact, with one piece body construction.
- Spring loaded V-packing with heavy duty wiper ring on operating shaft for dependable leak-free construction.
- Nylon bearing supported operating shaft provides smooth, easy operation.
- Simple operating lever allows for easy connection of cable controls.
- Built in excess flow valve
- Return spring forces the valve to the closed position when the lever is released.
- All critical operating components are located in the valve body and inside the container coupling for maximum protection against damage.
- Midway stem position allows for quick pressure equalization.
- Equipped with 212° F, UL listed fuse link for thermal protection.



A3211D

Materials

Body Ductile Iron
Operating Lever..... Cadmium Plated Carbon Steel
Stem Stainless Steel
Springs Stainless Steel
Shaft Bearing..... Nylon
Seat Disc Synthetic Rubber



Ordering Information

Part Number	Inlet M-NPT	Outlet F-NPT	Closing Flow GPM				LP-Gas Vapor Capacity (SCFH/Propane)		Accessories	
			Half Coupling		Full Coupling		25 PSIG Inlet	100 PSIG Inlet	Thermal Latch	Pneumatic Actuator
			LP-Gas	NH ₃	LP-Gas	NH ₃				
A3211D080	1½"	1½"	80	72	63	67	15,700	26,700	A3209TL	A3209PAF
A3211D110	1½"	1½"	110	99	84	76	N/A	N/A		

3" Flanged Internal Valves for Bobtail Delivery Trucks, Transports and Large Stationary Storage Containers A3217A & A3217DA

Application

Designed primarily for LP-Gas and anhydrous ammonia filling and/or withdrawal on MC331 bobtail delivery trucks, transports and stationary storage tanks with flanged pumps or piping. Installation is quick and easy, and the valve may be operated manually by cable or pneumatically.

Lever available on right or left side to allow for installation without the use of an extra pulley.



Features

Provides More Efficient Operation


- Flow passages designed to allow substantially higher without cavitation or loss of efficiency--saving time and money.
- Simple operating lever facilitates easy adaptation of all cable controls.
- Lever available on right or left side to allow for installation without the use of an extra pulley.
- Nylon bearing supported operating shaft provides smooth, easy operation.

Less Frequent-Easier Maintenance

- Stainless steel screws resist rusting and are easily removed during valve disassembly.
- Heavy duty rod wiper helps minimize dirt and foreign material from entering operating shaft and hampering operation.

Durable Construction

- Cadmium plating helps resist corrosion during storage and use.
- All ferrous materials with a temperature range of -40° F. to +130° F. and a pressure rating of 400 psi.
- Sturdy retaining ring secures operating cam to provide for more durable, slack-free operation.
- Built-in excess flow valve.
- Specify RegO® Internal Valves on your next new tank or when your truck is rebuilt.



Ordering Information

Part Number		Operating Lever Position	Inlet Connection	Outlet Connection	Closing Flow GPM		Accessories	
					LP-Gas	NH3	Pneumatic Actuator	
							Right Operation	Left Operation
Single Flange								
A3217AR160	A3217AL160	Left or Right	3" 300# ANSI RF Modified Flange*	3" 300# ANSI RF Flange	160	145	A3217ARPA	A3217ALPA
A3217AR210	A3217AL210				210	190		
A3217AR260	A3217AL260				260	236		
A3217AR410	A3217AL410				410	372		
A3217AR510	A3217AL510				510	459		
Double Flange								
A3217DAR160	A3217DAL160	Left or Right	3" 300# ANSI RF Modified Flange*	3" 300# ANSI RF Flange	160	145	A3217ARPA	A3217ALPA
A3217DAR210	A3217DAL210				210	190		
A3217DAR260	A3217DAL260				260	236		
A3217DAR410	A3217DAL410				410	372		
A3217DAR510	A3217DAL510				510	459		

Furnished with mounting studs and nuts

**Modified bore=4 1/4" diameter with 5/8" diameter raised face.

3" Flanged Internal Valves for Bobtail Delivery Trucks, Transports, and Large Stationary Storage Tanks

A3217FPA and A3217FLPA Pneumatic Actuators

These Pneumatic Actuators are designed specifically for use with the A3217 Series 3" Internal Valves. The diaphragm design provides a convenient means of opening and closing the valve from a remote location, using either air or nitrogen.





Features




- Diaphragm type—no seals to leak.
- Easily installed on internal valve "in-line."
- Utilizes standard air brake chamber with proven performance over many years of heavy-duty truck/trailer applications.
- Compatible with existing air interlock systems.
- Operates with pressures of 50-150 psig.
- Thermal Fuse installed complies with DOT thermal protection requirements.

Materials


Body and Valve Cage	Cadmium Plated Ductile Iron
Seat	Nickel Chrome Plated Steel
Strainer	Stainless Steel
Shaft	Stainless Steel
Pilot Valve Stem	Stainless Steel
Springs	Stainless Steel
Actuator Cam	Stainless Steel
Lever	Cadmium Plated Carbon Steel
Seat Disc	Resilient Synthetic Rubber



Typical Valve Installation



NOTE: Multiply flow rate by .94 to determine liquid butane flow and by .90 to determine liquid anhydrous ammonia flow.



4" Flanged Internal Valve for Transports and Large Stationary Storage Tanks A3219 Series

Application

Designed primarily for LP-Gas and anhydrous ammonia service on MC331 transport pressure vessels and large stationary storage tanks. Installation is quick and easy, and it fits in most existing tank flanges. The valve may be actuated manually or pneumatically.

Use of the A3219RT Remote Thermal Release with this valve is suggested to provide a remote means of mechanical closure along with thermal protection, as required by DOT.



Features

Provides More Efficient Operation

- Flow passages designed to allow higher pumping rates without cavitation or loss of efficiency—saves time and money.
- One piece, stainless steel pilot valve provides more accurate alignment for dependable operation.
- Remote release lever allows cables to run directly to opposite ends of vessel without pulleys or tubing.

Protects Your Pump

- Main disc retaining screws are installed from the top down to help minimize loose screws from entering and damaging the pump.
- Back-up cotter pin is designed to minimize the chance of a loosened actuator nut and washer from entering and damaging the pump.

Less Frequent-Easier Maintenance


- Easily replaceable chrome plated seat insert eliminates need for expensive remachining of valve body when overhauled.
- Stainless steel screws resist rusting and are easily removed during valve disassembly.
- Strainer completely covers the top of the valve to help keep out sediment and foreign material.
- Strainer seats at the top flange of the valve's seat insert, making removal of the valve easier.

Durable Construction

- Cadmium plating helps resist corrosion during storage and use.
- Taper pin lock secures the operating shaft to provide for more precise, trouble-free actuation.
- Built-in excess flow valve and thermal protection.
- Specify RegO® Internal Valves on your next new tank body or rebuild.



A3219FPA



Materials

Body and Valve Cage	Cadmium Plated Ductile Iron
Handle	Cadmium Plated Ductile Iron
Seat	Nickel Chrome Plated Steel
Strainer	Stainless Steel
Stem	Stainless Steel
Pilot Valve Plug	Stainless Steel
Springs	Stainless Steel
Roller Actuator	Cadmium Plated Carbon Steel
Lever Assembly	Cadmium Plated Carbon Steel
Seat Disc	Resilient Synthetic Rubber

Ordering Information

Part Number*	Inlet Connection	Outlet Connection	Closing Flow GPM		Accessories	
			LP-Gas	NH3	Pneumatic Actuator	Remote Thermal Release
A3219FA400L	4" 300# ANSI RF Modified Flange**	4" 300# ANSI RF Flange	400	360	A3219FPA	A3219RT (2)
A3219FA600L			600	540		

* Valve supplied with 16 nuts and 8 studs for mounting.

** Modified bore = 5 7/8" diameter with 7" diameter raised face.

4" Flanged Internal Valves for Transports and Large Stationary Storage Tanks

Application


A3219FPA Pneumatic Actuator

The A3219FPA Pneumatic Actuator is designed especially for use with the A3219FA Series Flanged Internal Valves. The diaphragm type A3219FPA provides a convenient means of opening and closing the valve from a remote location, using either air or nitrogen, on LP-Gas and NH₃ transport trailers and stationary tanks.



Features

- Diaphragm type—no seals to leak.
- Easily installed on internal valve "in-line,"
- Utilizes standard brake actuator with time proven performance in heavy-duty truck/trailer applications.
- Compatible with existing air interlock systems.
- Operate with pressures of 50-150 psig.
- Thermal fuse installed in actuator complies with DOT thermal protection requirements.





Typical Valve Positioning



Typical Valve Installation



NOTE: Multiply flow rate by .94 to determine liquid butane flow and by .90 to determine liquid anhydrous ammonia flow.



Remote Thermal Release for DOT MC331 Pressure Vessel A3219RT

Application

Designed especially for use with Internal Valves installed in DOT MC331 pressure vessels. The A3219RT provides a remote means of mechanical closure along with thermal protection, as required by DOT MC331.

The A3219RT is connected by cable to the internal valve(s) on the vessel. In the event of extreme heat (over 212° F.), the fuse link will melt, causing the spring to contract and pull the cable. When properly installed the cable will trip the internal valve release lever(s) allowing the connected handle(s) to move to the closed position.


Materials

Body Galvanized Steel
Springs Stainless Steel

Ordering Information

Part Number	For Use With	Release Temperature	Spring Load		Minimum Number Required By MC331
			Fully Extended	After 4" Travel	
A3219RT	Internal Valves	212° F.	≈100 lbs.	≈50 lbs.	2

Typical Mounting Side View



Remote Cable Controls for Internal Valves 3200C and 3200L

Application

The 3200C Remote Cable Kit is designed especially for use with the 3200L Remote Operating Lever to operate internal valves from a remote location.


The internal valve is opened by pulling back the remote operation lever and closed by returning the lever to its original position. A remote release is provided to close the internal valve from a different remote location.

Features

- Metal construction provide durability in heavy duty applications.
- Toggle action of operating lever allows for quick closure without extra springs and latches.
- The unique clamping nut and cable clamps provide easy installation.
- Fuse connections allow internal valves to close if connections are exposed to fire.
- Versatile design permits installation on bobbins and stationary tanks at bulk plants.
- Provides necessary remote closure system for bobbins required by DOT regulation on MC330/MC331 tanks and NFPA #58.

Ordering Information

Part Number	Description	Contents
3200C	Remote Cable Kit	100 Foot Cable, 6 Cable Clamps, Quick Link, Sign, Fuse Link, Steel Nut and Bolt
3200L	Operating Lever	Lever Assembly



Materials

Body Galvanized Steel
Springs Stainless Steel

Threaded Internal Valves For Bobtail Delivery Trucks, Transports and Stationary Storage Tanks A3213R Series

Application

Designed primarily for use with LP-Gas and anhydrous ammonia for liquid withdrawal; vapor transfer or vapor equalization of bobtail delivery trucks, transports, stationary storage tanks, and in-line installations. The valve may be operated manually by cable or pneumatically.

Features


- May be installed in full and half couplings.
- Nylon bearing supported operating shaft provides smooth, easy operation.
- Simple operating lever facilitates easy adaptation of all cable controls.
- Midway stem position allows for quicker pressure equalization.
- All critical operating components are located in the valve body inside the container coupling for maximum protection against physical damage.
- Built in excess flow valve.
- Return spring returns the valve to the closed position when the handle is released.
- Specify RegO® Internal Valves on your next new tank body or when your tank is rebuilt.
- A3213PA pneumatic actuator provides a convenient means of opening and closing the valve from a remote location, using either air or nitrogen for A3213R service valves.

Materials

Body Ductile Iron
Operating Lever..... Cadmium Plated Steel
Stem Stainless Steel
Springs Stainless Steel
Seat Disc Resilient Synthetic Rubber
Shaft Bearing..... Nylon

Seat disc fully retained and field replaceable.


Excess flow spring is independent from return spring operation



A3213R



Cam attached with Allen head fastener which is accessed from the 1/4" pipe plug on side of the body



A3213RT

Cam attached with Allen head fastener that is accessed from the 3" F-NPT outlet connection on the side of the body



Ordering Information

Part Number	Inlet Connection M-NPT	Outlet Connections F-NPT	Closing Flow Half Coupling (GPM)		Closing Flow Full Coupling (GPM)		LP-Gas Vapor Capacity (SCFH/Propane)		A	B	C	D	E	F	Accessories		
			LPG	NH ₃	LPG	NH ₃	25 PSIG Inlet	100 PSIG Inlet							Pneumatic Actuator	Rotary Actuator	Thermal Latch
A3213R150	3"	3"	150	135	125	113	-	-	1½"	5⅝"	4¼"	-	-	7⅞"	A3213PA	A3213RA	A3213TL
A3213R200			200	180	160	144	44,100	75,100									
A3213R300			300	270	250	225	57,900	90,500									
A3213R400			400	360	325	293	71,400	121,300									
A3213RT150			150	135	125	113	-	-	1½"	7⅞"	4¼"	3⅝"	4½"	3½"			
A3213RT200			200	180	160	144	44,100	75,100									
A3213RT300			300	270	250	225	57,900	90,500									
A3213RT400			400	360	325	293	71,400	121,300									

Threaded Internal Valves For Bobtail Delivery Trucks, Transports and Stationary Storage Tanks A3212 Series

Application



Designed primarily for use with LP-Gas and anhydrous ammonia for liquid withdrawal; vapor transfer or vapor equalization of bobtail delivery trucks, transports, stationary storage tanks, and in-line installations. The valve may be operated manually by cable or pneumatically.

Features



- May be installed in full and half couplings.
- Nylon bearing supported operating shaft provides smooth, easy operation.
- Simple operating lever facilitates easy adaptation of all cable controls.
- Midway stem position allows for quicker pressure equalization.
- All critical operating components are located in the valve body inside the container coupling for maximum protection against physical damage.
- Built in excess flow valve.
- Return spring returns the valve to the closed position when the handle is released.
- Specify RegO® Internal Valves on your next new tank body or when your tank is rebuilt.
- A3213PA pneumatic actuator provides a convenient means of opening and closing the valve from a remote location, using either air or nitrogen for both the A3212R & A3213A service valves.

Materials


Body	Ductile Iron
Operating Lever.....	Cadmium Plated Steel
Stem	Stainless Steel
Springs	Stainless Steel
Seat Disc	Resilient Synthetic Rubber
Shaft Bearing.....	Nylon



A3212R Series




A3212RT Series



Ordering Information

Part Number	Inlet Connection M. NPT	Outlet Connection F. NPT	Closing Flow (GPM) Half Coupling		Closing Flow (GPM) Full Coupling		Accessories		
			LP-Gas	NH3	LP-Gas	NH3	Thermal Latch	Pneumatic Actuator	Rotary Actuator
A3212R105	2"	2"	105	95	65	59	A3213TL	A3213PA	A3212RA
A3212RT105									
A3212R175			175	158	100	90			
A3212RT175									
A3212R250			250	225	130	117			
A3212RT250									


Flomatic® Internal Valve Operation



1. Normally Closed

When the valve is closed, liquid flows into the INLET PORTS, through a channel in the PISTON, and into area A. It also flows down through the PRIMING CHANNEL in the valve body, into area B beneath the valve seat, and into area C to prime the PUMP.


1



2. Pump On – Valve Opening

When the pump is started, differential pressure transmits through the 1/4" piping into chamber D, lifting the PILOT STEM. This opens the seat between the stem and piston at E. Pump suction then evacuates the tank pressure in area A, which becomes equal to the pump suction pressure.

2



General Information


RegO® piston type Flomatic® Internal Valves are normally closed and use pressure differential to provide completely automatic service. Mounted directly between the tank body and pump, the Flomatic® uses the pressure differential developed by the pump to open the valve and it closes automatically when the differential no longer exists.

This means the RegO® Flomatic® opens when the pump is on and closes when the pump is shut off – fully automatic.

3. Pump On – Valve Open

The force below the pilot stem forces the piston up to open the valve; rotating the INDICATOR SLOT to its vertical (valve open) position. Pump differential pressure in area D holds the PILOT STEM and PISTON open. Approximately 20 psig pump differential pressure is required to open the valve; approximately 8 psig differential pressure will hold the valve open.


3



4. Pump Off – Valve Closes

With the pump shut off, the pressure in area D which holds the valve open, bleeds out through the #60 DRILL ORIFICE. This loss of pressure permits the SPRING to push the PILOT STEM down to reseat at point E. Since pressures are equal above and below the PISTON, with no sustaining pressure in area D, the SPRING forces the valve closed. The INDICATOR SLOT rotates to the horizontal (valve closed) position.

4



Flomatic® Internal Valves for Bobtail Delivery Trucks, Transports and Large Stationary Storage Tanks A7883FK and A7884FK

Application

Designed primarily for LP-Gas and anhydrous ammonia liquid withdrawal on MC331 bobtail delivery trucks, transports and large stationary storage containers with flanged connections. The valve is fully automatic, opening and closing as the pump is turned on or off.



Features

Fully Automatic

- Operates on pressure differential from the pump to open and close.
- Automatically closes should downstream line rupture causing loss of pump differential pressure required to keep the valve open.
- Problems of improperly sized excess flow valves slugging shut during liquid transfer are eliminated.

Faster Unloading

- Straight through flow design provides minimum pressure drop and large flow capacity to the pump, resulting in higher flow rates and greater pump efficiency.
- Unloading is quicker and turn-around faster to provide more profitable operation.

Greater Protection

- Fully automatic operation virtually eliminates operator errors such as forgetting to close the valve after product transfer.
- Fully internal design reduces possibility of spillage that may result from a collision.
- Built-in visual indicator lets the operator know whether the valve seat is in the open or closed position.
- Never a cable problem. These valves must NEVER be held open by wire or any other means as the valve will not close as expected when the pump is shut-off.

Less Maintenance


- Easily replaceable, high efficiency external filter removes contaminant's as small as 20 microns. Filter virtually eliminates orifice clogging, excessive internal filter maintenance and service downtime.
- No need to check or replace air lines, cables or cable connections.

Economical

- Completely equipped with mounting bolts, flange gaskets, quick acting valve and filter - all in one purchase price.
- No need to purchase additional mounting equipment or actuating accessories.
- Specify RegO® Internal Valves on your next new tank body or when your tank is rebuilt.



A7883FK



Materials

Body	Cast Steel
Valve Stem	Stainless Steel
Operating Stem	Stainless Steel
Piston	Aluminum
Cylinder	Stainless Steel
Screen	Stainless Steel
Seats	Resilient Synthetic Rubber



Ordering Information

Part Number	Inlet Connection ANSI Flange	Outlet Connection ANSI Flange	Strainer Width	Base Width	Overall Height (Approx.)	Height from Indicator to Base	Accessories (included with Flomatic®)	
							Filter	3-Way Valve
A7883FK	3"-300#**	3"-300#	4 3/4"	8 1/4"	10 7/8"	4 13/16"	A7884-201	A7853A
A7884FK	4"-300#***	4"-300#	5 3/4"	10"	11 1/4"	4 15/16"		


*Supplied with A7853A 3-way valve, A7884-201 filter, studs, nuts and gaskets.

**With 4 1/8" diameter bore.

***With 5 1/8" diameter bore.



1/4" Three-Way Quick-Acting Valve A7853A

Flow Characteristics





A7853A 1/4" Three-Way Quick-Acting Valve

Typical Installation



A7853PAF

Flange Dimensions



A7853PA

Part Number	Flange Type	A	B	C	D	Accessories	
						Pneumatic Actuator	3-Way Valve
A7883FK	T-1 Steel Carbon Steel	4 ¹³ / ₁₆ "	5 ³ / ₄ "	6 ⁵ / ₈ "	8 ¹ / ₄ "	A7853PAF	A7853PA
A7884FK		5 ¹ / ₈ "	7"	7 ¹ / ₈ "	10"		

*Supplied with A7853A 3-way valve, A7884-201 filter, studs, nuts and gaskets.
 **With 4¹/₈" diameter bore.
 ***With 5¹/₈" diameter bore.

On The Job Service Guide for the Flomatic® Valve

Introduction

Efficient, profitable transport and delivery truck operations depend on keeping the equipment working safely and efficiently under changing conditions. It is important to know how to eliminate expensive delays by handling unloading problems as they arise.

The purpose of this technical guide is to provide basic information on the Flomatic® valve, along with simple, appropriate steps to follow in the event things go wrong.

The Flomatic® valve is mounted on the bottom of your transport or delivery truck tank, with the pump mounted immediately downstream. When the pump starts to push the liquid down the piping, the Flomatic® Valve opens automatically, allowing you to unload the tank, and closes when the pump stops pushing. It takes at least 20 pounds per square inch of "push" at the pump to open the valve.

Your flanged Flomatic® valve has an indicating shaft on it that shows whether it's open or closed (Figure 1). If the indicating shaft is horizontal, the valve is closed. If it's vertical, the valve is open.

A threaded type, diaphragm-operated Flomatic® valve has an indicating shaft on the bottom, covered by a clear plastic hood. The indicating shaft projects down when the valve is closed and is concealed when the valve is open (Figure 2).

Important Facts About Pressure

When handling propane or anhydrous ammonia, storage and transport tank pressures vary from about 20 pounds per square inch or less when it's cold to 200 pounds per square inch or more in hot weather (Figure 3). If you're hauling butane, tank pressures will be 50 pounds per square inch or less.

The transport or delivery truck tank pressure may be higher than the storage tank pressure when you are ready to unload (Figure 4). This is because your rig may have been freshly loaded at the terminal or bulk plant without a vapor equalizing line and hasn't had time to get back to normal. Also, the storage tank pressure tends to drop when a lot of LPGas is being used.

Troubleshooting on the Job

O.K. So you follow your procedures, hook up your hoses, open the required valves and start your pump. The indicating shaft on the Flomatic® valve moves to the open position and the liquid goes in to storage. Great! You're happy and so is the boss, and so are we.

But, let's say you do these things, start the pump and the liquid doesn't move. Now, how do you find out what is wrong?




Figure 1. Flanged Flomatic Valve




Figure 2. Threaded, Diaphragm-operated Flomatic Valve




Figure 3. Weather Conditions Affect Pressure




Figure 4. Unloading Conditions Affect Pressure

On The Job Service Guide for the Flomatic® Valve

Step 1

Immediately shut down the pump so you don't cause possible damage to the seals or valves. Next:

1. Check all manual valves in the system to make certain they are open or closed as required for proper operation.
2. Check the liquid level in the transport or delivery tank. If the level is low, it may slow the transfer rate.
3. Check to assure that the pump rotates normally when power is applied. If not, inspect and repair as needed the power takeoff, universal joints, drive shaft and clutch, etc.
4. Make sure the lever is straight out on the ¼" operating valve in the line between the pump discharge line and the Flomatic® valve (Figure 5). If it isn't, the Flomatic® valve will remain closed.
5. Make certain the priming valve on the side of the Flomatic® valve is open (Figure 6).




Figure 5. Operating Lever Positions

6. Ice in the system may prevent proper operation, as will a collapsed or kinked sensing line or a clogged sensing line filter. If you found the trouble within STEP 1, just start the pump and continue unloading. If not, proceed accordingly.

- a. New Models with T-handle: To adjust to the proper position, push in the end of the valve stem and tighten the needle valve clockwise until it seats. Then, turn counterclockwise 1½ turns.
- b. Old Models with Plug: To adjust to the proper position, carefully remove the plug. A small amount of liquid LP-Gas may be discharged when plug is loosened. Insert a small screwdriver and tighten the needle valve clockwise until it seats. Then turn it counterclockwise 1 turn only. **CAUTION: Do not open needle valve more than 1 turn as it might blow out!**
- c. Threaded Models with Internal Priming Channel. The internal priming channel normally self-actuates. To be sure the system is primed, remove the plastic hood and push the travel indicator up about 18" and hold for at least 15 seconds.




Figure 6. Priming Procedures

Step 2




Figure 7a. Unloading Diagram of Transport Trailer Truck

The liquid flows out of the transport tank through the Flomatic® valve, into the pump and through the delivery hose to the storage tank. The vapor line allows vapor to flow from storage back to the transport so that the storage tank pressure won't build up too much and make the pump work harder than necessary.

For Transport Trailer Trucks Only (Figure 7a)

1. Check the difference between the pressure in your transport and the storage tank. If there's 15 or 20 pounds per square inch more pressure in the transport tank than in the storage tank, chances are the Flomatic® valve won't open. This is because the pump can't develop enough "push".

If you have a good bypass valve on your rig to send the extra liquid back into the tank, you can merely close the liquid shut-off valve in the discharge line and restart your pump (Figure 8a). Now, the Flomatic® indicating shaft should move to the open position (see Figures 1 and 2).

2. Slowly open the liquid shut-off valve in the discharge line and the liquid will start to move out of the transport. If the Flomatic® valve indicating shaft starts to move toward the closed position once you've opened this liquid shut-off valve all the way, throttle the valve for a while until the transport tank pressure drops to where the Flomatic® valve indicating shaft will stay open. Then, open the liquid shut-off valve all the way until you finish unloading.

On The Job Service Guide for the Flomatic® Valve

3. If your pump system doesn't have a bypass valve, the liquid shut-off valve in the discharge line should be left partially open when you restart the pump. Just be sure that the pump is pushing at least 20 pounds per square inch, so the Flomatic® valve can open.

Don't worry about how much it may slow up your loading speed when you pinch down the liquid shut-off valve to get the Flomatic® valve open. Your pump is running at constant RPM and will move liquid at almost the same rate, even when pushing harder. (It's a lot like using engine braking on a downhill grade, except, in this case, the pump keeps the liquid moving at a constant flow rate.)




Figure 8a. Unloading Diagram of Transport Trailer Truck with Back-to-tank Bypass Valve You must have a separate back-to-tank bypass valve if the pump is to be run with the liquid shut-off valve closed.

For Delivery Trucks Only (Figure 7b)

1. Check the pump bypass piping. If your truck is equipped with a manual bypass valve, close it and try the pump again. (Figure 8b). If the Flomatic® valve indicating shaft moves to the open position, the problem is that the pump can't develop 20 pounds per square inch or more to "push" open the Flomatic® valve with the bypass valve open. You can prevent this in the future by not opening the manual bypass valve too wide.

2. If the delivery truck is not equipped with a manual bypass valve, merely start the pump. Slowly close the shut-off valve between the back-to-tank bypass valve and tank. If the Flomatic® valve indicating shaft moves to the open position as you close the valve, the back-to-tank bypass valve may be stuck open, adjusted too low, or the spring may be broken. **CAUTION: Don't close the shut-off valve all the way, because excessive pressures and pump damage may occur.**

3. If the Flomatic® valve indicating shaft remains in the closed position, the problem is either in the pump or the Flomatic® valve.




Figure 7b. Unloading Diagram of Delivery Truck

The liquid flows out of the truck tank, through the Flomatic® valve and into the pump, where it is then pushed through the meter and delivery hose into the storage tank. The liquid normally enters the vapor space of the storage tank to minimize pressure buildup, so a vapor equalizing line is usually not needed. The back-to-tank bypass valve opens to divert excess pump capacity back to the truck tank, preventing the pump from creating too much pressure.




Figure 8b. Unloading Diagram of Delivery Truck with Manual Bypass Valve

On The Job Service Guide for the Flomatic® Valve

USE EXTREME CARE AT ALL TIMES WHEN WORKING AROUND YOUR VEHICLE!
Watch out for drive shafts and moving parts. It is common knowledge that serious injury can result if any part of one's body or clothing is caught in moving machinery.

If you manually open the Flomatic® valve, you are responsible for safely unloading the liquid and closing the valve when you're through. If this procedure is being followed, under no circumstances must the valve be left unattended. The valve must never be permanently held in the open position.

If you are not able to cause the Flomatic® valve indicating shaft to move to the open position after completing the preceding steps, a complete detailed diagnosis will have to be made.

In the meantime, you can actuate the flanged Flomatic® valve by using a special wrench and attempt to unload manually (Figure 9).

If you still can't unload by following the preceding steps, it is suggested that you unload by an alternate method, such as through the valve normally used for liquid filling.

In any event, if you haven't solved the problem and the unit still doesn't operate properly, immediately take it out of service, have a complete analysis made and repair as needed.

Be sure to obtain and keep available for quick referral the Manufacturers' Operation and Service Manuals for the valves, pump, meter and all operating equipment in the system.




Figure 9. Actuating the Flanged Flomatic® Valve Manually

Pumping System Troubleshooting Guide

Introduction

Most LP-Gas and anhydrous ammonia systems use pumps to move liquid from one location to another. Unloading transport trailer tanks into plant storage, loading delivery trucks, filling bulk tanks, engine fuel tanks, portable cylinders, etc. and pressurizing LP-Gas vaporizers are only a few of many such applications. A well-designed and properly installed pumping system will perform well for some time, but eventually problems occur requiring attention.

Finding out what is wrong, and getting it working again, can be a timeconsuming and confusing experience, unless one knows clearly how to proceed.

The purpose for this technical guide is to provide simple, step-by-step guidelines for correcting LP-Gas and anhydrous ammonia pumping difficulties.

The procedure includes a preliminary checklist to help find out if the difficulty can be corrected without taking anything apart. Then, it shows how to zero in on more serious problems by using a few pressure gauges to pinpoint the cause.


It is recommended that the pumping system be equipped for easy pressure gauge installation before trouble occurs. Small manual shutoff valves can be installed at proper locations, with plugs inserted in the outlets.

This would allow pressure gauges to be put in easily without removing the LP-Gas or anhydrous ammonia from the system at the time trouble occurs, saving a lot of time and unnecessary expense. Pressure gauges should be installed temporarily at the time the system is first installed, and pressure readings recorded while the system is working properly. Then, in many cases, merely comparing pressures with original readings may tell what the trouble is.

NOTE: The figure below shows where pressure gauges should be installed. Pressure gauge readings from the original tests should be recorded for each gauge.

It is recommended that the pressure gauges not be used continuously, because vibrations and the ravages of weather cause their damage or ruin. Therefore, as soon as the initial tests are complete, it is best to (1) close the shutoff valves, (2) remove the gauges, (3) plug the valves and (4) keep the gauges in a safe place, ready for troubleshooting when really needed. It is easier to diagnose a problem if the original test results are available, but don't panic if they aren't. You can still solve the problem without this information, but it requires more time and effort.

Pump System Schematic



A



Tank Pressure doesn't change



Pump Inlet Pressure decreases



Pump Outlet Pressure doesn't change

The trouble is most likely somewhere in the inlet line. It could be:

1. The pump may be running at a speed too low to develop proper differential pressure.
2. An inlet strainer is clogged.
3. A valve is partially closed somewhere in the inlet line.
4. Ice has formed either in the bottom of the supply tank or somewhere in the inlet line. This is common particularly when the tank has been hydrostatically tested or purged with steam, and not completely drained and dehydrated.
5. If a Flomatic® valve is used, it may not be opening for a number of reasons.
 - a. Pressure in the tank to be filled may be considerably less than that in the supply tank, making it impossible for the pump to develop sufficient differential pressure to open the valve (Simply throttle a manual valve on the discharge line to cause the pump

to develop enough differential pressure to open the Flomatic® valve. As the pressure in the tank to be filled goes up, it will be possible to re-open the valve in the discharge line.)

- b. The pump by-pass valve may be blocked open or have broken or damaged parts, preventing the pump from developing sufficient differential pressure to open the Flomatic® valve. (Pump outlet pressure must rise at least 21 PSI to open the Flomatic® Valve.)
 - c. The Flomatic® strainer, filter, three-way valve or other element in the actuating line is clogged, or the actuating line is kinked.
 - d. The Flomatic® valve internal parts may be damaged or worn. (Refer to Installation Manual #A7884F-301 for flanged valves or #L-451 for diaphragm-type threaded valves for repair instructions.)
6. If an internal valve is used, the main valve may not be opening due to insufficient equalization time, broken or damaged valve parts, valve lever in closed position or insufficient excess flow sizing.

NOTE: Meter pressure is not needed for this condition.

B



Tank Pressure doesn't change



Pump Inlet Pressure doesn't change



Pump Outlet Pressure goes up a little

The trouble is most likely related to the pump or by-pass valve. It could be:

1. The pump may have excessively worn parts.
2. The internal by-pass valve in the pump may be blocked open by foreign material, or may have broken or damaged parts.
3. The back-to-tank by-pass valve may be blocked open by foreign material, or may have broken or damaged parts.
4. The manual by-pass valve, is so-equipped, may be open.

NOTE: Meter pressure is not needed for this condition.

Pumping System Troubleshooting Guide

Be sure to obtain and keep available for quick referral the Manufacturer's Operation and Service Manuals for the valves, pump, meter and all operating equipment in the system.

To avoid delays, maintain a complete stock of recommended spare parts on hand for quick repairs.

Follow the steps as shown. Don't assume the answer is known beforehand, or skip any applicable steps. Rather, be thorough and methodical and in most instances, you will solve the problem. On the

other hand, if you have done all of this and still haven't worked out your problem, feel free to call your local distributor or REGO®

direct. We will do our best to help. Perhaps, between us, we will be able to solve your problem and add something new to the procedure which could help everyone in the future.

Pumping System Troubleshooting Chart

BASIC ASSUMPTION

The pumping system did work OK, but now the transfer rate is considerably less, or the system won't pump at all.

PRELIMINARY REVIEW

1. Check the supply tank liquid level. The transfer rate could be considerably reduced if the level is low, due to vapor bubbles in the line, because of insufficient liquid head, or a vortex effect in the tank. Remember, reduction in the pumping rate from these causes will be more extreme in cold weather when tank pressures are low.
 2. Examine the pump drive to make sure the pump is rotating properly. Inspect for loose drive belts, damaged or broken flexible couplings or universal joints, broken drive keys and damaged or inoperative power take-off or pump clutch, etc.
 3. If the system is equipped with the Flomatic® Valve:
 - a. Make sure the three-way valve handle is straight out, allowing the valve to open.
 - b. Check the position indicator on the Flomatic Valve when the pump is running. If the indicator shows that the valve is open, the trouble **must** be downstream of the valve.
 - c. Make sure the priming valve is open, allowing pressure to equalize between the tank and pump inlet.
 4. If the system is equipped with internal valves, make sure the operating lever moves to a full open position. Repair if needed.
 5. Make sure all valves in the system are either open or closed as required for normal operation. Check each valve in sequence, starting from the supply tank, making sure that no valve element is missed.
- If the cause of the problem has not been determined during preliminary review, it will be necessary to conduct diagnostic tests, using pressure gauges at key points in the system. (See Introduction, Page 1.)

DIAGNOSTIC TESTS

Open all valves as required for proper pumping operation. Gauges should show tank pressure, pump inlet pressure, pump outlet pressure and meter pressure to be equal.


Start the pump and observe all pressure gauges. Match results with conditions A, B, C, or D. Follow the appropriate steps.

FINAL RESULTS

Make repairs or adjustments as needed, and test the system's operation. Record a new set of test pressures for future reference, and order replacements for all spare parts used.

The system is now ready to return to service.

C




Tank Pressure doesn't
Pump Inlet Pressure doesn't change
Pump Outlet Pressure rises substantially
Meter Pressure rises substantially

The trouble is most likely in the meter vapor eliminator or meter differential valve. It could be:

1. The meter's vapor eliminator may be malfunctioning. If the valve at the outlet of the vapor eliminator does not seat when the vapors have been purged, the differential valve downstream of the meter will not open. Such failure could be caused by a damaged vapor eliminator valve seat, foreign material blocking the vapor eliminator valve, a leak in the ball float, or a jammed or binding linkage between the ball and valve.
2. The diaphragm could be ruptured, or other parts could be damaged or broken in the differential valve downstream of the meter.

D



The problem is most likely somewhere downstream of the pump. Look for a closed valve, or some type of blockage in the discharge line. It could be:

1. The meter strainer may be clogged.
 2. A back check valve at the inlet of the meter may be blocked, closed, or jammed.
 3. The meter rotor may be jammed by foreign material, preventing it from moving properly, which would prevent or retard flow.
 4. The drive key on the meter gears may be sheared. (In this case, flow would actually be moving through the meter but not registering.)
 5. The differential valve downstream of the meter may be closed due to damage, foreign material or ice.
 6. If screw type hose fittings are used, it is extremely important that they be installed properly. If not, it is possible that a flap of rubber may be cut from the inside diameter of the hose, acting as a back check. It can flap across the discharge line, effectively stopping the flow.
 7. Check the hose nozzle valve, if so equipped. In some brands, a bent handle or other defect may prevent the inner valve from opening sufficiently to allow a proper amount of flow.
 8. The problem could be in the valve assemblies in the tank to be filled.
- If you are dealing with a delivery truck application, move to another tank and see whether the problem still exists. If not, it may be a problem with one specific tank, rather than the pumping system.
9. Some delivery trucks are equipped with a quick-acting valve immediately upstream, of the hose reel. **Make sure** that this valve is open.
 10. Some delivery trucks are equipped with excess flow valves between the meter and hose reel. Improper sizing, a weak spring, or other valve damage can cause this valve to close prematurely, effectively stopping the flow.
 11. If, with a delivery truck system, the flow reduced considerably while the tank is being filled, it is possible that the back-to-tank by-pass valve is not set high enough to compensate for vapor pressure buildup in the tank being filled. This can be solved merely by adjusting the by-pass valve to a slightly higher level. **Warning:** Do not raise the back-to-tank by-pass setting high enough to cause the internal relief valve in the pump to actuate. If this should happen, it could cause excessive cavitation, loss of capacity and premature pump wear.

FINAL RESULTS

Make repairs or adjustments as needed, and test the system's operation. Record a new set of test pressures for future reference, and order replacements for all spare parts used. The system now is ready to return to service.

Cross Reference by Part Number

3200C G14
 3200L G14
 A3209D050 G8
 A3209DT050 G8
 A3209D080 G8
 A3209DT080 G8
 A3211D110 G9
 A3211D080 G9
 A3212R105 G16
 A3212RT105 G16
 A3212R175 G16
 A3212RT175 G16
 A3212R250 G16
 A3212RT250 G16
 A3213R150 G15
 A3213RT150 G15
 A3213R200 G15
 A3213RT200 G15
 A3213R300 G15
 A3213RT300 G15
 A3213R400 G15
 A3213RT400 G15
 A3217AL160 G10
 A3217AR160 G10

A3217DAL160 G10
 A3217DAR160 G10
 A3217AL210 G10
 A3217AR210 G10
 A3217DAL210 G10
 A3217DAR210 G10
 A3217AL260 G10
 A3217AR260 G10
 A3217DAL260 G10
 A3217DAR260 G10
 A3217AL410 G10
 A3217AR410 G10
 A3217DAL410 G10
 A3217DAR410 G10
 A3217AL510 G10
 A3217AR510 G10
 A3217DAL510 G10
 A3217DAR510 G10
 A3219RT G14
 A3219FA400L G12
 A3219FA600L G12
 A7883FK G18
 A7883FK G19
 A7884FK G18
 A7884FK G19



LP-Gas & Anhydrous Ammonia Equipment

H

Section H

Adapters Connectors and Fittings

Limited Warranty and Limitation of Liability

LIMITED 10 YEAR WARRANTY AND LIMITATION OF LIABILITY

LIMITED 10 YEAR WARRANTY

REGO® warrants to the original purchasers the products and repair kits manufactured by it to be free from defects in materials and workmanship under normal use and service for a period of 10 years from the date of manufacture. If within thirty days after buyer's discovery of what buyer believes is a defect, buyer notifies in writing and ships the product to REGO® at 100 Rego Drive, Elon, NC 27244, REGO®, at its option, and within forty-five days of receipt, will repair, replace F.O.B. point of manufacture, or refund the purchase price of that part or product found by REGO® to be defective. Failure of buyer to give such written notice and ship the product within thirty days shall be deemed an absolute and unconditional waiver of any and all claims of buyer arising out of such defect.

This warranty does not extend to any product or part that is not installed and used continuously after installation in accordance with REGO®'s printed instructions, all applicable state and local regulations, and all applicable national standards, such as those promulgated by NFPA, DOT and ANSI. This warranty does not extend to any product or part that has been damaged by accident, misuse, abuse, failure to maintain, or neglect, nor does it extend to any product or part which has been modified, altered, disassembled, or repaired in the field. This warranty does not cover any cosmetic issues, such as scratches, dents, marring, fading of colors or discoloration.

Except as expressly set forth above, and subject to the limitation of liability below, REGO® MAKES NO OTHER WARRANTY, EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, with respect to its products and parts, whether used alone or in combination with others. REGO® disclaims all warranties not stated herein.

LIMITATION OF LIABILITY

REGO®'s total liability for any and all losses and damages arising out of any cause whatsoever shall in no event exceed the purchase price of the products or parts in respect of which such cause arises, whether such cause be based on theories of contract, negligence, strict liability, tort or otherwise.

REGO® shall not be liable for incidental, consequential or punitive damages or other losses. REGO® shall not be liable for, and buyer assumes any liability for, all personal injury and property damage connected with the handling, transportation, possession, further manufacture, other use or resale of products, whether used alone or in combination with any other products or materials.

From time to time buyers might call to ask REGO® for technical advice based upon limited facts disclosed to REGO®. If REGO® furnishes technical advice to buyer, whether or not at buyer's request, with respect to application, further manufacture or other use of the products and parts, REGO® shall not be liable for such technical advice or any such advice provided to buyer by any third party and buyer assumes all risks of such advice and the results thereof.

NOTE: Some states do not allow the exclusion or limitation of incidental, consequential or punitive damages, so the above limitation or exclusion may not apply to you. The warranty gives you specific legal rights, and you may have other rights that vary from State to State. The portions of this limited warranty and limitation of liability shall be considered severable and all portions which are not disallowed by applicable law shall remain in full force and effect.

NOTICE TO USERS OF PRODUCTS

The Limited Warranty stated above is a factory warranty to the first purchasers of REGO® products. Since most users have purchased these products from REGO® distributors, the user must within thirty (30) days after the user's discovery of what user believes is a defect, notify in writing and return the product to the distributor from whom he purchased the product/part. The distributor may or may not at the distributor's option choose to submit the product/parts to REGO®, pursuant to this Limited Warranty. Failure by buyer to give such written notice within thirty (30) days shall be deemed an absolute and unconditional waiver of buyer's claim for such defects. Acceptance of any alleged defective product/parts by REGO®'s distributor for replacement or repairs under the terms of REGO®'s Limited Warranty in no way determines REGO®'s obligations under this Limited Warranty.

Because of a policy of continuous product improvement, REGO® reserves the right to change designs, materials or specifications without notice.

Foreword

This catalog describes a complete line of equipment available from REGO® for use with LP-Gas and anhydrous ammonia (NH₃). The following points are important to know for proper use of the catalog:

1. Illustrations and drawings of individual products are representative of “product groups” and all products within a product group are similar in construction.
2. Materials used for construction of products in this catalog are suitable for rated service pressure at temperatures of -40° F. to +165° F., unless otherwise specified.
3. Products in this catalog are only intended for use in LP-Gas and/or anhydrous ammonia service as follows.
 - a. “A” or “AA” prefix — Products with this prefix are suitable for NH₃ service (i.e., contain no brass parts).
 - b. “AA” prefix on relief valves — These valves are NOT suitable for use with LP-Gas service. These are of partial aluminum materials and are listed by Underwriters Laboratories (UL) for NH₃ service only.
 - c. All other products are suitable for use with LP-Gas service.
 - d. “SS” prefix—Hydrostatic relief valve with this prefix are suitable for NH₃ service (i.e., they have stainless steel materials).

Caution

Do not use any product contained in this catalog with any service commodity other than LP-Gas or NH₃. If you have a need for use of another application, contact REGO®, 100 RegO Drive, Elon, NC 27244, (336) 449-7707 before proceeding.

Proper application, installation and maintenance of products in this catalog are essential. Users of these products should obtain further information if there are any doubts or questions.

Warning

All REGO® products are mechanical devices that will eventually become inoperative due to wear, corrosion and aging of components made of materials such as rubber. The environment and conditions of use will determine the safe service life of these products. Periodic inspection and maintenance are essential to avoid serious injury and property damage.

Many REGO® products are manufactured for storage, transport, transfer and use of toxic flammable and dangerous liquids and gases. Such substances should be handled by experienced and trained personnel only, using accepted governmental and industrial safety procedures. Never vent LP-Gas near any possible source of ignition.

Notice

Installation, usage, and maintenance of all REGO® products must be in compliance with all REGO® instructions as well as requirements and provisions of NFPA #54, NFPA#58, DOT, ANSI, and all applicable federal, state, provincial and local standards, codes, regulations, and laws.

Inspection and maintenance on a periodic basis is essential. Installation and maintenance should be performed only by qualified personnel.

Be sure all instructions are read and understood before installation, operation and service.

Filters

REGO® LP-Gas equipment is designed to operate in a system free from contamination. A variety of in-line filters are commercially available to the LP-Gas industry for installation in domestic systems.

The use of an in-line filter should be considered when other system components may be unclean and the system contaminated by rust, scale, dirt, debris or other foreign material.

Contents

Page

ACME Adapters.....	H9
ACME Check Connectors.....	H6
ACME Plugs.....	H7
Caps and Reducers.....	H8
Cross Reference by Part Number.....	H13
Extended Type Hose Couplings.....	H4
Filler Hose Adapters.....	H7
Miscellaneous Adapters.....	H11

Pigtails.....	H8
POL Adapters.....	H11
POL Plugs.....	H7
Pressure Gauge Adapter.....	H11
Short Type Hose Couplings.....	H5
Swivel Adapters.....	H10
Unloading Adapters.....	H6

Extended Type Hose Couplings for Vapor and Liquid Service A7571 and A7575 Series

Application

Designed especially for liquid filling and vapor equalization of LP-Gas and anhydrous ammonia. The limited travel of the handle on the tailpiece minimizes spin-off, encouraging cautious removal to properly bleed off trapped product to assure closure of the filler valve and hose end valve. The ACME threads are machined on a rugged steel insert which is permanently cast in the aluminum handle, providing for durability under repeated use.



Features


- Lightweight aluminum handle is contoured and ribbed for added comfort, easy handling allows for easy make-up.
- Free swivel action between tailpiece and handle allows for easy make-up.
- Simplified design eliminates an extra joint and provides smooth, uninterrupted flow.

Materials

Handle Aluminium
ACME Threads Steel Inlet
Restraining Ring Stainless Steel




A7571 Series



For Vapor
Equalizing



A7575 Series



For Liquid
Filling

Ordering Information

Part Number	Type of Service	A. Hose Connection (M. NPT)	B. Coupling Connection (F. ACME)	C. Approx. Length
A7575L2*	Liquid	1/2"	1 1/4"	7"
A7575L3		3/4"		
A7575L4		1"		
A7575L5**		1 1/4"		
A7571LA	Vapor	1/2"	1 1/4"	
A7571LB		3/4"		


* Includes 7199-33 adapter, shipped loose.

** Includes A7575L5-1 adapter, shipped loose.

Short Type Hose Couplings for Vapor and Liquid Service 3171, 3175, 3181, 3185 and 3195 Series




3175 Series



Style A
For Liquid Filling




A3185 Series



Style B
For Liquid Filling




3171A Series



Style C
For Vapor Equalizing



3191 Series



Style D
For Vapor Equalizing



Ordering Information

Part Number	Material	Style	A. Hose Connection (M. NPT)	B. Coupling Connection (F. ACME)	C. Tailpiece Bore	D. Hose End To Nut	E. Overall Length
3175B	Brass	A	1/2"	1 1/4"	35/64"	2"	2 7/8"
3175			3/4"		3/4"		
3175A			1"		3/4"		
3185	Brass Nut & Steel Nipple	B	1 1/4"	2 1/4"	1 1/16"	2 1/8"	3 1/8"
3195			2"	3 1/4"	1 13/16"	2 1/8"	3 5/8"
A3175	Steel	A	3/4"	1 1/4"	3/4"	2"	2 7/8"
A3175A			1"		3/4"		
A3185		B	1 1/4"	2 1/4"	1 1/16"	2 1/8"	3 1/8"
A3195			2"	3 1/4"	1 13/16"	2 1/8"	3 5/8"
3171	Brass	C	3/8"	1 1/4"	13/32"	1 1/8"	2 1/16"
3171A			1/2"		17/32"		
3181			3/4"	1 1/4"	1 1/16"	2"	3 1/4"
3181A			1"		1 5/16"	1 7/8"	3 1/8"
3191		D	1 1/4"	2 1/4"	3/16"	2 1/8"	3 5/16"

ACME Check Connectors for Lift Trucks 7141F and 7141M

Application

These brass connectors are especially designed to join the carburetor fuel line to the service valve on lift truck cylinders. Sturdy, long lasting ACME threads allow quick, hand-tight assembly that provides for quick and simple cylinder replacement. Back checks automatically close in each connector when disconnected.


The 7141M couples directly to the service valve. An integral O-ring is designed to seal before the internal check opens, aiding in product loss prevention. A gasket at the ACME thread is a secondary seal when the connectors are tightened together. The connector fits RegO® lift truck cylinder filling adapters for fast, convenient filling.

The 7141F accepts fuel line adapter and couples directly to the 7141M. The O-ring seal in the 7141M is designed to seal before the internal check opens to allow product to pass through the connection. The knurled coupling eases threading and the ACME threads provide rapid effortless make-up, even against LP-Gas pressure.


NOTE: Refer to the "Cylinder and Service Valves" section of the L-500 catalog for additional information.



7141M



7141F



Ordering Information

Part Number	Application	A. Inlet	B. Outlet	Protective Cap*	
				Rubber	Brass
7141M	Service Valve	3/8" F. NPT	1 1/4" M. ACME	7141M-40	7141FP
7141F	Fuel Line	1 1/4" F. ACME	1/4" F. NPT	-	-

* Recommended to minimize foreign material entering valves which could result in leakage.

Unloading Adapters for Container Evacuation 3119A and 3120

Application

Designed to provide an efficient means of evacuating an LP-Gas container for relocation or repair. They thread directly onto the 1 1/4" ACME male hose connection of RegO® Filler Valves used on RegO® Double Check Filler Valves and Multivalves®.


The unloading adapters can be used to withdraw liquid provided the container is equipped with a dip pipe extending from the filler valve to the bottom of the container.

Features


- Available in either angle or in-line type configurations.
- Built-in vent valve provides for a controlled release of gas which may be trapped within the unit after use and also helps to indicate closure of the Filler Valve.
- Integral plunger has two different lengths of travel, 1/4" and 1/2", depending on which way the lever is turned. Can be used with all RegO® Filler Valves.



3119A




3120



B



3121




Materials

Body Brass
Plunger Steel

Ordering Information

Part Number	Style	A. Filler Valve Connection	B. Hose Connection
3119A	In-Line	1 ¾" F. ACME	1¼" M. ACME
3120	Angle		¾" F. NPT
3121			

Filler Hose Adapters 3179B and 7577V



These adapters are designed with minimal flow restriction and recommended for use on the outlet of the LP-Gas delivery truck filler hose. If the controlled bleed off of the connection indicates the filler valve on the tank being filled has failed to close, the hose adapter should be left in place on the filler valve and disconnection should be made at the regular filler hose coupling. (Repair of the filler valve must be made as soon as possible). An integral check valve in these adapters helps prevent further loss of product. The standard filler valve cap should be attached to these adapters when left on the container.



Ordering Information

Part Number	Built-in Vent Valve	A Filler Valve Connection	B Hose Connection
7577V	Yes	1 1/4" F. ACME	1 1/4" M. ACME
3179B	No		

ACME Plugs

Specifically designed to withstand the everyday abuse given hose end valves on delivery trucks and hose end couplings on risers in bulk plants. These rugged plugs protect the coupling tip as well as prevent the entrance of dirt, dust, snow and rain. They also prevent possible gas contamination from these same sources. The heavily ribbed outer surface permits hand-tight make-up.

These plugs are available in a choice of four sizes which may be used with liquid as well as vapor type couplings. As a convenience, the nylon plugs have a retaining chain and ring to prevent loss during a transfer operation.

All are suitable for LPG or anhydrous ammonia service except the brass 5765PR, which is for LP-Gas only.


Not intended for use as pressure closures.




Ordering Information

Part Number	Material	A (M. ACME)	Chain & Ring Fits Pipe Size Up To:
C5763N	Nylon	1 1/4"	3/4"
C5765N		1 3/4"	1 1/4"
5765PR	Brass		Not Applicable
C5767N	Nylon	2 1/4"	1 1/4"
C5769N		3 1/4"	2"

POL Plugs



3705RC
W/Chain & Ring



Highly recommended for installation in LP-Gas cylinder valve POL outlets whenever the service line is disconnected or when the cylinder is being transported.

When properly installed, the POL plug is designed to prevent contamination of the valve outlet and guards against product leakage if the cylinder valve is accidentally opened.

Ordering Information


Part Number	Material	Connection
N970P	Cyclac	M. POL (CGA 510)
10538P	Brass	
3705RC		

Caps and Reducers


Ordering Information

Cap With Chain & Ring		Cap Only Part Number	Material	Thread Connection
Part Number	Ring Fits Pipe Size Up To:			
3144-91	3/4"	3144-9P	Cyclac	1 1/4" F. ACME
3174-91	3/4"	3174-9P		1 1/4" F. ACME
3174-93	1 1/4"	A8016-9P		1 1/4" F. ACME
A8016-93	1 1/4"	A8016-9P	Nylon	1 1/4" F. ACME
1708	3/4"	-	Brass	F. POL (CGA 510)
7141FP	3/4"			1 1/4" F. ACME
3175P	1 1/4"			1 1/4" F. ACME
3184-90	2"			2 1/4" F. ACME
3194-90	3"	3194-9		3 1/4" F. ACME
-	-	5776*	Steel	2 1/4" F. ACME
A3184-90	2"	-		3 1/4" F. ACME
A3194-90	3"	-		3 1/4" F. ACME
-	-	A5776*	Brass	1 1/4" F. ACME
907FP	1"	-		1 1/4" F. ACME


* Reduces to 1 1/4" M. ACME




3144-91 Plastic Cap




A5776 Reducer Coupling



7141FP Cap Plug




907FP




1708C POL Cap


CGA 510



3194-90G ACME Cap with Stainless Steel Flange



3175P Cap Plug



3144-90 Metal Cap

Copper Pigtails

Features

- Heavy duty construction.
- Individually soldered connections to the copper tubing.
- Each pigtail is individually tested prior to shipment.

Materials

Tubing..... Copper
Connections..... Brass

912JS12



Straight Pigtails

Ordering Information

Connections	Approximate Length	Part Number			
		1/4" Tube		3/8" Tube	
		3/8" Hex Short Nipple	1 1/8" Hex Long Nipple	3/8" Hex Short Nipple	3/8" Hex Short Nipple
M.POL x M.POL	5"	-	1/2"	913JS05	
	12"	912PS12	-	913PS12	
	20"	912PS20	912PA20	913PS20	
	30"	912PS30	-	913PS30	
	36"	912PS36	912PA36	913PS36	
	48"	912PS48	912PA48	913PS48	
1/4" Inverted Flare x M.POL	12"	912FS12	-	-	
	20"	912FS20	912FA20	-	
	30"	912FS30	-	-	
	36"	912FS36	-	-	
1/4" M.NPT x M.POL	5"	-	-	913JS05	
	12"	912JS12	-	-	
	20"	912JS20	-	-	
	36"	912JS36	-	-	
1/2" M.NPT x M.POL	12"	-	-	913LS12	
1/2" M.NPT x 3/8" M.POL	12"	-	-	913KL12	


612J Series Gauge Tail

1/4" NPT



0-300 PSIG Pressure Gauge


POL (CGA 510)



Fully Retained Bleeder Valve Flat Blade Screw Slot


612P Series Gauge Tail

POL (CGA 510)



0-300 PSIG Pressure Gauge

POL (CGA 510)



Fully Retained Bleeder Valve Flat Blade Screw Slot

913JS05A

913PS05A

913PS12G

Bent Pigtails


Ordering Information

Connections	Approximate Length	Part Number	Type/Degree of Bend
		3/8" Tube	
		7/8" Hex Short Nipple	
1/4" M. NPT x M. POL	5"	913JS05A	90°
M. POL x M. POL	12"	913PS05A	
		913PS12G	270° Right Hand
		913PS12H	270° Left Hand
		913PS12S	360°

ACME Adapters

Ordering Information

Part Number	Material	A M. ACME	B F.NPT	C Hex	D Overall Length	E Diameter	For Spare Gasket Order Part No
5764A	Brass	1¾"	¼"	1¾"	1½"	¾"	A2697-20R
5764B			⅜"				
5764C			½"				
5764D			¾"				
5764E			1"				
5766E		2¼"	1"	2¼"	2 ⅝"	1⅜"	A3184-8R
5766F			1¼"				
5768G		3¼"	1½"	3½"	3⅝"	2⅞"	A3194-8R
5768H			2"				
5768J			2½"				
A5764D	Steel	1¾"	¾"	1¾"	2 ⅜"	¾"	A2697-20R
A5764E			1"				
A5768H		3¼"	2"	3¼"	3¼"	1⅜"	A3194-8R




Gasket (Furnished with adapter)

ACME x Female NPT

Ordering Information

Part Number	Material	A M. ACME	B M. NPT	C Hex	D Overall Length	E Diameter	For Spare Gasket Order Part No.
5763D	Brass	1 1/4"	3/4"	1 1/4"	1 3/4"	7/16"	A2797-20R
5765D		1 3/4"	3/4"	1 3/4"	1 7/8"	1 1/16"	A2697-20R
5765E			1"		2 1/8"	3/4"	
5765F			1 1/4"				
5767F		2 1/4"	1 1/4"	2 1/4"	2 3/16"	1 3/8"	A3184-8R
5767G			1 1/2"	2 7/16"	1 5/8"		
5767H			2"		1 25/64"		
5769H		3 1/4"	2"	3 3/8"	2 7/8"	1 7/8"	A3194-8R
5769J			2 1/2"	3 1/4"	3 1/2"	2 5/8"	
5769K			3"	3 1/2"	3 5/8"		
A5765C	Steel	1 3/4"	1/2"	1 3/4"	2 3/16"	17/32"	A2697-20R
A5765D			3/4"			1 1/16"	
A5765E			1"			7/8"	
A5765F			1 1/4"			15/16"	
A5767F		2 1/4"	1 1/4"	2 1/4"	2 3/8"	1 3/16"	A3184-8R
A5769H		3 1/4"	2"	3 1/4"	2 5/8"	1 5/8"	A3194-8R
A5769K			3"		3 13/16"	2 5/8"	




Gasket (Furnished with adapter)

ACME x Male NPT

Ordering Information

Part Number	Material	A M. ACME	B Hex	C	D Diameter	For Spare Gasket Order Part No.
5765M	Brass	1 3/4"	1 3/4"	2 1/16"	7/8"	A2697-20R
5767M		2 1/4"	2 1/4"	2 5/16"	1 25/64"	A3184-8R
5769M		3 1/4"	3 1/4"	2 3/4"	2 1/8"	A3194-8R




Gasket (Furnished with adapter)

ACME x ACME

Ordering Information

Part Number	Material	A M. ACME	B F. NPT	C Hex	D Diameter	For Spare Gasket Order Part No.
A5764W	Steel	1 3/4"	3/8"	1 1/4"	1 1/16"	2697-20

* 3/8" -16 UNC Thread.



ACME x Miscellaneous
(Recommended for securing
hose-end valve when not in use).

3 1/4" M.ACME X 2" M.NPT Adapter with Vent Valve & Integral Screen 5769HVB

Application

Designed to prevent debris from impeding the action of valves and components of LPG piping systems at bulk plants and industrial plants.

Features


- Meets NFPA 58 requirements for liquid transfer
- Stainless steel screens
- Vent valve available in brass or stainless steel




5769HVB

Materials

Body Brass
Screen Stainless Steel
Gasket Resilient Rubber



STYLE 1




STYLE 2

Ordering Information

Part Number	Style	Gasket Qty	Vent Valve	Hex Size	Thread	"A" Length
5769H	1	1	-	3 1/4"	2" NPTF	2.875
5769K	1	1		3 1/2"	3" NPTF	3.625
5769M	2	2		3 1/4"	3/4" ACME	2.750
5769HVB	1	1	3165CBT		2" NPTF	3.150
5769VSS	1	1	TSS3169			3.150

Male POL Swivel Adapters



Ordering Information

Part Number	Material	A Outlet Thread	B Hex	C Drill	D Overall Length	Vapor at 100 PSIG Inlet (SCFH)	Liquid (GPM)
970	Brass	1/4" M. NPT	7/8"	5/16"	2 3/8"	-	-
970S				3/16"	2 3/32"	-	-
970AX				5/16"	2 5/64"	404	1.10
970AXS			1 1/8"	5/16"	2 7/16"	450	0.95
3199W				3/16"	2 3/32"	-	-
970AW				5/32"	2 5/8"	-	-
970HT		1/4" Hose Barb	7/8"	5/32"	2 5/8"	-	-
970JR				5/16"	2 1/2"	350	.95
3188A		1/2" M. NPT	1 1/8"	5/16"	2 1/2"	700	1.9
3188B				5/16"	2 1/2"	1180	2.9
3188C				5/16"	2 1/2"	1180	2.9


Note: All nipples incorporate wrench hex section.

CGA 555 Swivel Adapters


Part Number	Material	A Outlet Thread	B Hex	C Drill	D Overall Length
12982	Brass	1/4" M. NPT	1 1/4"	3/16"	1 15/16"
12982G		9/16" -18NF			

CGA 555

POL Adapters




Male POL x Female NPT



Male POL x Male NPT and SAE Flare

Ordering Information

Part Number	Material	A M. ACME	B	C Hex	D Diameter
2906A	Brass	1/4"	1 1/8"	1 5/16"	1/4"
2906G		1/2"	2"	1 1/8"	1/4"




Female POL x Female NPT and Female POL

Ordering Information

Part Number	Material	A	B	C Hex	D Diameter
5760Z	Brass	1/8"	1 5/8"	1 1/8"	5/16"
5760A		1/4"			13/32"
5760B		3/8"			35/64"
5760C		1/2"			43/64"
5760D		3/4"			13/32"
5760S	POL (CGA 510)	2 1/8"	1 1/8"		


Hose Adapter
For use with fuel gases (LP-Gas, Acetylene).



Ordering Information

Part Number	Material	A	B
1300	Brass	9/16" - 18NF (L.H.)	1/4" M. NPT

Pressure Gauge Adapter




Ordering Information

Part Number	Material	A	B	C
1494-1	Brass	1/2" F. NPT	1/4" F. NPT	1/2" M. NPT

Ordering Information

Part Number	Material	A	B	C Hex	D Diameter
2906D	Brass	3/8" M. NPT	2 1/8"	1 5/16"	1 1/32"
2906F		3/8" SAE Flare		7/8"	9/32"
2906E		1/2" SAE Flare	2 1/4"		




Female POL x Male NPT

Ordering Information


Part Number	Material	A	B	C Hex	D Diameter
5761A	Brass	1/4"	1 5/8"	1 1/8"	3/16"
5761B		3/8"			13/32"
5761C		1/2"			7/16"
5761D		3/4"			

Ordering Information

Part Number	Material	A	B
15774-1	Brass	1/4" M. NPT	Female Inverted Flare



Female Inverted Flare x Male NPT



Ordering Information

Part Number	Material	A	B	C	D	E	F
1328	Brass	5/8" - 18 UNF	5/8" - 18 UNF	1/4" Hose Barb	13/16"	2"	1 1/2"
1331		3/4" - 16 UNF	3/4" - 16 UNF		1 1/16"	2 1/8"	1 3/4"
1332		7/8" - 14 UNF	7/8" - 14 UNF		1 1/16"	2 1/2"	

Hose End Valve Adapter 7576

Application

No gas flow is allowed when this adapter is not connected to the 1 $\frac{1}{4}$ " ACME connection of a filler valve, it also acts as a back check.

Features


- Designed to be installed on the outlet connection of LP-Gas hose end valve; no flow is allowed until the 7576 adapter female ACME connection is engaged on to the male ACME threads on the filler valve.
- Incorporates a back check that will stop flow out of a filler valve that fails to close, when the 7576 adapter remains connected to the filler valve.
- Bleeder valve is designed to vent gas between the hose end valve connection and 7576 hose end adapter.
- Long grip ACME swivel for ease in connecting and disconnecting from a filler valve connection.



7576

Materials

Body	Brass
Inlet Connection.....	Brass
Outlet Connection.....	Brass
ACME Swivel.....	Aluminum
Spring	Stainless Steel
Seat Disc	Synthetic Rubber
O-Rings	Synthetic Rubber



Ordering Information

Part Number	Vent Valve	Filler Connection	Hose End Valve Connection	Propane Liquid Capacity @ 80 PSID
7576	Yes	1 $\frac{1}{4}$ " F. ACME	1 $\frac{1}{4}$ " M. ACME	57 GPM

Cross Reference by Part Number

907FP	H8
912FS12	H8
912JS12	H8
912PS12	H8
912FA20	H8
912FS20	H8
912JS20	H8
912PA20	H8
912PS20	H8
912FS30	H8
912PS30	H8
912FS36	H8
912JS36	H8
912PA36	H8
912PS36	H8
912PA48	H8
912PS48	H8
913JS05A	H8
913PS05A	H8
913PS12G	H8
913PS12H	H8
913PS12S	H8
970	H11
970AW	H11
970AX	H11
970AXS	H11
970HT	H11
970JR	H11
970S	H11
N970P	H7
1300	H12
1328	H12
1331	H12
1332	H12
1494-1	H12
1708	H8
2906A	H12
2906D	H12
2906E	H12
2906F	H12
2906G	H12
3119A	H6
3120	H6
3121	H6
3144-9P	H8
3144-91	H8
3171	H5
3171A	H5
3174-9P	H8
3174-91	H8
3174-93	H8
3175	H5
3175A	H5
3175B	H5
3175P	H8
A3175	H5
A3175A	H5
3179B	H7
3181	H5
3181A	H5
3184-90	H8
A3184-90	H8
3185	H5
A3185	H5
3188A	H11
3188B	H11
3188C	H11
3191	H5
3194-9	H8
3194-90	H8
A3194-90	H8
3195	H5

A3195	H5
3199W	H11
3705RC	H7
5760A	H12
5760B	H12
5760C	H12
5760D	H12
5760S	H12
5760Z	H12
5761A	H12
5761B	H12
5761C	H12
5761D	H12
5763D	H9
C5763N	H7
5764A	H9
5764B	H9
5764C	H9
5764D	H9
5764E	H9
A5764D	H9
A5764E	H9
A5764W	H9
5765D	H9
5765E	H9
5765F	H9
5765M	H9
5765PR	H7
A5765C	H9
A5765D	H9
A5765E	H9
A5765F	H9
C5765N	H7
5766E	H9
5766F	H9
5767F	H9
5767G	H9
5767H	H9
5767M	H9
A5767F	H9
C5767N	H7
5768G	H9
5768H	H9
5768J	H9
A5768H	H9
5769H	H9
5769H	H10
5769HVB	H10
5769J	H9
5769K	H9
5769K	H10
5769M	H9
5769M	H10
5769VSS	H10
A5769H	H9
A5769K	H9
C5769N	H7
5776	H8
A5776	H8
7141FP	H8
A7571LA	H4
A7571LB	H4
A7575L2	H4
A7575L3	H4
A7575L4	H4
A7575L5	H4
7576	H13
7577V	H7
A8016-9P	H8
A8016-93	H8
10538P	H7
12982	H11
12982G	H11
15774-1	H12



LP-Gas & Anhydrous Ammonia Equipment

Section J Miscellaneous Equipment (Including Rotogages and ESVs)

J

Limited Warranty and Limitation of Liability

LIMITED 10 YEAR WARRANTY AND LIMITATION OF LIABILITY

LIMITED 10 YEAR WARRANTY

REGO® warrants to the original purchasers the products and repair kits manufactured by it to be free from defects in materials and workmanship under normal use and service for a period of 10 years from the date of manufacture. If within thirty days after buyer's discovery of what buyer believes is a defect, buyer notifies in writing and ships the product to REGO® at 100 Rego Drive, Elon, NC 27244, REGO®, at its option, and within forty-five days of receipt, will repair, replace F.O.B. point of manufacture, or refund the purchase price of that part or product found by REGO® to be defective. Failure of buyer to give such written notice and ship the product within thirty days shall be deemed an absolute and unconditional waiver of any and all claims of buyer arising out of such defect.

This warranty does not extend to any product or part that is not installed and used continuously after installation in accordance with REGO®'s printed instructions, all applicable state and local regulations, and all applicable national standards, such as those promulgated by NFPA, DOT and ANSI. This warranty does not extend to any product or part that has been damaged by accident, misuse, abuse, failure to maintain, or neglect, nor does it extend to any product or part which has been modified, altered, disassembled, or repaired in the field. This warranty does not cover any cosmetic issues, such as scratches, dents, marring, fading of colors or discoloration.

Except as expressly set forth above, and subject to the limitation of liability below, REGO® MAKES NO OTHER WARRANTY, EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, with respect to its products and parts, whether used alone or in combination with others. REGO® disclaims all warranties not stated herein.

LIMITATION OF LIABILITY

REGO®'s total liability for any and all losses and damages arising out of any cause whatsoever shall in no event exceed the purchase price of the products or parts in respect of which such cause arises, whether such cause be based on theories of contract, negligence, strict liability, tort or otherwise.

REGO® shall not be liable for incidental, consequential or punitive damages or other losses. REGO® shall not be liable for, and buyer assumes any liability for, all personal injury and property damage connected with the handling, transportation, possession, further manufacture, other use or resale of products, whether used alone or in combination with any other products or materials.

From time to time buyers might call to ask REGO® for technical advice based upon limited facts disclosed to REGO®. If REGO® furnishes technical advice to buyer, whether or not at buyer's request, with respect to application, further manufacture or other use of the products and parts, REGO® shall not be liable for such technical advice or any such advice provided to buyer by any third party and buyer assumes all risks of such advice and the results thereof.

NOTE: Some states do not allow the exclusion or limitation of incidental, consequential or punitive damages, so the above limitation or exclusion may not apply to you. The warranty gives you specific legal rights, and you may have other rights that vary from State to State. The portions of this limited warranty and limitation of liability shall be considered severable and all portions which are not disallowed by applicable law shall remain in full force and effect.

NOTICE TO USERS OF PRODUCTS

The Limited Warranty stated above is a factory warranty to the first purchasers of REGO® products. Since most users have purchased these products from REGO® distributors, the user must within thirty (30) days after the user's discovery of what user believes is a defect, notify in writing and return the product to the distributor from whom he purchased the product/part. The distributor may or may not at the distributor's option choose to submit the product/parts to REGO®, pursuant to this Limited Warranty. Failure by buyer to give such written notice within thirty (30) days shall be deemed an absolute and unconditional waiver of buyer's claim for such defects. Acceptance of any alleged defective product/parts by REGO®'s distributor for replacement or repairs under the terms of REGO®'s Limited Warranty in no way determines REGO®'s obligations under this Limited Warranty.

Because of a policy of continuous product improvement, REGO® reserves the right to change designs, materials or specifications without notice.

Foreword

This catalog describes a complete line of equipment available from REGO® for use with LP-Gas and anhydrous ammonia (NH₃). The following points are important to know for proper use of the catalog:

1. Illustrations and drawings of individual products are representative of “product groups” and all products within a product group are similar in construction.
2. Materials used for construction of products in this catalog are suitable for rated service pressure at temperatures of -40° F. to +165° F., unless otherwise specified.
3. Products in this catalog are only intended for use in LP-Gas and/or anhydrous ammonia service as follows.
 - a. “A” or “AA” prefix — Products with this prefix are suitable for NH₃ service (i.e., contain no brass parts).
 - b. “AA” prefix on relief valves — These valves are NOT suitable for use with LP-Gas service. These are of partial aluminum materials and are listed by Underwriters Laboratories (UL) for NH₃ service only.
 - c. All other products are suitable for use with LP-Gas service.
 - d. “SS” prefix—Hydrostatic relief valve with this prefix are suitable for NH₃ service (i.e., they have stainless steel materials).

Caution

Do not use any product contained in this catalog with any service commodity other than LP-Gas or NH₃. If you have a need for use of another application, contact REGO®, 100 RegO Drive, Elon, NC 27244, (336) 449-7707 before proceeding.

Proper application, installation and maintenance of products in this catalog are essential. Users of these products should obtain further information if there are any doubts or questions.

Warning

All REGO® products are mechanical devices that will eventually become inoperative due to wear, corrosion and aging of components made of materials such as rubber. The environment and conditions of use will determine the safe service life of these products. Periodic inspection and maintenance are essential to avoid serious injury and property damage.

Many REGO® products are manufactured for storage, transport, transfer and use of toxic flammable and dangerous liquids and gases. Such substances should be handled by experienced and trained personnel only, using accepted governmental and industrial safety procedures. Never vent LP-Gas near any possible source of ignition.

Notice

Installation, usage, and maintenance of all REGO® products must be in compliance with all REGO® instructions as well as requirements and provisions of NFPA #54, NFPA#58, DOT, ANSI, and all applicable federal, state, provincial and local standards, codes, regulations, and laws.

Inspection and maintenance on a periodic basis is essential. Installation and maintenance should be performed only by qualified personnel.

Be sure all instructions are read and understood before installation, operation and service.

Filters

REGO® LP-Gas equipment is designed to operate in a system free from contamination. A variety of in-line filters are commercially available to the LP-Gas industry for installation in domestic systems.

The use of an in-line filter should be considered when other system components may be unclean and the system contaminated by rust, scale, dirt, debris or other foreign material.

Contents

Page

Combination Valve.....	J17
Cross Reference by Part Number	J21
Cylinder Filling Systems	J15
Emergency Shut-Off Valves (ESVs)	J8/J11
ESV Accessories	J12
Fixed Liquid Level Gauges	J18
Gas Alarms and Detectors.....	J20
Gritrol Filters.....	J17
Hose-End Adapters	J15/J16

Needle Valves.....	J20
Pressure Gauges.....	J19
Pull-Away Valves.....	J7
Quick Connect POL Filling Adapters	J19
Rotogages®	J4/J6
Sight Flow Indicators	J16
Spanner Wrench.....	J22
Vent Valves.....	J21

1" Rotogages® for Large Mobile and Stationary Containers A9090 Series

Application

Rotogages® are designed to provide an accurate determination of LP Gas or anhydrous ammonia container contents. They mount in a standard 1" NPT coupling on large mobile or stationary containers.

To operate the Rotogages®, the vent valve is opened and the dip tube rotated slowly from the container vapor space to the liquid space. The difference in appearance of the discharge indicates when the liquid level is reached. Dial readings then indicate the percentage of product in the container.

Features

- Supported design (TS Models) eliminates whipping and the need for internal support hangers.
- Resistance-free nylon bearing inserts reduce friction and promote operating ease.
- Dial face is dual calibrated to provide greater accuracy in reading contents in containers which are not level.
- Interchangeable accessory dials permit interchangeable service between LP-Gas and anhydrous ammonia.



Rotogage® Assembly

Materials

Body	Steel
Stem	Steel
Dip Tube	Seamless Steel
Indicator	Malleable Iron
Dial Plate	Aluminium
Vent Stem	Stainless Steel



Tubes for use with A9090 Series Roto Gauges Cut to length required.

Service	Part Number
Up to 48"	A9091-M24.0
Up to 72"	A9091-M36.0
Up to 96"	A9091-M48.0
Up to 120"	A9091-M60.0
Up to 144"	A9091-M72.0



A9091-18LX

Rotogage® Dials


Ordering Information

Part Number	Service	Container Size
A9091-18L	LP-Gas	All Sizes
A9091-18LX*	LP-Gas	Over 1200 U.S. gallons
A9091-18N	NH3	All Sizes


* Dial permits higher filling level, per NFPA 58,

1" Rotogages® for Large Mobile and Stationary Containers


For Small Mobile or Stationary Containers A9091R and A9092R Series





For Large Stationary Containers 9093RS, 9094RS and 9095RS Series



For Large Mobile or Stationary Containers A9093TS, A9094TS and A9095TS Series



Ordering Information

Part Number		For Container Inside Diameter			
					
		Ellipsoidal Heads		Hemispherical Heads	
For Mobile or Stationary Containers	For Stationary Containers Only	Side Mounted	End Mounted	Side Mounted	End Mounted
A9091R	-	30" - 45"	30" - 75"	30" - 45"	30" - 45"
A9092R	-	46" - 61"	76" - 108"	46" - 61"	46" - 61"
A9093TS*	A9093RS	62" - 79"	109" - 147"	62" - 79"	62" - 79"
A9094TS*	A9094RS	80" - 99"	-	80" - 99"	80" - 99"
A9095TS*	A9095RS	100" - 147"	-	100" - 147"	100" - 147"

* Supported Design

NOTE: The dip tube must be cut to the required length (1/2" of container inside diameter minus 5 3/4").

3/4" Rotogages® for Small Stationary and Mobile LP-Gas Containers 2070 Series

Application


Rotogages® are designed to provide accurate determination of LP-Gas container contents. They may be end or side mounted in a standard 3/4" NPT coupling on stationary or mobile containers. To guarantee accurate measurement, they should not be used on stationary containers that exceed 60" I.D. or on mobile containers, subject to vibration, with an I.D. of more than 24".

Features

- Provides long, trouble-free performance and ease of operation.
- Polished stems assure bind-proof operation.
- Dial face is dual calibrated to provide greater accuracy in reading contents in containers which are not level.

Materials

Body Brass
Stem Brass Tubing
Dip Tube Seamless Brass Tubing
Dial Plate Aluminium
Indicator Malleable Iron




2070 Series


2070 Series Rotogage® Mounting Positions




End at Center Line




Side at Maximum Filling Level



Side at Center Line



Recessed in Side at Center Line



Ordering Information

Part Number		For Containers with Inside Diameter	Tank Connection	Valve Seat Orifice
Rotogage®	Dip Tube			
2070C0	2071-L25.7	Up to 40"	3/4 M. NPT	No. 54 Drill Size
	2071-L39.7	Up to 60"		

NOTE: The dip tube must be cut to the required length ($\frac{1}{2}$ of container inside diameter minus $\frac{1}{2}$ "), when mounted on center line of tank.

Pull-Away Valves for Transfer Operations

A2141 Series

Application

Designed especially to provide pull-away protection for LP-Gas and anhydrous ammonia transfer operations including transport and delivery truck loading and unloading, engine fuel container filling and miscellaneous cylinder filling operations. When properly fastened to the inlet end of the discharge hose, the valve is designed to stop gas escape from both upstream and downstream lines in the event of a pull-away. An excessive tension pull causes the valve to automatically separate, closing two internal back pressure checks. Only a few cubic centimeters of gas escape at the instant of separation.

It is recommended that a convenient means be provided to safely remove the pressure from the line upstream of each coupling half to enable reassembly of the valve. To reassemble, simply push the male half firmly into the female half until the retaining balls slip into the retaining groove. Check for leaks after reassembly.

NOTE: It is recommended that pull-away valves be maintained and safety tested periodically to confirm that they will separate properly in the event of a pull-away. Lubrication **every six months** is essential to the pull-away's operation. Dry nitrogen or other inert gas is suggested as a source of pressure for pull-away tests.


If the A2141 pull-away valve is going to be stored for a period of time, A2141 Series such as in seasonal applications, it is recommended that it be sprayed with a good grade of rust-preventive machine oil, and covered to protect it from moisture.

Materials

Body (¾", 1").....	Cadmium Plated Steel
Body (1¼", 2").....	Cadmium Plated Steel
Seals.....	Buna-N Rubber
Cables	Nylon Coated, Galvanized Steel




A2141A6



A2141A10


Features

- Heavy-duty construction for long service life.
- A "true" pull-away type valve which simply reconnects by snapping together without unnecessary downtime or need for new parts.
- Buna-N seals provide leak tight operation.
- 400 PSIG operating pressure.



A2141A6
A2141A8

A2141A6L
A2141A8L



A2141A16

A2141A10



Ordering Information

Part Number	Inlet/Outlet Connections NPT F.	Disconnect Force Approx.-lbs	Reconnect Force Approx.-lbs	Length Of Valve	LP-Gas Liquid Flow Capacity at Various Differential Pressures (GPM)*			
					5 PSIG	10 PSIG	25 PSIG	50 PSIG
A2141A6	¾"	130	80	3¾"	11	16	25	36
A2141A6L**								
A2141A8	1"	75	50	4⅞"	21	30	47	67
A2141A8L**								
A2141A10	1¼"	160	25	5⅞"	52	75	120	170
A2141A16	2"	300	50	14⅞"	250	350	550	750

* To Determine NH₃ liquid flow capacity, multiply by .90.

LP-Gas Emergency Shut-Off Valves (ESV's)

Why and how they should be used for Bobtail Filling and Transport Unloading.

General Information

The primary purpose of Emergency Shut-Off Valves in bobtail filling and transport unloading is to allow quick shut-off of liquid and vapor flow in the event there is an accidental pull-away of a truck or a hose rupture, both of which could cause a fire.

A system using Emergency Shut-Off Valves will not prevent some spillage of liquid and vapor, but the total system should be constructed so this spillage will be kept to a minimum.

This can be accomplished either by making possible, quick action by the driver or plant personnel in closing the valves by manual remote or pneumatic remote actuation; or in case of a pull-away, by automatic closing of the liquid valve by means of a cable connected to the liquid hose.

By minimizing the presence of liquid and vapor, the chance of a fire or explosion will be reduced. In case of a fire, thermal links at the valves or at other appropriate locations could close the valves and prevent further release of liquid and vapor.

The valve closing systems will be discussed later in this section. The user should decide which system is most appropriate, depending on the piping configuration and the general layout of the filling/unloading area.

ESV Application for Bobtail Loading and Transport Unloading

A very important function of the typical LP-Gas storage plant is to transfer LP-Gas into bobtails for delivery to customers. How efficiently and rapidly these bobtails can be filled often determines the number of customers that can be served each day, as well as how many bobtails are required to satisfactorily serve all customers. Therefore, the selection of an ESV for the bobtail liquid loading line should be done with care so as to maximize efficiency in filling and have year-round dependability.

The RegO® 2" liquid ESV (6016) has a full open port so that the restrictions of flow would be no more than you would expect through an equivalent length of 2" schedule 80 pipe. To improve the overall efficiency of the system, the valve was also designed as an operating valve so it could replace an existing globe or angle valve already installed at the end of the fixed piping. Thus, installing a RegO® ESV could actually result in a more efficient pumping operation than the existing system.

Equally important in the consideration of an ESV is its performance in an emergency, especially bobtail pull-aways. According to the NPGA, it is the bobtail filling transfer process that produces almost 99% of all bulk plant accidents and fires. Therefore, when selecting the proper ESV for bobtail filling, also consider the dependability of performance, and simplicity of operation and maintenance.

The RegO® ESV clearly indicates to the operator its open or closed position. It allows full manual control by the operator and provides means for remote operation in emergencies from either in front of the valve or in the rear.

No complicated systems of pulleys and cables are necessary since direct, straight pulls will close the valve. Means are even provided to secure a length of cable to the transfer hose so as to produce an automatic closing in the event the driver pulls away without disconnecting the hose.

NFPA Provisions (1986)

The pertinent provisions of NFPA Pamphlet 58, as they apply to Emergency Shut-Off Valves and how they are to be installed, are as follows:

Section 2-4.5.4 Emergency shutoff valves shall be approved and incorporate all the following means of closing:

(a) Automatic shutoff through thermal (fire) actuation. When fusible elements are used they shall have a melting point not exceeding 250° F. (121° C).

(b) Manual shutoff from a remote location.

(c) Manual shutoff at the installed location.

This provision sets for the basic criteria for the emergency shutoff valve, a key valve in the protection of many liquid transfer operations. Actuating means for remote control may be electrical, mechanical or pneumatic.

Many systems use a pneumatic system where the tubing itself acts as a fusible element releasing the pressure holding the valve open. With respect to the feature of manual shutoff at the installed location, it is recommended that this valve be operated occasionally. Also, the system should be tested periodically to determine that it will function properly.

Section 3-2.7.9 on new installations, and by December 31, 1980 on existing installations, (1) stationary single container systems of over 4,000 gal. (15.1 m³) water capacity, or (2) stationary multiple container systems with an aggregate water capacity of more than 4,000 gal. (15.1 m³) utilizing a common or manifolded liquid transfer line, shall comply with 3-2.7.9 (a) and (b).

(a) When a hose or swivel type piping 1½" or larger is used for liquid transfer or a 1¼" or larger vapor hose or swivel type piping is used in this service (excluding flexible connectors in such liquid and vapor piping), and emergency shutoff valve complying with 2-4.5.4 shall be installed in the fixed piping of the transfer system within 20 ft (6m) of lineal pipe from the nearest end of the hose or swivel type piping to which the hose or swivel type piping is connected. The preceding sizes are nominal. Where the flow is only in one direction, a backflow check valve may be used in lieu of an emergency shutoff valve if installed in the fixed piping down-stream of the hose or swivel type piping, provided the backflow check valve has a metal-to-metal seat or a primary resilient seat with a secondary metal seat not hinged with combustible material. When either a liquid or vapor line has two or more hoses or swivel type piping of the sizes designated, either an emergency shutoff valve or a backflow check valve shall be installed in each leg of the piping.

(1) Emergency shutoff valves shall be installed so that the temperature sensitive element in the valve, or a supplemental temperature sensitive element [250° F. (121° C) maximum] connected to actuate the valve, is not more than 5 ft. (1.5 m) from the nearest end of the hose or swivel type piping connected to the line in which the valve is installed.

(b) The emergency shutoff valve(s) or backflow check valve(s) specified in 3-2.7.9 (a) shall be installed in the plant piping so that any break resulting from a pull will occur on the hose or swivel type piping side of the connection while retaining intact the valves and piping on the plant side of the connection. This may be accomplished by use of concrete bulkheads or equivalent anchorage or by the use of a weakness or shear fitting. Such anchorage is not required for tank car unloading.

These provisions have been interpreted by the National Propane Gas Association as to how bobtail filling and transport unloading stations should be configured. The diagrams shown here are in essential conformance with NPGA Bulletin 128-77.

LP-Gas Emergency Shut-Off Valves (ESV's)




FIGURE 1A
Bobtail Filling Only




FIGURE 1B
Transport Unloading Only




FIGURE 1C
Combined Bobtail Filling
and Transport Unloading

Installation Compliance with NFPA Requirements

A valve that is approved as an ESV may be installed in the fixed piping up to a distance of 20 feet (along the pipe) from the point where the transfer hose is attached to the fixed piping.

However, when the ESV is located more than five feet from the end of the fixed piping, an additional fusible element must be installed within five feet of the point of attachment of the hose, and be connected to the ESV valve in such a manner that it will cause the ESV to close in the event of a fire.

The ideal location of the ESV is as close to the end of the fixed piping as possible. This position eliminates the need for an additional fusible element and cable, and it may also permit the elimination of a restrictive valve already installed at the end of the fixed piping.

To this point, our comments have been principally concerned with ESV protection of the liquid line at bulk plants because this is the area of greatest potential danger in the event of a pull-away or hose rupture.

However, regulations also require an ESV in the vapor transfer line when the vapor hose is 1½" or larger. A helpful rule of thumb in determining whether or not an ESV control valve is required in your

vapor system is this: If the vapor flow is out of the storage tank, an ESV is required. ESV systems are designed to protect the storage tank contents against uncontrolled release.

Therefore, a bobtail loading system could use a 1¼" or larger back pressure check valve in the vapor system since the flow of vapor is always from the bobtail being filled back to the storage tank. To improve transfer rates, the use of the RegO® 6586D back check valve at this location would provide protection at minimum pressure drop.

If the bobtail vapor line is also used when unloading transports, then the RegO® 6010 ESV should be used. The 6010 provides thermal protection, manual closing and a remote emergency closing system similar to the RegO® 2" liquid ESV, 6016.

Remote Control Systems

Usually in transfer loading operations, the valve handles and cables are located in close proximity to the area of greatest potential danger during an emergency. Therefore, each bobtail filling system or transport unloading system should have installed in it at least one readily accessible, alternate remote operating device.




Figure 2
RegO® ESV's with Remote Pneumatic
and Transfer Hose Cable Release
Systems Typical Installation

6010, 6016, 6024 ESVs

2" & 3" Swing-Check ESVs for Bulk Plants 6016 Series and 6024 Series

Application

Designed for installation in liquid transfer lines at LP-Gas or Anhydrous Ammonia bulk plants to provide for quick shut-off of liquid or vapor flow in the event of an accidental pull-away, line break, or hose rupture.

Features


- Fusible Element is located in the thermal fuse assembly which acts at the latch open and close trigger. When exposed to fire, the element melts at 212 degrees F. allowing the shaft to return to the closed position.
- Valve can be opened by use of operating lever, if a pneumatic actuator is used it will open with the actuator.
- Valve can be closed by remote cable or pneumatic actuator.
- Valve can be closed by simply pushing the operating lever down, it is not necessary to trip the close trigger.
- Seat Disc is retained by a metal seat to minimize leakage in case direct fire impingement.
- Straight through design allows for a liquid flow of 230 GPM (LPG) with only a 1 psig drop. (6016)
- Quick closing regardless if the pump is running or not.

Sturdy Rugged Construction

- Will withstand hydraulic shock of sudden closings, piping strains, and temperature variations.
- Valve has only two moving parts, stem and close/thermal trigger.
- 6016 is UL listed for use in LP-Gas as an emergency and operating shut-off valve.
- Stem seals are spring loaded for leak free performance at low temperatures/pressures.

Materials

Body Ductile Iron Cad Plated
Stem Stainless Steel
Seat Stainless Steel
Seat Disc (6016) High Temperature Viton
Seat Disc (AA6016) Synthetic Rubber
Springs Stainless Steel
Gaskets Teflon



Ordering Information

Part Number	For Use With:	Inlet and Outlet Connections	Liquid Flow Capacity at 10 PSIG Drop (GPM)
6016	LP-Gas	2" F-NPT	711 (LP-Gas)
AA6016	NH ₃	2" F-NPT	640 (NH ₃)
6024	LP-Gas	3" F-NPT	1325 (LP-Gas)
AA6024	NH ₃	3" F-NPT	1173 (NH ₃)

1¼" Swing-Check ESV for Bulk Plants 6010 and AA6010

Application

Designed for installation in liquid or vapor transfer lines at LP-Gas or Anhydrous Ammonia bulk plants to provide for quick shut-off of liquid or vapor flow in the event of an accidental pull-away, line break, or hose rupture.

Features

Meets NFPA 58 and UL requirements

- Fusible Element is located in the thermal fuse assembly, which acts at the latch open and close trigger. When exposed to fire, the element melts at 212 degrees F. allowing the shaft to return to the closed position.
- Valve can be opened by use of operating lever, if a pneumatic actuator is used it will open with the actuator.
- Valve can be closed by remote cable or pneumatic actuator.
- Valve can be closed by simply pushing the operating lever down; it is not necessary to trip the close trigger.

Sturdy Rugged Construction



- Will withstand hydraulic shock of sudden closings, piping strains, and temperature variations.
- Valve has only two moving parts, stem and close/thermal trigger.
- **6010** is UL listed for use in LP-Gas as an emergency and operating shut-off valve.
- Stem seals are spring loaded for leak free performance at low temperatures/pressures.
- Seat Disc is retained by a metal seat to minimize leakage in case direct fire impingement.
- Quick closing regardless if the pump is running or not.

Materials

Body Ductile Iron Clad Plated
Stem Stainless Steel
Seat Stainless Steel
Seat Disc High Temperature Viton (6010 only)
Seat Disc Synthetic Rubber (AA6010 only)
Springs Stainless Steel
Gaskets Teflon



6010



Ordering Information

Part Number	For Use With	Inlet and Outlet Connections	Accessories		Liquid Flow Capacity @ 10 PSIG Pressure Drop (GPM)
			Remote Pneumatic Close	Remote Pneumatic Open/Close	
6010	LP-Gas	1¼" F. NPT	6016-60D	6016-60C	259
AA6010	NH ₃	1¼" F. NPT			233

ESV Pneumatic Controls

Application

RegO® Emergency Shut-Off Valves modified for remote pneumatic shutdown operation retain all the operating features of the standard valves.

Once equipped with pneumatic cylinders and then pressurized, the pneumatic cylinder piston rod disengages from a striker plate, allowing the ESV to be manually opened and the striker plate to act as a latch and hold the valve open. Release of the control system pressure for any reason closes the ESV for fail-safe operation.

Features

Convenience


- Closes the liquid and vapor ESV from a convenient remote location.
- Independent closed loop system allows the ESV to be pneumatically charged, but opened or closed manually or with cable controls to conserve pressurized gas.

Reliability

- Independent closed loop system will continue to hold pressure and close ESV in an emergency - even if supply pressure is cut off.

Security

- Any loss of pressure from the control line, such as accidents or the line melting from fire, automatically shuts down the liquid and vapor ESV.
- ESV must be reset after automatic shutdown.



6016 with 6016-60D Remote Close Actuator



7605PN-50 Pneumatic Remote Control Kit

Control kit with components for connecting and charging the pneumatic controls from a source of compressed gas (air or nitrogen) to a RegO® liquid or vapor ESV. Includes charging valves with low pressure indicator, operating valves, 100 feet of 1/4" plastic tubing and tube fittings.



Ordering Information

Part Number	Description
7781AFPN-1	Cylinder assembly kit to convert 7781AF ESVs to pneumatic shutdown.
6016-60D	Cylinder assembly kit to convert 6016 ESVs to pneumatic shutdown.
7605PN-50	Pneumatic remote shutdown system kit, complete with 100' of tubing, fittings, 1 charging valve assembly and 1 remote shutdown valve assembly
7605APN-8A	Extra shutdown valve assembly
7605A-BT	100' roll of 1/4" pneumatic tubing.
7605AP-16	1/4" tubing tee, with nuts.
7605AP-15	1/8" NPT x 1/4" tubing, straight connector.

Hydraulic Automatic Cylinder Filling System

7194MD and 7194HD

Application

Designed to provide accurate, economical filling of LP-Gas DOT and fork lift cylinders by weight. Filling stops automatically as the total weight of the cylinder reaches the amount pre-set on the scale. One individual can efficiently handle up to four cylinder filling operations simultaneously, to maximize profits, increase efficiency and allow servicing of more customers.

The RegO® automatic cylinder filling system is designed for use with these scales only:

FAIRBANKS-MORSE SCALES

New Style - 1280A Double Beam Scale or Single Beam Scales 1124A and 1174A.

Old Style - 1280 Double Beam Scale or Single Beam Scale 1123 with or without Howe No. 12108 "Over or Under" Indicator.

HOWE SCALES

(with or without Howe No. 8325 Balance Indicator)

—No. 54X Wood Pillar and Shelf Scale.

—No. 57 Steel Pillar and Shelf Scale (single beam).

—No. 57X Steel Pillar and Shelf Scale (double beam).

Features


- Completely self-contained with no electrical source or wiring required.
- Works hydraulically, like brakes on a car.
- Filling stops automatically when cylinders reach pre-set weight.
- Up to four stations can be handled by one individual.

How It Works

The scale beam weight is adjusted to the desired filled weight and the empty cylinder is placed on the scale. The loading hose is connected to the cylinder valve, and the lever on the master cylinder is moved to the vertical position. When the quick-acting valve on the loading hose is opened, the cylinder will rapidly fill. The master cylinder lever is designed to trip, move to a horizontal position and automatically shut off the control valve as soon as the scale reaches the pre-set filled weight.

Components may be ordered separately with piping done by the installer. Two completely assembled manifold configurations are also available.

Hydraulic self-contained system.
No external power required.



Ordering Information Hydraulic System Components

Key No.	Description	Size	Part No.
Assembly for Fairbanks-Morse. Includes items 1 thru 8 below.			7194MD
Assembly for Howe. Includes items 1 thru 8			7194HD
1	Propane Control Valve	½" NPT Female, with ⅛" NPT Female Hydraulic Connection	7177
2	Master Cylinder, with Actuator Lever	⅛" NPT Hydraulic Connection	7188
3	Hydraulic Hose Assembly	⅜" I.D. with ⅛" NPT Male Ends, 43½" Overall Length	7194-1
1-3	Valve, Cylinder and Hose Assembly for Fairbanks-Morse Scales	-	7188MS
1-3	Valve, Cylinder and Hose Assembly for Howe Scales	-	7188HS
4A	Bracket Kit for Fairbanks Morse Scales, Complete with Screws, Washers, Nuts and Instructions	-	7194M-3A
4B	Bracket Kit for Howe Scales, Complete with Screws, Washers, Nuts and Instructions	-	7194H-3
5	Can of Hydraulic Fluid, Complete with Filling Spout	1½ ounce	7188-21
6	Propane Filling Hose Assembly	½" I.D., with ½" NPT Male Ends. 50½" Overall Length	7193D
7	Quick-acting Shut Off Valve	½" NPT INlet X ¼" NPT Outlet	7901TB
8*	Soft Nose Cylinder Connector	¼" NPT Male X POL Male	7193D-10

Sight Flow Indicators for Bulk Plants A7794 and A7796


Application

Designed to promote maximum pump efficiency, these indicators enable bulk plant operators to visually inspect liquid flow conditions. With glass on both sides of the indicator, flow can be observed from either side, even under some poor light conditions. The integral swing check also serves as a back-check valve to prevent reverse flow and product loss if the hose fails in a loading operation.

By installing an indicator on the upstream side of the plant pump, suction conditions can be observed and the pump speed adjusted to obtain the maximum possible flow rate without cavitation. Additionally, if an indicator is installed in the piping at the loading rack, just ahead of the loading hose, the operator can maintain a constant check on pump conditions.

Both installations are designed to allow for observation to provide maximum pump efficiency and assure safe plant pump operation.

In compressor operations a sight flow indicator installed in the liquid line will give a visual indication when the tank car or transport is emptied. Compressor operation can then be immediately reversed to start recovery of the vapor




A7794

Features

- Durable ductile iron body assures long, trouble-free operation with design working pressure of 400 PSIG.
- Glass is polished, ground and tempered after fabrication for maximum strength up to 2,500 PSIG.
- Set screws minimize loosening of glass retainer rings.
- O-ring glass seals provide for leak-tight operation.

Materials

Body Ductile Iron
Swing Check..... Stainless Steel
Check Seat Disc..... Resilient Synthetic Rubber
Glass Polished, Ground and Tempered
Tested to 2,500 PSIG.



Ordering Information

Part Number	A Inlet/Outlet Connections	B Length
A7794	2" F. NPT	5 1/4"
A7796	3" F. NPT	7 1/8"

Hose End Adapters for DOT Cylinder Filling 7193D-10 and 7193U-10

Application

Designed to provide quick and easy filling of DOT cylinders with POL or Type I connections. This adapter may be used with hydraulic and electric automatic systems or with manual systems in conjunction with a RegO® 7901TB Quick Acting Shut-Off Valve.



These filling connectors have an extended connection on the handwheel, which makes it possible to connect the loading hose to valves on cylinders with fixed collars. The handwheel is well outside the collar for easy operation.



7193U-10



7193D-10




Part Number	Applications	Inlet Connection	Outlet Connection	Materials
7193D-10	Filling of DOT Cylinders with POL Connections	1/4" M. NPT	M. POL (CGA 510)	Brass & Stainless Steel
7193U-10	Filling of DOT Cylinders with Type I Connections		Type 1 Connection (1 " M. ACME)	Brass

Connector for DOT Cylinder Filling Adapter 7193T-10

Application

The 7193T-10 Connector is designed for use on the 7193D-10 Filling Adapters. Connector allows quick connection to the Type I 15/16 M. ACME threads for operators that fill both POL and Type I valves.



7193T-10

Ordering Information

Part Number	Applications	Inlet Connection	Outlet Connection	Materials
7193T-10	Converts 7193D-10 Adapters from POL to a Type 1 Connection	M. POL CGA 510	Type 1 Connection (1 1/16" M. ACME)	Brass

Hose End Adapter for Lift Truck Cylinder Filling 7193L-10A

Application


The 7193L-10A is designed to provide quick and easy attachment of the filling hose to DOT cylinders equipped with RegO® 7141M check connectors.

The 1 1/4" ACME outlet threads facilitate rapid make-up. When connected, back-checks in the adapter and check connector automatically open. Low pressure drop between the two assures high filling rates. An integral check closes when disconnected, eliminating the need to close any valves manually to disconnect the charging hose.

Because a leak-tight seal is formed before the integral check opens or closes, product loss is kept to an absolute minimum when connecting or disconnecting the loading hose.



7193L-10A



Ordering Information

Part Number	Application	Inlet Connection	Outlet Connection	Body Material	Accessories
					Adapter
7193L-10A	Filling of Fork Lift Cylinders*	1/4" M. NPT	1 1/4" F. ACME	Brass	5760A

* The 7193L-10A is intended to be permanently attached to the filling hose.

A 5760A adapter enables the 7193L-10A to be attached to the POL connection on the 7193D-10 at regulator cylinder filling stations to allow for occasional filling of fork lift cylinders.

Lever Operated Hose End Adapter for Fork Lift Cylinder Filling 7193K-10B

Application

Designed to drastically reduce labor and time when continuously filling large numbers of lift truck cylinders equipped with RegO® 7141M check connectors.


Rapid make-up is accomplished by simply slipping the adapter yoke behind the hex wrenching section of the 7141M connector and depressing the lever. When the cylinder is filled, the adapter is easily disengaged by releasing the operating lever. When connected, back checks in the adapter and connector automatically open. An integral check closes when disconnected, eliminating the need to close any valves manually on the filling manifold to disconnect the charging hose. The shut-off valve on the container must be closed after filling.

Because a leak-tight seal is formed before the checks close, product loss is kept to an absolute minimum when connecting or disconnecting the loading hose.

The 7193K-10B is intended to be permanently attached to the filling hose.



7193K-10B



Ordering Information

Part Number	Application	Inlet Connection	Outlet Connection	Materials
7193K-10B	Lever Operated for Quick Filling of Fork Lift Cylinders	1/4" F. NPT	Quick Disconnect Yoke*	Brass and Steel

* For use with RegO® 7141M check connector.

Combination Valve for Bulk Storage Containers A2805C

Application


Designed for installation on bulk storage containers, this valve combines a pressure gauge mounting and provision for a fixed tube liquid level gauge.

The shut-off valve prevents the pressure gauge from being subjected to constant pressure, thereby prolonging its life and accuracy. The valve may be closed, and the vent valve opened to vent pressure from the gauge to permit replacement.

For fixed liquid level gauging, the valve can be mounted at the maximum permitted filling level. When equipped with a dip tube threaded 1/8" M.NPT, it can be installed at any convenient level.

Materials

Body 2805C.....	Brass
Body A2805C.....	Ductile Iron
Bonnet.....	Steel
Valve Stem.....	Stainless Steel
Vent Stem.....	Stainless Steel
Valve Stem Seal.....	Resilient Synthetic Rubber
Vent Seal.....	Resilient Synthetic Rubber
Valve Seat.....	Nylon



Ordering Information


Part Number	Container Connection	Service Connection	Liquid Level Vent
A2805C	3/4" M. NPT	1/4" F. NPT for Gauge Mounting	Knurled*

* Has 1/8" F. NPT opening for installing separate dip tube.

Gritrol Fuel Line Filters 12802

Application

Designed especially for use in liquid motor fuel lines to trap foreign material which otherwise may damage precision components in the LP-Gas carburetion system. These filters incorporate an integral sintered metal filter element in a straight through design.



Ordering Information

Part Number	Inlet Connection	Outlet Connection
12802	1/4" F. NPT	1/4" M. NPT

Vent Valves 3165C, 3165S and TSS3169

Application

Especially designed to bleed off liquid or vapor pressures trapped in transfer lines. When installed in the downstream boss of RegO® globe and angle valves used at the end of a liquid transfer hose, the bleeder valve allows for the controlled venting of the product and indicates to the operator that the valves are closed and he can disconnect the coupling. They may also be used as a fixed liquid level gauge where the dip tube is part of the container.


All these valves incorporate a No. 54 drill size orifice.

An optional instruction plate with "Stop Filling When Liquid Appears" may be ordered for use with these valves.

Materials



Body (3165).....	Brass
Body (TSS3169).....	Stainless Steel
Seat Disc (3165).....	Resilient Synthetic Rubber
Seat Disc (3169).....	Teflon



Ordering Information

Part Number	Service	Connection	Actuation	Accessories
				Warning Plate Kit
3165C	LP-Gas Only	1/4" M. NPT	Knurled	2550-40P
3165S			Slotted	
TSS3169	LP-Gas & NH ₃		Tee Handle	

Fixed Liquid Level Gauges 3165 Series and TA3169F

Application

Especially designed to provide a visible warning when containers are filled to the maximum permitted filling level. At the start of the filling operation, with the vent stem opened, the valve discharges vapor. When the maximum permitted filling level is reached, the valve discharges liquid. These valves are normally furnished with a 12", 3/16" O.D. dip tube and incorporate a No. 54 drill size orifice.

An optional instruction plate with "Stop Filling When Liquid Appears" may be ordered for use with these valves.




3165SF12.0



TA3169F12.0

Materials

Body (3165).....	Brass
Body (TA3169).....	Stainless Steel
Seat Disc (3165).....	Resilient Synthetic Rubber
Seat Disc (TA3169)	Teflon



Ordering Information

Part Number	Service	Connection	Actuation	Dip Tube Length	Accessories
					Warning Plate Kit
3165CF*	LP-Gas Only	1/4" M. NPT	Knurled	*	2550-40P
3165CF12.0			Slotted	12"	
3165SF12.0					
TA3169F12.0	LP-Gas & NH3		Tee Handle		

Spanner Wrench for ACME Connectors 3195-50

Application

This aluminum spanner wrench is especially designed for use with 2¼" and 3¼" ACME couplings, adapters and caps.



3195-50



Ordering Information

Part Number	For Use With ACME Connector Size
3195-50	2¼" & 3¼"

Pressure Gauges

Application

Especially designed in a variety of sizes and construction for the LP-Gas and anhydrous ammonia industry.

All RegO® pressure gauges have a ¼" M. NPT connection unless otherwise noted.



Ordering Information

Part Number	Service	Case Material	Maximum Pressure	Case Size	Increment Divisions
2434A-2*	LP-Gas Only	Steel	35" w.c. and 20 oz. (Dual)	2½"	1" w.c. and 1 oz.
2434-2**			30 PSIG	2"	½ PSI
3226A-3					
2411					
5575		60 PSIG	1 PSI		
5547					
5576		100 PSIG	2 PSI		
1286					
948		300 PSIG	2"	5 PSI	
612**					
948B					
A8060	NH ₃ and LP-Gas	Steel	60 PSIG	2½"	5 lb.
A8150			150 PSIG		
A8400			400 PSIG		

* 1/4" Hose Connection
** 1/8" M. NPT Connection

Needle Valves 1224, 1316 and 1318

Application


These valves are high quality, "true" throttling valves. Unlike most so-called needle valves, both the body seat and stem are tapered to provide fine, precise control over a wide range of adjustment without stem galling.

The 1224 may be used as a small, inexpensive shut-off valve between a pressure gauge and bulk storage container to allow for convenient gauge replacement.

The 1316 and 1318 provide taper pipe thread by left hand hose connection threads and are useful in a wide range of torch and fuel burner applications where an accurate throttling action is required.



1224



Ordering Information

Part Number	A. Inlet Connection	B. Outlet Connection	C. Height	D. Length
1224WA	1/4" M. NPT	1/4" M. NPT	1 9/16"	1 1/4"
1314WA	9/16" - 18 L.H.	1/8" M. NPT		
1316WA		1/4" M. NPT		

Household Gas Detector/Alarm 100-HGD

Application

The 100-HGD gas fume detection/alarm unit gives advance warning of gas leaks well below the hazard level (1/4th the lowest explosive level). It provides the homeowner more time to take action to protect the family and remedy the problem.

Features

- Available in attractive high impact plastic housing.
- Fume detection systems are reliable and a snap to install.
- Early warning: a high pitched audio alarm and red light visual alarm is activated when propane fumes reach a level of only 1/4 the danger level.
- Built in power filtering system for protection against power fluctuations.
- Every semiconductor sensor unit is properly acclimatized and custom calibrated to the individual circuitry in which it is installed to ensure maximum sensitivity, reliability and accuracy.
- Solid state electronic circuitry.
- Supplied with CSA approved converter for use with standard 110 volt outlets.

Unit Specifications


Height 3 3/4"
Width 5 3/4"
Depth 1 3/8"



100-HGD



Typical Installation



Ordering Information

Part Number	Description
100-HGD	Household Propane Gas Alarm


Low Emission ACME Connector For Transports and Bobtails 6588LE & 6589LE

Application

Designed to provide fast filling of bobtails, transports and large bulk storage tanks while providing for low emission of LPG when disconnecting.

Features


- 3/4" Male Acme Connector with reduced emissions, 90% less than current ECII ACME adapters.
- 10.5 cubic centimeters of liquid discharged at disconnect
- UL Listed as a Filler Valve.
- Safety groove is designed to shear below ACME threads leaving the valve seat closed and unaffected if the vehicle pulls away with the hose connected.
- Seat disc is made of synthetic composition and is mechanically held in place by a seat disc retainer.
- Stainless Steel return spring.
- One- piece poppet stem for smooth operation.
- Will connect to any standard female 3/4" ACME adapter.
- Hydrostatic relief valve included (3125L).



6589 Series

Materials

Upper Body.....	Brass
Lower Body.....	Brass
Poppet & Stem Assembly	Brass
Spring	Stainless Steel
Gasket	Resilient Synthetic Rubber
Seat Disc	Resilient Synthetic Rubber



6588 Series

Ordering Information

Part Number	ACME Connection	Outlet Connection M.NPT	Wrench Flats	Hydrostatic Relief Valve	Propane Capacity at Various Differential Pressures (GPM)		
					5 PSIG	10 PSIG	25 PSIG
6588LE	3/4"	2"	3"	3125L	138	223	349
6589LE	3/4"	3"	3 1/4"	3125L			

Cross Reference by Part Number

100-HGD	J20	7188-21	J13
612	J19	7193D	J13
948	J19	7193D-10	J13
948B	J19	7193D-10	J15
1224WA	J20	7193K-10B	J16
1286	J19	7193L-10A	J16
1314WA	J20	7193T-10	J15
1316WA	J20	7193U-10	J15
2070CO	J6	7194HD	J13
2071-L25.7	J6	7194MD	J13
2071-L39.7	J6	7194-1	J13
A2141A6	J7	7194H-3	J13
A2141A6L	J7	7194M-3A	J13
A2141A8	J7	7605A-BT	J12
A2141A8L	J7	7605APN-8A	J12
A2141A10	J7	7605AP-15	J12
A2141A16	J7	7605AP-16	J12
2411	J19	7605PN-50	J12
2434-2	J19	7781AFPN-1	J12
2434A-2	J19	A7794	J14
A2805C	J17	A7796	J14
3165C	J18	7901TB	J13
3165CF	J18	A8060	J19
3165S	J18	A8150	J19
3165CF12.0	J18	A8400	J19
3165SF12.0	J18	A9091R	J5
TSS3169	J18	A9091-18L	J4
TA3169F12.0	J18	A9091-18LX	J4
3195-50	J19	A9091-18N	J4
3226A-3	J19	A9091-M24.0	J4
6010	J11	A9091-M36.0	J4
AA6010	J11	A9091-M48.0	J4
6016	J10	A9091-M60.0	J4
AA6016	J10	A9091-M72.0	J4
6016-60D	J12	A9092R	J5
6024	J10	A9093RS	J5
AA6024	J10	A9093TS	J5
7177	J13	A9094RS	J5
7188	J13	A9094TS	J5
7188HS	J13	A9095RS	J5
7188MS	J13	A9095TS	J5

REGGO

www.regoproducts.com

REGGO ONLINE
www.regoproducts.com

• Distributor Information • Service Manuals
• Application Guides • Product Literature
• Product Updates • Technical Guides

Catalog L-500



Printed in the USA 09-0111-0788

100 RegO Drive PO Box 247 Elon, NC 27244 USA Telephone (336) 449-7707 Fax (336) 449-6594